
# Physical Layer: Theory

#### Kameswari Chebrolu

All the figures used as part of the slides are either self created or from the public domain with either 'creative commons' or 'public domain dedication' licensing. The public sites from which some of the figures have been picked include: <a href="http://commons.wikimedia.org">http://commons.wikimedia.org</a> (Wikipedia, Wikimedia and workbooks); <a href="http://www.sxc.hu">http://www.sxc.hu</a> and <a href="http://www.pixabay.com">http://www.pixabay.com</a>

### Recap

- Nodes generate data (bits: 1's and 0's)
- Links carry signals in the form of electromagnetic waves
- Task on hand: Convert data into signals
  - Process termed: Encoding/Modulation
- First: Some Theory



#### **Link Characteristics**


- Data Rate: How many bits per second can be transferred on the link? (expressed in bps,kbps,Mbps,Gbps)
- Loss rate: What is the probability of packet error (or bit error) rate on the link?
- Delay: How much time does it take for the bits to reach other end?

# Simple Encoding

Data: 101111011


You Your Friend (Far Away)
Wire Pair
I will follow the wire, reach other
end and convey the data in person


How would you send the data over the wires?



# Signals and Bandwidth

 Fourier Analysis shows that any signal can be decomposed to sinusoids of different amplitude, frequency and phases





$$(4/\pi) \left[ \sin(2\pi f t) \right]$$


$$= \frac{1}{7}$$


$$(4/\pi) \left[ \sin(2\pi f t) + (1/3)\sin(2\pi (3f)t) \right]$$

$$f_{s} \approx f$$

$$(4/\pi) \left[ \sin(2\pi ft) + (1/3)\sin(2\pi(3f)t) + (1/5)\sin(2\pi(5f)t) \right]$$

$$(4/\pi) \left[ \sin(2\pi ft) + (1/3)\sin(2\pi (3f)t) + (1/5)\sin(2\pi (5f)t) + (1/7)\sin(2\pi (7f)t) \right]$$





earlier case, freq discrete: fourier series now continuous: fourier transform

Fourier Transform

### NRZ bandwidth


4 Data Rate

aperiodic.

Spectrum of a signal:
 Range of frequencies it contains

• Bandwidth: width of the spectrum " " Bw

– First Null Bandwidth = 1/T




Periode & operation?

Spectrum of a random NRZ signal


each bit is of duuration T... we are sending 1 bit per T sec in the cable.

#### Link Bandwidth

 How much link bandwidth do I need to recover signal?



Random NRZ Signal Bandwidth




# Nyquist Rate

- The number of independent pulses that could be put through a channel per unit time is limited to twice the bandwidth of the channel
- $f_p <= 2B$ 
  - f<sub>p</sub> is pulse rate (number of pulses/sec)
  - B is bandwidth of the channel
- Example: Binary pulse with rate 2000 bps needs link bandwidth of at least 1000 Hz

least band width needed to recover that pulse.

#### **Effect of Noise**



#### Shannon's Theorem

- Provides an upper bound to the capacity (bps) of a link
- $C = B \log_2 (1 + S/N)$  bits/sec
  - C: capacity (bps), B: channel bandwidth (Hz), S/N: signal to noise ratio
  - S/N often expressed in dB, 10log<sub>10</sub>(S/N)
    - E.g. 30dB corresponds to a ratio of 1000
- Example: Data over telephone line calculation
- B = 3300Hz 300Hz = 3000Hz; S/N = 1000 (30db); C ~ 30kbps

# **Implications**


- If R < C, there exists a coding technique which permits transmission of data with arbitrary small error
  - The theorem does not specify how to reach this bound
  - Real systems rarely achieve this upper bound
  - E.g. WiFi: 64-QAM Modulation operating in 20Mhz bandwidth needs SNR of 27dB for packet error rate under 10% to provide 54Mbps
    - R is 54Mbps rate, B is 20Mhz band,, C is 124Mbps
- If R > C, the probability of error increases without bound

#### **Error Rate**

- What is the probability of bit error on a link?
- Function of received SNR and type of modulation
- For a given modulation, charts of SNR vs BER are often provided

### Bit Error Rate (BER)

- Packet Error Rate
   (PER) = 1-(1-BER)<sup>N</sup>,
   where N is the size of
   packet in bits
  - BER 10<sup>-8</sup>, PER = 0.008%
- Typical BERs:
  - Wireless ~ 10<sup>-6</sup>,
     Twisted Pair ~ 10<sup>-8</sup>,
     Fiber-optics ~ 10<sup>-9</sup> to 10<sup>-12</sup>



# **Propagation Delay**

- Time required for a bit to propagate from beginning of link to end of the link
  - Depends on speed of light in the medium (S) & distance
     (D)
    - speed of light: 2\* 10<sup>8</sup> to 3 \* 10<sup>8</sup> m/s
  - Formula: D/S
- Note that Transmission delay(TD) is different from propagation delay
  - TD(sec) = Length of the packet (bits)/Data rate(bps)

Tx 
$$= 1 \text{Mbps} = 10^6 \text{ bps}$$
 $P = 1000 \text{ bits}$ 
 $P = 1000 \text{ bits$ 


RX

TX

1) = 2000 Km = 2 x 10 m

#### Goals of Modulation

- Bandwidth Efficiency: Data-rate/bandwidth-required, bps/Hz
   for recovery without errors.
  - Goal: Try to reach Shannon limit
  - Real Systems: Ranges from 0.001 to 16
- Power Efficiency: Energy per bit/N<sub>o</sub> better SNR ratio
  - N<sub>o</sub> is noise power spectral density
  - Goal: Minimize SNR required for a given BER
- Tradeoff bandwidth efficiency and power efficiency
  - Can achieve high BW only at the expense of more energy per bit
     means smaller bit intervals....unless u increase energy u cannot maintain same BER.



### Summary

- Signals and frequency domain representation (bandwidth they occupy)
- How many bits per sec can be sent on a link?
  - Upper bounded by Shannon theorem
  - In reality, depends on medium and modulation
- What is the packet error rate?
  - Function of BER which is determined by SNR and modulation
- Signal corresponding to a bit takes time to propagate
  - Propagation delay is function of speed of light in medium and distance
- Goals of Modulation