Router - fictional manual

router warranty: cracked case and broken screen on delivery are covered within 7 days. Photo and invoice required. Dented box alone is not covered. Normal wear and misuse are excluded.



Figure 1: Damage inspection diagram

Router - fictional manual

router return packing: power off, protect device, cushion in box and seal. Do not ship damaged batteries; contact support.



Figure 2: Device to protect before return