

Must Read Before Use

1.Set Up the Programming Environment

The installation and usage documentation for ACECode is located in the folder "English\ACECode(Beginner)\4.ACECode usage tutorial".

[Click here to obtain the installation steps for ACECode on Windows.](#)

[Click here to obtain the installation steps for ACECode on Mac.](#)

2. Battery Instructions

Due to logistics restrictions, we are unable to include the required batteries with the product. We sincerely apologize for any inconvenience this may cause.

This product requires **4 AAA dry batteries**, which you will need to provide yourself. Thank you for your understanding and support!

3.Special Note

Due to logistics issues, the motion-sensing gloves may arrive damaged. If you receive a damaged pair, you can refer to this video for self-repair: <https://youtu.be/LncNIY-BUHI>.

4.After-Sales Support

If you encounter any issues, please contact our support team via email at **support@acebott.com**, and we will respond within 24 hours. You can also scan the QR code below to follow us for troubleshooting guides and the latest updates.



ACEBOTT FB QR Code



YouTube QR Code