

SOLIDWORKS API (.NET VBA C#) — Reference

(4/337)

DModelViewEvents_DisplayModeChangePostNo-

DPartDocEvents_DynamicHighlightNotifyEve

SOLIDWORKS API Documentation (converted from CHM)

DModelViewEvents_DisplayModeChangePostNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DModelViewEvents_DisplayModeChangePostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_DisplayModeChangePostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the user program when a model view display mode is changed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_DisplayModeChangePostNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_DisplayModeChangePostNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_DisplayModeChangePostNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DModelViewEvents_DisplayModeChangePostNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayModeChangePostNotify_Event \(ModelView\)](#).

Example

Contact SOLIDWORKS API Support to obtain **Event Monitor for SOLIDWORKS 2012 (VBA)**.

Remarks

This event occurs after the display mode has been changed using [IModelDocExtension::DisplayMode](#).

If developing a C++ application, use [swViewDisplayModeChangePostNotify](#) to register for this notification.

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

DModelViewEvents_DisplayModeChangePreNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DModelViewEvents_DisplayModeChangePreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_DisplayModeChangePreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Pre-notifies the user program when a model view display mode is about to be changed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_DisplayModeChangePreNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_DisplayModeChangePreNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_DisplayModeChangePreNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DModelViewEvents_DisplayModeChangePreNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayModeChangePreNotify_Event \(ModelView\)](#).

Example

Contact SOLIDWORKS API Support to obtain **Event Monitor for SOLIDWORKS 2012 (VBA)**.

Remarks

This event occurs when the display mode is about to be changed using [IModelDocExtension::DisplayMode](#).

If developing a C++ application, use [swViewDisplayModeChangePreNotify](#) to register for this notification.

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

DModelViewEvents_GraphicsRenderPostNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DModelViewEvents_GraphicsRenderPostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_GraphicsRenderPostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired after all SOLIDWORKS graphics are drawn, including SOLIDWORKS model, sketch, dimension, and annotation graphics.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_GraphicsRenderPostNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_GraphicsRenderPostNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_GraphicsRenderPostNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DModelViewEvents_GraphicsRenderPostNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [GraphicsRenderPostNotify_Event \(ModelView\)](#).

Remarks

This event:

- is always fired after rendering to Layer2. Depending on optimization:
 - [RenderLayer0Notify](#) is fired when SOLIDWORKS renders to Layer0.
 - [BufferSwapNotify](#) is fired after rendering to Layer0.
- allows third-party applications to draw graphics in the SOLIDWORKS model window without worrying about SOLIDWORKS graphics being drawn over them.
- does not support depth buffering.

If developing a C++ application, use [swViewGraphicsRenderPostNotify](#) to register for this notification.

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

DModelViewEvents_PerspectiveViewNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DModelViewEvents_PerspectiveViewNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_PerspectiveViewNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the user program when the perspective view is changed (for example, if the user rotates the perspective view).

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_PerspectiveViewNotifyEventHandler( _  
    ByVal Left As System.Double, _  
    ByVal Right As System.Double, _  
    ByVal bottom As System.Double, _  
    ByVal Top As System.Double, _  
    ByVal zNear As System.Double, _  
    ByVal zFar As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_PerspectiveViewNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_PerspectiveViewNotifyEventHandler(  
    System.double Left,  
    System.double Right,  
    System.double bottom,  
    System.double Top,  
    System.double zNear,  
    System.double zFar  
)
```

C++/CLI

```
public delegate System.int DModelViewEvents_PerspectiveViewNotifyEventHandler(  
& System.double Left,  
& System.double Right,  
& System.double bottom,  
& System.double Top,  
& System.double zNear,  
& System.double zFar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Left

Coordinate of the left vertical clipping plane

Right

Coordinate of the right vertical clipping plane

bottom

Coordinate of the bottom horizontal clipping plane

Top

Coordinate of the top horizontal clipping plane

zNear

Distance to the near depth clipping plane

zFar

Distance to the far depth clipping plane

Visual Basic for Applications (VBA) Syntax

See [PerspectiveViewNotify Event \(ModelView\)](#).

Remarks

If developing a C++ application, use [swViewPerspectiveViewNotify](#) to register for this notification.

DModelViewEvents_PrintNotify2EventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DModelViewEvents_PrintNotify2EventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_PrintNotify2EventHandler Delegate (SolidWorks.Interop.sldworks)

Notifies the user program when a document is printed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_PrintNotify2EventHandler( _  
    ByVal pDC As System.Long, _  
    ByVal bPreview As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_PrintNotify2EventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_PrintNotify2EventHandler(  
    System.long pDC,  
    System.bool bPreview  
)
```

C++/CLI

```
public delegate System.int DModelViewEvents_PrintNotify2EventHandler(  
& System.int64 pDC,  
& System.bool bPreview  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

pDC

Pointer to the printer device context used to print the document (**see Remarks**)

bPreview

True to preview the document, false to not

Visual Basic for Applications (VBA) Syntax

See [PrintNotify2 Event \(ModelView\)](#).

Remarks

Always return S_OK in the swViewPrintNotify2 event handler.

If developing a C++ application, use [swViewPrintNotify2](#) to register for this notification.

pDC is the address of an MFC CDC instance, and it can be cast to a CDC*. C++ applications wanting to use this CDC* need to dynamically link to the MFC DLLs and use the same version of the Visual C++ compiler that SOLIDWORKS uses.

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

DModelViewEvents_PrintNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DModelViewEvents_PrintNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_PrintNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Obsolete. Superseded by [DModelViewEvents_PrintNotify2EventHandler](#).

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_PrintNotifyEventHandler( _  
    ByVal pDC As System.Long _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_PrintNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_PrintNotifyEventHandler(  
    System.long pDC  
)
```

C++/CLI

```
public delegate System.int DModelViewEvents_PrintNotifyEventHandler(  
& System.int64 pDC  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

pDC

HDC of the printer device context used to print the document

Visual Basic for Applications (VBA) Syntax

See [PrintNotify_Event \(ModelView\)](#).

Remarks

Always return S_OK in the swViewPrintNotify event handler.

If developing a C++ application, use [swViewPrintNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 SP2, Revision Number 15.2

DModelViewEvents_RenderLayer0NotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DModelViewEvents_RenderLayer0NotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_RenderLayer0NotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired whenever SOLIDWORKS renders to Layer0.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_RenderLayer0NotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_RenderLayer0NotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_RenderLayer0NotifyEventHandler()
```

C++/CLI

```
public delegate System.int DModelViewEvents_RenderLayer0NotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RenderLayer0Notify Event \(ModelView\)](#).

Remarks

This event allows you to render the model instead of SOLIDWORKS rendering the model. If the return value from the event is S_FALSE, then SOLIDWORKS will not render to Layer0, but will render to Layer1.

NOTE: When SOLIDWORKS renders to a frame, it renders two layers:

- Layer0: The model, usually shaded, but may be Fast HLR/LG and inactive sketch data.
- Layer2: Active sketch, annotations, and temporary graphic objects like the reference triad, View Orientation box, and the flyout FeatureManager design tree.

This event is not sent if [swViewRepaintNotify](#) returns S_FALSE. Also, if [swViewRenderLayer0Notify](#) returns S_FALSE, then [swViewBufferSwapNotify](#) is not sent.

[BufferSwapNotify](#) is fired after rendering to Layer0, depending on optimization. [GraphicsRenderPostNotify](#) is always fired after rendering to Layer2.

Prior to the event, the graphics area is cleared and the model view's xform is set.

If developing a C++ application, use [swViewRenderLayer0Notify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DModelViewEvents_RepaintNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DModelViewEvents_RepaintNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_RepaintNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Pre-notifies the user program when a view is about to be repainted and returns the paint type.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_RepaintNotifyEventHandler( _  
    ByVal paintType As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_RepaintNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_RepaintNotifyEventHandler(  
    System.int paintType  
)
```

C++/CLI

```
public delegate System.int DModelViewEvents_RepaintNotifyEventHandler(  
    & System.int paintType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

paintType

Valid paint type as defined in [swRepaintTypes_e](#) (only the first two types are supported)

Visual Basic for Applications (VBA) Syntax

See [RepaintNotify Event \(ModelView\)](#).

Remarks

Returns S_false to stop from proceeding with the action that caused the notification. This also prevents sending the IModelView [BufferSwapNotify](#) event.

If developing a C++ application, use [swViewBufferSwapNotify](#) to register for this notification.

Availability

SolidWorks 2001Plus FCS, Revision Number 10.0

DModelViewEvents_RepaintPostNotifyEventHandler (Type)

DModelViewEvents_RepaintPostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_RepaintPostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the user program when a view has been repainted.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_RepaintPostNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_RepaintPostNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_RepaintPostNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DModelViewEvents_RepaintPostNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [RepaintPostNotify Event \(ModelView\)](#).

Remarks

If developing a C++ application, use [swViewRepaintPostNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

DModelViewEvents_UserClearSelectionsNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DModelViewEvents_UserClearSelectionsNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_UserClearSelectionsNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when a user:

1. Clicks the right-mouse button when the pointer is over a selection box on a PropertyManager page.
2. Selects **Clear Selections** on the short-cut menu.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_UserClearSelectionsNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents\_UserClearSelectionsNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_UserClearSelectionsNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DModelViewEvents_UserClearSelectionsNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [UserClearSelectionsNotify_Event \(ModelView\)](#).

Remarks

If developing a C++ application, use [swViewUserClearSelectionsNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DModelViewEvents_ViewChangeNotifyEventHandler (Type)

DModelViewEvents_ViewChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DModelViewEvents_ViewChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the user program when a view is altered and returns the new transform matrix of the view.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Delegate Function DModelViewEvents_ViewChangeNotifyEventHandler( _  
    ByVal View As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DModelViewEvents_ViewChangeNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DModelViewEvents_ViewChangeNotifyEventHandler(  
    System.object View  
)
```

C++/CLI

```
public delegate System.int DModelViewEvents_ViewChangeNotifyEventHandler(  
& System.Object^ View  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

View
See Remarks

Visual Basic for Applications (VBA) Syntax

See [ViewChangeNotify Event \(ModelView\)](#).

Remarks

In Visual Basic for Applications (VBA), the view argument is a VARIANT of type SafeArray of 16 doubles:

Elements	Values
First 9	Standard 3x3 rotation matrix
Next 3	Define translation
Next 1	For scaling
Last 3	Not used

Your application is responsible for destroying the SafeArray when you are finished with it.

If developing a C++ application, use [swViewChangeNotify](#) to register for this notification.

Availability

DMouseEvents_MouseLBtnDbLClkNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DMouseEvents_MouseLBtnDbLClkNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseLBtnDbLClkNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the left-mouse button is double-clicked.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseLBtnDbLClkNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseLBtnDbLClkNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseLBtnDbLClkNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseLBtnDbLClkNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[X](#)

x coordinate of the pointer in the window space

[Y](#)

y coordinate of the pointer in the window space

[WParam](#)

Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseLBtnDbLClkNotify_Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseLBtnDbLClkNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseLBtnDownNotifyEventHandler (Type)

DMouseEvents_MouseLBtnDownNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseLBtnDownNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the left-mouse button is pressed down.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseLBtnDownNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseLBtnDownNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseLBtnDownNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseLBtnDownNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- X
x coordinate of the pointer in the window space
- Y
y coordinate of the pointer in the window space
- WParam
Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseLBtnDownNotify_Event \(Mouse\)](#).

Example

- [Run SOLIDWORKS Commands and Synthesize Mouse Events \(C#\)](#)
- [Run SOLIDWORKS Commands and Synthesize Mouse Events \(VB.NET\)](#)
- [Run SOLIDWORKS Commands and Synthesize Mouse Events \(VBA\)](#)

Remarks

If developing a C++ application, use [swMouseLBtnDownNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseLBtnUpNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DMouseEvents_MouseLBtnUpNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseLBtnUpNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the left-mouse button is released after being pressed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseLBtnUpNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseLBtnUpNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseLBtnUpNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseLBtnUpNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- [X](#)
x coordinate of the pointer in the window space
- [Y](#)
y coordinate of the pointer in the window space
- [WParam](#)
Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseLBtnUpNotify Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseLBtnUpNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseMBtnDbIClkNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DMouseEvents_MouseMBtnDbIClkNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseMBtnDbIClkNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the middle-mouse button is double-clicked.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseMBtnDbIClkNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseMBtnDbIClkNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseMBtnDbIClkNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseMBtnDbIClkNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[X](#)

x coordinate of the pointer in the window space

[Y](#)

y coordinate of the pointer in the window space

[WParam](#)

Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseMBtnDbIClkNotify_Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseMBtnDbIClkNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseMBtnDownNotifyEventHandler (Type)

DMouseEvents_MouseMBtnDownNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseMBtnDownNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the middle-mouse button is pressed down.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseMBtnDownNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseMBtnDownNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseMBtnDownNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseMBtnDownNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- [X](#)
x coordinate of the pointer in the window space
- [Y](#)
y coordinate of the pointer in the window space
- [WParam](#)
Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseMBtnDownNotify_Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseMBtnDownNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseMBtnUpNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DMouseEvents_MouseMBtnUpNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseMBtnUpNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the middle-mouse button is released after being pressed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseMBtnUpNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseMBtnUpNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseMBtnUpNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseMBtnUpNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[X](#)

x coordinate of the pointer in the window space

[Y](#)

y coordinate of the pointer in the window space

[WParam](#)

Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseMBtnUpNotify_Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseMBtnUpNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseMoveNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DMouseEvents_MouseMoveNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseMoveNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the mouse pointer is moved.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseMoveNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseMoveNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseMoveNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseMoveNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[X](#)
x coordinate of the pointer in the window space
[Y](#)
y coordinate of the pointer in the window space
[WParam](#)
Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseMoveNotify Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseMoveNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DMouseEvents_MouseNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired whenever a mouse event occurs.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseNotifyEventHandler( _  
    ByVal Message As System.Integer, _  
    ByVal WParam As System.Integer, _  
    ByVal LParam As System.Integer _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseNotifyEventHandler(  
    System.int Message,  
    System.int WParam,  
    System.int LParam  
    )
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseNotifyEventHandler(  
& System.int Message,  
& System.int WParam,  
& System.int LParam  
    )
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Message

Message to be sent

WParam

Additional message_dependent information

LParam

X, Y in a packed long requiring unpacking; see GET_X_LPARAM and GET_Y_LPARAM in MSDN for details on how to unpack LParam

Visual Basic for Applications (VBA) Syntax

See [MouseDown_Event \(Mouse\)](#).

Example

The following sample code shows a possible approach to decoding WParam and LParam.

```
'-----  
void NotifyHandler( UINT message, WPARAM wParam, LPARAM lParam)  
{  
    long x = GET_X_LPARAM(lParam); //Uses Windows macro  
    long y = GET_Y_LPARAM(lParam); //Uses Windows macro  
  
    switch(message)
```

```

{
    case WM_MOUSEWHEEL:
    case WM_MOUSEMOVE:
        //Your code to process event
        break;
    case WM_LBUTTONDOWN:
        //Your code to process event
        break;
    case WM_LBUTTONUP:
        //Your code to process event
        break;
    case WM_RBUTTONDOWN:
        //Your code to process event
        break;
    case WM_RBUTTONUP:
        //Your code to process event
        break;
    case WM_MBUTTONDOWN:
        //Your code to process event
        break;
    case WM_MBUTTONUP:
        //Your code to process event
        break;
    case WM_LBUTTONDBLCLK:
        //Your code to process event
        break;
    case WM_RBUTTONDBLCLK:
        //Your code to process event
        break;
    case WM_MBUTTONDBLCLK:
        //Your code to process event
        break;
}
}

```

Remarks

If developing a C++ application, use [swMouseNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseRBtnDbLClkNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DMouseEvents_MouseRBtnDbLClkNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseRBtnDbLClkNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the right-mouse button is double-clicked.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseRBtnDbLClkNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseRBtnDbLClkNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseRBtnDbLClkNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseRBtnDbLClkNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[X](#)
x coordinate of the pointer in the window space
[Y](#)
y coordinate of the pointer in the window space
[WParam](#)
Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseRBtnDbLClkNotify_Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseRBtnDbLClkNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseRBtnDownNotifyEventHandler (Type)

DMouseEvents_MouseRBtnDownNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseRBtnDownNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the right-mouse button is pressed down.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseRBtnDownNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseRBtnDownNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseRBtnDownNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseRBtnDownNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- [X](#)
x coordinate of the pointer in the window space
- [Y](#)
y coordinate of the pointer in the window space
- [WParam](#)
Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseRBtnDownNotify Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseRBtnDownNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseRBtnUpNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DMouseEvents_MouseRBtnUpNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseRBtnUpNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the right-mouse button is released after being pressed down.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseRBtnUpNotifyEventHandler( _  
    ByVal X As System.Integer, _  
    ByVal Y As System.Integer, _  
    ByVal WParam As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseRBtnUpNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseRBtnUpNotifyEventHandler(  
    System.int X,  
    System.int Y,  
    System.int WParam  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseRBtnUpNotifyEventHandler(  
& System.int X,  
& System.int Y,  
& System.int WParam  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[X](#)
x coordinate of the pointer in the window space
[Y](#)
y coordinate of the pointer in the window space
[WParam](#)
Data about the state of the keyboard at the time the event was sent; see MSDN for details on how to decode this data

Visual Basic for Applications (VBA) Syntax

See [MouseRBtnUpNotify Event \(Mouse\)](#).

Remarks

If developing a C++ application, use [swMouseRBtnUpNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DMouseEvents_MouseSelectNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DMouseEvents_MouseSelectNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : DMouseEvents_MouseSelectNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the user makes a selection in the model view using the mouse.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DMouseEvents_MouseSelectNotifyEventHandler( _  
    ByVal Ix As System.Integer, _  
    ByVal Iy As System.Integer, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DMouseEvents\_MouseSelectNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DMouseEvents_MouseSelectNotifyEventHandler(  
    System.int Ix,  
    System.int Iy,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
public delegate System.int DMouseEvents_MouseSelectNotifyEventHandler(  
& System.int Ix,  
& System.int Iy,  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[Ix](#)
x coordinate of the pointer in the window space
[Iy](#)
y coordinate of the pointer in the window space
[X](#)
x coordinate of the pointer in world space
[Y](#)
y coordinate of the pointer in world space
[Z](#)
z coordinate of the pointer in world space

Visual Basic for Applications (VBA) Syntax

See [MouseSelectNotify Event \(Mouse\)](#).

Example

[Run SOLIDWORKS Commands and Synthesize Mouse Events \(C#\)](#)
[Run SOLIDWORKS Commands and Synthesize Mouse Events \(VB.NET\)](#)
[Run SOLIDWORKS Commands and Synthesize Mouse Events \(VBA\)](#)

Remarks

If developing a C++ application, use [swMouseSelectNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DPartDocEvents_ActiveAnnotationViewChangeNotifyEventHandler (Type)

DPartDocEvents_ActiveAnnotationViewChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ActiveAnnotationViewChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the user changes the annotation view.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ActiveAnnotationViewChangeNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As New DPartDocEvents\_ActiveAnnotationViewChangeNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ActiveAnnotationViewChangeNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_ActiveAnnotationViewChangeNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ActiveAnnotationViewChangeNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartActiveAnnotationViewChangeNotify](#) to register for this notification.

Availability

DPartDocEvents_ActiveConfigChangeNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_ActiveConfigChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ActiveConfigChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired with the user switches to a different configuration.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ActiveConfigChangeNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As New DPartDocEvents\_ActiveConfigChangeNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ActiveConfigChangeNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_ActiveConfigChangeNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ActiveConfigChangeNotify_Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartActiveConfigChangeNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_ActiveConfigChangePostNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_ActiveConfigChangePostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ActiveConfigChangePostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the user program when the user has switched to a different configuration.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ActiveConfigChangePostNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As New DPartDocEvents\_ActiveConfigChangePostNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ActiveConfigChangePostNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_ActiveConfigChangePostNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ActiveConfigChangePostNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartConfigChangePostNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_ActiveDisplayStateChangePostNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DPartDocEvents_ActiveDisplayStateChangePostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ActiveDisplayStateChangePostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired after the display state of a configuration is changed or after a configuration is changed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ActiveDisplayStateChangePostNotifyEventHandler( _  
    ByVal DisplayStateName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_ActiveDisplayStateChangePostNotifyEventHandler(AddressOf  
HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ActiveDisplayStateChangePostNotifyEventHandler(  
    System.string DisplayStateName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_ActiveDisplayStateChangePostNotifyEventHandler(  
& System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of the active display state

Visual Basic for Applications (VBA) Syntax

See [ActiveDisplayStateChangePostNotify Event \(PartDoc\)](#).

Example

[Fire Events When Display State Changes in Part Document \(C#\)](#)
[Fire Events When Display State Changes in Part Document \(VB.NET\)](#)
[Fire Events When Display State Changes in Part Document \(VBA\)](#)

Remarks

When changing configurations, the following events are fired in this order:

- [ActiveConfigChangeNotify](#)
- [ActiveDisplayStateChangePreNotify](#)
- [ActiveConfigChangePostNotify](#)
- [ActiveDisplayStateChangePostNotify](#)

When changing the display state of a configuration, only ActiveDisplayStateChangePreNotify and ActiveDisplayStateChangePostNotify are fired

This event is fired even when configurations and display states are not linked; however, the initial and final display states will be the same.

Availability

SOLIDWORKS 2010 FCS, Revision Number 17.0

DPartDocEvents_ActiveDisplayStateChangePreNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_ActiveDisplayStateChangePreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ActiveDisplayStateChangePreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired before the display state of a configuration is changed or before a configuration is changed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ActiveDisplayStateChangePreNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_ActiveDisplayStateChangePreNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ActiveDisplayStateChangePreNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_ActiveDisplayStateChangePreNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ActiveDisplayStateChangePreNotify Event \(PartDoc\)](#).

Example

[Fire Events When Display State Changes in Part Document \(C#\)](#)
[Fire Events When Display State Changes in Part Document \(VB.NET\)](#)
[Fire Events When Display State Changes in Part Document \(VBA\)](#)

Remarks

When changing configurations, the following events are fired in this order:

- [ActiveConfigChangeNotify](#)
- [ActiveDisplayStateChangePreNotify](#)
- [ActiveConfigChangePostNotify](#)
- [ActiveDisplayStateChangePostNotify](#)

When changing the display state of a configuration, only [ActiveDisplayStateChangePreNotify](#) and [ActiveDisplayStateChangePostNotify](#) are fired

This event is fired even when configurations and display states are not linked; however, the initial and final display states will be the same.

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

DPartDocEvents_ActiveViewChangeNotifyEventHandler (Type)

DPartDocEvents_ActiveViewChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ActiveViewChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the active view changes.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ActiveViewChangeNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_ActiveViewChangeNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ActiveViewChangeNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_ActiveViewChangeNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ActiveViewChangeNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartActiveViewChangeNotify](#) to register for this notification.

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

DPartDocEvents_AddCustomPropertyNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DPartDocEvents_AddCustomPropertyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_AddCustomPropertyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the user program when the user has added a custom property.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_AddCustomPropertyNotifyEventHandler( _  
    ByVal propName As System.String, _  
    ByVal Configuration As System.String, _  
    ByVal Value As System.String, _  
    ByVal valueType As System.Integer _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_AddCustomPropertyNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_AddCustomPropertyNotifyEventHandler(  
    System.string propName,  
    System.string Configuration,  
    System.string Value,  
    System.int valueType  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_AddCustomPropertyNotifyEventHandler(  
& System.String^ propName,  
& System.String^ Configuration,  
& System.String^ Value,  
& System.int valueType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

propName

Name of the new custom property

Configuration

Configuration that contains the property

Value

Value of the new property

valueType

Valid type for VARIANT; see Microsoft MSDN for a list of valid VARIANT types

Visual Basic for Applications (VBA) Syntax

See [AddCustomPropertyNotify_Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartAddCustomPropertyNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_AddDependencyNotifyEventHandler (Type)

DPartDocEvents_AddDependencyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_AddDependencyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the part references the specified document for the first time.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_AddDependencyNotifyEventHandler( _  
    ByVal PathName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_AddDependencyNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_AddDependencyNotifyEventHandler(  
    System.string PathName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_AddDependencyNotifyEventHandler(  
& System.String^ PathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PathName
The full name and path of the newly referenced document.

Remarks

If developing a C++ application, use [swPartAddDependencyNotify](#) to register for this notification.

Availability

SOLIDWORKS 2026 SP03, Revision Number 34.3

DPartDocEvents_AddItemNotifyEventHandler (Type)

DPartDocEvents_AddItemNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_AddItemNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when an item is added to one of the SOLIDWORKS tree structures such as the FeatureManager design tree and the ConfigurationManager.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_AddItemNotifyEventHandler( _  
    ByVal EntityType As System.Integer, _  
    ByVal itemName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_AddItemNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_AddItemNotifyEventHandler(  
    System.int EntityType,  
    System.string itemName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_AddItemNotifyEventHandler(  
& System.int EntityType,  
& System.String^ itemName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityType
Type of new item as defined in [swNotifyEntityType_e](#)
itemName
Name of new item

Visual Basic for Applications (VBA) Syntax

See [AddItemNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartAddItemNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_AutoSaveNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_AutoSaveNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_AutoSaveNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the part document is automatically saved.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_AutoSaveNotifyEventHandler( _  
    ByVal FileName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_AutoSaveNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_AutoSaveNotifyEventHandler(  
    System.string FileName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_AutoSaveNotifyEventHandler(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName
File name to which to save the part document

Visual Basic for Applications (VBA) Syntax

See [AutoSaveNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartAutoSaveNotify](#) to register for this notification.

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

DPartDocEvents_AutoSaveToStorageNotifyEventHandler (Type)

DPartDocEvents_AutoSaveToStorageNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_AutoSaveToStorageNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the part document is automatically saved to third-party IStream storage.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_AutoSaveToStorageNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_AutoSaveToStorageNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_AutoSaveToStorageNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_AutoSaveToStorageNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AutoSaveToStorageNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swAutoSaveToStorageNotify](#) to register for this notification.

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

DPartDocEvents_AutoSaveToStorageStoreNotifyEventHandler (Type)

DPartDocEvents_AutoSaveToStorageStoreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_AutoSaveToStorageStoreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the part document is automatically saved to third-party IStorage storage.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_AutoSaveToStorageStoreNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_AutoSaveToStorageStoreNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_AutoSaveToStorageStoreNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_AutoSaveToStorageStoreNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AutoSaveToStorageStoreNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swAutoSaveToStorageStoreNotify](#) to register for this notification.

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

DPartDocEvents_BodyVisibleChangeNotifyEventHandler (Type)

DPartDocEvents_BodyVisibleChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_BodyVisibleChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired whenever the visible state of a body within this part changes.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_BodyVisibleChangeNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_BodyVisibleChangeNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_BodyVisibleChangeNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_BodyVisibleChangeNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BodyVisibleChangeNotify_Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartBodyVisibleChangeNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

DPartDocEvents_ChangeCustomPropertyNotifyEventHandler (Type)

DPartDocEvents_ChangeCustomPropertyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ChangeCustomPropertyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the user program when the user has changed a custom property.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ChangeCustomPropertyNotifyEventHandler( _  
    ByVal propName As System.String, _  
    ByVal Configuration As System.String, _  
    ByVal oldValue As System.String, _  
    ByVal NewValue As System.String, _  
    ByVal valueType As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_ChangeCustomPropertyNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ChangeCustomPropertyNotifyEventHandler(  
    System.string propName,  
    System.string Configuration,  
    System.string oldValue,  
    System.string NewValue,  
    System.int valueType  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_ChangeCustomPropertyNotifyEventHandler(  
& System.String^ propName,  
& System.String^ Configuration,  
& System.String^ oldValue,  
& System.String^ NewValue,  
& System.int valueType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- propName*
Name of the changed property
- Configuration*
Configuration that contains the property
- oldValue*
Previous value of the property
- NewValue*
New value of the property
- valueType*
Valid type for VARIANT; see Microsoft MSDN for a list of valid VARIANT types

Visual Basic for Applications (VBA) Syntax

See [ChangeCustomPropertyNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartChangeCustomPropertyNotify](#) to register for this event.

Availability

DPartDocEvents_ClearSelectionsNotifyEventHandler (Type)

DPartDocEvents_ClearSelectionsNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ClearSelectionsNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Notifies the user program when selections are cleared using **Clear Selections**.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ClearSelectionsNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_ClearSelectionsNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ClearSelectionsNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_ClearSelectionsNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ClearSelectionsNotify_Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartClearSelectionsNotify](#) to register for this event.

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

DPartDocEvents_CloseDesignTableNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_CloseDesignTableNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_CloseDesignTableNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Pre-notifies your application that a design table that was opened for editing is about to be closed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_CloseDesignTableNotifyEventHandler( _  
    ByVal DesignTable As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_CloseDesignTableNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_CloseDesignTableNotifyEventHandler(  
    System.Object DesignTable  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_CloseDesignTableNotifyEventHandler(  
& System.Object^ DesignTable  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DesignTable
[Design table](#)

Visual Basic for Applications (VBA) Syntax

See [CloseDesignTableNotify_Event \(PartDoc\)](#).

Remarks

The IPartDoc event [OpenDesignTableNotify](#) post-notifies when a design table has been opened for editing.

If developing a C++ application, use [swPartOpenDesignTableNotify](#) to register for this notification.

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

DPartDocEvents_CommandManagerTabActivatedPreNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_CommandManagerTabActivatedPreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_CommandManagerTabActivatedPreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Pre-notifies you that a SOLIDWORKS CommandManager tab is about to be activated.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_CommandManagerTabActivatedPreNotifyEventHandler( _  
    ByVal CommandTabIndex As System.Integer, _  
    ByVal CommandTabName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_CommandManagerTabActivatedPreNotifyEventHandler(AddressOf  
HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_CommandManagerTabActivatedPreNotifyEventHandler(  
    System.int CommandTabIndex,  
    System.string CommandTabName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_CommandManagerTabActivatedPreNotifyEventHandler(  
& System.int CommandTabIndex,  
& System.String^ CommandTabName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CommandTabIndex
Index of the tab that is about to be activated
CommandTabName
Name of the tab

Visual Basic for Applications (VBA) Syntax

See [CommandManagerTabActivatedPreNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartCommandManagerTabActivatedPreNotify](#) to register for this notification.

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

DPartDocEvents_ConfigurationChangeNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_ConfigurationChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ConfigurationChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Gets information about an object or feature that has had one if its configurable parameters changed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ConfigurationChangeNotifyEventHandler( _  
    ByVal ConfigurationName As System.String, _  
    ByVal Object As System.Object, _  
    ByVal ObjectType As System.Integer, _  
    ByVal changeType As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_ConfigurationChangeNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ConfigurationChangeNotifyEventHandler(  
    System.string ConfigurationName,  
    System.object Object,  
    System.int ObjectType,  
    System.int changeType  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_ConfigurationChangeNotifyEventHandler(  
& System.String^ ConfigurationName,  
& System.Object^ Object,  
& System.int ObjectType,  
& System.int changeType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigurationName

Name of the configuration that has changed

Object

Object that has changed

ObjectType

Type of the object that has changed as defined in [swSelectType_e](#):

- swSelDIMENSIONS
- swSelDATUMPOINTS
- swSelDATUMPLANES
- swSelDATUMAXES
- swSelHELIX
- swSelBODYFEATURES
- swSelMATEGROUP
- swSelMATES
- swSelCOORDSYS
- swSelCOMPONENTS
- swSelCONFIGURATIONS
- swSelSKETCHES
- swSelREFCURVES
- swSelDISPLAYSTATE

All other types are returned as swSelUNSUPPORTED.

changeType

Type of change as defined by [swConfigurationChangeTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [ConfigurationChangeNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartConfigurationChangeNotify](#) to register for this notification.

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

DPartDocEvents_ConvertToBodiesPostNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_ConvertToBodiesPostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ConvertToBodiesPostNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired after the Convert to Bodies dialog closes.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ConvertToBodiesPostNotifyEventHandler( _  
    ByVal FileName As System.String, _  
    ByVal SaveOption As System.Integer, _  
    ByVal PreserveGeometryAndSketches As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_ConvertToBodiesPostNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ConvertToBodiesPostNotifyEventHandler(  
    System.string FileName,  
    System.int SaveOption,  
    System.bool PreserveGeometryAndSketches  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_ConvertToBodiesPostNotifyEventHandler(  
& System.String^ FileName,  
& System.int SaveOption,  
& System.bool PreserveGeometryAndSketches  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

File name of the part to convert to a body

SaveOption

Save option as defined in [swFileSaveTypes](#) e:

- swFileSaveAs
- swFileSaveAsCopy
- swFileSaveAsCopyAndOpen

PreserveGeometryAndSketches

True to preserve geometry and sketches, false to not

Visual Basic for Applications (VBA) Syntax

See [ConvertToBodiesPostNotify Event \(PartDoc\)](#).

Remarks

This event is triggered after the user clicks **OK** or **Cancel** in the Convert to Bodies dialog and before user interface validation. FileName, SaveOption and PreserveGeometryAndSketches contain the values selected in the dialog.

If developing a C++ application, use [swPartConvertToBodiesPostNotify](#) to register for this notification.

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

DPartDocEvents_ConvertToBodiesPreNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_ConvertToBodiesPreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_ConvertToBodiesPreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired before the Convert to Bodies dialog opens.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_ConvertToBodiesPreNotifyEventHandler( _  
    ByVal FileName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_ConvertToBodiesPreNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_ConvertToBodiesPreNotifyEventHandler(  
    System.string FileName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_ConvertToBodiesPreNotifyEventHandler(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName
File name of the part to convert to a body

Visual Basic for Applications (VBA) Syntax

See [ConvertToBodiesPreNotify_Event \(PartDoc\)](#).

Remarks

This event is triggered before the Convert to Bodies dialog displays.
If developing a C++ application, use [swPartConvertToBodiesPreNotify](#) to register for this notification.

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

DPartDocEvents_DeleteCustomPropertyNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DPartDocEvents_DeleteCustomPropertyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DeleteCustomPropertyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the user program when the user has deleted a custom property.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DeleteCustomPropertyNotifyEventHandler( _  
    ByVal propName As System.String, _  
    ByVal Configuration As System.String, _  
    ByVal Value As System.String, _  
    ByVal valueType As System.Integer _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DeleteCustomPropertyNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DeleteCustomPropertyNotifyEventHandler(  
    System.string propName,  
    System.string Configuration,  
    System.string Value,  
    System.int valueType  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_DeleteCustomPropertyNotifyEventHandler(  
& System.String^ propName,  
& System.String^ Configuration,  
& System.String^ Value,  
& System.int valueType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

propName

Name of the deleted property

Configuration

Name of the configuration that contains the property

Value

Value of the deleted property

valueType

Valid type for VARIANT; see Microsoft MSDN for a list of valid VARIANT types

Visual Basic for Applications (VBA) Syntax

See [DeleteCustomPropertyNotify_Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartDeleteCustomPropertyNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_DeleteDependencyNotifyEventHandler (Type)

DPartDocEvents_DeleteDependencyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DeleteDependencyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the part no longer references the specified document.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DeleteDependencyNotifyEventHandler( _  
    ByVal PathName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DeleteDependencyNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DeleteDependencyNotifyEventHandler(  
    System.string PathName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_DeleteDependencyNotifyEventHandler(  
& System.String^ PathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PathName
The full name and path of the document no longer referenced.

Remarks

If developing a C++ application, use [swPartDeleteDependencyNotify](#) to register for this notification.

Availability

SOLIDWORKS 2026 SP03, Revision Number 34.3

DPartDocEvents_DeleteItemNotifyEventHandler (Type)

DPartDocEvents_DeleteItemNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DeleteItemNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Notifies the user program when an item is deleted from one of the SOLIDWORKS tree structures, such as the FeatureManager design tree and the ConfigurationManager.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DeleteItemNotifyEventHandler( _  
    ByVal EntityType As System.Integer, _  
    ByVal itemName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DeleteItemNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DeleteItemNotifyEventHandler(  
    System.int EntityType,  
    System.string itemName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_DeleteItemNotifyEventHandler(  
& System.int EntityType,  
& System.String^ itemName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityType
Type of item deleted as defined in [swNotifyEntityType_e](#)
itemName
Name of the deleted item

Visual Basic for Applications (VBA) Syntax

See [DeleteItemNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartDeleteItemNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_DeleteItemPreNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

DPartDocEvents_DeleteItemPreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DeleteItemPreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Notifies the user program when an item is about to be deleted from one of the SOLIDWORKS tree structures, such as the FeatureManager design tree and the ConfigurationManager.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DeleteItemPreNotifyEventHandler( _  
    ByVal EntityType As System.Integer, _  
    ByVal itemName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DeleteItemPreNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DeleteItemPreNotifyEventHandler(  
    System.int EntityType,  
    System.string itemName  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_DeleteItemPreNotifyEventHandler(  
& System.int EntityType,  
& System.String^ itemName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityType

Type of item deleted as defined in [swNotifyEntityType_e](#)

itemName

Name of the item to be deleted

Visual Basic for Applications (VBA) Syntax

See [DeleteItemPreNotify Event \(PartDoc\)](#).

Remarks

Use [IPartDoc::FeatureByName](#) or [IPartDoc::IFeatureByName](#) to get the object to be deleted.

If developing a C++ application, use [swPartDeleteItemPreNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_DeleteSelectionPreNotifyEventHandler (Type)

DPartDocEvents_DeleteSelectionPreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DeleteSelectionPreNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Pre-notifies the user when the selection is deleted.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DeleteSelectionPreNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DeleteSelectionPreNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DeleteSelectionPreNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_DeleteSelectionPreNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DeleteSelectionPreNotify_Event \(PartDoc\)](#).

Remarks

Returning S_false from your notification handler prevents deletion of the selected item.

If developing a COM application, use [swPartDeleteSelectionPreNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_DestroyNotify2EventHandler (Type)

DPartDocEvents_DestroyNotify2EventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DestroyNotify2EventHandler Delegate (SolidWorks.Interop.sldworks)

Pre-notifies the user program when a part document is about to be destroyed.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DestroyNotify2EventHandler( _  
    ByVal DestroyType As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DestroyNotify2EventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DestroyNotify2EventHandler(  
    System.int DestroyType  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_DestroyNotify2EventHandler(  
& System.int DestroyType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DestroyType
Value as defined by [swDestroyNotifyType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DestroyNotify2 Event \(PartDoc\)](#).

Remarks

The DestroyType argument indicates whether the part is being removed from memory (swDestroyNotifyDestroy) or if it remains open due to an outside reference (swDestroyNotifyHidden).

If developing a C++ application, use [swPartDestroyNotify2](#) to register for this notification.

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

DPartDocEvents_DestroyNotifyEventHandler (Type)

DPartDocEvents_DestroyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DestroyNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Obsolete. Superseded by [DPartDocEvents_DestroyNotify2EventHandler](#).

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DestroyNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DestroyNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DestroyNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_DestroyNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DestroyNotify_Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartDestroyNotify](#) to register for this notification.

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

DPartDocEvents_DimensionChangeNotifyEventHandler (Type)

DPartDocEvents_DimensionChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DimensionChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when a dimension is changed through the **Dimension** dialog.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DimensionChangeNotifyEventHandler( _  
    ByVal displayDim As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DimensionChangeNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DimensionChangeNotifyEventHandler(  
    System.object displayDim  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_DimensionChangeNotifyEventHandler(  
& System.Object^ displayDim  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

displayDim
[Display dimension](#) that changed

Visual Basic for Applications (VBA) Syntax

See [DimensionChangeNotify Event \(PartDoc\)](#).

Remarks

If developing a C++ application, use [swPartDimensionChangeNotify](#) to register for this notification.

Availability

DPartDocEvents_DisplayPaneCollapseNotifyEventHandler (Type)

DPartDocEvents_DisplayPaneCollapseNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DisplayPaneCollapseNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the Display Pane collapses in this part.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DisplayPaneCollapseNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DisplayPaneCollapseNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DisplayPaneCollapseNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_DisplayPaneCollapseNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayPaneCollapseNotify Event \(PartDoc\)](#).

Example

[Create Task Pane View Add-in \(C#\)](#).

Remarks

If developing a C++ application, use [swPartDisplayPaneCollapseNotify](#) to register for this notification.

Availability

SOLIDWORKS 2024 SP02, Revision Number 32.2

DPartDocEvents_DisplayPaneExpandNotifyEventHandler (Type)

DPartDocEvents_DisplayPaneExpandNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DisplayPaneExpandNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when the Display Pane expands in this part.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DisplayPaneExpandNotifyEventHandler() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DisplayPaneExpandNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DisplayPaneExpandNotifyEventHandler()
```

C++/CLI

```
public delegate System.int DPartDocEvents_DisplayPaneExpandNotifyEventHandler();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayPaneExpandNotify_Event \(PartDoc\)](#).

Example

[Create Task Pane View Add-in \(C#\)](#).

Remarks

If developing a C++ application, use [swPartDisplayPaneExpandNotify](#) to register for this notification.

Availability

SOLIDWORKS 2024 SP02, Revision Number 32.2

DPartDocEvents_DragStateChangeNotifyEventHandler (Type)

DPartDocEvents_DragStateChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DragStateChangeNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Fired when starting or stopping the dragging of an Instant3D manipulator.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DragStateChangeNotifyEventHandler( _  
    ByVal State As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DragStateChangeNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DragStateChangeNotifyEventHandler(  
    System.bool State  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_DragStateChangeNotifyEventHandler(  
& System.bool State  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

State
True if dragging of the Instant3D manipulator has started; false if dragging of the Instant3D manipulator has stopped

Visual Basic for Applications (VBA) Syntax

See [DragStateChangeNotify_Event \(PartDoc\)](#).

Example

[Fire Events When Dragging Instant3D Manipulator in a Part \(C#\)](#)
[Fire Events When Dragging Instant3D Manipulator in a Part \(VB.NET\)](#)
[Fire Events When Dragging Instant3D Manipulator in a Part \(VBA\)](#)

Remarks

If developing a C++ application, use [swPartDragStateChangeNotify](#) to register for this notification.

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

DPartDocEvents_DynamicHighlightNotifyEventHandler (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DPartDocEvents_DynamicHighlightNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : DPartDocEvents_DynamicHighlightNotifyEventHandler Delegate (SolidWorks.Interop.sldworks)

Post-notifies the application when dynamic highlighting of the selected object changes from on to off, and vice versa.

.NET Syntax

Visual Basic (Declaration)

```
Public Delegate Function DPartDocEvents_DynamicHighlightNotifyEventHandler( _  
    ByVal bHighlightState As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As New DPartDocEvents\_DynamicHighlightNotifyEventHandler(AddressOf HandlerMethod)
```

C#

```
public delegate System.int DPartDocEvents_DynamicHighlightNotifyEventHandler(  
    System.bool bHighlightState  
)
```

C++/CLI

```
public delegate System.int DPartDocEvents_DynamicHighlightNotifyEventHandler(  
& System.bool bHighlightState  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

bHighlightState

True if highlighting is on, false if it is off

Visual Basic for Applications (VBA) Syntax

See [DynamicHighlightNotify Event \(PartDoc\)](#).

Example

```
Private Function part_DynamicHighlightNotify() As Long  
    Dim one As Object  
    Dim x As Integer  
    Dim pt As Variant  
    Set one = mgr.GetSelectedObject5(-1)  
    If Not one Is Nothing Then  
        Debug.Print mgr.GetSelectedObjectType2(-1)  
        one.Select True  
        pt = mgr.GetSelectionPoint(-1)  
        If Not IsEmpty(pt) Then  
            Debug.Print pt(0), pt(1), pt(2)  
        Else  
            Debug.Print "Object selected in FeatureManager design tree, so no points."        End If  
    End If  
End Function
```

```
End If
Else
    Debug.Print "Dynamic highlighting is now off."
End If
```

Remarks

If developing a C++ application, use [swPartDynamicHighlightNotify](#) to register for this notification.

To send this notification, specify -1 for the index for any of the [ISelectionMgr](#) methods. See **Example**.

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0