

SOLIDWORKS API (.NET, VBA, C#) — Reference (8/337): IAdvancedSelectionCriteria-IAnimation

SOLIDWORKS API Documentation (converted from CHM)

IAdvancedSelectionCriteria (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAdvancedSelectionCriteria Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedSelectionCriteria Interface

Allows access to advanced component selection criteria for an assembly.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface IAdvancedSelectionCriteria
```

Visual Basic (Usage)

```
Dim instance As IAdvancedSelectionCriteria
```

C#

```
public interface IAdvancedSelectionCriteria
```

C++/CLI

```
public interface class IAdvancedSelectionCriteria
```

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria](#).

Example

```
'VBA
'-----
' Preconditions:
' 1. Open Public_Documents\SOLIDWORKS\SOLIDWORKS 2021\samples\tutorial\advdrawings\98food processor.sldasm.
' 2. Create InContextHasMate.xml with the following content:
'   <?xml version="1.0" encoding="UTF-8"?>
'   <SWQueryList>
'     <Query Name="InContextHasMate" Favourites_Index="1">
'       <Boolean Name="And" Category="In Context Relations" SubCategory="Has mate to part" Condition="=" Value="base plate-1@98food
processor"/>
'     </Query>
'   </SWQueryList>
' 3. Place InContextHasMate.xml in c:\temp.
' 4. Open the Immediate window.
'
' Postconditions: Inspect the Immediate window and the six selections
' in the FeatureManager design tree.
'-----
Option Explicit
Dim swAssem As SldWorks.AssemblyDoc
Dim criteria As SldWorks.AdvancedSelectionCriteria
Dim swApp As SldWorks.SldWorks
Dim Count As Long
Dim CriteriaFileName As String
Dim LoadSuccess As Boolean
Dim index As Long
Dim SelectSuccess As Boolean
Dim category1 As String
Dim category2 As String
Dim condition As Long
Dim val As String
Dim isAnd As Boolean

Sub main()

    Set swApp = Application.SldWorks
    Set swAssem = swApp.ActiveDoc
    Set criteria = swAssem.GetAdvancedSelection
```

```

Count = criteria.GetItemCount
Debug.Print "Before loading a query, GetItemCount returned " & Count

' Query file
CriteriaFileName = "C:\temp\InContextHasMate.xml"

' Load query file
LoadSuccess = criteria.LoadCriteria(CriteriaFileName)
Debug.Print "Query " & CriteriaFileName & " load was" & If(LoadSuccess = False, " NOT ", " ") & "successful"

Count = criteria.GetItemCount
Debug.Print "After loading a query, GetItemCount returned " & Count

For index = 0 To Count - 1
    If criteria.GetItem2(index, category1, category2, condition, val, isAnd) > -1 Then
        Debug.Print vbTab & " Criterion " & index & ": " & category1 & ", " & category2 & ", " & condition & ", " & val & ", " & isAnd
    Else
        Debug.Print vbTab & " Criterion " & index & " not found"
    End If
Next

Debug.Print swAssem.SelectionManager.GetSelectedObjectCount2(-1) & " objects selected before running query"

' Select components using selection criteria
SelectSuccess = criteria.Select
Debug.Print "Select was" & If(SelectSuccess = False, " NOT ", " ") & "successful"

Debug.Print swAssem.SelectionManager.GetSelectedObjectCount2(-1) & " objects selected after running query"

End Sub

```

Example

[Select Assembly Components Using Advanced Selection Criteria \(VB.NET\)](#)
[Select Assembly Components Using Advanced Selection Criteria \(C#\)](#)

Remarks

This interface represents functionality in the Advanced Component Selection dialog that appears when you click **Standard toolbar > Advanced Select**.

As of SOLIDWORKS 2021, you can [save](#) criteria only in XML format. You can now [load](#) either *.xml queries or *.sqy legacy queries.

For more information, see the **Assemblies > Basic Component Operations > Selecting Components > Advanced Component Selection** topic in the SOLIDWORKS Design user-interface help.

Accessors

[IAssemblyDoc::GetAdvancedSelection](#)

Access Diagram

[AdvancedSelectionCriteria](#)

See Also

[IAdvancedSelectionCriteria Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAdvancedSelectionCriteria Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedSelectionCriteria Interface

For a list of all members of this type, see [IAdvancedSelectionCriteria members](#).

Public Methods

Name	Description
 AddItem	Obsolete. Superseded by IAdvancedSelectionCriteria.AddItem2
 AddItem2	Adds the specified advanced component selection criterion to the list.
 DeleteItem	Deletes a criteria from the advanced component selection list.

 GetItem	Obsolete. Superseded by IAAdvancedSelectionCriteria::GetItem2
 GetItem2	Gets the specified advanced component selection criterion.
 GetItemCount	Gets the number of criteria in the advanced component selection criteria list.
 LoadCriteria	Loads the specified query file and makes it the current advanced component selection criteria list.
 SaveCriteria	Saves the current query to the specified XML file.
 Select	Selects the assembly components that satisfy the current advanced selection criteria.

[Top](#)

See Also

[IAAdvancedSelectionCriteria Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAAdvancedSelectionCriteria Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAAdvancedSelectionCriteria Interface

The following tables list the members exposed by [IAAdvancedSelectionCriteria](#).

Public Methods

Name	Description
 AddItem	Obsolete. Superseded by IAAdvancedSelectionCriteria::AddItem2
 AddItem2	Adds the specified advanced component selection criterion to the list.
 DeleteItem	Deletes a criteria from the advanced component selection list.
 GetItem	Obsolete. Superseded by IAAdvancedSelectionCriteria::GetItem2
 GetItem2	Gets the specified advanced component selection criterion.
 GetItemCount	Gets the number of criteria in the advanced component selection criteria list.
 LoadCriteria	Loads the specified query file and makes it the current advanced component selection criteria list.
 SaveCriteria	Saves the current query to the specified XML file.
 Select	Selects the assembly components that satisfy the current advanced selection criteria.

[Top](#)

See Also

[IAAdvancedSelectionCriteria Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddItem Method (IAAdvancedSelectionCriteria)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAAdvancedSelectionCriteria Interface](#) : AddItem Method (IAAdvancedSelectionCriteria)

Obsolete. Superseded by [IAAdvancedSelectionCriteria::AddItem2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddItem( _  
    ByVal Property As System.String, _  
    ByVal Condition As System.Integer, _  
    ByVal Value As System.String, _  
    ByVal IsAnd As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```

Dim instance As IAdvancedSelectionCriteria
Dim Property As System.String
Dim Condition As System.Integer
Dim Value As System.String
Dim IsAnd As System.Boolean
Dim value As System.Integer

value = instance.AddItem(Property, Condition, Value, IsAnd)

```

C#

```

System.int AddItem(
    System.string Property,
    System.int Condition,
    System.string Value,
    System.bool IsAnd
)

```

C++/CLI

```

System.int AddItem(
    & System.String^ Property,
    & System.int Condition,
    & System.String^ Value,
    & System.bool IsAnd
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Property

Name of property

Condition

Condition as defined in [swAdvSelectType_e](#)

Value

Text of the value

IsAnd

True if all of the criteria in the advanced component selection list must be met, false if only this criteria in the advanced component selection list must be met

Return Value

Index number of the newly added criteria in the advanced component selection list

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::AddItem](#).

Example

[Use Advanced Component Selection \(VBA\)](#)

[Use Advanced Component Selection \(VB.NET\)](#)

[Use Advanced Component Selection \(C#\)](#)

See Also

[IAdvancedSelectionCriteria Interface](#)

[IAdvancedSelectionCriteria Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddItem2 Method (IAdvancedSelectionCriteria)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSelectionCriteria Interface](#) : AddItem2 Method (IAdvancedSelectionCriteria)

Adds the specified advanced component selection criterion to the list.

.NET Syntax

Visual Basic (Declaration)

```
Function AddItem2( _  
    ByVal Category1 As System.String, _  
    ByVal Category2 As System.String, _  
    ByVal Condition As System.Integer, _  
    ByVal Value As System.String, _  
    ByVal IsAnd As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSelectionCriteria  
Dim Category1 As System.String  
Dim Category2 As System.String  
Dim Condition As System.Integer  
Dim Value As System.String  
Dim IsAnd As System.Boolean  
Dim value As System.Integer  
  
value = instance.AddItem2(Category1, Category2, Condition, Value, IsAnd)
```

C#

```
System.int AddItem2(  
    System.string Category1,  
    System.string Category2,  
    System.int Condition,  
    System.string Value,  
    System.bool IsAnd  
)
```

C++/CLI

```
System.int AddItem2(  
& System.String^ Category1,  
& System.String^ Category2,  
& System.int Condition,  
& System.String^ Value,  
& System.bool IsAnd  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Category1

Name of Category1 (see **Remarks**)

Category2

Name of Category2 (see **Remarks**)

Condition

Condition as defined in [swAdvSelectType_e](#) (see **Remarks**)

Value

Text value satisfying Condition (see **Remarks**)

IsAnd

True if all of the criteria in the advanced component selection list must be met, false if only this criteria in the advanced component selection list must be met

Return Value

Index number of the newly added criterion in the advanced component selection criteria list

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::AddItem2](#).

Remarks

For a list of possible Category1, Category2, Condition, and Value values, see the **Assemblies > Basic Component Operations > Selecting Components > Advanced Component Selection > Search Criteria for Advanced Component Selection** topic in the SOLIDWORKS Design user-interface help.

After calling this method multiple times to add criteria:

- [Save](#) the criteria.
- [Select](#) the components satisfying the criteria.

See Also

[IAdvancedSelectionCriteria Interface](#)
[IAdvancedSelectionCriteria Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteItem Method (IAdvancedSelectionCriteria)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSelectionCriteria Interface](#) : DeleteItem Method (IAdvancedSelectionCriteria)

Deletes a criteria from the advanced component selection list.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteItem( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSelectionCriteria  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.DeleteItem(Index)
```

C#

```
System.bool DeleteItem(  
    System.int Index  
)
```

C++/CLI

```
System.bool DeleteItem(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index number of the criteria to delete

Return Value

True if criteria is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::DeleteItem](#).

Remarks

Call [IAdvancedSelectionCriteria::GetItemCount](#) to get a valid value for Index before calling this method.

See Also

[IAdvancedSelectionCriteria Interface](#)
[IAdvancedSelectionCriteria Members](#)

Availability

GetItem Method (IAdvancedSelectionCriteria)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSelectionCriteria Interface](#) : GetItem Method (IAdvancedSelectionCriteria)Obsolete. Superseded by [IAdvancedSelectionCriteria::GetItem2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetItem( _
    ByVal Index As System.Integer, _
    ByRef Property As System.String, _
    ByRef Condition As System.Integer, _
    ByRef Value As System.String, _
    ByRef IsAnd As System.Boolean _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSelectionCriteria
Dim Index As System.Integer
Dim Property As System.String
Dim Condition As System.Integer
Dim Value As System.String
Dim IsAnd As System.Boolean
Dim value As System.Integer

value = instance.GetItem(Index, Property, Condition, Value, IsAnd)
```

C#

```
System.int GetItem(
    System.int Index,
    out System.string Property,
    out System.int Condition,
    out System.string Value,
    out System.bool IsAnd
)
```

C++/CLI

```
System.int GetItem(
    & System.int Index,
    & [Out] System.String^ Property,
    & [Out] System.int Condition,
    & [Out] System.String^ Value,
    & [Out] System.bool IsAnd
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index number of the criteria in the advanced component selection list

Property

Name of property

*Condition*Condition as defined in [swAdvSelectType_e](#)*Value*

Text of the value

IsAnd

True if all of the criteria in the advanced component selection list must be met, false if only this criteria in the advanced component selection list must be met

Return Value

Value of the Index argument or -1 if criteria specified by Index not found

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::GetItem](#).

Example

[Use Advanced Component Selection \(VBA\)](#)
[Use Advanced Component Selection \(VB.NET\)](#)
[Use Advanced Component Selection \(C#\)](#)

Remarks

Call [IAdvancedSelectionCriteria::GetItemCount](#) to get a valid value for Index before calling this method.

See Also

[IAdvancedSelectionCriteria Interface](#)
[IAdvancedSelectionCriteria Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetItem2 Method (IAdvancedSelectionCriteria)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSelectionCriteria Interface](#) : GetItem2 Method (IAdvancedSelectionCriteria)

Gets the specified advanced component selection criterion.

.NET Syntax

Visual Basic (Declaration)

```
Function GetItem2( _  
    ByVal Index As System.Integer, _  
    ByRef Category1 As System.String, _  
    ByRef Category2 As System.String, _  
    ByRef Condition As System.Integer, _  
    ByRef Value As System.String, _  
    ByRef IsAnd As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSelectionCriteria  
Dim Index As System.Integer  
Dim Category1 As System.String  
Dim Category2 As System.String  
Dim Condition As System.Integer  
Dim Value As System.String  
Dim IsAnd As System.Boolean  
Dim value As System.Integer
```

```
value = instance.GetItem2(Index, Category1, Category2, Condition, Value, IsAnd)
```

C#

```
System.int GetItem2(  
    System.int Index,  
    out System.string Category1,  
    out System.string Category2,  
    out System.int Condition,  
    out System.string Value,  
    out System.bool IsAnd  
)
```

C++/CLI

```

System.int GetItem2(
& System.int Index,
& [Out] System.String^ Category1,
& [Out] System.String^ Category2,
& [Out] System.int Condition,
& [Out] System.String^ Value,
& [Out] System.bool IsAnd
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index number of the criterion to retrieve

Category1

Name of Category1 (see **Remarks**)

Category2

Name of Category2 (see **Remarks**)

Condition

Condition as defined in [swAdvSelectType_e](#) (see **Remarks**)

Value

Text value satisfying Condition (see **Remarks**)

IsAnd

True if all of the criteria in the advanced component selection criteria list must be met, false if only this criterion must be met

Return Value

Value of the Index argument or -1 if criterion specified by Index not found

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::GetItem2](#).

Example

See the [IAdvancedSelectionCriteria](#) examples.

Remarks

Call [IAdvancedSelectionCriteria::GetItemCount](#) to get a valid value for Index before calling this method.

For a list of possible Category1, Category2, Condition, and Value values, see **Assemblies > Basic Component Operations > Selecting Components > Advanced Component Selection > Search Criteria for Advanced Component Selection** topic in the SOLIDWORKS Design user-interface help.

See Also

[IAdvancedSelectionCriteria Interface](#)

[IAdvancedSelectionCriteria Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetItemCount Method (IAdvancedSelectionCriteria)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSelectionCriteria Interface](#) : GetItemCount Method (IAdvancedSelectionCriteria)

Gets the number of criteria in the advanced component selection criteria list.

.NET Syntax

Visual Basic (Declaration)

```
Function GetItemCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IAdvancedSelectionCriteria
Dim value As System.Integer
```



```
value = instance.GetItemCount()
```

C#

```
System.int GetItemCount()
```

C++/CLI

```
System.int GetItemCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of criteria in the advanced component selection criteria list

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::GetItem](#).

Example

See the [AdvancedSelectionCriteria](#) examples.

Remarks

Call this method before calling [AdvancedSelectionCriteriaClass::GetItem](#) and [AdvancedSelectionCriteriaClass::DeleteItem](#) to get the number of criteria in the advanced component selection criteria list.

See Also

[IAdvancedSelectionCriteria Interface](#)
[IAdvancedSelectionCriteria Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoadCriteria Method (IAdvancedSelectionCriteria)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSelectionCriteria Interface](#) : LoadCriteria Method (IAdvancedSelectionCriteria)

Loads the specified query file and makes it the current advanced component selection criteria list.

.NET Syntax

Visual Basic (Declaration)

```
Function LoadCriteria( _  
    ByVal CriteriaFileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IAdvancedSelectionCriteria  
Dim CriteriaFileName As System.String  
Dim value As System.Boolean  
  
value = instance.LoadCriteria(CriteriaFileName)
```

C#

```
System.bool LoadCriteria(  
    System.string CriteriaFileName  
)
```



Copy Code

```
System.bool LoadCriteria(
& System.String^ CriteriaFileName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CriteriaFileName
Path and filename of query file (see **Remarks**)

Return Value

True if query file loads, false if not

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::LoadCriteria](#).

Example

See the [AdvancedSelectionCriteria](#) examples.

Remarks

Specify CriteriaFileName with either a *.xml file or a legacy *.sqy file.

To create a *.xml query file, you can either:

- Use the Advanced Component Selection dialog (**Standard toolbar > Advanced Select**) to export a query file in XML format.
- Or -

- Open a txt file in Notepad and add content as follows:

```
<?xml version="1.0" encoding="UTF-8"?>
```

```
<SWQueryList>
```

```
  <Query Name="InContextHasMate" Favourites_Index="1">
```

```
    <Boolean Name="And" Category="In Context Relations" SubCategory="Has mate to part" Condition="=" Value="base plate-1@98food processor"/>
```

```
  </Query>
```

```
</SWQueryList>
```

1. Replace the attribute values in the <Query> and <Boolean> elements as required. Refer to the **Assemblies > Basic Component Operations > Selecting Components > Advanced Component Selection > Search Criteria for Advanced Component Selection** topic in the SOLIDWORKS help to see all the options for populating the Category (Category1 in the dialog), SubCategory (Category2 in the dialog), Condition, and Value attributes.
2. In <Query> Favourites_Index specifies where the query appears at the end of the Select toolbar. This attribute corresponds to the row number in the Manage Searches tab of the dialog
3. In <Boolean> Name specifies "And" (default) or "Or" to indicate whether to logically AND or OR multiple Boolean elements in the Query element. This attribute corresponds to the And/Or column in the dialog.
4. Add more <Query> and <Boolean> elements as needed to further constrain your query.
5. Save the query file with a .xml extension.

After calling this method, call [AdvancedSelectionCriteria::Select](#) to select the assembly components that satisfy the query criteria.

See Also

[IAdvancedSelectionCriteria Interface](#)
[IAdvancedSelectionCriteria Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SaveCriteria Method (IAdvancedSelectionCriteria)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSelectionCriteria Interface](#) : SaveCriteria Method (IAdvancedSelectionCriteria)

Saves the current query to the specified XML file.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveCriteria( _
    ByVal CriteriaFileName As System.String _
```

) As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAdvancedSelectionCriteria
Dim CriteriaFileName As System.String
Dim value As System.Boolean

value = instance.SaveCriteria(CriteriaFileName)
```

C#

```
System.bool SaveCriteria(
    System.string CriteriaFileName
)
```

C++/CLI

```
System.bool SaveCriteria(
    & System.String^ CriteriaFileName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CriteriaFileName
Path and filename (*.xml) to which to save the current query

Return Value

True if current query is saved successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::SaveCriteria](#).

Remarks

Call this method after [adding](#) criteria to the current advanced component selection criteria list.

As of SOLIDWORKS 2021, you can save queries only in XML format.

As is done using the Advanced Component Selection dialog (**Standard toolbar > Advanced Select**), this method creates a query file in XML format with one or more <Query> and <Boolean> elements. Each <Query> element represents a particular search by Category (Category1 in the user interface) and SubCategory (Category2 in the user interface) to satisfy a Condition expression:

```
?xml version="1.0" encoding="UTF-8"?>
<SWQueryList>
  <Query Name="SelectPegs" Favourites_Index="1">
    <Boolean Name="And" Category="Custom Property" SubCategory="IsPeg" Condition="=" Value="Yes"/>
  </Query>
  <Query Name="SelectBlockParts" Favourites_Index="2">
    <Boolean Name="And" Category="Custom Property" SubCategory="IsBlockPart" Condition="=" Value="Yes"/>
  </Query>
</SWQueryList>
```

See Also

[IAdvancedSelectionCriteria Interface](#)
[IAdvancedSelectionCriteria Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (IAdvancedSelectionCriteria)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSelectionCriteria Interface](#) : Select Method (IAdvancedSelectionCriteria)

Selects the assembly components that satisfy the current advanced selection criteria.

.NET Syntax

Visual Basic (Declaration)

```
Function Select() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSelectionCriteria  
Dim value As System.Boolean  
  
value = instance.Select()
```

C#

```
System.bool Select()
```

C++/CLI

```
System.bool Select();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the components are selected, false if not

Visual Basic for Applications (VBA) Syntax

See [AdvancedSelectionCriteria::Select](#).

Example

See the [IAdvancedSelectionCriteria](#) examples.

Remarks

Call this method after either:

- [Loading](#) the criteria from a *.xml file or a *.sqy legacy file.
- or -
- [Adding](#) items to the advanced component selection criteria list.

See Also

[IAdvancedSelectionCriteria Interface](#)
[IAdvancedSelectionCriteria Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

IAngleMateFeatureData (Type)

IAngleMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAngleMateFeatureData Interface

Allows access to an angle mate or a limit angle mate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface IAngleMateFeatureData
```

Visual Basic (Usage)

```
Dim instance As IAngleMateFeatureData
```

C#

```
public interface IAngleMateFeatureData
```

C++/CLI

```
public interface class IAngleMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData](#).

Example

[Create and Edit Limit Angle Mate \(VBA\)](#)
[Create and Edit Limit Angle Mate \(C#\)](#)

Remarks

An angle mate places selected items at a specified angle. A limit angle mate is an advanced mate that allows items to move within a range of angles. Use [IAngleMateFeatureData::IsAdvancedMate](#) to determine whether this is a limit angle mate.

[IMateFeatureData](#) is the parent of this mate interface.

To create either an angle mate or a limit angle mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [IAngleMateFeatureData::EntitiesToMate](#) or use [IModelDocExtension::SelectByID2](#) to pre-select the entities using Mark = 1.
3. Specify [IAngleMateFeatureData::ReferenceEntity](#) or use [IModelDocExtension::SelectByID2](#) to pre-select the reference entity using Mark = 67108864.
4. Specify other properties of the AngleMateFeatureData object.

To edit an angle mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to an AngleMateFeatureData object.
3. Modify the AngleMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete this angle mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[AngleMateFeatureData](#)

See Also

[IAngleMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IAngleMateFeatureData Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [IAngleMateFeatureData](#).

Public Properties

Name	Description
Angle	Gets or sets the angle of this angle mate.
EntitiesToMate	Gets or sets the entities to mate in this angle mate.
FlipDimension	Gets or sets whether to move entities to opposite sides of the dimension in this angle mate.
IsAdvancedMate	Gets or sets whether this angle mate is a limit angle mate.
MateAlignment	Gets or sets the alignment of this angle mate.
MaximumAngle	Gets or sets the maximum angle of this limit angle mate.
MinimumAngle	Gets or sets the minimum angle of this limit angle mate.
ReferenceEntity	Gets or sets the direction reference entity for this angle mate.

[Top](#)

See Also

[IAngleMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IAngleMateFeatureData Interface Properties

[See Also](#)

For a list of all members of this type, see [IAngleMateFeatureData members](#).

Public Properties

Name	Description
Angle	Gets or sets the angle of this angle mate.
EntitiesToMate	Gets or sets the entities to mate in this angle mate.
FlipDimension	Gets or sets whether to move entities to opposite sides of the dimension in this angle mate.
IsAdvancedMate	Gets or sets whether this angle mate is a limit angle mate.
MateAlignment	Gets or sets the alignment of this angle mate.
MaximumAngle	Gets or sets the maximum angle of this limit angle mate.
MinimumAngle	Gets or sets the minimum angle of this limit angle mate.
ReferenceEntity	Gets or sets the direction reference entity for this angle mate.

[Top](#)

See Also

[IAngleMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

Angle Property (IAngleMateFeatureData)

[See Also](#)



Gets or sets the angle of this angle mate.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IAngleMateFeatureData
Dim value As System.Double

instance.Angle = value

value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians

Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData::Angle](#).

Example

See the [IAngleMateFeatureData](#) examples.

Remarks

If [IAngleMateFeatureData::IsAdvancedMate](#) is true, then this property specifies the starting angle of this mate.

See Also

[IAngleMateFeatureData Interface](#)
[IAngleMateFeatureData Members](#)
[IAngleMateFeatureData::MinimumAngle Property \(\)](#)
[IAngleMateFeatureData::MaximumAngle Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EntitiesToMate Property (IAngleMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAngleMateFeatureData Interface](#) : EntitiesToMate Property (IAngleMateFeatureData)

Gets or sets the entities to mate in this angle mate.

.NET Syntax

Visual Basic (Declaration)

Property EntitiesToMate As System.Object

Visual Basic (Usage)



```
Dim instance As IAngleMateFeatureData
Dim value As System.Object
```

```
instance.EntitiesToMate = value
value = instance.EntitiesToMate
```

C#

```
System.object EntitiesToMate {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of entities to mate (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData::EntitiesToMate](#).

 Example

See the [AngleMateFeatureData](#) examples.

 Remarks

You can create angle mates with the following mate entity combinations:

Mate entity/Mate entity	IRefAxis (cone, cylinder)	IFace2 (extrusion face, draft is not allowed)	IEdge , IRefAxis , ICenterLine , ISketchLine (line)	IRefPlane
IRefAxis (cone, cylinder)	•	•	•	
IFace2 (extrusion face, draft is not allowed)	•	•	•	
IEdge, IRefAxis, ICenterLine, ISketchLine (line)	•	•	•	
IRefPlane				•

 See Also

[AngleMateFeatureData Interface](#)
[AngleMateFeatureData Members](#)

 Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipDimension Property (IAngleMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [AngleMateFeatureData Interface](#) : FlipDimension Property (IAngleMateFeatureData)

Gets or sets whether to move entities to opposite sides of the dimension in this angle mate.

.NET Syntax

Visual Basic (Declaration)

```
Property FlipDimension As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAngleMateFeatureData
Dim value As System.Boolean

instance.FlipDimension = value
value = instance.FlipDimension
```

C#

```
System.bool FlipDimension {get; set;}
```

C++/CLI

```
property System.bool FlipDimension {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the dimension, false to not

Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData::FlipDimension](#).

Example

See the [IAngleMateFeatureData](#) examples.

See Also

[IAngleMateFeatureData Interface](#)
[IAngleMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsAdvancedMate Property (IAngleMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAngleMateFeatureData Interface](#) : IsAdvancedMate Property (IAngleMateFeatureData)

Gets or sets whether this angle mate is a limit angle mate.

.NET Syntax

Visual Basic (Declaration)

```
Property IsAdvancedMate As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAngleMateFeatureData
Dim value As System.Boolean
```

```
instance.IsAdvancedMate = value  
value = instance.IsAdvancedMate
```

C#

```
System.bool IsAdvancedMate {get; set;}
```

C++/CLI

```
property System.bool IsAdvancedMate {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if a limit angle mate, false if a standard angle mate

Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData::IsAdvancedMate](#).

See Also

[IAngleMateFeatureData Interface](#)
[IAngleMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateAlignment Property (IAngleMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAngleMateFeatureData Interface](#) : MateAlignment Property (IAngleMateFeatureData)

Gets or sets the alignment of this angle mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MateAlignment As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAngleMateFeatureData  
Dim value As System.Integer  
  
instance.MateAlignment = value  
value = instance.MateAlignment
```

C#

```
System.int MateAlignment {get; set;}
```

C++/CLI

```
property System.int MateAlignment {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mate alignment as defined in [swMateAlign_e](#)

Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData::MateAlignment](#).

Example

See the [AngleMateFeatureData](#) examples.

Remarks

If this property is set to swMateAlign_e:

- swMateAlignALIGNED, then vectors normal to the selected entities point in the same direction.
- swMateAlignANTI_ALIGNED, then vectors normal to the selected entities point in opposite directions.

See Also

[IAngleMateFeatureData Interface](#)
[AngleMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaximumAngle Property (IAngleMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAngleMateFeatureData Interface](#) : MaximumAngle Property (IAngleMateFeatureData)

Gets or sets the maximum angle of this limit angle mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MaximumAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAngleMateFeatureData  
Dim value As System.Double  
  
instance.MaximumAngle = value  
value = instance.MaximumAngle
```

C#

```
System.double MaximumAngle {get; set;}
```

C++/CLI

```
property System.double MaximumAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum angle in radians

Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData::MaximumAngle](#).

Example

See the [IAngleMateFeatureData](#) examples.

Remarks

This property is valid only if [IAngleMateFeatureData::IsAdvancedMate](#) is set to true.

See Also

[IAngleMateFeatureData Interface](#)
[IAngleMateFeatureData Members](#)
[IAngleMateFeatureData::Angle Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MinimumAngle Property (IAngleMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAngleMateFeatureData Interface](#) : MinimumAngle Property (IAngleMateFeatureData)

Gets or sets the minimum angle of this limit angle mate.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property MinimumAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAngleMateFeatureData  
Dim value As System.Double  
  
instance.MinimumAngle = value  
value = instance.MinimumAngle
```

C#

```
System.double MinimumAngle {get; set;}
```

C++/CLI

```
property System.double MinimumAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Minimum angle in radians

Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData::MinimumAngle](#).

Example

See the [IAngleMateFeatureData](#) examples.

Remarks

This property is valid only if [IAngleMateFeatureData::IsAdvancedMate](#) is set to true.

See Also

[IAngleMateFeatureData Interface](#)
[IAngleMateFeatureData Members](#)
[IAngleMateFeatureData::Angle Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceEntity Property (IAngleMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAngleMateFeatureData Interface](#) : ReferenceEntity Property (IAngleMateFeatureData)

Gets or sets the direction reference entity for this angle mate.

.NET Syntax

Visual Basic (Declaration)

Property ReferenceEntity As System.Object

Visual Basic (Usage)



```
Dim instance As IAngleMateFeatureData  
Dim value As System.Object  
  
instance.ReferenceEntity = value  
value = instance.ReferenceEntity
```

C#

```
System.Object ReferenceEntity {get; set;}
```

C++/CLI

```
property System.Object^ ReferenceEntity {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Plane](#), planar [face](#), linear [edge](#), or reference [axis](#)

Visual Basic for Applications (VBA) Syntax

See [AngleMateFeatureData::ReferenceEntity](#).

See Also

[IAngleMateFeatureData Interface](#)
[IAngleMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IAnimation (Type)

IAnimation Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnimation Interface

This interface is:

- obsolete and has not been superseded.
- nonfunctional in SOLIDWORKS 2008 and later.

Use the interfaces related to [motion studies](#) introduced in SOLIDWORKS 2008 to access animation and simulation.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IAnimation
```

Visual Basic (Usage)



```
Dim instance As IAnimation
```

C#

```
public interface IAnimation
```

C++/CLI

```
public interface class IAnimation
```

Visual Basic for Applications (VBA) Syntax

See [Animation](#).

Remarks

Do not confuse the **Animation Controller** pop-up toolbar available in the core SOLIDWORKS Design software with SOLIDWORKS Animator, a SOLIDWORKS add-in. SOLIDWORKS Anima provides more functionality than the **Animation Controller** pop-up toolbar. See the SOLIDWORKS Animator online Help for details.

See Also

[IAnimation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IAnimation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnimation Interface

The following tables list the members exposed by [IAnimation](#).

Public Properties

Name	Description
Duration	Obsolete. Not superseded.
PlayMode	Obsolete. Not superseded.
Speed	Obsolete. Not superseded.

[Top](#)

Public Methods

Name	Description
 Beginning	Obsolete. Not superseded.
 Close	Obsolete. Not superseded.
 End	Obsolete. Not superseded.
 Pause	Obsolete. Not superseded.
 Play	Obsolete. Not superseded.
 Stop	Obsolete. Not superseded.

[Top](#)

See Also

[IAnimation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAnimation Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnimation Interface

For a list of all members of this type, see [IAnimation members](#).

Public Methods

Name	Description
 Beginning	Obsolete. Not superseded.
 Close	Obsolete. Not superseded.
 End	Obsolete. Not superseded.
 Pause	Obsolete. Not superseded.
 Play	Obsolete. Not superseded.
 Stop	Obsolete. Not superseded.

[Top](#)

See Also

[IAnimation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAnimation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnimation Interface

For a list of all members of this type, see [IAnimation members](#).

Public Properties

Name	Description
 Duration	Obsolete. Not superseded.
 PlayMode	Obsolete. Not superseded.
 Speed	Obsolete. Not superseded.

[Top](#)

See Also

[IAnimation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

Beginning Method (IAnimation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : Beginning Method (IAnimation)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function Beginning() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnimation
Dim value As System.Boolean

value = instance.Beginning()
```

C#

```
System.bool Beginning()
```

C++/CLI

```
System.bool Beginning();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the animation is positioned at its beginning, false if an animation controller is not running

Visual Basic for Applications (VBA) Syntax

See [Animation::Beginning](#).

See Also

[IAnimation Interface](#)
[IAnimation Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

Close Method (IAnimation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : Close Method (IAnimation)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function Close() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnimation
Dim value As System.Boolean

value = instance.Close()
```

C#

```
System.bool Close()
```

C++/CLI

```
System.bool Close();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the animation controller closes, false if the animation controller is not running

Visual Basic for Applications (VBA) Syntax

See [Animation::Close](#).

See Also

[IAnimation Interface](#)
[IAnimation Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments](#) on this topic.

Duration Property (IAnimation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : Duration Property (IAnimation)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Duration As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAnimation
Dim value As System.Double

value = instance.Duration
```

C#

```
System.double Duration {get;}
```

C++/CLI

```
property System.double Duration {
    System.double get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of time, in seconds, this animation plays

Visual Basic for Applications (VBA) Syntax

See [Animation::Duration](#).

Remarks

[IAnimation::Speed](#) affects the duration of the animation. Animation::Speed allows you to specify whether or not to play the animation at half speed or double speed, which halves or doubles the animation duration.

If you use Animation::Duration while an animation is playing, then you might not get the same result as when the animation is not running.

If you get the Animation object using...	And then use...	Then the duration...
ISimulation::Animation	Animation::Duration	Is at the normal playing speed
ISimulation::PlayAnimation	Animation::Duration	Might be a different value because the animation is playing and the Animation Controller speed may be set to Normal , Slow Play , or Fast Play

 See Also

[IAnimation Interface](#)
[IAnimation Members](#)

 Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

End Method (IAnimation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : End Method (IAnimation)

Obsolete. Not superseded.

 .NET Syntax

Visual Basic (Declaration)

```
Function End() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnimation  
Dim value As System.Boolean  
  
value = instance.End()
```

C#

```
System.bool End()
```

C++/CLI

```
System.bool End();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the animation is positioned at its ends, false if the animation controller is not running

 Visual Basic for Applications (VBA) Syntax

See [Animation::End](#).

 See Also

[IAnimation Interface](#)
[IAnimation Members](#)

 Availability

SOLIDWORKS 2006 FCS, Revision Number 14

Pause Method (IAnimation)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : Pause Method (IAnimation)**Obsolete. Not superseded.**

.NET Syntax

Visual Basic (Declaration)

```
Function Pause() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnimation  
Dim value As System.Boolean  
  
value = instance.Pause()
```

C#

```
System.bool Pause()
```

C++/CLI

```
System.bool Pause();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the animation is paused at its current position, false if the animation controller is not running

Visual Basic for Applications (VBA) Syntax

See [Animation::Pause](#).

See Also

[IAnimation Interface](#)
[IAnimation Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

Play Method (IAnimation)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : Play Method (IAnimation)**Obsolete. Not superseded.**

.NET Syntax

Visual Basic (Declaration)

```
Function Play() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnimation  
Dim value As System.Boolean  
  
value = instance.Play()
```

C#

```
System.bool Play()
```

C++/CLI

```
System.bool Play();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the animation plays, false if the animation controller is not running

Visual Basic for Applications (VBA) Syntax

See [Animation::Play](#).

See Also

[IAnimation Interface](#)
[IAnimation Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

PlayMode Property (IAnimation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : PlayMode Property (IAnimation)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Property PlayMode As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnimation  
Dim value As System.Integer  
  
instance.PlayMode = value  
value = instance.PlayMode
```

C#

```
System.int PlayMode {get; set;}
```

C++/CLI

```
property System.int PlayMode {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mode in which this animation is playing as defined in [swAnimationPlayMode_e](#)

Visual Basic for Applications (VBA) Syntax

See [Animation::PlayMode](#).

See Also

[IAnimation Interface](#)
[IAnimation Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

Speed Property (IAnimation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : Speed Property (IAnimation)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

Property Speed As System.Integer

Visual Basic (Usage)



```
Dim instance As IAnimation
Dim value As System.Integer

instance.Speed = value

value = instance.Speed
```

C#

```
System.int Speed {get; set;}
```

C++/CLI

```
property System.int Speed {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Speed at which the animation plays as defined by [swAnimationPlaySpeed_e](#)

Visual Basic for Applications (VBA) Syntax

See [Animation::Speed](#).

Remarks

This property affects the duration of the animation. It allows you to specify whether or not to play the animation at half speed or double speed, which halves or doubles the animation duration.

If you use [IAnimation::Duration](#) while an animation is playing, then you might not get the same result as when the animation is not running.

If you get the Animation object using...

And then use...

Then the duration...

[ISimulation::Animation](#)

Animation::Duration

Is at the normal playing speed

[ISimulation::PlayAnimation](#)

Animation::Duration

Might be a different value because the animation is playing and the **Animation Controller** speed may be set to **Normal**, **Slow Play**, or **Fast Play**

See Also

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

Stop Method (IAnimation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnimation Interface](#) : Stop Method (IAnimation)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function Stop() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnimation  
Dim value As System.Boolean  
  
value = instance.Stop()
```

C#

```
System.bool Stop()
```

C++/CLI

```
System.bool Stop();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the animation stops playing and is positioned at its beginning, false if an animation controller is not running

Visual Basic for Applications (VBA) Syntax

See [Animation::Stop](#).

See Also

Availability

SOLIDWORKS 2006 FCS, Revision Number 14