

SOLIDWORKS API (.NET VBA C#) — Reference (16/337): IAssemblyDoc (part 4 of 5)

SOLIDWORKS API Documentation (converted from CHM)

IAssemblyDoc (part 4 of 5) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertWeld Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : InsertWeld Method (IAssemblyDoc)

Obsolete. Do not use. Superseded by [IFeatureManager::InsertCosmeticWeldBead](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertWeld( _  
    ByVal Type As System.String, _  
    ByVal Shape As System.String, _  
    ByVal TopDelta As System.Double, _  
    ByVal BottomDelta As System.Double, _  
    ByVal Radius As System.Double, _  
    ByVal Part As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim Type As System.String  
Dim Shape As System.String  
Dim TopDelta As System.Double  
Dim BottomDelta As System.Double  
Dim Radius As System.Double  
Dim Part As System.String  
  
instance.InsertWeld(Type, Shape, TopDelta, BottomDelta, Radius, Part)
```

C#

```
void InsertWeld(  
    System.string Type,  
    System.string Shape,  
    System.double TopDelta,  
    System.double BottomDelta,  
    System.double Radius,  
    System.string Part  
)
```

C++/CLI

```
void InsertWeld(  
& System.String^ Type,  
& System.String^ Shape,  
& System.double TopDelta,  
& System.double BottomDelta,  
& System.double Radius,  
& System.String^ Part  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Weld bead type

Shape

Surface shape

TopDelta

Distance for the top surface delta, if appropriate

BottomDelta

Distance for the bottom surface delta, if appropriate

Radius

Weld radius, if appropriate

Part

Path and filename for the part used for the weld; this file is created and merged into your assembly

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::InsertWeld](#).

Remarks

For the most up-to-date list of available types and shapes, see `C:\ProgramData\SolidWorks\SolidWorks 20nn\lang\english\gtol.sym`.

To programmatically select the top, stop, and contact faces for the weld bead and pass them as arrays, use [AssemblyDoc::InsertWeld2](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IWeldBead Interface](#)
[IWeldmentBeadFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertWeld2 Method (IAssemblyDoc)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [IAssemblyDoc Interface](#) : InsertWeld2 Method (IAssemblyDoc)

Obsolete. Do not use. Superseded by [IFeatureManager::InsertCosmeticWeldBead](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertWeld2( _  
    ByVal Type As System.String, _  
    ByVal Shape As System.String, _  
    ByVal TopDelta As System.Double, _  
    ByVal BottomDelta As System.Double, _  
    ByVal Radius As System.Double, _  
    ByVal Part As System.String, _  
    ByVal TopFaces As System.Object, _  
    ByVal StopFace As System.Object, _  
    ByVal ContactFaces As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim Type As System.String  
Dim Shape As System.String  
Dim TopDelta As System.Double  
Dim BottomDelta As System.Double  
Dim Radius As System.Double  
Dim Part As System.String  
Dim TopFaces As System.Object  
Dim StopFace As System.Object  
Dim ContactFaces As System.Object
```

```
instance.InsertWeld2(Type, Shape, TopDelta, BottomDelta, Radius, Part, TopFaces, StopFace,  
ContactFaces)
```

C#

```
void InsertWeld2(  
    System.string Type,  
    System.string Shape,  
    System.double TopDelta,  
    System.double BottomDelta,
```

```

        System.double Radius,
        System.string Part,
        System.object TopFaces,
        System.object StopFace,
        System.object ContactFaces
    )

```

C++/CLI

```

void InsertWeld2(
& System.String^ Type,
& System.String^ Shape,
& System.double TopDelta,
& System.double BottomDelta,
& System.double Radius,
& System.String^ Part,
& System.Object^ TopFaces,
& System.Object^ StopFace,
& System.Object^ ContactFaces
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Weld bead type

Shape

Surface shape

TopDelta

Distance for the top surface delta, if appropriate

BottomDelta

Distance for the bottom surface delta, if appropriate

Radius

Weld radius, if appropriate

Part

Path and filename for the part used for the weld; this file is created and merged into your assembly

TopFaces

Array of faces from which to measure the top surface delta

StopFace

Array of faces that define the beginning and the end of the weld bead

ContactFaces

Array of faces that are joined by the weld bead

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::InsertWeld2](#).

Remarks

For the most up-to-date list of available types and shapes, see **C:\ProgramData\SolidWorks\SolidWorks 20nn\lang\english\gtol.sym**.

To create a weld bead by preselecting the top, stop, and contact faces, use [IAssemblyDoc::InsertWeld](#).

See Also

[IAssemblyDoc Interface](#)

[IAssemblyDoc Members](#)

[IWeldBead Interface](#)

[IWeldmentBeadFeatureData Interface](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InterferenceDetectionManager Property (IAssemblyDoc)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : InterferenceDetectionManager Property (IAssemblyDoc)

Gets the Interference Detection manager, which allows you to run interference detection on an assembly to determine whether components interfere with each other.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property InterferenceDetectionManager As InterferenceDetectionMgr
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As InterferenceDetectionMgr  
  
value = instance.InterferenceDetectionManager
```

C#

```
InterferenceDetectionMgr InterferenceDetectionManager {get;}
```

C++/CLI

```
property InterferenceDetectionMgr^ InterferenceDetectionManager {  
    InterferenceDetectionMgr^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IInterferenceDetectionMgr](#)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::InterferenceDetectionManager](#).

Example

[Run Interference Detection \(C#\)](#)
[Run Interference Detection \(VB.NET\)](#)
[Run Interference Detection \(VBA\)](#)
[Detect Interferences Using a Transform \(VBA\)](#)
[Detect Interferences Using a Transform \(VB.NET\)](#)
[Detect Interferences Using a Transform \(C#\)](#)

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

IReorderComponents Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : IReorderComponents Method (IAssemblyDoc)

Moves components to a different location in the FeatureManager tree.

.NET Syntax

Visual Basic (Declaration)

```
Function IReorderComponents( _
    ByVal Count As System.Integer, _
    ByRef Source As Component2, _
    ByVal Target As System.Object, _
    ByVal Where As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
Dim Count As System.Integer
Dim Source As Component2
Dim Target As System.Object
Dim Where As System.Integer
Dim value As System.Boolean

value = instance.IReorderComponents(Count, Source, Target, Where)
```

C#

```
System.bool IReorderComponents(
    System.int Count,
    ref Component2 Source,
    System.object Target,
    System.int Where
)
```

C++/CLI

```
System.bool IReorderComponents(
    & System.int Count,
    & Component2^% Source,
    & System.Object^ Target,
    & System.int Where
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of items in the Source array

Source
Array of the [components](#) to move

Target
Target component or folder feature to which to move the components

Where
Where to move the components as defined in [swReorderComponentsWhere_e](#)

Return Value

True if the components were moved, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::IReorderComponents](#).

Remarks

The Source argument contains the components to reorder in the FeatureManager tree.

The order of the items in the array will be the order that the components appear after the reorder occurs. The components can only be moved within the same component of the model; you cannot move a component from a subassembly into the top level assembly.

The Where argument indicates where the Source should be moved relative to the Target as defined by [swReorderComponentsWhere_e](#). If the target is a feature, but not a folder feature, this method takes no action and returns false. Only folders that occur within the components section of the Assembly FeatureManager tree can be used; a folder that is among the body features will not be accepted. If the Where argument is specified as one of the two folder-related values, but the Target is a component, the method uses swReorderComponents_After.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ReorderComponents Method](#)
[IPartDoc::ReorderFeature Method](#)

Availability

SOLIDWORKS 2007 SP2, Revision Number 15.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IReorganizeComponents Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : IReorganizeComponents Method (IAssemblyDoc)

Reorganizes an assembly's structure by moving the selected components to the selected assembly or sub-assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function IReorganizeComponents( _  
    ByVal Count As System.Integer, _  
    ByRef Source As Component2, _  
    ByVal Target As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim Count As System.Integer  
Dim Source As Component2  
Dim Target As System.Object  
Dim value As System.Boolean
```

```
value = instance.IReorganizeComponents(Count, Source, Target)
```

C#

```
System.bool IReorganizeComponents(  
    System.int Count,  
    ref Component2 Source,  
    System.object Target  
)
```

C++/CLI

```
System.bool IReorganizeComponents(  
& System.int Count,  
& Component2^% Source,  
& System.Object^ Target  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of components to reorganize

Source

Array of selected components to move; all of the components must be at the same level in one parent assembly

Target

Where to move the components, which can be a top-level assembly or sub-assembly anywhere at any level of the hierarchy

Return Value

True if the selected components were moved to the selected assembly or sub-assembly, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::IReorganizeComponents](#).

Remarks

See the SOLIDWORKS Help for more information about reorganizing components.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ReorganizeComponents Method](#)
[IAssemblyDoc::ReorderComponents Method](#)
[DAssemblyDocEvents ComponentReorganizeNotifyEventHandler Delegate](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsComponentTreeValid Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : IsComponentTreeValid Method (IAssemblyDoc)

Checks the validity of the component tree for this assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function IsComponentTreeValid() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean
```

```
value = instance.IsComponentTreeValid()
```

C#

```
System.bool IsComponentTreeValid()
```

C++/CLI

```
System.bool IsComponentTreeValid();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the component tree is currently valid, false if the tree is currently invalid

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::IsComponentTreeValid](#).

Remarks

In certain cases, the current assembly component tree is invalid.

- You cannot query the assembly for a list of components ([IComponent2::GetChildren](#)) or use existing IComponent2 objects to make function calls.
- If you use the IComponent2 object's methods, then this method returns a NULL or empty value.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

Availability

ISetComponentState Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ISetComponentState Method (IAssemblyDoc)

Sets the suppression state for the specified components.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ISetComponentState( _
    ByVal SuppressionState As System.Integer, _
    ByVal NumComps As System.Integer, _
    ByRef CompArr As Component2, _
    ByVal ConfigOption As System.Integer, _
    ByVal WhichConfig As System.String, _
    ByVal SaveClosedDocs As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
Dim SuppressionState As System.Integer
Dim NumComps As System.Integer
Dim CompArr As Component2
Dim ConfigOption As System.Integer
Dim WhichConfig As System.String
Dim SaveClosedDocs As System.Boolean
Dim value As System.Boolean

value = instance.ISetComponentState(SuppressionState, NumComps, CompArr, ConfigOption,
WhichConfig, SaveClosedDocs)
```

C#

```
System.bool ISetComponentState(
    System.int SuppressionState,
    System.int NumComps,
    ref Component2 CompArr,
    System.int ConfigOption,
    System.string WhichConfig,
    System.bool SaveClosedDocs
)
```

C++/CLI

```
System.bool ISetComponentState(
    & System.int SuppressionState,
    & System.int NumComps,
    & Component2^% CompArr,
    & System.int ConfigOption,
    & System.String^ WhichConfig,
    & System.bool SaveClosedDocs
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SuppressionState

Component suppression state as defined in [swComponentSuppressionState_e](#) (see **Remarks**)

NumComps

Number of components to change

CompArr

Array of [components](#) to change of size numComps

ConfigOption

Configuration option as defined in [swInConfigurationOpts_e](#)

WhichConfig

Name of the configuration to change

SaveClosedDocs

True saves closed documents, false does not

Return Value

True if the components were changed, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ISetComponentState](#).

Remarks

You cannot set a component to lightweight using this method. Instead, use [IComponent::SetSuppression2](#).

See Also

[IAssemblyDoc Interface](#)

[IAssemblyDoc Members](#)

[IAssemblyDoc::SetComponentState Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetComponentVisibility Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ISetComponentVisibility Method (IAssemblyDoc)

Hides or shows the selected component in the specified configurations in this assembly document.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetComponentVisibility( _  
    ByVal Visibility As System.Boolean, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_count As System.Integer, _  
    ByRef Config\_names As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim Visibility As System.Boolean  
Dim Config_opt As System.Integer  
Dim Config_count As System.Integer  
Dim Config_names As System.String  
  
instance.ISetComponentVisibility(Visibility, Config_opt, Config_count, Config_names)
```

C#

```
void ISetComponentVisibility(  
    System.bool Visibility,  
    System.int Config\_opt,  
    System.int Config\_count,  
    ref System.string Config\_names  
)
```

C++/CLI

```
void ISetComponentVisibility(  
& System.bool Visibility,
```

```
& System.int Config\_opt,  
& System.int Config\_count,  
& System.String^% Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Visibility

True to show the selected component, false to hide it

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_count

Number of configurations for the component

Config_names

Array of the names of the configurations for the component

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::IsSetComponentVisibility](#).

See Also

[IAssemblyDoc Interface](#)

[IAssemblyDoc Members](#)

[IComponent2::GetVisibility Method](#)

[IComponent2::IsSetVisibility Method](#)

[IComponent2::Visible Property](#)

[IComponent2::SetVisibility Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

Isolate Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : Isolate Method (IAssemblyDoc)

Isolates the selected components.

.NET Syntax

Visual Basic (Declaration)

```
Function Isolate() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
```

```
Dim value As System.Boolean
```

```
value = instance.Isolate()
```

C#

```
System.bool Isolate()
```

C++/CLI

```
System.bool Isolate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the selected components are isolated, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::Isolate](#).

Example

[Isolate Component \(C#\)](#)
[Isolate Component \(VB.NET\)](#)
[Isolate Component \(VBA\)](#)

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ExitIsolate Method \(\)](#)
[IAssemblyDoc::SaveIsolate Method \(\)](#)
[IAssemblyDoc::SetIsolateVisibility Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsRouteAssembly Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : IsRouteAssembly Method (IAssemblyDoc)

Gets whether the assembly document is a routing assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function IsRouteAssembly() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean  
  
value = instance.IsRouteAssembly()
```

C#

```
System.bool IsRouteAssembly()
```

C++/CLI

```
System.bool IsRouteAssembly();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the assembly document is a routing assembly, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::IsRouteAssembly](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::GetRouteManager Method](#)
[IModelDoc2::InsertRoutePoint Method](#)
[IModelDoc2::EditRoute Method](#)

Availability

SOLIDWORKS 2007 SP1, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSupportedMatesAvailable Property (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : IsSupportedMatesAvailable Property (IAssemblyDoc)

Gets whether this assembly contains mates that are supportive of a mate controller.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property IsSupportedMatesAvailable As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean
```

```
value = instance.IsSupportedMatesAvailable
```

C#

```
System.bool IsSupportedMatesAvailable {get;}
```

C++/CLI

```
property System.bool IsSupportedMatesAvailable {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if mates supportive of a mate controller are available, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::IsSupportedMatesAvailable](#).

Example

See the [IMateControllerFeatureData](#) examples.

Remarks

Supportive mate types are as defined by [swMateType](#) e.:

- swMateANGLE
- swMateDISTANCE
- swMatePATH
- swMateSLOT
- swMateWIDTH

The Mate Controller feature does not support path, width, or slot mates created with either a free or a center in slot constraint.

If this property is true, then use [IAssemblyDoc::CollectAllSupportiveMates](#) to collect the supportive mates in this assembly.

To create a mate controller, see the Remarks section of [IMateControllerFeatureData](#).

For more information about the Mate Controller feature, see the **SOLIDWORKS Design user-interface help > Assemblies > Mates > Mate Controller** topic.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : IToolsCheckInterference2 Method (IAssemblyDoc)

Obsolete. See [IAssemblyDoc::IToolsCheckInterference3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IToolsCheckInterference2( _  
    ByVal NumComponents As System.Integer, _  
    ByRef LpComponents As Component, _  
    ByVal CoincidentInterference As System.Boolean, _  
    ByRef PComp As System.Object, _  
    ByRef PFace As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim NumComponents As System.Integer  
Dim LpComponents As Component  
Dim CoincidentInterference As System.Boolean  
Dim PComp As System.Object  
Dim PFace As System.Object  
  
instance.IToolsCheckInterference2(NumComponents, LpComponents, CoincidentInterference, PComp, PFace)
```

C#

```
void IToolsCheckInterference2(  
    System.int NumComponents,  
    ref Component LpComponents,  
    System.bool CoincidentInterference,  
    out System.object PComp,  
    out System.object PFace  
)
```

C++/CLI

```
void IToolsCheckInterference2(  
& System.int NumComponents,  
& Component^% LpComponents,  
& System.bool CoincidentInterference,  
& [Out] System.Object^ PComp,  
& [Out] System.Object^ PFace  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumComponents

LpComponents

CoincidentInterference

PComp

PFace

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::IToolsCheckInterference2](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

IToolsCheckInterference3 Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : IToolsCheckInterference3 Method (IAssemblyDoc)

Obsolete.

.NET Syntax

Visual Basic (Declaration)

```
Sub IToolsCheckInterference3( _
    ByVal NumComponents As System.Integer, _
    ByRef LpComponents As Component2, _
    ByVal CoincidentInterference As System.Boolean, _
    ByRef PComp As System.Object, _
    ByRef PFace As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
Dim NumComponents As System.Integer
Dim LpComponents As Component2
Dim CoincidentInterference As System.Boolean
Dim PComp As System.Object
Dim PFace As System.Object
```

```
instance.IToolsCheckInterference3(NumComponents, LpComponents, CoincidentInterference, PComp, PFace)
```

C#

```
void IToolsCheckInterference3(
    System.int NumComponents,
    ref Component2 LpComponents,
    System.bool CoincidentInterference,
    out System.object PComp,
    out System.object PFace
)
```

C++/CLI

```
void IToolsCheckInterference3(
    & System.int NumComponents,
    & Component2^% LpComponents,
    & System.bool CoincidentInterference,
    & [Out] System.Object^ PComp,
    & [Out] System.Object^ PFace
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumComponents

Number of components to check

LpComponents

Array of [components](#) being checked for interference

CoincidentInterference

True to check for coincident interference, false to not

PComp

Array of components where interference has been found

PFace

Array of [faces](#) where interference has been found

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::IToolsCheckInterference3](#).

Remarks

This method returns:

- an empty array of faces for components that have coincident faces that touch.
- an array of components for components that touch.

For each face that intersects, there is a corresponding component.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ToolsCheckInterference2 Method](#)
[InterferenceDetectionMgr Interface](#)
[Interference Interface](#)
[IModeler::CheckInterference3 Method](#)
[IModeler::!CheckInterference3 Method](#)
[IModeler::!CheckInterferenceCount3 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LargeDesignReviewTransparencyLevel Property (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : LargeDesignReviewTransparencyLevel Property (IAssemblyDoc)

Gets or sets the transparency level of unmodified components in the graphics area of this assembly opened in Large Design Review mode.

.NET Syntax

Visual Basic (Declaration)

Property LargeDesignReviewTransparencyLevel As System.Double

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
Dim value As System.Double
```

```
instance.LargeDesignReviewTransparencyLevel = value
```

```
value = instance.LargeDesignReviewTransparencyLevel
```

C#

```
System.double LargeDesignReviewTransparencyLevel {get; set;}
```

C++/CLI

```
property System.double LargeDesignReviewTransparencyLevel {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (opaque) <= transparency level of unmodified components <= 1.0 (invisible)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::LargeDesignReviewTransparencyLevel](#).

Example

[Set Transparency of Components in Large Design Review \(C#\)](#)
[Set Transparency of Components in Large Design Review \(VB.NET\)](#)
[Set Transparency of Components in Large Design Review \(VBA\)](#)

Remarks

This property is valid only if all of the following are true:

- This assembly is opened in Large Design Review mode.
- One or more assembly components have been modified.
- [IAssemblyDoc.LargeDesignReviewTransparencyLevelEnabled](#) is set to true.

When transparency levels are enabled, modified components are opaque, and unmodified components have the transparency level specified by this property.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc.LargeDesignReviewTransparencyLevelDynamic Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LargeDesignReviewTransparencyLevelDynamic Property (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : LargeDesignReviewTransparencyLevelDynamic Property (IAssemblyDoc)

Gets or sets whether to dynamically modify the transparency level of unmodified components in the graphics area when the transparency level slider is moved on the Filter Modified Components PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property LargeDesignReviewTransparencyLevelDynamic As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean
```

```
instance.LargeDesignReviewTransparencyLevelDynamic = value
```

```
value = instance.LargeDesignReviewTransparencyLevelDynamic
```

C#

```
System.bool LargeDesignReviewTransparencyLevelDynamic {get; set;}
```

C++/CLI

```
property System.bool LargeDesignReviewTransparencyLevelDynamic {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to dynamically modify the transparency level of unmodified components in the graphics area when moving the transparency level slider, false to not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc.LargeDesignReviewTransparencyLevelDynamic](#).

Example

[Set Transparency of Components in Large Design Review \(C#\)](#)
[Set Transparency of Components in Large Design Review \(VB.NET\)](#)
[Set Transparency of Components in Large Design Review \(VBA\)](#)

Remarks

This property is valid only when the assembly is opened in Large Design Review mode, and one or more of its components have been modified. When this property is enabled, modified components are opaque, and unmodified components change transparency as the transparency level slider moves.

The Filter Modified Components PropertyManager page appears when you click **Filter Modified Components** on the Large Design Review toolbar.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::LargeDesignReviewTransparencyLevel Property](#)
[IAssemblyDoc::LargeDesignReviewTransparencyLevelEnabled Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LargeDesignReviewTransparencyLevelEnabled Property (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : LargeDesignReviewTransparencyLevelEnabled Property (IAssemblyDoc)

Gets or sets whether transparency levels are activated for unmodified components in the graphics area for this assembly opened in Large Design Review mode.

.NET Syntax

Visual Basic (Declaration)

Property LargeDesignReviewTransparencyLevelEnabled As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean
```

```
instance.LargeDesignReviewTransparencyLevelEnabled = value  
value = instance.LargeDesignReviewTransparencyLevelEnabled
```

C#

```
System.bool LargeDesignReviewTransparencyLevelEnabled {get; set;}
```

C++/CLI

```
property System.bool LargeDesignReviewTransparencyLevelEnabled {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if transparency levels are activated, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::LargeDesignReviewTransparencyLevelEnabled](#).

Example

[Set Transparency of Components in Large Design Review \(C#\)](#)
[Set Transparency of Components in Large Design Review \(VB.NET\)](#)
[Set Transparency of Components in Large Design Review \(VBA\)](#)

Remarks

This property is valid only when the assembly is opened in Large Design Review mode, and one or more of its components have been modified. If this property is enabled, modified components are opaque, and unmodified components are transparent.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::LargeDesignReviewTransparencyLevel Property](#)
[IAssemblyDoc::LargeDesignReviewTransparencyLevelDynamic Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LightweightAllResolved Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : LightweightAllResolved Method (IAssemblyDoc)

Sets to lightweight all resolved child components of the selected components.

.NET Syntax

Visual Basic (Declaration)

```
Function LightweightAllResolved() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean  
  
value = instance.LightweightAllResolved()
```

C#

```
System.bool LightweightAllResolved()
```

C++/CLI

```
System.bool LightweightAllResolved();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if all child components of the selected components are set to lightweight, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::LightweightAllResolved](#).

Remarks

If no components are selected, then this method is applied to this assembly document.
Suppressed components are ignored.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::GetLightWeightComponentCount Method](#)
[IAssemblyDoc::ResolveAllLightweight Method](#)
[IAssemblyDoc::ResolveAllLightWeightComponents Method](#)
[IAssemblyDoc::ResolveOutOfDateLightWeightComponents Method](#)
[IAssemblyDoc::SetComponentState Method](#)
[IComponent2::GetSuppression Method](#)

[IComponent2::SetSuppression2 Method](#)
[IAssemblyDoc::MakeLightWeight Method](#)
[IAssemblyDoc::SelectiveOpen Method](#)

Availability

SOLIDWORKS 2006 SP1, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

MakeAssemblyFromSelectedComponents Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : MakeAssemblyFromSelectedComponents Method (IAssemblyDoc)

Creates a new assembly comprised of the selected components of this assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function MakeAssemblyFromSelectedComponents( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim FileName As System.String  
Dim value As System.Boolean
```

```
value = instance.MakeAssemblyFromSelectedComponents(FileName)
```

C#

```
System.bool MakeAssemblyFromSelectedComponents(  
    System.string FileName  
)
```

C++/CLI

```
System.bool MakeAssemblyFromSelectedComponents(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Path and filename of the new assembly

Return Value

True if a new assembly is created, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::MakeAssemblyFromSelectedComponents](#).

Example

[Make Assembly From Selected Components \(VB.NET\)](#)
[Make Assembly From Selected Components \(VBA\)](#)
[Make Assembly From Selected Components \(C#\)](#)

Remarks

If **Tools > Options > System Options > Assemblies > Save new components to external files** is selected, then a virtual sub-assembly is created and saved to an external file. Be sure to save the parent assembly before calling this method.

If **Tools > Options > System Options > Assemblies > Save new components to external files** is not selected, then the *FileName* input parameter is ignored, and only a virtual sub-assembly is created.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MakeIndependent Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : MakeIndependent Method (IAssemblyDoc)

Makes the selected component independent.

.NET Syntax

Visual Basic (Declaration)

```
Function MakeIndependent( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.MakeIndependent(FileName)
```

C#

```
System.bool MakeIndependent(  
    System.string FileName  
)
```

C++/CLI

```
System.bool MakeIndependent(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Path and file name where to save the new part (see **Remarks**)

Return Value

True if the component is made independent, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::MakeIndependent](#).

Example

[Make Component Independent \(C#\)](#)
[Make Component Independent \(VB.NET\)](#)
[Make Component Independent \(VBA\)](#)

Remarks

Making a component independent saves the component as a new file within the assembly and to the specified path and file name. The new part is referenced in the assembly.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ReplaceComponents2 Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MakeLightWeight Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : MakeLightWeight Method (IAssemblyDoc)

Sets the selected components to lightweight.

.NET Syntax

Visual Basic (Declaration)

```
Sub MakeLightWeight()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
```

```
instance.MakeLightWeight()
```

C#

```
void MakeLightWeight()
```

C++/CLI

```
void MakeLightWeight();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::MakeLightWeight](#).

Example

[Make Assembly Components Lightweight \(VBA\)](#)

Remarks

The purpose of this method is to support recording macros. You should use [IComponent2::GetSuppression](#) or [IComponent2::SetSuppression2](#) to get or set a component to lightweight.

This method sets the current selected components to lightweight, which is suitable for recording and running macros. [IComponent2::GetSuppression](#) and [IComponent2::SetSuppression2](#) operate on the component itself.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ResolveAllLightWeight Method](#)
[IAssemblyDoc::ResolveAllLightWeightComponents Method](#)
[IAssemblyDoc::ResolveOutOfDateLightWeightComponents Method](#)
[IAssemblyDoc::LightweightAllResolved Method](#)
[IAssemblyDoc::SetComponentState Method](#)
[IComponent2::GetSuppression Method](#)
[IComponent2::SetSuppression2 Method](#)
[IAssemblyDoc::SelectiveOpen Method](#)

Availability

MirrorComponents Method (IAssemblyDoc)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : MirrorComponents Method (IAssemblyDoc)Obsolete. Superseded by [IAssemblyDoc::MirrorComponents2](#). .NET Syntax

Visual Basic (Declaration)

```

Function MirrorComponents( _
    ByVal Plane As System.Object, _
    ByVal ComponentsToInstance As System.Object, _
    ByVal ComponentsToMirror As System.Object, _
    ByVal MirroredComponentFileNames As System.Object, _
    ByVal RecreateMates As System.Boolean, _
    ByVal ComponentModifier As System.Integer, _
    ByVal ComponentNameModifier As System.String, _
    ByVal MirroredFileLocation As System.String, _
    ByVal CopyCustomProperties As System.Boolean _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As IAssemblyDoc
Dim Plane As System.Object
Dim ComponentsToInstance As System.Object
Dim ComponentsToMirror As System.Object
Dim MirroredComponentFileNames As System.Object
Dim RecreateMates As System.Boolean
Dim ComponentModifier As System.Integer
Dim ComponentNameModifier As System.String
Dim MirroredFileLocation As System.String
Dim CopyCustomProperties As System.Boolean
Dim value As System.Object

value = instance.MirrorComponents(Plane, ComponentsToInstance, ComponentsToMirror,
MirroredComponentFileNames, RecreateMates, ComponentModifier, ComponentNameModifier,
MirroredFileLocation, CopyCustomProperties)

```

C#

```

System.object MirrorComponents(
    System.object Plane,
    System.object ComponentsToInstance,
    System.object ComponentsToMirror,
    System.object MirroredComponentFileNames,
    System.bool RecreateMates,
    System.int ComponentModifier,
    System.string ComponentNameModifier,
    System.string MirroredFileLocation,
    System.bool CopyCustomProperties
)

```

C++/CLI

```

System.Object^ MirrorComponents(
    & System.Object^ Plane,
    & System.Object^ ComponentsToInstance,
    & System.Object^ ComponentsToMirror,
    & System.Object^ MirroredComponentFileNames,
    & System.bool RecreateMates,
    & System.int ComponentModifier,
    & System.String^ ComponentNameModifier,
    & System.String^ MirroredFileLocation,

```

& System.bool [CopyCustomProperties](#)
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Plane

Plane or planar face about which to mirror the components

ComponentsToInstance

Array of instances of the component to mirror

ComponentsToMirror

Array of [components](#) to mirror

MirroredComponentFilenames

Array of filenames for the newly created mirrored assemblies or parts

RecreateMates

True to preserve any mates between the selected components if more than one component is to be mirrored, false to not

ComponentModifier

Prefix or suffix for the newly mirrored components if MirroredComponentFilenames is not specified, as defined by [swMirrorComponentNameModifier_e](#)

ComponentNameModifier

String to add to the prefix or suffix of the name of the newly mirrored component if MirroredComponentFilenames is not specified

MirroredFileLocation

Name of the folder where to store the file of the newly created mirrored components

CopyCustomProperties

True to copy the custom properties from the selected components to the mirrored components, false to not

Return Value

Array of the newly created [components](#)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::MirrorComponents](#).

See Also

[IAssemblyDoc Interface](#)

[IAssemblyDoc Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorComponents2 Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : MirrorComponents2 Method (IAssemblyDoc)

Obsolete. Superseded by [IAssemblyDoc::MirrorComponents3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function MirrorComponents2( _  
    ByVal MirrorPlane As System.Object, _  
    ByVal ComponentsToInstance As System.Object, _  
    ByVal ComponentOrientations As System.Object, _  
    ByVal OrientAboutCenterOfMass As System.Boolean, _  
    ByVal ComponentsToMirror As System.Object, _  
    ByVal CreateDerivedConfigurations As System.Boolean, _  
    ByVal MirroredComponentFilenames As System.Object, _  
    ByVal NameModifierType As System.Integer, _  
    ByVal NameModifier As System.String, _  
    ByVal MirroredComponentFileLocation As System.String, _  
    ByVal ImportOptions As System.Integer, _  
    ByVal BreakLinks As System.Boolean, _  
    ByVal PreserveZAxis As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IAssemblyDoc  
Dim MirrorPlane As System.Object
```



```

Dim ComponentsToInstance As System.Object
Dim ComponentOrientations As System.Object
Dim OrientAboutCenterOfMass As System.Boolean
Dim ComponentsToMirror As System.Object
Dim CreateDerivedConfigurations As System.Boolean
Dim MirroredComponentFileNames As System.Object
Dim NameModifierType As System.Integer
Dim NameModifier As System.String
Dim MirroredComponentFileLocation As System.String
Dim ImportOptions As System.Integer
Dim BreakLinks As System.Boolean
Dim PreserveZAxis As System.Boolean
Dim value As System.Object

```

```

value = instance.MirrorComponents2(MirrorPlane, ComponentsToInstance, ComponentOrientations,
OrientAboutCenterOfMass, ComponentsToMirror, CreateDerivedConfigurations,
MirroredComponentFileNames, NameModifierType, NameModifier, MirroredComponentFileLocation,
ImportOptions, BreakLinks, PreserveZAxis)

```

C#

```

System.object MirrorComponents2(
    System.object MirrorPlane,
    System.object ComponentsToInstance,
    System.object ComponentOrientations,
    System.bool OrientAboutCenterOfMass,
    System.object ComponentsToMirror,
    System.bool CreateDerivedConfigurations,
    System.object MirroredComponentFileNames,
    System.int NameModifierType,
    System.string NameModifier,
    System.string MirroredComponentFileLocation,
    System.int ImportOptions,
    System.bool BreakLinks,
    System.bool PreserveZAxis
)

```

C++/CLI

```

System.Object^ MirrorComponents2(
& System.Object^ MirrorPlane,
& System.Object^ ComponentsToInstance,
& System.Object^ ComponentOrientations,
& System.bool OrientAboutCenterOfMass,
& System.Object^ ComponentsToMirror,
& System.bool CreateDerivedConfigurations,
& System.Object^ MirroredComponentFileNames,
& System.int NameModifierType,
& System.String^ NameModifier,
& System.String^ MirroredComponentFileLocation,
& System.int ImportOptions,
& System.bool BreakLinks,
& System.bool PreserveZAxis
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MirrorPlane

Reference plane or planar face about which to mirror the components

ComponentsToInstance

Array of seed [components](#) with which to create copy mirror components

ComponentOrientations

Array of [swMirrorComponentOrientation_e](#) values; valid only if ComponentsToInstance is not null

OrientAboutCenterOfMass

True to orient the mirror components about the center of mass, false to orient them about the bounding box center

ComponentsToMirror

Array of seed components with which to create opposite-hand mirror components

CreateDerivedConfigurations

True to create a derived configuration of the mirror components in the original assembly, false to create new part files; valid only if ComponentsToMirror and MirroredComponentFileNames are not null and NameModifierType is [swMirrorComponentNameModifier_e.swMirrorComponentName_Custom](#)

MirroredComponentFileNames

Array of mirror part file names whose names can be further modified by the settings of NameModifierType and NameModifier; if CreateDerivedConfigurations is true, then this array contains the names for the new configurations and NameModifierType must be [swMirrorComponentNameModifier_e.swMirrorComponentName_Custom](#); valid only if ComponentsToMirror is not null

NameModifierType

Mirror part file name modifier type as defined in `swMirrorComponentNameModifier_e`; valid only if `ComponentsToMirror` and `MirroredComponentFileNames` are not null

NameModifier

Prefix or suffix to apply to file names of mirror parts; valid only if `NameModifierType` is `swMirrorComponentNameModifier_e.swMirrorComponentName_Prefix` or `swMirrorComponentNameModifier_e.swMirrorComponentName_Suffix` and `ComponentsToMirror` and if `MirroredComponentFileNames` are not null

MirroredComponentFileLocation

Folder where to save the mirror parts; valid only if `CreateDerivedConfigurations` is false

ImportOptions

Mirror transfer options as defined in [swMirrorPartOptions_e](#)

BreakLinks

True to break the links between the mirror parts and the original parts, false to keep the links

PreserveZAxis

True to mirror the Z-axis orientation in the mirror part, false to flip the Z-axis orientation in the mirror part

Return Value

Array of mirror [components](#)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::MirrorComponents2](#).

See Also

[IAssemblyDoc Interface](#)

[IAssemblyDoc Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorComponents3 Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : MirrorComponents3 Method (IAssemblyDoc)

Obsolete. Superseded by [IFeatureManager::CreateDefinition](#), [IFeatureManager::CreateFeature](#), and [IMirrorComponentFeatureData](#).

.NET Syntax

Visual Basic (Declaration)

```
Function MirrorComponents3( _  
    ByVal MirrorPlane As System.Object, _  
    ByVal ComponentsToInstance As System.Object, _  
    ByVal ComponentOrientations As System.Object, _  
    ByVal OrientAboutCenterOfMass As System.Boolean, _  
    ByVal ComponentsToMirror As System.Object, _  
    ByVal CreateDerivedConfigurations As System.Boolean, _  
    ByVal MirroredComponentFileNames As System.Object, _  
    ByVal NameModifierType As System.Integer, _  
    ByVal NameModifier As System.String, _  
    ByVal MirroredComponentFileLocation As System.String, _  
    ByVal ImportOptions As System.Integer, _  
    ByVal BreakLinks As System.Boolean, _  
    ByVal PreserveZAxis As System.Boolean, _  
    ByVal SyncFlexibleSubAssemblies As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IAssemblyDoc  
Dim MirrorPlane As System.Object  
Dim ComponentsToInstance As System.Object  
Dim ComponentOrientations As System.Object  
Dim OrientAboutCenterOfMass As System.Boolean  
Dim ComponentsToMirror As System.Object  
Dim CreateDerivedConfigurations As System.Boolean  
Dim MirroredComponentFileNames As System.Object  
Dim NameModifierType As System.Integer  
Dim NameModifier As System.String
```



```
Dim MirroredComponentFileLocation As System.String
Dim ImportOptions As System.Integer
Dim BreakLinks As System.Boolean
Dim PreserveZAxis As System.Boolean
Dim SyncFlexibleSubAssemblies As System.Boolean
Dim value As System.Object
```

```
value = instance.MirrorComponents3(MirrorPlane, ComponentsToInstance, ComponentOrientations,
OrientAboutCenterOfMass, ComponentsToMirror, CreateDerivedConfigurations,
MirroredComponentFileNames, NameModifierType, NameModifier, MirroredComponentFileLocation,
ImportOptions, BreakLinks, PreserveZAxis, SyncFlexibleSubAssemblies)
```

C#

```
System.Object MirrorComponents3(
    System.Object MirrorPlane,
    System.Object ComponentsToInstance,
    System.Object ComponentOrientations,
    System.bool OrientAboutCenterOfMass,
    System.Object ComponentsToMirror,
    System.bool CreateDerivedConfigurations,
    System.Object MirroredComponentFileNames,
    System.int NameModifierType,
    System.string NameModifier,
    System.string MirroredComponentFileLocation,
    System.int ImportOptions,
    System.bool BreakLinks,
    System.bool PreserveZAxis,
    System.bool SyncFlexibleSubAssemblies
)
```

C++/CLI

```
System.Object^ MirrorComponents3(
    & System.Object^ MirrorPlane,
    & System.Object^ ComponentsToInstance,
    & System.Object^ ComponentOrientations,
    & System.bool OrientAboutCenterOfMass,
    & System.Object^ ComponentsToMirror,
    & System.bool CreateDerivedConfigurations,
    & System.Object^ MirroredComponentFileNames,
    & System.int NameModifierType,
    & System.String^ NameModifier,
    & System.String^ MirroredComponentFileLocation,
    & System.int ImportOptions,
    & System.bool BreakLinks,
    & System.bool PreserveZAxis,
    & System.bool SyncFlexibleSubAssemblies
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MirrorPlane

[Reference plane](#) or planar [face](#) about which to mirror the components

ComponentsToInstance

Array of seed [components](#) with which to create copy mirror components

ComponentOrientations

Array of [swMirrorComponentOrientation_e](#) values; valid only if ComponentsToInstance is not Nothing or null

OrientAboutCenterOfMass

True to orient the mirror components about the center of mass, false to orient them about the bounding box center

ComponentsToMirror

Array of seed components with which to create opposite-hand mirror components

CreateDerivedConfigurations

True to create a derived configuration of the mirror components in the original assembly, false to create new part files; valid only if ComponentsToMirror and MirroredComponentFileNames are not Nothing or null and NameModifierType is [swMirrorComponentNameModifier_e.swMirrorComponentName_Custom](#)

MirroredComponentFileNames

Array of mirror part file names whose names can be further modified by the settings of NameModifierType and NameModifier; if CreateDerivedConfigurations is true, then this array contains the names for the new configurations and NameModifierType must be [swMirrorComponentNameModifier_e.swMirrorComponentName_Custom](#); valid only if ComponentsToMirror is not Nothing or null

NameModifierType

Mirror part file name modifier type as defined in [swMirrorComponentNameModifier_e](#); valid only if ComponentsToMirror and MirroredComponentFileNames are not Nothing or null

NameModifier

Prefix or suffix to apply to file names of mirror parts; valid only if NameModifierType is [swMirrorComponentNameModifier_e.swMirrorComponentName_Prefix](#) or [swMirrorComponentNameModifier_e.swMirrorComponentName_Suffix](#) and ComponentsToMirror and if MirroredComponentFileNames are not Nothing or null

MirroredComponentFileLocation

Folder where to save the mirror parts; valid only if CreateDerivedConfigurations is false

ImportOptions

Mirror transfer options as defined in [swMirrorPartOptions_e](#)

BreakLinks

True to break the links between the mirror parts and the original parts, false to keep the links

PreserveZAxis

True to mirror the Z-axis orientation in the mirror part, false to flip the Z-axis orientation in the mirror part

SyncFlexibleSubAssemblies

True to synchronize the movement of flexible subassembly components with the parent component, false to not

Return Value

Array of mirror [components](#)

 Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::MirrorComponents3](#).

 Example

[Mirror Components \(C#\)](#)
[Mirror Components \(VB.NET\)](#)
[Mirror Components \(VBA\)](#)

 See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IComponent2::IsMirrored Method \(\)](#)
[IPartDoc::IsMirrored Method \(\)](#)

 Availability

SOLIDWORKS 2016 SP5, Revision Number 24.5

SOLIDWORKS API Help

[Send comments](#) on this topic.

OpenCompFile Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : OpenCompFile Method (IAssemblyDoc)

Obsolete. Superseded by [ISldWorks::ActivateDoc2](#) and [ISldWorks::OpenDoc6](#).

 .NET Syntax

Visual Basic (Declaration)

```
Sub OpenCompFile()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
```

```
instance.OpenCompFile()
```

C#

```
void OpenCompFile()
```

C++/CLI

```
void OpenCompFile();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::OpenCompFile](#).

 See Also

Availability

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveFromFeatureScope Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : RemoveFromFeatureScope Method (IAssemblyDoc)

Removes a component from the scope of the currently selected assembly feature.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveFromFeatureScope( _  
    ByVal CompName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim CompName As System.String  
Dim value As System.Boolean  
  
value = instance.RemoveFromFeatureScope(CompName)
```

C#

```
System.bool RemoveFromFeatureScope(  
    System.string CompName  
)
```

C++/CLI

```
System.bool RemoveFromFeatureScope(  
& System.String^ CompName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CompName

Name of component to remove

Return Value

True if successfully removed, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::RemoveFromFeatureScope](#).

Remarks

If no assembly feature is selected, this method removes a component from the list that is to be used with the next assembly feature created.

Assembly features allow you to create a feature that affects multiple components in an assembly. For example, if you need a hole through two blocks to bolt them together, you can create a hole as an assembly feature and make it go through both blocks.

The scope of the assembly feature determines which components are affected by this feature. In other words, it describes which components contain the feature.

There are two ways to use this technique:

- If you have an assembly feature selected, this method removes a component from the assembly features scope. Any component that is not in the scope of the assembly feature cannot be affected by the assembly feature.

- If you create a list of components, this method allows you to remove a component from the list. The next assembly feature created affects each of the components in your list.

After you use one of these techniques, you can use [IAssemblyDoc::UpdateFeatureScope](#) to display the changes.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::UpdateFeatureScope Method](#)
[IAssemblyDoc::AddToFeatureScope Method](#)
[IAssemblyDoc::GetFeatureScope Method](#)
[IAssemblyDoc::GetFeatureScopeCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReorderComponents Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ReorderComponents Method (IAssemblyDoc)

Moves components to a different location in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function ReorderComponents( _
    ByVal Source As System.Object, _
    ByVal Target As System.Object, _
    ByVal Where As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
Dim Source As System.Object
Dim Target As System.Object
Dim Where As System.Integer
Dim value As System.Boolean
```

```
value = instance.ReorderComponents(Source, Target, Where)
```

C#

```
System.bool ReorderComponents(
    System.object Source,
    System.object Target,
    System.int Where
)
```

C++/CLI

```
System.bool ReorderComponents(
    & System.Object^ Source,
    & System.Object^ Target,
    & System.int Where
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Source

Array of [components](#) to move

Target

Target component or folder to which to move the components

Where

Where to move the components as defined in [swReorderComponentsWhere_e](#)

Return Value

True if the components are moved, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ReorderComponents](#).

Example

[Move Assembly Components to New Folder \(C#\)](#)
[Move Assembly Components to New Folder \(VB.NET\)](#)
[Move Assembly Components to New Folder \(VBA\)](#)

Remarks

The Source argument contains the components to reorder in the FeatureManager design tree.

The order of the elements in the array will be the order that the components appear after the reorder occurs. The components can only be move within the same component of the model; you cannot move a component from a subassembly into the top-level assembly.

The Where argument indicates where the Source should be moved relative to the Target as defined by swReorderComponentsWhere_e. If the target is not a folder feature, then this method takes no action and returns false. Only folders that occur within the components section of the assembly FeatureManager design tree can be used; a folder that is among the body features will not be accepted. If the Where argument is specified as one of the two folder-related values, but the Target is a component, the method uses swReorderCompentsWhere_e.swReorderComponents_After.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::IReorderComponents Method](#)
[IFeatureManager::InsertFeatureTreeFolder2 Method](#)
[IFeatureManager::GroupComponentInstances Property](#)
[IAssemblyDoc::UngroupComponents Method](#)
[IPartDoc::ReorderFeature Method](#)
[IModelDocExtension::ReorderFeature Method](#)

Availability

SOLIDWORKS 2007 SP2, Revision Number 15.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReorganizeComponents Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ReorganizeComponents Method (IAssemblyDoc)

Reorganizes an assembly's structure by moving the selected components to the selected assembly or sub-assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function ReorganizeComponents( _  
    ByVal Source As System.Object, _  
    ByVal Target As System.Object _  
    ) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IAssemblyDoc  
Dim Source As System.Object  
Dim Target As System.Object  
Dim value As System.Boolean
```

```
value = instance.ReorganizeComponents(Source, Target)
```

C#

```
System.bool ReorganizeComponents(  
    System.object Source,  
    System.object Target  
)
```

C++/CLI



```
System.bool ReorganizeComponents(  
& System.Object^ Source,  
& System.Object^ Target  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Source

Array of selected [components](#) to move; all of the components must be at the same level in one parent assembly

Target

Where to move the components, which can be a top-level assembly or sub-assembly anywhere at any level of the hierarchy

Return Value

True if the selected components were moved to the selected assembly or sub-assembly, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ReorganizeComponents](#).

Example

[Reorganize Components \(VBA\)](#)

Remarks

See SOLIDWORKS Help for more information about reorganizing components and restructuring assemblies.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::IReorganizeComponents Method](#)
[IAssemblyDoc::ReorderComponents Method](#)
[DAssemblyDocEvents.ComponentReorganizeNotifyEventHandler Delegate](#)
[IFeatureManager::GroupComponentInstances Property](#)
[IAssemblyDoc::UngroupComponents Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReplaceComponents Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ReplaceComponents Method (IAssemblyDoc)

Obsolete. Superseded by [IAssemblyDoc::ReplaceComponents2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ReplaceComponents( _  
    ByVal FileName As System.String, _  
    ByVal ConfigName As System.String, _  
    ByVal ReplaceAllInstance As System.Boolean, _  
    ByVal ReAttachMates As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim FileName As System.String  
Dim ConfigName As System.String  
Dim ReplaceAllInstance As System.Boolean  
Dim ReAttachMates As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.ReplaceComponents(FileName, ConfigName, ReplaceAllInstance, ReAttachMates)
```

C#

```
System.bool ReplaceComponents(  
    System.string FileName,  
    System.string ConfigName,  
    System.bool ReplaceAllInstance,  
    System.bool ReAttachMates  
)
```

C++/CLI

```
System.bool ReplaceComponents(  
    & System.String^ FileName,  
    & System.String^ ConfigName,  
    & System.bool ReplaceAllInstance,  
    & System.bool ReAttachMates  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Path and new file name

ConfigName

Name of configuration

ReplaceAllInstance

True to replace all instances, false to not

ReAttachMates

True to reattach all of the mates if the component is found in the subassembly component, false to not

Return Value

True if the component is successfully replaced, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ReplaceComponents](#).

Remarks

You cannot replace a selected component with a component of the same name even if the components are in different folders.

The component must be a top-level component. It cannot be a component of a sub-assembly. If the application needs to replace a component of the sub-assembly, then it should open the sub-assembly and get the component from that assembly.

This method closes any component files when called in an assembly. If the components were modified, then those modifications are not automatically saved. You must save any modifications before closing the files.

See Also

[IAssemblyDoc Interface](#)

[IAssemblyDoc Members](#)

[IAssemblyDoc::AddComponents Method](#)

[IAssemblyDoc::AddComponent5 Method](#)

[IAssemblyDoc::IAddComponents2 Method](#)

[IModelDoc2::ReloadOrReplace Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReplaceComponents2 Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ReplaceComponents2 Method (IAssemblyDoc)

Replaces one or more selected components with another model.

.NET Syntax

```

Function ReplaceComponents2( _
    ByVal FileName As System.String, _
    ByVal ConfigName As System.String, _
    ByVal ReplaceAllInstance As System.Boolean, _
    ByVal UseConfigChoice As System.Integer, _
    ByVal ReAttachMates As System.Boolean _
) As System.Boolean

```



```

Dim instance As IAssemblyDoc
Dim FileName As System.String
Dim ConfigName As System.String
Dim ReplaceAllInstance As System.Boolean
Dim UseConfigChoice As System.Integer
Dim ReAttachMates As System.Boolean
Dim value As System.Boolean

```

```

value = instance.ReplaceComponents2(FileName, ConfigName, ReplaceAllInstance, UseConfigChoice,
ReAttachMates)

```

```

System.bool ReplaceComponents2(
    System.string FileName,
    System.string ConfigName,
    System.bool ReplaceAllInstance,
    System.int UseConfigChoice,
    System.bool ReAttachMates
)

```

```

System.bool ReplaceComponents2(
    & System.String^ FileName,
    & System.String^ ConfigName,
    & System.bool ReplaceAllInstance,
    & System.int UseConfigChoice,
    & System.bool ReAttachMates
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Path and file name of the replacement component

ConfigName

Name of a configuration in the replacement component; an empty string indicates the default configuration of the replacement component

ReplaceAllInstance

True to replace all instances of the selected components with the replacement component, false to not

UseConfigChoice

Configuration to use as defined in [swReplaceComponentsConfiguration_e](#)

ReAttachMates

True to reattach existing mates to the replacement component, false to not

Return Value

True if the selected components are replaced, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ReplaceComponents2](#).

Example

[Replace Component \(C#\)](#)
[Replace Component \(VB.NET\)](#)
[Replace Component \(VBA\)](#)

Remarks

You cannot replace a selected component with a component of the same name even if the components reside in different folders.

The component must be a top-level component. It cannot be a component of a sub-assembly. If your application needs to replace a component of a sub-assembly, then your application must open the sub-assembly and get the component from that assembly.

This method closes any component files when called in an assembly. If components were modified, then those modifications are not automatically saved. You must save any modifications before closing the files.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IModelDoc2::ReloadOrReplace Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReplacePLMComponents Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ReplacePLMComponents Method (IAssemblyDoc)

Replaces a selected [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#) component in this assembly with the specified component from a 3DEXPERIENCE collaborative space.

.NET Syntax

Visual Basic (Declaration)

```
Function ReplacePLMComponents( _  
    ByVal PLMID As System.String, _  
    ByVal ConfigName As System.String, _  
    ByVal ReplaceAllInstance As System.Boolean, _  
    ByVal UseConfigChoice As System.Integer, _  
    ByVal ReAttachMates As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim PLMID As System.String  
Dim ConfigName As System.String  
Dim ReplaceAllInstance As System.Boolean  
Dim UseConfigChoice As System.Integer  
Dim ReAttachMates As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.ReplacePLMComponents(PLMID, ConfigName, ReplaceAllInstance, UseConfigChoice,  
ReAttachMates)
```

C#

```
System.bool ReplacePLMComponents(  
    System.string PLMID,  
    System.string ConfigName,  
    System.bool ReplaceAllInstance,  
    System.int UseConfigChoice,  
    System.bool ReAttachMates  
)
```

C++/CLI

```

System.bool ReplacePLMComponents(
& System.String^ PLMID,
& System.String^ ConfigName,
& System.bool ReplaceAllInstance,
& System.int UseConfigChoice,
& System.bool ReAttachMates
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PLMID

Unique ID of a replacement component in the collaboration space

ConfigName

Name of a configuration (Physical Product) in the replacement component; an empty string indicates the default configuration of the replacement component

ReplaceAllInstance

True to replace all instances of the selected components with the replacement component, false to not

UseConfigChoice

Configuration to use as defined in [swReplaceComponentsConfiguration_e](#)

ReAttachMates

True to reattach any existing mates to the replacement component, false to not

Return Value

True if the selected component is replaced, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ReplacePLMComponents](#).

Remarks

Before calling this method, save any components that have been modified in this assembly. This method closes any open component files without saving modifications.

See Also

[IAssemblyDoc Interface](#)

[IAssemblyDoc Members](#)

[IAssemblyDoc::AddPLMComponent Method \(\)](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResolveAllLightweight Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ResolveAllLightweight Method (IAssemblyDoc)

Resolves all lightweight child components of the selected components

.NET Syntax

Visual Basic (Declaration)

```
Function ResolveAllLightweight() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
```

```
Dim value As System.Boolean
```

```
value = instance.ResolveAllLightweight()
```

C#

```
System.bool ResolveAllLightweight()
```

C++/CLI

```
System.bool ResolveAllLightweight();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if all lightweight child components of the selected components are resolved, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ResolveAllLightweight](#).

Remarks

If no components are selected, then this method is applied to this assembly document.

Suppressed components are ignored.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::GetLightWeightComponentCount Method](#)
[IAssemblyDoc::LightWeightAllResolved Method](#)
[IAssemblyDoc::MakeLightWeight Method](#)
[IAssemblyDoc::ResolveAllLightWeightComponents Method](#)
[IAssemblyDoc::ResolveOutOfDateLightWeightComponents Method](#)
[IAssemblyDoc::SetComponentState Method](#)
[IAssemblyDoc::SetComponentSuppression Method](#)
[IAssemblyDoc::SelectiveOpen Method](#)

Availability

SOLIDWORKS SP1, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResolveAllLightWeightComponents Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ResolveAllLightWeightComponents Method (IAssemblyDoc)

Resolves the lightweight components in this assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function ResolveAllLightWeightComponents( _  
    ByVal WarnUser As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim WarnUser As System.Boolean  
Dim value As System.Integer
```

```
value = instance.ResolveAllLightWeightComponents(WarnUser)
```

C#

```
System.int ResolveAllLightWeightComponents(  
    System.bool WarnUser  
)
```

C++/CLI

```
System.int ResolveAllLightWeightComponents(  
    & System.bool WarnUser  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WarnUser

True prompts the user to resolve components, false does not

Return Value

Status of resolving the components as defined in [swComponentResolveStatus_e](#)

 Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ResolveAllLightWeightComponents](#).

 Example

[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)
[Get Visibility of and Resolve Lightweight Components \(VBA\)](#)
[Lock all External References \(VBA\)](#)
[Resolve All Components and Fix a Component \(C#\)](#)
[Resolve All Components and Fix a Component \(VB.NET\)](#)
[Resolve All Components and Fix a Component \(VBA\)](#)

 Remarks

The assembly must be open in its own window. Call [ISldWorks::ActivateDoc2](#) or [IModelDoc2::Visible](#) to ensure that it is. If the assembly is only open as a reference in another document, then this method returns swComponentResolveStatus_e.swResolveNotPerformed.

 See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::GetLightWeightComponentCount Method](#)
[IAssemblyDoc::LightweightAllResolved Method](#)
[IAssemblyDoc::ResolveAllLightweight Method](#)
[IAssemblyDoc::ResolveOutOfDateLightWeightComponents Method](#)
[IAssemblyDoc::SetComponentSuppression Method](#)
[IAssemblyDoc::SelectiveOpen Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResolveOutOfDateLightWeightComponents Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ResolveOutOfDateLightWeightComponents Method (IAssemblyDoc)

Resolves the selected out-of-date lightweight component, and any out-of-date lightweight sub-components, in the assembly.

 .NET Syntax

Visual Basic (Declaration)

```
Function ResolveOutOfDateLightWeightComponents() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean
```

```
value = instance.ResolveOutOfDateLightWeightComponents()
```

C#

```
System.bool ResolveOutOfDateLightWeightComponents()
```

C++/CLI

```
System.bool ResolveOutOfDateLightWeightComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if out-of-date components are resolved, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ResolveOutOfDateLightWeightComponents](#).

Remarks

You must select a lightweight component before using this method. If the lightweight component and any of its lightweight subcomponents are out-of-date, then this method resolves them. If you selection is invalid, then this method returns false.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::GetLightWeightComponentCount Method](#)
[IAssemblyDoc::LightweightAllResolved Method](#)
[IAssemblyDoc::MakeLightWeight Method](#)
[IAssemblyDoc::ResolveAllLightWeight Method](#)
[IAssemblyDoc::ResolveAllLightWeightComponents Method](#)
[IAssemblyDoc::SetComponentSuppression Method](#)
[IAssemblyDoc::SelectiveOpen Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

RotateComponent Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : RotateComponent Method (IAssemblyDoc)

Displays the Rotate Component PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Sub RotateComponent()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
instance.RotateComponent()
```

C#

```
void RotateComponent()
```

C++/CLI

```
void RotateComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::RotateComponent](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

RotateComponentAxis Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : RotateComponentAxis Method (IAssemblyDoc)

Rotates the component axis by a fixed amount.

.NET Syntax

Visual Basic (Declaration)

```
Sub RotateComponentAxis()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
instance.RotateComponentAxis()
```

C#

```
void RotateComponentAxis()
```

C++/CLI

```
void RotateComponentAxis();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::RotateComponentAxis](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SaveIsolate Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SaveIsolate Method (IAssemblyDoc)

Saves the display characteristics of the [isolated components](#) to a new display state.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveIsolate( _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim Name As System.String  
Dim value As System.Boolean  
  
value = instance.SaveIsolate(Name)
```

C#

```
System.bool SaveIsolate(  
    System.string Name  
)
```

C++/CLI

```
System.bool SaveIsolate(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the new display state to which to save the characteristics of the isolated components

Return Value

True if a new display state of the characteristics of the isolated components is created, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SaveIsolate](#).

Example

[Isolate Component \(C#\)](#)
[Isolate Component \(VB.NET\)](#)
[Isolate Component \(VBA\)](#)

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ExitIsolate Method \(\)](#)
[IAssemblyDoc::SetIsolateVisibility Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic](#).

SelectComponentsBySize Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SelectComponentsBySize Method (IAssemblyDoc)

Selects assembly components by percent of assembly size.

.NET Syntax

Visual Basic (Declaration)

```
Function SelectComponentsBySize( _  
    ByVal Percent As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim Percent As System.Double  
Dim value As System.Boolean  
  
value = instance.SelectComponentsBySize(Percent)
```

C#

```
System.bool SelectComponentsBySize(  
    System.double Percent  
)
```

C++/CLI

```
System.bool SelectComponentsBySize(  
&    System.double Percent  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Percent

0.0 <= Percent of assembly size <= 100.0

Return Value

True if Percent is valid, false if Percent > 100 or Percent < 0

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SelectComponentsBySize](#).

Example

[Select Assembly Components by Size \(VBA\)](#)
[Select Assembly Components by Size \(VB.NET\)](#)
[Select Assembly Components by Size \(C#\)](#)

Remarks

This method corresponds to **Tools > Component Selection > Select By Size**.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IModelDocExtension::SelectByID2 Method \(\)](#)
[IModelDocExtension::SelectAll Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectiveOpen Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SelectiveOpen Method (IAssemblyDoc)

Selectively opens the components of an assembly that is opened in Large Design Review mode.

.NET Syntax

Visual Basic (Declaration)

```
Function SelectiveOpen( _  
    ByVal SelectedComponents As System.Boolean, _  
    ByVal OpenLightWeight As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim SelectedComponents As System.Boolean  
Dim OpenLightWeight As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SelectiveOpen(SelectedComponents, OpenLightWeight)
```

C#

```
System.bool SelectiveOpen(  
    System.bool SelectedComponents,  
    System.bool OpenLightWeight  
)
```

C++/CLI

```
System.bool SelectiveOpen(  
& System.bool SelectedComponents,  
& System.bool OpenLightWeight  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SelectedComponents

True to open only the components in the current selection list, false to open all of the components in the assembly

OpenLightWeight

True to open the components in lightweight mode, false to not

Return Value

True if successful, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SelectiveOpen](#).

Example

[Open Assembly in Large Design Review Mode \(VBA\)](#)
[Open Assembly in Large Design Review Mode \(VB.NET\)](#)
[Open Assembly in Large Design Review Mode \(C#\)](#)

Remarks

This method only works for assemblies that are opened in Large Design Review mode.

To open an assembly in Large Design Review mode:

1. Call [ISldWorks::GetOpenDocSpec](#) to create an instance of [IDocumentSpecification](#).
2. Set [IDocumentSpecification::ViewOnly](#) to true.
3. Call [ISldWorks::OpenDoc7](#), passing it the instance of [IDocumentSpecification](#).

Before calling this method, call [IModelDocExtension::SelectById2](#) to select the components that you want to open.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[ISldWorks::OpenDoc6 Method](#)
[IAssemblyDoc::GetComponents Method](#)
[IAssemblyDoc::GetLightWeightComponentCount Method](#)
[IAssemblyDoc::MakeLightWeight Method](#)
[IAssemblyDoc::ResolveAllLightWeight Method](#)
[IAssemblyDoc::ResolveAllLightWeightComponents Method](#)
[IAssemblyDoc::ResolveOutOfDateLightWeightComponents Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetComponentState Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetComponentState Method (IAssemblyDoc)

Sets the suppression state for the specified components.

.NET Syntax

Visual Basic (Declaration)

```
Function SetComponentState( _
    ByVal SuppressionState As System.Integer, _
    ByVal CompArr As System.Object, _
    ByVal ConfigOption As System.Integer, _
    ByVal WhichConfig As System.String, _
    ByVal SaveClosedDocs As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
Dim SuppressionState As System.Integer
Dim CompArr As System.Object
Dim ConfigOption As System.Integer
Dim WhichConfig As System.String
Dim SaveClosedDocs As System.Boolean
Dim value As System.Boolean

value = instance.SetComponentState(SuppressionState, CompArr, ConfigOption, WhichConfig,
SaveClosedDocs)
```

C#

```
System.bool SetComponentState(
    System.int SuppressionState,
    System.object CompArr,
    System.int ConfigOption,
    System.string WhichConfig,
    System.bool SaveClosedDocs
)
```

C++/CLI

```
System.bool SetComponentState(
    & System.int SuppressionState,
    & System.Object^ CompArr,
    & System.int ConfigOption,
    & System.String^ WhichConfig,
    & System.bool SaveClosedDocs
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SuppressionState

Component suppression state as defined in [swComponentSuppressionState_e](#) (see **Remarks**)

CompArr

Array of [components](#) to change

ConfigOption

Configuration option as defined in [swInConfigurationOpts_e](#)

WhichConfig

Name of the configuration to change

SaveClosedDocs

True saves closed documents, false does not

Return Value

True if the components were changed, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetComponentState](#).

Example

[Set Component State \(VBA\)](#)

Remarks

You cannot set a component to lightweight using this method. Instead, use [IComponent::SetSuppression2](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::SetComponentState Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetComponentSuppression Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetComponentSuppression Method (IAssemblyDoc)

Suppresses, resolves, or sets to lightweight selected components of this assembly in the active configuration only.

.NET Syntax

Visual Basic (Declaration)

```
Function SetComponentSuppression( _  
    ByVal State As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim State As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetComponentSuppression(State)
```

C#

```
System.bool SetComponentSuppression(  
    System.int State  
)
```

C++/CLI

```
System.bool SetComponentSuppression(  
& System.int State  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

State

State to set as defined by [swComponentSuppressionState_e](#) (see **Remarks**)

Return Value

True if the selected components are suppressed, resolved, or set to lightweight, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetComponentSuppression](#).

Remarks

Only swComponentSuppressed, swComponentLightweight, or swComponentResolved are valid values for State. If you specify another value for State, this method does nothing.

This method works on selected components in the active configuration only.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::LightweightAllResolved Method](#)
[IAssemblyDoc::GetLightWeightComponentCount Method](#)
[IAssemblyDoc::MakeLightWeight Method](#)
[IAssemblyDoc::ResolveAllLightweight Method](#)
[IAssemblyDoc::ResolveAllLightWeightComponents Method](#)
[IAssemblyDoc::ResolveOutOfDateLightWeightComponents Method](#)
[IAssemblyDoc::SetComponentState Method](#)
[IComponent2::GetSuppression Method](#)
[IComponent2::IsSuppressed Method](#)
[IComponent2::SetSuppression2 Method](#)

Availability

SOLIDWORKS 2006 SP1, Revision Number 14

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetComponentTransparent Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetComponentTransparent Method (IAssemblyDoc)

Enables or disables transparency on the selected components.

.NET Syntax

Visual Basic (Declaration)

```
Function SetComponentTransparent( _  
    ByVal State As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim State As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.SetComponentTransparent(State)
```

C#

```
System.bool SetComponentTransparent(  
    System.bool State  
)
```

C++/CLI

```
System.bool SetComponentTransparent(  
&    System.bool State  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

State

True to set the components transparent, false to not

Return Value

True if components are transparent, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetComponentTransparent](#).

Example

[Set Components Transparent \(VBA\)](#)

Remarks

If you set the transparent state to True, then the components are automatically assigned a transparency value of 75%.

If you want transparency (and other optical properties) set to specific values, then use the [IComponent2::GetMaterialPropertyValues2](#) and [ISetMaterialPropertyValues2 MethodSetMaterialPropertyValues2 MethodIComponent2::SetMaterialPropertyValues2](#).

To set other component transparencies, set these user preferences: [swEdgesInContextEditTransparencyType](#) and [swEdgesInContextEditTransparency](#). You should set these preferences before editing the part to see their effect while editing the part.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetComponentVisibility Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetComponentVisibility Method (IAssemblyDoc)

Hides or shows the selected component in the specified configurations in this assembly document.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetComponentVisibility( _  
    ByVal Visibility As System.Boolean, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IAssemblyDoc  
Dim Visibility As System.Boolean  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
  
instance.SetComponentVisibility(Visibility, Config_opt, Config_names)
```

C#

```
void SetComponentVisibility(  
    System.bool Visibility,  
    System.int Config\_opt,  
    System.object Config\_names  
)
```

C++/CLI

```
void SetComponentVisibility(  
& System.bool Visibility,  
& System.int Config\_opt,  
& System.Object^ Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Visibility

True to show the selected component, false to hide it

Config_opt

Configuration option as defined in [swInConfigurationOptions_e](#)

Config_names

Array of the names of the configurations for the component

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetComponentVisibility](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IComponent2::ISetVisibility Method](#)
[IComponent2::GetVisibility Method](#)
[IComponent2::SetVisibility Method](#)
[IComponent2::IGetVisibility Method](#)
[IComponent2::Visible Property](#)
[IAssemblyDoc::ISetComponentVisibility Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDroppedFileConfigName Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetDroppedFileConfigName Method (IAssemblyDoc)

Sets the configuration name for the recently dropped file.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDroppedFileConfigName( _  
    ByVal ConfigName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim ConfigName As System.String  
Dim value As System.Boolean
```

```
value = instance.SetDroppedFileConfigName(ConfigName)
```

C#

```
System.bool SetDroppedFileConfigName(  
    System.string ConfigName  
)
```

C++/CLI

```
System.bool SetDroppedFileConfigName(  
& System.String^ ConfigName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName
Name of the configuration to set

Return Value

True if the name is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetDroppedFileConfigName](#).

Remarks

If the configuration name is set in response to the [FileDropNotify](#) event, SOLIDWORKS does not display the dialog for the selected configurator names when a file is dropped in an assembly.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::SetDroppedFileName Method](#)
[IAssemblyDoc::GetDroppedAtEntity Method](#)

Availability

SOLIDWORKS 99 SP03, datecode 1999271

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDroppedFileFeatureName Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetDroppedFileFeatureName Method (IAssemblyDoc)

Sets the name of the feature for the recently dropped file.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDroppedFileFeatureName( _  
    ByVal FeatureName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim FeatureName As System.String  
Dim value As System.Boolean
```

```
value = instance.SetDroppedFileFeatureName(FeatureName)
```

C#

```
System.bool SetDroppedFileFeatureName(  
    System.string FeatureName  
)
```

C++/CLI

```
System.bool SetDroppedFileFeatureName(  
& System.String^ FeatureName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeatureName
Feature name

Return Value

True if the feature name is set, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetDroppedFileFeatureName](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::GetDroppedAtEntity Method](#)

[IAssemblyDoc::SetDroppedFileConfigName Method](#)
[IAssemblyDoc::SetDroppedFileName Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDroppedFileName Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetDroppedFileName Method (IAssemblyDoc)

Sets the new file name for a recently dropped file.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDroppedFileName( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.SetDroppedFileName(FileName)
```

C#

```
System.bool SetDroppedFileName(  
    System.string FileName  
)
```

C++/CLI

```
System.bool SetDroppedFileName(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Name of the file to use for the rest of the drop process

Return Value

True if name is set, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetDroppedFileName](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::GetDroppedAtEntity Method](#)
[IAssemblyDoc::SetDroppedFileConfigName Method](#)
[IAssemblyDoc::SetDroppedFileFeatureName Method](#)
[DAssemblyDocEvents_FileDropPreNotifyEventHandler Delegate](#)
[IPartDoc::SetDroppedFileName Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SetIsolateVisibility Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetIsolateVisibility Method (IAssemblyDoc)

Sets the display characteristics of all of the components not selected to [isolate](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetIsolateVisibility( _
    ByVal Option As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
Dim Option As System.Integer

instance.SetIsolateVisibility(Option)
```

C#

```
void SetIsolateVisibility(
    System.int Option
)
```

C++/CLI

```
void SetIsolateVisibility(
    & System.int Option
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Option
Display characteristics of all of the components not selected to isolate as defined in [swIsolateVisibility_e](#)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetIsolateVisibility](#).

Example

[Isolate Component \(C#\)](#)
[Isolate Component \(VB.NET\)](#)
[Isolate Component \(VBA\)](#)

Remarks

Before you [exit isolate](#), you can [save the display characteristics to a new display state](#), which you can access from the ConfigurationManager. If you do not save before exiting isolate, then the display returns to its original state.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SetSpeedPakConfigurations Method (IAssemblyDoc)

[See Also](#)



Sets the configurations in the selected subassemblies to which to apply SpeedPak in this assembly.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetSpeedPakConfigurations( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
Dim value As System.Boolean  
  
value = instance.SetSpeedPakConfigurations(Config_opt, Config_names)
```

C#

```
System.bool SetSpeedPakConfigurations(  
    System.int Config\_opt,  
    System.object Config\_names  
)
```

C++/CLI

```
System.bool SetSpeedPakConfigurations(  
& System.int Config\_opt,  
& System.Object^ Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#) (see **Remarks**)

Config_names

Array of the names of the configurations in the selected subassemblies to which to apply SpeedPak; valid only if Config_opt = swInConfigurationOpts_e.swSpecifyConfiguration (see **Remarks**)

Return Value

True if the specified configurations in the selected subassemblies are applied SpeedPak, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetSpeedPakConfigurations](#).

Remarks

Valid option for Config_opt is:

- swInConfigurationOpts_e.swAllConfiguration,
- swInConfigurationOpts_e.swSpecifyConfiguration, or
- swInConfigurationOpts_e.swThisConfiguration

If Config_names = swInConfigurationOpts_e.swAllConfiguration or swInConfigurationOpts_e.swThisConfiguration, then pass Nothing or null.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::CreateSpeedPak Method \(\)](#)
[IAssemblyDoc::SetSpeedPakToParent Method \(\)](#)
[IAssemblyDoc::UpdateSpeedPak Method \(\)](#)
[IAssemblyDoc::UseSpeedPak Method \(\)](#)
[IAssemblyDoc::IsSpeedPak Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSpeedPakToParent Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : SetSpeedPakToParent Method (IAssemblyDoc)

Switches the selected subassemblies from the SpeedPak configuration to the parent configuration of the SpeedPak configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSpeedPakToParent() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean
```

```
value = instance.SetSpeedPakToParent()
```

C#

```
System.bool SetSpeedPakToParent()
```

C++/CLI

```
System.bool SetSpeedPakToParent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the selected subassemblies switch from the SpeedPak configuration to the parent configuration of the SpeedPak configuration, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::SetSpeedPakToParent](#).

Example

[Create SpeedPak for Subassemblies \(C#\)](#)
[Create SpeedPak for Subassemblies \(VB.NET\)](#)
[Create SpeedPak for Subassemblies \(VBA\)](#)

Remarks

To switch back to the SpeedPak configuration, use [IAssemblyDoc::UseSpeedPak](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::CreateSpeedPak Method \(\)](#)
[IAssemblyDoc::SetSpeedPakConfigurations Method \(\)](#)
[IAssemblyDoc::UpdateSpeedPak Method \(\)](#)
[IAssemblyDoc::IsSpeedPak Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0