

SOLIDWORKS API (.NET VBA C#) — Reference

(38/337): ICenterLine-ICenterOfMass

SOLIDWORKS API Documentation (converted from CHM)

ICenterLine (Type)

ICenterLine Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterLine Interface

Allows access to a centerline.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ICenterLine

Visual Basic (Usage)

Dim instance As [ICenterLine](#)

C#

public interface ICenterLine

C++/CLI

public interface class ICenterLine

Visual Basic for Applications (VBA) Syntax

See [CenterLine](#).

Example

[Get Centerlines in Drawing \(C#\)](#)
[Get Centerlines in Drawing \(VB.NET\)](#)
[Get Centerlines in Drawing \(VBA\)](#)

Accessors

- [IAngleMateFeatureData::EntitiesToMate](#)
- [ICenterLine::GetNext Method](#)
- [ICoincidentMateFeatureData::EntitiesToMate](#)
- [IDrawingDoc::InsertCenterLine2 Method](#)
- [IRackPinionMateFeatureData::EntitiesToMate](#)
- [IView::GetFirstCenterLine Method](#)
- [IView::GetCenterLines](#) and [IView::IGetCenterLines](#)

Access Diagram

[CenterLine](#)

See Also

[ICenterLine Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICenterLine Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterLine Interface

For a list of all members of this type, see [ICenterLine members](#).

Public Methods

Name	Description
 GetAnnotation	Gets the general annotation for this centerline.
 GetNext	Gets the next centerline in this drawing view .

[Top](#)

See Also

[ICenterLine Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICenterLine Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterLine Interface

The following tables list the members exposed by [ICenterLine](#).

Public Methods

Name	Description
 GetAnnotation	Gets the general annotation for this centerline.
 GetNext	Gets the next centerline in this drawing view .

[Top](#)

See Also

[ICenterLine Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAnnotation Method (ICenterLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterLine Interface](#) : GetAnnotation Method (ICenterLine)

Gets the general annotation for this centerline.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As ICenterLine  
Dim value As Annotation  
  
value = instance.GetAnnotation()
```

C#

```
Annotation GetAnnotation()
```

C++/CLI

```
Annotation^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [CenterLine::GetAnnotation](#).

Example

[Get Centerline Annotation Information \(VBA\)](#)
[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)
[Get Centerlines in Drawing \(C#\)](#)
[Get Centerlines in Drawing \(VB.NET\)](#)
[Get Centerlines in Drawing \(VBA\)](#)

See Also

[ICenterLine Interface](#)
[ICenterLine Members](#)

Availability

SOLIDWORKS 2003 SP1, Revision 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (ICenterLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterLine Interface](#) : GetNext Method (ICenterLine)

Gets the next centerline in this [drawing view](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As Centerline
```

Visual Basic (Usage)



```
Dim instance As ICenterLine  
Dim value As Centerline  
  
value = instance.GetNext()
```

C#

```
Centerline GetNext()
```

C++/CLI

```
Centerline^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [centerline](#) in this drawing view

Visual Basic for Applications (VBA) Syntax

See [CenterLine::GetNext](#).

Example

[Get Centerlines in Drawing \(C#\)](#)
[Get Centerlines in Drawing \(VB.NET\)](#)
[Get Centerlines in Drawing \(VBA\)](#)

See Also

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

ICenterMark (Type)

ICenterMark Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterMark Interface

Allows access to a center mark or center mark set in a [drawing view](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICenterMark
```

Visual Basic (Usage)

```
Dim instance As ICenterMark
```

C#

```
public interface ICenterMark
```

C++/CLI

```
public interface class ICenterMark
```

Visual Basic for Applications (VBA) Syntax

See [CenterMark](#).

Example

[Select All Center Marks \(C#\)](#)
[Select All Center Marks \(VB.NET\)](#)
[Select All Center Marks \(VBA\)](#)
[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

Remarks

Center marks are now annotations. Previously, center marks were features.

Use [ICenterMark::GetAnnotation](#) to access the [IAnnotation](#) APIs. If you use [ISelectionMgr::GetSelectedObject6](#) or [ISelectionMgr::GetSelectedObjectType3](#) to retrieve center marks, then these values are returned:

- swSelCENTERMARKSSYMS = 100 for the center marks that are annotations
- swSelCENTERMARKS = 28 for the center marks that are features

Both methods retrieve the ICenterMark object.

To...	Use...
Traverse center marks that are annotations	IView::GetFirstAnnotation3 , IAnnotation::GetNext3 or IView::GetFirstCenterMark , and ICenterMark::GetNext
Retrieve center marks that are features	IView::GetCenterMarkCount2 and IView::GetCenterMarks

Center marks are displayed using the document's default display attribute settings. If you want the setting to be local to this symbol, then set the [ICenterMark::UseDocDisplaySettings](#) property to false and modify the [ICenterMark::ShowLines](#), [ICenterMark::Size](#), and [ICenterMark::CenterLineFont](#) properties as needed.

A center mark set is a linear or circular pattern.

Accessors

[ICenterMark::GetNext Method](#)

[IDrawingDoc::InsertCenterMark3 Method](#)

[IView::GetCenterMarks](#) and [IView::IGetCenterMarks Method](#)

[IView::GetFirstCenterMark Method](#)

Access Diagram

[CenterMark](#)

See Also

[ICenterMark Members](#)

[SolidWorks.Interop.sldworks Namespace](#)

[IView::AutoInsertCenterMarks Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICenterMark Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterMark Interface

For a list of all members of this type, see [ICenterMark members](#).

Public Methods

Name	Description
 AddToCenterMarkGroup	Adds a center mark for the selected entity in an existing center mark set.
 GetAnnotation	Gets the annotation for this center mark.
 GetExtendedLength	Gets the extended length of the specified arm (handle) of this center mark.
 GetNext	Gets the next center mark.
 GetPosition	Gets the x, y, and z coordinates for the specified center mark.
 HasDetachCenterMark	Gets whether the selected center mark set contains any detached center marks.
 IsDeleted	Gets whether the specified center mark is deleted in this center mark set.
 IsDetached	Gets whether the specified center mark is detached.
 ReattachToCenterMarkGroup	Reattaches the specified center mark to the selected entity in a center mark set.
 Select	Selects the center mark.
 SetExtendedLength	Sets the extended length of this center mark.

[Top](#)

See Also

[ICenterMark Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

[IView::AutoInsertCenterMarks Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICenterMark Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterMark Interface

The following tables list the members exposed by [ICenterMark](#).

Public Properties

Name	Description
 CenterLineFont	Gets or sets whether the centerline font is used for the lines in this center mark.

 ConnectionLines	Gets or sets the visibility of the connection line of this center mark.
 Gap	Gets or sets the gap between this center mark and extension line.
 GroupCount	Gets the number of center marks in a center mark set.
 IsGrouped	Gets whether a center mark is in a center mark set.
 RotationAngle	Gets or sets the angle for this center mark.
 ShowLines	Gets or sets whether the extension lines are shown in this center mark.
 Size	Gets or sets the length of the lines in this center mark.
 Style	Gets the style of this center mark.
 UseDocDisplaySettings	Gets or sets whether to use the document defaults for this center mark's display settings.

[Top](#)

Public Methods

Name	Description
 AddToCenterMarkGroup	Adds a center mark for the selected entity in an existing center mark set.
 GetAnnotation	Gets the annotation for this center mark.
 GetExtendedLength	Gets the extended length of the specified arm (handle) of this center mark.
 GetNext	Gets the next center mark.
 GetPosition	Gets the x, y, and z coordinates for the specified center mark.
 HasDetachCenterMark	Gets whether the selected center mark set contains any detached center marks.
 IsDeleted	Gets whether the specified center mark is deleted in this center mark set.
 IsDetached	Gets whether the specified center mark is detached.
 ReattachToCenterMarkGroup	Reattaches the specified center mark to the selected entity in a center mark set.
 Select	Selects the center mark.
 SetExtendedLength	Sets the extended length of this center mark.

[Top](#)

See Also

[ICenterMark Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IView::AutoInsertCenterMarks Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICenterMark Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ICenterMark Interface

For a list of all members of this type, see [ICenterMark members](#).

Public Properties

Name	Description
 CenterLineFont	Gets or sets whether the centerline font is used for the lines in this center mark.
 ConnectionLines	Gets or sets the visibility of the connection line of this center mark.
 Gap	Gets or sets the gap between this center mark and extension line.
 GroupCount	Gets the number of center marks in a center mark set.
 IsGrouped	Gets whether a center mark is in a center mark set.
 RotationAngle	Gets or sets the angle for this center mark.
 ShowLines	Gets or sets whether the extension lines are shown in this center mark.
 Size	Gets or sets the length of the lines in this center mark.



[Style](#)

Gets the style of this center mark.



[UseDocDisplaySettings](#)

Gets or sets whether to use the document defaults for this center mark's display settings.

[Top](#)

See Also

[ICenterMark Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

[IView::AutoInsertCenterMarks Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddToCenterMarkGroup Method (ICenterMark)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : AddToCenterMarkGroup Method (ICenterMark)

Adds a center mark for the selected entity in an existing center mark set.

.NET Syntax

Visual Basic (Declaration)

```
Function AddToCenterMarkGroup() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim value As System.Boolean
```

```
value = instance.AddToCenterMarkGroup()
```

C#

```
System.bool AddToCenterMarkGroup()
```

C++/CLI

```
System.bool AddToCenterMarkGroup();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a center mark is added for the selected entity in an existing center mark set, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CenterMark::AddToCenterMarkGroup](#).

Remarks

You must pre-select an entity in an existing center mark set (i.e., a linear or circular pattern) for which to add a center mark. If the existing center mark set is a linear pattern, then the selected entity must be in that linear pattern, else this method fails. The same rule applies when adding an entity to an existing center mark set that is a circular pattern.

To determine if a center mark is in a center mark set, use [ICenterMark::IsGrouped](#).

See Also

[ICenterMark Interface](#)

[ICenterMark Members](#)

[ICenterMark::GroupCount Property \(\)](#)

[ICenterMark::HasDetachCenterMark Method \(\)](#)

[ICenterMark::IsDetached Method \(\)](#)

[ICenterMark::ReattachToCenterMarkGroup Method \(\)](#)

Availability

CenterLineFont Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : CenterLineFont Property (ICenterMark)

Gets or sets whether the centerline font is used for the lines in this center mark.

.NET Syntax

Visual Basic (Declaration)

Property CenterLineFont As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim value As System.Boolean

instance.CenterLineFont = value

value = instance.CenterLineFont
```

C#

```
System.bool CenterLineFont {get; set;}
```

C++/CLI

```
property System.bool CenterLineFont {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if centerline font is used for the lines in center marks, false if not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::CenterLineFont](#).

Example

[List Center Marks in Drawing \(VBA\)](#)

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

ConnectionLines Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : ConnectionLines Property (ICenterMark)

Gets or sets the visibility of the connection line of this center mark.

.NET Syntax

Visual Basic (Declaration)

Property ConnectionLines As System.Integer

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim value As System.Integer

instance.ConnectionLines = value

value = instance.ConnectionLines
```

C#

```
System.int ConnectionLines {get; set;}
```

C++/CLI

```
property System.int ConnectionLines {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

State of the visibility of the connection line as defined in [swCenterMarkConnectionLine_e](#)

Visual Basic for Applications (VBA) Syntax

See [CenterMark::ConnectionLines](#).

Example

[List Center Marks in Drawing_\(VBA\)](#)

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Gap Property (ICenterMark)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : Gap Property (ICenterMark)

Gets or sets the gap between this center mark and extension line.

.NET Syntax

Visual Basic (Declaration)

Property Gap As System.Double

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim value As System.Double

instance.Gap = value

value = instance.Gap
```

C#

```
System.double Gap {get; set;}
```

C++/CLI

```
property System.double Gap {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gap

Visual Basic for Applications (VBA) Syntax

See [CenterMark::Gap](#).

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : GetAnnotation Method (ICenterMark)

Gets the annotation for this center mark.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim value As Annotation  
  
value = instance.GetAnnotation()
```

C#

```
Annotation GetAnnotation()
```

C++/CLI

```
Annotation^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#) object

Visual Basic for Applications (VBA) Syntax

See [CenterMark::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)
[Select All Center Marks \(C#\)](#)
[Select All Center Marks \(VB.NET\)](#)
[Select All Center Marks \(VBA\)](#)

Remarks

This method returns null or nothing for center marks created as features (earlier style of center marks). See [ICenterMark](#) for details about the old and new style center marks. See SOLIDWORKS Help for details about center marks.

For example, if [ISelectionMgr::GetSelectedObjectType3](#) equals swSelCENTERMARKS, then ICenterMark::GetAnnotation equals null or nothing. But, if ISelectionMgr::GetSelectedObjectType3 equals swSelCENTERMARKSYMS, then ICenterMark::GetAnnotation points to the IAnnotation object.

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExtendedLength Method (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : GetExtendedLength Method (ICenterMark)

Gets the extended length of the specified arm (handle) of this center mark.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExtendedLength( _  
    ByVal GroupID As System.Integer, _  
    ByVal HandleID As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim GroupID As System.Integer  
Dim HandleID As System.Integer  
Dim value As System.Double  
  
value = instance.GetExtendedLength(GroupID, HandleID)
```

C#

```
System.double GetExtendedLength(  
    System.int GroupID,  
    System.int HandleID  
)
```

C++/CLI

```
System.double GetExtendedLength(  
& System.int GroupID,  
& System.int HandleID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GroupID
Center mark instance (see **Remarks**)
HandleID
Center mark handle ID as defined in [swCenterMarkHandle_e](#)

Return Value

Extended length of the HandleID

Visual Basic for Applications (VBA) Syntax

See [CenterMark::GetExtendedLength](#).

Example

[Extend Arms of Center Mark \(VBA\)](#)
[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

Remarks

If the center mark is in a center mark set (i.e., a linear or circular pattern), then use [ICenterMark::GroupCount](#) to get the range of valid values for the GroupID parameter. You can use a value from 0 to ICenterMark::GroupCount for the GroupID parameter. To determine if a center mark is in center mark set, use [ICenterMark::IsGrouped](#).

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)
[ICenterMark::SetExtendedLength Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : GetNext Method (ICenterMark)

Gets the next center mark.

.NET Syntax

Visual Basic (Declaration)

Function GetNext() As CenterMark

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim value As CenterMark

value = instance.GetNext()
```

C#

CenterMark GetNext()

C++/CLI

CenterMark^ GetNext();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [center mark](#)

Visual Basic for Applications (VBA) Syntax

See [CenterMark::GetNext](#).

Example

[List Center Marks in Drawing \(VBA\)](#)
[Select All Center Marks \(C#\)](#)
[Select All Center Marks \(VB.NET\)](#)
[Select All Center Marks \(VBA\)](#)

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)
[IView::GetCenterMarks Method](#)
[IView::GetFirstCenterMark Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPosition Method (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : GetPosition Method (ICenterMark)

Gets the x, y, and z coordinates for the specified center mark.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPosition( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetPosition(Index)
```

C#

```
System.Object GetPosition(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetPosition(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the center mark (see **Remarks**)

Return Value

Array of three doubles of the x, y, and z coordinates of the center mark specified by Index

Visual Basic for Applications (VBA) Syntax

See [CenterMark::GetPosition](#).

Example

[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

Remarks

This method is available to center marks in a center mark set and center marks in an array of center marks.

Use:

- [ICenterMark::IsGrouped](#) to determine if the center mark is in a center mark set (i.e., a linear or circular pattern)
- [ICenterMark::GroupCount](#) to get a valid value for Index for a center mark in a center mark set.

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GroupCount Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : GroupCount Property (ICenterMark)

Gets the number of center marks in a center mark set.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property GroupCount As System.Integer

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim value As System.Integer  
  
value = instance.GroupCount
```

C#

```
System.int GroupCount {get;}
```

C++/CLI

```
property System.int GroupCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of center marks in a center mark set

Visual Basic for Applications (VBA) Syntax

See [CenterMark::GroupCount](#).

Example

[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

Remarks

If the center mark is in a center mark set (i.e., a linear or circular pattern), then:

- you can only change the length of the arms of any of the center marks in that pattern; you cannot change any other properties of those center marks. Call [ICenterMark::IsGrouped](#) to determine if a center mark is in a center mark set.
- use this property to get a range of valid values for [ICenterMark::GetExtendedLength](#)'s and [ICenterMark::SetExtendedLength](#)'s GroupID parameter. You can use a value from 0 to the number of center marks in a center mark set for the GroupID parameter.

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasDetachCenterMark Method (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : HasDetachCenterMark Method (ICenterMark)

Gets whether the selected center mark set contains any detached center marks.

.NET Syntax

Visual Basic (Declaration)

```
Function HasDetachCenterMark() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim value As System.Boolean
```

```
value = instance.HasDetachCenterMark()
```

C#

```
System.bool HasDetachCenterMark()
```

C++/CLI

```
System.bool HasDetachCenterMark();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the selected center mark set contains any detached center marks, false if not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::HasDetachCenterMark](#).

Example

[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

Remarks

You must select the center mark set before calling this method. To determine if a center mark is in a center mark set (i.e., a linear or circular pattern), use [ICenterMark::IsGrouped](#).

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)
[ICenterMark::IsGrouped Property\(\)](#)

[ICenterMark::GroupCount Property \(\)](#)
[ICenterMark::IsDetached Method \(\)](#)
[ICenterMark::ReattachToCenterMarkGroup Method \(\)](#)
[ICenterMark::AddToCenterMarkGroup Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDeleted Method (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : IsDeleted Method (ICenterMark)

Gets whether the specified center mark is deleted in this center mark set.

.NET Syntax

Visual Basic (Declaration)

```
Function IsDeleted( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim Index As System.Integer  
Dim value As System.Boolean
```

```
value = instance.IsDeleted(Index)
```

C#

```
System.bool IsDeleted(  
    System.int Index  
)
```

C++/CLI

```
System.bool IsDeleted(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the center mark in the center mark set (see **Remarks**)

Return Value

True if the specified center mark in this center mark set is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::IsDeleted](#).

Example

[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

Remarks

You can use a value from 0 to the [number of center marks in a center mark set](#) for the Index parameter.

See Also

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsDetached Method (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : IsDetached Method (ICenterMark)

Gets whether the specified center mark is detached.

.NET Syntax

Visual Basic (Declaration)

```
Function IsDetached( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.IsDetached(Index)
```

C#

```
System.bool IsDetached(  
    System.int Index  
)
```

C++/CLI

```
System.bool IsDetached(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of center mark (see **Remarks**)

Return Value

True if the center mark specified by Index is detached, false if not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::IsDetached](#).

Example

[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

Remarks

This method is available to center marks in a center mark set and center marks in an array of center marks.

Use:

- [ICenterMark::IsGrouped](#) to determine if the center mark is in a center mark set (i.e., a linear or circular pattern).
- [ICenterMark::GroupCount](#) to get a valid value for Index for a center mark in a center mark set.

Use [ICenterMark::ReattachToCenterMarkGroup](#) to reattach a detached center mark in a center mark set. You cannot reattach a detached center mark that is not in a center mark set.

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)
[ICenterMark::IsGrouped Property \(\)](#)
[ICenterMark::GroupCount Property \(\)](#)
[ICenterMark::HasDetachCenterMark Method \(\)](#)
[ICenterMark::ReattachToCenterMarkGroup Method \(\)](#)
[ICenterMark::AddToCenterMarkGroup Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsGrouped Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : IsGrouped Property (ICenterMark)

Gets whether a center mark is in a center mark set.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property IsGrouped As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim value As System.Boolean

value = instance.IsGrouped
```

C#

```
System.bool IsGrouped {get;}
```

C++/CLI

```
property System.bool IsGrouped {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the center mark is in a center mark set, false if not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::IsGrouped](#).

Example

[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)
[ICenterMark::GroupCount Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

ReattachToCenterMarkGroup Method (ICenterMark)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : ReattachToCenterMarkGroup Method (ICenterMark)

Reattaches the specified center mark to the selected entity in a center mark set.

.NET Syntax

Visual Basic (Declaration)

```
Function ReattachToCenterMarkGroup( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim Index As System.Integer  
Dim value As System.Boolean
```

```
value = instance.ReattachToCenterMarkGroup(Index)
```

C#

```
System.bool ReattachToCenterMarkGroup(  
    System.int Index  
)
```

C++/CLI

```
System.bool ReattachToCenterMarkGroup(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of center mark (see **Remarks**)

Return Value

True if the center mark specified by Index is reattached to the selected entity in a center mark set, false if not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::ReattachToCenterMarkGroup](#).

Remarks

You must pre-select an entity in an existing center mark set (i.e., a linear or circular pattern) for which to reattach the center mark. If the existing center mark set is a linear pattern, then the selected entity must be in that linear pattern, else this method fails. The same rule applies when reattaching an entity to an existing center mark set that is a circular pattern.

Use:

- [ICenterMark::IsGrouped](#) to determine if the center mark is in a center mark set (i.e., a linear or circular pattern).
- [ICenterMark::GroupCount](#) to get a valid value for Index for a center mark in a center mark set.

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)
[ICenterMark::HasDetachCenterMark Method \(\)](#)
[ICenterMark::IsDetached Method \(\)](#)
[ICenterMark::IsGrouped Property \(\)](#)

Availability

RotationAngle Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : RotationAngle Property (ICenterMark)

Gets or sets the angle for this center mark.

.NET Syntax

Visual Basic (Declaration)

Property RotationAngle As System.Double

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim value As System.Double

instance.RotationAngle = value

value = instance.RotationAngle
```

C#

```
System.double RotationAngle {get; set;}
```

C++/CLI

```
property System.double RotationAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle

Visual Basic for Applications (VBA) Syntax

See [CenterMark::RotationAngle](#).

Example

[List Center Marks in Drawing \(VBA\)](#)

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

Select Method (ICenterMark)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : Select Method (ICenterMark)

Selects the center mark.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _
    ByVal Append As System.Boolean, _
    ByVal Data As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim Append As System.Boolean
Dim Data As System.Object
Dim value As System.Boolean

value = instance.Select(Append, Data)
```

C#

```
System.bool Select(
    System.bool Append,
    System.object Data
)
```

C++/CLI

```
System.bool Select(
    & System.bool Append,
    & System.Object^ Data
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append
True appends the center mark to the selection list, false replaces the selection list with this center mark
Data
[SelectData](#) object

Return Value

True if the center mark is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::Select](#).

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetExtendedLength Method (ICenterMark)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : SetExtendedLength Method (ICenterMark)

Sets the extended length of this center mark.

.NET Syntax

Visual Basic (Declaration)

```
Function SetExtendedLength( _
    ByVal GroupID As System.Integer, _
    ByVal HandleID As System.Integer, _
```

```
ByVal ExtendedLength As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim GroupID As System.Integer  
Dim HandleID As System.Integer  
Dim ExtendedLength As System.Double  
Dim value As System.Boolean
```

```
value = instance.SetExtendedLength(GroupID, HandleID, ExtendedLength)
```

C#

```
System.bool SetExtendedLength(  
    System.int GroupID,  
    System.int HandleID,  
    System.double ExtendedLength  
)
```

C++/CLI

```
System.bool SetExtendedLength(  
& System.int GroupID,  
& System.int HandleID,  
& System.double ExtendedLength  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GroupID

Instance of center mark (see **Remarks**)

HandleID

Center mark handle ID as defined by [swCenterMarkHandle_e](#)

ExtendedLength

Extended length of HandleID

Return Value

True if the extended length of the specified center mark is set, false if not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::SetExtendedLength](#).

Example

[Extend Arms of Center Mark \(VBA\)](#)

[Get and Set Center Mark Set \(C#\)](#)

[Get and Set Center Mark Set \(VB.NET\)](#)

[Get and Set Center Mark Set \(VBA\)](#)

Remarks

If the center mark is in a center mark set (i.e., a linear or circular pattern), then use [ICenterMark::GroupCount](#) to get the range of valid values for the GroupID parameter. You can use a value from 0 to ICenterMark::GroupCount for the GroupID parameter. To determine if a center mark is in center mark set, use [ICenterMark::IsGrouped](#).

See Also

[ICenterMark Interface](#)

[ICenterMark Members](#)

[ICenterMark::GetExtendedLength Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

ShowLines Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : ShowLines Property (ICenterMark)

Gets or sets whether the extension lines are shown in this center mark.

.NET Syntax

Visual Basic (Declaration)

Property ShowLines As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICenterMark
Dim value As System.Boolean
```

```
instance.ShowLines = value
```

```
value = instance.ShowLines
```

C#

```
System.bool ShowLines {get; set;}
```

C++/CLI

```
property System.bool ShowLines {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True shows the lines, false does not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::ShowLines](#).

Example

[List Center Marks in Drawing \(VBA\)](#)

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Size Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : Size Property (ICenterMark)

Gets or sets the length of the lines in this center mark.

.NET Syntax

Visual Basic (Declaration)

Property Size As System.Double

```
Dim instance As ICenterMark
Dim value As System.Double

instance.Size = value

value = instance.Size
```

C#

```
System.double Size {get; set;}
```

C++/CLI

```
property System.double Size {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of lines

Visual Basic for Applications (VBA) Syntax

See [CenterMark::Size](#).

Example

[List Center Marks in Drawing \(VBA\)](#)

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : Style Property (ICenterMark)

Gets the style of this center mark.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Style As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ICenterMark
Dim value As System.Integer

value = instance.Style
```

C#

```
System.int Style {get;}
```

C++/CLI

```
property System.int Style {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Center mark style as defined in [swCenterMarkStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [CenterMark::Style](#).

Example

[List Center Marks in Drawing \(VBA\)](#)
[Get and Set Center Mark Set \(C#\)](#)
[Get and Set Center Mark Set \(VB.NET\)](#)
[Get and Set Center Mark Set \(VBA\)](#)

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDocDisplaySettings Property (ICenterMark)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterMark Interface](#) : UseDocDisplaySettings Property (ICenterMark)

Gets or sets whether to use the document defaults for this center mark's display settings.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDocDisplaySettings As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICenterMark  
Dim value As System.Boolean  
  
instance.UseDocDisplaySettings = value  
value = instance.UseDocDisplaySettings
```

C#

```
System.bool UseDocDisplaySettings {get; set;}
```

C++/CLI

```
property System.bool UseDocDisplaySettings {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the document defaults, false does not

Visual Basic for Applications (VBA) Syntax

See [CenterMark::UseDocDisplaySettings](#).

Example

[List Center Marks in Drawing \(VBA\)](#)

Remarks

You can use the following user-preference methods to get or set these document defaults:

- [IModelDocExtension::SetUserPreferenceToggle](#) or [IModelDocExtension::GetUserPreferenceToggle](#) - swDetailingCenterMarkShowLines, swDetailingNoOptionSpecified
- [IModelDocExtension::SetUserPreferenceDouble](#) or [IModelDocExtension::GetUserPreferenceDouble](#) - swDetailingCenterMarkSize, swDetailingNoOptionSpecified

See Also

[ICenterMark Interface](#)
[ICenterMark Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

ICenterOfMass (Type)

ICenterOfMass Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterOfMass Interface

Allows access to the centers of mass in a [drawing view](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICenterOfMass
```

Visual Basic (Usage)



```
Dim instance As ICenterOfMass
```

C#

```
public interface ICenterOfMass
```

C++/CLI

```
public interface class ICenterOfMass
```

Visual Basic for Applications (VBA) Syntax

See [CenterOfMass](#).

Example

[Get Centers of Mass in Drawing Views \(VBA\)](#)
[Get Centers of Mass in Drawing Views \(VB.NET\)](#)
[Get Centers of Mass in Drawing Views \(C#\)](#)

Accessors

[ICenterOfMass::GetNext](#) and [ICenterOfMass::!GetNext](#)
[IView::GetFirstCenterOfMass](#) and [IView::!GetFirstCenterOfMass](#)

Access Diagram

[CenterOfMass](#)

See Also

[ICenterOfMass Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCenterOfMass Method](#)
[IFeatureManager::InsertCenterOfMassReferencePoint Method](#)

ICenterOfMass Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterOfMass Interface

The following tables list the members exposed by [ICenterOfMass](#).

Public Methods

Name	Description
GetAnnotation	Gets the annotation for this center of mass.

		
	GetCoordinates	Gets the coordinates of this center of mass.
	GetNext	Gets the next center of mass in this drawing view.
	IGetAnnotation	Gets the annotation for this center of mass.
	IGetCoordinates	Gets the coordinates of this center of mass.
	IGetNext	Gets the next center of mass in this drawing view.

[Top](#)

See Also

[ICenterOfMass Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCenterOfMass Method](#)
[IFeatureManager::InsertCenterOfMassReferencePoint Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICenterOfMass Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICenterOfMass Interface

For a list of all members of this type, see [ICenterOfMass members](#).

Public Methods

Name	Description
 GetAnnotation	Gets the annotation for this center of mass.
 GetCoordinates	Gets the coordinates of this center of mass.
 GetNext	Gets the next center of mass in this drawing view.
 IGetAnnotation	Gets the annotation for this center of mass.
 IGetCoordinates	Gets the coordinates of this center of mass.
 IGetNext	Gets the next center of mass in this drawing view.

[Top](#)

See Also

[ICenterOfMass Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCenterOfMass Method](#)
[IFeatureManager::InsertCenterOfMassReferencePoint Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAnnotation Method (ICenterOfMass)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterOfMass Interface](#) : GetAnnotation Method (ICenterOfMass)

Gets the annotation for this center of mass.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)

```
Dim instance As ICenterOfMass
Dim value As System.Object

value = instance.GetAnnotation()
```

C#



```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IAnnotation](#)

Visual Basic for Applications (VBA) Syntax

See [CenterOfMass::GetAnnotation](#).

Example

[Get Centers of Mass in Drawing Views \(VBA\)](#)
[Get Centers of Mass in Drawing Views \(VB.NET\)](#)
[Get Centers of Mass in Drawing Views \(C#\)](#)

See Also

[ICenterOfMass Interface](#)
[ICenterOfMass Members](#)
[ICenterOfMass::IGetAnnotation Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCoordinates Method (ICenterOfMass)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterOfMass Interface](#) : GetCoordinates Method (ICenterOfMass)

Gets the coordinates of this center of mass.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCoordinates() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICenterOfMass  
Dim value As System.Object  
  
value = instance.GetCoordinates()
```

C#

```
System.object GetCoordinates()
```

C++/CLI

```
System.Object^ GetCoordinates();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles of the x, y, and z coordinates of the center of mass

Visual Basic for Applications (VBA) Syntax

See [CenterOfMass::GetCoordinates](#).

Example

[Get Centers of Mass in Drawing Views \(VBA\)](#)
[Get Centers of Mass in Drawing Views \(VB.NET\)](#)
[Get Centers of Mass in Drawing Views \(C#\)](#)

See Also

[ICenterOfMass Interface](#)
[ICenterOfMass Members](#)
[ICenterOfMass::IGetCoordinates Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (ICenterOfMass)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterOfMass Interface](#) : GetNext Method (ICenterOfMass)

Gets the next center of mass in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICenterOfMass  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ICenterOfMass](#)

Visual Basic for Applications (VBA) Syntax

See [CenterOfMass::GetNext](#).

Example

[Get Centers of Mass in Drawing Views \(VBA\)](#)
[Get Centers of Mass in Drawing Views \(VB.NET\)](#)
[Get Centers of Mass in Drawing Views \(C#\)](#)

See Also

[ICenterOfMass Interface](#)
[ICenterOfMass Members](#)
[ICenterOfMass::IGetNext Method](#)

Availability

IGetAnnotation Method (ICenterOfMass)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICenterOfMass Interface](#) : IGetAnnotation Method (ICenterOfMass)

Gets the annotation for this center of mass.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As ICenterOfMass
Dim value As Annotation

value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to the [IAnnotation](#) object
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ICenterOfMass Interface](#)
[ICenterOfMass Members](#)
[ICenterOfMass::GetAnnotation Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

IGetCoordinates Method (ICenterOfMass)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICenterOfMass Interface](#) : IGetCoordinates Method (ICenterOfMass)

Gets the coordinates of this center of mass.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCoordinates() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICenterOfMass
Dim value As System.Double

value = instance.IGetCoordinates()
```

C#

```
System.double IGetCoordinates()
```

C++/CLI

```
System.double IGetCoordinates();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles of the x, y, and z coordinates of the center of mass
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ICenterOfMass Interface](#)

[ICenterOfMass Members](#)

[ICenterOfMass::GetCoordinates Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (ICenterOfMass)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICenterOfMass Interface](#) : IGetNext Method (ICenterOfMass)

Gets the next center of mass in this drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As CenterOfMass
```

Visual Basic (Usage)



```
Dim instance As ICenterOfMass
```

```
Dim value As CenterOfMass
```

```
value = instance.IGetNext()
```

C#

```
CenterOfMass IGetNext()
```

C++/CLI

```
CenterOfMass^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to [ICenterOfMass](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ICenterOfMass Interface](#)

[ICenterOfMass Members](#)

[ICenterOfMass::GetNext Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0