

SOLIDWORKS API (.NET VBA C#) — Reference

(39/337) · IChainPatternFeatureData-
IChamferFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IChainPatternFeatureData (Type)

IChainPatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChainPatternFeatureData Interface

Allows access to a chain component pattern feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IChainPatternFeatureData
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData
```

C#

```
public interface IChainPatternFeatureData
```

C++/CLI

```
public interface class IChainPatternFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData](#).

Example

[Create and Modify Distance Chain Pattern Feature \(C#\)](#)
[Create and Modify Distance Chain Pattern Feature \(VB.NET\)](#)
[Create and Modify Distance Chain Pattern Feature \(VBA\)](#)

Remarks

This interface supports the following chain component patterns:

- distance
- distance linkage
- connected linkage

Read [Pattern Features and their Feature Data Objects](#).

Before calling IFeatureManager::CreateDefinition, you must pre-select the entities needed to populate the chain component pattern.

Entity to select	Corresponding Chain Pattern PropertyManager control	Selection mark	Number of selections
2D or 3D sketch containing an open or closed loop, Sketch line, or Model edge	Path	2	1 for all types of chain patterns
Assembly component	Chain Group 1 Component to Pattern	1	1 for all types of chain patterns
- Cylindrical face, - Circular or linear edge, Sketch point, Vertex, or Reference axis	Chain Group 1 Path Link 1	256	1 for all types of chain patterns
- Cylindrical face, - Circular or linear edge, Sketch point, Vertex, or Reference axis	Chain Group 1 Path Link 2	512	1 for distance linkage or connected linkage - None for distance
Component plane or planar face	Chain Group 1 Path Alignment Plane	16384	1 for all types of chain patterns
Assembly component	Chain Group 2 Component to Pattern	2048	1 for connected linkage - None for distance or linkage distance
- Cylindrical face, - Circular or linear edge, Sketch point, Vertex, or Reference axis	Chain Group 2 Path Link 1	4096	1 for connected linkage - None for distance or linkage distance
- Cylindrical face, - Circular or linear edge, Sketch point, Vertex, or Reference axis	Chain Group 2 Path Link 2	8192	1 for connected linkage - None for distance or linkage distance
Component plane or planar face	Group 2 Path Alignment Plane	32768	1 for connected linkage - None for distance or linkage distance

Entity to select	Corresponding Chain Pattern PropertyManager control	Selection mark	Number of selections
Assembly plane	Face normal alignment	1024	1 if the chain path is a sketch line - None for all other types of paths

You must call [IFeatureManager::CreateFeature](#) after initializing this feature data object in order to successfully create the chain component pattern feature.

Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[ChainPatternFeatureData](#)

See Also

[IChainPatternFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IChainPatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChainPatternFeatureData Interface

The following tables list the members exposed by [IChainPatternFeatureData](#).

Public Properties

Name	Description
AlignMethod	Gets or sets how to align this chain pattern feature.
FillPath	Gets or sets whether the maximum number of pattern instances to fill the path is calculated by SOLIDWORKS for this chain pattern feature.
ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this chain pattern feature.
Group1FlipPlane	Gets or sets whether to flip the position plane for Chain Group 1 in this chain pattern feature.
Group1PathLink1	Gets or sets Path Link 1 in Chain Group 1 in this chain pattern feature.
Group1PathLink2	Gets or sets Path Link 2 in Chain Group 1 in this chain pattern feature.
Group1PathPlane	Gets or sets the position of the pattern component relative to the path in Chain Group 1 in this chain pattern feature.
Group1PatternComponent	Gets or sets the component to pattern for Chain Group 1 in this chain pattern feature.
Group2FlipPlane	Gets or sets whether to flip the position plane for Chain Group 2 in this chain pattern feature.
Group2PathLink1	Gets or sets Path Link 1 in Chain Group 2 in this chain pattern feature.
Group2PathLink2	Gets or sets Path Link 2 in Chain Group 2 in this chain pattern feature.
Group2PathPlane	Gets or sets the position of the pattern component relative to the path in Chain Group 2 in this chain pattern feature.
Group2PatternComponent	Gets or sets the component to pattern for Chain Group 2 in this chain pattern feature.
InstanceCount	Gets or sets the number of pattern instances in this chain pattern feature.
Options	Gets or sets whether to calculate the mates between each pattern instance or copy each pattern instance without creating mates in this chain pattern feature.
Path	Gets or sets the path for this chain pattern feature.
PathPlaneReference	Gets or sets the reference plane for the path selected for this chain pattern feature.
PitchMethod	Gets or sets the pitch method for this chain pattern feature.
ReverseDirection	Gets or sets whether to reverse the direction of the path in this chain pattern feature.
Spacing	Gets or sets the distance between the pattern instances in the path in this chain pattern feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this chain pattern feature.
 ClearGroup2Selections	Clears Chain Group 2 selections in this connected linkage chain pattern feature.
 ReleaseSelectionAccess	Releases access to the selections that define this chain pattern feature.
 SetEqualSpacing	Sets equal spacing between each chain pattern instance in this chain pattern feature.

[Top](#)

See Also

[IChainPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IChainPatternFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IChainPatternFeatureData Interface

For a list of all members of this type, see [IChainPatternFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this chain pattern feature.
 ClearGroup2Selections	Clears Chain Group 2 selections in this connected linkage chain pattern feature.
 ReleaseSelectionAccess	Releases access to the selections that define this chain pattern feature.
 SetEqualSpacing	Sets equal spacing between each chain pattern instance in this chain pattern feature.

[Top](#)

See Also

[IChainPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IChainPatternFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IChainPatternFeatureData Interface

For a list of all members of this type, see [IChainPatternFeatureData members](#).

Public Properties

Name	Description
 AlignMethod	Gets or sets how to align this chain pattern feature.
 FillPath	Gets or sets whether the maximum number of pattern instances to fill the path is calculated by SOLIDWORKS for this chain pattern feature.
 ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this chain pattern feature.
 Group1FlipPlane	Gets or sets whether to flip the position plane for Chain Group 1 in this chain pattern feature.
 Group1PathLink1	Gets or sets Path Link 1 in Chain Group 1 in this chain pattern feature.
 Group1PathLink2	Gets or sets Path Link 2 in Chain Group 1 in this chain pattern feature.
 Group1PathPlane	Gets or sets the position of the pattern component relative to the path in Chain Group 1 in this chain pattern feature.
 Group1PatternComponent	Gets or sets the component to pattern for Chain Group 1 in this chain pattern feature.
 Group2FlipPlane	Gets or sets whether to flip the position plane for Chain Group 2 in this chain pattern feature.
 Group2PathLink1	Gets or sets Path Link 1 in Chain Group 2 in this chain pattern feature.
 Group2PathLink2	Gets or sets Path Link 2 in Chain Group 2 in this chain pattern feature.
 Group2PathPlane	Gets or sets the position of the pattern component relative to the path in Chain Group 2 in this chain pattern feature.

 Group2PatternComponent	Gets or sets the component to pattern for Chain Group 2 in this chain pattern feature.
 InstanceCount	Gets or sets the number of pattern instances in this chain pattern feature.
 Options	Gets or sets whether to calculate the mates between each pattern instance or copy each pattern instance without creating mates in this chain pattern feature.
 Path	Gets or sets the path for this chain pattern feature.
 PathPlaneReference	Gets or sets the reference plane for the path selected for this chain pattern feature.
 PitchMethod	Gets or sets the pitch method for this chain pattern feature.
 ReverseDirection	Gets or sets whether to reverse the direction of the path in this chain pattern feature.
 Spacing	Gets or sets the distance between the pattern instances in the path in this chain pattern feature.

[Top](#)

See Also

[IChainPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IChainPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : AccessSelections Method (IChainPatternFeatureData)

Gains access to the selections that define this chain pattern feature.

NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code.](#)

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which to modify the feature (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::AccessSelections](#).

Example

[Create and Modify Distance Chain Pattern Feature \(C#\)](#)
[Create and Modify Distance Chain Pattern Feature \(VB.NET\)](#)
[Create and Modify Distance Chain Pattern Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the ModelDoc2 object for the part - Component argument is Nothing or null
Assembly	- TopDoc is the ModelDoc2 object for the assembly - Component argument is the Component2 object in which to modify the feature

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IChainPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AlignMethod Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : AlignMethod Property (IChainPatternFeatureData)

Gets or sets how to align this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property AlignMethod As System.Integer

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Integer
```

```
instance.AlignMethod = value
```

```
value = instance.AlignMethod
```

C#

```
System.int AlignMethod {get; set;}
```

C++/CLI

```
property System.int AlignMethod {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Align method as defined in [swChainPatternAlignment_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::AlignMethod](#).

Remarks

This property is only available for distance chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ClearGroup2Selections Method (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : ClearGroup2Selections Method (IChainPatternFeatureData)

Clears **Chain Group 2** selections in this connected linkage chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ClearGroup2Selections() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Boolean
```

```
value = instance.ClearGroup2Selections()
```

C#

```
System.bool ClearGroup2Selections()
```

C++/CLI

```
System.bool ClearGroup2Selections();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if **Chain Group 2** selections are cleared, false if no selections for **Chain Group 2** existed (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::ClearGroup2Selections](#).

Remarks

This method allows you to change a **Chain Group 1** and **Chain Group 2** connected linkage chain pattern feature to a **Chain Group 1** connected linkage chain pattern feature.

This property is only available to connected linkage chain patterns.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group2FlipPlane Property \(\)](#)
[IChainPatternFeatureData::Group2PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group2PathLink2 Property \(\)](#)
[IChainPatternFeatureData::Group2PathPlane Property \(\)](#)
[IChainPatternFeatureData::Group2PatternComponent Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FillPath Property (IChainPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : FillPath Property (IChainPatternFeatureData)

Gets or sets whether the maximum number of pattern instances to fill the path is calculated by SOLIDWORKS for this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FillPath As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Boolean
```

```
instance.FillPath = value
```

```
value = instance.FillPath
```

C#

```
System.bool FillPath {get; set;}
```

C++/CLI

```
property System.bool FillPath {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the maximum number of pattern instances to fill the path is calculated by SOLIDWORKS, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::FillPath](#).

Example

[Create and Modify Distance Chain Pattern Feature \(C#\)](#)
[Create and Modify Distance Chain Pattern Feature \(VB.NET\)](#)
[Create and Modify Distance Chain Pattern Feature \(VBA\)](#)

Remarks

This property is available for all types of chain patterns, but it is only available for distance and distance linkage chain patterns when [equal spacing](#) is not set.

To set the distance between the pattern instances, use [IChainPatternFeatureData::Spacing](#).

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ForceUseSeedConfiguration Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : ForceUseSeedConfiguration Property (IChainPatternFeatureData)

Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property ForceUseSeedConfiguration As System.Boolean

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Boolean
```

```
instance.ForceUseSeedConfiguration = value
```

```
value = instance.ForceUseSeedConfiguration
```

C#

```
System.bool ForceUseSeedConfiguration {get; set;}
```

C++/CLI

```
property System.bool ForceUseSeedConfiguration {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the seed component configuration for all pattern components, false to not

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::ForceUseSeedConfiguration](#).

Remarks

If this property is set to true, the **Referenced configuration** section of the Component Properties dialog is disabled, and you cannot use [IComponent2::ReferencedConfiguration](#) to change the pattern instance configuration.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

Group1FlipPlane Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group1FlipPlane Property (IChainPatternFeatureData)

Gets or sets whether to flip the [position plane](#) for **Chain Group 1** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Group1FlipPlane As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Boolean
```

```
instance.Group1FlipPlane = value
```

```
value = instance.Group1FlipPlane
```

C#

```
System.bool Group1FlipPlane {get; set;}
```

C++/CLI

```
property System.bool Group1FlipPlane {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the position plane, false to not

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group1FlipPlane](#).

Remarks

This property is available for all types of chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group1PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group1PathLink2 Property \(\)](#)
[IChainPatternFeatureData::Group1PathPlane Property \(\)](#)
[IChainPatternFeatureData::Group1PatternComponent Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Group1PathLink1 Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group1PathLink1 Property (IChainPatternFeatureData)

Gets or sets **Path Link 1** in **Chain Group 1** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property Group1PathLink1 As System.Object

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData
Dim value As System.Object

instance.Group1PathLink1 = value

value = instance.Group1PathLink1
```

C#

```
System.object Group1PathLink1 {get; set;}
```

C++/CLI

```
property System.Object^ Group1PathLink1 {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path Link 1 in Chain Group 1:

- Cylindrical [face](#).
- Circular or linear [edge](#).
- [Sketch point](#).
- [Vertex](#), or
- [Reference axis](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group1PathLink1](#).

Remarks

This property is available for all types of chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group1FlipPlane Property \(\)](#)
[IChainPatternFeatureData::Group1PathLink2 Property \(\)](#)
[IChainPatternFeatureData::Group1PathPlane Property \(\)](#)
[IChainPatternFeatureData::Group1PatternComponent Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Group1PathLink2 Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group1PathLink2 Property (IChainPatternFeatureData)

Gets or sets **Path Link 2** in **Chain Group 1** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Group1PathLink2 As System.Object
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData
Dim value As System.Object

instance.Group1PathLink2 = value

value = instance.Group1PathLink2
```

C#

```
System.Object Group1PathLink2 {get; set;}
```

C++/CLI

```
property System.Object^ Group1PathLink2 {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path Link 2 in Chain Group 1:

- Cylindrical [face](#).
- Circular or linear [edge](#).
- [Sketch point](#).
- [Vertex](#), or
- [Reference axis](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group1PathLink2](#).

Remarks

This property is only available for distance linkage and connected linkage chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group1FlipPlane Property \(\)](#)
[IChainPatternFeatureData::Group1PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group1PathPlane Property \(\)](#)
[IChainPatternFeatureData::Group1PatternComponent Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Group1PathPlane Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group1PathPlane Property (IChainPatternFeatureData)

Gets or sets the position of the [pattern component](#) relative to the [path](#) in **Chain Group 1** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Group1PathPlane As System.Object
```

Visual Basic (Usage)

```
Dim instance As IChainPatternFeatureData
Dim value As System.Object
```



```
instance.Group1PathPlane = value  
value = instance.Group1PathPlane
```

C#

```
System.Object Group1PathPlane {get; set;}
```

C++/CLI

```
property System.Object^ Group1PathPlane {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Component [plane](#) or planar [face](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group1PathPlane](#).

Remarks

This property is available for all types of chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group1FlipPlane Property \(\)](#)
[IChainPatternFeatureData::Group1PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group1PathLink2 Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Group1PatternComponent Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group1PatternComponent Property (IChainPatternFeatureData)

Gets or sets the component to pattern for **Chain Group 1** in this chain pattern feature.

Visual Basic .NET Syntax

Visual Basic (Declaration)

```
Property Group1PatternComponent As System.Object
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Object
```

```
instance.Group1PatternComponent = value
```

```
value = instance.Group1PatternComponent
```

C#

```
System.Object Group1PatternComponent {get; set;}
```

C++/CLI

```
property System.Object^ Group1PatternComponent {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Component](#) to pattern

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group1PatternComponent](#).

Remarks

This property is available to all types of chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group1FlipPlane Property \(\)](#)
[IChainPatternFeatureData::Group1PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group1PathLink2 Property \(\)](#)
[IChainPatternFeatureData::Group1PathPlane Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Group2FlipPlane Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group2FlipPlane Property (IChainPatternFeatureData)

Gets or sets whether to flip the [position plane](#) for **Chain Group 2** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property Group2FlipPlane As System.Boolean

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData
Dim value As System.Boolean
```

```
instance.Group2FlipPlane = value
```

```
value = instance.Group2FlipPlane
```

C#

```
System.bool Group2FlipPlane {get; set;}
```

C++/CLI

```
property System.bool Group2FlipPlane {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the position plane, false to not

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group2FlipPlane](#).

Remarks

This property is only available for connected linkage chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group2PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group2PathLink2 Property \(\)](#)
[IChainPatternFeatureData::Group2PathPlane Property \(\)](#)
[IChainPatternFeatureData::Group2PatternComponent Property \(\)](#)
[IChainPatternFeatureData::ClearGroup2Selections Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Group2PathLink1 Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group2PathLink1 Property (IChainPatternFeatureData)

Gets or sets **Path Link 1** in **Chain Group 2** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Group2PathLink1 As System.Object
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Object
```

```
instance.Group2PathLink1 = value
```

```
value = instance.Group2PathLink1
```

C#

```
System.Object Group2PathLink1 {get; set;}
```

C++/CLI

```
property System.Object^ Group2PathLink1 {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path Link 1 in **Chain Group 2**:

- Cylindrical [face](#).
- Circular or linear [edge](#).
- [Sketch point](#).
- [Vertex](#), or
- [Reference axis](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group2PathLink1](#).

Remarks

This property is only available for connected linkage chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group2FlipPlane Property\(\)](#)
[IChainPatternFeatureData::Group2PathLink2 Property\(\)](#)
[IChainPatternFeatureData::Group2PathPlane Property\(\)](#)
[IChainPatternFeatureData::Group2PatternComponent Property\(\)](#)
[IChainPatternFeatureData::ClearGroup2Selections Method\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Group2PathLink2 Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group2PathLink2 Property (IChainPatternFeatureData)

Gets or sets **Path Link 2** in **Chain Group 2** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Group2PathLink2 As System.Object
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Object
```

```
instance.Group2PathLink2 = value
```

```
value = instance.Group2PathLink2
```

C#

```
System.Object Group2PathLink2 {get; set;}
```

C++/CLI

```
property System.Object^ Group2PathLink2 {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path Link 2 in Chain Group 2:

- Cylindrical [face](#).
- Circular or linear [edge](#).
- [Sketch point](#).
- [Vertex](#), or
- [Reference axis](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group2PathLink2](#).

Remarks

This property is only available for connected linkage chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group2FlipPlane Property \(\)](#)
[IChainPatternFeatureData::Group2PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group2PathPlane Property \(\)](#)
[IChainPatternFeatureData::Group2PatternComponent Property \(\)](#)
[IChainPatternFeatureData::ClearGroup2Selections Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Group2PathPlane Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group2PathPlane Property (IChainPatternFeatureData)

Gets or sets the position of the [pattern component](#) relative to the [path](#) in **Chain Group 2** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property Group2PathPlane As System.Object

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Object
```

```
instance.Group2PathPlane = value
```

```
value = instance.Group2PathPlane
```

C#

```
System.Object Group2PathPlane {get; set;}
```

C++/CLI

```
property System.Object^ Group2PathPlane {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Component [plane](#) or planar [face](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group2PathPlane](#).

Remarks

This property is only available for connected linkage chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group2FlipPlane Property \(\)](#)

[IChainPatternFeatureData::Group2PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group2PathLink2 Property \(\)](#)
[IChainPatternFeatureData::ClearGroup2Selections Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Group2PatternComponent Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Group2PatternComponent Property (IChainPatternFeatureData)

Gets or sets the component to pattern for **Chain Group 2** in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Group2PatternComponent As System.Object
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Object
```

```
instance.Group2PatternComponent = value
```

```
value = instance.Group2PatternComponent
```

C#

```
System.Object Group2PatternComponent {get; set;}
```

C++/CLI

```
property System.Object^ Group2PatternComponent {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Component](#) to pattern

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Group2PatternComponent](#).

Remarks

This property is only available to connected linkage chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::Group2FlipPlane Property \(\)](#)
[IChainPatternFeatureData::Group2PathLink1 Property \(\)](#)
[IChainPatternFeatureData::Group2PathLink2 Property \(\)](#)
[IChainPatternFeatureData::Group2PathPlane Property \(\)](#)
[IChainPatternFeatureData::ClearGroup2Selections Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InstanceCount Property (IChainPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : InstanceCount Property (IChainPatternFeatureData)

Gets or sets the number of pattern instances in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property InstanceCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Integer
```

```
instance.InstanceCount = value
```

```
value = instance.InstanceCount
```

C#

```
System.int InstanceCount {get; set;}
```

C++/CLI

```
property System.int InstanceCount {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of pattern instances

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::InstanceCount](#).

Example

[Create and Modify Distance Chain Pattern Feature \(C#\)](#)
[Create and Modify Distance Chain Pattern Feature \(VB.NET\)](#)
[Create and Modify Distance Chain Pattern Feature \(VBA\)](#)

Remarks

This property is available to all types of chain patterns when [IChainPatternFeatureData::FillPath](#) is false.

If the pattern instances are not [equally spaced](#), then use [IChainPatternFeatureData::Spacing](#) to specify the distance between each pattern instance.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Options Property (IChainPatternFeatureData)

Gets or sets whether to calculate the mates between each pattern instance or copy each pattern instance without creating mates in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property Options As System.Integer

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData
Dim value As System.Integer
```

```
instance.Options = value
```

```
value = instance.Options
```

C#

```
System.int Options {get; set;}
```

C++/CLI

```
property System.int Options {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Option as defined in [swChainPatternOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Options](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Path Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Path Property (IChainPatternFeatureData)

Gets or sets the path for this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property Path As System.Object

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData
Dim value As System.Object

instance.Path = value

value = instance.Path
```

C#

```
System.Object Path {get; set;}
```

C++/CLI

```
property System.Object^ Path {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path:

- 2D or 3D [sketch](#) containing an open or closed loop,
- Line in a sketch, or
- Model [edge](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Path](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::ReverseDirection Property \(\)](#)
[IChainPatternFeatureData::PathPlaneReference Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PathPlaneReference Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : PathPlaneReference Property (IChainPatternFeatureData)

Gets or sets the reference plane for the [path](#) selected for this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PathPlaneReference As System.Object
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData
Dim value As System.Object

instance.PathPlaneReference = value

value = instance.PathPlaneReference
```

C#

```
System.Object PathPlaneReference {get; set;}
```

C++/CLI

```
property System.Object^ PathPlaneReference {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Reference plane](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::PathPlaneReference](#).

Remarks

This property is:

- only available when the path is a [sketch line](#).
- available for all types of chain patterns.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PitchMethod Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : PitchMethod Property (IChainPatternFeatureData)

Gets or sets the pitch method for this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PitchMethod As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Integer
```

```
instance.PitchMethod = value
```

```
value = instance.PitchMethod
```

C#

```
System.int PitchMethod {get; set;}
```

C++/CLI

```
property System.int PitchMethod {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pitch method as defined in [swChainPatternPitchMethod_e](#)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::PitchMethod](#).

Remarks

This property gets or sets the type of chain feature pattern.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : ReleaseSelectionAccess Method (IChainPatternFeatureData)

Releases access to the selections that define this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::ReleaseSelectionAccess](#).

Remarks

[IChainPatternFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : ReverseDirection Property (IChainPatternFeatureData)

Gets or sets whether to reverse the direction of the [path](#) in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of the path, false to not

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::ReverseDirection](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEqualSpacing Method (IChainPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : SetEqualSpacing Method (IChainPatternFeatureData)

Sets equal spacing between each chain pattern instance in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetEqualSpacing() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Boolean  
  
value = instance.SetEqualSpacing()
```

C#

```
System.bool SetEqualSpacing()
```

C++/CLI

```
System.bool SetEqualSpacing();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if equal spacing is set between each chain pattern instance, false if not

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::SetEqualSpacing](#).

Remarks

This method is only available for distance and distance linkage chain patterns when [IChainPatternFeatureData::FillPath](#) is false.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)
[IChainPatternFeatureData::InstanceCount\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Spacing Property (IChainPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChainPatternFeatureData Interface](#) : Spacing Property (IChainPatternFeatureData)

Gets or sets the distance between the pattern instances in the [path](#) in this chain pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Spacing As System.Double
```

Visual Basic (Usage)



```
Dim instance As IChainPatternFeatureData  
Dim value As System.Double  
  
instance.Spacing = value
```

```
value = instance.Spacing
```

C#

```
System.double Spacing {get; set;}
```

C++/CLI

```
property System.double Spacing {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance between the pattern instances (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ChainPatternFeatureData::Spacing](#).

Example

[Create and Modify Distance Chain Pattern Feature \(C#\)](#)
[Create and Modify Distance Chain Pattern Feature \(VB.NET\)](#)
[Create and Modify Distance Chain Pattern Feature \(VBA\)](#)

Remarks

This property is only available for distance and linkage distance chain patterns when [equal spacing](#) is not set.

To:

- have SOLIDWORKS calculate the maximum number of pattern instances to fill the path using the specified distance, use [IChainPatternFeatureData::FillPath](#).
- or -
- set the number of pattern instances for the path using the specified distance, use [IChainPatternFeatureData::InstanceCount](#).

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChainPatternFeatureData Interface](#)
[IChainPatternFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

IChamferFeatureData (Type)

IChamferFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChamferFeatureData Interface

Obsolete. Superseded by [IChamferFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IChamferFeatureData
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData
```

C#

```
public interface IChamferFeatureData
```

C++/CLI

```
public interface class IChamferFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData](#).

See Also

[IChamferFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IChamferFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChamferFeatureData Interface

For a list of all members of this type, see [IChamferFeatureData members](#).

Public Methods

Name	Description
GetEdgeChamferDistance	Obsolete. Superseded by IChamferFeatureData2::GetEdgeChamferDistance .
GetVertexChamferDistance	Obsolete. Superseded by IChamferFeatureData2::GetVertexChamferDistance .
SetEdgeChamferDistance	Obsolete. Superseded by IChamferFeatureData2::SetEdgeChamferDistance .
SetVertexChamferDistance	Obsolete. Superseded by IChamferFeatureData2::SetVertexChamferDistance .

[Top](#)

See Also

[IChamferFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IChamferFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChamferFeatureData Interface

The following tables list the members exposed by [IChamferFeatureData](#).

 Public Properties

Name	Description
 EdgeChamferAngle	Obsolete. Superseded by IChamferFeatureData2::EdgeChamferAngle .
 Type	Obsolete. Superseded by IChamferFeatureData2::Type .

[Top](#)

 Public Methods

Name	Description
 GetEdgeChamferDistance	Obsolete. Superseded by IChamferFeatureData2::GetEdgeChamferDistance .
 GetVertexChamferDistance	Obsolete. Superseded by IChamferFeatureData2::GetVertexChamferDistance .
 SetEdgeChamferDistance	Obsolete. Superseded by IChamferFeatureData2::SetEdgeChamferDistance .
 SetVertexChamferDistance	Obsolete. Superseded by IChamferFeatureData2::SetVertexChamferDistance .

[Top](#)

 See Also

[IChamferFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IChamferFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChamferFeatureData Interface

For a list of all members of this type, see [IChamferFeatureData members](#).

 Public Properties

Name	Description
 EdgeChamferAngle	Obsolete. Superseded by IChamferFeatureData2::EdgeChamferAngle .
 Type	Obsolete. Superseded by IChamferFeatureData2::Type .

[Top](#)

 See Also

[IChamferFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EdgeChamferAngle Property (IChamferFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData Interface](#) : EdgeChamferAngle Property (IChamferFeatureData)

Obsolete. Superseded by [IChamferFeatureData2::EdgeChamferAngle](#).

 .NET Syntax

Visual Basic (Declaration)

Property EdgeChamferAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData
Dim value As System.Double

instance.EdgeChamferAngle = value
```

```
value = instance.EdgeChamferAngle
```

C#

```
System.double EdgeChamferAngle {get; set;}
```

C++/CLI

```
property System.double EdgeChamferAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData::EdgeChamferAngle](#).

See Also

[IChamferFeatureData Interface](#)
[IChamferFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEdgeChamferDistance Method (IChamferFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData Interface](#) : GetEdgeChamferDistance Method (IChamferFeatureData)

Obsolete. Superseded by [IChamferFeatureData2::GetEdgeChamferDistance](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeChamferDistance( _  
    ByVal Side As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData  
Dim Side As System.Integer  
Dim value As System.Double
```

```
value = instance.GetEdgeChamferDistance(Side)
```

C#

```
System.double GetEdgeChamferDistance(  
    System.int Side  
)
```

C++/CLI

```
System.double GetEdgeChamferDistance(  
& System.int Side  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData::GetEdgeChamferDistance](#).

See Also

[IChamferFeatureData Interface](#)
[IChamferFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetVertexChamferDistance Method (IChamferFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData Interface](#) : GetVertexChamferDistance Method (IChamferFeatureData)

Obsolete. Superseded by [IChamferFeatureData2::GetVertexChamferDistance](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertexChamferDistance( _  
    ByVal Side As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData  
Dim Side As System.Integer  
Dim value As System.Double  
  
value = instance.GetVertexChamferDistance(Side)
```

C#

```
System.double GetVertexChamferDistance(  
    System.int Side  
)
```

C++/CLI

```
System.double GetVertexChamferDistance(  
& System.int Side  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData::GetVertexChamferDistance](#).

See Also

[IChamferFeatureData Interface](#)
[IChamferFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetEdgeChamferDistance Method (IChamferFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData Interface](#) : SetEdgeChamferDistance Method (IChamferFeatureData)

Obsolete. Superseded by [IChamferFeatureData2::SetEdgeChamferDistance](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEdgeChamferDistance( _
    ByVal Side As System.Integer, _
    ByVal Distance As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData
Dim Side As System.Integer
Dim Distance As System.Double

instance.SetEdgeChamferDistance(Side, Distance)
```

C#

```
void SetEdgeChamferDistance(
    System.int Side,
    System.double Distance
)
```

C++/CLI

```
void SetEdgeChamferDistance(
    & System.int Side,
    & System.double Distance
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Distance

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData::SetEdgeChamferDistance](#).

See Also

[IChamferFeatureData Interface](#)
[IChamferFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetVertexChamferDistance Method (IChamferFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData Interface](#) : SetVertexChamferDistance Method (IChamferFeatureData)

Obsolete. Superseded by [IChamferFeatureData2::SetVertexChamferDistance](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVertexChamferDistance( _
    ByVal Side As System.Integer, _
    ByVal Distance As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData
Dim Side As System.Integer
Dim Distance As System.Double

instance.SetVertexChamferDistance(Side, Distance)
```

C#

```
void SetVertexChamferDistance(  
    System.int Side,  
    System.double Distance  
)
```

C++/CLI

```
void SetVertexChamferDistance(  
& System.int Side,  
& System.double Distance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Distance

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData::SetVertexChamferDistance](#).

See Also

[IChamferFeatureData Interface](#)
[IChamferFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (IChamferFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData Interface](#) : Type Property (IChamferFeatureData)

Obsolete. Superseded by [IChamferFeatureData2::Type](#).

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData::Type](#).

See Also

[IChamferFeatureData Interface](#)
[IChamferFeatureData Members](#)