

SOLIDWORKS API (.NET VBA C#) — Reference

(44/337): ICombineBodiesFeatureData- ICommandGroup

SOLIDWORKS API Documentation (converted from CHM)

ICombineBodiesFeatureData (Type)

ICombineBodiesFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICombineBodiesFeatureData Interface

Allows access to a combine feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICombineBodiesFeatureData
```

Visual Basic (Usage)

```
Dim instance As ICombineBodiesFeatureData
```

C#

```
public interface ICombineBodiesFeatureData
```

C++/CLI

```
public interface class ICombineBodiesFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [CombineBodiesFeatureData](#).

Example

[Combine Bodies \(C#\)](#)
[Combine Bodies \(VB.NET\)](#)
[Combine Bodies \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[CombineBodiesFeatureData](#)

See Also

[ICombineBodiesFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCombineFeature Method](#)
[IFeatureManager::InsertCombineFeature Method](#)

ICombineBodiesFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICombineBodiesFeatureData Interface

For a list of all members of this type, see [ICombineBodiesFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this combine feature.
GetBodiesToCombineCount	Gets the number of bodies to combine.

		
	IGetBodiesToCombine	Gets the bodies to combine.
	ISetBodiesToCombine	Sets the bodies to combine.
	ReleaseSelectionAccess	Releases access to the selections that define this combine feature.

[Top](#)

See Also

[ICombineBodiesFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCombineFeature Method](#)
[IFeatureManager::InsertCombineFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICombineBodiesFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICombineBodiesFeatureData Interface

The following tables list the members exposed by [ICombineBodiesFeatureData](#).

Public Properties

Name	Description
 BodiesToCombine	Gets or sets the bodies to combine.
 MainBody	Gets or sets the main body to keep when subtracting bodies from this combine feature.
 OperationType	Gets or sets how to combine multiple solid bodies for a combine feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this combine feature.
 GetBodiesToCombineCount	Gets the number of bodies to combine.
 IGetBodiesToCombine	Gets the bodies to combine.
 ISetBodiesToCombine	Sets the bodies to combine.
 ReleaseSelectionAccess	Releases access to the selections that define this combine feature.

[Top](#)

See Also

[ICombineBodiesFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCombineFeature Method](#)
[IFeatureManager::InsertCombineFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICombineBodiesFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICombineBodiesFeatureData Interface

For a list of all members of this type, see [ICombineBodiesFeatureData members](#).

Public Properties

Name	Description
 BodiesToCombine	Gets or sets the bodies to combine.
 MainBody	Gets or sets the main body to keep when subtracting bodies from this combine feature.
 OperationType	Gets or sets how to combine multiple solid bodies for a combine feature.

[Top](#)

See Also

[ICombineBodiesFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCombineFeature Method](#)
[IFeatureManager::InsertCombineFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ICombineBodiesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICombineBodiesFeatureData Interface](#) : AccessSelections Method (ICombineBodiesFeatureData)

Gains access to the selections that define this combine feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal PTopDoc As ModelDoc2, _  
    ByVal PComponent As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICombineBodiesFeatureData  
Dim PTopDoc As ModelDoc2  
Dim PComponent As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(PTopDoc, PComponent)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 PTopDoc,  
    Component2 PComponent  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ PTopDoc,  
& Component2^ PComponent  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PTopDoc
Top-level document
PComponent
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed

Visual Basic for Applications (VBA) Syntax

See [CombineBodiesFeatureData::AccessSelections](#).

Example

[Combine Bodies \(C#\)](#)
[Combine Bodies \(VB.NET\)](#)
[Combine Bodies \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ICombineBodiesFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICombineBodiesFeatureData Interface](#)
[ICombineBodiesFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

BodiesToCombine Property (ICombineBodiesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICombineBodiesFeatureData Interface](#) : BodiesToCombine Property (ICombineBodiesFeatureData)

Gets or sets the bodies to combine.

.NET Syntax

Visual Basic (Declaration)

```
Property BodiesToCombine As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICombineBodiesFeatureData
Dim value As System.Object

instance.BodiesToCombine = value

value = instance.BodiesToCombine
```

C#

```
System.object BodiesToCombine {get; set;}
```

C++/CLI

```
property System.Object^ BodiesToCombine {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [bodies](#)

Visual Basic for Applications (VBA) Syntax

See [CombineBodiesFeatureData::BodiesToCombine](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ICombineBodiesFeatureData Interface](#)
[ICombineBodiesFeatureData Members](#)
[ICombineBodiesFeatureData::GetBodiesToCombineCount Method](#)
[ICombineBodiesFeatureData::IGetBodiesToCombine Method](#)
[ICombineBodiesFeatureData::ISetBodiesToCombine Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBodiesToCombineCount Method (ICombineBodiesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICombineBodiesFeatureData Interface](#) : GetBodiesToCombineCount Method (ICombineBodiesFeatureData)

Gets the number of bodies to combine.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodiesToCombineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICombineBodiesFeatureData  
Dim value As System.Integer  
  
value = instance.GetBodiesToCombineCount()
```

C#

```
System.int GetBodiesToCombineCount()
```

C++/CLI

```
System.int GetBodiesToCombineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bodies to combine

Visual Basic for Applications (VBA) Syntax

See [CombineBodiesFeatureData::GetBodiesToCombineCount](#).

Remarks

Call this method before calling [ICombineBodiesFeatureData::IGetBodiesToCombine](#) to determine the size of the array for that method.

See Also

[ICombineBodiesFeatureData Interface](#)
[ICombineBodiesFeatureData Members](#)
[IColorTable::ISetBodiesToCombine Method](#)
[IColorTable::BodiesToCombine Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBodiesToCombine Method (ICombineBodiesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICombineBodiesFeatureData Interface](#) : IGetBodiesToCombine Method (ICombineBodiesFeatureData)

Gets the bodies to combine.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetBodiesToCombine( _  
    ByVal NCount As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As ICombineBodiesFeatureData  
Dim NCount As System.Integer  
Dim value As Body2  
  
value = instance.IGetBodiesToCombine(NCount)
```

C#

```
Body2 IGetBodiesToCombine(  
    System.int NCount  
)
```

C++/CLI

```
Body2^ IGetBodiesToCombine(  
& System.int NCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NCount
Number of bodies to combine

Return Value

- in-process, unmanaged C++: Pointer to an array of [bodies](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [ICombineBodiesFeatureData::GetBodiesToCombineCount](#) before calling this method to determine the size of the array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ICombineBodiesFeatureData Interface](#)
[ICombineBodiesFeatureData Members](#)
[ICombineBodiesFeatureData::ISetBodiesToCombine Method](#)
[ICombineBodiesFeatureData::BodiesToCombine Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetBodiesToCombine Method (ICombineBodiesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICombineBodiesFeatureData Interface](#) : ISetBodiesToCombine Method (ICombineBodiesFeatureData)

Sets the bodies to combine.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetBodiesToCombine( _  
    ByVal NCount As System.Integer, _
```

```
ByRef PBodiesToCombine As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As ICombineBodiesFeatureData  
Dim NCount As System.Integer  
Dim PBodiesToCombine As Body2  
  
instance.ISetBodiesToCombine(NCount, PBodiesToCombine)
```

C#

```
void ISetBodiesToCombine(  
    System.int NCount,  
    ref Body2 PBodiesToCombine  
)
```

C++/CLI

```
void ISetBodiesToCombine(  
& System.int NCount,  
& Body2^% PBodiesToCombine  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NCount

Number of bodies to combine

PBodiesToCombine

- in-process, unmanaged C++: Pointer to an array of [bodies](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ICombineBodiesFeatureData Interface](#)

[ICombineBodiesFeatureData Members](#)

[ICombineBodiesFeatureData::GetBodiesToCombineCount Method](#)

[ICombineBodiesFeatureData::IGetBodiesToCombine Method](#)

[ICombineBodiesFeatureData::BodiesToCombine Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

MainBody Property (ICombineBodiesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICombineBodiesFeatureData Interface](#) : MainBody Property (ICombineBodiesFeatureData)

Gets or sets the main body to keep when subtracting bodies from this combine feature.

.NET Syntax

Visual Basic (Declaration)

```
Property MainBody As Body2
```

Visual Basic (Usage)



```
Dim instance As ICombineBodiesFeatureData  
Dim value As Body2  
  
instance.MainBody = value
```

```
value = instance.MainBody
```

C#

```
Body2 MainBody {get; set;}
```

C++/CLI

```
property Body2^ MainBody {  
    Body2^ get();  
    void set ( &    Body2^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Body](#) of main body to keep

Visual Basic for Applications (VBA) Syntax

See [CombineBodiesFeatureData::MainBody](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ICombineBodiesFeatureData Interface](#)
[ICombineBodiesFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

OperationType Property (ICombineBodiesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICombineBodiesFeatureData Interface](#) : OperationType Property (ICombineBodiesFeatureData)

Gets or sets how to combine multiple solid bodies for a combine feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OperationType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICombineBodiesFeatureData  
Dim value As System.Integer
```

```
instance.OperationType = value
```

```
value = instance.OperationType
```

C#

```
System.int OperationType {get; set;}
```

C++/CLI

```
property System.int OperationType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of combination as defined in [swCombineBodiesOperationType](#) e

Visual Basic for Applications (VBA) Syntax

See [CombineBodiesFeatureData::OperationType](#).

Example

[Combine Bodies \(C#\)](#)
[Combine Bodies \(VB.NET\)](#)
[Combine Bodies \(VBA\)](#)

See Also

[ICombineBodiesFeatureData Interface](#)
[ICombineBodiesFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ICombineBodiesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICombineBodiesFeatureData Interface](#) : ReleaseSelectionAccess Method (ICombineBodiesFeatureData)

Releases access to the selections that define this combine feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ICombineBodiesFeatureData
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CombineBodiesFeatureData::ReleaseSelectionAccess](#).

Example

[Combine Bodies \(C#\)](#)
[Combine Bodies \(VB.NET\)](#)
[Combine Bodies \(VBA\)](#)

Remarks

[ICombineBodiesFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[ICombineBodiesFeatureData Interface](#)
[ICombineBodiesFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

ICommandGroup (Type)

ICommandGroup Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICommandGroup Interface

Allows add-in applications to create toolbars and menu items, including flyout toolbars and submenus, and add them to the [ICommandManager](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICommandGroup
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup
```

C#

```
public interface ICommandGroup
```

C++/CLI

```
public interface class ICommandGroup
```

Visual Basic for Applications (VBA) Syntax

See [CommandGroup](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)
[Create Submenus in the CommandManager \(C#\)](#)

Remarks

See [CommandManager and CommandGroups](#) to learn how to add and remove CommandGroups.

Accessors

[ICommandManager::GetCommandGroup](#)
[ICommandManager::GetGroups](#) and [ICommandManager::!GetGroups](#)
[ICommandManager::CreateCommandGroup](#)
[ICommandManager::AddContextMenu](#)

Access Diagram

[CommandGroup](#)

See Also

[ICommandGroup Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICommandGroup Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICommandGroup Interface

The following tables list the members exposed by [ICommandGroup](#).

 Public Properties

Name	Description
 CommandID	Gets the command ID for the specified item in the CommandGroup.
 CustomNames	Gets or sets the custom names in the CommandGroup.
 DockingState	Gets or sets the docking state of the toolbar in the CommandGroup.
 HasEnabledButton	Gets whether any buttons in this CommandGroup are enabled.
 HasMenu	Gets or sets whether this CommandGroup has a menu.
 HasToolbar	Gets or sets whether this CommandGroup has a toolbar.
 IconList	Gets or sets the paths for the icons for the toolbar buttons and separators for this CommandGroup.
 LargeIconList	Obsolete. Superseded by ICommandGroup.IconList .
 LargeMainIcon	Obsolete. Superseded by ICommandGroup.MainIconList .
 MainIconList	Gets or sets the paths for the icons for the buttons for this CommandGroup.
 MenuPosition	Gets or sets the position of the CommandGroup for the specified document templates.
 Name	Gets the name of the CommandGroup.
 NumberOfGroupItems	Gets the number of items in the CommandGroup.
 SelectType	This property: - gets the type of object selected on the context sensitive, pop-up menu. - sets the type of object that the user must select to show the context sensitive, pop-up menu.
 ShowInDocumentType	Gets or sets the types of documents to show this CommandGroup.
 SmallIconList	Obsolete. Superseded by ICommandGroup.IconList .
 SmallMainIcon	Obsolete. Superseded by ICommandGroup.MainIconList .
 ToolBarId	Gets the toolbar ID of this CommandGroup.

[Top](#)

 Public Methods

Name	Description
 Activate	Activates the CommandGroup.
 AddCommandItem	Obsolete. Superseded by ICommandGroup.AddComandItem2 .
 AddCommandItem2	Adds a combination menu item and toolbar item to a CommandGroup.
 AddSpacer	Obsolete. Superseded by ICommandGroup.AddSpacer2 .
 AddSpacer2	Adds a spacer between items in a CommandGroup.
 GetToolBarVisibility	Gets whether this toolbar is visible.
 SetToolBarVisibility	Sets the visibility of the toolbar in the CommandGroup.

[Top](#)

 See Also

[ICommandGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

Public Methods

Name	Description
 Activate	Activates the CommandGroup.
 AddCommandItem	Obsolete. Superseded by ICommandGroup.AddComandItem2
 AddCommandItem2	Adds a combination menu item and toolbar item to a CommandGroup.
 AddSpacer	Obsolete. Superseded by ICommandGroup.AddSpacer2
 AddSpacer2	Adds a spacer between items in a CommandGroup.
 GetToolBarVisibility	Gets whether this toolbar is visible.
 SetToolBarVisibility	Sets the visibility of the toolbar in the CommandGroup.

[Top](#)

See Also

[ICommandGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICommandGroup Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICommandGroup Interface

For a list of all members of this type, see [ICommandGroup members](#).

Public Properties

Name	Description
 CommandID	Gets the command ID for the specified item in the CommandGroup.
 CustomNames	Gets or sets the custom names in the CommandGroup.
 DockingState	Gets or sets the docking state of the toolbar in the CommandGroup.
 HasEnabledButton	Gets whether any buttons in this CommandGroup are enabled.
 HasMenu	Gets or sets whether this CommandGroup has a menu.
 HasToolBar	Gets or sets whether this CommandGroup has a toolbar.
 IconList	Gets or sets the paths for the icons for the toolbar buttons and separators for this CommandGroup.
 LargeIconList	Obsolete. Superseded by ICommandGroup.IconList
 LargeMainIcon	Obsolete. Superseded by ICommandGroup.MainIconList
 MainIconList	Gets or sets the paths for the icons for the buttons for this CommandGroup.
 MenuPosition	Gets or sets the position of the CommandGroup for the specified document templates.
 Name	Gets the name of the CommandGroup.
 NumberOfGroupItems	Gets the number of items in the CommandGroup.
 SelectType	This property: • gets the type of object selected on the context sensitive, pop-up menu. • sets the type of object that the user must select to show the context sensitive, pop-up menu.
 ShowInDocumentType	Gets or sets the types of documents to show this CommandGroup.
 SmallIconList	Obsolete. Superseded by ICommandGroup.IconList
 SmallMainIcon	Obsolete. Superseded by ICommandGroup.MainIconList
 ToolBarId	Gets the toolbar ID of this CommandGroup.

[Top](#)

See Also

Activate Method (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : Activate Method (ICommandGroup)

Activates the CommandGroup.

.NET Syntax

Visual Basic (Declaration)

```
Function Activate() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim value As System.Boolean
```

```
value = instance.Activate()
```

C#

```
System.bool Activate()
```

C++/CLI

```
System.bool Activate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the CommandGroup is activated, false if not

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::Activate](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)
[Create Submenus in the CommandManager \(C#\)](#)

Remarks

After completely creating a CommandGroup, use this method to activate it. You only need to activate the top-level group; you do not need to activate child groups.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::MenuPosition Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

AddCommandItem Method (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : AddCommandItem Method (ICommandGroup)

Obsolete. Superseded by [ICommandGroup::AddComandItem2](#).

Visual Basic (Declaration)

```
Function AddCommandItem( _
    ByVal Name As System.String, _
    ByVal Position As System.Integer, _
    ByVal HintString As System.String, _
    ByVal ToolTip As System.String, _
    ByVal ImageListIndex As System.Integer, _
    ByVal CallbackFunction As System.String, _
    ByVal EnableMethod As System.String, _
    ByVal UserID As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim Name As System.String
Dim Position As System.Integer
Dim HintString As System.String
Dim ToolTip As System.String
Dim ImageListIndex As System.Integer
Dim CallbackFunction As System.String
Dim EnableMethod As System.String
Dim UserID As System.Integer
Dim value As System.Integer

value = instance.AddCommandItem(Name, Position, HintString, ToolTip, ImageListIndex,
    CallbackFunction, EnableMethod, UserID)
```

C#

```
System.int AddCommandItem(
    System.string Name,
    System.int Position,
    System.string HintString,
    System.string ToolTip,
    System.int ImageListIndex,
    System.string CallbackFunction,
    System.string EnableMethod,
    System.int UserID
)
```

C++/CLI

```
System.int AddCommandItem(
    & System.String^ Name,
    & System.int Position,
    & System.String^ HintString,
    & System.String^ ToolTip,
    & System.int ImageListIndex,
    & System.String^ CallbackFunction,
    & System.String^ EnableMethod,
    & System.int UserID
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Position

HintString

ToolTip

ImageListIndex

CallbackFunction

EnableMethod

Visual Basic for Applications (VBA) Syntax

See [CommandGroup.AddCommandItem](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddCommandItem2 Method (ICommandGroup)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : AddCommandItem2 Method (ICommandGroup)

Adds a combination menu item and toolbar item to a CommandGroup.

.NET Syntax

Visual Basic (Declaration)

```
Function AddCommandItem2( _
    ByVal Name As System.String, _
    ByVal Position As System.Integer, _
    ByVal HintString As System.String, _
    ByVal ToolTip As System.String, _
    ByVal ImageListIndex As System.Integer, _
    ByVal CallbackFunction As System.String, _
    ByVal EnableMethod As System.String, _
    ByVal UserID As System.Integer, _
    ByVal MenuTBOption As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim Name As System.String
Dim Position As System.Integer
Dim HintString As System.String
Dim ToolTip As System.String
Dim ImageListIndex As System.Integer
Dim CallbackFunction As System.String
Dim EnableMethod As System.String
Dim UserID As System.Integer
Dim MenuTBOption As System.Integer
Dim value As System.Integer
```

```
value = instance.AddCommandItem2(Name, Position, HintString, ToolTip, ImageListIndex,
    CallbackFunction, EnableMethod, UserID, MenuTBOption)
```

C#

```
System.int AddCommandItem2(
    System.string Name,
    System.int Position,
    System.string HintString,
    System.string ToolTip,
    System.int ImageListIndex,
    System.string CallbackFunction,
    System.string EnableMethod,
    System.int UserID,
    System.int MenuTBOption
)
```

C++/CLI

```

System.int AddCommandItem2(
& System.String^ Name,
& System.int Position,
& System.String^ HintString,
& System.String^ ToolTip,
& System.int ImageListIndex,
& System.String^ CallbackFunction,
& System.String^ EnableMethod,
& System.int UserID,
& System.int MenuTBOption
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the item to add to the CommandGroup

Position

Position of the item within the CommandGroup

NOTE: Specify 0 to add this item to the beginning of the CommandGroup, or specify -1 to add it to the end of the CommandGroup. This argument specifies the position of the item in relation to its immediate parent item.

HintString

Text displayed in the SOLIDWORKS status bar when the pointer is on the item

ToolTip

ToolTip displayed when the pointer is on the item

ImageListIndex

Index number of the image for the item in the parent CommandGroup (see **Remarks**)

CallbackFunction

Function to call when this item is selected (see **Remarks**)

EnableMethod

Optional function that controls the state of the item; if specified, then SOLIDWORKS calls this function before displaying the item

If your method returns...	Then SOLIDWORKS...
0	Deselects and disables the item
1	Deselects and enables the item; this is the default state if no update function is specified
2	Selects and disables the item
3	Selects and enables the item
4	Not supported

(see **Remarks**)

UserID

User-defined command ID or 0 if not used

MenuTBOption

Command item type as defined in [swCommandItemType_e](#)

Return Value

Index of the item within the CommandGroup as assigned by SOLIDWORKS

Visual Basic for Applications (VBA) Syntax

See [CommandGroup.AddCommandItem2](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)
[Create Submenus in the CommandManager \(C#\)](#)

Remarks

See [Add-in Callback and Enable Methods](#) to learn how to specify CallbackFunction and EnableMethod.

ImageListIndex is 0-based. The size of the index is equal to number of the images in the image files for that CommandGroup.

See [ICommandGroup.IconList](#) for details. You can use -1 for ImageListIndex to specify that no icon is needed for a command item of type swCommandItemType_e.swMenuItem; however, command items of type swCommandItemType_e.swMenuItem always need an icon.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::CommandID Property](#)
[ISldWorks::GetCommandID Method](#)
[ICommandGroup::HasEnabledButton Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddSpacer Method (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : AddSpacer Method (ICommandGroup)

Obsolete. Superseded by [ICommandGroup::AddSpacer2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddSpacer( _  
    ByVal Position As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim Position As System.Integer  
Dim value As System.Integer  
  
value = instance.AddSpacer(Position)
```

C#

```
System.int AddSpacer(  
    System.int Position  
)
```

C++/CLI

```
System.int AddSpacer(  
& System.int Position  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Position

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::AddSpacer](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddSpacer2 Method (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : AddSpacer2 Method (ICommandGroup)

Adds a spacer between items in a CommandGroup.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function AddSpacer2( _  
    ByVal Position As System.Integer, _  
    ByVal MenuTBOption As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim Position As System.Integer  
Dim MenuTBOption As System.Integer  
Dim value As System.Integer  
  
value = instance.AddSpacer2(Position, MenuTBOption)
```

C#

```
System.int AddSpacer2(  
    System.int Position,  
    System.int MenuTBOption  
)
```

C++/CLI

```
System.int AddSpacer2(  
& System.int Position,  
& System.int MenuTBOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Position

Position of the spacer within the CommandGroup

NOTE: Specify 0 to add this a spacer to the beginning of the CommandGroup, or specify -1 to add it to the end of the CommandGroup. This argument specifies the position of the spacer in relation to its immediate parent item.

MenuTBOption

Command item type as defined in [swCommandItemType_e](#)

Return Value

Index of the item within the CommandGroup as assigned by SOLIDWORKS

Visual Basic for Applications (VBA) Syntax

See [CommandGroup.AddSpacer2](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

CommandID Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : CommandID Property (ICommandGroup)

Gets the command ID for the specified item in the CommandGroup.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property CommandID( _  
    ByVal CommandIndex As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim CommandIndex As System.Integer  
Dim value As System.Integer  
  
value = instance.CommandID(CommandIndex)
```

C#

```
System.int CommandID(  
    System.int CommandIndex  
) {get;}
```

C++/CLI

```
property System.int CommandID {  
    System.int get(System.int CommandIndex);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CommandIndex
Index of the item in the CommandGroup

Property Value

Command ID of the specified item

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::CommandID](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

The value of CommandIndex is the value returned by [ICommandGroup::AddCommandItem2](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ISldWorks::GetCommandID Method](#)
[ICommandGroup::NumberOfGroupItems Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

CustomNames Property (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : CustomNames Property (ICommandGroup)

Gets or sets the custom names in the CommandGroup.

.NET Syntax

Visual Basic (Declaration)

```
Property CustomNames As System.String
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim value As System.String

instance.CustomNames = value
value = instance.CustomNames
```

C#

```
System.string CustomNames {get; set;}
```

C++/CLI

```
property System.String^ CustomNames {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

String containing the custom names in the CommandGroup (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::CustomNames](#).

Remarks

Format CustomNames as a semicolon-separated list of the names of the custom feature types.

This method is applicable only if [ICommandGroup::SelectType](#) is a custom feature type, like swSelATTRIBUTES. For example, if you want a context-sensitive, pop-up menu to appear for an attribute when the user right-clicks the attribute in the FeatureManager design tree, then:

1. Create the attribute (see [IAttributeDef::CreateInstance5](#))
2. Set the name of the attribute in [ICommandGroup::SelectType](#).
3. Set the name of the attribute definition in ICommandGroup::CustomNames.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandManager::AddContextMenu Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

DockingState Property (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : DockingState Property (ICommandGroup)

Gets or sets the docking state of the toolbar in the CommandGroup.

.NET Syntax

Visual Basic (Declaration)

Property DockingState As System.Integer

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim value As System.Integer

instance.DockingState = value

value = instance.DockingState
```

C#

```
System.int DockingState {get; set;}
```

C++/CLI

```
property System.int DockingState {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Docking state of the toolbar as defined in [swToolbarDockStatePosition_e](#)

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::DockingState](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::SetToolbarVisibility Method](#)
[ICommandGroup::HasToolbar Property](#)
[ICommandGroup::ToolBarId Property](#)

Availability

SOLIDWORKS 2006 SP5, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetToolbarVisibility Method (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : GetToolbarVisibility Method (ICommandGroup)

Gets whether this toolbar is visible.

.NET Syntax

Visual Basic (Declaration)

```
Function GetToolbarVisibility( _
    ByVal SwContext As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim SwContext As System.Integer
Dim value As System.Boolean

value = instance.GetToolbarVisibility(SwContext)
```

C#

```
System.bool GetToolbarVisibility(  
    System.int SwContext  
)
```

C++/CLI

```
System.bool GetToolbarVisibility(  
&    System.int SwContext  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SwContext

Context in which to show or hide toolbar as defined in [swDocumentTypes_e](#)

Return Value

True to show the toolbar, false to hide it

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::GetToolbarVisibility](#).

See Also

[ICommandGroup Interface](#)

[ICommandGroup Members](#)

[ICommandGroup::SetToolbarVisibility Method](#)

[ICommandGroup::HasToolbar Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasEnabledButton Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : HasEnabledButton Property (ICommandGroup)

Gets whether any buttons in this CommandGroup are enabled.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property HasEnabledButton As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim value As System.Boolean
```

```
value = instance.HasEnabledButton
```

C#

```
System.bool HasEnabledButton {get;}
```

C++/CLI

```
property System.bool HasEnabledButton {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if at least one CommandGroup button is enabled, false if not

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::HasEnabledButton](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

Add-in applications can call this method to determine whether to disable flyout buttons in the CommandManager.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::AddCommandItem2 Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasMenu Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : HasMenu Property (ICommandGroup)

Gets or sets whether this CommandGroup has a menu.

.NET Syntax

Visual Basic (Declaration)

Property HasMenu As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim value As System.Boolean
```

```
instance.HasMenu = value
```

```
value = instance.HasMenu
```

C#

```
System.bool HasMenu {get; set;}
```

C++/CLI

```
property System.bool HasMenu {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this CommandGroup has a menu, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::HasMenu](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)
[Create Submenus in the CommandManager \(C#\)](#)

Remarks

By default, this CommandGroup has a menu.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup.HasMenu Property](#)
[ICommandManager.AddContextMenu Method](#)
[ICommandGroup.MenuPosition Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments](#) on this topic.

HasToolbar Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : HasToolbar Property (ICommandGroup)

Gets or sets whether this CommandGroup has a toolbar.

.NET Syntax

Visual Basic (Declaration)

Property HasToolbar As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim value As System.Boolean
```

```
instance.HasToolbar = value
```

```
value = instance.HasToolbar
```

C#

```
System.bool HasToolbar {get; set;}
```

C++/CLI

```
property System.bool HasToolbar {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this CommandGroup has a toolbar, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CommandGroup.HasToolbar](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)
[Create Submenus in the CommandManager \(C#\)](#)

Remarks

By default, this CommandGroup has a toolbar.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::HasMenu Property](#)
[ICommandGroup::SetToolBarVisibility Method](#)
[ICommandGroup::DockingState Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

IconList Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : IconList Property (ICommandGroup)

Gets or sets the paths for the icons for the toolbar buttons and separators for this CommandGroup.

.NET Syntax

Visual Basic (Declaration)

```
Property IconList As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim value As System.Object
```

```
instance.IconList = value
```

```
value = instance.IconList
```

C#

```
System.object IconList {get; set;}
```

C++/CLI

```
property System.Object^ IconList {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of strings of the paths for the icons for the toolbar buttons and separators for this CommandGroup (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::IconList](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

This property supports scaling for high resolution screens with high resolution operating system scaling options.

The array of strings of the paths to the image files can contain icons of the following sizes:

- 20 x 20 pixels
- 32 x 32 pixels
- 40 x 40 pixels
- 64 x 64 pixels

- 96 x 96 pixels
- 128 x 128 pixels

Each image file (**.bmp** or **.png**) should contain all of the same-size icons for all of the buttons and separators for both parent and child toolbars. For example:



Each icon strip should use a 256-color palette.

The order in which you specify the icons must be the same for this property and [ICommandGroup::MainIconList](#). For example, if you specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels icons for this property, then you must specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels icons for [ICommandGroup::MainIconList](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ISldWorks::GetImageSize Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LargeIconList Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : LargeIconList Property (ICommandGroup)

Obsolete. Superseded by [ICommandGroup::IconList](#).

.NET Syntax

Visual Basic (Declaration)

```
Property LargeIconList As System.String
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim value As System.String

instance.LargeIconList = value
value = instance.LargeIconList
```

C#

```
System.string LargeIconList {get; set;}
```

C++/CLI

```
property System.String^ LargeIconList {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path for the bitmap or PNG files containing all of the large images of the toolbar buttons and separators for this CommandGroup

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::LargeIconList](#).

Example

[Create Submenus in the CommandManager \(C#\)](#)

Remarks

The bitmap or PNG file should contain all of the images for all of the large buttons and separators for this CommandGroup, in a single bitmap for both parent and child toolbars. Each image of each button must be 24x24. The images should use a 256-color palette.

You can only set this property for the top-level CommandGroup.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::AddCommandItem2 Method](#)
[ICommandGroup::LargeMainIcon Property](#)
[ICommandGroup::SmallIconList Property](#)
[ICommandGroup::SmallMainIcon Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

LargeMainIcon Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : LargeMainIcon Property (ICommandGroup)

Obsolete. Superseded by [ICommandGroup::MainIconList](#).

.NET Syntax

Visual Basic (Declaration)

```
Property LargeMainIcon As System.String
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim value As System.String
```

```
instance.LargeMainIcon = value
```

```
value = instance.LargeMainIcon
```

C#

```
System.string LargeMainIcon {get; set;}
```

C++/CLI

```
property System.String^ LargeMainIcon {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path of the large bitmap or PNG for this CommandGroup

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::LargeMainIcon](#).

Example

[Create Submenus in the CommandManager \(C#\)](#)

Remarks

The large bitmap or PNG must be 24x24 and use a 256-color palette.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::AddCommandItem2 Method](#)
[ICommandGroup::LargeIconList Property](#)
[ICommandGroup::SmallIconList Property](#)
[ICommandGroup::SmallMainIcon Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

MainIconList Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : MainIconList Property (ICommandGroup)

Gets or sets the paths for the icons for the buttons for this CommandGroup.

.NET Syntax

Visual Basic (Declaration)

Property MainIconList As System.Object

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim value As System.Object
```

```
instance.MainIconList = value
```

```
value = instance.MainIconList
```

C#

```
System.Object MainIconList {get; set;}
```

C++/CLI

```
property System.Object^ MainIconList {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of strings of the paths for the icons for the buttons for this CommandGroup (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::MainIconList](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

This property supports scaling for high resolution screens with high resolution operating system scaling options.

The array of strings for the paths to the image files can contain icons of the following sizes:

- 20 x 20 pixels
- 32 x 32 pixels
- 40 x 40 pixels

- 64 x 64 pixels
- 96 x 96 pixels
- 128 x 128 pixels

Each image file (**.bmp** or **.png**) contains a single icon. Each icon should use a 256-color palette.

The order in which you specify the icons must be the same for this property and [ICommandGroup::IconList](#). For example, if you specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels icons for this property, then you must specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels icons for [ICommandGroup::IconList](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ISldWorks::GetImageSize Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MenuPosition Property (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : MenuPosition Property (ICommandGroup)

Gets or sets the position of the CommandGroup for the specified document templates.

.NET Syntax

Visual Basic (Declaration)

```
Property MenuPosition( _  
    ByVal Context As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim Context As System.Integer  
Dim value As System.Integer  
  
instance.MenuPosition(Context) = value  
  
value = instance.MenuPosition(Context)
```

C#

```
System.int MenuPosition(  
    System.int Context  
) {get; set;}
```

C++/CLI

```
property System.int MenuPosition {  
    System.int get(System.int Context);  
    void set (System.int Context, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Context
Context as defined in [swDocTemplateTypes_e](#)

Property Value

Position of the CommandGroup in the CommandManager

NOTE: Specify 0 to add the CommandGroup to the beginning of the CommandManager, or specify -1 to add it to the end of the CommandManager.

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::MenuPosition](#).

Remarks

If setting the position of the CommandGroup using this property, you must use it before using [ICommandGroup::Activate](#). If you use this property after using [ICommandGroup::Activate](#), then this property has no effect.

If you do not use this property to set the position of the ICommandGroup, then the position specified in [ICommandManager::CreateCommandGroup](#) is used.

Calling this property to get the position of the CommandGroup returns the position of the CommandGroup set by either this property or [ICommandManager::CreateCommandGroup](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::HasMenu Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : Name Property (ICommandGroup)

Gets the name of the CommandGroup.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Name As System.String

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim value As System.String

value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the CommandGroup that corresponds to the name specified in [ICommandManager::AddContextMenu](#), and [ICommandManager::CreateCommandGroup](#).

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::Name](#).

Remarks

If you used [ICommandManager::GetGroups](#) or [ICommandManager::!GetGroups](#), then use this property to get the specific CommandGroup with which you want to work.

See Also

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

NumberOfGroupItems Property (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : NumberOfGroupItems Property (ICommandGroup)

Gets the number of items in the CommandGroup.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property NumberOfGroupItems As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup
Dim value As System.Integer

value = instance.NumberOfGroupItems
```

C#

```
System.int NumberOfGroupItems {get;}
```

C++/CLI

```
property System.int NumberOfGroupItems {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of items in the CommandGroup

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::NumberOfGroupItems](#).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::AddCommandItem2 Method](#)
[ICommandGroup::CommandID Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectType Property (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : SelectType Property (ICommandGroup)

This property:

- gets the type of object selected on the context sensitive, pop-up menu.
- sets the type of object that the user must select to show the context sensitive, pop-up menu.

.NET Syntax

```
Property SelectType As System.Integer
```



```
Dim instance As ICommandGroup
Dim value As System.Integer
```

```
instance.SelectType = value
```

```
value = instance.SelectType
```

```
System.int SelectType {get; set;}
```

```
property System.int SelectType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of object as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::SelectType](#).

Remarks

This property only applies to CommandGroups created using [ICommandManager::AddContextMenu](#).

If setting SelectType to a custom feature type such as an attribute (swSelATTRIBUTES), then you must use [ICommandGroup::CustomNames](#) to set the name of the attribute definition.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SetToolbarVisibility Method (ICommandGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : SetToolbarVisibility Method (ICommandGroup)

Sets the visibility of the toolbar in the CommandGroup.

.NET Syntax

```
Sub SetToolbarVisibility( _
    ByVal Visible As System.Boolean, _
    ByVal Mask As System.Integer _
)
```



```
Dim instance As ICommandGroup
Dim Visible As System.Boolean
Dim Mask As System.Integer

instance.SetToolBarVisibility(Visible, Mask)
```

C#

```
void SetToolBarVisibility(
    System.bool Visible,
    System.int Mask
)
```

C++/CLI

```
void SetToolBarVisibility(
    & System.bool Visible,
    & System.int Mask
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Visible

True to show the toolbar, false to hide it

Mask

Context in which to show or hide toolbar as defined in [swDocTemplateTypes](#) e

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::SetToolBarVisibility](#).

See Also

[ICommandGroup Interface](#)

[ICommandGroup Members](#)

[ICommandGroup::HasMenu Property](#)

[ICommandGroup::HasToolBar Property](#)

[ICommandManager::AddContextMenu Method](#)

Availability

SOLIDWORKS 2006 SP4, Revision Number 14

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowInDocumentType Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : ShowInDocumentType Property (ICommandGroup)

Gets or sets the types of documents to show this CommandGroup.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowInDocumentType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup
```

```
Dim value As System.Integer
```

```
instance.ShowInDocumentType = value
```

```
value = instance.ShowInDocumentType
```

C#

```
System.int ShowInDocumentType {get; set;}
```

C++/CLI

```
property System.int ShowInDocumentType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Types of documents in which to show this CommandGroup as defined in [swDocTemplateTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::ShowInDocumentType](#).

Example

[Create Submenus in the CommandManager \(C#\)](#)

Remarks

This method only affects menus. The toolbar for the CommandGroup will be visible in every context, i.e., none, part, assembly, or drawing.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments](#) on this topic.

SmallIconList Property (ICommandGroup)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : SmallIconList Property (ICommandGroup)

Obsolete. Superseded by [ICommandGroup::IconList](#).

.NET Syntax

Visual Basic (Declaration)

```
Property SmallIconList As System.String
```

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim value As System.String  
  
instance.SmallIconList = value  
value = instance.SmallIconList
```

C#

```
System.string SmallIconList {get; set;}
```

C++/CLI

```
property System.String^ SmallIconList {  
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path for the bitmap or PNG file containing all of the small images of the buttons and separators for this CommandGroup

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::SmallIconList](#).

Example

[Create Submenus in the CommandManager \(C#\)](#)

Remarks

The bitmap or PNG file should contain all of the images for all of the small buttons and separators for this CommandGroup, in a single bitmap for both parent and child toolbars. Each image of each button must be 16x16. The images should use a 256-color palette.

You can only set this property for the top-level CommandGroup.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::AddCommandItem2 Method](#)
[ICommandGroup::LargeIconList Property](#)
[ICommandGroup::LargeMainIcon Property](#)
[ICommandGroup::SmallMainIcon Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

SmallMainIcon Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : SmallMainIcon Property (ICommandGroup)

Obsolete. Superseded by [ICommandGroup::MainIconList](#).

.NET Syntax

Visual Basic (Declaration)

Property SmallMainIcon As System.String

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim value As System.String
```

```
instance.SmallMainIcon = value
```

```
value = instance.SmallMainIcon
```

C#

```
System.string SmallMainIcon {get; set;}
```

C++/CLI

```
property System.String^ SmallMainIcon {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path of the small bitmap or PNG for this CommandGroup

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::SmallMainIcon](#).

Example

[Create Submenus in the CommandManager \(C#\)](#)

Remarks

The small bitmap must be 16x16 and use a 256-color palette.

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandGroup::AddCommandItem2 Method](#)
[ICommandGroup::LargeIconList Property](#)
[ICommandGroup::LargeMainIcon Property](#)
[ICommandGroup::SmallIconList Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

ToolBarId Property (ICommandGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICommandGroup Interface](#) : ToolBarId Property (ICommandGroup)

Gets the toolbar ID of this CommandGroup.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ToolBarId As System.Integer

Visual Basic (Usage)



```
Dim instance As ICommandGroup  
Dim value As System.Integer
```

```
value = instance.ToolBarId
```

C#

```
System.int ToolBarId {get;}
```

C++/CLI

```
property System.int ToolBarId {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

ToolBar ID of this CommandGroup

Visual Basic for Applications (VBA) Syntax

See [CommandGroup::ToolBarId](#).

Example

[Create Flyouts in the CommandManager \(VB.NET\)](#)
[Create Flyouts in the CommandManager \(C#\)](#)

Remarks

Use this property when [dragging a toolbar button](#) from one toolbar (native SOLIDWORKS or a CommandGroup toolbar) to another toolbar (native SOLIDWORKS or a CommandGroup toolbar).

See Also

[ICommandGroup Interface](#)
[ICommandGroup Members](#)
[ICommandManager.HasToolbar Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14