

SOLIDWORKS API (.NET VBA C#) — Reference

(69/337): IDerivedPatternFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IDerivedPatternFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDerivedPatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDerivedPatternFeatureData Interface

Allows access to a derived pattern feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDerivedPatternFeatureData
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData
```

C#

```
public interface IDerivedPatternFeatureData
```

C++/CLI

```
public interface class IDerivedPatternFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData](#).

Example

[Get and Set Seed Components \(C#\)](#)
[Get and Set Seed Components \(VB.NET\)](#)
[Get and Set Seed Components \(VBA\)](#)
[Get Number of Instances Skipped in Driving Feature \(C#\)](#)
[Get Number of Instances Skipped in Driving Feature \(VB.NET\)](#)
[Get Number of Instances Skipped in Driving Feature \(VBA\)](#)
[Create Derived Pattern Feature \(C#\)](#)
[Create Derived Pattern Feature \(VB.NET\)](#)
[Create Derived Pattern Feature \(VBA\)](#)

Remarks

Read [Pattern Features and their Feature Data Objects](#).

Before calling `IFeatureManager::CreateDefinition`, you must pre-select the entities needed to create the derived pattern feature. Use [IModelDocExtension::SelectById2](#) to select the seed components and pattern feature in any order using Marks:

- seed component = 1
- pattern feature = 2

You must call [IFeatureManager::CreateFeature](#) after initializing this feature data object in order to successfully create the derived pattern feature

NOTE: A derived pattern feature is also called a pattern driven pattern feature.

For more information, see the **SOLIDWORKS Design user-interface help > Assemblies > Basic Component Operations > Component Patterns > Pattern Driven Component Pattern PropertyManager** topic.

Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[DerivedPatternFeatureData](#)

See Also

[IDerivedPatternFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDerivedPatternFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDerivedPatternFeatureData Interface

For a list of all members of this type, see [IDerivedPatternFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this derived pattern feature.
 GetSeedComponentCount	Gets the number of seed component features for this derived pattern feature.
 GetSkippedItemCount	Gets the number of skipped items for this derived pattern feature.
 GetTransform	Gets the transform for the specified instance of this derived-pattern feature.
 IAccessSelections	Obsolete. See IDerivedPatternFeatureData.IAccessSelections2
 IAccessSelections2	Gains access to the selections that describe this derived pattern feature.
 IGetSeedComponentArray	Gets the seed component features for this derived pattern feature.
 IGetSkippedItemArray	Gets the list of skipped items for this derived pattern feature.
 ISetSeedComponentArray	Sets an array of the seed component features for this derived pattern feature.
 ISetSkippedItemArray	Sets the list of items to skip for this derived pattern feature.
 ReleaseSelectionAccess	Releases access to the selections that describe this derived pattern feature.

[Top](#)

See Also

[IDerivedPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDerivedPatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDerivedPatternFeatureData Interface

The following tables list the members exposed by [IDerivedPatternFeatureData](#).

Public Properties

Name	Description
 DrivingFeatureSkippedItemArray	Gets the skipped instances in the driving feature of this derived pattern feature.
 ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this derived pattern feature.
 PatternFeature	Gets or sets the pattern feature for this derived pattern feature.
 PropagateVisualProperty	Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) in this derived pattern feature.
 SeedComponentArray	Gets or sets an array of seed component features for this derived pattern feature.
 SeedPosition	Gets or sets which pattern instance to use as the seed feature for this derived pattern feature.
 SkippedItemArray	Gets or sets the list of skipped items for this derived pattern feature.

[Top](#)

Public Methods

Name	Description
AccessSelections	Gains access to the selections that describe this derived pattern feature.

		
	GetSeedComponentCount	Gets the number of seed component features for this derived pattern feature.
	GetSkippedItemCount	Gets the number of skipped items for this derived pattern feature.
	GetTransform	Gets the transform for the specified instance of this derived-pattern feature.
	IAccessSelections	Obsolete. See IDerivedPatternFeatureData.IAccessSelections2 .
	IAccessSelections2	Gains access to the selections that describe this derived pattern feature.
	IGetSeedComponentArray	Gets the seed component features for this derived pattern feature.
	IGetSkippedItemArray	Gets the list of skipped items for this derived pattern feature.
	ISetSeedComponentArray	Sets an array of the seed component features for this derived pattern feature.
	ISetSkippedItemArray	Sets the list of items to skip for this derived pattern feature.
	ReleaseSelectionAccess	Releases access to the selections that describe this derived pattern feature.

[Top](#)

See Also

[IDerivedPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDerivedPatternFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDerivedPatternFeatureData Interface

For a list of all members of this type, see [IDerivedPatternFeatureData members](#).

Public Properties

Name	Description
 DrivingFeatureSkippedItemArray	Gets the skipped instances in the driving feature of this derived pattern feature.
 ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this derived pattern feature.
 PatternFeature	Gets or sets the pattern feature for this derived pattern feature.
 PropagateVisualProperty	Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) in this derived pattern feature.
 SeedComponentArray	Gets or sets an array of seed component features for this derived pattern feature.
 SeedPosition	Gets or sets which pattern instance to use as the seed feature for this derived pattern feature.
 SkippedItemArray	Gets or sets the list of skipped items for this derived pattern feature.

[Top](#)

See Also

[IDerivedPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IDerivedPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : AccessSelections Method (IDerivedPatternFeatureData)

Gains access to the selections that describe this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _
```

```
ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::AccessSelections](#).

Example

[Get and Set Seed Components \(C#\)](#)
[Get and Set Seed Components \(VB.NET\)](#)
[Get and Set Seed Components \(VBA\)](#)
[Get Number of Instances Skipped in Driving Feature \(C#\)](#)
[Get Number of Instances Skipped in Driving Feature \(VB.NET\)](#)
[Get Number of Instances Skipped in Driving Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) and [IFeature::IModifyDefinition2](#) if you modified the feature
- [IDerivedPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::AccessSelections2 Method](#)

Availability

DrivingFeatureSkippedItemArray Property (IDerivedPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : DrivingFeatureSkippedItemArray Property (IDerivedPatternFeatureData)

Gets the skipped instances in the driving feature of this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property DrivingFeatureSkippedItemArray As System.Object

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData
Dim value As System.Object

value = instance.DrivingFeatureSkippedItemArray
```

C#

```
System.Object DrivingFeatureSkippedItemArray {get;}
```

C++/CLI

```
property System.Object^ DrivingFeatureSkippedItemArray {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of longs or integers of the skipped instances in the driving feature

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::DrivingFeatureSkippedItemArray](#).

Example

[Get Number of Instances Skipped in Driving Feature \(C#\)](#)
[Get Number of Instances Skipped in Driving Feature \(VB.NET\)](#)
[Get Number of Instances Skipped in Driving Feature \(VBA\)](#)

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::PatternFeature Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

ForceUseSeedConfiguration Property (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : ForceUseSeedConfiguration Property (IDerivedPatternFeatureData)

Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property ForceUseSeedConfiguration As System.Boolean

```
Dim instance As IDerivedPatternFeatureData
Dim value As System.Boolean

instance.ForceUseSeedConfiguration = value

value = instance.ForceUseSeedConfiguration
```

C#

```
System.bool ForceUseSeedConfiguration {get; set;}
```

C++/CLI

```
property System.bool ForceUseSeedConfiguration {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the seed component configuration for all pattern components, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::ForceUseSeedConfiguration](#).

Remarks

If this property is set to true, the **Referenced configuration** section of the Component Properties dialog is disabled, and you cannot use [IComponent2::ReferencedConfiguration](#) to change the pattern instance configuration.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSeedComponentCount Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : GetSeedComponentCount Method (IDerivedPatternFeatureData)

Gets the number of seed component features for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSeedComponentCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IDerivedPatternFeatureData
Dim value As System.Integer

value = instance.GetSeedComponentCount()
```

C#

```
System.int GetSeedComponentCount()
```

C++/CLI

```
System.int GetSeedComponentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of seed component features on which the pattern is based

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::GetSeedComponentCount](#).

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::IGetSeedComponentArray Method](#)
[IDerivedPatternFeatureData::ISetSeedComponentArray Method](#)
[IDerivedPatternFeatureData::SeedComponentArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSkippedItemCount Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : GetSkippedItemCount Method (IDerivedPatternFeatureData)

Gets the number of skipped items for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSkippedItemCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetSkippedItemCount()
```

C#

```
System.int GetSkippedItemCount()
```

C++/CLI

```
System.int GetSkippedItemCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of skipped items

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::GetSkippedItemCount](#).

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::IGetSkippedItemArray Method](#)
[IDerivedPatternFeatureData::ISetSkippedItemArray Method](#)
[IDerivedPatternFeatureData::SkippedItemArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTransform Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : GetTransform Method (IDerivedPatternFeatureData)

Gets the transform for the specified instance of this derived-pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTransform( _  
    ByVal Instance As System.Integer _  
) As MathTransform
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim Instance As System.Integer  
Dim value As MathTransform  
  
value = instance.GetTransform(Instance)
```

C#

```
MathTransform GetTransform(  
    System.int Instance  
)
```

C++/CLI

```
MathTransform^ GetTransform(  
& System.int Instance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Instance

Index of one repeating element in this pattern (see **Remarks**)

Return Value

[Transform](#)

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::GetTransform](#).

Remarks

To get the number of instances in this pattern, get the number of subfeatures of the pattern by traversing the FeatureManager design tree, getting the derived-pattern feature, getting the derived-pattern feature's subfeatures, and keeping count of the number of subfeatures. You can use [IModelDoc2::FirstFeature](#), [IFeature::GetFirstSubFeature](#), and [IFeature::GetNextSubFeature](#) to traverse the FeatureManager design tree and get the derived-pattern feature's subfeatures.

Transform each instance by calling this method, setting its parameter *Instance* as follows:

1 <= *Instance* <= total number of instances in this pattern

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::SkippedItemArray Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : IAccessSelections Method (IDerivedPatternFeatureData)

Obsolete. See [IDerivedPatternFeatureData::IAccessSelections2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::IAccessSelections](#).

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections2 Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : IAccessSelections2 Method (IDerivedPatternFeatureData)

Gains access to the selections that describe this derived pattern feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) and [IFeature::IModifyDefinition2](#) if you modified the feature
- [IDerivedPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IGetSeedComponentArray Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : IGetSeedComponentArray Method (IDerivedPatternFeatureData)

Gets the seed component features for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSeedComponentArray() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim value As System.Object
```

```
value = instance.IGetSeedComponentArray()
```

C#

```
System.object IGetSeedComponentArray()
```

C++/CLI

```
System.Object^ IGetSeedComponentArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of seed component [features](#) (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

You can use [IFeature::GetSpecificFeature2](#) to get the [IComponent2](#) object for each seed component represented by a feature.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::GetSeedComponentCount Method](#)
[IDerivedPatternFeatureData::ISetSeedComponentArray Method](#)
[IDerivedPatternFeatureData::SeedComponentArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSkippedItemArray Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : IGetSkippedItemArray Method (IDerivedPatternFeatureData)

Gets the list of skipped items for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSkippedItemArray() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim value As System.Integer  
  
value = instance.IGetSkippedItemArray()
```

C#

```
System.int IGetSkippedItemArray()
```

C++/CLI

```
System.int IGetSkippedItemArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of longs of the items skipped
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::GetSkippedItemCount Method](#)
[IDerivedPatternFeatureData::ISetSkippedItemArray Method](#)
[IDerivedPatternFeatureData::SkippedItemArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSeedComponentArray Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : ISetSeedComponentArray Method (IDerivedPatternFeatureData)

Sets an array of the seed component features for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetSeedComponentArray( _  
    ByVal FeatCount As System.Integer, _  
    ByRef ArrayDataIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim FeatCount As System.Integer  
Dim ArrayDataIn As System.Object  
  
instance.ISetSeedComponentArray(FeatCount, ArrayDataIn)
```

C#

```
void ISetSeedComponentArray(  
    System.int FeatCount,  
    ref System.object ArrayDataIn  
)
```

C++/CLI

```
void ISetSeedComponentArray(
& System.int FeatCount,
& System.Object^% ArrayDataIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeatCount

Number of seed features

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of seed component [features](#) (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

- See [In-process Methods](#) for details about this type of method.

Remarks

You can pass a mixed array of [IComponent2](#) and [IFeature](#) objects representing components.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDerivedPatternFeatureData Interface](#)

[IDerivedPatternFeatureData Members](#)

[IDerivedPatternFeatureData::GetSeedComponentCount Method](#)

[IDerivedPatternFeatureData::ISetSeedComponentArray Method](#)

[IDerivedPatternFeatureData::SeedComponentArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSkippedItemArray Method (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : ISetSkippedItemArray Method (IDerivedPatternFeatureData)

Sets the list of items to skip for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetSkippedItemArray( _
    ByVal FeatCount As System.Integer, _
    ByRef ArrayDataIn As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData
Dim FeatCount As System.Integer
Dim ArrayDataIn As System.Integer
```

```
instance.ISetSkippedItemArray(FeatCount, ArrayDataIn)
```

C#

```
void ISetSkippedItemArray(
    System.int FeatCount,
    ref System.int ArrayDataIn
)
```

C++/CLI

```
void ISetSkippedItemArray(
& System.int FeatCount,
```

```
& System.int% ArrayDataIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeatCount

Number of items to skip

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of longs of the items to skip
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDerivedPatternFeatureData Interface](#)

[IDerivedPatternFeatureData Members](#)

[IDerivedPatternFeatureData::GetSkippedItemCount Method](#)

[IDerivedPatternFeatureData::GetSkippedItemArray Method](#)

[IDerivedPatternFeatureData::SkippedItemArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternFeature Property (IDerivedPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : PatternFeature Property (IDerivedPatternFeatureData)

Gets or sets the pattern feature for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PatternFeature As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData
Dim value As System.Object
```

```
instance.PatternFeature = value
```

```
value = instance.PatternFeature
```

C#

```
System.object PatternFeature {get; set;}
```

C++/CLI

```
property System.Object^ PatternFeature {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pattern [feature](#) on which to base this derived pattern feature

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::PatternFeature](#).

Example

[Create Derived Pattern Feature \(C#\)](#)
[Create Derived Pattern Feature \(VB.NET\)](#)
[Create Derived Pattern Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::DrivingFeatureSkippedItemArray Property\(\)](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateVisualProperty Property (IDerivedPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : PropagateVisualProperty Property (IDerivedPatternFeatureData)

Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) in this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PropagateVisualProperty As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim value As System.Boolean
```

```
instance.PropagateVisualProperty = value
```

```
value = instance.PropagateVisualProperty
```

C#

```
System.bool PropagateVisualProperty {get; set;}
```

C++/CLI

```
property System.bool PropagateVisualProperty {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate visual properties, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::PropagateVisualProperty](#).

Example

[Get Number of Instances Skipped in Driving Feature \(C#\)](#)
[Get Number of Instances Skipped in Driving Feature \(VB.NET\)](#)

[Get Number of Instances Skipped in Driving Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IDerivedPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : ReleaseSelectionAccess Method (IDerivedPatternFeatureData)

Releases access to the selections that describe this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::ReleaseSelectionAccess](#).

Example

[Get Number of Instances Skipped in Driving Feature \(C#\)](#)
[Get Number of Instances Skipped in Driving Feature \(VB.NET\)](#)
[Get Number of Instances Skipped in Driving Feature \(VBA\)](#)

Remarks

[IDerivedPatternFeatureData::AccessSelections](#) and [IDerivedPatternFeatureData::!AccessSelections2](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SeedComponentArray Property (IDerivedPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : SeedComponentArray Property (IDerivedPatternFeatureData)

Gets or sets an array of seed component features for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property SeedComponentArray As System.Object

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData  
Dim value As System.Object
```

```
instance.SeedComponentArray = value
```

```
value = instance.SeedComponentArray
```

C#

```
System.object SeedComponentArray {get; set;}
```

C++/CLI

```
property System.Object^ SeedComponentArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of seed component [features](#)

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::SeedComponentArray](#).

Example

[Get and Set Seed Components \(VBA\)](#)
[Get and Set Seed Components \(VB.NET\)](#)
[Get and Set Seed Components \(C#\)](#)

Remarks

You can:

- get the [IComponent2](#) object for each seed component represented by a feature using [IFeature::GetSpecificFeature2](#).
- pass a mixed array of [IComponent2](#) and [IFeature](#) objects representing components.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::GetSeedComponentCount Method](#)
[IDerivedPatternFeatureData::IGetSeedComponentArray Method](#)
[IDerivedPatternFeatureData::ISetSeedComponentArray Method](#)

Availability

SeedPosition Property (IDerivedPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : SeedPosition Property (IDerivedPatternFeatureData)

Gets or sets which pattern instance to use as the seed feature for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property SeedPosition As System.Integer

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData
Dim value As System.Integer
```

```
instance.SeedPosition = value
```

```
value = instance.SeedPosition
```

C#

```
System.int SeedPosition {get; set;}
```

C++/CLI

```
property System.int SeedPosition {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pattern instance to use as the seed feature (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::SeedPosition](#).

Example

[Create Derived Pattern Feature \(C#\)](#)
[Create Derived Pattern Feature \(VB.NET\)](#)
[Create Derived Pattern Feature \(VBA\)](#)

Remarks

The seed position is the index of a pattern instance, feature, or component that is part of an existing pattern and is used to drive the derived pattern feature.

The total number of seed positions = total number of pattern instances in the pattern used to create the derived pattern feature.

If the pattern used to create the derived pattern has pattern instances in Direction 1 and Direction 2, then the total number of seed positions = ((Number pattern instances in Direction 1) * (Number pattern instances in Direction 2) - 1).

Setting the seed position outside of the range of pattern instances is silently rejected, and the seed position remains unchanged.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)

Availability

SkippedItemArray Property (IDerivedPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPatternFeatureData Interface](#) : SkippedItemArray Property (IDerivedPatternFeatureData)

Gets or sets the list of skipped items for this derived pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property SkippedItemArray As System.Object

Visual Basic (Usage)



```
Dim instance As IDerivedPatternFeatureData
Dim value As System.Object

instance.SkippedItemArray = value
value = instance.SkippedItemArray
```

C#

```
System.Object SkippedItemArray {get; set;}
```

C++/CLI

```
property System.Object^ SkippedItemArray {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of the skipped items

Visual Basic for Applications (VBA) Syntax

See [DerivedPatternFeatureData::SkippedItemArray](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDerivedPatternFeatureData Interface](#)
[IDerivedPatternFeatureData Members](#)
[IDerivedPatternFeatureData::GetSkippedItemCount Method](#)
[IDerivedPatternFeatureData::IGetSkippedItemArray Method](#)
[IDerivedPatternFeatureData::ISetSkippedItemArray Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2