

SOLIDWORKS API (.NET VBA C#) — Reference (85/337): IDrawingDoc (part 2 of 7)

SOLIDWORKS API Documentation (converted from CHM)

IDrawingDoc (part 2 of 7) (Type)

Create1stAngleViews Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : Create1stAngleViews Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::1stAngleViews2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Create1stAngleViews( _  
    ByVal ModelName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim value As System.Boolean  
  
value = instance.Create1stAngleViews(ModelName)
```

C#

```
System.bool Create1stAngleViews(  
    System.string ModelName  
)
```

C++/CLI

```
System.bool Create1stAngleViews(  
& System.String^ ModelName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::Create1stAngleViews](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Create1stAngleViews2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : Create1stAngleViews2 Method (IDrawingDoc)

Creates standard three orthographic views (first angle projection) for the specified model.

.NET Syntax

Visual Basic (Declaration)

```
Function Create1stAngleViews2( _  
    ByVal ModelName As System.String _  
) As System.Boolean
```

```
Dim instance As IDrawingDoc
Dim ModelName As System.String
Dim value As System.Boolean

value = instance.Create1stAngleViews2(ModelName)
```

C#

```
System.bool Create1stAngleViews2(
    System.string ModelName
)
```

C++/CLI

```
System.bool Create1stAngleViews2(
    & System.String^ ModelName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

Name of the document from which to create views

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::Create1stAngleViews2](#).

Remarks

The views honor the automatic scaling behavior as specified in the document setting.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt4](#)
[IDrawingDoc::CreateDrawViewFromModelView2 Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::ICreateSectionViewAt4 Method](#)

Availability

SOLIDWORKS 99 SP01, datecode 1999229

SOLIDWORKS API Help

[Send comments on this topic.](#)

Create3rdAngleViews Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : Create3rdAngleViews Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::Create3rdAngleViews2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Create3rdAngleViews( _
    ByVal ModelName As System.String _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim value As System.Boolean  
  
value = instance.Create3rdAngleViews(ModelName)
```

C#

```
System.bool Create3rdAngleViews(  
    System.string ModelName  
)
```

C++/CLI

```
System.bool Create3rdAngleViews(  
& System.String^ ModelName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::Create3rdAngleViews](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Create3rdAngleViews2 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : Create3rdAngleViews2 Method (IDrawingDoc)

Creates standard three orthographic views (third angle projection) for the specified model.

.NET Syntax

Visual Basic (Declaration)

```
Function Create3rdAngleViews2( _  
    ByVal ModelName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim value As System.Boolean  
  
value = instance.Create3rdAngleViews2(ModelName)
```

C#

```
System.bool Create3rdAngleViews2(  
    System.string ModelName  
)
```

C++/CLI

```
System.bool Create3rdAngleViews2(  
& System.String^ ModelName
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

Name of the document from which to create views

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::Create3rdAngleViews2](#).

Example

[Access Assembly \(C++\)](#)
[Dimension Edge in Drawing \(VBA\)](#)
[Select Entity in Drawing View \(VBA\)](#)
[Get Annotations Arrays \(C#\)](#)
[Get Annotations Arrays \(VB.NET\)](#)
[Get Annotations Arrays \(VBA\)](#)

Remarks

The views honor the automatic scaling behavior as specified in the document setting.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateDrawViewFromModelView2 Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::ICreateDetailViewAt3 Method](#)
[IDrawingDoc::ICreateSectionViewAt4 Method](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateRelativeView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::ICreateDetailViewAt3 Method](#)
[IDrawingDoc::ICreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)

Availability

SOLIDWORKS 99 SP01, datecode 1999229

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateAngDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateAngDim Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateAngDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateAngDim( _  
    ByVal VP0 As System.Object, _  
    ByVal VP1 As System.Object, _  
    ByVal VP2 As System.Object, _  
    ByVal VP3 As System.Object, _  
    ByVal VP4 As System.Object, _  
    ByVal VP5 As System.Object, _
```

```

    ByVal VP6 As System.Object, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim VP0 As System.Object
Dim VP1 As System.Object
Dim VP2 As System.Object
Dim VP3 As System.Object
Dim VP4 As System.Object
Dim VP5 As System.Object
Dim VP6 As System.Object
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim value As System.Boolean

```

```

value = instance.CreateAngDim(VP0, VP1, VP2, VP3, VP4, VP5, VP6, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot)

```

C#

```

System.bool CreateAngDim(
    System.object VP0,
    System.object VP1,
    System.object VP2,
    System.object VP3,
    System.object VP4,
    System.object VP5,
    System.object VP6,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot
)

```

C++/CLI

```

System.bool CreateAngDim(
    & System.Object^ VP0,
    & System.Object^ VP1,
    & System.Object^ VP2,
    & System.Object^ VP3,
    & System.Object^ VP4,
    & System.Object^ VP5,
    & System.Object^ VP6,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VP0

VP1

VP2

VP3

VP4
VP5
VP6
ArrowSize
Text
TextHeight
WitnessGap
WitnessOvershoot

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateAngDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateAngDim2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateAngDim2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateAngDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateAngDim2(  
    ByVal VP0 As System.Object, _  
    ByVal VP1 As System.Object, _  
    ByVal VP2 As System.Object, _  
    ByVal VP3 As System.Object, _  
    ByVal VP4 As System.Object, _  
    ByVal VP5 As System.Object, _  
    ByVal VP6 As System.Object, _  
    ByVal ArrowSize As System.Double, _  
    ByVal Text As System.String, _  
    ByVal TextHeight As System.Double, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double, _  
    ByVal VTextPoint As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim VP0 As System.Object  
Dim VP1 As System.Object  
Dim VP2 As System.Object  
Dim VP3 As System.Object  
Dim VP4 As System.Object  
Dim VP5 As System.Object  
Dim VP6 As System.Object  
Dim ArrowSize As System.Double  
Dim Text As System.String  
Dim TextHeight As System.Double  
Dim WitnessGap As System.Double  
Dim WitnessOvershoot As System.Double  
Dim VTextPoint As System.Object  
Dim value As System.Boolean
```



```
value = instance.CreateAngDim2(VP0, VP1, VP2, VP3, VP4, VP5, VP6, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot, VTextPoint)
```

C#

```
System.bool CreateAngDim2(
    System.object VP0,
    System.object VP1,
    System.object VP2,
    System.object VP3,
    System.object VP4,
    System.object VP5,
    System.object VP6,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    System.object VTextPoint
)
```

C++/CLI

```
System.bool CreateAngDim2(
    & System.Object^ VP0,
    & System.Object^ VP1,
    & System.Object^ VP2,
    & System.Object^ VP3,
    & System.Object^ VP4,
    & System.Object^ VP5,
    & System.Object^ VP6,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot,
    & System.Object^ VTextPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VP0

VP1

VP2

VP3

VP4

VP5

VP6

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

VTextPoint

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateAngDim2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

CreateAngDim3 Method (IDrawingDoc)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateAngDim3 Method (IDrawingDoc)Obsolete. Superseded by [IDrawingDoc::CreateAngDim4](#). .NET Syntax

Visual Basic (Declaration)

```

Function CreateAngDim3( _
    ByVal VP0 As System.Object, _
    ByVal VP1 As System.Object, _
    ByVal VP2 As System.Object, _
    ByVal VP3 As System.Object, _
    ByVal VP4 As System.Object, _
    ByVal VP5 As System.Object, _
    ByVal VP6 As System.Object, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double, _
    ByVal VTextPoint As System.Object _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim VP0 As System.Object
Dim VP1 As System.Object
Dim VP2 As System.Object
Dim VP3 As System.Object
Dim VP4 As System.Object
Dim VP5 As System.Object
Dim VP6 As System.Object
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim VTextPoint As System.Object
Dim value As System.Object

```

```

value = instance.CreateAngDim3(VP0, VP1, VP2, VP3, VP4, VP5, VP6, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot, VTextPoint)

```

C#

```

System.object CreateAngDim3(
    System.object VP0,
    System.object VP1,
    System.object VP2,
    System.object VP3,
    System.object VP4,
    System.object VP5,
    System.object VP6,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    System.object VTextPoint
)

```

C++/CLI

```

System.Object^ CreateAngDim3(
& System.Object^ VP0,
& System.Object^ VP1,
& System.Object^ VP2,
& System.Object^ VP3,
& System.Object^ VP4,
& System.Object^ VP5,
& System.Object^ VP6,
& System.double ArrowSize,
& System.String^ Text,
& System.double TextHeight,
& System.double WitnessGap,
& System.double WitnessOvershoot,
& System.Object^ VTextPoint
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VP0

VP1

VP2

VP3

VP4

VP5

VP6

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

VTextPoint

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateAngDim3](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateAngDim4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateAngDim4 Method (IDrawingDoc)

Creates a non-associative angular dimension.

.NET Syntax

Visual Basic (Declaration)

```

Function CreateAngDim4( _
    ByVal P0 As System.Object, _
    ByVal P1 As System.Object, _
    ByVal P2 As System.Object, _
    ByVal P3 As System.Object, _
    ByVal P4 As System.Object, _
    ByVal P5 As System.Object, _
    ByVal P6 As System.Object, _
    ByVal TextPoint As System.Object, _

```

```
ByVal TextHeight As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Object  
Dim P1 As System.Object  
Dim P2 As System.Object  
Dim P3 As System.Object  
Dim P4 As System.Object  
Dim P5 As System.Object  
Dim P6 As System.Object  
Dim TextPoint As System.Object  
Dim TextHeight As System.Double  
Dim value As System.Object
```

```
value = instance.CreateAngDim4(P0, P1, P2, P3, P4, P5, P6, TextPoint, TextHeight)
```

C#

```
System.object CreateAngDim4(  
    System.object P0,  
    System.object P1,  
    System.object P2,  
    System.object P3,  
    System.object P4,  
    System.object P5,  
    System.object P6,  
    System.object TextPoint,  
    System.double TextHeight  
)
```

C++/CLI

```
System.Object^ CreateAngDim4(  
& System.Object^ P0,  
& System.Object^ P1,  
& System.Object^ P2,  
& System.Object^ P3,  
& System.Object^ P4,  
& System.Object^ P5,  
& System.Object^ P6,  
& System.Object^ TextPoint,  
& System.double TextHeight  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0
Array of 3 doubles (x,y,z); dimension end point
P1
Array of 3 doubles (x,y,z); dimension point
P2
Array of 3 doubles (x,y,z); extension1 start point
P3
Array of 3 doubles (x,y,z); extension1 end point
P4
Array of 3 doubles (x,y,z); extension2 start point
P5
Array of 3 doubles (x,y,z); extension2 end point
P6
Array of 3 doubles (x,y,z); plane normal
TextPoint
Array of 3 doubles (x,y,z); position of text
TextHeight
Text height in meters

Return Value

Newly created display dimension

Remarks

SOLIDWORKS creates this type of dimension between the two points that you specify. It has no relation to your geometry.

This method does not replace [IDrawingDoc::CreateDiamDim4](#) or [IDrawingDoc::!CreateDiamDim4](#); it changes the number of arguments required to construct the [IDisplayDimension](#) object.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::!CreateAngDim4 Method](#)
[IDrawingDoc::CreateLinearDim4 Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::!CreateLinearDim4 Method](#)
[IDrawingDoc::!CreateOrdinateDim4 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateAutoBalloonOptions Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateAutoBalloonOptions Method (IDrawingDoc)

Creates an object that stores auto balloon options.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateAutoBalloonOptions() As AutoBalloonOptions
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As AutoBalloonOptions  
  
value = instance.CreateAutoBalloonOptions()
```

C#

```
AutoBalloonOptions CreateAutoBalloonOptions()
```

C++/CLI

```
AutoBalloonOptions^ CreateAutoBalloonOptions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IAutoBalloonOptions](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateAutoBalloonOptions](#).

Example

[Add Autoballoons to Drawing \(C#\)](#)
[Add Autoballoons to Drawing \(VB.NET\)](#)
[Add Autoballoons to Drawing \(VBA\)](#)

Remarks

To automatically create BOM balloons:

1. Select one or more views or sheets for which to automatically create BOM balloons.

2. Call this method to create an [IAutoBalloonOptions](#) object.
3. Set the properties on the IAutoBalloonOptions object.
4. Pass the IAutoBalloonOptions object in a call to [IDrawingDoc::AutoBalloon5](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IModelDocExtension::CreateBalloonOptions Method](#)
[IModelDocExtension::CreateStackedBalloonOptions Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateAuxiliaryViewAt Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateAuxiliaryViewAt Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateAuxiliaryViewAt2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateAuxiliaryViewAt( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal NotAligned As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim NotAligned As System.Boolean  
Dim value As System.Boolean  
  
value = instance.CreateAuxiliaryViewAt(X, Y, Z, NotAligned)
```

C#

```
System.bool CreateAuxiliaryViewAt(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.bool NotAligned  
)
```

C++/CLI

```
System.bool CreateAuxiliaryViewAt(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.bool NotAligned  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

NotAligned

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateAuxiliaryViewAt](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateAuxiliaryViewAt2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateAuxiliaryViewAt2 Method (IDrawingDoc)

Creates an auxiliary view based on a selected edge in a drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateAuxiliaryViewAt2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal NotAligned As System.Boolean, _  
    ByVal Label As System.String, _  
    ByVal Showarrow As System.Boolean, _  
    ByVal Flip As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim NotAligned As System.Boolean  
Dim Label As System.String  
Dim Showarrow As System.Boolean  
Dim Flip As System.Boolean  
Dim value As System.Object
```

```
value = instance.CreateAuxiliaryViewAt2(X, Y, Z, NotAligned, Label, Showarrow, Flip)
```

C#

```
System.object CreateAuxiliaryViewAt2(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.bool NotAligned,  
    System.string Label,  
    System.bool Showarrow,  
    System.bool Flip  
)
```

C++/CLI

```
System.Object^ CreateAuxiliaryViewAt2(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.bool NotAligned,  
& System.String^ Label,  
& System.bool Showarrow,
```

```
& System.bool Flip  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

X position for the auxiliary view

Y

Y position for the auxiliary view

Z

Z position for the auxiliary view

NotAligned

True aligns the view from its owner, false does not

Label

String that holds label of the auxiliary view

Showarrow

True shows the arrow, false hides the arrow

Flip

True flips the side shown in the auxiliary view, false does not

Return Value

Newly created auxiliary view

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateAuxiliaryViewAt2](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)

[IDrawingDoc::ICreateDetailViewAt3 Method](#)

[IDrawingDoc::CreateDetailViewAt3 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateBlockDefinition Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateBlockDefinition Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::MakeSketchBlockFromFile](#), [ISketchManager::MakeSketchBlockSelected](#), and [ISketchManager::MakeSketchBlockFromSketch](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function CreateBlockDefinition( _  
    ByVal Name As System.String, _  
    ByVal XRefFileName As System.String, _  
    ByVal Instance As System.Boolean, _  
    ByVal Segments As System.Object, _  
    ByVal Points As System.Object, _  
    ByVal Notes As System.Object, _  
    ByVal Dimensions As System.Object, _  
    ByVal Blocks As System.Object _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim Name As System.String  
Dim XRefFileName As System.String  
Dim Instance As System.Boolean
```



```
Dim Segments As System.Object
Dim Points As System.Object
Dim Notes As System.Object
Dim Dimensions As System.Object
Dim Blocks As System.Object
Dim value As System.Object
```

```
value = instance.CreateBlockDefinition(Name, XRefFileName, Instance, Segments, Points, Notes,
Dimensions, Blocks)
```

C#

```
System.object CreateBlockDefinition(
    System.string Name,
    System.string XRefFileName,
    System.bool Instance,
    System.object Segments,
    System.object Points,
    System.object Notes,
    System.object Dimensions,
    System.object Blocks
)
```

C++/CLI

```
System.Object^ CreateBlockDefinition(
    & System.String^ Name,
    & System.String^ XRefFileName,
    & System.bool Instance,
    & System.Object^ Segments,
    & System.Object^ Points,
    & System.Object^ Notes,
    & System.Object^ Dimensions,
    & System.Object^ Blocks
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

XRefFileName

Instance

Segments

Points

Notes

Dimensions

Blocks

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateBlockDefinition](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateBreakOutSection Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateBreakOutSection Method (IDrawingDoc)

Creates a broken-out section in a drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateBreakOutSection( _  
    ByVal Depth As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Depth As System.Double  
Dim value As System.Boolean  
  
value = instance.CreateBreakOutSection(Depth)
```

C#

```
System.bool CreateBreakOutSection(  
    System.double Depth  
)
```

C++/CLI

```
System.bool CreateBreakOutSection(  
& System.double Depth  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Depth

Depth of the broken-out section

Return Value

True if the broken-out section was created, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateBreakOutSection](#).

Example

[Create Broken-Out Section \(VBA\)](#)
[Create Broken-Out Section \(VB.NET\)](#)
[Create Broken-Out Section \(C#\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::ICreateSectionViewAt4 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateCompoundNote Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateCompoundNote Method (IDrawingDoc)

Obsolete for documents created in SOLIDWORKS 2016 and later. Superseded by [ISketchBlockDefinition](#) and [ISketchBlockInstance](#). Creates and returns a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateCompoundNote( _
    ByVal Height As System.Double, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim Height As System.Double
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Object

value = instance.CreateCompoundNote(Height, X, Y, Z)
```

C#

```
System.object CreateCompoundNote(
    System.double Height,
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
System.Object^ CreateCompoundNote(
    & System.double Height,
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Height

Note height in meters

X

x location of note in meters

Y

y location of note in meters

Z

z location of note in meters

Return Value

Newly created compound note

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateCompoundNote](#).

Example

[Create Compound Note \(VBA\)](#)

Remarks

A compound note is a note that can contain multiple text strings and sketch geometry.

Compound notes are equivalent to a user-defined symbol. After creating a compound note, you can use the other compound note methods to add text and sketch geometry to the object.

This object appears to the end-user as though it were one item. If the user selects the compound note and drags it, all of the entities and text move together.

Because a compound note can have multiple pieces of text, many of the compound note methods require that you specify the index value of the text. For example, the first piece of text added to the compound note using [INote::AddText](#) has index number 1, the second text added has index number 2, and so on.

SOLIDWORKS adds the note to the view of the current selection, so you must make a selection before you call this method.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ICreateCompoundNote Method](#)
[IDrawingDoc::InsertRevisionSymbol Method](#)
[IDrawingDoc::ICreateText2 Method](#)
[IDrawingDoc::CreateText2 Method](#)
[IDrawingDoc::InsertNewNote2 Method](#)
[IDrawingDoc::NewNote Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateConstructionGeometry Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateConstructionGeometry Method (IDrawingDoc)

Sets the selected sketch segments to be construction geometry instead of sketch geometry.

.NET Syntax

Visual Basic (Declaration)

```
Sub CreateConstructionGeometry()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.CreateConstructionGeometry()
```

C#

```
void CreateConstructionGeometry()
```

C++/CLI

```
void CreateConstructionGeometry();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateConstructionGeometry](#).

Remarks

This method ignores construction geometry when it generates the solid body.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[ISketchManager::CreateConstructionGeometry Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateCustomSymbol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateCustomSymbol Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::MakeSketchBlockFromFile](#), [ISketchManager::MakeSketchBlockSelected](#), and [ISketchManager::MakeSketchBlockFromSketch](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateCustomSymbol( _  
    ByVal Segments As System.Object, _  
    ByVal Points As System.Object, _  
    ByVal Notes As System.Object _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Segments As System.Object  
Dim Points As System.Object  
Dim Notes As System.Object  
Dim value As System.Object  
  
value = instance.CreateCustomSymbol(Segments, Points, Notes)
```

C#

```
System.object CreateCustomSymbol(  
    System.object Segments,  
    System.object Points,  
    System.object Notes  
)
```

C++/CLI

```
System.Object^ CreateCustomSymbol(  
& System.Object^ Segments,  
& System.Object^ Points,  
& System.Object^ Notes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Segments

Points

Notes

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateCustomSymbol](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateDetailView Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDetailView Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDetailViewAt3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub CreateDetailView()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.CreateDetailView()
```

C#

```
void CreateDetailView()
```

C++/CLI

```
void CreateDetailView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDetailView](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateDetailViewAt Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDetailViewAt Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDetailViewAt3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDetailViewAt( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean  
  
value = instance.CreateDetailViewAt(X, Y, Z)
```

C#

```
System.bool CreateDetailViewAt(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool CreateDetailViewAt(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDetailViewAt](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateDetailViewAt2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDetailViewAt2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDetailViewAt3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDetailViewAt2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.CreateDetailViewAt2(X, Y, Z)
```

C#

```
System.bool CreateDetailViewAt2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool CreateDetailViewAt2(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDetailViewAt2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateDetailViewAt3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDetailViewAt3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDetailViewAt4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDetailViewAt3( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal Style As System.Integer, _  
    ByVal Scale1 As System.Double, _  
    ByVal Scale2 As System.Double, _  
    ByVal LabelIn As System.String, _  
    ByVal Showtype As System.Integer, _  
    ByVal FullOutline As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Style As System.Integer  
Dim Scale1 As System.Double  
Dim Scale2 As System.Double  
Dim LabelIn As System.String  
Dim Showtype As System.Integer  
Dim FullOutline As System.Boolean  
Dim value As System.Object  
  
value = instance.CreateDetailViewAt3(X, Y, Z, Style, Scale1, Scale2, LabelIn, Showtype, FullOutline)
```

C#

```
System.object CreateDetailViewAt3(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.int Style,  
    System.double Scale1,  
    System.double Scale2,  
    System.string LabelIn,  
    System.int Showtype,  
    System.bool FullOutline  
)
```

C++/CLI

```
System.Object^ CreateDetailViewAt3(  
& System.double X,
```

```

& System.double Y,
& System.double Z,
& System.int Style,
& System.double Scale1,
& System.double Scale2,
& System.String^ LabelIn,
& System.int Showtype,
& System.bool FullOutline
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

X position for the detail view

Y

Y position for the detail view

Z

Z position for the detail view

Style

Style for the detail view as defined in [swDetViewStyle_e](#)

Scale1

Scale numerator

Scale2

Scale denominator

LabelIn

String for the detail view label

Showtype

Type of sketch profile for the detail view as defined in [swDetCircleShowType_e](#)

FullOutline

True shows the full outline of the detail view, false does not

Return Value

Detail [view](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDetailViewAt3](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::ICreateDetailViewAt3 Method](#)

[IDrawingDoc::CreateViewport3 Method](#)

[IDrawingDoc::Create1stAngleViews2 Method](#)

[IDrawingDoc::Create3rdAngleViews2 Method](#)

[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)

[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)

[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)

[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)

[IDrawingDoc::ICreateDetailViewAt3 Method](#)

[IDrawingDoc::ICreateSectionViewAt4 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateDetailViewAt4 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDetailViewAt4 Method (IDrawingDoc)

Creates a detail view in a drawing document.

.NET Syntax

Visual Basic (Declaration)

```

Function CreateDetailViewAt4( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal Style As System.Integer, _
    ByVal Scale1 As System.Double, _
    ByVal Scale2 As System.Double, _
    ByVal LabelIn As System.String, _
    ByVal Showtype As System.Integer, _
    ByVal FullOutline As System.Boolean, _
    ByVal JaggedOutline As System.Boolean, _
    ByVal NoOutline As System.Boolean, _
    ByVal ShapeIntensity As System.Integer _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim Style As System.Integer
Dim Scale1 As System.Double
Dim Scale2 As System.Double
Dim LabelIn As System.String
Dim Showtype As System.Integer
Dim FullOutline As System.Boolean
Dim JaggedOutline As System.Boolean
Dim NoOutline As System.Boolean
Dim ShapeIntensity As System.Integer
Dim value As System.Object

```

```

value = instance.CreateDetailViewAt4(X, Y, Z, Style, Scale1, Scale2, LabelIn, Showtype,
FullOutline, JaggedOutline, NoOutline, ShapeIntensity)

```

C#

```

System.object CreateDetailViewAt4(
    System.double X,
    System.double Y,
    System.double Z,
    System.int Style,
    System.double Scale1,
    System.double Scale2,
    System.string LabelIn,
    System.int Showtype,
    System.bool FullOutline,
    System.bool JaggedOutline,
    System.bool NoOutline,
    System.int ShapeIntensity
)

```

C++/CLI

```

System.Object^ CreateDetailViewAt4(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.int Style,
    & System.double Scale1,
    & System.double Scale2,
    & System.String^ LabelIn,
    & System.int Showtype,
    & System.bool FullOutline,
    & System.bool JaggedOutline,
    & System.bool NoOutline,
    & System.int ShapeIntensity
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

X position for the detail view

Y

Y position for the detail view

Z

Z position for the detail view

Style

Style for the detail view as defined in [swDetViewStyle_e](#)

Scale1

Scale numerator

Scale2

Scale denominator

LabelIn

Detail view label

Showtype

Type of sketch for the detail view as defined in [swDetCircleShowType_e](#)

FullOutline

True to show a full outline, false to not; valid only if NoOutline is false

JaggedOutline

True to show a jagged outline, false to not; only valid if NoOutline is false

NoOutline

True to not show an outline, false to show an outline

ShapeIntensity

Intensity of jagged outline; valid range is 1 (most) to 5 (least) and only valid if JaggedOutline is true and NoOutline is false

Return Value

Detail [view](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDetailViewAt4](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)

[Create Detail Circle and Detail View \(VB.NET\)](#)

[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::CreateViewport3 Method \(\)](#)

[IDrawingDoc::Create1stAngleViews2 Method \(\)](#)

[IDrawingDoc::Create3rdAngleViews2 Method \(\)](#)

[IDrawingDoc::CreateAuxiliaryViewAt2 Method \(\)](#)

[IDrawingDoc::CreateDrawViewFromModelView3 Method \(\)](#)

[IDrawingDoc::CreateUnfoldedViewAt3 Method \(\)](#)

[IDrawingDoc::CreateSectionViewAt5 Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateDiamDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDiamDim Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDiamDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDiamDim( _  
    ByVal DimVal As System.Double, _  
    ByVal VP0 As System.Object, _
```

```

    ByVal VP1 As System.Object, _
    ByVal VP2 As System.Object, _
    ByVal VP3 As System.Object, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim DimVal As System.Double
Dim VP0 As System.Object
Dim VP1 As System.Object
Dim VP2 As System.Object
Dim VP3 As System.Object
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim value As System.Boolean

```

```

value = instance.CreateDiamDim(DimVal, VP0, VP1, VP2, VP3, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot)

```

C#

```

System.bool CreateDiamDim(
    System.double DimVal,
    System.object VP0,
    System.object VP1,
    System.object VP2,
    System.object VP3,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot
)

```

C++/CLI

```

System.bool CreateDiamDim(
    & System.double DimVal,
    & System.Object^ VP0,
    & System.Object^ VP1,
    & System.Object^ VP2,
    & System.Object^ VP3,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimVal

VP0

VP1

VP2

VP3

ArrowSize

Text

[TextHeight](#)

[WitnessGap](#)

[WitnessOvershoot](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDiamDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateDiamDim2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDiamDim2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDiamDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDiamDim2( _  
    ByVal DimVal As System.Double, _  
    ByVal VP0 As System.Object, _  
    ByVal VP1 As System.Object, _  
    ByVal VP2 As System.Object, _  
    ByVal VP3 As System.Object, _  
    ByVal ArrowSize As System.Double, _  
    ByVal Text As System.String, _  
    ByVal TextHeight As System.Double, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double, _  
    ByVal VTextPoint As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim DimVal As System.Double  
Dim VP0 As System.Object  
Dim VP1 As System.Object  
Dim VP2 As System.Object  
Dim VP3 As System.Object  
Dim ArrowSize As System.Double  
Dim Text As System.String  
Dim TextHeight As System.Double  
Dim WitnessGap As System.Double  
Dim WitnessOvershoot As System.Double  
Dim VTextPoint As System.Object  
Dim value As System.Boolean
```

```
value = instance.CreateDiamDim2(DimVal, VP0, VP1, VP2, VP3, ArrowSize, Text, TextHeight,  
WitnessGap, WitnessOvershoot, VTextPoint)
```

C#

```
System.bool CreateDiamDim2(  
    System.double DimVal,  
    System.object VP0,  
    System.object VP1,  
    System.object VP2,  
    System.object VP3,  
    System.double ArrowSize,
```

```

        System.string Text,
        System.double TextHeight,
        System.double WitnessGap,
        System.double WitnessOvershoot,
        System.object VTextPoint
    )

```

C++/CLI

```

System.bool CreateDiamDim2(
    & System.double DimVal,
    & System.Object^ VP0,
    & System.Object^ VP1,
    & System.Object^ VP2,
    & System.Object^ VP3,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot,
    & System.Object^ VTextPoint
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimVal

VP0

VP1

VP2

VP3

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

VTextPoint

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDiamDim2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateDiamDim3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDiamDim3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDiamDim4](#).

.NET Syntax

Visual Basic (Declaration)

```

Function CreateDiamDim3( _
    ByVal DimVal As System.Double, _
    ByVal VP0 As System.Object, _
    ByVal VP1 As System.Object, _
    ByVal VP2 As System.Object, _
    ByVal VP3 As System.Object, _
)

```

```

    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double, _
    ByVal VTextPoint As System.Object _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim DimVal As System.Double
Dim VP0 As System.Object
Dim VP1 As System.Object
Dim VP2 As System.Object
Dim VP3 As System.Object
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim VTextPoint As System.Object
Dim value As System.Object

```

```

value = instance.CreateDiamDim3(DimVal, VP0, VP1, VP2, VP3, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot, VTextPoint)

```

C#

```

System.object CreateDiamDim3(
    System.double DimVal,
    System.object VP0,
    System.object VP1,
    System.object VP2,
    System.object VP3,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    System.object VTextPoint
)

```

C++/CLI

```

System.Object^ CreateDiamDim3(
    & System.double DimVal,
    & System.Object^ VP0,
    & System.Object^ VP1,
    & System.Object^ VP2,
    & System.Object^ VP3,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot,
    & System.Object^ VTextPoint
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimVal

VP0

VP1

VP2

VP3

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

VTextPoint

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDiamDim3](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateDiamDim4 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDiamDim4 Method (IDrawingDoc)

Creates a non-associative diameter dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDiamDim4( _  
    ByVal P0 As System.Object, _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object, _  
    ByVal P3 As System.Object, _  
    ByVal TextPoint As System.Object, _  
    ByVal Val As System.Double, _  
    ByVal TextHeight As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Object  
Dim P1 As System.Object  
Dim P2 As System.Object  
Dim P3 As System.Object  
Dim TextPoint As System.Object  
Dim Val As System.Double  
Dim TextHeight As System.Double  
Dim value As System.Object
```

```
value = instance.CreateDiamDim4(P0, P1, P2, P3, TextPoint, Val, TextHeight)
```

C#

```
System.object CreateDiamDim4(  
    System.object P0,  
    System.object P1,  
    System.object P2,  
    System.object P3,  
    System.object TextPoint,  
    System.double Val,  
    System.double TextHeight  
)
```

C++/CLI

```
System.Object^ CreateDiamDim4(  
& System.Object^ P0,
```

```

& System.Object^ P1,
& System.Object^ P2,
& System.Object^ P3,
& System.Object^ TextPoint,
& System.double Val,
& System.double TextHeight
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

Array of 3 doubles (x,y,z); location of dimension point

P1

Array of 3 doubles (x,y,z); nearest point on circle

P2

Array of 3 doubles (x,y,z); farthest point on circle diametrically opposite to P1

P3

Array of 3 doubles (x,y,z); plane normal

TextPoint

Array of 3 doubles (x,y,z); position of text

Val

Dimension value in meters

TextHeight

Text height in meters

Return Value

Newly created display dimension

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDiamDim4](#).

Example

[Create Non-associative Diameter Dimension \(VBA\)](#)

Remarks

SOLIDWORKS creates this type of dimension between the two points you specify. It has no relation to your geometry.

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::!CreateDiamDim4 Method](#)

[IDrawingDoc::!CreateAngDim4 Method](#)

[IDrawingDoc::!CreateAngDim4 Method](#)

[IDrawingDoc::!CreateLinearDim4 Method](#)

[IDrawingDoc::!CreateLinearDim4 Method](#)

[IDrawingDoc::!CreateOrdinateDim4 Method](#)

[IDrawingDoc::!CreateOrdinateDim4 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateDrawViewFromModelView Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDrawViewFromModelView Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDrawViewFromModelView3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDrawViewFromModelView( _
    ByVal ModelName As System.String, _
    ByVal ViewName As System.String, _
    ByVal LocX As System.Double, _
    ByVal LocY As System.Double, _
    ByVal LocZ As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim ModelName As System.String
Dim ViewName As System.String
Dim LocX As System.Double
Dim LocY As System.Double
Dim LocZ As System.Double
Dim value As System.Boolean

value = instance.CreateDrawViewFromModelView(ModelName, ViewName, LocX, LocY, LocZ)
```

C#

```
System.bool CreateDrawViewFromModelView(
    System.string ModelName,
    System.string ViewName,
    System.double LocX,
    System.double LocY,
    System.double LocZ
)
```

C++/CLI

```
System.bool CreateDrawViewFromModelView(
    & System.String^ ModelName,
    & System.String^ ViewName,
    & System.double LocX,
    & System.double LocY,
    & System.double LocZ
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

ViewName

LocX

LocY

LocZ

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDrawViewFromModelView](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateDrawViewFromModelView2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateDrawViewFromModelView2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDrawViewFromModelView3](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function CreateDrawViewFromModelView2( _  
    ByVal ModelName As System.String, _  
    ByVal ViewName As System.String, _  
    ByVal LocX As System.Double, _  
    ByVal LocY As System.Double, _  
    ByVal LocZ As System.Double _  
    ) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim ViewName As System.String  
Dim LocX As System.Double  
Dim LocY As System.Double  
Dim LocZ As System.Double  
Dim value As View  
  
value = instance.CreateDrawViewFromModelView2(ModelName, ViewName, LocX, LocY, LocZ)
```

C#

```
View CreateDrawViewFromModelView2(  
    System.string ModelName,  
    System.string ViewName,  
    System.double LocX,  
    System.double LocY,  
    System.double LocZ  
)
```

C++/CLI

```
View^ CreateDrawViewFromModelView2(  
& System.String^ ModelName,  
& System.String^ ViewName,  
& System.double LocX,  
& System.double LocY,  
& System.double LocZ  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

ViewName

LocX

LocY

LocZ

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDrawViewFromModelView2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Creates a drawing view on the current drawing sheet using the specified model view.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDrawViewFromModelView3( _
    ByVal ModelName As System.String, _
    ByVal ViewName As System.String, _
    ByVal LocX As System.Double, _
    ByVal LocY As System.Double, _
    ByVal LocZ As System.Double _
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim ModelName As System.String
Dim ViewName As System.String
Dim LocX As System.Double
Dim LocY As System.Double
Dim LocZ As System.Double
Dim value As View

value = instance.CreateDrawViewFromModelView3(ModelName, ViewName, LocX, LocY, LocZ)
```

C#

```
View CreateDrawViewFromModelView3(
    System.string ModelName,
    System.string ViewName,
    System.double LocX,
    System.double LocY,
    System.double LocZ
)
```

C++/CLI

```
View^ CreateDrawViewFromModelView3(
    & System.String^ ModelName,
    & System.String^ ViewName,
    & System.double LocX,
    & System.double LocY,
    & System.double LocZ
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

Full pathname of the model document for which to create the drawing view (see **Remarks**)

ViewName

Name of the model view from which to create the drawing view (see **Remarks**)

LocX

x location of drawing view center in meters

LocY

y location of drawing view center in meters

LocZ

z location of drawing view center in meters

Return Value

Pointer to the newly create [IView](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateDrawViewFromModelView3](#).

Example

[Insert Model Annotations \(C#\)](#)

[Insert Model Annotations \(VB.NET\)](#)

Remarks

This method:

- Places the center of the view at the specified location.
- Uses the [swAutomaticScaling3ViewDrawings](#) setting to set the view scale. If this setting is set to True, then when a new drawing view is inserted, that view automatically scales to fit nicely on the drawing sheet. If there are no views on the sheet, the sheet scale is changed to the appropriate scale, and the view created uses the sheet scale.

If a model document is currently open in SOLIDWORKS and you don't know its full pathname, call [IModelDoc2::GetPathName](#) to populate ModelName. Include the **.sldprt** or **.sldasm** extension in the pathname.

ViewName must exactly match the name of the model view. For example, the names of the standard views begin with an asterisk. This asterisk is part of the view name and must be included (for example, "*Front").

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::ICreateDetailViewAt3 Method](#)
[IDrawingDoc::ICreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)

Availability

SOLIDWORKS 2005 SP2, Revision Number 13.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateFlatPatternViewFromModelView Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateFlatPatternViewFromModelView Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateFlatPatternViewFromModelView2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateFlatPatternViewFromModelView( _  
    ByVal ModelName As System.String, _  
    ByVal ConfigName As System.String, _  
    ByVal LocX As System.Double, _  
    ByVal LocY As System.Double, _  
    ByVal LocZ As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim ConfigName As System.String  
Dim LocX As System.Double  
Dim LocY As System.Double  
Dim LocZ As System.Double  
Dim value As System.Boolean
```

```
value = instance.CreateFlatPatternViewFromModelView(ModelName, ConfigName, LocX, LocY, LocZ)
```

C#

```
System.bool CreateFlatPatternViewFromModelView(  
    System.string ModelName,
```

```
System.string ConfigName,  
System.double LocX,  
System.double LocY,  
System.double LocZ  
)
```

C++/CLI

```
System.bool CreateFlatPatternViewFromModelView(  
& System.String^ ModelName,  
& System.String^ ConfigName,  
& System.double LocX,  
& System.double LocY,  
& System.double LocZ  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

ConfigName

LocX

LocY

LocZ

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateFlatPatternViewFromModelView](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateFlatPatternViewFromModelView2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateFlatPatternViewFromModelView2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateFlatPatternViewFromModelView3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateFlatPatternViewFromModelView2( _  
    ByVal ModelName As System.String, _  
    ByVal ConfigName As System.String, _  
    ByVal LocX As System.Double, _  
    ByVal LocY As System.Double, _  
    ByVal LocZ As System.Double, _  
    ByVal HideBendLines As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim ConfigName As System.String  
Dim LocX As System.Double  
Dim LocY As System.Double  
Dim LocZ As System.Double  
Dim HideBendLines As System.Boolean  
Dim value As System.Boolean
```



```
value = instance.CreateFlatPatternViewFromModelView2(ModelName, ConfigName, LocX, LocY, LocZ, HideBendLines)
```

C#

```
System.bool CreateFlatPatternViewFromModelView2(  
    System.string ModelName,  
    System.string ConfigName,  
    System.double LocX,  
    System.double LocY,  
    System.double LocZ,  
    System.bool HideBendLines  
)
```

C++/CLI

```
System.bool CreateFlatPatternViewFromModelView2(  
& System.String^ ModelName,  
& System.String^ ConfigName,  
& System.double LocX,  
& System.double LocY,  
& System.double LocZ,  
& System.bool HideBendLines  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName
Name of model
ConfigName
Name of configuration
LocX
X coordinate
LocY
Y coordinate
LocZ
Z coordinate
HideBendLines
True hides bend lines, false does not

Return Value

True if the flat-pattern view was created successfully, false if it was not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateFlatPatternViewFromModelView2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ChangeRefConfigurationOfFlatPatternView Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateFlatPatternViewFromModelView3 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateFlatPatternViewFromModelView3 Method (IDrawingDoc)

Creates a flat-pattern view from a model view.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateFlatPatternViewFromModelView3( _  
    ByVal ModelName As System.String, _
```

```

    ByVal ConfigName As System.String, _
    ByVal LocX As System.Double, _
    ByVal LocY As System.Double, _
    ByVal LocZ As System.Double, _
    ByVal HideBendLines As System.Boolean, _
    ByVal FlipView As System.Boolean _
) As View

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim ModelName As System.String
Dim ConfigName As System.String
Dim LocX As System.Double
Dim LocY As System.Double
Dim LocZ As System.Double
Dim HideBendLines As System.Boolean
Dim FlipView As System.Boolean
Dim value As View

```

```

value = instance.CreateFlatPatternViewFromModelView3(ModelName, ConfigName, LocX, LocY, LocZ,
HideBendLines, FlipView)

```

C#

```

View CreateFlatPatternViewFromModelView3(
    System.string ModelName,
    System.string ConfigName,
    System.double LocX,
    System.double LocY,
    System.double LocZ,
    System.bool HideBendLines,
    System.bool FlipView
)

```

C++/CLI

```

View^ CreateFlatPatternViewFromModelView3(
    & System.String^ ModelName,
    & System.String^ ConfigName,
    & System.double LocX,
    & System.double LocY,
    & System.double LocZ,
    & System.bool HideBendLines,
    & System.bool FlipView
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

Name of model

ConfigName

Name of configuration

LocX

X coordinate

LocY

Y coordinate

LocZ

Z coordinate

HideBendLines

True hides bend lines, false does not

FlipView

True flips the view, false does not

Return Value

Flat-pattern [view](#)

See [DrawingDoc::CreateFlatPatternViewFromModelView3](#).

Example

[Create and Flip Flat-Pattern View of Sheet Metal Part \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IView::FlipView Property](#)
[IView::IsFlatPatternView Method](#)

Availability

SOLIDWORKS 2007 SP5, Revision Number 15.5

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateLayer Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateLayer Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateLayer2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateLayer( _  
    ByVal Layername As System.String, _  
    ByVal LayerDesc As System.String, _  
    ByVal LayerColor As System.Integer, _  
    ByVal LayerStyle As System.Integer, _  
    ByVal LayerWidth As System.Integer, _  
    ByVal BOn As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Layername As System.String  
Dim LayerDesc As System.String  
Dim LayerColor As System.Integer  
Dim LayerStyle As System.Integer  
Dim LayerWidth As System.Integer  
Dim BOn As System.Boolean  
Dim value As System.Boolean  
  
value = instance.CreateLayer(Layername, LayerDesc, LayerColor, LayerStyle, LayerWidth, BOn)
```

C#

```
System.bool CreateLayer(  
    System.string Layername,  
    System.string LayerDesc,  
    System.int LayerColor,  
    System.int LayerStyle,  
    System.int LayerWidth,  
    System.bool BOn  
)
```

C++/CLI

```
System.bool CreateLayer(  
& System.String^ Layername,  
& System.String^ LayerDesc,  
& System.int LayerColor,  
& System.int LayerStyle,
```

```
& System.int LayerWidth,  
& System.bool BOn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layername

Layer name (see **Remarks**)

LayerDesc

Description for the new layer

LayerColor

COLORREF value specifying the color of items in this layer

LayerStyle

Line style as defined in [swLineStyles_e](#)

LayerWidth

Line width as defined in [swLineWeights_e](#)

BOn

True makes this layer visible, false makes it invisible

Return Value

True if the layer was created successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateLayer](#).

Remarks

If this layer is not visible, then SOLIDWORKS does not display entities on the layer.

Do not use the backslash (/) or at sign (@) symbols in LayerName.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::SetCurrentLayer Method](#)
[ILayer Interface](#)
[ILayerMgr Interface](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateLayer2 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateLayer2 Method (IDrawingDoc)

Creates a layer for this document.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateLayer2( _  
    ByVal Layername As System.String, _  
    ByVal LayerDesc As System.String, _  
    ByVal LayerColor As System.Integer, _  
    ByVal LayerStyle As System.Integer, _  
    ByVal LayerWidth As System.Integer, _  
    ByVal BOn As System.Boolean, _  
    ByVal BPrint As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim Layername As System.String
Dim LayerDesc As System.String
Dim LayerColor As System.Integer
Dim LayerStyle As System.Integer
Dim LayerWidth As System.Integer
Dim BOn As System.Boolean
Dim BPrint As System.Boolean
Dim value As System.Boolean

value = instance.CreateLayer2(Layername, LayerDesc, LayerColor, LayerStyle, LayerWidth, BOn,
BPrint)

```

C#

```

System.bool CreateLayer2(
    System.string Layername,
    System.string LayerDesc,
    System.int LayerColor,
    System.int LayerStyle,
    System.int LayerWidth,
    System.bool BOn,
    System.bool BPrint
)

```

C++/CLI

```

System.bool CreateLayer2(
    & System.String^ Layername,
    & System.String^ LayerDesc,
    & System.int LayerColor,
    & System.int LayerStyle,
    & System.int LayerWidth,
    & System.bool BOn,
    & System.bool BPrint
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layername
Layer name (see **Remarks**)

LayerDesc
Description for the new layer

LayerColor
COLORREF value specifying the color of items in this layer

LayerStyle
Line style as defined in [swLineStyles_e](#)

LayerWidth
Line width as defined in [swLineWeights_e](#)

BOn
True makes this layer visible, false makes it invisible

BPrint
True to print this layer when printing the document, false to not

Return Value

True if the layer was created successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateLayer2](#).

Example

[Create Layer for Selected View \(VBA\)](#)
[Create Layer for Selected View \(VB.NET\)](#)
[Create Layer for Selected View \(C#\)](#)

Remarks

If this layer is not visible, then SOLIDWORKS does not display entities on the layer.

Do not use backslash or @ symbols in Layername.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::SetCurrentLayer Method \(\)](#)
[ILayer Interface](#)
[ILayerMgr Interface](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateLinearDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateLinearDim Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateLinearDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateLinearDim( _  
    ByVal P0 As System.Object, _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object, _  
    ByVal P3 As System.Object, _  
    ByVal P4 As System.Object, _  
    ByVal Angle As System.Double, _  
    ByVal ArrowSize As System.Double, _  
    ByVal Text As System.String, _  
    ByVal TextHeight As System.Double, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Object  
Dim P1 As System.Object  
Dim P2 As System.Object  
Dim P3 As System.Object  
Dim P4 As System.Object  
Dim Angle As System.Double  
Dim ArrowSize As System.Double  
Dim Text As System.String  
Dim TextHeight As System.Double  
Dim WitnessGap As System.Double  
Dim WitnessOvershoot As System.Double  
Dim value As System.Boolean  
  
value = instance.CreateLinearDim(P0, P1, P2, P3, P4, Angle, ArrowSize, Text, TextHeight,  
WitnessGap, WitnessOvershoot)
```

C#

```
System.bool CreatelLinearDim(  
    System.object P0,  
    System.object P1,  
    System.object P2,  
    System.object P3,  
    System.object P4,  
    System.double Angle,  
    System.double ArrowSize,  
    System.string Text,
```

```
System.double TextHeight,  
System.double WitnessGap,  
System.double WitnessOvershoot  
)
```

C++/CLI

```
System.bool CreateLinearDim(  
& System.Object^ P0,  
& System.Object^ P1,  
& System.Object^ P2,  
& System.Object^ P3,  
& System.Object^ P4,  
& System.double Angle,  
& System.double ArrowSize,  
& System.String^ Text,  
& System.double TextHeight,  
& System.double WitnessGap,  
& System.double WitnessOvershoot  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Angle

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateLinearDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateLinearDim2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateLinearDim2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateLinearDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateLinearDim2( _  
    ByVal P0 As System.Object, _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object, _  
    ByVal P3 As System.Object, _  
    ByVal P4 As System.Object, _  
    ByVal Val As System.Double, _  
    ByVal PrimPrec As System.Integer, _
```

```

ByVal Text As System.String, _
ByVal TextPoint As System.Object, _
ByVal Angle As System.Double, _
ByVal TextHeight As System.Double, _
ByVal Prefix As System.String, _
ByVal Suffix As System.String, _
ByVal Callout1 As System.String, _
ByVal Callout2 As System.String, _
ByVal TolType As System.Integer, _
ByVal TolMin As System.String, _
ByVal TolMax As System.String, _
ByVal TolPrec As System.Integer, _
ByVal ArrowSize As System.Double, _
ByVal ArrowStyle As System.Integer, _
ByVal ArrowDir As System.Integer, _
ByVal WitnessGap As System.Double, _
ByVal WitnessOvershoot As System.Double, _
ByVal DualDisplay As System.Boolean, _
ByVal DualPrec As System.Integer _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim P0 As System.Object
Dim P1 As System.Object
Dim P2 As System.Object
Dim P3 As System.Object
Dim P4 As System.Object
Dim Val As System.Double
Dim PrimPrec As System.Integer
Dim Text As System.String
Dim TextPoint As System.Object
Dim Angle As System.Double
Dim TextHeight As System.Double
Dim Prefix As System.String
Dim Suffix As System.String
Dim Callout1 As System.String
Dim Callout2 As System.String
Dim TolType As System.Integer
Dim TolMin As System.String
Dim TolMax As System.String
Dim TolPrec As System.Integer
Dim ArrowSize As System.Double
Dim ArrowStyle As System.Integer
Dim ArrowDir As System.Integer
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim DualDisplay As System.Boolean
Dim DualPrec As System.Integer
Dim value As System.Boolean

```

```

value = instance.CreateLinearDim2(P0, P1, P2, P3, P4, Val, PrimPrec, Text, TextPoint, Angle,
TextHeight, Prefix, Suffix, Callout1, Callout2, TolType, TolMin, TolMax, TolPrec, ArrowSize,
ArrowStyle, ArrowDir, WitnessGap, WitnessOvershoot, DualDisplay, DualPrec)

```

C#

```

System.bool CreateLinearDim2(
    System.object P0,
    System.object P1,
    System.object P2,
    System.object P3,
    System.object P4,
    System.double Val,
    System.int PrimPrec,
    System.string Text,
    System.object TextPoint,
    System.double Angle,

```

```

        System.double TextHeight,
        System.string Prefix,
        System.string Suffix,
        System.string Callout1,
        System.string Callout2,
        System.int TolType,
        System.string TolMin,
        System.string TolMax,
        System.int TolPrec,
        System.double ArrowSize,
        System.int ArrowStyle,
        System.int ArrowDir,
        System.double WitnessGap,
        System.double WitnessOvershoot,
        System.bool DualDisplay,
        System.int DualPrec
    )

```

C++/CLI

```

System.bool CreateLinearDim2(
& System.Object^ P0,
& System.Object^ P1,
& System.Object^ P2,
& System.Object^ P3,
& System.Object^ P4,
& System.double Val,
& System.int PrimPrec,
& System.String^ Text,
& System.Object^ TextPoint,
& System.double Angle,
& System.double TextHeight,
& System.String^ Prefix,
& System.String^ Suffix,
& System.String^ Callout1,
& System.String^ Callout2,
& System.int TolType,
& System.String^ TolMin,
& System.String^ TolMax,
& System.int TolPrec,
& System.double ArrowSize,
& System.int ArrowStyle,
& System.int ArrowDir,
& System.double WitnessGap,
& System.double WitnessOvershoot,
& System.bool DualDisplay,
& System.int DualPrec
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Val

PrimPrec

Text

TextPoint

Angle

TextHeight

Prefix

Suffix

Callout1

Callout2
TolType
TolMin
TolMax
TolPrec
ArrowSize
ArrowStyle
ArrowDir
WitnessGap
WitnessOvershoot
DualDisplay
DualPrec

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateLinearDim2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateLinearDim3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateLinearDim3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateLinearDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateLinearDim3( _  
    ByVal P0 As System.Object, _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object, _  
    ByVal P3 As System.Object, _  
    ByVal P4 As System.Object, _  
    ByVal Val As System.Double, _  
    ByVal PrimPrec As System.Integer, _  
    ByVal Text As System.String, _  
    ByVal TextPoint As System.Object, _  
    ByVal Angle As System.Double, _  
    ByVal TextHeight As System.Double, _  
    ByVal Prefix As System.String, _  
    ByVal Suffix As System.String, _  
    ByVal Callout1 As System.String, _  
    ByVal Callout2 As System.String, _  
    ByVal TolType As System.Integer, _  
    ByVal TolMin As System.String, _  
    ByVal TolMax As System.String, _  
    ByVal TolPrec As System.Integer, _  
    ByVal ArrowSize As System.Double, _  
    ByVal ArrowStyle As System.Integer, _  
    ByVal ArrowDir As System.Integer, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double, _  
    ByVal DualDisplay As System.Boolean, _  
    ByVal DualPrec As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim P0 As System.Object
Dim P1 As System.Object
Dim P2 As System.Object
Dim P3 As System.Object
Dim P4 As System.Object
Dim Val As System.Double
Dim PrimPrec As System.Integer
Dim Text As System.String
Dim TextPoint As System.Object
Dim Angle As System.Double
Dim TextHeight As System.Double
Dim Prefix As System.String
Dim Suffix As System.String
Dim Callout1 As System.String
Dim Callout2 As System.String
Dim TolType As System.Integer
Dim TolMin As System.String
Dim TolMax As System.String
Dim TolPrec As System.Integer
Dim ArrowSize As System.Double
Dim ArrowStyle As System.Integer
Dim ArrowDir As System.Integer
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim DualDisplay As System.Boolean
Dim DualPrec As System.Integer
Dim value As System.Object

```

```

value = instance.CreateLinearDim3(P0, P1, P2, P3, P4, Val, PrimPrec, Text, TextPoint, Angle,
TextHeight, Prefix, Suffix, Callout1, Callout2, TolType, TolMin, TolMax, TolPrec, ArrowSize,
ArrowStyle, ArrowDir, WitnessGap, WitnessOvershoot, DualDisplay, DualPrec)

```

C#

```

System.object CreateLinearDim3(
    System.object P0,
    System.object P1,
    System.object P2,
    System.object P3,
    System.object P4,
    System.double Val,
    System.int PrimPrec,
    System.string Text,
    System.object TextPoint,
    System.double Angle,
    System.double TextHeight,
    System.string Prefix,
    System.string Suffix,
    System.string Callout1,
    System.string Callout2,
    System.int TolType,
    System.string TolMin,
    System.string TolMax,
    System.int TolPrec,
    System.double ArrowSize,
    System.int ArrowStyle,
    System.int ArrowDir,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    System.bool DualDisplay,
    System.int DualPrec
)

```

C++/CLI

```

System.Object^ CreateLinearDim3(
    & System.Object^ P0,
    & System.Object^ P1,

```

```

& System.Object^ P2,
& System.Object^ P3,
& System.Object^ P4,
& System.double Val,
& System.int PrimPrec,
& System.String^ Text,
& System.Object^ TextPoint,
& System.double Angle,
& System.double TextHeight,
& System.String^ Prefix,
& System.String^ Suffix,
& System.String^ Callout1,
& System.String^ Callout2,
& System.int TolType,
& System.String^ TolMin,
& System.String^ TolMax,
& System.int TolPrec,
& System.double ArrowSize,
& System.int ArrowStyle,
& System.int ArrowDir,
& System.double WitnessGap,
& System.double WitnessOvershoot,
& System.bool DualDisplay,
& System.int DualPrec
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Val

PrimPrec

Text

TextPoint

Angle

TextHeight

Prefix

Suffix

Callout1

Callout2

TolType

TolMin

TolMax

TolPrec

ArrowSize

ArrowStyle

ArrowDir

WitnessGap

WitnessOvershoot

DualDisplay

DualPrec

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateLinearDim4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateLinearDim4 Method (IDrawingDoc)

Creates a non-associative linear dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateLinearDim4( _  
    ByVal P0 As System.Object, _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object, _  
    ByVal P3 As System.Object, _  
    ByVal P4 As System.Object, _  
    ByVal TextPoint As System.Object, _  
    ByVal Val As System.Double, _  
    ByVal Angle As System.Double, _  
    ByVal TextHeight As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Object  
Dim P1 As System.Object  
Dim P2 As System.Object  
Dim P3 As System.Object  
Dim P4 As System.Object  
Dim TextPoint As System.Object  
Dim Val As System.Double  
Dim Angle As System.Double  
Dim TextHeight As System.Double  
Dim value As System.Object
```

```
value = instance.CreateLinearDim4(P0, P1, P2, P3, P4, TextPoint, Val, Angle, TextHeight)
```

C#

```
System.object CreateLinearDim4(  
    System.object P0,  
    System.object P1,  
    System.object P2,  
    System.object P3,  
    System.object P4,  
    System.object TextPoint,  
    System.double Val,  
    System.double Angle,  
    System.double TextHeight  
)
```

C++/CLI

```
System.Object^ CreateLinearDim4(  
& System.Object^ P0,  
& System.Object^ P1,  
& System.Object^ P2,  
& System.Object^ P3,  
& System.Object^ P4,  
& System.Object^ TextPoint,  
& System.double Val,  
& System.double Angle,
```

& System.double [TextHeight](#)
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0
Array of 3 doubles (x,y,z), dimension point
P1
Array of 3 doubles (x,y,z), dimension end
P2
Array of 3 doubles (x,y,z), normal to the plane of sketch
P3
Array of 3 doubles (x,y,z), extension line 1 reference point
P4
Array of 3 doubles (x,y,z), extension line 2 reference point
TextPoint
Array of 3 doubles (x,y,z), position of text
Val
Value for the non-associative linear dimension
Angle
Inclination angle of the text in radians
TextHeight
Text height in meters

Return Value

Display dimension

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateLinearDim4](#).

Remarks

SOLIDWORKS creates this type of dimension between the two specified points. The dimension is not related to the geometry.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateAngDim4 Method](#)
[IDrawingDoc::CreateDiamDim4 Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::ICreateDiamDim4 Method](#)
[IDrawingDoc::ICreateLinearDim4 Method](#)
[IDrawingDoc::ICreateOrdinateDim4 Method](#)
[IDrawingDoc::ICreateAngDim4 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateOrdinateDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateOrdinateDim Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateOrdinateDim4](#).

.NET Syntax

Visual Basic (Declaration)

```

Function CreateOrdinateDim( _
    ByVal P0 As System.Object, _
    ByVal P1 As System.Object, _
    ByVal P2 As System.Object, _
    ByVal P3 As System.Object, _
    ByVal P4 As System.Object, _
    ByVal Angle As System.Double, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim P0 As System.Object
Dim P1 As System.Object
Dim P2 As System.Object
Dim P3 As System.Object
Dim P4 As System.Object
Dim Angle As System.Double
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim value As System.Boolean

```

```

value = instance.CreateOrdinateDim(P0, P1, P2, P3, P4, Angle, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot)

```

C#

```

System.bool CreateOrdinateDim(
    System.object P0,
    System.object P1,
    System.object P2,
    System.object P3,
    System.object P4,
    System.double Angle,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot
)

```

C++/CLI

```

System.bool CreateOrdinateDim(
    & System.Object^ P0,
    & System.Object^ P1,
    & System.Object^ P2,
    & System.Object^ P3,
    & System.Object^ P4,
    & System.double Angle,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[P0](#)

P1
P2
P3
P4
Angle
ArrowSize
Text
TextHeight
WitnessGap
WitnessOvershoot

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateOrdinateDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateOrdinateDim2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateOrdinateDim2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateOrdinateDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateOrdinateDim2( _  
    ByVal P0 As System.Object, _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object, _  
    ByVal P3 As System.Object, _  
    ByVal P4 As System.Object, _  
    ByVal Angle As System.Double, _  
    ByVal ArrowSize As System.Double, _  
    ByVal Text As System.String, _  
    ByVal TextHeight As System.Double, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double, _  
    ByVal P5 As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim P0 As System.Object  
Dim P1 As System.Object  
Dim P2 As System.Object  
Dim P3 As System.Object  
Dim P4 As System.Object  
Dim Angle As System.Double  
Dim ArrowSize As System.Double  
Dim Text As System.String  
Dim TextHeight As System.Double  
Dim WitnessGap As System.Double  
Dim WitnessOvershoot As System.Double  
Dim P5 As System.Object  
Dim value As System.Boolean
```



```
value = instance.CreateOrdinateDim2(P0, P1, P2, P3, P4, Angle, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot, P5)
```

C#

```
System.bool CreateOrdinateDim2(
    System.object P0,
    System.object P1,
    System.object P2,
    System.object P3,
    System.object P4,
    System.double Angle,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    System.object P5
)
```

C++/CLI

```
System.bool CreateOrdinateDim2(
    & System.Object^ P0,
    & System.Object^ P1,
    & System.Object^ P2,
    & System.Object^ P3,
    & System.Object^ P4,
    & System.double Angle,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot,
    & System.Object^ P5
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Angle

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

P5

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateOrdinateDim2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)



.NET Syntax

Visual Basic (Declaration)

```
Function CreateOrdinateDim3( _  
    ByVal P0 As System.Object, _  
    ByVal P1 As System.Object, _  
    ByVal P2 As System.Object, _  
    ByVal P3 As System.Object, _  
    ByVal P4 As System.Object, _  
    ByVal Angle As System.Double, _  
    ByVal ArrowSize As System.Double, _  
    ByVal Text As System.String, _  
    ByVal TextHeight As System.Double, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double, _  
    ByVal P5 As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Object  
Dim P1 As System.Object  
Dim P2 As System.Object  
Dim P3 As System.Object  
Dim P4 As System.Object  
Dim Angle As System.Double  
Dim ArrowSize As System.Double  
Dim Text As System.String  
Dim TextHeight As System.Double  
Dim WitnessGap As System.Double  
Dim WitnessOvershoot As System.Double  
Dim P5 As System.Object  
Dim value As System.Object
```

```
value = instance.CreateOrdinateDim3(P0, P1, P2, P3, P4, Angle, ArrowSize, Text, TextHeight,  
WitnessGap, WitnessOvershoot, P5)
```

C#

```
System.object CreateOrdinateDim3(  
    System.object P0,  
    System.object P1,  
    System.object P2,  
    System.object P3,  
    System.object P4,  
    System.double Angle,  
    System.double ArrowSize,  
    System.string Text,  
    System.double TextHeight,  
    System.double WitnessGap,  
    System.double WitnessOvershoot,  
    System.object P5  
)
```

C++/CLI

```
System.Object^ CreateOrdinateDim3(  
& System.Object^ P0,  
& System.Object^ P1,  
& System.Object^ P2,  
& System.Object^ P3,  
& System.Object^ P4,  
& System.double Angle,
```

```

& System.double ArrowSize,
& System.String^ Text,
& System.double TextHeight,
& System.double WitnessGap,
& System.double WitnessOvershoot,
& System.Object^ P5
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Angle

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

P5

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateOrdinateDim3](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateOrdinateDim4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateOrdinateDim4 Method (IDrawingDoc)

Creates a non-associative ordinate dimension.

.NET Syntax

Visual Basic (Declaration)

```

Function CreateOrdinateDim4( _
    ByVal P0 As System.Object, _
    ByVal P1 As System.Object, _
    ByVal P2 As System.Object, _
    ByVal P3 As System.Object, _
    ByVal P4 As System.Object, _
    ByVal P5 As System.Object, _
    ByVal Val As System.Double, _
    ByVal Angle As System.Double, _
    ByVal TextHeight As System.Double _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim P0 As System.Object
Dim P1 As System.Object
Dim P2 As System.Object
Dim P3 As System.Object
Dim P4 As System.Object

```

```

Dim P5 As System.Object
Dim Val As System.Double
Dim Angle As System.Double
Dim TextHeight As System.Double
Dim value As System.Object

```

```
value = instance.CreateOrdinateDim4(P0, P1, P2, P3, P4, P5, Val, Angle, TextHeight)
```

C#

```

System.object CreateOrdinateDim4(
    System.object P0,
    System.object P1,
    System.object P2,
    System.object P3,
    System.object P4,
    System.object P5,
    System.double Val,
    System.double Angle,
    System.double TextHeight
)

```

C++/CLI

```

System.Object^ CreateOrdinateDim4(
    & System.Object^ P0,
    & System.Object^ P1,
    & System.Object^ P2,
    & System.Object^ P3,
    & System.Object^ P4,
    & System.Object^ P5,
    & System.double Val,
    & System.double Angle,
    & System.double TextHeight
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

Array of 3 doubles (x,y,z); dimension point

P1

Array of 3 doubles (x,y,z); unit vector that specifies the direction of the ordinate dimension

P2

Array of 3 doubles (x,y,z); extension line start point

P3

Array of 3 doubles (x,y,z); extension line end point

P4

Array of 3 doubles (x,y,z); unit vector and specifies the orientation of the text; for example, (1, 0, 0) results in horizontal text read from left to right

P5

Array of 3 doubles (x,y,z); position of text

Val

Value for the ordinate dimension

Angle

Inclination angle of the text in radians (character slant)

TextHeight

Text height in meters

Return Value

[Display dimension](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateOrdinateDim4](#).

Remarks

SOLIDWORKS creates this type of dimension between the two specified points. The dimension is not related to the geometry.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateAngDim4 Method](#)
[IDrawingDoc::CreateDiamDim4 Method](#)
[IDrawingDoc::CreateLinearDim4 Method](#)
[IDrawingDoc::ICreateAngDim4 Method](#)
[IDrawingDoc::ICreateDiamDim4 Method](#)
[IDrawingDoc::ICreateLinearDim4 Method](#)
[IDrawingDoc::ICreateOrdinateDim4 Method](#)
[IDrawingDoc::AddOrdinateDimension2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateRelativeView Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateRelativeView Method (IDrawingDoc)

Creates a relative drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateRelativeView( _  
    ByVal ModelName As System.String, _  
    ByVal XPos As System.Double, _  
    ByVal YPos As System.Double, _  
    ByVal ViewDirFront As System.Integer, _  
    ByVal ViewDirRight As System.Integer _  
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim XPos As System.Double  
Dim YPos As System.Double  
Dim ViewDirFront As System.Integer  
Dim ViewDirRight As System.Integer  
Dim value As View  
  
value = instance.CreateRelativeView(ModelName, XPos, YPos, ViewDirFront, ViewDirRight)
```

C#

```
View CreateRelativeView(  
    System.string ModelName,  
    System.double XPos,  
    System.double YPos,  
    System.int ViewDirFront,  
    System.int ViewDirRight  
)
```

C++/CLI

```
View^ CreateRelativeView(  
& System.String^ ModelName,  
& System.double XPos,  
& System.double YPos,  
& System.int ViewDirFront,  
& System.int ViewDirRight  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName
Path and filename of the model for which to create a relative drawing view
XPos
x coordinate where to create the relative drawing view
YPos
y coordinate where to create a relative drawing view
ViewDirFront
Orientation as defined by [swRelativeViewCreationDirection_e](#)
ViewDirRight
Orientation as defined by [swRelativeViewCreationDirection_e](#)

Return Value

[View](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateRelativeView](#).

Example

[Create Relative Drawing View \(C#\)](#)
[Create Relative Drawing View \(VB.NET\)](#)
[Create Relative Drawing View \(VBA\)](#)

Remarks

Select:

- the first orientation component using selection mark 1.
- the second orientation component using selection mark 2.

For multi-body parts only, select bodies to be shown in the created view using selection mark 4.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::!CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::!CreateDetailViewAt3 Method](#)
[IDrawingDoc::!CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0