

SOLIDWORKS API (.NET VBA C#) — Reference (86/337): IDrawingDoc (part 3 of 7)

SOLIDWORKS API Documentation (converted from CHM)

IDrawingDoc (part 3 of 7) (Type)

CreateSectionView Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateSectionView Method (IDrawingDoc)

Creates a section view in the drawing using the selected section line.

.NET Syntax

Visual Basic (Declaration)

```
Sub CreateSectionView()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.CreateSectionView()
```

C#

```
void CreateSectionView()
```

C++/CLI

```
void CreateSectionView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateSectionView](#).

Remarks

This method prompts the end-user for a name for the new section view.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateRelativeView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::ICreateDetailViewAt3 Method](#)
[IDrawingDoc::IDrawingDoc::ICreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)

CreateSectionViewAt Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateSectionViewAt Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateSectionViewAt4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSectionViewAt( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal NotAligned As System.Boolean, _
    ByVal IsOffsetSection As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim NotAligned As System.Boolean
Dim IsOffsetSection As System.Boolean
Dim value As System.Boolean

value = instance.CreateSectionViewAt(X, Y, Z, NotAligned, IsOffsetSection)
```

C#

```
System.bool CreateSectionViewAt(
    System.double X,
    System.double Y,
    System.double Z,
    System.bool NotAligned,
    System.bool IsOffsetSection
)
```

C++/CLI

```
System.bool CreateSectionViewAt(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.bool NotAligned,
    & System.bool IsOffsetSection
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

NotAligned

IsOffsetSection

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateSectionViewAt](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateSectionViewAt2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateSectionViewAt2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateSectionViewAt4](#).

Visual Basic (Declaration)

```
Function CreateSectionViewAt2( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal NotAligned As System.Boolean, _
    ByVal IsOffsetSection As System.Boolean, _
    ByVal Label As System.String, _
    ByVal Chgdirection As System.Boolean, _
    ByVal Scwithmodel As System.Boolean, _
    ByVal Partial As System.Boolean, _
    ByVal Dispsurfcut As System.Boolean _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim NotAligned As System.Boolean
Dim IsOffsetSection As System.Boolean
Dim Label As System.String
Dim Chgdirection As System.Boolean
Dim Scwithmodel As System.Boolean
Dim Partial As System.Boolean
Dim Dispsurfcut As System.Boolean
Dim value As System.Object
```

```
value = instance.CreateSectionViewAt2(X, Y, Z, NotAligned, IsOffsetSection, Label, Chgdirection,
Scwithmodel, Partial, Dispsurfcut)
```

C#

```
System.object CreateSectionViewAt2(
    System.double X,
    System.double Y,
    System.double Z,
    System.bool NotAligned,
    System.bool IsOffsetSection,
    System.string Label,
    System.bool Chgdirection,
    System.bool Scwithmodel,
    System.bool Partial,
    System.bool Dispsurfcut
)
```

C++/CLI

```
System.Object^ CreateSectionViewAt2(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.bool NotAligned,
    & System.bool IsOffsetSection,
    & System.String^ Label,
    & System.bool Chgdirection,
    & System.bool Scwithmodel,
    & System.bool Partial,
    & System.bool Dispsurfcut
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

NotAligned

IsOffsetSection

Label

Chgdirection

Scwithmodel

Partial

Dispsurfcut

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateSectionViewAt2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateSectionViewAt3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateSectionViewAt3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateSectionViewAt4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSectionViewAt3( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal NotAligned As System.Boolean, _  
    ByVal IsOffsetSection As System.Boolean, _  
    ByVal Label As System.String, _  
    ByVal Chgdirection As System.Boolean, _  
    ByVal Scwithmodel As System.Boolean, _  
    ByVal Partial As System.Boolean, _  
    ByVal Dispsurfcut As System.Boolean, _  
    ByVal ExcludedComponents As System.Object _  
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim NotAligned As System.Boolean  
Dim IsOffsetSection As System.Boolean  
Dim Label As System.String  
Dim Chgdirection As System.Boolean  
Dim Scwithmodel As System.Boolean  
Dim Partial As System.Boolean  
Dim Dispsurfcut As System.Boolean  
Dim ExcludedComponents As System.Object  
Dim value As View
```

```
value = instance.CreateSectionViewAt3(X, Y, Z, NotAligned, IsOffsetSection, Label, Chgdirection,  
Scwithmodel, Partial, Dispsurfcut, ExcludedComponents)
```

C#

```
View CreateSectionViewAt3(
    System.double X,
    System.double Y,
    System.double Z,
    System.bool NotAligned,
    System.bool IsOffsetSection,
    System.string Label,
    System.bool Chgdirection,
    System.bool Scwithmodel,
    System.bool Partial,
    System.bool Dispsurfcut,
    System.object ExcludedComponents
)
```

C++/CLI

```
View^ CreateSectionViewAt3(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.bool NotAligned,
    & System.bool IsOffsetSection,
    & System.String^ Label,
    & System.bool Chgdirection,
    & System.bool Scwithmodel,
    & System.bool Partial,
    & System.bool Dispsurfcut,
    & System.Object^ ExcludedComponents
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

NotAligned

IsOffsetSection

Label

Chgdirection

Scwithmodel

Partial

Dispsurfcut

ExcludedComponents

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateSectionViewAt3](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateSectionViewAt4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateSectionViewAt4 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateSectionViewAt5](#).

.NET Syntax

```

Function CreateSectionViewAt4( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal SectionLabel As System.String, _
    ByVal Options As System.Integer, _
    ByVal ExcludedComponents As System.Object _
) As View

```



```

Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim SectionLabel As System.String
Dim Options As System.Integer
Dim ExcludedComponents As System.Object
Dim value As View

value = instance.CreateSectionViewAt4(X, Y, Z, SectionLabel, Options, ExcludedComponents)

```

```

View CreateSectionViewAt4(
    System.double X,
    System.double Y,
    System.double Z,
    System.string SectionLabel,
    System.int Options,
    System.object ExcludedComponents
)

```

```

View^ CreateSectionViewAt4(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.String^ SectionLabel,
    & System.int Options,
    & System.Object^ ExcludedComponents
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[X](#)
x position on the drawing sheet for the center of the section view

[Y](#)
y position on the drawing sheet for the center of the section view

[Z](#)
z position on the drawing sheet for the center of the section view

[SectionLabel](#)
Letter for the label for the section view

[Options](#)
Options that affect the section view as defined in [swCreateSectionViewAtOptions_e](#)

[ExcludedComponents](#)
Array of components to exclude from the section view

Return Value

Pointer to the newly created [IView](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateSectionViewAt4](#).

Remarks

Before calling this method, select the section line or the lines to use as a section line.

This method runs silently; the end-user is not prompted for a label.

Use [IView::GetSection](#) to get the [IDrSection](#) object, and use [IDrSection::SetLabel2](#) to set the name for the label, which provides a warning if the name is a duplicate and the standard does not accept duplicate names.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::!CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::!CreateDetailViewAt3 Method](#)
[IDrawingDoc::!CreateSectionViewAt4 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateSectionViewAt5 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateSectionViewAt5 Method (IDrawingDoc)

Creates the specified section view.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSectionViewAt5( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal SectionLabel As System.String, _  
    ByVal Options As System.Integer, _  
    ByVal ExcludedComponents As System.Object, _  
    ByVal SectionDepth As System.Double _  
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim SectionLabel As System.String  
Dim Options As System.Integer  
Dim ExcludedComponents As System.Object  
Dim SectionDepth As System.Double  
Dim value As View
```

```
value = instance.CreateSectionViewAt5(X, Y, Z, SectionLabel, Options, ExcludedComponents,  
SectionDepth)
```

C#

```
View CreateSectionViewAt5(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.string SectionLabel,  
    System.int Options,  
    System.object ExcludedComponents,
```

```
        System.double SectionDepth  
    )
```

C++/CLI

```
View^ CreateSectionViewAt5(  
    & System.double X,  
    & System.double Y,  
    & System.double Z,  
    & System.String^ SectionLabel,  
    & System.int Options,  
    & System.Object^ ExcludedComponents,  
    & System.double SectionDepth  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

x position on the drawing sheet for the center of the section view

Y

y position on the drawing sheet for the center of the section view

Z

z position on the drawing sheet for the center of the section view

SectionLabel

Letter for the label for the section view

Options

Options that affect the section view as defined in [swCreateSectionViewAtOptions_e](#)

ExcludedComponents

Array of components to exclude from the section view

SectionDepth

Distance from the selected section line (see **Remarks**)

Return Value

Section [view](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateSectionViewAt5](#).

Example

[Create Section View and Get Some Data \(VBA\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(C#\)](#)

Remarks

Before calling this method, select the section line or lines to use as a section line.

This method runs silently; the end-user is not prompted for a label.

Use [IView::GetSection](#) to get the [IDrSection](#) object, and use [IDrSection::SetLabel2](#) to set the name for the label, which provides a warning if the name is a duplicate and the standard does not accept duplicate names.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ICreateSectionViewAt5 Method](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView3 Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::ICreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateRelativeView Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

CreateText Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateText Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateText2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateText( _  
    ByVal TextString As System.String, _  
    ByVal TextX As System.Double, _  
    ByVal TextY As System.Double, _  
    ByVal TextZ As System.Double, _  
    ByVal TextHeight As System.Double, _  
    ByVal TextAngle As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim TextString As System.String  
Dim TextX As System.Double  
Dim TextY As System.Double  
Dim TextZ As System.Double  
Dim TextHeight As System.Double  
Dim TextAngle As System.Double  
Dim value As System.Boolean  
  
value = instance.CreateText(TextString, TextX, TextY, TextZ, TextHeight, TextAngle)
```

C#

```
System.bool CreateText(  
    System.string TextString,  
    System.double TextX,  
    System.double TextY,  
    System.double TextZ,  
    System.double TextHeight,  
    System.double TextAngle  
)
```

C++/CLI

```
System.bool CreateText(  
& System.String^ TextString,  
& System.double TextX,  
& System.double TextY,  
& System.double TextZ,  
& System.double TextHeight,  
& System.double TextAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextString

TextX

TextY

TextZ

TextHeight

TextAngle

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateText](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateText2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateText2 Method (IDrawingDoc)

Creates a [note](#) containing the specified text at a given location.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateText2( _  
    ByVal TextString As System.String, _  
    ByVal TextX As System.Double, _  
    ByVal TextY As System.Double, _  
    ByVal TextZ As System.Double, _  
    ByVal TextHeight As System.Double, _  
    ByVal TextAngle As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim TextString As System.String  
Dim TextX As System.Double  
Dim TextY As System.Double  
Dim TextZ As System.Double  
Dim TextHeight As System.Double  
Dim TextAngle As System.Double  
Dim value As System.Object  
  
value = instance.CreateText2(TextString, TextX, TextY, TextZ, TextHeight, TextAngle)
```

C#

```
System.object CreateText2(  
    System.string TextString,  
    System.double TextX,  
    System.double TextY,  
    System.double TextZ,  
    System.double TextHeight,  
    System.double TextAngle  
)
```

C++/CLI

```
System.Object^ CreateText2(  
& System.String^ TextString,  
& System.double TextX,  
& System.double TextY,  
& System.double TextZ,  
& System.double TextHeight,  
& System.double TextAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextString

User input text

TextX

X text location in meters (see **Remarks**)

TextY

Y text location in meters (see **Remarks**)

TextZ

Z text location in meters (see **Remarks**)

TextHeight

Text height in meters

TextAngle

Text angle for rotated text in radians

Return Value

Newly created note

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateText2](#).

Remarks

The location specifies the position of the upper-left corner of the box containing the text with respect to the lower-left corner of the drawing.

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::!CreateText2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateUnfoldedViewAt Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateUnfoldedViewAt Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateUnfoldedViewAt3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateUnfoldedViewAt( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.CreateUnfoldedViewAt(X, Y, Z)
```

C#

```
System.bool CreateUnfoldedViewAt(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool CreateUnfoldedViewAt(  
& System.double X,  
& System.double Y,
```

```
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateUnfoldedViewAt](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateUnfoldedViewAt2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateUnfoldedViewAt2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateUnfoldedViewAt3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateUnfoldedViewAt2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal NotAligned As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim NotAligned As System.Boolean  
Dim value As System.Boolean  
  
value = instance.CreateUnfoldedViewAt2(X, Y, Z, NotAligned)
```

C#

```
System.bool CreateUnfoldedViewAt2(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.bool NotAligned  
)
```

C++/CLI

```
System.bool CreateUnfoldedViewAt2(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.bool NotAligned  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

NotAligned

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateUnfoldedViewAt2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateUnfoldedViewAt3 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateUnfoldedViewAt3 Method (IDrawingDoc)

Creates an unfolded drawing view from the selected drawing view and places it in the drawing at the specified location.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateUnfoldedViewAt3( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal NotAligned As System.Boolean _  
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim NotAligned As System.Boolean  
Dim value As View  
  
value = instance.CreateUnfoldedViewAt3(X, Y, Z, NotAligned)
```

C#

```
View CreateUnfoldedViewAt3(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.bool NotAligned  
)
```

C++/CLI

```
View^ CreateUnfoldedViewAt3(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.bool NotAligned  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

x position in the drawing sheet space for the center of the drawing view

Y

y position in the drawing sheet space for the center of the drawing view

Z

z position in the drawing sheet space for the center of the drawing view

NotAligned

True if you want to break the alignment with the parent view, false if you want to keep the view aligned with the parent view

Return Value

Pointer to the newly created [IView](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateUnfoldedViewAt3](#).

Example

[Create Unfolded View \(VBA\)](#)
[Create Unfolded View \(VB.NET\)](#)
[Create Unfolded View \(C#\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateRelativeView Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::ICreateDetailViewAt3 Method](#)
[IDrawingDoc::ICreateSectionViewAt4 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateViewport Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateViewport Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateViewport3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateViewport( _  
    ByVal LowerLeftX As System.Double, _  
    ByVal LowerLeftY As System.Double, _  
    ByVal UpperRightX As System.Double, _  
    ByVal UpperRightY As System.Double, _  
    ByVal SketchSize As System.Short _  
    ) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim LowerLeftX As System.Double  
Dim LowerLeftY As System.Double  
Dim UpperRightX As System.Double  
Dim UpperRightY As System.Double  
Dim SketchSize As System.Short  
Dim value As System.String
```

```
value = instance.CreateViewport(LowerLeftX, LowerLeftY, UpperRightX, UpperRightY, SketchSize)
```

C#

```
System.string CreateViewport(  
    System.double LowerLeftX,  
    System.double LowerLeftY,  
    System.double UpperRightX,  
    System.double UpperRightY,  
    System.short SketchSize  
)
```

C++/CLI

```
System.String^ CreateViewport(  
& System.double LowerLeftX,  
& System.double LowerLeftY,  
& System.double UpperRightX,  
& System.double UpperRightY,  
& System.short SketchSize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LowerLeftX

LowerLeftY

UpperRightX

UpperRightY

SketchSize

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateViewport](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateViewport2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateViewport2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateViewport3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateViewport2( _  
    ByVal LowerLeftX As System.Double, _  
    ByVal LowerLeftY As System.Double, _  
    ByVal UpperRightX As System.Double, _  
    ByVal UpperRightY As System.Double, _  
    ByVal SketchSize As System.Short, _  
    ByVal Scale As System.Double _  
) As System.String
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim LowerLeftX As System.Double  
Dim LowerLeftY As System.Double
```



Copy Code

```
Dim UpperRightX As System.Double
Dim UpperRightY As System.Double
Dim SketchSize As System.Short
Dim Scale As System.Double
Dim value As System.String
```

```
value = instance.CreateViewport2(LowerLeftX, LowerLeftY, UpperRightX, UpperRightY, SketchSize,
Scale)
```

C#

```
System.string CreateViewport2(
    System.double LowerLeftX,
    System.double LowerLeftY,
    System.double UpperRightX,
    System.double UpperRightY,
    System.short SketchSize,
    System.double Scale
)
```

C++/CLI

```
System.String^ CreateViewport2(
    & System.double LowerLeftX,
    & System.double LowerLeftY,
    & System.double UpperRightX,
    & System.double UpperRightY,
    & System.short SketchSize,
    & System.double Scale
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LowerLeftX

LowerLeftY

UpperRightX

UpperRightY

SketchSize

Scale

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateViewport2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateViewport3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CreateViewport3 Method (IDrawingDoc)

Creates an empty view in a drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateViewport3( _
    ByVal LowerLeftX As System.Double, _
    ByVal LowerLeftY As System.Double, _
    ByVal SketchSize As System.Short, _
```

```
ByVal Scale As System.Double _  
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim LowerLeftX As System.Double  
Dim LowerLeftY As System.Double  
Dim SketchSize As System.Short  
Dim Scale As System.Double  
Dim value As View  
  
value = instance.CreateViewport3(LowerLeftX, LowerLeftY, SketchSize, Scale)
```

C#

```
View CreateViewport3(  
    System.double LowerLeftX,  
    System.double LowerLeftY,  
    System.short SketchSize,  
    System.double Scale  
)
```

C++/CLI

```
View^ CreateViewport3(  
&    System.double LowerLeftX,  
&    System.double LowerLeftY,  
&    System.short SketchSize,  
&    System.double Scale  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LowerLeftX

x value for lower-left coordinate for the view

LowerLeftY

y value for lower-left coordinate for the view

SketchSize

Approximate number of entries

Scale

Scale to use for the view

Return Value

Pointer to the newly created [IView](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CreateViewport3](#).

Remarks

You cannot set the size of an empty view or resize it. Instead, resizing of the view occurs automatically when you add sketch or model geometry to the view.

The center of the empty view is computed from the specified lower-left corner and default values for the upper-right corner. The latter is set to (0.001, 0.001). The center is computed as follows:

$$\text{center} = \text{lower-left_corner} + (\text{upper-right_corner} - \text{lower-left_corner}) / 2.0$$

To move the view, use [IView::Position](#) or [IView::!Position](#).

The default SketchSize value is 0. If you are creating more than 500 sketch entities, specify a value instead of using the default.

After you use this method, you can create sketch entities in the new view. One advantage is that users can move the entities around the drawing by dragging the view instead of selecting all the entities.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateRelativeView Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::!CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::!CreateDetailViewAt3 Method](#)
[IDrawingDoc::!CreateSectionViewAt4 Method](#)

Availability

SOLIDWORKS 2005 SP2, Revision Number 13.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteAllCosmeticThreads Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : DeleteAllCosmeticThreads Method (IDrawingDoc)

Deletes all cosmetic threads, which do not have callouts, in a drawing of an assembly only.

.NET Syntax

Visual Basic (Declaration)

```
Sub DeleteAllCosmeticThreads()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.DeleteAllCosmeticThreads()
```

C#

```
void DeleteAllCosmeticThreads()
```

C++/CLI

```
void DeleteAllCosmeticThreads();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::DeleteAllCosmeticThreads](#).

Example

VB.NET:

```
' .....  
'  
' Preconditions: Drawing of an assembly with  
' cosmetic threads is active.  
'  
' Postconditions: Cosmetic threads without callouts  
' are deleted.  
'  
' .....
```

Option

Explicit On

Imports SOLIDWORKS.Interop.sldworks

Imports

SOLIDWORKS.Interop.swconst

Imports

System

Partial

Class SOLIDWORKSMacro

Public Sub main()

Dim swDrawingDoc As DrawingDoc

Dim swModel As ModelDoc2

Dim boolstatus As Boolean

swDrawingDoc = swApp.ActiveDoc

swDrawingDoc.DeleteAllCosmeticThreads()

swModel = swDrawingDoc

boolstatus = swModel.ForceRebuild3(False)

End Sub

''' <summary>

''' The SldWorks swApp variable is pre-assigned for you.

''' </summary>

Public swApp As SldWorks

End

Class

Remarks

This method only deletes cosmetic threads in a drawing of an assembly; this method does not delete cosmetic threads in a drawing of a part.

By default, cosmetic threads are not imported into an drawing of an assembly for performance reasons, but are imported into a drawing of part and belong to the features in the part; thus, they cannot be deleted using this method.

This method also does not delete any cosmetic threads with callouts in a drawing of an assembly.

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[ICThread Interface](#)

Availability

DeleteLineStyle Method (IDrawingDoc)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : DeleteLineStyle Method (IDrawingDoc)

Deletes the specified line style from the current drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteLineStyle( _
    ByVal StyleName As System.String, _
    ByVal ReplaceName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim StyleName As System.String
Dim ReplaceName As System.String
Dim value As System.Boolean

value = instance.DeleteLineStyle(StyleName, ReplaceName)
```

C#

```
System.bool DeletelineStyle(
    System.string StyleName,
    System.string ReplaceName
)
```

C++/CLI

```
System.bool DeletelineStyle(
    & System.String^ StyleName,
    & System.String^ ReplaceName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StyleName

Name of line style to delete

ReplaceName

Name of line style to replace deleted StyleName

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::DeleteLineStyle](#).

Example

[Manage Drawing Document Line Styles \(C#\)](#)
[Manage Drawing Document Line Styles \(VB.NET\)](#)
[Manage Drawing Document Line Styles \(VBA\)](#)

Remarks

The following line styles cannot be deleted:

- Solid
- Dashed
- Phantom
- Chain
- Center
- Stitch
- Thin/Thick Chain

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AddLineStyle Method](#)
[IDrawingDoc::GetLineStyles Method](#)
[IDrawingDoc::LoadLineStyles Method](#)
[IDrawingDoc::SaveLineStyles Method](#)
[ISldWorks::GetLineStyles Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Dimensions Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : Dimensions Method (IDrawingDoc)

Adds dimensions to the drawing from model.

.NET Syntax

Visual Basic (Declaration)

```
Sub Dimensions()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.Dimensions()
```

C#

```
void Dimensions()
```

C++/CLI

```
void Dimensions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::Dimensions](#).

Remarks

This method displays the **Insert Model Items** dialog in the SOLIDWORKS Design user interface.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AddChamferDim Method](#)
[IDrawingDoc::AddOrdinateDimension2 Method](#)
[IDrawingDoc::AttachDimensions Method](#)
[IDrawingDoc::AutoDimension Method](#)
[IDrawingDoc::DragModelDimension Method](#)
[IDrawingDoc::HideShowDimensions Method](#)
[IDrawingDoc::IAddChamferDim Method](#)
[IDrawingDoc::InsertRefDim Method](#)
[IDrawingDoc::InsertBaseDim Method](#)
[IDrawingDoc::SketchDim Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DragModelDimension Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : DragModelDimension Method (IDrawingDoc)

Copies or moves dimensions to a different drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub DragModelDimension( _  
    ByVal ViewName As System.String, _  
    ByVal DropEffect As System.Short, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim ViewName As System.String  
Dim DropEffect As System.Short  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
  
instance.DragModelDimension(ViewName, DropEffect, X, Y, Z)
```

C#

```
void DragModelDimension(  
    System.string ViewName,  
    System.short DropEffect,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
void DragModelDimension(  
& System.String^ ViewName,  
& System.short DropEffect,  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ViewName

Name of the drawing view to which you want to copy or move the selected model dimension

DropEffect

- Copy = 1
- Move = 2

X

X location in sheet space for the newly copied or moved dimension

Y

Y location in sheet space for the newly copied or moved dimension

Z

Z location in sheet space for the newly copied or moved dimension; set to 0

Return Value

The ViewName argument cannot be the current view for the dimension.

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::DragModelDimension](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Dimensions Method](#)

DrawingViewRotate Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : DrawingViewRotate Method (IDrawingDoc)

Rotates the selected drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function DrawingViewRotate( _  
    ByVal NewAngle As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim NewAngle As System.Double  
Dim value As System.Boolean
```

```
value = instance.DrawingViewRotate(NewAngle)
```

C#

```
System.bool DrawingViewRotate(  
    System.double NewAngle  
)
```

C++/CLI

```
System.bool DrawingViewRotate(  
& System.double NewAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NewAngle

New angle value for the drawing view

Return Value

True if successfully rotated, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::DrawingViewRotate](#).

Example

[Rotate Drawing View 45 Degrees \(C#\)](#)
[Rotate Drawing View 45 Degrees \(VB.NET\)](#)
[Rotate Drawing View 45 Degrees \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AlignHorz Method](#)
[IDrawingDoc::AlignVert Method](#)
[IDrawingDoc::RestoreRotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207



Obsolete. Superseded by [IDrawingDoc::DropDrawingViewFromPalette2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function DropDrawingViewFromPalette( _  
    ByVal Layout As System.Integer, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Layout As System.Integer  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As View  
  
value = instance.DropDrawingViewFromPalette(Layout, X, Y, Z)
```

C#

```
View DropDrawingViewFromPalette(  
    System.int Layout,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
View^ DropDrawingViewFromPalette(  
& System.int Layout,  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layout

ID of the drawing view to move to the drawing sheet

X

x coordinate where to drop the drawing view

Y

y coordinate where to drop the drawing view

Z

z coordinate where to drop the drawing view; this coordinate is always 0

Return Value

Pointer to the [IView](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::DropDrawingViewFromPalette](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Availability

DropDrawingViewFromPalette2 Method (IDrawingDoc)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : DropDrawingViewFromPalette2 Method (IDrawingDoc)

Moves the specified drawing view from the View Palette to the current drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function DropDrawingViewFromPalette2( _
    ByVal PaletteViewName As System.String, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim PaletteViewName As System.String
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As View

value = instance.DropDrawingViewFromPalette2(PaletteViewName, X, Y, Z)
```

C#

```
View DropDrawingViewFromPalette2(
    System.string PaletteViewName,
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
View^ DropDrawingViewFromPalette2(
    & System.String^ PaletteViewName,
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PaletteViewName

Name of the drawing view to move to the drawing sheet

X

x coordinate where to drop the drawing view

Y

y coordinate where to drop the drawing view

Z

z coordinate where to drop the drawing view; this coordinate is always 0

Return Value

[View](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::DropDrawingViewFromPalette2](#).

Example

[Drop Drawing Views from View Palette \(VBA\)](#)
[Drop First Drawing View from View Palette \(VBA\)](#)
[Get the Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(C#\)](#)
[Get the Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(VB.NET\)](#)
[Get the Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(VBA\)](#)

Remarks

The x, y, and z coordinates are in paper space. Thus, the drawing sheet scale is irrelevant.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GenerateViewPaletteViews Method](#)
[IDrawingDoc::GetDrawingPaletteViewNames Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditCenterMarkProperties Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EditCenterMarkProperties Method (IDrawingDoc)

Edits center mark properties.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditCenterMarkProperties( _  
    ByVal Angle As System.Double, _  
    ByVal Size As System.Double, _  
    ByVal Lines As System.Boolean, _  
    ByVal DocSettings As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Angle As System.Double  
Dim Size As System.Double  
Dim Lines As System.Boolean  
Dim DocSettings As System.Boolean  
  
instance.EditCenterMarkProperties(Angle, Size, Lines, DocSettings)
```

C#

```
void EditCenterMarkProperties(  
    System.double Angle,  
    System.double Size,  
    System.bool Lines,  
    System.bool DocSettings  
)
```

C++/CLI

```
void EditCenterMarkProperties(  
& System.double Angle,  
& System.double Size,  
& System.bool Lines,  
& System.bool DocSettings  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle
New angle of the center mark
Size
New size of the center mark
Lines
True displays the center mark lines, false displays the plus sign (+) at the circle center
DocSettings
True uses the default settings for this document, false does not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EditCenterMarkProperties](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[ICenterMark Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditOrdinate Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EditOrdinate Method (IDrawingDoc)

Edits an ordinate dimension.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditOrdinate()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.EditOrdinate()
```

C#

```
void EditOrdinate()
```

C++/CLI

```
void EditOrdinate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EditOrdinate](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AlignOrdinate Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::InsertOrdinate Method](#)
[IDrawingDoc::InsertHorizontalOrdinate Method](#)
[IDrawingDoc::InsertVerticalOrdinate Method](#)
[IModelDoc2::EditOrdinate Method](#)
[IModelDoc2::ReattachOrdinate Method](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IModelDoc2::AlignOrdinate Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditRebuild Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EditRebuild Method (IDrawingDoc)

Obsolete. Superseded by [IModelDoc2::EditRebuild3](#).

.NET Syntax

Visual Basic (Declaration)

Sub EditRebuild()

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.EditRebuild()
```

C#

```
void EditRebuild()
```

C++/CLI

```
void EditRebuild();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EditRebuild](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditSelectedGtol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EditSelectedGtol Method (IDrawingDoc)

Gets the selected GTol to edit.

.NET Syntax

Visual Basic (Declaration)

Function EditSelectedGtol() As System.Object

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Object  
  
value = instance.EditSelectedGtol()
```

C#

```
System.object EditSelectedGtol()
```

C++/CLI

```
System.Object^ EditSelectedGtol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Existing GTol

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EditSelectedGtol](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::!EditSelectedGtol Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditSheet Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EditSheet Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::EditSheet2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub EditSheet()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
```

```
instance.EditSheet()
```

C#

```
void EditSheet()
```

C++/CLI

```
void EditSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EditSheet](#).

Remarks

Subsequently created geometry resides on this drawing sheet.

You can use this method with [IDrawingDoc::EditSketch](#) or [IDrawingDoc::EditTemplate](#). Use [IDrawingDoc::GetEditSheet](#) to determine the current state.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[ISheet Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditSheet2 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EditSheet2 Method (IDrawingDoc)

Puts the current drawing sheet in edit mode.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditSheet2()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.EditSheet2()
```

C#

```
void EditSheet2()
```

C++/CLI

```
void EditSheet2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EditSheet2](#).

Example

[Place Note Behind Drawing Sheet \(VBA\)](#)
[Place Note Behind Drawing Sheet \(VB.NET\)](#)
[Place Note Behind Drawing Sheet \(C#\)](#)

Remarks

The drawing sheet in edit mode ensures graphics updates and contains all subsequently created geometry.

You can use this method with [IDrawingDoc::EditSketch](#) or [IDrawingDoc::EditTemplate](#). Use [IDrawingDoc::GetEditSheet](#) to determine the current state.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[ISheet Interface](#)

Availability

SOLIDWORKS 2024 SP02, Revision Number 32.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditSketch Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EditSketch Method (IDrawingDoc)

Allows editing of a sketch in the selected drawing view or sheet.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditSketch()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.EditSketch()
```

C#

```
void EditSketch()
```

C++/CLI

```
void EditSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EditSketch](#).

Remarks

Creating subsequent geometry resides in this drawing view or sheet.

If you selected a drawing view and called `IDrawingDoc::EditSketch`, then you can resume editing the drawing sheet by calling [IDrawingDoc::EditSheet](#) or by selecting the sheet and calling `IDrawingDoc::EditSketch` again.

To determine the current state, use [IDrawingDoc::GetEditSheet](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[ISketch Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditTemplate Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EditTemplate Method (IDrawingDoc)

Puts the template of the current drawing sheet in edit mode.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditTemplate()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.EditTemplate()
```

C#

```
void EditTemplate()
```

C++/CLI

```
void EditTemplate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EditTemplate](#).

Example

[Place Note Behind Drawing Sheet \(C#\)](#)
[Place Note Behind Drawing Sheet \(VB.NET\)](#)
[Place Note Behind Drawing Sheet \(VBA\)](#)

Remarks

Creating subsequent geometry resides on the drawing template.

You can use this method with [IDrawingDoc::EditSheet](#) or [IDrawingDoc::EditSketch](#). Use [IDrawingDoc::GetEditSheet](#) to determine the current state.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[ISheet::ReloadTemplate Method \(\)](#)
[ISheet::SaveFormat Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndDrawing Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : EndDrawing Method (IDrawingDoc)

Provides faster creation of entities in a drawing when used with [IDrawingDoc::StartDrawing](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub EndDrawing()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.EndDrawing()
```

C#

```
void EndDrawing()
```

C++/CLI

```
void EndDrawing();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::EndDrawing](#).

Remarks

Use [IDrawingDoc::StartDrawing](#) and this method to bound your entity creation statements.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExplodeBlockInstance Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ExplodeBlockInstance Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::ExplodeSketchBlockInstance](#).

.NET Syntax

Visual Basic (Declaration)

Function ExplodeBlockInstance() As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Boolean  
  
value = instance.ExplodeBlockInstance()
```

C#

```
System.bool ExplodeBlockInstance()
```

C++/CLI

```
System.bool ExplodeBlockInstance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ExplodeBlockInstance](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ExplodeCustomSymbol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ExplodeCustomSymbol Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::ExplodeSketchBlockInstance](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ExplodeCustomSymbol()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.ExplodeCustomSymbol()
```

C#

```
void ExplodeCustomSymbol()
```

C++/CLI

```
void ExplodeCustomSymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ExplodeCustomSymbol](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

FeatureByName Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : FeatureByName Method (IDrawingDoc)

Gets the specified feature in the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureByName( _  
    ByVal Name As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Name As System.String  
Dim value As System.Object  
  
value = instance.FeatureByName(Name)
```

C#

```
System.object FeatureByName(  
    System.string Name  
)
```

C++/CLI

```
System.Object^ FeatureByName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the feature

Return Value

Feature

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::FeatureByName](#).

Example

[Create and Name Planes \(VBA\)](#)
[Get and Set Table Anchor of Hole Table \(C#\)](#)
[Get and Set Table Anchor of Hole Table \(VB.NET\)](#)
[Get and Set Table Anchor of Hole Table \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::IFeatureByName Method](#)

FlipSectionLine Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : FlipSectionLine Method (IDrawingDoc)

Flips the cut direction of the selected section line.

.NET Syntax

Visual Basic (Declaration)

```
Sub FlipSectionLine()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.FlipSectionLine()
```

C#

```
void FlipSectionLine()
```

C++/CLI

```
void FlipSectionLine();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::FlipSectionLine](#).

Remarks

SOLIDWORKS creates the corresponding section view, if one exists, on the next rebuild.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrSection Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ForceRebuild Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ForceRebuild Method (IDrawingDoc)

Obsolete. Superseded by [IModel2::ForceRebuild3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ForceRebuild()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.ForceRebuild()
```

C#

```
void ForceRebuild()
```

C++/CLI

```
void ForceRebuild();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ForceRebuild](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GenerateViewPaletteViews Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GenerateViewPaletteViews Method (IDrawingDoc)

Adds the specified document's predefined drawing views to the View Palette.

.NET Syntax

Visual Basic (Declaration)

```
Function GenerateViewPaletteViews( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.GenerateViewPaletteViews(FileName)
```

C#

```
System.bool GenerateViewPaletteViews(  
    System.string FileName  
)
```

C++/CLI

```
System.bool GenerateViewPaletteViews(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Path and file name of the document from which to add the predefined drawing views to the View Palette

Return Value

True if the drawing views are added to the View Palette, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GenerateViewPaletteViews](#).

Example

[Get and Set Whether to Hide Cutting Line Shoulders \(C#\)](#)
[Get and Set Whether to Hide Cutting Line Shoulders \(VB.NET\)](#)
[Get and Set Whether to Hide Cutting Line Shoulders \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBlockDefinition Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetBlockDefinition Method (IDrawingDoc)

Obsolete. Superseded by [SketchManager::GetSketchBlockDefinitions](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBlockDefinition( _  
    ByVal Name As System.String _  
) As BlockDefinition
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Name As System.String  
Dim value As BlockDefinition  
  
value = instance.GetBlockDefinition(Name)
```

C#

```
BlockDefinition GetBlockDefinition(  
    System.string Name  
)
```

C++/CLI

```
BlockDefinition^ GetBlockDefinition(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetBlockDefinition](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBlockDefinitionCount Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetBlockDefinitionCount Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::GetSketchBlockDefinitionCount](#).

.NET Syntax

Visual Basic (Declaration)

Function GetBlockDefinitionCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As System.Integer

value = instance.GetBlockDefinitionCount()
```

C#

```
System.int GetBlockDefinitionCount()
```

C++/CLI

```
System.int GetBlockDefinitionCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetBlockDefinitionCount](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBlockDefinitions Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetBlockDefinitions Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::GetSketchBlockDefinitions](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBlockDefinitions() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As System.Object

value = instance.GetBlockDefinitions()
```

C#

```
System.object GetBlockDefinitions()
```

C++/CLI

```
System.Object^ GetBlockDefinitions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetBlockDefinitions](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

GetCurrentSheet Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetCurrentSheet Method (IDrawingDoc)

Gets the currently active drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentSheet() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As System.Object

value = instance.GetCurrentSheet()
```

C#

```
System.object GetCurrentSheet()
```

C++/CLI

```
System.Object^ GetCurrentSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Sheet

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetCurrentSheet](#).

Example

[Copy and Paste Drawing Sheet \(C#\)](#)
[Copy and Paste Drawing Sheet \(VB.NET\)](#)
[Copy and Paste Drawing Sheet \(VBA\)](#)
[Delete OLE Objects from Drawing Sheet and Template \(VBA\)](#)
[Get and Set Sheet Properties \(VBA\)](#)
[Get Drawing View Names and Types \(VBA\)](#)
[Get Name and Properties of Drawing Sheet Template \(VBA\)](#)
[Get Revision Table \(VBA\)](#)
[Get Sheet Numbers and Names \(VBA\)](#)
[Rebuild All Configurations \(VBA\)](#)
[Get Notes from New or Existing Title Block \(C#\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)

Remarks

The returned [ISheet](#) object includes methods that you can use to access the [IBomTable](#) object.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ActivateSheet Method](#)
[IDrawingDoc::GetSheetCount Method](#)
[IDrawingDoc::GetSheetNames Method](#)
[IDrawingDoc::SheetNext Method](#)
[IDrawingDoc::SheetPrevious Method](#)
[IDrawingDoc::IGetCurrentSheet Method](#)

GetDrawingPaletteViewNames Method (IDrawingDoc)

[See Also](#) [Example](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetDrawingPaletteViewNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As System.Object

value = instance.GetDrawingPaletteViewNames()
```

C#

```
System.Object GetDrawingPaletteViewNames()
```

C++/CLI

```
System.Object^ GetDrawingPaletteViewNames();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the names of the drawing views in the View Palette for the active drawing sheet

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetDrawingPaletteViewNames](#).

Example

[Drop Drawing Views from View Palette \(VBA\)](#)
[Drop First Drawing View from View Palette \(VBA\)](#)
[Get Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(C#\)](#)
[Get Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(VB.NET\)](#)
[Get Number of Lines in Flat-pattern Drawing View's Boundary-box Sketch \(VBA\)](#)

Remarks

If...	Then this method...
a part or assembly was not pre-selected for the View Palette (i.e., the View Palette is empty)	returns an empty array.
an end-user moves a drawing view from the View Palette to the drawing sheet (either through the user-interface or via an API)	does not include that drawing name the next time this method is called.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::DropDrawingViewFromPalette2 Method](#)
[IDrawingDoc::GenerateViewPaletteViews Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEditBlock Method (IDrawingDoc)

[See Also](#)



Obsolete. Superseded by [ISketchManager::EditSketchBlock](#) and [ISketchManager::EndEditSketchBlock](#).

 .NET Syntax

Visual Basic (Declaration)

Function GetEditBlock() As System.Boolean

Visual Basic (Usage)

Dim instance As [IDrawingDoc](#)
Dim value As System.Boolean

value = instance.GetEditBlock()

C#

System.bool GetEditBlock()

C++/CLI

System.bool GetEditBlock();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetEditBlock](#).

 Remarks

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEditSheet Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) ; GetEditSheet Method (IDrawingDoc)

Gets whether the current drawing is in edit sheet mode or edit template mode.

 .NET Syntax

Visual Basic (Declaration)

Function GetEditSheet() As System.Boolean

Visual Basic (Usage)

Dim instance As [IDrawingDoc](#)
Dim value As System.Boolean

value = instance.GetEditSheet()

C#

System.bool GetEditSheet()

C++/CLI

System.bool GetEditSheet();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True for edit sheet mode, false for edit template mode

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetEditSheet](#).

Remarks

Use:

- [IDrawingDoc::EditSheet](#) to set the drawing to be editing the sheet.
- [IDrawingDoc::EditTemplate](#) to set the drawing to be editing the template.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::EditSketch Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstView Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetFirstView Method (IDrawingDoc)

Gets the first drawing [view](#) on the current sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstView() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Object  
  
value = instance.GetFirstView()
```

C#

```
System.Object GetFirstView()
```

C++/CLI

```
System.Object^ GetFirstView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First drawing [view](#) in this drawing document

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetFirstView](#).

Example

[Change Note Text \(VBA\)](#)
[Create Section View at Specified Location \(VBA\)](#)
[Dimension Edge in Drawing \(VBA\)](#)

[Get Crosshatches on View \(VBA\)](#)
[Get Drawing View Names and Types \(VBA\)](#)
[Select Entity in Drawing View \(VBA\)](#)
[Traverse Drawing FeatureManager Design Tree \(VBA\)](#)
[Get Notes from New or Existing Title Block \(C#\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)
[Get View Bounding Box and Position \(C#\)](#)
[Get View Bounding Box and Position \(VB.NET\)](#)
[Get View Bounding Box and Position \(VBA\)](#)

Remarks

This method might be useful for starting an iteration through all the drawing views on the current sheet.

Because the drawing sheet also has sketch geometry, notes, GTols, and so on, this method returns the current drawing sheet. The next view returned by [IView::GetNextView](#) is the first drawing view in the current sheet.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ActivateSheet Method](#)
[IDrawingDoc::ActivateView Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::ActiveDrawingView Property](#)
[IDrawingDoc::IActiveDrawingView Property](#)
[IView::GetNextView Method](#)
[IView::IGetNextView Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetInsertionPoint Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetInsertionPoint Method (IDrawingDoc)

Gets the current insertion (pick) point in a drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function GetInsertionPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Object  
  
value = instance.GetInsertionPoint()
```

C#

```
System.object GetInsertionPoint()
```

C++/CLI

```
System.Object^ GetInsertionPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 3 doubles (x,y,z)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetInsertionPoint](#).

Remarks

You might want to use [ISelectionMgr::GetSelectionPointInSketchSpace2](#) to handle multiple selections.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::IGetInsertionPoint Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineFontCount Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetLineFontCount Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::GetLineFontCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineFontCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Integer  
  
value = instance.GetLineFontCount()
```

C#

```
System.int GetLineFontCount()
```

C++/CLI

```
System.int GetLineFontCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetLineFontCount](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineFontCount2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetLineFontCount2 Method (IDrawingDoc)

Gets the a number line fonts supported by this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineFontCount2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Integer  
  
value = instance.GetLineFontCount2()
```

C#

```
System.int GetLineFontCount2()
```

C++/CLI

```
System.int GetLineFontCount2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of line fonts supported by this drawing

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetLineFontCount2](#).

Remarks

Each line font is identified by an index in the range [0, (retval -1)].

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetLineFontId Method](#)
[IDrawingDoc::GetLineFontInfo Method](#)
[IDrawingDoc::GetLineFontName2 Method](#)
[IDrawingDoc::SetLineColor Method](#)
[IDrawingDoc::SetLineStyle Method](#)
[IDrawingDoc::SetLineWidth Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineFontId Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetLineFontId Method (IDrawingDoc)

Gets the associated line font ID.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineFontId( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetLineFontId(Index)
```

C#

```
System.int GetLineFontId(  
    System.int Index  
)
```

C++/CLI

```
System.int GetLineFontId(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index position of the line font which is within the index range returned by [IDrawingDoc::GetLineFontCount2](#)

Return Value

Line font ID

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetLineFontId](#).

Remarks

SOLIDWORKS uses the line font ID to represent specific line fonts whose names are, for example, Visible, Hidden, Sketch, and so on.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetLineFontName2 Method](#)
[IDrawingDoc::GetLineFontInfo2 Method](#)
[IDrawingDoc::SetLineColor Method](#)
[IDrawingDoc::SetLineStyle Method](#)
[IDrawingDoc::SetLineWidth Method](#)
[IDrawingDoc::GetLineFontCount2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineFontInfo Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetLineFontInfo Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::GetLineFontInfo2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineFontInfo( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetLineFontInfo(Index)
```

C#

```
System.object GetLineFontInfo(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetLineFontInfo(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetLineFontInfo](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineFontInfo2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetLineFontInfo2 Method (IDrawingDoc)

Gets the detailed information about the specified line font.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineFontInfo2( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetLineFontInfo2(Index)
```

C#

```
System.Object GetLineFontInfo2(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetLineFontInfo2(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index position of the line font which is within the index range returned by [IDrawingDoc::GetLineFontCount2](#)

Return Value

Array containing the line font information (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetLineFontInfo2](#).

Remarks

This method breaks down the line font into its individual segment lengths.

Lines are repeating patterns of space and solid segments. The segCount argument returns the number of segments that define the pattern, and segLengths[] specifies the length of each segment. A negative length value indicates space.

For example:

Solid line: segCount = 1, segLengths[] = {0.5}

Dashed line: segCount = 2, segLengths[] = {0.25, -0.25}

VARIANT format:

double segCount - Number of segments in the pattern

double segLengths[segCount] - Length of each segment

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetLineFontId Method](#)
[IDrawingDoc::GetLineFontName2 Method](#)
[GetLineFontCount2 Method](#)
[IDrawingDoc::SetLineColor Method](#)
[IDrawingDoc::SetLineStyle Method](#)
[IDrawingDoc::SetLineWidth Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineFontName Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetLineFontName Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::GetLineFontName2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineFontName( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetLineFontName(Index)
```

C#

```
System.string GetLineFontName(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetLineFontName(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetLineFontName](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineFontName2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetLineFontName2 Method (IDrawingDoc)

Gets the name of the specified line font.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineFontName2( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetLineFontName2(Index)
```

C#

```
System.string GetLineFontName2(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetLineFontName2(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index position of the line font which is within the index range returned by [IDrawingDoc::GetLineFontCount2](#)

Return Value

Line font name

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetLineFontName2](#).

Remarks

This method can return a font name Hidden, Visible, etc.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetLineFontId Method](#)
[IDrawingDoc::GetLineFontInfo2 Method](#)
[IDrawingDoc::SetLineColor Method](#)
[IDrawingDoc::SetLineStyle Method](#)
[IDrawingDoc::SetLineWidth Method](#)
[IDrawingDoc::GetLineFontCount2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineStyle Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetLineStyle Method (IDrawingDoc)

Gets all of the line styles used in the current document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineStyle( _  
    ByRef StyleNameList As System.Object, _  
    ByRef StyleList As System.Object _  
) As System.Boolean
```

```
Dim instance As IDrawingDoc  
Dim StyleNameList As System.Object  
Dim StyleList As System.Object  
Dim value As System.Boolean  
  
value = instance.GetLineStyles(StyleNameList, StyleList)
```

C#

```
System.bool GetLineStyles(  
    out System.object StyleNameList,  
    out System.object StyleList  
)
```

C++/CLI

```
System.bool GetLineStyles(  
& [Out] System.Object^ StyleNameList,  
& [Out] System.Object^ StyleList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StyleNameList
Array of strings containing style names
StyleList
Array of strings containing style types

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetLineStyles](#).

Example

[Manage Drawing Document Line Styles \(C#\)](#)
[Manage Drawing Document Line Styles \(VB.NET\)](#)
[Manage Drawing Document Line Styles \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AddLineStyle Method](#)
[IDrawingDoc::DeleteLineStyle Method](#)
[IDrawingDoc::LoadLineStyles Method](#)
[IDrawingDoc::SaveLineStyles Method](#)
[ISldWorks::GetLineStyles Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0