

SOLIDWORKS API (.NET VBA C#) — Reference (88/337): IDrawingDoc (part 5 of 7)

SOLIDWORKS API Documentation (converted from CHM)

IDrawingDoc (part 5 of 7) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetCurrentSheet Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IGetCurrentSheet Method (IDrawingDoc)

Gets the currently active drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCurrentSheet() As Sheet
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As Sheet
```

```
value = instance.IGetCurrentSheet()
```

C#

```
Sheet IGetCurrentSheet()
```

C++/CLI

```
Sheet^ IGetCurrentSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [ISheet](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc.IGetCurrentSheet](#).

Example

[Insert Spline in Drawing \(C++\)](#)

Remarks

The returned [ISheet](#) object includes methods that you can use to access the [IBomTable](#) object.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetCurrentSheet Method](#)
[IDrawingDoc::ActivateSheet Method](#)
[IDrawingDoc::EditSheet Method](#)
[IDrawingDoc::GetEditSheet Method](#)
[IDrawingDoc::GetSheetCount Method](#)
[IDrawingDoc::GetSheetNames Method](#)
[IDrawingDoc::IGetSheetNames Method](#)
[IDrawingDoc::IReorderSheets Method](#)
[IDrawingDoc::ReorderSheets Method](#)
[IDrawingDoc::SetupSheet4 Method](#)
[IDrawingDoc::SheetNext Method](#)
[IDrawingDoc::SheetPrevious Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFirstView Method (IDrawingDoc)

[See Also](#) [Example](#)



Gets the first drawing [view](#) on the current sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstView() As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As View  
  
value = instance.IGetFirstView()
```

C#

```
View IGetFirstView()
```

C++/CLI

```
View^ IGetFirstView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the first drawing [view](#) in this drawing document

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IGetFirstView](#).

Example

[Insert Spline in Drawing \(C++\)](#)

Remarks

This method might be useful for starting an iteration through all the drawing views on the current sheet.

Because the drawing sheet also has sketch geometry, notes, GTols, and so on, this method returns the current drawing sheet. The next view returned by [IView::GetNextView](#) is the first drawing view in the current sheet.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ActivateView Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::ActiveDrawingView Property](#)
[IDrawingDoc::IActiveDrawingView Property](#)
[IView::IGetNextView Method](#)
[IView::GetNextView Method](#)

IGetInsertionPoint Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IGetInsertionPoint Method (IDrawingDoc)

Gets the current insertion (pick) point in a drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetInsertionPoint() As System.Double
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim value As System.Double  
  
value = instance.IGetInsertionPoint()
```

C#

```
System.double IGetInsertionPoint()
```

C++/CLI

```
System.double IGetInsertionPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of 3 doubles (x,y,z)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Example

You might want to use [ISelectionMgr::IGetSelectionPointInSketchSpace2](#) to handle multiple selections.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetInsertionPoint Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetPenInfo Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IGetPenInfo Method (IDrawingDoc)

Gets information about the pens used in SOLIDWORKS.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPenInfo() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim value As System.Integer  
  
value = instance.IGetPenInfo()
```

C#

```
System.int IGetPenInfo()
```

C++/CLI

```
System.int IGetPenInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of longs (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The return value is the following array of longs: [*font*, *weight*, *color*]

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetPenCount Method](#)
[IDrawingDoc::GetPenInfo Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSheetNames Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IGetSheetNames Method (IDrawingDoc)

Gets a list of the names of the drawing sheets in this drawing.

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetSheetNames(  
    ByRef Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Count As System.Integer  
Dim value As System.String  
  
value = instance.IGetSheetNames(Count)
```

C#

```
System.string IGetSheetNames(  
    out System.int Count  
)
```

C++/CLI

```
System.String^ IGetSheetNames(  
& [Out] System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of drawing sheets in this drawing (see Remarks)

Return Value

- in-process, unmanaged C++: Pointer to an array containing the names of the drawing sheets in this drawing of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

 Remarks

The argument Count is used to help prevent memory overwrites. First call [IDrawingDoc::GetSheetCount](#) to get the number of sheets in this drawing. Then use its return value to dimension the return value array.

This method compares the number of sheets in this part with the value passed in.

If the actual number of sheets is...	Then...
Larger than the value passed in	no sheets are returned, and status returns S_ERROR.
Smaller than this value	the names of all of the sheets in the return value is returned and changes Count to reflect the actual number of sheets.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ActivateSheet Method](#)
[IDrawingDoc::EditSheet Method](#)
[IDrawingDoc::GetCurrentSheet Method](#)
[IDrawingDoc::GetSheetNames Method](#)
[IDrawingDoc::IGetCurrentSheet Method](#)
[IDrawingDoc::NewSheet3 Method](#)
[IDrawingDoc::SetupSheet4 Method](#)
[ISheet Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCustomSymbol2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IInsertCustomSymbol2 Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::InsertSketchBlockInstance](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertCustomSymbol2( _  
    ByVal FileName As System.String _  
) As CustomSymbol
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim FileName As System.String  
Dim value As CustomSymbol
```

```
value = instance.IInsertCustomSymbol2(FileName)
```

C#

```
CustomSymbol IInsertCustomSymbol2(  
    System.string FileName  
)
```

C++/CLI

```
CustomSymbol^ IInsertCustomSymbol2(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IInsertCustomSymbol2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IInsertDowelSymbol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IInsertDowelSymbol Method (IDrawingDoc)

Inserts a dowel pin symbol on the currently selected edge or edges.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IInsertDowelSymbol() As DowelSymbol
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As DowelSymbol  
  
value = instance.IInsertDowelSymbol()
```

C#

```
DowelSymbol IInsertDowelSymbol()
```

C++/CLI

```
DowelSymbol^ IInsertDowelSymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Dowel pin symbol](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IInsertDowelSymbol](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::InsertDowelSymbol Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IInsertMultiJogLeader2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IInsertMultiJogLeader2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertMultiJogLeader3](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IInsertMultiJogLeader2( _  
    ByVal PointsCount As System.Integer, _  
    ByRef Points As MathPoint _  
) As MultiJogLeader
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim PointsCount As System.Integer  
Dim Points As MathPoint  
Dim value As MultiJogLeader  
  
value = instance.IInsertMultiJogLeader2(PointsCount, Points)
```

C#

```
MultiJogLeader IInsertMultiJogLeader2(
    System.int PointsCount,
    ref MathPoint Points
)
```

C++/CLI

```
MultiJogLeader^ IInsertMultiJogLeader2(
    & System.int PointsCount,
    & MathPoint^% Points
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointsCount

Points

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IInsertMultiJogLeader2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IInsertMultiJogLeader3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IInsertMultiJogLeader3 Method (IDrawingDoc)

Inserts a multi-jog leader.

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertMultiJogLeader3( _
    ByVal PointsCount As System.Integer, _
    ByRef Points As MathPoint, _
    ByVal StartPointArrowStyle As System.Integer, _
    ByVal EndPointArrowStyle As System.Integer _
) As MultiJogLeader
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim PointsCount As System.Integer
Dim Point As MathPoint
Dim StartPointArrowStyle As System.Integer
Dim EndPointArrowStyle As System.Integer
Dim value As MultiJogLeader

value = instance.IInsertMultiJogLeader3(PointsCount, Points, StartPointArrowStyle,
EndPointArrowStyle)
```

C#

```
MultiJogLeader IInsertMultiJogLeader3(
    System.int PointsCount,
    ref MathPoint Points,
    System.int StartPointArrowStyle,
    System.int EndPointArrowStyle
)
```

```
MultiJogLeader^ IInsertMultiJogLeader3(
& System.int PointsCount,
& MathPoint^% Points,
& System.int StartPointArrowStyle,
& System.int EndPointArrowStyle
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointsCount

Number of points

Points

Array of [points](#) of size PointsCount

StartPointArrowStyle

Starting point's arrowhead style as defined in [swArrowStyle_e](#)

EndPointArrowStyle

Ending point's arrowhead style as defined in [swArrowStyle_e](#)

Return Value

Pointer to the newly created [multi-jog leader](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertMultiJogLeader3](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::InsertMultiJogLeader3 Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRevisionCloud Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertRevisionCloud Method (IDrawingDoc)

Inserts a revision cloud annotation with the specified shape into a view or sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertRevisionCloud( _
    ByVal CloudShape As System.Integer _
) As RevisionCloud
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim CloudShape As System.Integer
Dim value As RevisionCloud
```

```
value = instance.IInsertRevisionCloud(CloudShape)
```

C#

```
RevisionCloud IInsertRevisionCloud(
    System.int CloudShape
)
```

C++/CLI

```
RevisionCloud^ IInsertRevisionCloud(  
& System.int CloudShape  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CloudShape
Revision cloud annotation shape as defined in [swRevisionCloudShape_e](#)

Return Value

- in-process, unmanaged C++: Pointer to an [IRevisionCloud](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

 Remarks

After calling this method:

1. Call [IRevisionCloud::IGetAnnotation](#) to get the annotation object for the revision cloud.
2. Call [IAnnotation::SetPosition](#) to set the revision cloud position point on the drawing. If you eliminate this step, the revision cloud is rendered starting at the drawing origin of x=0, y=0, z=0. Set the revision cloud position point as follows:

For revision cloud shape...	Set the revision cloud position point to...
Ellipse	The center of the revision cloud.
Rectangle	A corner of the revision cloud.
Polygon	One of the points on the revision cloud.
Freehand	One of the points on the revision cloud.

3. Call [IRevisionCloud::ArcRadius](#) to set the arc radius of the revision cloud.
4. Call [IRevisionCloud::SetPathPointAtIndex](#) with Index = -1 to create points on the revision cloud as follows:

For revision cloud shape...	Call IRevisionCloud::SetPathPointAtIndex...
Ellipse	Once, specifying the coordinates of a corner of the ellipse-inscribed rectangle.
Rectangle	Once, specifying the coordinates of a corner opposite the revision cloud position point.
Polygon	(Number of polygon sides + 1) times, such that the first and last points coincide with the revision cloud position point.
Freehand	Indefinite number of times, such that the first and last points coincide with the revision cloud position point.

5. Call [IRevisionCloud::Finalize](#) to close the revision cloud path. Once the revision cloud path is closed, you can no longer add points to it.
6. Call [IRevisionCloud::SetPathPointAtIndex](#) to modify the position of an existing point on the revision cloud.

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IView::InsertRevisionCloud Method \(\)](#)

 Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMakeCustomSymbol2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IMakeCustomSymbol2 Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::MakeSketchBlockFromFile](#), [ISketchManager::MakeSketchBlockSelected](#), and [ISketchManager::MakeSketchBlockFromSketch](#).

 .NET Syntax

Visual Basic (Declaration)

Function IMakeCustomSymbol2() As CustomSymbol

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As CustomSymbol

value = instance.IMakeCustomSymbol2()
```

C#

```
CustomSymbol IMakeCustomSymbol2()
```

C++/CLI

```
CustomSymbol^ IMakeCustomSymbol2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IMakeCustomSymbol2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

INewGtol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : INewGtol Method (IDrawingDoc)

Creates a new Gtol.

.NET Syntax

Visual Basic (Declaration)

```
Function INewGtol() As Gtol
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As Gtol

value = instance.INewGtol()
```

C#

```
Gtol INewGtol()
```

C++/CLI

```
Gtol^ INewGtol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the newly created [Gtol](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::INewGtol](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::EditSelectedGtol Method](#)
[IDrawingDoc::NewGtol Method](#)

InsertAngularRunningDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertAngularRunningDim Method (IDrawingDoc)

Inserts an angular running dimension into this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertAngularRunningDim()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertAngularRunningDim()
```

C#

```
void InsertAngularRunningDim()
```

C++/CLI

```
void InsertAngularRunningDim();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertAngularRunningDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IModelDocExtension::AddAngularRunningDim Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

InsertBaseDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertBaseDim Method (IDrawingDoc)

Inserts the base model dimensions into this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertBaseDim()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertBaseDim()
```

C#

```
void InsertBaseDim()
```

C++/CLI

```
void InsertBaseDim();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertBaseDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AttachDimensions Method](#)
[IDrawingDoc::AutoDimension Method](#)
[IDrawingDoc::Dimensions Method](#)
[IDrawingDoc::DragModelDimension Method](#)
[IDrawingDoc::HideShowDimensions Method](#)
[IDimension Interface](#)
[IDisplayDimension Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertBlock Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertBlock Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::InsertSketchBlockInstance](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBlock( _  
    ByVal FileName As System.String, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Angle As System.Double, _  
    ByVal Scale As System.Double _  
    ) As BlockInstance
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim FileName As System.String  
Dim X As System.Double  
Dim Y As System.Double  
Dim Angle As System.Double  
Dim Scale As System.Double  
Dim value As BlockInstance
```

```
value = instance.InsertBlock(FileName, X, Y, Angle, Scale)
```

C#

```
BlockInstance InsertBlock(  
    System.string FileName,  
    System.double X,  
    System.double Y,  
    System.double Angle,  
    System.double Scale  
)
```

C++/CLI

```
BlockInstance^ InsertBlock(  
& System.String^ FileName,  
& System.double X,  
& System.double Y,  
& System.double Angle,  
& System.double Scale  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

X

Y

Angle

Scale

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertBlock](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertBreakHorizontal Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertBreakHorizontal Method (IDrawingDoc)

Inserts a horizontal break in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertBreakHorizontal()
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
instance.InsertBreakHorizontal()
```

C#

```
void InsertBreakHorizontal()
```

C++/CLI

```
void InsertBreakHorizontal();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertBreakHorizontal](#).

Remarks

To create the break view, use [IDrawingDoc::BreakView](#).

You can:

- Customize the break by dragging and repositioning the break lines.

- Set the font of the break lines using [IBreakLine::Style](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::UnInsertBreakVertical Method](#)
[IDrawingDoc::UnBreakView Method](#)
[IDrawingDoc::BreakView Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBreakVertical Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertBreakVertical Method (IDrawingDoc)

Inserts a vertical break in this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertBreakVertical()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertBreakVertical()
```

C#

```
void InsertBreakVertical()
```

C++/CLI

```
void InsertBreakVertical();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertBreakVertical](#).

Remarks

To create the break view, use [IDrawingDoc::BreakView](#).

You can:

- Customize the break by dragging and repositioning the break lines.
- Set the font of the break lines using [IBreakLine::Style](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::UnBreakView Method](#)
[IDrawingDoc::InsertBreakHorizontal Method](#)
[IDrawingDoc::BreakView Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertCenterLine Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertCenterLine Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertCenterLine2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCenterLine() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Boolean
```

```
value = instance.InsertCenterLine()
```

C#

```
System.bool InsertCenterLine()
```

C++/CLI

```
System.bool InsertCenterLine();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertCenterLine](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCenterLine2 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertCenterLine2 Method (IDrawingDoc)

Inserts a centerline on the selected entities.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCenterLine2() As Centerline
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As Centerline
```

```
value = instance.InsertCenterLine2()
```

C#

```
Centerline InsertCenterLine2()
```

C++/CLI

```
Centerline^ InsertCenterLine2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [ICenterLine](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertCenterLine2](#).

Example

[Get Centerlines in Drawing \(C#\)](#)
[Get Centerlines in Drawing \(VB.NET\)](#)
[Get Centerlines in Drawing \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCenterMark Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertCenterMark Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertCenterMark2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCenterMark( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Size As System.Double, _  
    ByVal ShowLines As System.Boolean, _  
    ByVal Angle As System.Double _  
) As CenterMark
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim UseDoc As System.Boolean  
Dim Size As System.Double  
Dim ShowLines As System.Boolean  
Dim Angle As System.Double  
Dim value As CenterMark  
  
value = instance.InsertCenterMark(UseDoc, Size, ShowLines, Angle)
```

C#

```
CenterMark InsertCenterMark(  
    System.bool UseDoc,  
    System.double Size,  
    System.bool ShowLines,  
    System.double Angle  
)
```

C++/CLI

```
CenterMark^ InsertCenterMark(  
& System.bool UseDoc,  
& System.double Size,  
& System.bool ShowLines,  
& System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

Size

ShowLines

Angle

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertCenterMark](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCenterMark2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertCenterMark2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertCenterMark3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCenterMark2( _  
    ByVal Style As System.Integer, _  
    ByVal Propagate As System.Boolean _  
) As CenterMark
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Style As System.Integer  
Dim Propagate As System.Boolean  
Dim value As CenterMark
```

```
value = instance.InsertCenterMark2(Style, Propagate)
```

C#

```
CenterMark InsertCenterMark2(  
    System.int Style,  
    System.bool Propagate  
)
```

C++/CLI

```
CenterMark^ InsertCenterMark2(  
& System.int Style,  
& System.bool Propagate  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Style as defined in [swCenterMarkStyle_e](#)

Propagate

True if the center mark should propagate throughout the pattern, false if not

Return Value

Pointer to the [centermark](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertCenterMark2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertCenterMark3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertCenterMark3 Method (IDrawingDoc)

Inserts a center mark in a drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCenterMark3( _  
    ByVal Style As System.Integer, _  
    ByVal Propagate As System.Boolean, _  
    ByVal Slot As System.Boolean _  
) As CenterMark
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Style As System.Integer  
Dim Propagate As System.Boolean  
Dim Slot As System.Boolean  
Dim value As CenterMark  
  
value = instance.InsertCenterMark3(Style, Propagate, Slot)
```

C#

```
CenterMark InsertCenterMark3(  
    System.int Style,  
    System.bool Propagate,  
    System.bool Slot  
)
```

C++/CLI

```
CenterMark^ InsertCenterMark3(  
&    System.int Style,  
&    System.bool Propagate,  
&    System.bool Slot  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Style as defined in [swCenterMarkStyle_e](#)

Propagate

True if the center mark should propagate throughout the pattern, false if not

Slot

True if this is slot-style center mark, false if not

Return Value

[Center mark](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertCenterMark3](#).

Remarks

Call [IView::AutoInsertCenterMarks](#) to automatically insert center marks in multiple drawing views.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertChainDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertChainDim Method (IDrawingDoc)

Obsolete. Superseded by [IModelDocExtension::InsertChainDimensions](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertChainDim()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertChainDim()
```

C#

```
void InsertChainDim()
```

C++/CLI

```
void InsertChainDim();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertChainDim](#).

Remarks

To insert a chain dimension into a drawing:

1. Call this method.
2. Call [IModelDocExtension::SelectById2](#) to select the first entity. This entity is used to create all dimensions in the chain.
3. Call [IModelDocExtension::SelectById2](#) to select the second entity to dimension with respect to the first.
4. Call [IModelDoc2::AddDimension2](#).
5. Call [IModelDocExtension::SelectById2](#) to select the next entity to dimension with respect to the first.
6. Call [IModelDoc2::AddDimension2](#) to add the dimension to the chain.
7. Repeat steps 5 and 6 to add more dimensions to the chain.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCircularNotePattern Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertCircularNotePattern Method (IDrawingDoc)

Inserts a circular note pattern using the selected [note](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCircularNotePattern( _
    ByVal ArcRadius As System.Double, _
    ByVal ArcAngle As System.Double, _
    ByVal PatternNum As System.Integer, _
    ByVal PatternSpacing As System.Double, _
    ByVal PatternRotate As System.Boolean, _
    ByVal DeleteInstances As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim ArcRadius As System.Double
Dim ArcAngle As System.Double
Dim PatternNum As System.Integer
Dim PatternSpacing As System.Double
Dim PatternRotate As System.Boolean
Dim DeleteInstances As System.String
Dim value As System.Boolean
```

```
value = instance.InsertCircularNotePattern(ArcRadius, ArcAngle, PatternNum, PatternSpacing,
PatternRotate, DeleteInstances)
```

C#

```
System.bool InsertCircularNotePattern(
    System.double ArcRadius,
    System.double ArcAngle,
    System.int PatternNum,
    System.double PatternSpacing,
    System.bool PatternRotate,
    System.string DeleteInstances
)
```

C++/CLI

```
System.bool InsertCircularNotePattern(
    & System.double ArcRadius,
    & System.double ArcAngle,
    & System.int PatternNum,
    & System.double PatternSpacing,
    & System.bool PatternRotate,
    & System.String^ DeleteInstances
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ArcRadius

Radius for the circular note pattern

ArcAngle

Angle relative to the notes being patterned

PatternNum

Total number of pattern instances, including the seed geometry

PatternSpacing

Spacing between pattern instances in radians

PatternRotate

True to rotate the pattern, false to not

DeleteInstances

Number of instances to delete, passed as a string formatted as "(a) (b) (c) "

Return Value

True if the circular note pattern is created, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertCircularNotePattern](#).

Example

[Insert Linear and Circular Note Patterns \(C#\)](#)
[Insert Linear and Circular Note Patterns \(VB.NET\)](#)
[Insert Linear and Circular Note Patterns \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::InsertLinearNotePattern Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCustomSymbol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertCustomSymbol Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::InsertSketchBlockInstance](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCustomSymbol( _  
    ByVal SymbolPath As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim SymbolPath As System.String  
  
instance.InsertCustomSymbol(SymbolPath)
```

C#

```
void InsertCustomSymbol(  
    System.string SymbolPath  
)
```

C++/CLI

```
void InsertCustomSymbol(  
& System.String^ SymbolPath  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SymbolPath

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertCustomSymbol](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCustomSymbol2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertCustomSymbol2 Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::InsertSketchBlockInstance](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCustomSymbol2( _  
    ByVal FileName As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim FileName As System.String  
Dim value As System.Object  
  
value = instance.InsertCustomSymbol2(FileName)
```

C#

```
System.object InsertCustomSymbol2(  
    System.string FileName  
)
```

C++/CLI

```
System.Object^ InsertCustomSymbol2(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertCustomSymbol2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertDatumTag Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertDatumTag Method (IDrawingDoc)

Obsolete. Superseded by [IModelDoc2::InsertDatumTag2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertDatumTag()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.InsertDatumTag()
```

C#

```
void InsertDatumTag()
```

C++/CLI

```
void InsertDatumTag();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertDatumTag](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertDowelSymbol Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertDowelSymbol Method (IDrawingDoc)

Inserts a dowel pin symbol on the currently selected edge or edges in this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertDowelSymbol() As System.Object
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IDrawingDoc  
Dim value As System.Object
```

```
value = instance.InsertDowelSymbol()
```

C#

```
System.Object InsertDowelSymbol()
```

C++/CLI

```
System.Object^ InsertDowelSymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Dowel pin symbol](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertDowelSymbol](#).

Example

[Flip Dowel Pin Symbol \(C#\)](#)
[Flip Dowel Pin Symbol \(VB.NET\)](#)
[Flip Dowel Pin Symbol \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::InsertDowelSymbol Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertGroup Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertGroup Method (IDrawingDoc)

Inserts the currently selected items into a group (or view).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertGroup()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertGroup()
```

C#

```
void InsertGroup()
```

C++/CLI

```
void InsertGroup();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertGroup](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertHorizontalOrdinate Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertHorizontalOrdinate Method (IDrawingDoc)

Inserts a horizontal ordinate dimension into this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertHorizontalOrdinate()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertHorizontalOrdinate()
```

C#

```
void InsertHorizontalOrdinate()
```

C++/CLI

```
void InsertHorizontalOrdinate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertHorizontalOrdinate](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::InsertVerticalOrdinate Method](#)
[IDrawingDoc::InsertOrdinate Method](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IDisplayDimension Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertLinearNotePattern Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertLinearNotePattern Method (IDrawingDoc)

Inserts a linear note pattern using the selected [note](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertLinearNotePattern( _  
    ByVal NumX As System.Integer, _  
    ByVal NumY As System.Integer, _  
    ByVal SpacingX As System.Double, _  
    ByVal SpacingY As System.Double, _  
    ByVal AngleX As System.Double, _  
    ByVal AngleY As System.Double, _  
    ByVal DeleteInstances As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim NumX As System.Integer  
Dim NumY As System.Integer  
Dim SpacingX As System.Double  
Dim SpacingY As System.Double  
Dim AngleX As System.Double  
Dim AngleY As System.Double  
Dim DeleteInstances As System.String  
Dim value As System.Boolean
```

```
value = instance.InsertLinearNotePattern(NumX, NumY, SpacingX, SpacingY, AngleX, AngleY,  
DeleteInstances)
```

C#

```
System.bool InsertLinearNotePattern(  
    System.int NumX,  
    System.int NumY,  
    System.double SpacingX,  
    System.double SpacingY,  
    System.double AngleX,  
    System.double AngleY,
```

```
        System.string DeleteInstances
    )
```

C++/CLI

```
System.bool InsertLinearNotePattern(
& System.int NumX,
& System.int NumY,
& System.double SpacingX,
& System.double SpacingY,
& System.double AngleX,
& System.double AngleY,
& System.String^ DeleteInstances
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumX

Total number of instances along the x axis, including the seed

NumY

Total number of instances along the y axis, including the seed

SpacingX

Spacing between pattern instances along the x axis

SpacingY

Spacing between pattern instances along the y axis

AngleX

Angle for direction 1 relative to the x axis

AngleY

Angle for direction 2 relative to the y axis

DeleteInstances

Number of instances to delete, passed as a string in the format "(a) (b) (c) "

Return Value

True if the linear note pattern is created, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertLinearNotePattern](#).

Example

[Insert Linear and Circular Note Patterns \(C#\)](#)

[Insert Linear and Circular Note Patterns \(VB.NET\)](#)

[Insert Linear and Circular Note Patterns \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::InsertCircularNotePattern Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertModelAnnotations Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertModelAnnotations Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertModelAnnotations3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertModelAnnotations( _
    ByVal Option As System.Integer, _
    ByVal AllTypes As System.Boolean, _
    ByVal Types As System.Integer, _
```

```
ByVal AllViews As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Option As System.Integer  
Dim AllTypes As System.Boolean  
Dim Types As System.Integer  
Dim AllViews As System.Boolean  
Dim value As System.Boolean  
  
value = instance.InsertModelAnnotations(Option, AllTypes, Types, AllViews)
```

C#

```
System.bool InsertModelAnnotations(  
    System.int Option,  
    System.bool AllTypes,  
    System.int Types,  
    System.bool AllViews  
)
```

C++/CLI

```
System.bool InsertModelAnnotations(  
& System.int Option,  
& System.bool AllTypes,  
& System.int Types,  
& System.bool AllViews  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Option

AllTypes

Types

AllViews

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertModelAnnotations](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertModelAnnotations2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertModelAnnotations2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertModelAnnotations3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertModelAnnotations2( _  
    ByVal Option As System.Integer, _  
    ByVal AllTypes As System.Boolean, _  
    ByVal Types As System.Integer, _  
    ByVal AllViews As System.Boolean, _  
    ByVal DuplicateDims As System.Boolean, _
```

```
ByVal HiddenFeatureDims As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Option As System.Integer  
Dim AllTypes As System.Boolean  
Dim Types As System.Integer  
Dim AllViews As System.Boolean  
Dim DuplicateDims As System.Boolean  
Dim HiddenFeatureDims As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.InsertModelAnnotations2(Option, AllTypes, Types, AllViews, DuplicateDims,  
HiddenFeatureDims)
```

C#

```
System.bool InsertModelAnnotations2(  
    System.int Option,  
    System.bool AllTypes,  
    System.int Types,  
    System.bool AllViews,  
    System.bool DuplicateDims,  
    System.bool HiddenFeatureDims  
)
```

C++/CLI

```
System.bool InsertModelAnnotations2(  
& System.int Option,  
& System.bool AllTypes,  
& System.int Types,  
& System.bool AllViews,  
& System.bool DuplicateDims,  
& System.bool HiddenFeatureDims  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Option

AllTypes

Types

AllViews

DuplicateDims

HiddenFeatureDims

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertModelAnnotations2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertModelAnnotations3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertModelAnnotations3 Method (IDrawingDoc)

Inserts model annotations into this drawing document's currently selected drawing view.

.NET Syntax

```
Function InsertModelAnnotations3( _
    ByVal Option As System.Integer, _
    ByVal Types As System.Integer, _
    ByVal AllViews As System.Boolean, _
    ByVal DuplicateDims As System.Boolean, _
    ByVal HiddenFeatureDims As System.Boolean, _
    ByVal UsePlacementInSketch As System.Boolean _
) As System.Object
```

```
Dim instance As IDrawingDoc
Dim Option As System.Integer
Dim Types As System.Integer
Dim AllViews As System.Boolean
Dim DuplicateDims As System.Boolean
Dim HiddenFeatureDims As System.Boolean
Dim UsePlacementInSketch As System.Boolean
Dim value As System.Object

value = instance.InsertModelAnnotations3(Option, Types, AllViews, DuplicateDims,
HiddenFeatureDims, UsePlacementInSketch)
```

```
System.object InsertModelAnnotations3(
    System.int Option,
    System.int Types,
    System.bool AllViews,
    System.bool DuplicateDims,
    System.bool HiddenFeatureDims,
    System.bool UsePlacementInSketch
)
```

```
System.Object^ InsertModelAnnotations3(
    & System.int Option,
    & System.int Types,
    & System.bool AllViews,
    & System.bool DuplicateDims,
    & System.bool HiddenFeatureDims,
    & System.bool UsePlacementInSketch
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Option

Source of dimensions as defined by [swImportModelItemsSource_e](#) (see **Remarks**)

Types

Bitwise OR of annotation types as defined in [swInsertAnnotation_e](#)

AllViews

True to insert the annotations in all views in the drawing, false to insert annotations only in the selected view

DuplicateDims

True to eliminate duplicate dimensions, false to allow duplicate dimensions

HiddenFeatureDims

True to insert dimensions from features that are hidden, false to not insert dimensions from features that are hidden

UsePlacementInSketch

True to insert dimensions as they were placed in sketch, false to not

Return Value

Array of inserted [IAnnotation](#) objects

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertModelAnnotations3](#).

Remarks

The Option argument was incorrectly documented in versions of the SOLIDWORKS API Help published before SOLIDWORKS 2008 SP3.

Incorrect	Correct
0 - All dimensions in the view	swImportModelItemsFromEntireModel = 0
1 - All dimensions of the currently selected component (for assembly drawings)	swImportModelItemsFromSelectedFeature = 1
2 - All dimensions of the currently selected feature	swImportModelItemsFromSelectedComponent = 2
All dimensions of the assembly	. swImportModelItemsFromAssemblyOnly = 3

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AddCenterMark Method](#)
[IDrawingDoc::AddChamferDim Method](#)
[IDrawingDoc::AddHoleCallout2 Method](#)
[IDrawingDoc::Dimensions Method](#)
[IDrawingDoc::INewGtol Method](#)
[IDrawingDoc::InsertBaseDim Method](#)
[IDrawingDoc::ICreateText2 Method](#)
[IDrawingDoc::CreateText2 Method](#)
[IDrawingDoc::CreateCompoundNote Method](#)
[IDrawingDoc::IAddHoleCallout2 Method](#)
[IDrawingDoc::ICreateCompoundNote Method](#)
[IDrawingDoc::InsertDatumTag Method](#)
[IDrawingDoc::InsertNewNote2 Method](#)
[IDrawingDoc::InsertRefDim Method](#)
[IDrawingDoc::InsertRevisionSymbol Method](#)
[IDrawingDoc::InsertSurfaceFinishSymbol Method](#)
[IDrawingDoc::InsertThreadCallout Method](#)
[IDrawingDoc::InsertWeldSymbol Method](#)
[IDrawingDoc::NewGtol Method](#)
[IDrawingDoc::NewNote Method](#)
[IDrawingDoc::AttachAnnotation Method \(\)](#)

 Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertModelAnnotations4 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertModelAnnotations4 Method (IDrawingDoc)

Inserts model annotations into this drawing document's currently selected drawing view.

 .NET Syntax

Visual Basic (Declaration)

```
Function InsertModelAnnotations4(_  
    ByVal Option As System.Integer, _  
    ByVal Types As System.Integer, _  
    ByVal AllViews As System.Boolean, _  
    ByVal DuplicateDims As System.Boolean, _  
    ByVal HiddenFeatureDims As System.Boolean, _  
    ByVal UsePlacementInSketch As System.Boolean, _  
    ByVal InsertAllAnnotations As System.Boolean, _  
    ByVal InsertAllReferenceGeometry As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim Option As System.Integer  
Dim Types As System.Integer  
Dim AllViews As System.Boolean  
Dim DuplicateDims As System.Boolean  
Dim HiddenFeatureDims As System.Boolean  
Dim UsePlacementInSketch As System.Boolean
```



```
Dim InsertAllAnnotations As System.Boolean
Dim InsertAllReferenceGeometry As System.Boolean
Dim value As System.Object
```

```
value = instance.InsertModelAnnotations4(Option, Types, AllViews, DuplicateDims,
HiddenFeatureDims, UsePlacementInSketch, InsertAllAnnotations, InsertAllReferenceGeometry)
```

C#

```
System.Object InsertModelAnnotations4(
    System.int Option,
    System.int Types,
    System.bool AllViews,
    System.bool DuplicateDims,
    System.bool HiddenFeatureDims,
    System.bool UsePlacementInSketch,
    System.bool InsertAllAnnotations,
    System.bool InsertAllReferenceGeometry
)
```

C++/CLI

```
System.Object^ InsertModelAnnotations4(
    & System.int Option,
    & System.int Types,
    & System.bool AllViews,
    & System.bool DuplicateDims,
    & System.bool HiddenFeatureDims,
    & System.bool UsePlacementInSketch,
    & System.bool InsertAllAnnotations,
    & System.bool InsertAllReferenceGeometry
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Option

Source of dimensions as defined by [swImportModelItemsSource_e](#)

Types

Annotation types to insert as defined in [swInsertAnnotation_e](#); only valid if InsertAllAnnotations and InsertAllReferenceGeometry are False

AllViews

True to insert the annotations in all views in the drawing, false to insert annotations only in the selected view

DuplicateDims

True to eliminate duplicate dimensions, false to allow duplicate dimensions

HiddenFeatureDims

True to insert dimensions from features that are hidden, false to not insert dimensions from features that are hidden

UsePlacementInSketch

True to insert dimensions as they were placed in sketch, false to not

InsertAllAnnotations

True to insert all annotations, false to insert only those specified in Types

InsertAllReferenceGeometry

True to insert all reference geometry, false to insert only those specified in Types

Return Value

Array of inserted [IAnnotation](#) objects

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertModelAnnotations4](#).

Example

[Insert Model Annotations \(VBA\)](#)
[Insert Model Annotations \(VB.NET\)](#)
[Insert Model Annotations \(C#\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::InsertModelDimensions Method \(\)](#)
[IDrawingDoc::InsertModelInPredefinedView Method \(\)](#)

Availability

InsertModelDimensions Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertModelDimensions Method (IDrawingDoc)

Inserts model dimensions into the selected drawing view according to the option specified.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertModelDimensions( _  
    ByVal Option As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Option As System.Integer  
  
instance.InsertModelDimensions(Option)
```

C#

```
void InsertModelDimensions(  
    System.int Option  
)
```

C++/CLI

```
void InsertModelDimensions(  
& System.int Option  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Option

- 0 - All dimensions in the view
- 1 - All dimensions of the currently selected component (for assembly drawings)
- 2 - All dimensions of the currently selected feature
- 3 - All dimensions of the assembly

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertModelDimensions](#).

Remarks

The **Insert Model Items** dialog is not displayed.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Dimensions Method](#)
[IDrawingDoc::DragModelDimension Method](#)
[IDrawingDoc::HideShowDimensions Method](#)
[IDrawingDoc::InsertModelAnnotations3 Method](#)
[IDrawingDoc::InsertRefDim Method](#)

InsertModelInPredefinedView Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertModelInPredefinedView Method (IDrawingDoc)

Inserts the model into the predefined drawing views in the active drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertModelInPredefinedView( _  
    ByVal ModelName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim value As System.Boolean  
  
value = instance.InsertModelInPredefinedView(ModelName)
```

C#

```
System.bool InsertModelInPredefinedView(  
    System.string ModelName  
)
```

C++/CLI

```
System.bool InsertModelInPredefinedView(  
& System.String^ ModelName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

Name of the model to insert into the predefined drawing views in the active drawing sheet

Return Value

True if the model is inserted, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertModelInPredefinedView](#).

Remarks

If you...	Then...
Preselect drawing views	This method inserts the model in those predefined drawing views.
Do not preselect any drawing views	This method inserts the model in all predefined views in the drawing.
Specify an empty filename	SOLIDWORKS prompts the user for the desired model's filename.
Specify a filename	SOLIDWORKS inserts that model into the predefined drawing views, without displaying any dialogs.

If the model is not already open, SOLIDWORKS attempts to open it hidden.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ActivateView Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::HideShowDrawingViews Method](#)
[IDrawingDoc::IGetFirstView Method](#)
[IDrawingDoc::SuppressView Method](#)
[IDrawingDoc::UnsuppressView Method](#)
[IDrawingDoc::ActiveDrawingView Property](#)
[IDrawingDoc::!ActiveDrawingView Property](#)
[IDrawingDoc::ReplaceViewModel Method\(\)](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertMultiJogLeader Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertMultiJogLeader Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertMultiJogLeader3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertMultiJogLeader()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertMultiJogLeader()
```

C#

```
void InsertMultiJogLeader()
```

C++/CLI

```
void InsertMultiJogLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertMultiJogLeader](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertMultiJogLeader2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertMultiJogLeader2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertMultiJogLeader3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertMultiJogLeader2( _  
    ByVal Points As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Points As System.Object  
Dim value As System.Object  
  
value = instance.InsertMultiJogLeader2(Points)
```

C#

```
System.object InsertMultiJogLeader2(  
    System.object Points  
)
```

C++/CLI

```
System.Object^ InsertMultiJogLeader2(  
& System.Object^ Points  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Points

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertMultiJogLeader2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertMultiJogLeader3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertMultiJogLeader3 Method (IDrawingDoc)

Inserts a multi-jog leader.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertMultiJogLeader3( _  
    ByVal Points As System.Object, _  
    ByVal StartPointArrowStyle As System.Integer, _  
    ByVal EndPointArrowStyle As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Points As System.Object  
Dim StartPointArrowStyle As System.Integer  
Dim EndPointArrowStyle As System.Integer  
Dim value As System.Object  
  
value = instance.InsertMultiJogLeader3(Points, StartPointArrowStyle, EndPointArrowStyle)
```

C#

```
System.object InsertMultiJogLeader3(  
    System.object Points,  
    System.int StartPointArrowStyle,  
    System.int EndPointArrowStyle  
)
```

C++/CLI

```
System.Object^ InsertMultiJogLeader3(  
& System.Object^ Points,  
& System.int StartPointArrowStyle,  
& System.int EndPointArrowStyle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Points

Array of [points](#) of size PointsCount

StartPointArrowStyle

Starting point's arrowhead style as defined in [swArrowStyle_e](#)

EndPointArrowStyle

Ending point's arrowhead style as defined in [swArrowStyle_e](#)

Return Value

Newly created multi-jog leader

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertMultiJogLeader3](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::InsertMultiJogLeader3 Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertNewNote Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertNewNote Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertNewNote2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertNewNote( _  
    ByVal Text As System.String, _  
    ByVal NoLeader As System.Boolean, _  
    ByVal BalloonNote As System.Boolean, _  
    ByVal BentLeader As System.Boolean, _  
    ByVal ArrowStyle As System.Short, _  
    ByVal LeaderSide As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Text As System.String  
Dim NoLeader As System.Boolean  
Dim BalloonNote As System.Boolean  
Dim BentLeader As System.Boolean  
Dim ArrowStyle As System.Short  
Dim LeaderSide As System.Short  
  
instance.InsertNewNote(Text, NoLeader, BalloonNote, BentLeader, ArrowStyle, LeaderSide)
```

C#

```
void InsertNewNote(  
    System.string Text,  
    System.bool NoLeader,  
    System.bool BalloonNote,  
    System.bool BentLeader,  
    System.short ArrowStyle,  
    System.short LeaderSide  
)
```

```

void InsertNewNote(
& System.String^ Text,
& System.bool NoLeader,
& System.bool BalloonNote,
& System.bool BentLeader,
& System.short ArrowStyle,
& System.short LeaderSide
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text

NoLeader

BalloonNote

BentLeader

ArrowStyle

LeaderSide

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertNewNote](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertNewNote2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertNewNote2 Method (IDrawingDoc)

Creates a new note in this drawing.

.NET Syntax

Visual Basic (Declaration)

```

Sub InsertNewNote2( _
    ByVal UpperText As System.String, _
    ByVal LowerText As System.String, _
    ByVal NoLeader As System.Boolean, _
    ByVal BentLeader As System.Boolean, _
    ByVal ArrowStyle As System.Short, _
    ByVal LeaderSide As System.Short, _
    ByVal Angle As System.Double, _
    ByVal BalloonStyle As System.Short, _
    ByVal BalloonFit As System.Short, _
    ByVal UpperNoteContent As System.Short, _
    ByVal LowerNoteContent As System.Short _
)

```

Visual Basic (Usage)

```

Dim instance As IDrawingDoc
Dim UpperText As System.String
Dim LowerText As System.String
Dim NoLeader As System.Boolean
Dim BentLeader As System.Boolean
Dim ArrowStyle As System.Short
Dim LeaderSide As System.Short
Dim Angle As System.Double

```



```
Dim BalloonStyle As System.Short
Dim BalloonFit As System.Short
Dim UpperNoteContent As System.Short
Dim LowerNoteContent As System.Short
```

```
instance.InsertNewNote2(UpperText, LowerText, NoLeader, BentLeader, ArrowStyle, LeaderSide, Angle,
BalloonStyle, BalloonFit, UpperNoteContent, LowerNoteContent)
```

C#

```
void InsertNewNote2(
    System.string UpperText,
    System.string LowerText,
    System.bool NoLeader,
    System.bool BentLeader,
    System.short ArrowStyle,
    System.short LeaderSide,
    System.double Angle,
    System.short BalloonStyle,
    System.short BalloonFit,
    System.short UpperNoteContent,
    System.short LowerNoteContent
)
```

C++/CLI

```
void InsertNewNote2(
    & System.String^ UpperText,
    & System.String^ LowerText,
    & System.bool NoLeader,
    & System.bool BentLeader,
    & System.short ArrowStyle,
    & System.short LeaderSide,
    & System.double Angle,
    & System.short BalloonStyle,
    & System.short BalloonFit,
    & System.short UpperNoteContent,
    & System.short LowerNoteContent
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UpperText

Upper text string to be put in the note

LowerText

Unused; pass an empty string

NoLeader

True does not add a leader line, false does

BentLeader

True adds a bent leader line, false does not

ArrowStyle

Arrowhead type as defined in [swArrowStyle_e](#)

LeaderSide

Leader line side as defined in [swLeaderSide_e](#)

Angle

Text angle

BalloonStyle

Balloon style type as defined in [swBalloonStyle_e](#)

BalloonFit

Balloon fit type as defined in [swBalloonFit_e](#)

UpperNoteContent

Unused; set to 0

LowerNoteContent

Unused; set to 0

Example

Contact SOLIDWORKS API Support to obtain **Insert Note Leader at Sketch Point (VBA, VB.NET, and C#)**.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateCompoundNote Method](#)
[IDrawingDoc::CreateText2 Method](#)
[IDrawingDoc::ICreateCompoundNote Method](#)
[IDrawingDoc::ICreateText2 Method](#)
[IDrawingDoc::NewNote Method](#)
[IDrawingDoc::InsertRevisionSymbol Method](#)
[IDrawingDoc::InsertCircularNotePattern Method](#)
[IDrawingDoc::InsertLinearNotePattern Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertOrdinate Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertOrdinate Method (IDrawingDoc)

Inserts an ordinate dimension into this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertOrdinate()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertOrdinate()
```

C#

```
void InsertOrdinate()
```

C++/CLI

```
void InsertOrdinate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertOrdinate](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IDrawingDoc::IAddOrdinateDimension2 Method](#)
[IDrawingDoc::IAlignOrdinate Method](#)
[IDrawingDoc::ICreateOrdinateDim4 Method](#)
[IDrawingDoc::IEditOrdinate Method](#)
[IDrawingDoc::InsertHorizontalOrdinate Method](#)
[IDrawingDoc::InsertVerticalOrdinate Method](#)
[IDisplayDimension Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRefDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertRefDim Method (IDrawingDoc)

Inserts reference dimensions in this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertRefDim()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertRefDim()
```

C#

```
void InsertRefDim()
```

C++/CLI

```
void InsertRefDim();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertRefDim](#).

Remarks

Reference dimensions do not drive the model.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDimension::IsReference Method](#)
[IDisplayDimension::IsReferenceDim Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRevisionCloud Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertRevisionCloud Method (IDrawingDoc)

Inserts a revision cloud annotation with the specified shape into a view or sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertRevisionCloud(  
    ByVal CloudShape As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim CloudShape As System.Integer  
Dim value As System.Object  
  
value = instance.InsertRevisionCloud(CloudShape)
```

C#

```
System.object InsertRevisionCloud(  
    System.int CloudShape  
)
```

C++/CLI

```
System.Object^ InsertRevisionCloud(
& System.int CloudShape
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CloudShape
Revision cloud annotation shape as defined in [swRevisionCloudShape_e](#)

Return Value

[IRevisionCloud](#)

 Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertRevisionCloud](#).

 Example

[Insert Revision Cloud into a Drawing \(VBA\)](#)
[Insert Revision Cloud into a Drawing \(VB.NET\)](#)
[Insert Revision Cloud into a Drawing \(C#\)](#)

 Remarks

After calling this method:

1. Call [IRevisionCloud::GetAnnotation](#) to get the annotation object for the revision cloud.
2. Call [IAnnotation::SetPosition](#) to set the revision cloud position point on the drawing. If you eliminate this step, the revision cloud is rendered starting at the drawing origin of x=0, y=0, z=0. Set the revision cloud position point as follows:

For revision cloud shape...	Set the revision cloud position point to...
Ellipse	The center of the revision cloud.
Rectangle	A corner of the revision cloud.
Polygon	One of the points on the revision cloud.
Freehand	One of the points on the revision cloud.

3. Call [IRevisionCloud::ArcRadius](#) to set the arc radius of the revision cloud.
4. Call [IRevisionCloud::SetPathPointAtIndex](#) with Index = -1 to create points on the revision cloud as follows:

For revision cloud shape...	Call IRevisionCloud::SetPathPointAtIndex...
Ellipse	Once, specifying the coordinates of a corner of the ellipse-inscribed rectangle.
Rectangle	Once, specifying the coordinates of a corner opposite the revision cloud position point.
Polygon	(Number of polygon sides + 1) times, such that the first and last points coincide with the revision cloud position point.
Freehand	Indefinite number of times, such that the first and last points coincide with the revision cloud position point.

5. Call [IRevisionCloud::Finalize](#) to close the revision cloud path. Once the revision cloud path is closed, you can no longer add points to it.
6. Call [IRevisionCloud::SetPathPointAtIndex](#) to modify the position of an existing point on the revision cloud.

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::InsertRevisionCloud Method \(\)](#)

 Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRevisionSymbol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertRevisionSymbol Method (IDrawingDoc)

Inserts a revision symbol note in this drawing.

 .NET Syntax

Visual Basic (Declaration)

```
Function InsertRevisionSymbol( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim value As Note  
  
value = instance.InsertRevisionSymbol(X, Y)
```

C#

```
Note InsertRevisionSymbol(  
    System.double X,  
    System.double Y  
)
```

C++/CLI

```
Note^ InsertRevisionSymbol(  
& System.double X,  
& System.double Y  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X coordinate at which to insert revision symbol note

Y
Y coordinate at which to insert revision symbol note

Return Value

Pointer to the newly created [INote](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertRevisionSymbol](#).

Remarks

To attach the revision symbol to entities in the drawing, the end-user must interactively preselect those entities. The revision symbol is then inserted with leaders to those selected entities. If there are no preselected entities, the symbol is free-standing.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateCompoundNote Method](#)
[IDrawingDoc::CreateText2 Method](#)
[IDrawingDoc::ICreateCompoundNote Method](#)
[IDrawingDoc::ICreateText2 Method](#)
[IDrawingDoc::InsertNewNote2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertSurfaceFinishSymbol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertSurfaceFinishSymbol Method (IDrawingDoc)

.NET Syntax

Visual Basic (Declaration)

```
Function InsertSurfaceFinishSymbol( _
    ByVal SymType As System.Integer, _
    ByVal LeaderType As System.Integer, _
    ByVal LocX As System.Double, _
    ByVal LocY As System.Double, _
    ByVal LocZ As System.Double, _
    ByVal LaySymbol As System.Integer, _
    ByVal ArrowType As System.Integer, _
    ByVal MachAllowance As System.String, _
    ByVal OtherVals As System.String, _
    ByVal ProdMethod As System.String, _
    ByVal SampleLen As System.String, _
    ByVal MaxRoughness As System.String, _
    ByVal MinRoughness As System.String, _
    ByVal RoughnessSpacing As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim SymType As System.Integer
Dim LeaderType As System.Integer
Dim LocX As System.Double
Dim LocY As System.Double
Dim LocZ As System.Double
Dim LaySymbol As System.Integer
Dim ArrowType As System.Integer
Dim MachAllowance As System.String
Dim OtherVals As System.String
Dim ProdMethod As System.String
Dim SampleLen As System.String
Dim MaxRoughness As System.String
Dim MinRoughness As System.String
Dim RoughnessSpacing As System.String
Dim value As System.Boolean
```

```
value = instance.InsertSurfaceFinishSymbol(SymType, LeaderType, LocX, LocY, LocZ, LaySymbol,
ArrowType, MachAllowance, OtherVals, ProdMethod, SampleLen, MaxRoughness, MinRoughness,
RoughnessSpacing)
```

C#

```
System.bool InsertSurfaceFinishSymbol(
    System.int SymType,
    System.int LeaderType,
    System.double LocX,
    System.double LocY,
    System.double LocZ,
    System.int LaySymbol,
    System.int ArrowType,
    System.string MachAllowance,
    System.string OtherVals,
    System.string ProdMethod,
    System.string SampleLen,
    System.string MaxRoughness,
    System.string MinRoughness,
    System.string RoughnessSpacing
)
```

C++/CLI

```
System.bool InsertSurfaceFinishSymbol(
    & System.int SymType,
```

```
& System.int LeaderType,  
& System.double LocX,  
& System.double LocY,  
& System.double LocZ,  
& System.int LaySymbol,  
& System.int ArrowType,  
& System.String^ MachAllowance,  
& System.String^ OtherVals,  
& System.String^ ProdMethod,  
& System.String^ SampleLen,  
& System.String^ MaxRoughness,  
& System.String^ MinRoughness,  
& System.String^ RoughnessSpacing  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SymType

LeaderType

LocX

LocY

LocZ

LaySymbol

ArrowType

MachAllowance

OtherVals

ProdMethod

SampleLen

MaxRoughness

MinRoughness

RoughnessSpacing

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertSurfaceFinishSymbol](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertTableAnnotation Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertTableAnnotation Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertTableAnnotation2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertTableAnnotation( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal AnchorType As System.Integer, _  
    ByVal Rows As System.Integer, _  
    ByVal Columns As System.Integer _  
) As TableAnnotation
```

Visual Basic (Usage)

 Copy Code

```

Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim AnchorType As System.Integer
Dim Rows As System.Integer
Dim Columns As System.Integer
Dim value As TableAnnotation

value = instance.InsertTableAnnotation(X, Y, AnchorType, Rows, Columns)

```

C#

```

TableAnnotation InsertTableAnnotation(
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.int Rows,
    System.int Columns
)

```

C++/CLI

```

TableAnnotation^ InsertTableAnnotation(
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.int Rows,
    & System.int Columns
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

AnchorType

Rows

Columns

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertTableAnnotation](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertTableAnnotation2 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertTableAnnotation2 Method (IDrawingDoc)

Inserts a table annotation in this drawing.

.NET Syntax

Visual Basic (Declaration)

```

Function InsertTableAnnotation2(
    ByVal UseAnchorPoint As System.Boolean, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal AnchorType As System.Integer, _
    ByVal TableTemplate As System.String, _

```

```

        ByVal Rows As System.Integer, _
        ByVal Columns As System.Integer _
    ) As TableAnnotation

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim UseAnchorPoint As System.Boolean
Dim X As System.Double
Dim Y As System.Double
Dim AnchorType As System.Integer
Dim TableTemplate As System.String
Dim Rows As System.Integer
Dim Columns As System.Integer
Dim value As TableAnnotation

```

```

value = instance.InsertTableAnnotation2(UseAnchorPoint, X, Y, AnchorType, TableTemplate, Rows, Columns)

```

C#

```

TableAnnotation InsertTableAnnotation2(
    System.bool UseAnchorPoint,
    System.double X,
    System.double Y,
    System.int AnchorType,
    System.string TableTemplate,
    System.int Rows,
    System.int Columns
)

```

C++/CLI

```

TableAnnotation^ InsertTableAnnotation2(
    & System.bool UseAnchorPoint,
    & System.double X,
    & System.double Y,
    & System.int AnchorType,
    & System.String^ TableTemplate,
    & System.int Rows,
    & System.int Columns
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAnchorPoint

True to anchor the table to the general table anchor point and ignore any coordinates specified for X and Y, or false to use the coordinates specified for X and Y

X

X coordinate to insert this table annotation

Y

Y coordinate to insert this table annotation

AnchorType

Type of anchor as defined in [swBOMConfigurationAnchorType_e](#) (see **Remarks**)

TableTemplate

Path and filename of the general table template to use (see **Remarks**)

Rows

Number of rows in the table annotation

Columns

Number of columns in the table annotation

Return Value

Pointer to the [ITableAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertTableAnnotation2](#).

Example

[Insert General Table \(VBA\)](#)
[Get General Table Feature \(C#\)](#)
[Get General Table Feature \(VB.NET\)](#)
[Get General Table Feature \(VBA\)](#)

 Remarks

If TableTemplate is...	Then..
A valid path and filename	AnchorType and Columns are ignored, and the information from the table template is used instead
Empty	General table is inserted based only on the other input arguments

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IModelDocExtension::InsertGeneralTableAnnotation Method \(\)](#)

 Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help [Send comments on this topic.](#)

InsertThreadCallout Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertThreadCallout Method (IDrawingDoc)

Inserts a thread callout into this drawing.

 Visual Basic (Declaration)

```
Sub InsertThreadCallout()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertThreadCallout()
```

C#

```
void InsertThreadCallout()
```

C++/CLI

```
void InsertThreadCallout();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertThreadCallout](#).

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[ICosmeticThreadFeatureData Interface](#)
[ICThread Interface](#)

 Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

InsertVerticalOrdinate Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertVerticalOrdinate Method (IDrawingDoc)

Inserts a vertical ordinate dimension in this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertVerticalOrdinate()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.InsertVerticalOrdinate()
```

C#

```
void InsertVerticalOrdinate()
```

C++/CLI

```
void InsertVerticalOrdinate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertVerticalOrdinate](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IDrawingDoc::AlignOrdinate Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::EditOrdinate Method](#)
[IDrawingDoc::InsertHorizontalOrdinate Method](#)
[IDrawingDoc::InsertOrdinate Method](#)
[IDisplayDimension Interface](#)

InsertWeldSymbol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : InsertWeldSymbol Method (IDrawingDoc)

Creates a weld symbol located at the last edge selection.

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertWeldSymbol( _  
    ByVal Dim1 As System.String, _  
    ByVal Symbol As System.String, _  
    ByVal Dim2 As System.String, _  
    ByVal Symmetric As System.Boolean, _  
    ByVal FieldWeld As System.Boolean, _  
    ByVal ShowOtherSide As System.Boolean, _  
    ByVal DashOnTop As System.Boolean, _  
    ByVal Peripheral As System.Boolean, _  
    ByVal HasProcess As System.Boolean, _  
    ByVal ProcessValue As System.String _  
)
```

Visual Basic (Usage)

```

Dim instance As IDrawingDoc
Dim Dim1 As System.String
Dim Symbol As System.String
Dim Dim2 As System.String
Dim Symmetric As System.Boolean
Dim FieldWeld As System.Boolean
Dim ShowOtherSide As System.Boolean
Dim DashOnTop As System.Boolean
Dim Peripheral As System.Boolean
Dim HasProcess As System.Boolean
Dim ProcessValue As System.String

```

```

instance.InsertWeldSymbol(Dim1, Symbol, Dim2, Symmetric, FieldWeld, ShowOtherSide, DashOnTop,
Peripheral, HasProcess, ProcessValue)

```

C#

```

void InsertWeldSymbol(
    System.string Dim1,
    System.string Symbol,
    System.string Dim2,
    System.bool Symmetric,
    System.bool FieldWeld,
    System.bool ShowOtherSide,
    System.bool DashOnTop,
    System.bool Peripheral,
    System.bool HasProcess,
    System.string ProcessValue
)

```

C++/CLI

```

void InsertWeldSymbol(
& System.String^ Dim1,
& System.String^ Symbol,
& System.String^ Dim2,
& System.bool Symmetric,
& System.bool FieldWeld,
& System.bool ShowOtherSide,
& System.bool DashOnTop,
& System.bool Peripheral,
& System.bool HasProcess,
& System.String^ ProcessValue
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Dim1

First text value to the left of the symbol

Symbol

Weld symbol name (see **Remarks**)

Dim2

Text value to the right of the symbol

Symmetric

True puts the symbol above and below the horizontal line

FieldWeld

True puts a flag for field welding

ShowOtherSide

True puts Dim1, Symbol, and Dim2 on the other side of the horizontal line

DashOnTop

True puts the dash line on top

Peripheral

True puts a peripheral symbol

HasProcess

True uses ProcessValue

ProcessValue

Process value if HasProcess is set to True

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::InsertWeldSymbol](#).

Remarks

Symbol specifies the weld symbol name. You can find a list of weld symbol names in **C:\ProgramData\SolidWorks\SolidWorks 20nn\lang\english\gtol.sym**.

The format of Symbol is **<Standard-Type>**. For example, a JIS seam is **<JWELD-JSM>**, and an ISO seam is **<WELD-JSM>**. You must include the right- and left-angle brackets and separate *Standard* and *Type* with a hyphen.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IWeldSymbol Interface](#)