

SOLIDWORKS API (.NET VBA C#) — Reference (143/337): ILocalCircularPatternFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ILocalCircularPatternFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ILocalCircularPatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILocalCircularPatternFeatureData Interface

Allows access to a circular component pattern feature in an assembly.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILocalCircularPatternFeatureData
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData
```

C#

```
public interface ILocalCircularPatternFeatureData
```

C++/CLI

```
public interface class ILocalCircularPatternFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData](#).

Example

'VBA

'-----

' Preconditions: Verify that the assembly exists.

,

' Postconditions:

' 1. Opens the assembly.

' 2. Selects an edge for the direction axis.

' 3. Selects a subassembly to pattern.

' 4. Creates **LocalCirPattern1**.

' 5. Examine the FeatureManager design tree and

' graphics area.

,

' NOTE: Because the assembly is used elsewhere, do not

' save changes.

'-----

Option Explicit

Dim swApp As SldWorks.SldWorks

Dim swModel As SldWorks.ModelDoc2

Dim swModelDocExt As SldWorks.ModelDocExtension

Dim swFeatureManager As SldWorks.FeatureManager

Dim swFeature As SldWorks.Feature

Dim swLocalCirPattFD As SldWorks.LocalCircularPatternFeatureData

Dim status As Boolean

Dim errors As Long

Dim warnings As Long

Dim fileName As String

Sub main()

Set swApp = Application.SldWorks

fileName = "C:\Users\Public\Documents\SOLIDWORKS\SOLIDWORKS 2019\samples\tutorial\api\distance linkage.sldasm"

Set swModel = swApp.OpenDoc6(fileName, swDocumentTypes_e.swDocASSEMBLY,

swOpenDocOptions_e.swOpenDocOptions_Silent, "", errors, warnings)

Set swModelDocExt = swModel.Extension

Set swFeatureManager = swModel.FeatureManager

status = swModelDocExt.SelectByID2("", "EDGE", 0.22639417933982, -0.194822643434378, 0.102086175644843, False, 2, Nothing, (

status = swModelDocExt.SelectByID2("mount base-1@distance linkage", "COMPONENT", 0, 0, 0, True, 1, Nothing, 0)

```
Set swLocalCirPattFD = swFeatureManager.CreateDefinition(swFmLocalCirPattern)
swLocalCirPattFD.TotalInstances = 3
swLocalCirPattFD.EqualSpacing = True
Set swFeature = swFeatureManager.CreateFeature(swLocalCirPattFD)
swModel.ClearSelection2 True
```

End Sub

Example

[Get and Set Seed Components \(C#\)](#)
[Get and Set Seed Components \(VB.NET\)](#)
[Get and Set Seed Components \(VBA\)](#)
[Create Local Circular Pattern \(C#\)](#)

Remarks

Read [Pattern Features and their Feature Data Objects](#).
Before calling IFeatureManager::CreateDefinition, you must pre-select the entities needed to create the local circular pattern feature.

If...	To select a component, use...
Using IModelDocExtension::SelectByID2 to select components, ordered selection of the components is required	• 1 to mark the components to pattern • 2 to mark the axis
Directly selecting a component or axis	ISelectData::Mark and Component2::Select3 • 1 to mark the components to pattern • 2 to mark the axis

You must call [IFeatureManager::CreateFeature](#) after initializing this feature data object in order to successfully create the local circular pattern feature.

Accessors

[IFeature::GetDefinition](#)
[IFeatureManager::CreateDefinition](#)

Access Diagram

[LocalCircularPatternFeatureData](#)

See Also

[ILocalCircularPatternFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICircularPatternFeatureData Interface](#)

ILocalCircularPatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ILocalCircularPatternFeatureData Interface

The following tables list the members exposed by [ILocalCircularPatternFeatureData](#).

Public Properties

Name	Description
 Axis	Gets or sets the circular axis for this circular component pattern feature.
 Direction2	Gets or sets whether to create a bidirectional circular component pattern feature.
 EqualSpacing	Gets or sets whether to equally space the pattern instances in Direction 1 in this circular component pattern feature.
 EqualSpacing2	Gets or sets whether the pattern instances in Direction 2 are equally spaced in this bidirectional circular component pattern feature.

 ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this local circular pattern feature.
 ReverseDirection	Gets or sets whether the direction axis for this local circular pattern is reversed for this circular component pattern feature.
 SeedComponentArray	Gets or sets an array of seed component features for this circular component pattern feature.
 SkippedItemArray	Gets or sets the skipped components in this circular component pattern feature.
 Spacing	Gets or sets the distance between pattern instances in Direction 1 for this circular component pattern feature.
 Spacing2	Gets or sets the spacing between pattern instances in Direction 2 of this bidirectional circular component pattern feature.
 Symmetric	Gets or sets whether Direction 2 properties are symmetric with those of Direction 1 of this bidirectional circular component pattern feature.
 SynchronizeFlexibleComponents	Gets or sets whether to synchronize the movement of flexible subassembly components in this circular component pattern feature.
 TotalInstances	Gets or sets the total number of instances in Direction 1 for this circular component pattern feature.
 TotalInstances2	Gets or sets the total number of pattern instances in Direction 2 of this bidirectional circular component pattern feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this circular component pattern feature.
 GetAxisType	Gets whether the circular axis is a reference axis, edge, or dimension for this circular component pattern feature.
 GetModifiedInstance	Gets the modified values for the specified pattern instance in this circular component pattern feature.
 GetModifiedInstances	Gets the instance numbers of all modified instances in this circular component pattern.
 GetSeedComponentCount	Gets the number of seed component features for this circular component pattern feature.
 GetSkippedItemCount	Gets the number of skipped items for this circular component pattern feature.
 GetTransform	Gets the transform for the specified instance of this circular component pattern feature.
 IAccessSelections	Obsolete. Superseded by ILocalCircularPatternFeatureData::IAccessSelections2
 IAccessSelections2	Gains access to the selections that define this circular component pattern feature.
 IGetSeedComponentArray	Gets an array of seed component features for this circular component pattern feature.
 IGetSkippedItemArray	Gets the list of skipped items in this circular component pattern feature.
 ISetSeedComponentArray	Sets an array of seed component features for this circular component pattern feature.
 ISetSkippedItemArray	Sets the list of skipped items for this circular component pattern feature.
 ModifyInstance	Modifies the specified pattern instance with the specified angle in this circular component pattern feature.
 ReleaseSelectionAccess	Releases access to the selections for this circular component pattern feature.

[Top](#)

See Also

[ILocalCircularPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICircularPatternFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILocalCircularPatternFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ILocalCircularPatternFeatureData Interface

For a list of all members of this type, see [ILocalCircularPatternFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this circular component pattern feature.
 GetAxisType	Gets whether the circular axis is a reference axis, edge, or dimension for this circular component pattern feature.
 GetModifiedInstance	Gets the modified values for the specified pattern instance in this circular component pattern feature.

		
	GetModifiedInstances	Gets the instance numbers of all modified instances in this circular component pattern.
	GetSeedComponentCount	Gets the number of seed component features for this circular component pattern feature.
	GetSkippedItemCount	Gets the number of skipped items for this circular component pattern feature.
	GetTransform	Gets the transform for the specified instance of this circular component pattern feature.
	IAccessSelections	Obsolete. Superseded by ILocalCircularPatternFeatureData.IAccessSelections2
	IAccessSelections2	Gains access to the selections that define this circular component pattern feature.
	IGetSeedComponentArray	Gets an array of seed component features for this circular component pattern feature.
	IGetSkippedItemArray	Gets the list of skipped items in this circular component pattern feature.
	ISetSeedComponentArray	Sets an array of seed component features for this circular component pattern feature.
	ISetSkippedItemArray	Sets the list of skipped items for this circular component pattern feature.
	ModifyInstance	Modifies the specified pattern instance with the specified angle in this circular component pattern feature.
	ReleaseSelectionAccess	Releases access to the selections for this circular component pattern feature.

[Top](#)

See Also

[ILocalCircularPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICircularPatternFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILocalCircularPatternFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILocalCircularPatternFeatureData Interface

For a list of all members of this type, see [ILocalCircularPatternFeatureData members](#).

Public Properties

Name	Description
 Axis	Gets or sets the circular axis for this circular component pattern feature.
 Direction2	Gets or sets whether to create a bidirectional circular component pattern feature.
 EqualSpacing	Gets or sets whether to equally space the pattern instances in Direction 1 in this circular component pattern feature.
 EqualSpacing2	Gets or sets whether the pattern instances in Direction 2 are equally spaced in this bidirectional circular component pattern feature.
 ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this local circular pattern feature.
 ReverseDirection	Gets or sets whether the direction axis for this local circular pattern is reversed for this circular component pattern feature.
 SeedComponentArray	Gets or sets an array of seed component features for this circular component pattern feature.
 SkippedItemArray	Gets or sets the skipped components in this circular component pattern feature.
 Spacing	Gets or sets the distance between pattern instances in Direction 1 for this circular component pattern feature.
 Spacing2	Gets or sets the spacing between pattern instances in Direction 2 of this bidirectional circular component pattern feature.
 Symmetric	Gets or sets whether Direction 2 properties are symmetric with those of Direction 1 of this bidirectional circular component pattern feature.
 SynchronizeFlexibleComponents	Gets or sets whether to synchronize the movement of flexible subassembly components in this circular component pattern feature.
 TotalInstances	Gets or sets the total number of instances in Direction 1 for this circular component pattern feature.
 TotalInstances2	Gets or sets the total number of pattern instances in Direction 2 of this bidirectional circular component pattern feature.

[Top](#)

See Also

[ILocalCircularPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICircularPatternFeatureData Interface](#)

AccessSelections Method (ILocalCircularPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : AccessSelections Method (ILocalCircularPatternFeatureData)

Gains access to the selections that define this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::AccessSelections](#).

Example

[Get and Set Seed Components \(C#\)](#)

[Get and Set Seed Components \(VB.NET\)](#)

[Get and Set Seed Components \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature

- [ILocalCircularPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

Axis Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : Axis Property (ILocalCircularPatternFeatureData)

Gets or sets the circular axis for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property Axis As System.Object

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Object
```

```
instance.Axis = value
```

```
value = instance.Axis
```

C#

```
System.object Axis {get; set;}
```

C++/CLI

```
property System.Object^ Axis {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Circular axis entity

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::Axis](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetAxisType Method](#)
[ILocalCircularPatternFeatureData::ReverseDirection Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

Direction2 Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : Direction2 Property (ILocalCircularPatternFeatureData)

Gets or sets whether to create a bidirectional circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property Direction2 As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Boolean
```

```
instance.Direction2 = value
```

```
value = instance.Direction2
```

C#

```
System.bool Direction2 {get; set;}
```

C++/CLI

```
property System.bool Direction2 {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if bidirectional, false if not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::Direction2](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData.EqualSpacing2 Property \(\)](#)
[ILocalCircularPatternFeatureData.Spacing2 Property \(\)](#)
[ILocalCircularPatternFeatureData.TotalInstances2 Property \(\)](#)
[ILocalCircularPatternFeatureData.Symmetric Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

EqualSpacing Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : EqualSpacing Property (ILocalCircularPatternFeatureData)

Gets or sets whether to equally space the pattern instances in Direction 1 in this circular component pattern feature.

.NET Syntax

Property EqualSpacing As System.Boolean



```
Dim instance As ILocalCircularPatternFeatureData
Dim value As System.Boolean

instance.EqualSpacing = value

value = instance.EqualSpacing
```

```
System.bool EqualSpacing {get; set;}
```

```
property System.bool EqualSpacing {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to equally space the pattern instances in Direction 1, false to not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::EqualSpacing](#).

Example

See the [ILocalCircularPatternFeatureData](#) example.

Remarks

If this property is set to true, then [ILocalCircularPatternFeatureData::Spacing](#) is automatically set to 360 degrees.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::EqualSpacing2 Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

EqualSpacing2 Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : EqualSpacing2 Property (ILocalCircularPatternFeatureData)

Gets or sets whether the pattern instances in Direction 2 are equally spaced in this bidirectional circular component pattern feature.

.NET Syntax

Property EqualSpacing2 As System.Boolean



```
Dim instance As ILocalCircularPatternFeatureData
Dim value As System.Boolean

instance.EqualSpacing2 = value

value = instance.EqualSpacing2
```

C#

```
System.bool EqualSpacing2 {get; set;}
```

C++/CLI

```
property System.bool EqualSpacing2 {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use equal spacing in Direction 2, false to not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData.EqualSpacing2](#).

Remarks

This property is only available when:

- [ILocalCircularPatternFeatureData.Direction2](#) is true, and
- [ILocalCircularPatternFeatureData.Symmetric](#) is false.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData.EqualSpacing Property\(\)](#)
[ILocalCircularPatternFeatureData.Spacing2 Property\(\)](#)
[ILocalCircularPatternFeatureData.TotalInstances2 Property\(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ForceUseSeedConfiguration Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : ForceUseSeedConfiguration Property (ILocalCircularPatternFeatureData)

Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this local circular pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ForceUseSeedConfiguration As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData
Dim value As System.Boolean

instance.ForceUseSeedConfiguration = value

value = instance.ForceUseSeedConfiguration
```

C#

```
System.bool ForceUseSeedConfiguration {get; set;}
```

C++/CLI

```
property System.bool ForceUseSeedConfiguration {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the seed component configuration for all pattern components, false to not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::ForceUseSeedConfiguration](#).

Remarks

If this property is set to true, the **Referenced configuration** section of the Component Properties dialog is disabled, and you cannot use [IComponent2::ReferencedConfiguration](#) to change the configuration of a pattern component.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAxisType Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : GetAxisType Method (ILocalCircularPatternFeatureData)

Gets whether the circular axis is a reference axis, edge, or dimension for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAxisType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetAxisType()
```

C#

```
System.int GetAxisType()
```

C++/CLI

```
System.int GetAxisType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Axis type used to create the circular pattern:

- 0 = reference axis
- 1 = edge

- 2 = dimension

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::GetAxisType](#).

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::Axis Property](#)
[ILocalCircularPatternFeatureData::ReverseDirection Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetModifiedInstance Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : GetModifiedInstance Method (ILocalCircularPatternFeatureData)

Gets the modified values for the specified pattern instance in this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetModifiedInstance( _
    ByVal Instance As System.Integer, _
    ByRef AngleFromSeed As System.Double, _
    ByRef OffsetFromNominal As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData
Dim Instance As System.Integer
Dim AngleFromSeed As System.Double
Dim OffsetFromNominal As System.Double

instance.GetModifiedInstance(Instance, AngleFromSeed, OffsetFromNominal)
```

C#

```
void GetModifiedInstance(
    System.int Instance,
    out System.double AngleFromSeed,
    out System.double OffsetFromNominal
)
```

C++/CLI

```
void GetModifiedInstance(
    & System.int Instance,
    & [Out] System.double AngleFromSeed,
    & [Out] System.double OffsetFromNominal
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Instance
 Pattern instance number (see **Remarks**)
AngleFromSeed
 Angle from the pattern seed
OffsetFromNominal
 Degree offset from the nominal position of Instance

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::GetModifiedInstance](#).

Remarks

To specify Instance, you can use [ILocalCircularPatternFeatureData::GetModifiedInstances](#) to learn which pattern instances are modified.

To calculate Instance:

Calculate:

For a bi-directional pattern:

$$I = n2 * (i - 1) + (j - 1)$$

For a uni-directional pattern:

$$I = i - 1$$

where:

- I = pattern instance number
- $n2$ = number of instances in Direction 2
- i = index for Direction 1
- j = index for Direction 2

In the pattern's PropertyManager, find $n2$ in the **Direction 2 > Spacing and Instances > Number of instances** field and find $[i,j]$ in the **Modified Instances** section.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetModifiedInstances Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : GetModifiedInstances Method (ILocalCircularPatternFeatureData)

Gets the instance numbers of all modified instances in this circular component pattern.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModifiedInstances() As System.Object
```

Visual Basic (Usage)

```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Object  
  
value = instance.GetModifiedInstances()
```

C#

```
System.object GetModifiedInstances()
```

C++/CLI

```
System.Object^ GetModifiedInstances();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of modified pattern instance numbers

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::GetModifiedInstances](#).

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetModifiedInstance Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSeedComponentCount Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : GetSeedComponentCount Method (ILocalCircularPatternFeatureData)

Gets the number of seed component features for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSeedComponentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetSeedComponentCount()
```

C#

```
System.int GetSeedComponentCount()
```

C++/CLI

```
System.int GetSeedComponentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of seed component features

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::GetSeedComponentCount](#).

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::IGetSeedComponentArray Method](#)
[ILocalCircularPatternFeatureData::ISetSeedComponentArray Method](#)
[ILocalCircularPatternFeatureData::SeedComponentArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSkippedItemCount Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : GetSkippedItemCount Method (ILocalCircularPatternFeatureData)

Gets the number of skipped items for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSkippedItemCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetSkippedItemCount()
```

C#

```
System.int GetSkippedItemCount()
```

C++/CLI

```
System.int GetSkippedItemCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of skipped items

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::GetSkippedItemCount](#).

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::IGetSkippedItemArray Method](#)
[ILocalCircularPatternFeatureData::ISetSkippedItemArray Method](#)
[ILocalCircularPatternFeatureData::SkippedItemArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTransform Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : GetTransform Method (ILocalCircularPatternFeatureData)

Gets the transform for the specified instance of this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTransform( _  
    ByVal Instance As System.Integer _  
) As MathTransform
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim Instance As System.Integer  
Dim value As MathTransform
```

```
value = instance.GetTransform(Instance)
```

C#

```
MathTransform GetTransform(  
    System.int Instance  
)
```

C++/CLI

```
MathTransform^ GetTransform(  
& System.int Instance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Instance

Index of one repeating element in this pattern (see **Remarks**)

Return Value

[Transform](#)

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::GetTransform](#).

Remarks

1 <= *Instance* <= [ILocalCircularPatternFeatureData::TotalInstances](#)

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : IAccessSelections Method (ILocalCircularPatternFeatureData)

Obsolete. Superseded by [ILocalCircularPatternFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::IAccessSelections](#).

See Also

[ILocalCircularPatternFeatureData Interface](#)

[ILocalCircularPatternFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections2 Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : IAccessSelections2 Method (ILocalCircularPatternFeatureData)

Gains access to the selections that define this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)
Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::IAccessSelections2](#).

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [ILocalCircularPatternFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::AccessSelections Method](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSeedComponentArray Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : IGetSeedComponentArray Method (ILocalCircularPatternFeatureData)

Gets an array of seed component features for this circular component pattern feature.

 .NET Syntax

Visual Basic (Declaration)

Function IGetSeedComponentArray() As System.Object

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Object  
  
value = instance.IGetSeedComponentArray()
```

C#

System.object IGetSeedComponentArray()

C++/CLI

System.Object^ IGetSeedComponentArray();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of seed component [features](#) (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

- See [In-process Methods](#) for details about this type of method.

Remarks

You can use [IFeature::GetSpecificFeature2](#) to get the [IComponent2](#) object for each seed component represented by a feature. See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetSeedComponentCount Method](#)
[ILocalCircularPatternFeatureData::ISetSeedComponentArray Method](#)
[ILocalCircularPatternFeatureData::SeedComponentArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSkippedItemArray Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : IGetSkippedItemArray Method (ILocalCircularPatternFeatureData)

Gets the list of skipped items in this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSkippedItemArray() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.IGetSkippedItemArray()
```

C#

```
System.int IGetSkippedItemArray()
```

C++/CLI

```
System.int IGetSkippedItemArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of long values that represent the skipped items in the pattern
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

This is a 0-based array, so if you skipped the third feature and the fifth feature in the pattern, then:

- Array[0] = 3
- Array[1] = 5

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetSkippedItemCount Method](#)
[ILocalCircularPatternFeatureData::ISetSkippedItemArray Method](#)
[ILocalCircularPatternFeatureData::SkippedItemArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetSeedComponentArray Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : ISetSeedComponentArray Method (ILocalCircularPatternFeatureData)

Sets an array of seed component features for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetSeedComponentArray( _  
    ByVal FeatCount As System.Integer, _  
    ByRef ArrayDataIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim FeatCount As System.Integer  
Dim ArrayDataIn As System.Object  
  
instance.ISetSeedComponentArray(FeatCount, ArrayDataIn)
```

C#

```
void ISetSeedComponentArray(  
    System.int FeatCount,  
    ref System.object ArrayDataIn  
)
```

C++/CLI

```
void ISetSeedComponentArray(  
& System.int FeatCount,  
& System.Object^% ArrayDataIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeatCount

Number of seed components

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of seed component [features](#) (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

- See [In-process Methods](#) for details about this type of method.

Remarks

You can pass a mixed array of [IComponent2](#) and [IFeature](#) objects representing components.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetSeedComponentCount Method](#)
[ILocalCircularPatternFeatureData::IGetSeedComponentArray Method](#)
[ILocalCircularPatternFeatureData::SeedComponentArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSkippedItemArray Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : ISetSkippedItemArray Method (ILocalCircularPatternFeatureData)

Sets the list of skipped items for this circular component pattern feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetSkippedItemArray( _  
    ByVal FeatCount As System.Integer, _  
    ByRef ArrayDataIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim FeatCount As System.Integer  
Dim ArrayDataIn As System.Integer  
  
instance.ISetSkippedItemArray(FeatCount, ArrayDataIn)
```

C#

```
void ISetSkippedItemArray(  
    System.int FeatCount,  
    ref System.int ArrayDataIn  
)
```

C++/CLI

```
void ISetSkippedItemArray(  
& System.int FeatCount,  
& System.int% ArrayDataIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeatCount

Number of skipped items

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of skipped items

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetSkippedItemCount Method](#)
[ILocalCircularPatternFeatureData::ISetSkippedItemArray Method](#)
[ILocalCircularPatternFeatureData::SkippedItemArray Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

ModifyInstance Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : ModifyInstance Method (ILocalCircularPatternFeatureData)

Modifies the specified pattern instance with the specified angle in this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ModifyInstance( _
    ByVal Instance As System.Integer, _
    ByVal AngleFromSeed As System.Double, _
    ByVal IsOffsetFromNominal As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData
Dim Instance As System.Integer
Dim AngleFromSeed As System.Double
Dim IsOffsetFromNominal As System.Boolean
Dim value As System.Boolean

value = instance.ModifyInstance(Instance, AngleFromSeed, IsOffsetFromNominal)
```

C#

```
System.bool ModifyInstance(
    System.int Instance,
    System.double AngleFromSeed,
    System.bool IsOffsetFromNominal
)
```

C++/CLI

```
System.bool ModifyInstance(
    & System.int Instance,
    & System.double AngleFromSeed,
    & System.bool IsOffsetFromNominal
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Instance

Pattern instance number (see **Remarks**)

AngleFromSeed

Angle from the pattern seed

IsOffsetFromNominal

True if AngleFromSeed is the offset from the nominal position of Instance, false if not

Return Value

True if the pattern instance is modified successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::ModifyInstance](#).

Remarks

To calculate Instance:

Calculate:

For a bi-directional pattern:

$$I = n2 * (i - 1) + (j - 1)$$

For a uni-directional pattern:

$I = i - 1$

where:

- I = pattern instance number
- $n2$ = number of instances in Direction 2
- i = index for Direction 1
- j = index for Direction 2

In the pattern's PropertyManager, find $n2$ in the **Direction 2 > Spacing and Instances > Number of instances** field and find $[i,j]$ in the **Modified Instances** section.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : ReleaseSelectionAccess Method (ILocalCircularPatternFeatureData)

Releases access to the selections for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::ReleaseSelectionAccess](#).

Remarks

[ILocalCircularPatternFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

ReverseDirection Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : ReverseDirection Property (ILocalCircularPatternFeatureData)

Gets or sets whether the direction axis for this local circular pattern is reversed for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the direction, false does not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::ReverseDirection](#).

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetAxisType Method](#)
[ILocalCircularPatternFeatureData::Axis Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SeedComponentArray Property (ILocalCircularPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : SeedComponentArray Property (ILocalCircularPatternFeatureData)

Gets or sets an array of seed component features for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property SeedComponentArray As System.Object

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData
Dim value As System.Object

instance.SeedComponentArray = value

value = instance.SeedComponentArray
```

C#

```
System.Object SeedComponentArray {get; set;}
```

C++/CLI

```
property System.Object^ SeedComponentArray {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of seed component [features](#)

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::SeedComponentArray](#).

Example

[Get and Set Seed Components \(VBA\)](#)
[Get and Set Seed Components \(VB.NET\)](#)
[Get and Set Seed Components \(C#\)](#)

Remarks

You can:

- get the [IComponent2](#) object for each seed component represented by a feature using [IFeature::GetSpecificFeature2](#).
- pass a mixed array of [IComponent2](#) and [IFeature](#) objects representing components.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetSeedComponentCount Method](#)
[ILocalCircularPatternFeatureData::IGetSeedComponentArray Method](#)
[ILocalCircularPatternFeatureData::ISetSeedComponentArray Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

SkippedItemArray Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : SkippedItemArray Property (ILocalCircularPatternFeatureData)

Gets or sets the skipped components in this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property SkippedItemArray As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData
Dim value As System.Object

instance.SkippedItemArray = value
value = instance.SkippedItemArray
```

C#

```
System.Object SkippedItemArray {get; set;}
```

C++/CLI

```
property System.Object^ SkippedItemArray {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of integers representing the skipped components

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::SkippedItemArray](#).

Remarks

This array is 0-based. If you skip the third and fifth components, then the array looks like ArrayOut[0]=3 and ArrayOut[1]=5.

To calculate the pattern instance numbers to skip:

Calculate:

For a bi-directional pattern:

$$I = n2 * (i - 1) + (j - 1)$$

For a uni-directional pattern:

$$I = i - 1$$

where:

- I = pattern instance number
- $n2$ = number of instances in Direction 2
- i = index for Direction 1
- j = index for Direction 2

In the pattern's PropertyManager, find $n2$ in the **Direction 2 > Spacing and Instances > Number of instances** field and find $[i,j]$ in the **Modified Instances** section.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::GetSkippedItemCount Method](#)
[ILocalCircularPatternFeatureData::IGetSkippedItemArray Method](#)
[ILocalCircularPatternFeatureData::ISetSkippedItemArray Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Spacing Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : Spacing Property (ILocalCircularPatternFeatureData)

Gets or sets the distance between pattern instances in Direction 1 for this circular component pattern feature.

.NET Syntax

```
Property Spacing As System.Double
```



```
Dim instance As ILocalCircularPatternFeatureData
Dim value As System.Double

instance.Spacing = value

value = instance.Spacing
```

```
System.double Spacing {get; set;}
```

```
property System.double Spacing {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance in radians between pattern instances in Direction 1

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::Spacing](#).

Remarks

This property is automatically set to 360 if [ILocalCircularPatternFeatureData::EqualSpacing](#) is set to true.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::TotalInstances Property](#)
[ILocalCircularPatternFeatureData::Spacing2 Property\(\)](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

Spacing2 Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : Spacing2 Property (ILocalCircularPatternFeatureData)

Gets or sets the spacing between pattern instances in Direction 2 of this bidirectional circular component pattern feature.

.NET Syntax

```
Property Spacing2 As System.Double
```



```
Dim instance As ILocalCircularPatternFeatureData
Dim value As System.Double

instance.Spacing2 = value
```

```
value = instance.Spacing2
```

C#

```
System.double Spacing2 {get; set;}
```

C++/CLI

```
property System.double Spacing2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance in radians between pattern instances in Direction 2

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::Spacing2](#).

Remarks

This property is only available when:

- [ILocalCircularPatternFeatureData::Direction2](#) is true, and
- [ILocalCircularPatternFeatureData::Symmetric](#) is false.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::Spacing Property \(\)](#)
[ILocalCircularPatternFeatureData::EqualSpacing2 Property \(\)](#)
[ILocalCircularPatternFeatureData::TotalInstances2 Property \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Symmetric Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : Symmetric Property (ILocalCircularPatternFeatureData)

Gets or sets whether Direction 2 properties are symmetric with those of Direction 1 of this bidirectional circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Symmetric As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Boolean
```

```
instance.Symmetric = value
```

```
value = instance.Symmetric
```

C#

```
System.bool Symmetric {get; set;}
```

C++/CLI

```
property System.bool Symmetric {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if Direction 2 properties mirror Direction 1 properties, false if not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::Symmetric](#).

Remarks

This property is only available when [ILocalCircularPatternFeatureData::Direction2](#) is true.

If this property is set to false, then you must specify:

- [ILocalCircularPatternFeatureData::EqualSpacing2](#)
- [ILocalCircularPatternFeatureData::TotalInstances2](#)

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SynchronizeFlexibleComponents Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : SynchronizeFlexibleComponents Property (ILocalCircularPatternFeatureData)

Gets or sets whether to synchronize the movement of flexible subassembly components in this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property SynchronizeFlexibleComponents As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData
Dim value As System.Boolean
```

```
instance.SynchronizeFlexibleComponents = value
```

```
value = instance.SynchronizeFlexibleComponents
```

C#

```
System.bool SynchronizeFlexibleComponents {get; set;}
```

C++/CLI

```
property System.bool SynchronizeFlexibleComponents {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to synchronize the movement of flexible subassembly components, false to not

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::SynchronizeFlexibleComponents](#).

Remarks

If this property is set to true, then when you move components in the seed flexible subassembly, components in the patterned instances move, and vice versa.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TotalInstances Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData Interface](#) : TotalInstances Property (ILocalCircularPatternFeatureData)

Gets or sets the total number of instances in Direction 1 for this circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property TotalInstances As System.Integer

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Integer
```

```
instance.TotalInstances = value
```

```
value = instance.TotalInstances
```

C#

```
System.int TotalInstances {get; set;}
```

C++/CLI

```
property System.int TotalInstances {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of instances in Direction 1

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::TotalInstances](#).

Example

See the [ILocalCircularPatternFeatureData](#) example.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::Spacing Property](#)
[ILocalCircularPatternFeatureData::TotalInstances2 Property\(\)](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

TotalInstances2 Property (ILocalCircularPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCircularPatternFeatureData interface](#) : TotalInstances2 Property (ILocalCircularPatternFeatureData)

Gets or sets the total number of pattern instances in Direction 2 of this bidirectional circular component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property TotalInstances2 As System.Integer

Visual Basic (Usage)



```
Dim instance As ILocalCircularPatternFeatureData  
Dim value As System.Integer
```

```
instance.TotalInstances2 = value
```

```
value = instance.TotalInstances2
```

C#

```
System.int TotalInstances2 {get; set;}
```

C++/CLI

```
property System.int TotalInstances2 {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Total number of pattern instances in Direction 2

Visual Basic for Applications (VBA) Syntax

See [LocalCircularPatternFeatureData::TotalInstances2](#).

Remarks

This property is only available when:

- [ILocalCircularPatternFeatureData::Direction2](#) is true, and
- [ILocalCircularPatternFeatureData::Symmetric](#) is false.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCircularPatternFeatureData Interface](#)
[ILocalCircularPatternFeatureData Members](#)
[ILocalCircularPatternFeatureData::TotalInstances Property\(\)](#)
[ILocalCircularPatternFeatureData::EqualSpacing2 Property\(\)](#)
[ILocalCircularPatternFeatureData::Spacing2 Property\(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0