

SOLIDWORKS API (.NET VBA C#) — Reference

(148/337): ILoop-ILoop2

SOLIDWORKS API Documentation (converted from CHM)

ILoop (Type)

ILoop Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILoop Interface

Obsolete. Superseded by [ILoop2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILoop
```

Visual Basic (Usage)

```
Dim instance As ILoop
```

C#

```
public interface ILoop
```

C++/CLI

```
public interface class ILoop
```

Visual Basic for Applications (VBA) Syntax

See [Loop](#).

See Also

[ILoop Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ILoop Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILoop Interface

The following tables list the members exposed by [ILoop](#).

Public Methods

Name	Description
EnumCoEdges	Obsolete. Superseded by ILoop2::EnumCoEdges .
EnumEdges	Obsolete. Superseded by ILoop2::EnumEdges .
GetEdgeCount	Obsolete. Superseded by ILoop2::GetEdgeCount .
GetEdges	Obsolete. Superseded by ILoop2::GetEdges .
GetFace	Obsolete. Superseded by ILoop2::GetFace .
GetFirstCoEdge	Obsolete. Superseded by ILoop2::GetFirstCoEdge .
GetNext	Obsolete. Superseded by ILoop2::GetNext .
IGetEdges	Obsolete. Superseded by ILoop2::IGetEdges .
IGetFace	Obsolete. Superseded by ILoop2::IGetFirstFace .
IGetFirstCoEdge	Obsolete. Superseded by ILoop2::IGetFirstCoEdge .
IGetNext	Obsolete. Superseded by ILoop2::IGetNext .
IRevolvePlanarLoop	Obsolete. Superseded by ILoop2::IRevolvePlanarLoop .

		
	IsOuter	Obsolete. Superseded by ILoop2::IsOuter .
	ISweepPlanarLoop	Obsolete. Superseded by ILoop2::ISweepPlanarLoop .
	RevolvePlanarLoop	Obsolete. Superseded by ILoop2::RevolvePlanarLoop .
	SweepPlanarLoop	Obsolete. Superseded by ILoop2::SweepPlanarLoop .

[Top](#)

 See Also

[ILoop Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILoop Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ILoop Interface

For a list of all members of this type, see [ILoop members](#).

 Public Methods

Name	Description
	EnumCoEdges Obsolete. Superseded by ILoop2::EnumCoEdges .
	EnumEdges Obsolete. Superseded by ILoop2::EnumEdges .
	GetEdgeCount Obsolete. Superseded by ILoop2::GetEdgeCount .
	GetEdges Obsolete. Superseded by ILoop2::GetEdges .
	GetFace Obsolete. Superseded by ILoop2::GetFace .
	GetFirstCoEdge Obsolete. Superseded by ILoop2::GetFirstCoEdge .
	GetNext Obsolete. Superseded by ILoop2::GetNext .
	IGetEdges Obsolete. Superseded by ILoop2::IGetEdges .
	IGetFace Obsolete. Superseded by ILoop2::IGetFirstFace .
	IGetFirstCoEdge Obsolete. Superseded by ILoop2::IGetFirstCoEdge .
	IGetNext Obsolete. Superseded by ILoop2::IGetNext .
	IRevolvePlanarLoop Obsolete. Superseded by ILoop2::IRevolvePlanarLoop .
	IsOuter Obsolete. Superseded by ILoop2::IsOuter .
	ISweepPlanarLoop Obsolete. Superseded by ILoop2::ISweepPlanarLoop .
	RevolvePlanarLoop Obsolete. Superseded by ILoop2::RevolvePlanarLoop .
	SweepPlanarLoop Obsolete. Superseded by ILoop2::SweepPlanarLoop .

[Top](#)

 See Also

[ILoop Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnumCoEdges Method (ILoop)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : EnumCoEdges Method (ILoop)

Obsolete. Superseded by [ILoop2::EnumCoEdges](#).

 .NET Syntax

Visual Basic (Declaration)

Function EnumCoEdges() As EnumCoEdges

Visual Basic (Usage)



```
Dim instance As ILoop
Dim value As EnumCoEdges

value = instance.EnumCoEdges()
```

C#

```
EnumCoEdges EnumCoEdges()
```

C++/CLI

```
EnumCoEdges^ EnumCoEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::EnumCoEdges](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EnumEdges Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : EnumEdges Method (ILoop)

Obsolete. Superseded by [ILoop2::EnumEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EnumEdges() As EnumEdges
```

Visual Basic (Usage)



```
Dim instance As ILoop
Dim value As EnumEdges

value = instance.EnumEdges()
```

C#

```
EnumEdges EnumEdges()
```

C++/CLI

```
EnumEdges^ EnumEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::EnumEdges](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

GetEdgeCount Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : GetEdgeCount Method (ILoop)

Obsolete. Superseded by [ILoop2::GetEdgeCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As System.Integer  
  
value = instance.GetEdgeCount()
```

C#

```
System.int GetEdgeCount()
```

C++/CLI

```
System.int GetEdgeCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::GetEdgeCount](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

GetEdges Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : GetEdges Method (ILoop)

Obsolete. Superseded by [ILoop2::GetEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdges() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As System.Object  
  
value = instance.GetEdges()
```

C#

```
System.object GetEdges()
```

C++/CLI

```
System.Object^ GetEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::GetEdges](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFace Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : GetFace Method (ILoop)

Obsolete. Superseded by [ILoop2::GetFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFace() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As System.Object  
  
value = instance.GetFace()
```

C#

```
System.object GetFace()
```

C++/CLI

```
System.Object^ GetFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::GetFace](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstCoEdge Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : GetFirstCoEdge Method (ILoop)

Obsolete. Superseded by [ILoop2::GetFirstCoEdge](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstCoEdge() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As System.Object  
  
value = instance.GetFirstCoEdge()
```

C#

```
System.Object GetFirstCoEdge()
```

C++/CLI

```
System.Object^ GetFirstCoEdge();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::GetFirstCoEdge](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : GetNext Method (ILoop)

Obsolete. Superseded by [ILoop2::GetNext](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.Object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::GetNext](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdges Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : IGetEdges Method (ILoop)

Obsolete. Superseded by [ILoop2::IGetEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdges() As System.IntPtr
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As System.IntPtr  
  
value = instance.IGetEdges()
```

C#

```
System.IntPtr IGetEdges()
```

C++/CLI

```
System.IntPtr IGetEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::IGetEdges](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFace Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : IGetFace Method (ILoop)

Obsolete. Superseded by [ILoop2::IGetFirstFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFace() As Face
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As Face  
  
value = instance.IGetFace()
```

C#

```
Face IGetFace()
```

C++/CLI

```
Face^ IGetFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::IGetFace](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFirstCoEdge Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : IGetFirstCoEdge Method (ILoop)

Obsolete. Superseded by [ILoop2::IGetFirstCoEdge](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstCoEdge() As CoEdge
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As CoEdge
```

```
value = instance.IGetFirstCoEdge()
```

C#

```
CoEdge IGetFirstCoEdge()
```

C++/CLI

```
CoEdge^ IGetFirstCoEdge();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::IGetFirstCoEdge](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : IGetNext Method (ILoop)

Obsolete. Superseded by [ILoop2::IGetNext](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As Loop
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim value As Loop
```

```
value = instance.IGetNext()
```

C#

Loop IGetNext()

C++/CLI

Loop^ IGetNext();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop.IGetNext](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRvolvePlanarLoop Method (ILoop)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [ILoop Interface](#) : IRvolvePlanarLoop Method (ILoop)

Obsolete. Superseded by [ILoop2.IRevolvePlanarLoop](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IRvolvePlanarLoop( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal Axisx As System.Double, _  
    ByVal Axisy As System.Double, _  
    ByVal Axisz As System.Double, _  
    ByVal RevAngle As System.Double, _  
    ByRef StopFacesOut As Face _  
) As Body
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Axisx As System.Double  
Dim Axisy As System.Double  
Dim Axisz As System.Double  
Dim RevAngle As System.Double  
Dim StopFacesOut As Face  
Dim value As Body
```

```
value = instance.IRvolvePlanarLoop(X, Y, Z, Axisx, Axisy, Axisz, RevAngle, StopFacesOut)
```

C#

```
Body IRvolvePlanarLoop(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.double Axisx,  
    System.double Axisy,  
    System.double Axisz,  
    System.double RevAngle,  
    ref Face StopFacesOut  
)
```

C++/CLI

```
Body^ IRevolvePlanarLoop(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.double Axisx,  
& System.double Axisy,  
& System.double Axisz,  
& System.double RevAngle,  
& Face^% StopFacesOut  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Axisx

Axisy

Axisz

RevAngle

StopFacesOut

Visual Basic for Applications (VBA) Syntax

See [Loop::IRevolvePlanarLoop](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsOuter Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : IsOuter Method (ILoop)

Obsolete. Superseded by [ILoop2::IsOuter](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsOuter() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ILoop  
Dim value As System.Boolean  
  
value = instance.IsOuter()
```

C#

```
System.bool IsOuter()
```

C++/CLI

```
System.bool IsOuter();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Loop::IsOuter](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISweepPlanarLoop Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : ISweepPlanarLoop Method (ILoop)

Obsolete. Superseded by [ILoop2::ISweepPlanarLoop](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISweepPlanarLoop( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal DraftAngle As System.Double, _  
    ByRef StopFacesOut As Face _  
) As Body
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim DraftAngle As System.Double  
Dim StopFacesOut As Face  
Dim value As Body  
  
value = instance.ISweepPlanarLoop(X, Y, Z, DraftAngle, StopFacesOut)
```

C#

```
Body ISweepPlanarLoop(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.double DraftAngle,  
    ref Face StopFacesOut  
)
```

C++/CLI

```
Body^ ISweepPlanarLoop(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.double DraftAngle,  
& Face^% StopFacesOut  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

DraftAngle

StopFacesOut

Visual Basic for Applications (VBA) Syntax

See [Loop::ISweepPlanarLoop](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

RevolvePlanarLoop Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : RevolvePlanarLoop Method (ILoop)

Obsolete. Superseded by [ILoop2::RevolvePlanarLoop](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RevolvePlanarLoop( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal Axisx As System.Double, _  
    ByVal Axisy As System.Double, _  
    ByVal Axisz As System.Double, _  
    ByVal RevAngle As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Axisx As System.Double  
Dim Axisy As System.Double  
Dim Axisz As System.Double  
Dim RevAngle As System.Double  
Dim value As System.Object  
  
value = instance.RevolvePlanarLoop(X, Y, Z, Axisx, Axisy, Axisz, RevAngle)
```

C#

```
System.object RevolvePlanarLoop(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.double Axisx,  
    System.double Axisy,  
    System.double Axisz,  
    System.double RevAngle  
)
```

C++/CLI

```
System.Object^ RevolvePlanarLoop(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.double Axisx,  
& System.double Axisy,  
& System.double Axisz,  
& System.double RevAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Axisx

Axisy

Axisz

RevAngle

Visual Basic for Applications (VBA) Syntax

See [Loop::RevolvePlanarLoop](#).

See Also

[ILoop Interface](#)
[ILoop Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SweepPlanarLoop Method (ILoop)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop Interface](#) : SweepPlanarLoop Method (ILoop)

Obsolete. Superseded by [ILoop2::SweepPlanarLoop](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SweepPlanarLoop( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal DraftAngle As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim DraftAngle As System.Double  
Dim value As System.Object  
  
value = instance.SweepPlanarLoop(X, Y, Z, DraftAngle)
```

C#

```
System.object SweepPlanarLoop(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.double DraftAngle  
)
```

C++/CLI

```
System.Object^ SweepPlanarLoop(  
& System.double X,  
& System.double Y,  
& System.double Z,
```

```
& System.double DraftAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

DraftAngle

Visual Basic for Applications (VBA) Syntax

See [Loop::SweepPlanarLoop](#).

See Also

[ILoop Interface](#)

[ILoop Members](#)

ILoop2 (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ILoop2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILoop2 Interface

Allows access to the owning face and to the list of edges and coedges contained in the loop.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILoop2
```

Visual Basic (Usage)



```
Dim instance As ILoop2
```

C#

```
public interface ILoop2
```

C++/CLI

```
public interface class ILoop2
```

Visual Basic for Applications (VBA) Syntax

See [Loop2](#).

Example

[Get Sketch Regions \(VBA\)](#)
[Get Sketch Regions \(VB.NET\)](#)
[Get Sketch Regions \(C#\)](#)

Accessors

[ICoEdge::GetLoop](#)

[ICoEdge::!GetLoop2](#)

[IEnumLoops2::Next](#)

[IFace2::GetFirstLoop](#) and [IFace2::!GetFirstLoop](#)

[ILoop2::GetNext](#) and [ILoop2::!GetNext](#)

[ISelectionMgr::GetSelectedObjectLoop2](#)

[ISimpleFilletFeatureData2::!GetLoops](#)

[ISimpleFilletFeatureData2::Loops](#)

[ISketchRegion::GetFirstLoop](#)

Access Diagram

[Loop2](#)

See Also

[ILoop2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEdge Interface](#)
[ICoEdge Interface](#)
[IFace2 Interface](#)
[DAssemblyDocEvents_FlipLoopNotifyEventHandler Delegate](#)
[DPartDocEvents_FlipLoopNotifyEventHandler Delegate](#)

ILoop2 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILoop2 Interface

The following tables list the members exposed by [ILoop2](#).

Public Methods

Name	Description
EnumCoEdges	Enumerates the coedges in a loop.
EnumEdges	Enumerates the edges in a face.
GetCoEdgeCount	Gets the number of coedges in this loop.
GetCoEdges	Gets the coedges in this loop.
GetEdgeCount	Gets the number of edges in the loop.
GetEdges	Gets all the edges in the loop.
GetFace	Gets the face containing this loop.
GetFirstCoEdge	Gets the first coedge of the loop.
GetNext	Gets the next loop on the face.
GetTrackingIDs	Gets the tracking IDs assigned to this loop .
GetTrackingIDsCount	Gets the number of tracking IDs on this loop.
GetVertexCount	Gets the number of vertices in the loop.
GetVertices	Gets the vertices in this loop.
IGetCoEdges	Gets the coedges in this loop.
IGetEdges	Gets all the edges in the loop.
IGetFace	Gets the face containing this loop.
IGetFirstCoEdge	Gets the first coedge in the loop.
IGetNext	Gets the next loop in the face.
IGetTrackingIDs	Gets the tracking IDs assigned to this loop .
IGetVertices	Gets the vertices in this loop.
IRevolvePlanarLoop	Creates a body by revolving a planar loop around an axis.
IsOuter	Indicates whether the loop is the outermost loop on the face.
IsSingular	Gets whether this loop is singular.
ISweepPlanarLoop	Creates a temporary body by sweeping a planar loop along a vector.
RemoveTrackingID	Removes a tracking ID assigned to this loop .
RevolvePlanarLoop	Creates a body by revolving a planar loop around an axis.
Select	Selects a loop in the graphics area.
SetTrackingID	Assigns a tracking ID to this loop.
SweepPlanarLoop	Creates a temporary body by sweeping a planar loop along a vector.

[Top](#)

See Also

[ILoop2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEdge Interface](#)
[ICoEdge Interface](#)
[IFace2 Interface](#)
[DAssemblyDocEvents_FlipLoopNotifyEventHandler Delegate](#)
[DPartDocEvents_FlipLoopNotifyEventHandler Delegate](#)

ILoop2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILoop2 Interface

For a list of all members of this type, see [ILoop2 members](#).

Public Methods

Name	Description
 EnumCoEdges	Enumerates the coedges in a loop.
 EnumEdges	Enumerates the edges in a face.
 GetCoEdgeCount	Gets the number of coedges in this loop.
 GetCoEdges	Gets the coedges in this loop.
 GetEdgeCount	Gets the number of edges in the loop.
 GetEdges	Gets all the edges in the loop.
 GetFace	Gets the face containing this loop.
 GetFirstCoEdge	Gets the first coedge of the loop.
 GetNext	Gets the next loop on the face.
 GetTrackingIDs	Gets the tracking IDs assigned to this loop .
 GetTrackingIDsCount	Gets the number of tracking IDs on this loop.
 GetVertexCount	Gets the number of vertices in the loop.
 GetVertices	Gets the vertices in this loop.
 IGetCoEdges	Gets the coedges in this loop.
 IGetEdges	Gets all the edges in the loop.
 IGetFace	Gets the face containing this loop.
 IGetFirstCoEdge	Gets the first coedge in the loop.
 IGetNext	Gets the next loop in the face.
 IGetTrackingIDs	Gets the tracking IDs assigned to this loop .
 IGetVertices	Gets the vertices in this loop.
 IRevolvePlanarLoop	Creates a body by revolving a planar loop around an axis.
 IsOuter	Indicates whether the loop is the outermost loop on the face.
 IsSingular	Gets whether this loop is singular.
 ISweepPlanarLoop	Creates a temporary body by sweeping a planar loop along a vector.
 RemoveTrackingID	Removes a tracking ID assigned to this loop .
 RevolvePlanarLoop	Creates a body by revolving a planar loop around an axis.
 Select	Selects a loop in the graphics area.
 SetTrackingID	Assigns a tracking ID to this loop.
 SweepPlanarLoop	Creates a temporary body by sweeping a planar loop along a vector.

[Top](#)

See Also

- [ILoop2 Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [IEdge Interface](#)
- [ICoEdge Interface](#)
- [IFace2 Interface](#)
- [DAssemblyDocEvents_FlipLoopNotifyEventHandler Delegate](#)
- [DPartDocEvents_FlipLoopNotifyEventHandler Delegate](#)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : EnumCoEdges Method (ILoop2)

Enumerates the coedges in a loop.

.NET Syntax

Visual Basic (Declaration)

```
Function EnumCoEdges() As EnumCoEdges
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As EnumCoEdges  
  
value = instance.EnumCoEdges()
```

C#

```
EnumCoEdges EnumCoEdges()
```

C++/CLI

```
EnumCoEdges^ EnumCoEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Coedges enumeration](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::EnumCoEdges](#).

Remarks

The [ICoEdge](#) objects are returned in a CW or CCW manner based on the direction of the [ILoop2](#).

The loop direction is determined as follows: if a loop is viewed along its direction, with the face normal pointing upwards, then the face that owns the loop is to the left. This means that inner loops are CW and outer loops are CCW. To determine if a loop is an outer loop, see [ILoop2::IsOuter](#)

The coedge direction always aligns with the direction of the ILoop2.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::IGetFirstCoEdge Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnumEdges Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : EnumEdges Method (ILoop2)

Enumerates the edges in a face.

.NET Syntax

Visual Basic (Declaration)

```
Function EnumEdges() As EnumEdges
```

```
Dim instance As ILoop2
Dim value As EnumEdges

value = instance.EnumEdges()
```

C#

```
EnumEdges EnumEdges()
```

C++/CLI

```
EnumEdges^ EnumEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Edges enumeration](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::EnumEdges](#).

Remarks

The edge objects are returned in a CW or CCW manner based on the direction of the [ILoop2](#).

The loop direction is determined as follows: if a loop is viewed along its direction, with the face normal pointing upwards, then the face that owns the loop is to the left. This means that inner loops are CW and outer loops are CCW. To determine if a loop is an outer loop, see [ILoop2::IsOuter](#)

Because an edge is shared by multiple loops, the edge direction may be opposite to the direction of the ILoop2. To check this, use [IEdge::EdgeInFaceSense](#).

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetEdgeCount Method](#)
[ILoop2::GetEdges Method](#)
[ILoop2::IGetEdges Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCoEdgeCount Method (ILoop2)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetCoEdgeCount Method (ILoop2)

Gets the number of coedges in this loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCoEdgeCount() As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ILoop2
Dim value As System.Integer

value = instance.GetCoEdgeCount()
```

C#

```
System.int GetCoEdgeCount()
```

C++/CLI

```
System.int GetCoEdgeCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of coedges in this loop

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetCoEdgeCount](#).

Example

[Get Sense for Each Coedge in a Loop \(VBA\)](#)

Remarks

Call this method before calling [ILoop2::IGetCoEdges](#) to determine the size of the array for that method.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetCoEdges Method](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::IGetFirstCoEdge Method](#)
[ICoEdge::GetNext Method](#)
[ICoEdge::IGetNext Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCoEdges Method (ILoop2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetCoEdges Method (ILoop2)

Gets the coedges in this loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCoEdges() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As System.Object  
  
value = instance.GetCoEdges()
```

C#

```
System.object GetCoEdges()
```

C++/CLI

```
System.Object^ GetCoEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [coedges](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetCoEdges](#).

Example

[Get Sense for Each Coedge in a Loop \(VBA\)](#)

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetCoEdgeCount Method](#)
[ILoop2::IGetCoEdges Method](#)
[ILoop2::IGetFirstCoEdge Method](#)
[ILoop2::IGetNextCoEdge Method](#)
[ICoEdge::GetNext Method](#)
[ICoEdge::IGetNext Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEdgeCount Method (ILoop2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetEdgeCount Method (ILoop2)

Gets the number of edges in the loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoop2
Dim value As System.Integer

value = instance.GetEdgeCount()
```

C#

```
System.int GetEdgeCount()
```

C++/CLI

```
System.int GetEdgeCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges in the loop

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetEdgeCount](#).

Example

[Get Circular Holes in Face \(C++\)](#)
[Get Loops \(VBA\)](#)
[Get Loops \(VB.NET\)](#)
[Get Loops \(C#\)](#)
[Select Edges of All Holes on Face \(C#\)](#)

[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetEdges Method](#)
[ILoop2::!GetEdges Method](#)
[ILoop2::EnumEdges Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdges Method (ILoop2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetEdges Method (ILoop2)

Gets all the edges in the loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdges() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As System.Object  
  
value = instance.GetEdges()
```

C#

```
System.object GetEdges()
```

C++/CLI

```
System.Object^ GetEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [edges](#) that make up the loop

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetEdges](#).

Example

[Find Outside Edges of Face \(VBA\)](#)
[Select Loop of Edges \(VBA\)](#)
[Fill Holes in Part \(C#\)](#)
[Fill Holes in Part \(VB.NET\)](#)
[Fill Holes in Part \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

Remarks

The [IEdge](#) objects are returned in a clockwise (CW) or counter-clockwise (CCW) manner based on the direction of the [ILoop2](#).

The loop direction is determined as follows: if a loop is viewed along its direction, with the face normal pointing upwards, then the face that owns the loop is to the left. This means that inner loops are CW and outer loops are CCW. To determine if a loop is an outer loop, use [ILoop2::IsOuter](#)

Because an edge is shared by multiple loops, the edge direction might be opposite to the direction of the ILoop2. To check this, use [IEdge::EdgeInFaceSense](#).

If the loop is a singular loop, use [ILoop2::GetVertices](#) to get its position (a single vertex). ILoop2::GetEdges returns an empty array if the loop is singular.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetEdgeCount Method](#)
[ILoop2::IGetEdges Method](#)
[ILoop2::EnumEdges Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFace Method (ILoop2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetFace Method (ILoop2)

Gets the face containing this loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFace() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As System.Object  
  
value = instance.GetFace()
```

C#

```
System.Object GetFace()
```

C++/CLI

```
System.Object^ GetFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Face](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetFace](#).

Example

[Determine Type of Face \(VBA\)](#)
[Select Loop of Edges \(VBA\)](#)
[Select Tangent Faces \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::IGetFace Method](#)

Availability

GetFirstCoEdge Method (ILoop2)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetFirstCoEdge Method (ILoop2)

Gets the first coedge of the loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstCoEdge() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop2
Dim value As System.Object

value = instance.GetFirstCoEdge()
```

C#

```
System.object GetFirstCoEdge()
```

C++/CLI

```
System.Object^ GetFirstCoEdge();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Return Value**First [coedge](#) in loop

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetFirstCoEdge](#).

Example

[Determine Type of Face \(VBA\)](#)
[Select Tangent Faces \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

Remarks

The [ICoEdge](#) objects are returned in a CW or CCW manner based on the direction of the [ILoop2](#).

The loop direction is determined as follows: if a loop is viewed along its direction, with the face normal pointing upwards, then the face that owns the loop is to the left. This means that inner loops are CW and outer loops are CCW. To determine if a loop is an outer loop, see [ILoop2::IsOuter](#)

The coedge direction always aligns with the direction of the loop.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::EnumCoEdges Method](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::GetCoEdgeCount Method](#)
[ILoop2::GetCoEdges Method](#)
[ILoop2::GetCoEdges Method](#)

Availability

GetNext Method (ILoop2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetNext Method (ILoop2)

Gets the next loop on the face.

.NET Syntax

Visual Basic (Declaration)

Function GetNext() As System.Object

Visual Basic (Usage)



```
Dim instance As ILoop2
Dim value As System.Object

value = instance.GetNext()
```

C#

System.object GetNext()

C++/CLI

System.Object^ GetNext();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [loop](#) in face, or null or nothing if it is the last loop

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetNext](#).

Example

[Determine Type of Face \(VBA\)](#)
[Find Outside Edges of Face \(VBA\)](#)
[Get Loops \(VBA\)](#)
[Select Tangent Faces \(VBA\)](#)
[Fill Holes in Part \(C#\)](#)
[Fill Holes in Part \(VB.NET\)](#)
[Fill Holes in Part \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrackingIDs Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetTrackingIDs Method (ILoop2)

Gets the [tracking IDs](#) assigned to this loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrackingIDs( _
    ByVal TrackingCookie As System.Integer, _
    ByRef TrackingIDs As System.Object _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoop2
Dim TrackingCookie As System.Integer
Dim TrackingIDs As System.Object
Dim value As System.Integer

value = instance.GetTrackingIDs(TrackingCookie, TrackingIDs)
```

C#

```
System.int GetTrackingIDs(
    System.int TrackingCookie,
    out System.object TrackingIDs
)
```

C++/CLI

```
System.int GetTrackingIDs(
    & System.int TrackingCookie,
    & [Out] System.Object^ TrackingIDs
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)
TrackingIDs
Array of tracking IDs on this loop

Return Value

Status as defined by [swTrackingIDError e](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetTrackingIDs](#).

Remarks

See [Tracking IDs](#) for more information.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetTrackingIDsCount Method](#)
[ILoop2::IGetTrackingIDs Method](#)
[ILoop2::RemoveTrackingID Method](#)
[ILoop2::SetTrackingID Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrackingIDsCount Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : [GetTrackingIDsCount Method \(ILoop2\)](#)

Gets the number of tracking IDs on this loop.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetTrackingIDsCount( _  
    ByVal TrackingCookie As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim TrackingCookie As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTrackingIDsCount(TrackingCookie)
```

C#

```
System.int GetTrackingIDsCount(  
    System.int TrackingCookie  
)
```

C++/CLI

```
System.int GetTrackingIDsCount(  
& System.int TrackingCookie  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)

Return Value

Number of tracking IDs on this loop

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetTrackingIDsCount](#).

Remarks

Call this method before calling [ILoop2::!GetTrackingIDs](#) to determine the size of the array for that method.

See [Tracking IDs](#) for more information.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetTrackingIDs Method](#)
[ILoop2::RemoveTrackingID Method](#)
[ILoop2::SetTrackingID Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetVertexCount Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetVertexCount Method (ILoop2)

Gets the number of vertices in the loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertexCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As System.Integer  
  
value = instance.GetVertexCount()
```

C#

```
System.int GetVertexCount()
```

C++/CLI

```
System.int GetVertexCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of vertices

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetVertexCount](#).

Example

See the [ILoop2](#) examples.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetVertices Method](#)
[ILoop2::IGetVertices Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVertices Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : GetVertices Method (ILoop2)

Gets the vertices in this loop.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertices() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As System.Object  
  
value = instance.GetVertices()
```

C#

```
System.object GetVertices()
```

C++/CLI

```
System.Object^ GetVertices();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [vertices](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::GetVertices](#).

Example

See the [ILoop2](#) examples.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetVertexCount Method](#)
[ILoop2::IGetVertices Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetCoEdges Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IGetCoEdges Method (ILoop2)

Gets the coedges in this loop.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCoEdges( _  
    ByVal NumCoEdges As System.Integer _  
) As CoEdge
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim NumCoEdges As System.Integer  
Dim value As CoEdge  
  
value = instance.IGetCoEdges(NumCoEdges)
```

C#

```
CoEdge IGetCoEdges(  
    System.int NumCoEdges  
)
```

C++/CLI

```
CoEdge^ IGetCoEdges(  
&    System.int NumCoEdges  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumCoEdges

Number of coedges in this loop

Return Value

- in-process, unmanaged C++: Pointer to an array of [coedges](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILoop2::GetCoEdgeCount](#) to get NumCoEdges.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetCoEdges Method](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::IGetFirstCoEdge Method](#)
[ICoEdge::GetNext Method](#)
[ICoEdge::IGetNext Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdges Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IGetEdges Method (ILoop2)

Gets all the edges in the loop.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdges() As Edge
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As Edge  
  
value = instance.IGetEdges()
```

C#

```
Edge IGetEdges()
```

C++/CLI

```
Edge^ IGetEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#) that make up the loop
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

The [IEdge](#) objects are returned in a CW or CCW manner based on the direction of the [ILoop2](#).

The loop direction is determined as follows: if a loop is viewed along its direction, with the face normal pointing upwards, then the face that owns the loop is to the left. This means that inner loops are CW and outer loops are CCW. To determine if a loop is an outer loop, use [ILoop2::IsOuter](#)

Because an edge is shared by multiple loops, the edge direction might be opposite to the direction of the ILoop2. To check this, use [IEdge::IEdgeInFaceSense2](#).

If the loop is a singular loop, use [ILoop2::!GetVertices](#) to get its position (a single vertex). ILoop2::GetEdges returns an empty array if the loop is singular.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetEdgeCount Method](#)
[ILoop2::GetEdges Method](#)
[ILoop2::EnumEdges Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFace Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IGetFace Method (ILoop2)

Gets the face containing this loop.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFace() As Face2
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As Face2  
  
value = instance.IGetFace()
```

C#

```
Face2 IGetFace()
```

C++/CLI

```
Face2^ IGetFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Face](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::!GetFace](#).

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstCoEdge Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IGetFirstCoEdge Method (ILoop2)

Gets the first coedge in the loop.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstCoEdge() As CoEdge
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As CoEdge  
  
value = instance.IGetFirstCoEdge()
```

C#

```
CoEdge IGetFirstCoEdge()
```

C++/CLI

```
CoEdge^ IGetFirstCoEdge();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [coedge](#) in loop

Visual Basic for Applications (VBA) Syntax

See [Loop2::IGetFirstCoEdge](#).

Remarks

The [ICoEdge](#) objects are returned in a CW or CCW manner based on the direction of the [ILoop2](#).

The loop direction is determined as follows: if a loop is viewed along its direction, with the face normal pointing upwards, then the face that owns the loop is to the left. This means that inner loops are CW and outer loops are CCW. To determine if a loop is an outer loop, see [ILoop2::IsOuter](#)

The coedge direction always aligns with the direction of the loop.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::EnumCoEdges Method](#)
[ILoop2::GetCoEdgeCount Method](#)
[ILoop2::GetCoEdges Method](#)
[ILoop2::GetFirstCoEdge Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IGetNext Method (ILoop2)

Gets the next loop in the face.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As Loop2
```

Visual Basic (Usage)



```
Dim instance As ILoop2
Dim value As Loop2

value = instance.IGetNext()
```

C#

```
Loop2 IGetNext()
```

C++/CLI

```
Loop2^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [loop](#) on the face, or NULL if it is the last loop

Visual Basic for Applications (VBA) Syntax

See [Loop2::IGetNext](#).

Remarks

See [ILoop2](#) accessors for a list of methods and properties that return loops.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetNext Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTrackingIDs Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IGetTrackingIDs Method (ILoop2)

Gets the [tracking IDs assigned to this loop](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTrackingIDs( _
    ByVal TrackingCookie As System.Integer, _
    ByVal Count As System.Integer, _
    ByRef TrackingIDs As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoop2
Dim TrackingCookie As System.Integer
Dim Count As System.Integer
Dim TrackingIDs As System.Integer
Dim value As System.Integer

value = instance.IGetTrackingIDs(TrackingCookie, Count, TrackingIDs)
```

C#

```
System.int IGetTrackingIDs(  
    System.int TrackingCookie,  
    System.int Count,  
    out System.int TrackingIDs  
)
```

C++/CLI

```
System.int IGetTrackingIDs(  
& System.int TrackingCookie,  
& System.int Count,  
& [Out] System.int TrackingIDs  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie

Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)

Count

Number of tracking IDs on this loop

TrackingIDs

- in-process, unmanaged C++: Pointer to an array of tracking IDs on this loop

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

Status as defined by [swTrackingIDError_e](#)

Remarks

Before calling this method, call [ILoop2::GetTrackingIDsCount](#) to get Count.

See [Tracking IDs](#) for more information.

See Also

[ILoop2 Interface](#)

[ILoop2 Members](#)

[ILoop2::GetTrackingIDs Method](#)

[ILoop2::RemoveTrackingID Method](#)

[ILoop2::SetTrackingID Method](#)

[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetVertices Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IGetVertices Method (ILoop2)

Gets the vertices in this loop.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetVertices( _  
    ByVal NumVertices As System.Integer, _  
    ByRef Vertices As Vertex _  
)
```

Visual Basic (Usage)

```
Dim instance As ILoop2  
Dim NumVertices As System.Integer  
Dim Vertices As Vertex
```



```
instance.IGetVertices(NumVertices, Vertices)
```

C#

```
void IGetVertices(  
    System.int NumVertices,  
    out Vertex Vertices  
)
```

C++/CLI

```
void IGetVertices(  
& System.int NumVertices,  
& [Out] Vertex^ Vertices  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumVertices

Number of vertices in this loop

Vertices

- in-process, unmanaged C++: Pointer to an array of [vertices](#) for this loop
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetVertexCount Method](#)
[ILoop2::GetVertices Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRevolvePlanarLoop Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IRevolvePlanarLoop Method (ILoop2)

Creates a body by revolving a planar loop around an axis.

.NET Syntax

Visual Basic (Declaration)

```
Function IRevolvePlanarLoop( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal Axisx As System.Double, _  
    ByVal Axisy As System.Double, _  
    ByVal Axisz As System.Double, _  
    ByVal RevAngle As System.Double, _  
    ByRef StopFacesOut As Face2 _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Axisx As System.Double  
Dim Axisy As System.Double  
Dim Axisz As System.Double  
Dim RevAngle As System.Double
```

```
Dim StopFacesOut As Face2
Dim value As Body2
```

```
value = instance.IRevolvePlanarLoop(X, Y, Z, Axisx, Axisy, Axisz, RevAngle, StopFacesOut)
```

C#

```
Body2 IRevolvePlanarLoop(
    System.double X,
    System.double Y,
    System.double Z,
    System.double Axisx,
    System.double Axisy,
    System.double Axisz,
    System.double RevAngle,
    out Face2 StopFacesOut
)
```

C++/CLI

```
Body2^ IRevolvePlanarLoop(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.double Axisx,
    & System.double Axisy,
    & System.double Axisz,
    & System.double RevAngle,
    & [Out] Face2^ StopFacesOut
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x coordinate of the axis point

Y
y coordinate of the axis point

Z
z coordinate of the axis point

Axisx
Direction along x

Axisy
Direction along y

Axisz
Direction along z

RevAngle
Angle of revolution in radians

StopFacesOut
Array of two stop [faces](#)

Return Value

New [body](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::IRevolvePlanarLoop](#).

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::RevolvePlanarLoop Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IsOuter Method (ILoop2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IsOuter Method (ILoop2)

Indicates whether the loop is the outermost loop on the face.

.NET Syntax

Visual Basic (Declaration)

```
Function IsOuter() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim value As System.Boolean  
  
value = instance.IsOuter()
```

C#

```
System.bool IsOuter()
```

C++/CLI

```
System.bool IsOuter();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the loop is the outermost loop, false if not

Visual Basic for Applications (VBA) Syntax

See [Loop2::IsOuter](#).

Example

[Determine Type of Face \(VBA\)](#)
[Find Outside Edges of Face \(VBA\)](#)
[Get Loops \(VBA\)](#)
[Fill Holes in Part \(C#\)](#)
[Fill Holes in Part \(VB.NET\)](#)
[Fill Holes in Part \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

Remarks

Some situations exist where no clear outer loop is defined. For example, the cylindrical face of an extruded circle has two loops that could be considered outer loops.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSingular Method (ILoop2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : IsSingular Method (ILoop2)

Gets whether this loop is singular.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IsSingular() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ILoop2
Dim value As System.Boolean

value = instance.IsSingular()
```

C#

```
System.bool IsSingular()
```

C++/CLI

```
System.bool IsSingular();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the loop is singular, false if not

Visual Basic for Applications (VBA) Syntax

See [Loop2::IsSingular](#).

Example

[Find Outside Edges of Face \(VBA\)](#)
[Get Loops \(VBA\)](#)

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISweepPlanarLoop Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : ISweepPlanarLoop Method (ILoop2)

Creates a temporary body by sweeping a planar loop along a vector.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ISweepPlanarLoop( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal DraftAngle As System.Double, _
    ByRef StopFacesOut As Face2 _
) As Body2
```

Visual Basic (Usage)



```

Dim instance As ILoop2
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim DraftAngle As System.Double
Dim StopFacesOut As Face2
Dim value As Body2

value = instance.ISweepPlanarLoop(X, Y, Z, DraftAngle, StopFacesOut)

```

C#

```

Body2 ISweepPlanarLoop(
    System.double X,
    System.double Y,
    System.double Z,
    System.double DraftAngle,
    ref Face2 StopFacesOut
)

```

C++/CLI

```

Body2^ ISweepPlanarLoop(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.double DraftAngle,
    & Face2^% StopFacesOut
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
 X component of the sweep vector
Y
 Y component of the sweep vector
Z
 Z component of the sweep vector
DraftAngle
 Draft angle for the faces on the side of this swept body
StopFacesOut
 Array of two stop [faces](#)

Return Value

New swept [body](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::ISweepPlanarLoop](#).

Remarks

This method requires simplification of the imported body.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::SweepPlanarLoop Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

RemoveTrackingID Method (ILoop2)

[See Also](#)



Removes a [tracking ID assigned to this loop](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTrackingID( _  
    ByVal TrackingCookie As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim TrackingCookie As System.Integer  
Dim value As System.Integer  
  
value = instance.RemoveTrackingID(TrackingCookie)
```

C#

```
System.int RemoveTrackingID(  
    System.int TrackingCookie  
)
```

C++/CLI

```
System.int RemoveTrackingID(  
& System.int TrackingCookie  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)

Return Value

Status as defined by [swTrackingIDError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::RemoveTrackingID](#).

Remarks

See [Tracking IDs](#) for more information.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetTrackingIDs Method](#)
[ILoop2::SetTrackingID Method](#)
[ILoop2::GetTrackingIDs Method](#)
[ILoop2::GetTrackingIDs Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic](#).

RevolvePlanarLoop Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : RevolvePlanarLoop Method (ILoop2)

Creates a body by revolving a planar loop around an axis.

Visual Basic (Declaration)

```
Function RevolvePlanarLoop( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal Axisx As System.Double, _
    ByVal Axisy As System.Double, _
    ByVal Axisz As System.Double, _
    ByVal RevAngle As System.Double _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop2
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim Axisx As System.Double
Dim Axisy As System.Double
Dim Axisz As System.Double
Dim RevAngle As System.Double
Dim value As System.Object

value = instance.RevolvePlanarLoop(X, Y, Z, Axisx, Axisy, Axisz, RevAngle)
```

C#

```
System.object RevolvePlanarLoop(
    System.double X,
    System.double Y,
    System.double Z,
    System.double Axisx,
    System.double Axisy,
    System.double Axisz,
    System.double RevAngle
)
```

C++/CLI

```
System.Object^ RevolvePlanarLoop(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.double Axisx,
    & System.double Axisy,
    & System.double Axisz,
    & System.double RevAngle
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x coordinate of the axis point

Y
y coordinate of the axis point

Z
z coordinate of the axis point

Axisx
Direction along x

Axisy
Direction along y

Axisz
Direction along z

RevAngle
Angle of revolution in radians

Return Value

Array containing new [body](#) (element 1) and two stop [faces](#) (elements 2 and 3)

Visual Basic for Applications (VBA) Syntax

See [Loop2::RevolvePlanarLoop](#).

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::ILoop2RevolvePlanarLoop Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : Select Method (ILoop2)

Selects a loop in the graphics area.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Edge As System.Object, _  
    ByVal Append As System.Boolean, _  
    ByVal SelectionData As System.Object _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim Edge As System.Object  
Dim Append As System.Boolean  
Dim SelectionData As System.Object  
Dim value As System.Boolean  
  
value = instance.Select(Edge, Append, SelectionData)
```

C#

```
System.bool Select(  
    System.object Edge,  
    System.bool Append,  
    System.object SelectionData  
)
```

C++/CLI

```
System.bool Select(  
& System.Object^ Edge,  
& System.bool Append,  
& System.Object^ SelectionData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Edge

[Edge](#) of the loop (see **Remarks**)

Append

True to append this selection to the selection list, false to replace the selection list with this selection

SelectionData

[ISelectData](#) object

Return Value

True if the loop is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [Loop2::Select](#).

Example

```
'VBA
'=====
' Preconditions:
' 1. Open a model with a triangular face.
' 2. Multi-select the triangular face and one of its edges.
' 3. Comment out one of the highlighted lines with swLoop.Select.
' 4. Run the macro.
' 5. Comment out the other highlighted line.
' 6. Run the macro again.
' Postconditions:
' 1. Inspect the Immediate window after each run.
' 2. Notice that a different loop is selected each time.
'=====

Option Explicit

Sub main()
    Dim swApp As SldWorks.SldWorks
    Set swApp = Application.SldWorks

    Dim swModel As ModelDoc2
    Set swModel = swApp.ActiveDoc
    If swModel Is Nothing Then Exit Sub

    Dim swSelMgr As SelectionMgr
    Set swSelMgr = swModel.SelectionManager

    Dim swFace As Face2
    Dim swEdge As Edge

    Dim iSel As Long
    For iSel = 1 To 2
        Select Case swSelMgr.GetSelectedObjectType3(iSel, -1)
            Case swSelFACES
                Set swFace = swSelMgr.GetSelectedObject6(iSel, -1)
            Case swSelEDGES
                Set swEdge = swSelMgr.GetSelectedObject6(iSel, -1)
        End Select
    Next

    If swFace Is Nothing Or swEdge Is Nothing Then Exit Sub

    Dim vLoops As Variant
    vLoops = swFace.GetLoops()

    Dim vLoop As Variant
    Dim swLoop As Loop2
    For Each vLoop In vLoops
        Set swLoop = vLoop
        Dim vEdges As Variant
        vEdges = swLoop.GetEdges()

        Dim loopUsesEdges As Boolean
        loopUsesEdges = False
        Dim vEdge As Variant
        For Each vEdge In vEdges
            If vEdge Is swEdge Then
                loopUsesEdges = True
            Exit For
        End If
    Next
```

```

Next
If loopUsesEdges Then
    ' Demonstrate that we have the right loop..
    Debug.Assert swLoop.GetFace Is swFace
    swModel.ClearSelection2 True
    For Each vEdge In vEdges
        Dim swLoopEdge As Entity
        Set swLoopEdge = vEdge
        swLoopEdge.Select4 True, Nothing
    Next
    Exit For
Else
    Set swLoop = Nothing
End If
Next

Stop ' Examine highlighted edges of this loop

If Not swLoop Is Nothing Then
    Debug.Print "Loop has " & swLoop.GetEdgeCount() & " edges."

    Dim bResult As Boolean

    ' Comment and uncomment out different lines after each run:

    bResult = swLoop.Select(swEdge, False, Nothing) 'Selects the adjacent loop
    bResult = swLoop.Select(Nothing, False, Nothing) 'Selects this loop

    Stop ' Examine highlighted edges of selected loop. This loop or its adjacent loop?

    Dim swSelLoop As Loop2
    Set swSelLoop = swSelMgr.GetSelectedObjectLoop2(1, -1)

    Debug.Print "Selected loop has " & swSelLoop.GetEdgeCount() & " edges."

    swModel.ClearSelection2 True
    vEdge = vbEmpty
    vEdge = swSelLoop.GetEdges()

    For Each vEdge In vEdges

        Set swLoopEdge = vEdge
        swLoopEdge.Select4 True, Nothing
    Next
    Debug.Print "Selected " & swSelMgr.GetSelectedObjectCount2(-1) & " edges in loop."
End If

End Sub

```

Remarks

This loop can share Edge with an adjacent loop, if it exists.

If Edge is:

- a valid edge on this loop, this method selects the adjacent loop.
- Nothing or null, this method selects this loop.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[DPartDocEvents_FlipLoopNotifyEventHandler Delegate](#)
[DAssemblyDocEvents_FileDropNotifyEventHandler Delegate](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTrackingID Method (ILoop2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : SetTrackingID Method (ILoop2)

Assigns a tracking ID to this loop.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetTrackingID( _  
    ByVal TrackingCookie As System.Integer, _  
    ByVal TrackingID As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim TrackingCookie As System.Integer  
Dim TrackingID As System.Integer  
Dim value As System.Integer  
  
value = instance.SetTrackingID(TrackingCookie, TrackingID)
```

C#

```
System.int SetTrackingID(  
    System.int TrackingCookie,  
    System.int TrackingID  
)
```

C++/CLI

```
System.int SetTrackingID(  
& System.int TrackingCookie,  
& System.int TrackingID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)
TrackingID
Application-defined value for the tracking ID

Value	Action
>0	Loop is tracked
0	Tracking of loop is stopped

Return Value

Status as defined by [swTrackingIDError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Loop2::SetTrackingID](#).

Remarks

You can assign tracking IDs to [bodies](#), [edges](#), [faces](#), loops, and [vertices](#) in parts and assemblies only; you cannot assign tracking IDs to these entities in drawings. See [Tracking IDs](#) for more information.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::GetTrackingIDs Method](#)
[ILoop2::RemoveTrackingID Method](#)
[ILoop2::GetTrackingIDsCount Method](#)
[ILoop2::IGetTrackingIDs Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SweepPlanarLoop Method (ILoop2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoop2 Interface](#) : SweepPlanarLoop Method (ILoop2)

Creates a temporary body by sweeping a planar loop along a vector.

.NET Syntax

Visual Basic (Declaration)

```
Function SweepPlanarLoop( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal DraftAngle As System.Double _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoop2  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim DraftAngle As System.Double  
Dim value As System.Object  
  
value = instance.SweepPlanarLoop(X, Y, Z, DraftAngle)
```

C#

```
System.Object SweepPlanarLoop(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.double DraftAngle  
)
```

C++/CLI

```
System.Object^ SweepPlanarLoop(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.double DraftAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

X component of the sweep vector

Y

Y component of the sweep vector

Z

Z component of the sweep vector

DraftAngle

Draft angle for the faces on the side of this swept body

Return Value

Array containing new swept [body](#) (element 1) and two stop [faces](#) (elements 2 and 3)

Visual Basic for Applications (VBA) Syntax

See [Loop2::SweepPlanarLoop](#).

Example

Remarks

This method requires simplification of the imported body.

See Also

[ILoop2 Interface](#)
[ILoop2 Members](#)
[ILoop2::ISweepPlanarLoop Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0