

SOLIDWORKS API (.NET, VBA, C#) — Reference

(163/337): IMirrorPatternFeatureData- IMirrorSolidFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IMirrorPatternFeatureData (Type)

IMirrorPatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorPatternFeatureData Interface

Allows access to a mirror pattern feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMirrorPatternFeatureData
```

Visual Basic (Usage)

```
Dim instance As IMirrorPatternFeatureData
```

C#

```
public interface IMirrorPatternFeatureData
```

C++/CLI

```
public interface class IMirrorPatternFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData](#).

Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

Remarks

For more information see the **Mirror Feature PropertyManager** topic in the SOLIDWORKS Design user-interface help.

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[MirrorPatternFeatureData](#)

See Also

[IMirrorPatternFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeature::InsertMirrorFeature Method](#)

IMirrorPatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorPatternFeatureData Interface

The following tables list the members exposed by [IMirrorPatternFeatureData](#).

Public Properties

Name	Description
 FeatureScope	Gets or sets whether to use scope for the mirror pattern feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the mirror pattern feature affects in a multibody part.
 GeometryPattern	Gets or sets whether to mirror only the geometry (faces and edges) of the feature for this mirror pattern feature.
 MirrorFaceArray	Gets or sets the faces to mirror.
 PatternFeatureArray	Gets or sets the seed features to use to create the mirror pattern.
 Plane	Gets or sets the plane about which to mirror the part.
 PropagateVisualProperty	Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all pattern instances.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define the mirror pattern feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the mirror pattern feature in a multibody part.
 GetMirrorFaceCount	Gets the number of mirrored faces.
 GetMirrorPlaneType	Gets whether the mirror plane is a face or a reference plane.
 GetPatternFeatureCount	Gets the number of seed features used to create this mirror pattern.
 IAccessSelections	Obsolete. Superseded by IMirrorPatternFeatureData.IAccessSelections2 .
 IAccessSelections2	Gains access to the selections that define the mirror pattern feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the mirror pattern feature affects in a multibody part.
 IGetMirrorFaceArray	Gets the mirrored faces.
 IGetPatternFeatureArray	Gets the seed features used to create the mirror pattern.
 ISetFeatureScopeBodies	Sets the solid bodies that the mirror pattern feature affects in a multibody part.
 ISetMirrorFaceArray	Sets the faces to mirror.
 ISetPatternFeatureArray	Sets the seed features to use to create this mirror pattern feature.
 ReleaseSelectionAccess	Releases access to the selections used to define the mirror pattern feature.

[Top](#)

See Also

[IMirrorPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeature::InsertMirrorFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMirrorPatternFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [IMirrorPatternFeatureData Interface](#)

For a list of all members of this type, see [IMirrorPatternFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define the mirror pattern feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the mirror pattern feature in a multibody part.
 GetMirrorFaceCount	Gets the number of mirrored faces.
 GetMirrorPlaneType	Gets whether the mirror plane is a face or a reference plane.
 GetPatternFeatureCount	Gets the number of seed features used to create this mirror pattern.
 IAccessSelections	Obsolete. Superseded by IMirrorPatternFeatureData.IAccessSelections2 .

	IAccessSelections2	Gains access to the selections that define the mirror pattern feature.
	IGetFeatureScopeBodies	Gets the solid bodies that the mirror pattern feature affects in a multibody part.
	IGetMirrorFaceArray	Gets the mirrored faces.
	IGetPatternFeatureArray	Gets the seed features used to create the mirror pattern.
	ISetFeatureScopeBodies	Sets the solid bodies that the mirror pattern feature affects in a multibody part.
	ISetMirrorFaceArray	Sets the faces to mirror.
	ISetPatternFeatureArray	Sets the seed features to use to create this mirror pattern feature.
	ReleaseSelectionAccess	Releases access to the selections used to define the mirror pattern feature.

[Top](#)

 See Also

[IMirrorPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeature::InsertMirrorFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMirrorPatternFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [IMirrorPatternFeatureData Interface](#)

For a list of all members of this type, see [IMirrorPatternFeatureData members](#).

 Public Properties

Name	Description
 FeatureScope	Gets or sets whether to use scope for the mirror pattern feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the mirror pattern feature affects in a multibody part.
 GeometryPattern	Gets or sets whether to mirror only the geometry (faces and edges) of the feature for this mirror pattern feature.
 MirrorFaceArray	Gets or sets the faces to mirror.
 PatternFeatureArray	Gets or sets the seed features to use to create the mirror pattern.
 Plane	Gets or sets the plane about which to mirror the part.
 PropagateVisualProperty	Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all pattern instances.

[Top](#)

 See Also

[IMirrorPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeature::InsertMirrorFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : [AccessSelections Method \(IMirrorPatternFeatureData\)](#)

Gains access to the selections that define the mirror pattern feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object,  
    ByVal Component As System.Object  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::AccessSelections](#).

Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <i>Nothing</i> or <i>null</i>
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IMirrorPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::IAccessSelections2 Method](#)

Availability

SOLIDWORKS 2000 SP2, Revision Number 8.2

Gets or sets whether to use scope for the mirror pattern feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureScope As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData
Dim value As System.Integer
```

```
instance.FeatureScope = value
```

```
value = instance.FeatureScope
```

C#

```
System.int FeatureScope {get; set;}
```

C++/CLI

```
property System.int FeatureScope {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Feature scope option as defined in [swFeatureScope_e](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::FeatureScope](#).

Remarks

This property is valid only if [IMirrorPatternFeatureData::GeometryPattern](#) is true.

If this property is set to either `swFeatureScope_SelectedBodiesWithAutoSelect` or `swFeatureScope_SelectedBodiesWithoutAutoSelect`, you can use [IMirrorPatternFeatureData::FeatureScopeBodies](#) to specify affected bodies.

For more information, see the **Mirror Feature PropertyManager** topic in the SOLIDWORKS Design user-interface help.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::GetFeatureScopeBodiesCount Method](#)
[IMirrorPatternFeatureData::GetFeatureScopeBodies Method](#)
[IMirrorPatternFeatureData::SetFeatureScopeBodies Method](#)
[IMirrorPatternFeatureData::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

FeatureScopeBodies Property (IMirrorPatternFeatureData)

[See Also](#)



Gets or sets the solid bodies that the mirror pattern feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScopeBodies As System.Object

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData
Dim value As System.Object
```

```
instance.FeatureScopeBodies = value
```

```
value = instance.FeatureScopeBodies
```

C#

```
System.Object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of solid [bodies](#) that the feature affects

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::FeatureScopeBodies](#).

Remarks

This property is valid only if:

- [IMirrorPatternFeatureData::GeometryPattern](#) is true, and
- [IMirrorPatternFeatureData::FeatureScope](#) is not [swFeatureScope_e.swFeatureScope_AllBodies](#).

You cannot edit this property to null or Nothing after the feature is created with feature scope bodies. If you try, [IFeature::ModifyDefinition](#) returns true but this property does not change.

For more information, see the **Mirror Feature PropertyManager** topic in the SOLIDWORKS Design user-interface help.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::GetFeatureScopeBodiesCount Method](#)
[IMirrorPatternFeatureData::IGetFeatureScopeBodies Method](#)
[IMirrorPatternFeatureData::ISetFeatureScopeBodies Method](#)
[IMirrorPatternFeatureData::FeatureScope Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GeometryPattern Property (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : GeometryPattern Property (IMirrorPatternFeatureData)

Gets or sets whether to mirror only the geometry (faces and edges) of the feature for this mirror pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property GeometryPattern As System.Boolean
```

```
Dim instance As IMirrorPatternFeatureData
Dim value As System.Boolean

instance.GeometryPattern = value
value = instance.GeometryPattern
```

C#

```
System.bool GeometryPattern {get; set;}
```

C++/CLI

```
property System.bool GeometryPattern {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to mirror only the geometry of the feature, false to solve the entire feature

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::GeometryPattern](#).

Example

[Get Mirror Pattern Feature Data \(VBA\)](#)
[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeatureScopeBodiesCount Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : GetFeatureScopeBodiesCount Method (IMirrorPatternFeatureData)

Gets the number of solid bodies affected by the mirror pattern feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureScopeBodiesCount() As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IMirrorPatternFeatureData
Dim value As System.Integer

value = instance.GetFeatureScopeBodiesCount()
```

C#

```
System.int GetFeatureScopeBodiesCount()
```

C++/CLI

```
System.int GetFeatureScopeBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of solid bodies affected

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::GetFeatureScopeBodiesCount](#).

Remarks

Call this method before calling [IMirrorPatternFeatureData::IGetFeatureScopeBodies](#) to get the size of the array for that method.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::IGetFeatureScopeBodies Method](#)
[IMirrorPatternFeatureData::FeatureScope Property](#)
[IMirrorPatternFeatureData::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMirrorFaceCount Method (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : GetMirrorFaceCount Method (IMirrorPatternFeatureData)

Gets the number of mirrored faces.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMirrorFaceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetMirrorFaceCount()
```

C#

```
System.int GetMirrorFaceCount()
```

C++/CLI

```
System.int GetMirrorFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of mirrored faces

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::GetMirrorFaceCount](#).

Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::IGetMirrorFaceArray Method](#)
[IMirrorPatternFeatureData::ISetMirrorFaceArray Method](#)
[IMirrorPatternFeatureData::MirrorFaceArray Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMirrorPlaneType Method (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : GetMirrorPlaneType Method (IMirrorPatternFeatureData)

Gets whether the mirror plane is a face or a reference plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMirrorPlaneType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetMirrorPlaneType()
```

C#

```
System.int GetMirrorPlaneType()
```

C++/CLI

```
System.int GetMirrorPlaneType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of object specified as the mirror plane:

- 0 = face
- 1 = plane

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::GetMirrorPlaneType](#).

Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::Plane Property](#)

Availability

SOLIDWORKS 2000 SP2, Revision Number 8.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPatternFeatureCount Method (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : GetPatternFeatureCount Method (IMirrorPatternFeatureData)

Gets the number of seed features used to create this mirror pattern.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatternFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetPatternFeatureCount()
```

C#

```
System.int GetPatternFeatureCount()
```

C++/CLI

```
System.int GetPatternFeatureCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of seed features used to create this mirror pattern

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::GetPatternFeatureCount](#).

Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::IGetPatternFeatureArray Method](#)
[IMirrorPatternFeatureData::ISetPatternFeatureArray Method](#)
[IMirrorPatternFeatureData::PatternFeatureArray Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : IAccessSelections Method (IMirrorPatternFeatureData)

Obsolete. Superseded by [IMirrorPatternFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::IAccessSelections](#).

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections2 Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : IAccessSelections2 Method (IMirrorPatternFeatureData)

Gains access to the selections that define the mirror pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefintion2](#) if you modified the feature
- [IMirrorPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMirrorPatternFeatureData Interface](#)

[IMirrorPatternFeatureData Members](#)

[IMirrorPatternFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2000 SP2, Revision Number 8.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFeatureScopeBodies Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : IGetFeatureScopeBodies Method (IMirrorPatternFeatureData)

Gets the solid bodies that the mirror pattern feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeatureScopeBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

```
Dim instance As IMirrorPatternFeatureData
Dim Count As System.Integer
Dim value As Body2

value = instance.IGetFeatureScopeBodies(Count)
```

C#

```
Body2 IGetFeatureScopeBodies(
    System.int Count
)
```

C++/CLI

```
Body2^ IGetFeatureScopeBodies(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

Return Value

- In-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IMirrorPatternFeatureData::GetFeatureScopeBodiesCount](#) to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::ISetFeatureScopeBodies Method](#)
[IMirrorPatternFeatureData::FeatureScope Property](#)
[IMirrorPatternFeatureData::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetMirrorFaceArray Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : IGetMirrorFaceArray Method (IMirrorPatternFeatureData)

Gets the mirrored faces.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMirrorFaceArray() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IMirrorPatternFeatureData
Dim value As System.Object

value = instance.IGetMirrorFaceArray()
```

C#

```
System.Object IGetMirrorFaceArray()
```

C++/CLI

```
System.Object^ IGetMirrorFaceArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of mirrored [faces](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::MirrorFaceArray Property](#)
[IMirrorPatternFeatureData::ISetMirrorFaceArray Method](#)
[IMirrorPatternFeatureData::GetMirrorFaceCount Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetPatternFeatureArray Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : IGetPatternFeatureArray Method (IMirrorPatternFeatureData)

Gets the seed features used to create the mirror pattern.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternFeatureArray() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim value As System.Object  
  
value = instance.IGetPatternFeatureArray()
```

C#

```
System.Object IGetPatternFeatureArray()
```

C++/CLI

```
System.Object^ IGetPatternFeatureArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [features](#) used to create this mirror pattern feature
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::PatternFeatureArray Property](#)
[IMirrorPatternFeatureData::ISetPatternFeatureArray Method](#)
[IMirrorPatternFeatureData::GetPatternFeatureCount Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetFeatureScopeBodies Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : ISetFeatureScopeBodies Method (IMirrorPatternFeatureData)

Sets the solid bodies that the mirror pattern feature affects in a multibody part.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetFeatureScopeBodies( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArr As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim Count As System.Integer  
Dim BodyArr As Body2  
  
instance.ISetFeatureScopeBodies(Count, BodyArr)
```

C#

```
void ISetFeatureScopeBodies(  
    System.int Count,  
    ref Body2 BodyArr  
)
```

C++/CLI

```
void ISetFeatureScopeBodies(  
& System.int Count,  
& Body2^% BodyArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

BodyArr

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::!GetFeatureScopeBodies Method](#)
[IMirrorPatternFeatureData::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetMirrorFaceArray Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : ISetMirrorFaceArray Method (IMirrorPatternFeatureData)

Sets the faces to mirror.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetMirrorFaceArray( _  
    ByVal FaceCount As System.Integer, _  
    ByRef ArrayDataIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim FaceCount As System.Integer  
Dim ArrayDataIn As System.Object  
  
instance.ISetMirrorFaceArray(FaceCount, ArrayDataIn)
```

C#

```
void ISetMirrorFaceArray(  
    System.int FaceCount,  
    ref System.object ArrayDataIn  
)
```

C++/CLI

```
void ISetMirrorFaceArray(  
& System.int FaceCount,  
& System.Object^% ArrayDataIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of faces

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size FaceCount

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::GetMirrorFaceCount Method](#)
[IMirrorPatternFeatureData::!GetMirrorFaceArray Method](#)
[IMirrorPatternFeatureData::MirrorFaceArray Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetPatternFeatureArray Method (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : ISetPatternFeatureArray Method (IMirrorPatternFeatureData)

Sets the seed features to use to create this mirror pattern feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetPatternFeatureArray( _  
    ByVal FeatCount As System.Integer, _  
    ByRef ArrayDataIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim FeatCount As System.Integer  
Dim ArrayDataIn As System.Object  
  
instance.ISetPatternFeatureArray(FeatCount, ArrayDataIn)
```

C#

```
void ISetPatternFeatureArray(  
    System.int FeatCount,  
    ref System.object ArrayDataIn  
)
```

C++/CLI

```
void ISetPatternFeatureArray(  
& System.int FeatCount,  
& System.Object^% ArrayDataIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeatCount

Number of seed features to use to create this mirror pattern

ArrayDataIn

- In-process, unmanaged C++: Pointer to an array of [features](#) that to use as seed feature to create the mirror pattern

VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMirrorPatternFeatureData Interface](#)

[IMirrorPatternFeatureData Members](#)

[IMirrorPatternFeatureData::GetPatternFeatureCount Method](#)

[IMirrorPatternFeatureData::ISetPatternFeatureArray Method](#)

[IMirrorPatternFeatureData::PatternFeatureArray Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MirrorFaceArray Property (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : MirrorFaceArray Property (IMirrorPatternFeatureData)

Gets or sets the faces to mirror.

.NET Syntax

Visual Basic (Declaration)

Property MirrorFaceArray As System.Object

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData  
Dim value As System.Object
```

```
instance.MirrorFaceArray = value
```

```
value = instance.MirrorFaceArray
```

C#

```
System.object MirrorFaceArray {get; set;}
```

C++/CLI

```
property System.Object^ MirrorFaceArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::MirrorFaceArray](#).

Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::GetMirrorFaceCount Method](#)
[IMirrorPatternFeatureData::IGetMirrorFaceArray Method](#)
[IMirrorPatternFeatureData::ISetMirrorFaceArray Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternFeatureArray Property (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : PatternFeatureArray Property (IMirrorPatternFeatureData)

Gets or sets the seed features to use to create the mirror pattern.

 .NET Syntax

Visual Basic (Declaration)

Property PatternFeatureArray As System.Object

Visual Basic (Usage) [Copy Code](#)

```
Dim instance As IMirrorPatternFeatureData
Dim value As System.Object

instance.PatternFeatureArray = value

value = instance.PatternFeatureArray
```

C#

```
System.object PatternFeatureArray {get; set;}
```

C++/CLI

```
property System.Object^ PatternFeatureArray {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Seed [features](#) on which this pattern feature is based

 Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::PatternFeatureArray](#).

 Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

 Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

 See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::GetPatternFeatureCount Method](#)
[IMirrorPatternFeatureData::!GetPatternFeatureArray Method](#)
[IMirrorPatternFeatureData::!SetPatternFeatureArray Method](#)

 Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Plane Property (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : Plane Property (IMirrorPatternFeatureData)

Gets or sets the plane about which to mirror the part.

 .NET Syntax

```
Property Plane As System.Object
```



```
Dim instance As IMirrorPatternFeatureData
Dim value As System.Object

instance.Plane = value

value = instance.Plane
```

```
System.Object Plane {get; set;}
```

```
property System.Object^ Plane {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Plane about which to mirror the part

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::Plane](#).

Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)
[IMirrorPatternFeatureData::GetMirrorPlaneType Method](#)

Availability

SOLIDWORKS 2000 SP2, Revision Number 8.2

PropagateVisualProperty Property (IMirrorPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : PropagateVisualProperty Property (IMirrorPatternFeatureData)

Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all pattern instances.

.NET Syntax

```
Property PropagateVisualProperty As System.Boolean
```



```
Dim instance As IMirrorPatternFeatureData
Dim value As System.Boolean

instance.PropagateVisualProperty = value
value = instance.PropagateVisualProperty
```

C#

```
System.bool PropagateVisualProperty {get; set;}
```

C++/CLI

```
property System.bool PropagateVisualProperty {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate visual properties, false to not

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::PropagateVisualProperty](#).

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IMirrorPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorPatternFeatureData Interface](#) : ReleaseSelectionAccess Method (IMirrorPatternFeatureData)

Releases access to the selections used to define the mirror pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IMirrorPatternFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MirrorPatternFeatureData::ReleaseSelectionAccess](#).

Example

[Get Mirror Pattern Feature Data \(C#\)](#)
[Get Mirror Pattern Feature Data \(VB.NET\)](#)
[Get Mirror Pattern Feature Data \(VBA\)](#)

Remarks

[IMirrorPatternFeatureData::AccessSelections](#) and [IMirrorPatternFeatureData::IAccessSelections2](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IMirrorPatternFeatureData Interface](#)
[IMirrorPatternFeatureData Members](#)

Availability

SOLIDWORKS 2000 SP2, Revision Number 8.2

IMirrorSolidFeatureData (Type)

IMirrorSolidFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorSolidFeatureData Interface

Allows access to a mirror solid feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMirrorSolidFeatureData
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData
```

C#

```
public interface IMirrorSolidFeatureData
```

C++/CLI

```
public interface class IMirrorSolidFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData](#).

Example

[Get Mirror Solid Feature Data \(C#\)](#)
[Get Mirror Solid Feature Data \(VB.NET\)](#)
[Get Mirror Solid Feature Data \(VBA\)](#)

Remarks

After creating the mirror solid feature, use [IMirrorSolidFeatureData::StructureSystemToPatternArray](#) to change the structure system to mirror. For more information see the **Mirror Feature PropertyManager** topic in the SOLIDWORKS Design user-interface help.

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[MirrorSolidFeatureData](#)

See Also

[IMirrorSolidFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMirrorFeature Method](#)
[IMirrorPartFeatureData Interface](#)

IMirrorSolidFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorSolidFeatureData Interface

The following tables list the members exposed by [IMirrorSolidFeatureData](#).

Public Properties

Name	Description
 Face	Gets or sets the end-condition face for this mirror solid feature.
 KnitSurface	Gets or sets whether to knit the surface for this mirror solid feature.
 Merge	Gets or sets the merge results option for the mirrored solid feature in a multibody part.
 PatternBodyArray	Gets or sets the seed bodies to pattern for this mirror solid feature.
 PropagateVisualProperty	Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all mirrored instances.
 StructureSystemToPatternArray	Gets or sets the structure systems to pattern in this mirror solid feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define the mirror solid feature.
 GetPatternBodyCount	Gets the number of seed bodies in this mirror solid feature.
 GetTransform	Gets the transform for this mirror-solid feature.
 IAccessSelections	Obsolete. Superseded by IMirrorSolidFeatureData.IAccessSelections2 .
 IAccessSelections2	Gains access to the selections that define the mirror solid feature.
 IGetPatternBodyArray	Gets the seed bodies for this mirror solid feature.
 ISetPatternBodyArray	Sets the seed bodies for this mirror solid feature.
 ReleaseSelectionAccess	Releases access to the selections used to define the mirror solid feature.

[Top](#)

See Also

[IMirrorSolidFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertMirrorFeature Method](#)
[IMirrorPartFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMirrorSolidFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMirrorSolidFeatureData Interface

For a list of all members of this type, see [IMirrorSolidFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define the mirror solid feature.
 GetPatternBodyCount	Gets the number of seed bodies in this mirror solid feature.
 GetTransform	Gets the transform for this mirror-solid feature.
 IAccessSelections	Obsolete. Superseded by IMirrorSolidFeatureData.IAccessSelections2 .
 IAccessSelections2	Gains access to the selections that define the mirror solid feature.
 IGetPatternBodyArray	Gets the seed bodies for this mirror solid feature.
 ISetPatternBodyArray	Sets the seed bodies for this mirror solid feature.
 ReleaseSelectionAccess	Releases access to the selections used to define the mirror solid feature.

[Top](#)

See Also

IMirrorSolidFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : [IMirrorSolidFeatureData Interface](#)

For a list of all members of this type, see [IMirrorSolidFeatureData members](#).

Public Properties

Name	Description
 Face	Gets or sets the end-condition face for this mirror solid feature.
 KnitSurface	Gets or sets whether to knit the surface for this mirror solid feature.
 Merge	Gets or sets the merge results option for the mirrored solid feature in a multibody part.
 PatternBodyArray	Gets or sets the seed bodies to pattern for this mirror solid feature.
 PropagateVisualProperty	Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all mirrored instances.
 StructureSystemToPatternArray	Gets or sets the structure systems to pattern in this mirror solid feature.

[Top](#)

See Also

[IMirrorSolidFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMirrorFeature Method](#)
[IMirrorPartFeatureData Interface](#)

AccessSelections Method (IMirrorSolidFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : [AccessSelections Method \(IMirrorSolidFeatureData\)](#)

Gains access to the selections that define the mirror solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IMirrorSolidFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,
```



```
& System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Top-level document (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [IMirrorSolidFeatureData::AccessSelections](#).

Example

[Get Mirror Solid Feature Data \(C#\)](#)

[Get Mirror Solid Feature Data \(VB.NET\)](#)

[Get Mirror Solid Feature Data \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <code>Nothing</code> or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IMirrorSolidFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMirrorSolidFeatureData Interface](#)

[IMirrorSolidFeatureData Members](#)

[IMirrorSolidFeaturePattern::IAccessSelections2 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Face Property (IMirrorSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : Face Property (IMirrorSolidFeatureData)

Gets or sets the end-condition face for this mirror solid feature.

.NET Syntax

Visual Basic (Declaration)

Property Face As System.Object

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData
Dim value As System.Object
```

```
instance.Face = value
```

```
value = instance.Face
```

C#

```
System.Object Face {get; set;}
```

C++/CLI

```
property System.Object^ Face {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Face](#) that determines the end condition

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::Face](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPatternBodyCount Method (IMirrorSolidFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : GetPatternBodyCount Method (IMirrorSolidFeatureData)

Gets the number of seed bodies in this mirror solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatternBodyCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
Dim value As System.Integer  
  
value = instance.GetPatternBodyCount()
```

C#

```
System.int GetPatternBodyCount()
```

C++/CLI

```
System.int GetPatternBodyCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of seed bodies

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::GetPatternBodyCount](#).

Example

[Get Mirror Solid Feature Data \(C#\)](#)
[Get Mirror Solid Feature Data \(VB.NET\)](#)
[Get Mirror Solid Feature Data \(VBA\)](#)

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)
[IMirrorSolidFeatureData::IGetPatternBodyArray Method](#)
[IMirrorSolidFeatureData::ISetPatternBodyArray Method](#)
[IMirrorSolidFeatureData::PatternBodyArray Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTransform Method (IMirrorSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : GetTransform Method (IMirrorSolidFeatureData)

Gets the transform for this mirror-solid feature.

.NET Syntax

Visual Basic (Declaration)

Function GetTransform() As MathTransform

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
Dim value As MathTransform  
  
value = instance.GetTransform()
```

C#

MathTransform GetTransform()

C++/CLI

MathTransform^ GetTransform();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Transform](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::GetTransform](#).

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IMirrorSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : IAccessSelections Method (IMirrorSolidFeatureData)

Obsolete. Superseded by [IMirrorSolidFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::IAccessSelections](#).

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections2 Method (IMirrorSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : IAccessSelections2 Method (IMirrorSolidFeatureData)

Gains access to the selections that define the mirror solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _
```

```
ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Top-level document (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IMirrorSolidFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)
[IMirrorSolidFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPatternBodyArray Method (IMirrorSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : IGetPatternBodyArray Method (IMirrorSolidFeatureData)

Gets the seed bodies for this mirror solid feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetPatternBodyArray() As Body2
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
Dim value As Body2
```

```
value = instance.IGetPatternBodyArray()
```

C#

```
Body2 IGetPatternBodyArray()
```

C++/CLI

```
Body2^ IGetPatternBodyArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of seed [bodies](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)
[IMirrorSolidFeatureData::GetPatternBodyCount Method](#)
[IMirrorSolidFeatureData::ISetPatternBodyArray Method](#)
[IMirrorSolidFeatureData::PatternBodyArray Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetPatternBodyArray Method (IMirrorSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : ISetPatternBodyArray Method (IMirrorSolidFeatureData)

Sets the seed bodies for this mirror solid feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetPatternBodyArray( _  
    ByVal BodyCount As System.Integer, _  
    ByRef ArrayDataIn As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData
Dim BodyCount As System.Integer
Dim ArrayDataIn As Body2

instance.ISetPatternBodyArray(BodyCount, ArrayDataIn)
```

C#

```
void ISetPatternBodyArray(
    System.int BodyCount,
    ref Body2 ArrayDataIn
)
```

C++/CLI

```
void ISetPatternBodyArray(
    & System.int BodyCount,
    & Body2^% ArrayDataIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyCount

Number of seed bodies

ArrayDataIn

- in-process, unmanaged C++: Pointer to an array of seed [bodies](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IMirrorSolidFeatureData Interface](#)

[IMirrorSolidFeatureData Members](#)

[IMirrorSolidFeatureData::GetPatternBodyCount Method](#)

[IMirrorSolidFeatureData::IGetPatternBodyArray Method](#)

[IMirrorSolidFeatureData::PatternBodyArray Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

KnitSurface Property (IMirrorSolidFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : KnitSurface Property (IMirrorSolidFeatureData)

Gets or sets whether to knit the surface for this mirror solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Property KnitSurface As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData
Dim value As System.Boolean
```

```
instance.KnitSurface = value
```

```
value = instance.KnitSurface
```

C#

```
System.bool KnitSurface {get; set;}
```

C++/CLI

```
property System.bool KnitSurface {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True knits the surface, false does not

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::KnitSurface](#).

Example

[Get Mirror Solid Feature Data \(C#\)](#)
[Get Mirror Solid Feature Data \(VB.NET\)](#)
[Get Mirror Solid Feature Data \(VBA\)](#)

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Merge Property (IMirrorSolidFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : Merge Property (IMirrorSolidFeatureData)

Gets or sets the merge results option for the mirrored solid feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property Merge As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
Dim value As System.Boolean
```

```
instance.Merge = value
```

```
value = instance.Merge
```

C#

```
System.bool Merge {get; set;}
```

C++/CLI

```
property System.bool Merge {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables the merge results option, false does not

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::Merge](#).

Example

[Get Mirror Solid Feature Data \(C#\)](#)
[Get Mirror Solid Feature Data \(VB.NET\)](#)
[Get Mirror Solid Feature Data \(VBA\)](#)

Remarks

The merge results option tells the SOLIDWORKS Design software whether to merge the new body or bodies with existing bodies in the multibody part. This property is set to True by default.

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternBodyArray Property (IMirrorSolidFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : PatternBodyArray Property (IMirrorSolidFeatureData)

Gets or sets the seed bodies to pattern for this mirror solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PatternBodyArray As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
Dim value As System.Object
```

```
instance.PatternBodyArray = value
```

```
value = instance.PatternBodyArray
```

C#

```
System.object PatternBodyArray {get; set;}
```

C++/CLI

```
property System.Object^ PatternBodyArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of seed [bodies](#) to pattern

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::PatternBodyArray](#).

Example

[Get Mirror Solid Feature Data \(C#\)](#)
[Get Mirror Solid Feature Data \(VB.NET\)](#)
[Get Mirror Solid Feature Data \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)
[IMirrorSolidFeatureData::GetPatternBodyCount Method](#)
[IMirrorSolidFeatureData::!GetPatternBodyArray Method](#)
[IMirrorSolidFeatureData::!SetPatternBodyArray Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateVisualProperty Property (IMirrorSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : PropagateVisualProperty Property (IMirrorSolidFeatureData)

Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all mirrored instances.

.NET Syntax

Visual Basic (Declaration)

```
Property PropagateVisualProperty As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
Dim value As System.Boolean
```

```
instance.PropagateVisualProperty = value
```

```
value = instance.PropagateVisualProperty
```

C#

```
System.bool PropagateVisualProperty {get; set;}
```

C++/CLI

```
property System.bool PropagateVisualProperty {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::PropagateVisualProperty](#).

Remarks

True to propagate visual properties, false to not

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IMirrorSolidFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : ReleaseSelectionAccess Method (IMirrorSolidFeatureData)

Releases access to the selections used to define the mirror solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::ReleaseSelectionAccess](#).

Example

[Get Mirror Solid Feature Data \(C#\)](#)
[Get Mirror Solid Feature Data \(VB.NET\)](#)
[Get Mirror Solid Feature Data \(VBA\)](#)

Remarks

[IMirrorSolidFeatureData::AccessSelections](#) and [IMirrorSolidFeatureData::!AccessSelections2](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefintion2](#) if you did.

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StructureSystemToPatternArray Property (IMirrorSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMirrorSolidFeatureData Interface](#) : StructureSystemToPatternArray Property (IMirrorSolidFeatureData)

Gets or sets the structure systems to pattern in this mirror solid feature.

.NET Syntax

Visual Basic (Declaration)

Property StructureSystemToPatternArray As System.Object

Visual Basic (Usage)



```
Dim instance As IMirrorSolidFeatureData
Dim value As System.Object

instance.StructureSystemToPatternArray = value

value = instance.StructureSystemToPatternArray
```

C#

```
System.Object StructureSystemToPatternArray {get; set;}
```

C++/CLI

```
property System.Object^ StructureSystemToPatternArray {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IStructureSystemFolders](#)

Visual Basic for Applications (VBA) Syntax

See [MirrorSolidFeatureData::StructureSystemToPatternArray](#).

Example

```
'VBA
'This example demonstrates how to create a mirror feature using a structure system.
'=====
'Preconditions:
'1. Ensure the specified part template exists.
'2. Open an Immediate window.
'3. Press F5.
'
'Postconditions:
'1. Creates Sketch1 containing two sketch segments.
'2. Configures the start/end extensions and the member profile.
'3. Selects the two sketch segments.
'4. Creates primary Structure System1 with two primary path segment members (Member1 and Member2).
'5. Creates a solid body to pattern.
'6. Inspect the graphics area.
'7. Press F5 to create Mirror1.
'8. Press F5 to finish.
'9. Inspect the Immediate window.
'=====
Option Explicit

Dim swApp As SldWorks.SldWorks
Dim modDoc As SldWorks.ModelDoc2
Dim swFeatMgr As SldWorks.FeatureManager
Dim swSelMgr As SldWorks.SelectionMgr
Dim modDocExt As SldWorks.ModelDocExtension
Dim structMemDef As SldWorks.StructureSystemMemberFeatureData
Dim profDef As SldWorks.StructureSystemMemberProfile
Dim PrimDef As SldWorks.PrimaryStructuralMemberFeatureData
```

```

Dim memPathSegDef As PrimaryMemberPathSegmentFeatureData
Dim memBetweenPointsSecDef As SldWorks.SecondaryMemberBetweenPointsFeatureData
Dim secMemDatToChange As SldWorks.SecondaryMemberBetweenPointsFeatureData
Dim memSupportPlaneSecDef As SldWorks.SecondaryMemberSupportPlaneFeatureData
Dim segments(2) As Object
Dim stat As Boolean
Dim memData(0) As SldWorks.StructureSystemMemberFeatureData
Dim memDataArray As Variant
Dim structSys As SldWorks.Feature
Dim baseSecondarySystem As SldWorks.StructureSystemFolder
Dim structSysDef As SldWorks.StructureSystemFolder
Dim structSysSecDef As SldWorks.StructureSystemFolder
Dim feat As SldWorks.Feature
Dim structSysModDef As SldWorks.StructureSystemFolder
Dim outProfiles As Variant
Dim MemberData As SldWorks.StructureSystemMemberFeatureData
Dim memberArray As Variant
Dim profileGrpFeat As SldWorks.Feature
Dim profileGrp As SldWorks.ProfileGroupFolder
Dim memToChange As SldWorks.StructureSystemMemberFeatureData
Dim i As Long
Dim j As Long
Dim secDef As SldWorks.SecondaryStructuralMemberFeatureData
Dim UpToMemDef As SldWorks.SecondaryMemberUpToMembersFeatureData
Dim point As Object
Dim Members(0) As Object

Dim swModel As SldWorks.ModelDoc2
Dim swModelDocExt As SldWorks.ModelDocExtension
Dim swSelectionMgr As SldWorks.SelectionMgr
Dim swFeatureMgr As SldWorks.FeatureManager
Dim swFeature As SldWorks.Feature
Dim swMirrorSolidFeatureData As SldWorks.MirrorSolidFeatureData
Dim sketchSegments As Variant
Dim status As Boolean
Dim obj As Object
Dim patternFeatures(1) As Object

Sub main()
    Set swApp = Application.SldWorks

    Dim swSheetWidth As Double
    swSheetWidth = 0
    Dim swSheetHeight As Double
    swSheetHeight = 0
    Set modDoc = swApp.NewDocument("C:\ProgramData\SolidWorks\SOLIDWORKS 2023\templates\Part.PRTDOT", 0, swSheetWidth,
    swSheetHeight)

    Set modDocExt = modDoc.Extension

    modDoc.SketchManager.InsertSketch True
    stat = modDocExt.SelectByID2("Front Plane", "PLANE", -0.077188654347454, 0.054268560279924, 3.86214196026222E-03, False, 0,
    Nothing, 0)
    modDoc.ClearSelection2 True

    Dim skSegment As Object
    Set skSegment = modDoc.SketchManager.CreateLine(-0.168061, 0.084736, 0#, -0.168061, -0.077684, 0#)
    Set skSegment = modDoc.SketchManager.CreateLine(0.075216, 0.107771, 0#, 0.075216, -0.006699, 0#)
    modDoc.ClearSelection2 True

    stat = modDocExt.SelectByID2("Top Plane", "PLANE", 0, 0, 0, True, 0, Nothing, 0)
    Dim myRefPlane As SldWorks.RefPlane
    Set myRefPlane = modDoc.FeatureManager.InsertRefPlane(8, 0.03, 0, 0, 0, 0)
    modDoc.ClearSelection2 True
    stat = modDocExt.SelectByID2("Top Plane", "PLANE", 0, 0, 0, False, 0, Nothing, 0)
    modDoc.ClearSelection2 True
    modDoc.SketchManager.InsertSketch True

    stat = modDocExt.SelectByID2("Line1@Sketch1", "EXTSKETCHSEGMENT", -0.168061313304597, 5.44142573846353E-02, 0, False, 0,
    Nothing, 0)
    stat = modDocExt.SelectByID2("Line2@Sketch1", "EXTSKETCHSEGMENT", 7.52162521083513E-02, 5.32390034454423E-02, 0, True, 0,
    Nothing, 0)

    'Create primary structure system path segment members
    Set structMemDef = modDocExt.CreateStructureSystemMemberData(0)
    Debug.Print "Type of structure system member as defined by swStructureSystemMemberType_e: " &
    structMemDef.StructureSystemMemberType

    structMemDef.StartEndExtendD1 = 1#
    structMemDef.StartEndExtendD2 = 2#

    Set profDef = structMemDef.MemberProfile

```

```

profDef.ProfileStandard = "ansi inch"
profDef.ProfileType = "c channel"
profDef.ProfileSize = "3 x 5"

Set PrimDef = structMemDef
Debug.Print "Structure system primary member creation type as defined by swStructureSystemMemberCreationType_e: " &
PrimDef.PrimaryMemberType

Set memPathSegDef = PrimDef
memPathSegDef.MergeTangentMembers = True

Set swSelMgr = modDoc.SelectionManager

Dim segments(1) As Object
Set segments(0) = swSelMgr.GetSelectedObject6(1, 0)
Set segments(1) = swSelMgr.GetSelectedObject6(2, 0)
stat = memPathSegDef.SetPathSegments(segments)
Debug.Print "Path segments successfully set: " & stat

Dim PrimMemData(0) As SldWorks.StructureSystemMemberFeatureData
Set PrimMemData(0) = structMemDef

Dim PrimMemDatArray As Variant
PrimMemDatArray = PrimMemData

Dim structSysFeat As SldWorks.Feature
Set structSysFeat = modDocExt.CreateStructureSystem(PrimMemDatArray, Nothing)

'Create a solid body to also pattern
status = modDocExt.SelectByID2("Front Plane", "PLANE", 0, 0, 0, False, 0, Nothing, 0)
modDoc.SketchManager.InsertSketch True
modDoc.ClearSelection2 True
status = modDocExt.SketchBoxSelect("0.509957", "-0.990370", "0.000000", "1.024907", "-1.314598", "0.000000")
status = modDocExt.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstToRectEntity,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, False)
status = modDocExt.SetUserPreferenceToggle(swUserPreferenceToggle_e.swSketchAddConstLineDiagonalType,
swUserPreferenceOption_e.swDetailingNoOptionSpecified, True)
Dim vSkLines As Variant
vSkLines = modDoc.SketchManager.CreateCornerRectangle(0.713394086918119, -0.907724114572968, 0, 1.44449597678115,
-1.33367043301491, 0)
modDoc.ClearSelection2 True
modDoc.SketchManager.InsertSketch True
modDoc.SketchManager.InsertSketch True
Dim myFeature As SldWorks.Feature
Set myFeature = modDoc.FeatureManager.FeatureExtrusion2(True, False, False, 0, 0, 0.07, 0.01, False, False, False, False,
1.74532925199433E-02, 1.74532925199433E-02, False, False, False, False, True, True, 0, 0, False)
modDoc.SelectionManager.EnableContourSelection = False

modDoc.ViewZoomtofit

Stop

Set swModel = swApp.ActiveDoc
Set swModelDocExt = swModel.Extension
Set swFeatureMgr = swModel.FeatureManager
Set swSelectionMgr = swModel.SelectionManager

'Pre-select mirror face, bodies, structure system folders
swModel.ClearSelection2 True

status = swModelDocExt.SelectByRay(1.44449597678107, -1.08350443384643, 3.67298798859679E-02, -0.790470353092525,
-0.254349019385703, -0.557192244399822, 2.59382235707926E-02, 2, False, 2, 0)
status = swModelDocExt.SelectByID2("Boss-Extrude1", "SOLIDBODY", 0, 0, 0, True, 256, Nothing, 0)
status = swModelDocExt.SelectByID2("Structure System1", "BODYFEATURE", 0, 0, 0, True, 134217728, Nothing, 0)

Set swFeature = swFeatureMgr.InsertMirrorFeature2(True, False, False, False, swFeatureScope_e.swFeatureScope_AllBodies)

Stop

swModel.ClearSelection2 True
status = swModelDocExt.SelectByID2("Mirror1", "BODYFEATURE", 0, 0, 0, False, 0, Nothing, 0)
Set swFeature = swSelectionMgr.GetSelectedObject6(1, -1)
Set swMirrorSolidFeatureData = swFeature.GetDefinition
swMirrorSolidFeatureData.AccessSelections swModel, Nothing

Dim var As Variant
var = swMirrorSolidFeatureData.StructureSystemToPatternArray

Dim strctSysFolder As StructureSystemFolder
Dim index As Integer
For index = LBound(var) To UBound(var)

```

```

Set strctSysFolder = var(index)
Set patternFeatures(0) = strctSysFolder
Debug.Print "Profile group folders count: " & strctSysFolder.GetProfileGroupFoldersCount
Next

'Uncomment the following lines of code to modify the linear pattern
'to use another structure system (e.g., Structure System2)
'Stop

'Dim feat As Feature
'swModel.ClearSelection2 True
'status = swModelDocExt.SelectByID2("Structure System2", "BODYFEATURE", 0, 0, 0, True, 0, Nothing, 0)
'Set feat = swSelectionMgr.GetSelectedObject6(1, 0)
'Set patternFeatures(1) = feat.GetSpecificFeature2()

"During mirror solid modification, use StructureSystemPatternArray property to change structure system to pattern
'swMirrorSolidFeatureData.StructureSystemToPatternArray = patternFeatures

Debug.Print swFeature.ModifyDefinition(swMirrorSolidFeatureData, swModel, Nothing)

End Sub

```

Remarks

Use this property to change structure systems only after the mirror solid feature has been created.

Before using this property in .NET code, read [Dispatch Object Arrays as Input in .NET](#). To remove a structure system from the pattern, set this property to a Dispatcher array containing one null element.

For more information, see the **SOLIDWORKS Design user-interface help > Weldments and Structure System > Pattern and Mirror Support** topic.

See Also

[IMirrorSolidFeatureData Interface](#)
[IMirrorSolidFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31