

SOLIDWORKS API (.NET VBA C#) — Reference (172/337): IModelDoc (part 8 of 13)

SOLIDWORKS API Documentation (converted from CHM)

IModelDoc (part 8 of 13) (Type)

IGetUnits Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IGetUnits Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IGetUnits](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetUnits() As System.Short
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim value As System.Short  
  
value = instance.IGetUnits()
```

C#

```
System.short IGetUnits()
```

C++/CLI

```
System.short IGetUnits();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IGetUnits](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

IGetUserPreferenceTextFormat Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IGetUserPreferenceTextFormat Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IGetUserPreferenceTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetUserPreferenceTextFormat(  
    ByVal UserPreferenceValue As System.Integer _  
) As TextFormat
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim UserPreferenceValue As System.Integer  
Dim value As TextFormat  
  
value = instance.IGetUserPreferenceTextFormat(UserPreferenceValue)
```

C#

```
TextFormat IGetUserPreferenceTextFormat(  
    System.int UserPreferenceValue  
)
```

C++/CLI

```
TextFormat^ IGetUserPreferenceTextFormat(  
& System.int UserPreferenceValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UserPreferenceValue

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::IGetUserPreferenceTextFormat](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetUserUnit Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IGetUserUnit Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IGetUserUnit](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetUserUnit( _  
    ByVal UnitType As System.Integer _  
) As UserUnit
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim UnitType As System.Integer  
Dim value As UserUnit
```

```
value = instance.IGetUserUnit(UnitType)
```

C#

```
UserUnit IGetUserUnit(  
    System.int UnitType  
)
```

C++/CLI

```
UserUnit^ IGetUserUnit(  
& System.int UnitType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UnitType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IGetUserUnit](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetVersionHistoryCount Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IGetVersionHistoryCount Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IGetVersionHistoryCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVersionHistoryCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As System.Integer

value = instance.IGetVersionHistoryCount()
```

C#

```
System.int IGetVersionHistoryCount()
```

C++/CLI

```
System.int IGetVersionHistoryCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IGetVersionHistoryCount](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IInsertBOMBalloon2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IInsertBOMBalloon2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IInsertBOMBalloon2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertBOMBalloon2( _
    ByVal Style As System.Integer, _
    ByVal Size As System.Integer, _
    ByVal UpperTextStyle As System.Integer, _
    ByVal UpperText As System.String, _
    ByVal LowerTextStyle As System.Integer, _
    ByVal LowerText As System.String _
) As Note
```

```

Dim instance As IModelDoc
Dim Style As System.Integer
Dim Size As System.Integer
Dim UpperTextStyle As System.Integer
Dim UpperText As System.String
Dim LowerTextStyle As System.Integer
Dim LowerText As System.String
Dim value As Note

value = instance.IInsertBOMBalloon2(Style, Size, UpperTextStyle, UpperText, LowerTextStyle, LowerText)

```

C#

```

Note IInsertBOMBalloon2(
    System.int Style,
    System.int Size,
    System.int UpperTextStyle,
    System.string UpperText,
    System.int LowerTextStyle,
    System.string LowerText
)

```

C++/CLI

```

Note^ IInsertBOMBalloon2(
    & System.int Style,
    & System.int Size,
    & System.int UpperTextStyle,
    & System.String^ UpperText,
    & System.int LowerTextStyle,
    & System.String^ LowerText
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Size

UpperTextStyle

UpperText

LowerTextStyle

LowerText

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::IInsertBOMBalloon2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertDatumTag2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertDatumTag2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertDatumTag2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertDatumTag2() As DatumTag
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As DatumTag

value = instance.IInsertDatumTag2()
```

C#

```
DatumTag IInsertDatumTag2()
```

C++/CLI

```
DatumTag^ IInsertDatumTag2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IInsertDatumTag2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertGtol Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertGtol Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertGtol](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertGtol() As Gtol
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As Gtol

value = instance.IInsertGtol()
```

C#

```
Gtol IInsertGtol()
```

C++/CLI

```
Gtol^ IInsertGtol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertGtol](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

IInsertMidSurfaceExt Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IInsertMidSurfaceExt Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IInsertMidSurfaceExt](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertMidSurfaceExt( _  
    ByVal Placement As System.Double, _  
    ByVal KnitFlag As System.Boolean _  
) As MidSurface
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Placement As System.Double  
Dim KnitFlag As System.Boolean  
Dim value As MidSurface  
  
value = instance.IInsertMidSurfaceExt(Placement, KnitFlag)
```

C#

```
MidSurface IInsertMidSurfaceExt(  
    System.double Placement,  
    System.bool KnitFlag  
)
```

C++/CLI

```
MidSurface^ IInsertMidSurfaceExt(  
& System.double Placement,  
& System.bool KnitFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Placement

KnitFlag

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IInsertMidSurfaceExt](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

IInsertNote Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IInsertNote Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IInsertNote](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertNote( _  
    ByVal Text As System.String _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Text As System.String  
Dim value As Note  
  
value = instance.IInsertNote(Text)
```

C#

```
Note IInsertNote(  
    System.string Text  
)
```

C++/CLI

```
Note^ IInsertNote(  
&    System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IInsertNote](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertProjectedSketch2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProjectedSketch2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IInsertProjectedSketch2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertProjectedSketch2( _  
    ByVal Reverse As System.Integer _  
) As Feature
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Reverse As System.Integer  
Dim value As Feature  
  
value = instance.IInsertProjectedSketch2(Reverse)
```

C#


```
Feature IInsertProjectedSketch2(  
    System.int Reverse  
)
```

C++/CLI

```
Feature^ IInsertProjectedSketch2(  
&    System.int Reverse  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Reverse

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IInsertProjectedSketch2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertWeldSymbol3 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertWeldSymbol3 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IInsertWeldSymbol3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IInsertWeldSymbol3() As WeldSymbol
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim value As WeldSymbol
```

```
value = instance.IInsertWeldSymbol3()
```

C#

```
WeldSymbol IInsertWeldSymbol3()
```

C++/CLI

```
WeldSymbol^ IInsertWeldSymbol3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IInsertWeldSymbol3](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ILightSourcePropertyValues Property (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ILightSourcePropertyValues Property (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ILightSourcePropertyValues](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ILightSourcePropertyValues( _  
    ByVal ID As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim ID As System.Integer  
Dim value As System.Double
```

```
instance.ILightSourcePropertyValues(ID) = value  
  
value = instance.ILightSourcePropertyValues(ID)
```

C#

```
System.double ILightSourcePropertyValues(  
    System.int ID  
) {get; set;}
```

C++/CLI

```
property System.double ILightSourcePropertyValues {  
    System.double get(System.int ID);  
    void set (System.int ID, System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ILightSourcePropertyValues](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IListExternalFileReferences Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IListExternalFileReferences Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IListExternalFileReferences](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IListExternalFileReferences( _  
    ByVal UseSearchRules As System.Boolean, _  
    ByVal NumRefs As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim UseSearchRules As System.Boolean
Dim NumRefs As System.Integer
Dim value As System.String

value = instance.IListExternalFileReferences(UseSearchRules, NumRefs)
```

C#

```
System.string IListExternalFileReferences(
    System.bool UseSearchRules,
    System.int NumRefs
)
```

C++/CLI

```
System.String^ IListExternalFileReferences(
    & System.bool UseSearchRules,
    & System.int NumRefs
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseSearchRules

NumRefs

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2.IListExternalFileReferences](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMaterialPropertyValues Property (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IMaterialPropertyValues Property (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IMaterialPropertyValues](#).

.NET Syntax

Visual Basic (Declaration)

```
Property IMaterialPropertyValues As System.Double
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As System.Double

instance.IMaterialPropertyValues = value

value = instance.IMaterialPropertyValues
```

C#

```
System.double IMaterialPropertyValues {get; set;}
```

C++/CLI

```
property System.double IMaterialPropertyValues {
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IMaterialPropertyValues](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMultiSelectByRay Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IMultiSelectByRay Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IMultiSelectByRay](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IMultiSelectByRay( _  
    ByRef PointIn As System.Double, _  
    ByRef VectorIn As System.Double, _  
    ByVal RadiusIn As System.Double, _  
    ByVal TypeWanted As System.Integer, _  
    ByVal Append As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim PointIn As System.Double  
Dim VectorIn As System.Double  
Dim RadiusIn As System.Double  
Dim TypeWanted As System.Integer  
Dim Append As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.IMultiSelectByRay(PointIn, VectorIn, RadiusIn, TypeWanted, Append)
```

C#

```
System.bool IMultiSelectByRay(  
    ref System.double PointIn,  
    ref System.double VectorIn,  
    System.double RadiusIn,  
    System.int TypeWanted,  
    System.bool Append  
)
```

C++/CLI

```
System.bool IMultiSelectByRay(  
& System.double% PointIn,  
& System.double% VectorIn,  
& System.double RadiusIn,  
& System.int TypeWanted,  
& System.bool Append  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointIn

VectorIn
RadiusIn
TypeWanted
Append

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IMultiSelectByRay](#).

 See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

Insert3DSketch Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : Insert3DSketch Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::Insert3DSketch](#).

 .NET Syntax

Visual Basic (Declaration)

Sub Insert3DSketch()

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.Insert3DSketch()
```

C#

```
void Insert3DSketch()
```

C++/CLI

```
void Insert3DSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc::Insert3DSketch](#).

 See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

Insert3DSketch2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : Insert3DSketch2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::Insert3DSketch2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Sub Insert3DSketch2( _  
    ByVal UpdateEditRebuild As System.Boolean _
```

)

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim UpdateEditRebuild As System.Boolean  
  
instance.Insert3DSketch2(UpdateEditRebuild)
```

C#

```
void Insert3DSketch2(  
    System.bool UpdateEditRebuild  
)
```

C++/CLI

```
void Insert3DSketch2(  
&    System.bool UpdateEditRebuild  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UpdateEditRebuild

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::Insert3DSketch2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Insert3DSplineCurve Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : Insert3DSplineCurve Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::Insert3DSplineCurve](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub Insert3DSplineCurve( _  
    ByVal CurveClosed As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim CurveClosed As System.Boolean  
  
instance.Insert3DSplineCurve(CurveClosed)
```

C#

```
void Insert3DSplineCurve(  
    System.bool CurveClosed  
)
```

C++/CLI

```
void Insert3DSplineCurve(  
&    System.bool CurveClosed
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CurveClosed

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc::Insert3DSplineCurve](#).

 See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertAxis Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertAxis Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertAxis](#).

 .NET Syntax

Visual Basic (Declaration)

Function InsertAxis() As System.Boolean

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim value As System.Boolean  
  
value = instance.InsertAxis()
```

C#

System.bool InsertAxis()

C++/CLI

System.bool InsertAxis();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertAxis](#).

 See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertBendTableEdit Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertBendTableEdit Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertBendTableEdit](#).

 .NET Syntax

Visual Basic (Declaration)

```
Sub InsertBendTableEdit()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.InsertBendTableEdit()
```

C#

```
void InsertBendTableEdit()
```

C++/CLI

```
void InsertBendTableEdit();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertBendTableEdit](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertBendTableNew Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertBendTableNew Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertBendTableNew](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBendTableNew( _  
    ByVal FileName As System.String, _  
    ByVal Units As System.String, _  
    ByVal Type As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim FileName As System.String  
Dim Units As System.String  
Dim Type As System.String  
Dim value As System.Boolean  
  
value = instance.InsertBendTableNew(FileName, Units, Type)
```

C#

```
System.bool InsertBendTableNew(  
    System.string FileName,  
    System.string Units,  
    System.string Type  
)
```

C++/CLI

```
System.bool InsertBendTableNew(  
& System.String^ FileName,  
& System.String^ Units,
```



```
& System.String^ Type
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Units

Type

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertBendTableNew](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertBendTableOpen Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertBendTableOpen Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertBendTableOpen](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBendTableOpen( _
    ByVal FileName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim FileName As System.String
Dim value As System.Boolean
```

```
value = instance.InsertBendTableOpen(FileName)
```

C#

```
System.bool InsertBendTableOpen(
    System.string FileName
)
```

C++/CLI

```
System.bool InsertBendTableOpen(
& System.String^ FileName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertBendTableOpen](#).

See Also

InsertBkgImage Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertBkgImage Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertBkgImage](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertBkgImage(  
    ByVal NewName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim NewName As System.String  
  
instance.InsertBkgImage(NewName)
```

C#

```
void InsertBkgImage(  
    System.string NewName  
)
```

C++/CLI

```
void InsertBkgImage(  
& System.String^ NewName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NewName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertBkgImage](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

InsertBOMBalloon Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertBOMBalloon Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertBOMBalloon](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertBOMBalloon()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertBOMBalloon()
```

C#

```
void InsertBOMBalloon()
```

C++/CLI

```
void InsertBOMBalloon();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertBOMBalloon](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertBOMBalloon2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertBOMBalloon2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertBOMBalloon2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertBOMBalloon2( _  
    ByVal Style As System.Integer, _  
    ByVal Size As System.Integer, _  
    ByVal UpperTextStyle As System.Integer, _  
    ByVal UpperText As System.String, _  
    ByVal LowerTextStyle As System.Integer, _  
    ByVal LowerText As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Style As System.Integer  
Dim Size As System.Integer  
Dim UpperTextStyle As System.Integer  
Dim UpperText As System.String  
Dim LowerTextStyle As System.Integer  
Dim LowerText As System.String  
Dim value As System.Object  
  
value = instance.InsertBOMBalloon2(Style, Size, UpperTextStyle, UpperText, LowerTextStyle,  
LowerText)
```

C#

```
System.object InsertBOMBalloon2(  
    System.int Style,  
    System.int Size,  
    System.int UpperTextStyle,  
    System.string UpperText,  
    System.int LowerTextStyle,  
    System.string LowerText  
)
```

C++/CLI

```
System.Object^ InsertBOMBalloon2(  
& System.int Style,  
& System.int Size,  
& System.int UpperTextStyle,  
& System.String^ UpperText,  
& System.int LowerTextStyle,  
& System.String^ LowerText  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style

Size

UpperTextStyle

UpperText

LowerTextStyle

LowerText

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertBOMBalloon2](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCompositeCurve Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCompositeCurve Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCompositeCurve](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCompositeCurve() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim value As System.Boolean
```

```
value = instance.InsertCompositeCurve()
```

C#

```
System.bool InsertCompositeCurve()
```

C++/CLI

```
System.bool InsertCompositeCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCompositeCurve](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertConnectionPoint Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertConnectionPoint Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertConnectionPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertConnectionPoint()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.InsertConnectionPoint()
```

C#

```
void InsertConnectionPoint()
```

C++/CLI

```
void InsertConnectionPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertConnectionPoint](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCoordinateSystem Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCoordinateSystem Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCoordinateSystem](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCoordinateSystem(  
    ByVal XFlippedIn As System.Boolean, _  
    ByVal YFlippedIn As System.Boolean, _
```

```
ByVal ZFlippedIn As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim XFlippedIn As System.Boolean  
Dim YFlippedIn As System.Boolean  
Dim ZFlippedIn As System.Boolean  
Dim value As System.Boolean  
  
value = instance.InsertCoordinateSystem(XFlippedIn, YFlippedIn, ZFlippedIn)
```

C#

```
System.bool InsertCoordinateSystem(  
    System.bool XFlippedIn,  
    System.bool YFlippedIn,  
    System.bool ZFlippedIn  
)
```

C++/CLI

```
System.bool InsertCoordinateSystem(  
& System.bool XFlippedIn,  
& System.bool YFlippedIn,  
& System.bool ZFlippedIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XFlippedIn

YFlippedIn

ZFlippedIn

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCoordinateSystem](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCosmeticThread Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCosmeticThread Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCosmeticThread](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCosmeticThread( _  
    ByVal Type As System.Short, _  
    ByVal Depth As System.Double, _  
    ByVal Length As System.Double, _  
    ByVal Note As System.String _  
)
```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim Type As System.Short
Dim Depth As System.Double
Dim Length As System.Double
Dim Note As System.String

instance.InsertCosmeticThread(Type, Depth, Length, Note)

```

C#

```

void InsertCosmeticThread(
    System.short Type,
    System.double Depth,
    System.double Length,
    System.string Note
)

```

C++/CLI

```

void InsertCosmeticThread(
    & System.short Type,
    & System.double Depth,
    & System.double Length,
    & System.String^ Note
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Depth

Length

Note

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCosmeticThread](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertCurveFile Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCurveFile Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCurveFile](#).

.NET Syntax

Visual Basic (Declaration)

```

Function InsertCurveFile( _
    ByVal FileName As System.String _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim FileName As System.String
Dim value As System.Boolean

value = instance.InsertCurveFile(FileName)

```

C#

```
System.bool InsertCurveFile(  
    System.string FileName  
)
```

C++/CLI

```
System.bool InsertCurveFile(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCurveFile](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCurveFileBegin Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCurveFileBegin Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCurveFileBegin](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCurveFileBegin()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.InsertCurveFileBegin()
```

C#

```
void InsertCurveFileBegin()
```

C++/CLI

```
void InsertCurveFileBegin();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCurveFileBegin](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCurveFileEnd Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCurveFileEnd Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCurveFileEnd](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCurveFileEnd() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim value As System.Boolean  
  
value = instance.InsertCurveFileEnd()
```

C#

```
System.bool InsertCurveFileEnd()
```

C++/CLI

```
System.bool InsertCurveFileEnd();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCurveFileEnd](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertCurveFilePoint Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCurveFilePoint Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCurveFilePoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertCurveFilePoint( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean  
  
value = instance.InsertCurveFilePoint(X, Y, Z)
```

C#

```
System.bool InsertCurveFilePoint(  
    System.double X,
```

```
System.double Y,  
System.double Z  
)
```

C++/CLI

```
System.bool InsertCurveFilePoint(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCurveFilePoint](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCutBlend Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutBlend Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCutBlend](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCutBlend( _  
    ByVal Closed As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
  
instance.InsertCutBlend(Closed)
```

C#

```
void InsertCutBlend(  
    System.bool Closed  
)
```

C++/CLI

```
void InsertCutBlend(  
& System.bool Closed  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCutBlend](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCutBlend2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutBlend2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCutBlend2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCutBlend2( _  
    ByVal Closed As System.Boolean, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
  
instance.InsertCutBlend2(Closed, KeepTangency, ForceNonRational)
```

C#

```
void InsertCutBlend2(  
    System.bool Closed,  
    System.bool KeepTangency,  
    System.bool ForceNonRational  
)
```

C++/CLI

```
void InsertCutBlend2(  
& System.bool Closed,  
& System.bool KeepTangency,  
& System.bool ForceNonRational  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

KeepTangency

ForceNonRational

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCutBlend2](#).

See Also

InsertCutBlend3 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutBlend3 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCutBlend3](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub InsertCutBlend3( _  
    ByVal Closed As System.Boolean, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean, _  
    ByVal TessToleranceFactor As System.Double, _  
    ByVal StartMatchingType As System.Short, _  
    ByVal EndMatchingType As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
Dim TessToleranceFactor As System.Double  
Dim StartMatchingType As System.Short  
Dim EndMatchingType As System.Short  
  
instance.InsertCutBlend3(Closed, KeepTangency, ForceNonRational, TessToleranceFactor,  
    StartMatchingType, EndMatchingType)
```

C#

```
void InsertCutBlend3(  
    System.bool Closed,  
    System.bool KeepTangency,  
    System.bool ForceNonRational,  
    System.double TessToleranceFactor,  
    System.short StartMatchingType,  
    System.short EndMatchingType  
)
```

C++/CLI

```
void InsertCutBlend3(  
& System.bool Closed,  
& System.bool KeepTangency,  
& System.bool ForceNonRational,  
& System.double TessToleranceFactor,  
& System.short StartMatchingType,  
& System.short EndMatchingType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

KeepTangency

ForceNonRational

TessToleranceFactor

StartMatchingType

EndMatchingType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCutBlend3](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCutBlend4 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutBlend4 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCutBlend4](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCutBlend4( _  
    ByVal Closed As System.Boolean, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean, _  
    ByVal TessToleranceFactor As System.Double, _  
    ByVal StartMatchingType As System.Short, _  
    ByVal EndMatchingType As System.Short, _  
    ByVal IsThinBody As System.Boolean, _  
    ByVal Thickness1 As System.Double, _  
    ByVal Thickness2 As System.Double, _  
    ByVal ThinType As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
Dim TessToleranceFactor As System.Double  
Dim StartMatchingType As System.Short  
Dim EndMatchingType As System.Short  
Dim IsThinBody As System.Boolean  
Dim Thickness1 As System.Double  
Dim Thickness2 As System.Double  
Dim ThinType As System.Short
```

```
instance.InsertCutBlend4(Closed, KeepTangency, ForceNonRational, TessToleranceFactor,  
StartMatchingType, EndMatchingType, IsThinBody, Thickness1, Thickness2, ThinType)
```

C#

```
void InsertCutBlend4(  
    System.bool Closed,  
    System.bool KeepTangency,  
    System.bool ForceNonRational,  
    System.double TessToleranceFactor,  
    System.short StartMatchingType,  
    System.short EndMatchingType,  
    System.bool IsThinBody,  
    System.double Thickness1,  
    System.double Thickness2,  
    System.short ThinType  
)
```

C++/CLI

```

void InsertCutBlend4(
& System.bool Closed,
& System.bool KeepTangency,
& System.bool ForceNonRational,
& System.double TessToleranceFactor,
& System.short StartMatchingType,
& System.short EndMatchingType,
& System.bool IsThinBody,
& System.double Thickness1,
& System.double Thickness2,
& System.short ThinType
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

KeepTangency

ForceNonRational

TessToleranceFactor

StartMatchingType

EndMatchingType

IsThinBody

Thickness1

Thickness2

ThinType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2.InsertCutBlend4](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertCutSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2.InsertCutSurface](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub InsertCutSurface( _
    ByVal Flip As System.Boolean, _
    ByVal KeepPieceIndex As System.Integer _
)

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim Flip As System.Boolean
Dim KeepPieceIndex As System.Integer

```

```
instance.InsertCutSurface(Flip, KeepPieceIndex)
```

C#

```

void InsertCutSurface(
    System.bool Flip,

```

```
        System.int KeepPieceIndex
    )
```

C++/CLI

```
void InsertCutSurface(
&    System.bool Flip,
&    System.int KeepPieceIndex
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Flip

KeepPieceIndex

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertCutSurface](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCutSwept Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutSwept Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCutSwept](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCutSwept( _
    ByVal Propagate As System.Boolean, _
    ByVal Alignment As System.Boolean, _
    ByVal KeepNormalConstant As System.Boolean _
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim Propagate As System.Boolean
Dim Alignment As System.Boolean
Dim KeepNormalConstant As System.Boolean

instance.InsertCutSwept(Propagate, Alignment, KeepNormalConstant)
```

C#

```
void InsertCutSwept(
    System.bool Propagate,
    System.bool Alignment,
    System.bool KeepNormalConstant
)
```

C++/CLI

```
void InsertCutSwept(
&    System.bool Propagate,
&    System.bool Alignment,
&    System.bool KeepNormalConstant
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

Alignment

KeepNormalConstant

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertCutSwept](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCutSwept2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutSwept2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCutSwept2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCutSwept2( _  
    ByVal Propagate As System.Boolean, _  
    ByVal Alignment As System.Boolean, _  
    ByVal TwistCtrlOption As System.Short, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Propagate As System.Boolean  
Dim Alignment As System.Boolean  
Dim TwistCtrlOption As System.Short  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean
```

```
instance.InsertCutSwept2(Propagate, Alignment, TwistCtrlOption, KeepTangency, ForceNonRational)
```

C#

```
void InsertCutSwept2(  
    System.bool Propagate,  
    System.bool Alignment,  
    System.short TwistCtrlOption,  
    System.bool KeepTangency,  
    System.bool ForceNonRational  
)
```

C++/CLI

```
void InsertCutSwept2(  
& System.bool Propagate,  
& System.bool Alignment,  
& System.short TwistCtrlOption,  
& System.bool KeepTangency,  
& System.bool ForceNonRational  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate
Alignment
TwistCtrlOption
KeepTangency
ForceNonRational

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertCutSwept2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertCutSwept3 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutSwept3 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCutSwept3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertCutSwept3( _  
    ByVal Propagate As System.Boolean, _  
    ByVal Alignment As System.Boolean, _  
    ByVal TwistCtrlOption As System.Short, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean, _  
    ByVal StartMatchingType As System.Short, _  
    ByVal EndMatchingType As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Propagate As System.Boolean  
Dim Alignment As System.Boolean  
Dim TwistCtrlOption As System.Short  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
Dim StartMatchingType As System.Short  
Dim EndMatchingType As System.Short  
  
instance.InsertCutSwept3(Propagate, Alignment, TwistCtrlOption, KeepTangency, ForceNonRational,  
StartMatchingType, EndMatchingType)
```

C#

```
void InsertCutSwept3(  
    System.bool Propagate,  
    System.bool Alignment,  
    System.short TwistCtrlOption,  
    System.bool KeepTangency,  
    System.bool ForceNonRational,  
    System.short StartMatchingType,  
    System.short EndMatchingType  
)
```

C++/CLI

```
void InsertCutSwept3(  
& System.bool Propagate,
```

```

& System.bool Alignment,
& System.short TwistCtrlOption,
& System.bool KeepTangency,
& System.bool ForceNonRational,
& System.short StartMatchingType,
& System.short EndMatchingType
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

Alignment

TwistCtrlOption

KeepTangency

ForceNonRational

StartMatchingType

EndMatchingType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCutSwept3](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertCutSwept4 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertCutSwept4 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertCutSwept4](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub InsertCutSwept4( _
    ByVal Propagate As System.Boolean, _
    ByVal Alignment As System.Boolean, _
    ByVal TwistCtrlOption As System.Short, _
    ByVal KeepTangency As System.Boolean, _
    ByVal ForceNonRational As System.Boolean, _
    ByVal StartMatchingType As System.Short, _
    ByVal EndMatchingType As System.Short, _
    ByVal IsThinBody As System.Boolean, _
    ByVal Thickness1 As System.Double, _
    ByVal Thickness2 As System.Double, _
    ByVal ThinType As System.Short _
)

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim Propagate As System.Boolean
Dim Alignment As System.Boolean
Dim TwistCtrlOption As System.Short
Dim KeepTangency As System.Boolean
Dim ForceNonRational As System.Boolean
Dim StartMatchingType As System.Short
Dim EndMatchingType As System.Short
Dim IsThinBody As System.Boolean
Dim Thickness1 As System.Double

```

```
Dim Thickness2 As System.Double
Dim ThinType As System.Short
```

```
instance.InsertCutSwept4(Propagate, Alignment, TwistCtrlOption, KeepTangency, ForceNonRational,
StartMatchingType, EndMatchingType, IsThinBody, Thickness1, Thickness2, ThinType)
```

C#

```
void InsertCutSwept4(
    System.bool Propagate,
    System.bool Alignment,
    System.short TwistCtrlOption,
    System.bool KeepTangency,
    System.bool ForceNonRational,
    System.short StartMatchingType,
    System.short EndMatchingType,
    System.bool IsThinBody,
    System.double Thickness1,
    System.double Thickness2,
    System.short ThinType
)
```

C++/CLI

```
void InsertCutSwept4(
    & System.bool Propagate,
    & System.bool Alignment,
    & System.short TwistCtrlOption,
    & System.bool KeepTangency,
    & System.bool ForceNonRational,
    & System.short StartMatchingType,
    & System.short EndMatchingType,
    & System.bool IsThinBody,
    & System.double Thickness1,
    & System.double Thickness2,
    & System.short ThinType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

Alignment

TwistCtrlOption

KeepTangency

ForceNonRational

StartMatchingType

EndMatchingType

IsThinBody

Thickness1

Thickness2

ThinType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertCutSwept4](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertDatumTag2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertDatumTag2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertDatumTag2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As System.Object

value = instance.InsertDatumTag2()
```

C#

```
System.object InsertDatumTag2()
```

C++/CLI

```
System.Object^ InsertDatumTag2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertDatumTag2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertDatumTargetSymbol Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertDatumTargetSymbol Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertDatumTargetSymbol](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertDatumTargetSymbol( _
    ByVal Datum1 As System.String, _
    ByVal Datum2 As System.String, _
    ByVal Datum3 As System.String, _
    ByVal AreaStyle As System.Short, _
    ByVal AreaOutside As System.Boolean, _
    ByVal Value1 As System.Double, _
    ByVal Value2 As System.Double, _
    ByVal ValueStr1 As System.String, _
    ByVal ValueStr2 As System.String, _
    ByVal ArrowsSmart As System.Boolean, _
    ByVal ArrowStyle As System.Short, _
    ByVal LeaderLineStyle As System.Short, _
    ByVal LeaderBent As System.Boolean, _
    ByVal ShowArea As System.Boolean, _
    ByVal ShowSymbol As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim Datum1 As System.String
Dim Datum2 As System.String
Dim Datum3 As System.String
Dim AreaStyle As System.Short
Dim AreaOutside As System.Boolean
Dim Value1 As System.Double
Dim Value2 As System.Double
Dim ValueStr1 As System.String
Dim ValueStr2 As System.String
Dim ArrowsSmart As System.Boolean
Dim ArrowStyle As System.Short
Dim LeaderLineStyle As System.Short
Dim LeaderBent As System.Boolean
Dim ShowArea As System.Boolean
Dim ShowSymbol As System.Boolean
Dim value As System.Boolean

```

```

value = instance.InsertDatumTargetSymbol(Datum1, Datum2, Datum3, AreaStyle, AreaOutside, Value1,
Value2, ValueStr1, ValueStr2, ArrowsSmart, ArrowStyle, LeaderLineStyle, LeaderBent, ShowArea,
ShowSymbol)

```

C#

```

System.bool InsertDatumTargetSymbol(
    System.string Datum1,
    System.string Datum2,
    System.string Datum3,
    System.short AreaStyle,
    System.bool AreaOutside,
    System.double Value1,
    System.double Value2,
    System.string ValueStr1,
    System.string ValueStr2,
    System.bool ArrowsSmart,
    System.short ArrowStyle,
    System.short LeaderLineStyle,
    System.bool LeaderBent,
    System.bool ShowArea,
    System.bool ShowSymbol
)

```

C++/CLI

```

System.bool InsertDatumTargetSymbol(
& System.String^ Datum1,
& System.String^ Datum2,
& System.String^ Datum3,
& System.short AreaStyle,
& System.bool AreaOutside,
& System.double Value1,
& System.double Value2,
& System.String^ ValueStr1,
& System.String^ ValueStr2,
& System.bool ArrowsSmart,
& System.short ArrowStyle,
& System.short LeaderLineStyle,
& System.bool LeaderBent,
& System.bool ShowArea,
& System.bool ShowSymbol
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Datum1

Datum2

Datum3

AreaStyle
AreaOutside
Value1
Value2
ValueStr1
ValueStr2
ArrowsSmart
ArrowStyle
LeaderLineStyle
LeaderBent
ShowArea
ShowSymbol

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertDatumTargetSymbol](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertDeleteFace Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertDeleteFace Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertDeleteFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertDeleteFace()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertDeleteFace()
```

C#

```
void InsertDeleteFace()
```

C++/CLI

```
void InsertDeleteFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertDeleteFace](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertDeleteHole Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertDeleteHole Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertDeleteHole](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertDeleteHole()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertDeleteHole()
```

C#

```
void InsertDeleteHole()
```

C++/CLI

```
void InsertDeleteHole();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertDeleteHole](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertDome Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertDome Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertDome](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertDome( _  
    ByVal Height As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal DoEllipticSurface As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Height As System.Double  
Dim ReverseDir As System.Boolean  
Dim DoEllipticSurface As System.Boolean  
  
instance.InsertDome(Height, ReverseDir, DoEllipticSurface)
```

C#

```
void InsertDome(  
    System.double Height,  
    System.bool ReverseDir,
```

```
        System.bool DoEllipticSurface
    )
```

C++/CLI

```
void InsertDome(
&    System.double Height,
&    System.bool ReverseDir,
&    System.bool DoEllipticSurface
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Height

ReverseDir

DoEllipticSurface

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertDome](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertExtendSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertExtendSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertExtendSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertExtendSurface( _
    ByVal ExtendLinear As System.Boolean, _
    ByVal EndCondition As System.Integer, _
    ByVal Distance As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim ExtendLinear As System.Boolean
Dim EndCondition As System.Integer
Dim Distance As System.Double
```

```
instance.InsertExtendSurface(ExtendLinear, EndCondition, Distance)
```

C#

```
void InsertExtendSurface(
    System.bool ExtendLinear,
    System.int EndCondition,
    System.double Distance
)
```

C++/CLI

```
void InsertExtendSurface(
&    System.bool ExtendLinear,
&    System.int EndCondition,
```



```
& System.double Distance
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExtendLinear

EndCondition

Distance

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertExtendSurface](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertFamilyTableEdit Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertFamilyTableEdit Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertFamilyTableEdit](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertFamilyTableEdit()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.InsertFamilyTableEdit()
```

C#

```
void InsertFamilyTableEdit()
```

C++/CLI

```
void InsertFamilyTableEdit();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertFamilyTableEdit](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertFamilyTableNew Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertFamilyTableNew Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertFamilyTableNew](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertFamilyTableNew()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertFamilyTableNew()
```

C#

```
void InsertFamilyTableNew()
```

C++/CLI

```
void InsertFamilyTableNew();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertFamilyTableNew](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertFamilyTableOpen Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertFamilyTableOpen Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertFamilyTableOpen](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertFamilyTableOpen( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.InsertFamilyTableOpen(FileName)
```

C#

```
System.bool InsertFamilyTableOpen(  
    System.string FileName  
)
```

C++/CLI

```
System.bool InsertFamilyTableOpen(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertFamilyTableOpen](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertFeatureShell Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertFeatureShell Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertFeatureShell](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertFeatureShell( _  
    ByVal Thickness As System.Double, _  
    ByVal Outward As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Thickness As System.Double  
Dim Outward As System.Boolean  
  
instance.InsertFeatureShell(Thickness, Outward)
```

C#

```
void InsertFeatureShell(  
    System.double Thickness,  
    System.bool Outward  
)
```

C++/CLI

```
void InsertFeatureShell(  
& System.double Thickness,  
& System.bool Outward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Outward

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertFeatureShell](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertFeatureShellAddThickness Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertFeatureShellAddThickness Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertFeatureShellAddThickness](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertFeatureShellAddThickness( _  
    ByVal Thickness As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Thickness As System.Double  
  
instance.InsertFeatureShellAddThickness(Thickness)
```

C#

```
void InsertFeatureShellAddThickness(  
    System.double Thickness  
)
```

C++/CLI

```
void InsertFeatureShellAddThickness(  
& System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertFeatureShellAddThickness](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertFramePoint Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertFramePoint Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertFramePoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertFramePoint( _  
    ByVal Xx As System.Double, _  
    ByVal Yy As System.Double, _  
    ByVal Zz As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Xx As System.Double
```

```
Dim Yy As System.Double
Dim Zz As System.Double

instance.InsertFramePoint(Xx, Yy, Zz)
```

C#

```
void InsertFramePoint(
    System.double Xx,
    System.double Yy,
    System.double Zz
)
```

C++/CLI

```
void InsertFramePoint(
    & System.double Xx,
    & System.double Yy,
    & System.double Zz
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Xx

Yy

Zz

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertFramePoint](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertGtol Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertGtol Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertGtol](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertGtol() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As System.Object

value = instance.InsertGtol()
```

C#

```
System.object InsertGtol()
```

C++/CLI

```
System.Object^ InsertGtol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertGtol](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertHatchedFace Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertHatchedFace Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertHatchedFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertHatchedFace()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertHatchedFace()
```

C#

```
void InsertHatchedFace()
```

C++/CLI

```
void InsertHatchedFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertHatchedFace](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertHelix Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertHelix Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertHelix](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertHelix( _  
    ByVal Reversed As System.Boolean, _  
    ByVal Clockwised As System.Boolean, _  
    ByVal Tapered As System.Boolean, _  
    ByVal Outward As System.Boolean, _  
    ByVal Helixdef As System.Integer, _  
    ByVal Height As System.Double, _  
    ByVal Pitch As System.Double, _
```

```

    ByVal Revolution As System.Double, _
    ByVal TaperAngle As System.Double, _
    ByVal Startangle As System.Double _
)

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim Reversed As System.Boolean
Dim Clockwised As System.Boolean
Dim Tapered As System.Boolean
Dim Outward As System.Boolean
Dim Helixdef As System.Integer
Dim Height As System.Double
Dim Pitch As System.Double
Dim Revolution As System.Double
Dim TaperAngle As System.Double
Dim Startangle As System.Double

```

```

instance.InsertHelix(Reversed, Clockwised, Tapered, Outward, Helixdef, Height, Pitch, Revolution,
TaperAngle, Startangle)

```

C#

```

void InsertHelix(
    System.bool Reversed,
    System.bool Clockwised,
    System.bool Tapered,
    System.bool Outward,
    System.int Helixdef,
    System.double Height,
    System.double Pitch,
    System.double Revolution,
    System.double TaperAngle,
    System.double Startangle
)

```

C++/CLI

```

void InsertHelix(
& System.bool Reversed,
& System.bool Clockwised,
& System.bool Tapered,
& System.bool Outward,
& System.int Helixdef,
& System.double Height,
& System.double Pitch,
& System.double Revolution,
& System.double TaperAngle,
& System.double Startangle
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Reversed

Clockwised

Tapered

Outward

Helixdef

Height

Pitch

Revolution

TaperAngle

Startangle

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertHelix](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertLibraryFeature Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertLibraryFeature Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertLibraryFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertLibraryFeature( _  
    ByVal LibFeatPartNameIn As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim LibFeatPartNameIn As System.String  
  
instance.InsertLibraryFeature(LibFeatPartNameIn)
```

C#

```
void InsertLibraryFeature(  
    System.string LibFeatPartNameIn  
)
```

C++/CLI

```
void InsertLibraryFeature(  
& System.String^ LibFeatPartNameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LibFeatPartNameIn

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertLibraryFeature](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)