

SOLIDWORKS API (.NET VBA C#) — Reference (173/337): IModelDoc (part 9 of 13)

SOLIDWORKS API Documentation (converted from CHM)

IModelDoc (part 9 of 13) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertLoftRefSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertLoftRefSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertLoftRefSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertLoftRefSurface( _  
    ByVal Closed As System.Boolean, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
  
instance.InsertLoftRefSurface(Closed, KeepTangency, ForceNonRational)
```

C#

```
void InsertLoftRefSurface(  
    System.bool Closed,  
    System.bool KeepTangency,  
    System.bool ForceNonRational  
)
```

C++/CLI

```
void InsertLoftRefSurface(  
& System.bool Closed,  
& System.bool KeepTangency,  
& System.bool ForceNonRational  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

KeepTangency

ForceNonRational

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertLoftRefSurface](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertLoftRefSurface2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertLoftRefSurface2 Method (IModelDoc)

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertLoftRefSurface2( _  
    ByVal Closed As System.Boolean, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean, _  
    ByVal TessToleranceFactor As System.Double, _  
    ByVal StartMatchingType As System.Short, _  
    ByVal EndMatchingType As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
Dim TessToleranceFactor As System.Double  
Dim StartMatchingType As System.Short  
Dim EndMatchingType As System.Short  
  
instance.InsertLoftRefSurface2(Closed, KeepTangency, ForceNonRational, TessToleranceFactor,  
StartMatchingType, EndMatchingType)
```

C#

```
void InsertLoftRefSurface2(  
    System.bool Closed,  
    System.bool KeepTangency,  
    System.bool ForceNonRational,  
    System.double TessToleranceFactor,  
    System.short StartMatchingType,  
    System.short EndMatchingType  
)
```

C++/CLI

```
void InsertLoftRefSurface2(  
& System.bool Closed,  
& System.bool KeepTangency,  
& System.bool ForceNonRational,  
& System.double TessToleranceFactor,  
& System.short StartMatchingType,  
& System.short EndMatchingType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

KeepTangency

ForceNonRational

TessToleranceFactor

StartMatchingType

EndMatchingType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertLoftRefSurface2](#).

See Also

InsertMfDraft Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertMfDraft Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertMfDraft](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertMfDraft( _  
    ByVal Angle As System.Double, _  
    ByVal FlipDir As System.Boolean, _  
    ByVal IsEdgeDraft As System.Boolean, _  
    ByVal PropType As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Angle As System.Double  
Dim FlipDir As System.Boolean  
Dim IsEdgeDraft As System.Boolean  
Dim PropType As System.Integer  
  
instance.InsertMfDraft(Angle, FlipDir, IsEdgeDraft, PropType)
```

C#

```
void InsertMfDraft(  
    System.double Angle,  
    System.bool FlipDir,  
    System.bool IsEdgeDraft,  
    System.int PropType  
)
```

C++/CLI

```
void InsertMfDraft(  
& System.double Angle,  
& System.bool FlipDir,  
& System.bool IsEdgeDraft,  
& System.int PropType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

FlipDir

IsEdgeDraft

PropType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertMfDraft](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

InsertMfDraft2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertMfDraft2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertMfDraft2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertMfDraft2( _  
    ByVal Angle As System.Double, _  
    ByVal FlipDir As System.Boolean, _  
    ByVal IsEdgeDraft As System.Boolean, _  
    ByVal PropType As System.Integer, _  
    ByVal StepDraft As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Angle As System.Double  
Dim FlipDir As System.Boolean  
Dim IsEdgeDraft As System.Boolean  
Dim PropType As System.Integer  
Dim StepDraft As System.Boolean  
  
instance.InsertMfDraft2(Angle, FlipDir, IsEdgeDraft, PropType, StepDraft)
```

C#

```
void InsertMfDraft2(  
    System.double Angle,  
    System.bool FlipDir,  
    System.bool IsEdgeDraft,  
    System.int PropType,  
    System.bool StepDraft  
)
```

C++/CLI

```
void InsertMfDraft2(  
& System.double Angle,  
& System.bool FlipDir,  
& System.bool IsEdgeDraft,  
& System.int PropType,  
& System.bool StepDraft  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

FlipDir

IsEdgeDraft

PropType

StepDraft

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertMfDraft2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

InsertMidSurfaceExt Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertMidSurfaceExt Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertMidSurfaceExt](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertMidSurfaceExt( _  
    ByVal Placement As System.Double, _  
    ByVal KnitFlag As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Placement As System.Double  
Dim KnitFlag As System.Boolean  
Dim value As System.Object
```

```
value = instance.InsertMidSurfaceExt(Placement, KnitFlag)
```

C#

```
System.object InsertMidSurfaceExt(  
    System.double Placement,  
    System.bool KnitFlag  
)
```

C++/CLI

```
System.Object^ InsertMidSurfaceExt(  
& System.double Placement,  
& System.bool KnitFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Placement

KnitFlag

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertMidSurfaceExt](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

InsertNewNote3 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertNewNote3 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertNewNote3](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub InsertNewNote3( _
    ByVal UpperText As System.String, _
    ByVal NoLeader As System.Boolean, _
    ByVal BentLeader As System.Boolean, _
    ByVal ArrowStyle As System.Short, _
    ByVal LeaderSide As System.Short, _
    ByVal Angle As System.Double, _
    ByVal BalloonStyle As System.Short, _
    ByVal BalloonFit As System.Short, _
    ByVal SmartArrow As System.Boolean _
)

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim UpperText As System.String
Dim NoLeader As System.Boolean
Dim BentLeader As System.Boolean
Dim ArrowStyle As System.Short
Dim LeaderSide As System.Short
Dim Angle As System.Double
Dim BalloonStyle As System.Short
Dim BalloonFit As System.Short
Dim SmartArrow As System.Boolean

```

```

instance.InsertNewNote3(UpperText, NoLeader, BentLeader, ArrowStyle, LeaderSide, Angle,
BalloonStyle, BalloonFit, SmartArrow)

```

C#

```

void InsertNewNote3(
    System.string UpperText,
    System.bool NoLeader,
    System.bool BentLeader,
    System.short ArrowStyle,
    System.short LeaderSide,
    System.double Angle,
    System.short BalloonStyle,
    System.short BalloonFit,
    System.bool SmartArrow
)

```

C++/CLI

```

void InsertNewNote3(
    & System.String^ UpperText,
    & System.bool NoLeader,
    & System.bool BentLeader,
    & System.short ArrowStyle,
    & System.short LeaderSide,
    & System.double Angle,
    & System.short BalloonStyle,
    & System.short BalloonFit,
    & System.bool SmartArrow
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UpperText

NoLeader

BentLeader

ArrowStyle

LeaderSide

Angle

BalloonStyle

BalloonFit

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertNewNote3](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertNote Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertNote Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertNote](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertNote( _  
    ByVal Text As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Text As System.String  
Dim value As System.Object  
  
value = instance.InsertNote(Text)
```

C#

```
System.object InsertNote(  
    System.string Text  
)
```

C++/CLI

```
System.Object^ InsertNote(  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertNote](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertObject Method (IModelDoc)

[See Also](#)



Obsolete. Superseded by [IModelDoc2::InsertObject](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertObject()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertObject()
```

C#

```
void InsertObject()
```

C++/CLI

```
void InsertObject();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertObject](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertObjectFromFile Method (IModelDoc)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [IModelDoc Interface](#) : InsertObjectFromFile Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertObjectFromFile](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertObjectFromFile( _  
    ByVal FilePath As System.String, _  
    ByVal CreateLink As System.Boolean, _  
    ByVal Xx As System.Double, _  
    ByVal Yy As System.Double, _  
    ByVal Zz As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim FilePath As System.String  
Dim CreateLink As System.Boolean  
Dim Xx As System.Double  
Dim Yy As System.Double  
Dim Zz As System.Double  
Dim value As System.Boolean
```

```
value = instance.InsertObjectFromFile(FilePath, CreateLink, Xx, Yy, Zz)
```

C#

```
System.bool InsertObjectFromFile(
    System.string FilePath,
    System.bool CreateLink,
    System.double Xx,
    System.double Yy,
    System.double Zz
)
```

C++/CLI

```
System.bool InsertObjectFromFile(
    & System.String^ FilePath,
    & System.bool CreateLink,
    & System.double Xx,
    & System.double Yy,
    & System.double Zz
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePath

CreateLink

Xx

Yy

Zz

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertObjectFromFile](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertOffsetSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertOffsetSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertOffsetSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertOffsetSurface( _
    ByVal Thickness As System.Double, _
    ByVal Reverse As System.Boolean _
)
```

Visual Basic (Usage)

```
Dim instance As IModelDoc
Dim Thickness As System.Double
Dim Reverse As System.Boolean

instance.InsertOffsetSurface(Thickness, Reverse)
```

C#

```
void InsertOffsetSurface(
    System.double Thickness,
```



```
        System.bool Reverse
    )
```

C++/CLI

```
void InsertOffsetSurface(
&    System.double Thickness,
&    System.bool Reverse
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Reverse

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertOffsetSurface](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertPlanarRefSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertPlanarRefSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertPlanarRefSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertPlanarRefSurface() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As System.Boolean
```

```
value = instance.InsertPlanarRefSurface()
```

C#

```
System.bool InsertPlanarRefSurface()
```

C++/CLI

```
System.bool InsertPlanarRefSurface();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertPlanarRefSurface](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertPoint Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertPoint Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertPoint()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertPoint()
```

C#

```
void InsertPoint()
```

C++/CLI

```
void InsertPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertPoint](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertProjectedSketch Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProjectedSketch Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProjectedSketch](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProjectedSketch()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertProjectedSketch()
```

C#

```
void InsertProjectedSketch()
```

C++/CLI

```
void InsertProjectedSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertProjectedSketch](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertProjectedSketch2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProjectedSketch2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProjectedSketch2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertProjectedSketch2( _  
    ByVal Reverse As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Reverse As System.Integer  
Dim value As System.Object  
  
value = instance.InsertProjectedSketch2(Reverse)
```

C#

```
System.object InsertProjectedSketch2(  
    System.int Reverse  
)
```

C++/CLI

```
System.Object^ InsertProjectedSketch2(  
    & System.int Reverse  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Reverse

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertProjectedSketch2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertProtrusionBlend Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProtrusionBlend Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProtrusionBlend](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProtrusionBlend( _  
    ByVal Closed As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
  
instance.InsertProtrusionBlend(Closed)
```

C#

```
void InsertProtrusionBlend(  
    System.bool Closed  
)
```

C++/CLI

```
void InsertProtrusionBlend(  
&    System.bool Closed  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertProtrusionBlend](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertProtrusionBlend2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProtrusionBlend2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProtrusionBlend2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProtrusionBlend2( _  
    ByVal Closed As System.Boolean, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
  
instance.InsertProtrusionBlend2(Closed, KeepTangency, ForceNonRational)
```

C#

```
void InsertProtrusionBlend2(  
    System.bool Closed,  
    System.bool KeepTangency,  
    System.bool ForceNonRational  
)
```

C++/CLI

```
void InsertProtrusionBlend2(  
& System.bool Closed,  
& System.bool KeepTangency,  
& System.bool ForceNonRational  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

KeepTangency

ForceNonRational

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertProtrusionBlend2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertProtrusionBlend3 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProtrusionBlend3 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProtrusionBlend3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProtrusionBlend3( _  
    ByVal Closed As System.Boolean, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean, _  
    ByVal TessToleranceFactor As System.Double, _  
    ByVal StartMatchingType As System.Short, _  
    ByVal EndMatchingType As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Closed As System.Boolean  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
Dim TessToleranceFactor As System.Double  
Dim StartMatchingType As System.Short  
Dim EndMatchingType As System.Short
```

```
instance.InsertProtrusionBlend3(Closed, KeepTangency, ForceNonRational, TessToleranceFactor,  
StartMatchingType, EndMatchingType)
```

C#

```
void InsertProtrusionBlend3(
    System.bool Closed,
    System.bool KeepTangency,
    System.bool ForceNonRational,
    System.double TessToleranceFactor,
    System.short StartMatchingType,
    System.short EndMatchingType
)
```

C++/CLI

```
void InsertProtrusionBlend3(
    & System.bool Closed,
    & System.bool KeepTangency,
    & System.bool ForceNonRational,
    & System.double TessToleranceFactor,
    & System.short StartMatchingType,
    & System.short EndMatchingType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

KeepTangency

ForceNonRational

TessToleranceFactor

StartMatchingType

EndMatchingType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertProtrusionBlend3](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertProtrusionBlend4 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProtrusionBlend4 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProtrusionBlend4](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProtrusionBlend4( _
    ByVal Closed As System.Boolean, _
    ByVal KeepTangency As System.Boolean, _
    ByVal ForceNonRational As System.Boolean, _
    ByVal TessToleranceFactor As System.Double, _
    ByVal StartMatchingType As System.Short, _
    ByVal EndMatchingType As System.Short, _
    ByVal IsThinBody As System.Boolean, _
    ByVal Thickness1 As System.Double, _
    ByVal Thickness2 As System.Double, _
    ByVal ThinType As System.Short _
)
```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim Closed As System.Boolean
Dim KeepTangency As System.Boolean
Dim ForceNonRational As System.Boolean
Dim TessToleranceFactor As System.Double
Dim StartMatchingType As System.Short
Dim EndMatchingType As System.Short
Dim IsThinBody As System.Boolean
Dim Thickness1 As System.Double
Dim Thickness2 As System.Double
Dim ThinType As System.Short

```

```

instance.InsertProtrusionBlend4(Closed, KeepTangency, ForceNonRational, TessToleranceFactor,
StartMatchingType, EndMatchingType, IsThinBody, Thickness1, Thickness2, ThinType)

```

C#

```

void InsertProtrusionBlend4(
    System.bool Closed,
    System.bool KeepTangency,
    System.bool ForceNonRational,
    System.double TessToleranceFactor,
    System.short StartMatchingType,
    System.short EndMatchingType,
    System.bool IsThinBody,
    System.double Thickness1,
    System.double Thickness2,
    System.short ThinType
)

```

C++/CLI

```

void InsertProtrusionBlend4(
    & System.bool Closed,
    & System.bool KeepTangency,
    & System.bool ForceNonRational,
    & System.double TessToleranceFactor,
    & System.short StartMatchingType,
    & System.short EndMatchingType,
    & System.bool IsThinBody,
    & System.double Thickness1,
    & System.double Thickness2,
    & System.short ThinType
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Closed

KeepTangency

ForceNonRational

TessToleranceFactor

StartMatchingType

EndMatchingType

IsThinBody

Thickness1

Thickness2

ThinType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertProtrusionBlend4](#).

See Also

InsertProtrusionSwept Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProtrusionSwept Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProtrusionSwept](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProtrusionSwept( _  
    ByVal Propagate As System.Boolean, _  
    ByVal Alignment As System.Boolean, _  
    ByVal KeepNormalConstant As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Propagate As System.Boolean  
Dim Alignment As System.Boolean  
Dim KeepNormalConstant As System.Boolean  
  
instance.InsertProtrusionSwept(Propagate, Alignment, KeepNormalConstant)
```

C#

```
void InsertProtrusionSwept(  
    System.bool Propagate,  
    System.bool Alignment,  
    System.bool KeepNormalConstant  
)
```

C++/CLI

```
void InsertProtrusionSwept(  
& System.bool Propagate,  
& System.bool Alignment,  
& System.bool KeepNormalConstant  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

Alignment

KeepNormalConstant

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertProtrusionSwept](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

InsertProtrusionSwept2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProtrusionSwept2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProtrusionSwept2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProtrusionSwept2( _  
    ByVal Propagate As System.Boolean, _  
    ByVal Alignment As System.Boolean, _  
    ByVal TwistCtrlOption As System.Short, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Propagate As System.Boolean  
Dim Alignment As System.Boolean  
Dim TwistCtrlOption As System.Short  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
  
instance.InsertProtrusionSwept2(Propagate, Alignment, TwistCtrlOption, KeepTangency,  
ForceNonRational)
```

C#

```
void InsertProtrusionSwept2(  
    System.bool Propagate,  
    System.bool Alignment,  
    System.short TwistCtrlOption,  
    System.bool KeepTangency,  
    System.bool ForceNonRational  
)
```

C++/CLI

```
void InsertProtrusionSwept2(  
& System.bool Propagate,  
& System.bool Alignment,  
& System.short TwistCtrlOption,  
& System.bool KeepTangency,  
& System.bool ForceNonRational  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

Alignment

TwistCtrlOption

KeepTangency

ForceNonRational

Visual Basic for Applications (VBA) Syntax

See [ModelDoc.InsertProtrusionSwept2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

Obsolete. Superseded by [IModelDoc2::InsertProtrusionSwept3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProtrusionSwept3( _
    ByVal Propagate As System.Boolean, _
    ByVal Alignment As System.Boolean, _
    ByVal TwistCtrlOption As System.Short, _
    ByVal KeepTangency As System.Boolean, _
    ByVal ForceNonRational As System.Boolean, _
    ByVal StartMatchingType As System.Short, _
    ByVal EndMatchingType As System.Short _
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim Propagate As System.Boolean
Dim Alignment As System.Boolean
Dim TwistCtrlOption As System.Short
Dim KeepTangency As System.Boolean
Dim ForceNonRational As System.Boolean
Dim StartMatchingType As System.Short
Dim EndMatchingType As System.Short

instance.InsertProtrusionSwept3(Propagate, Alignment, TwistCtrlOption, KeepTangency,
ForceNonRational, StartMatchingType, EndMatchingType)
```

C#

```
void InsertProtrusionSwept3(
    System.bool Propagate,
    System.bool Alignment,
    System.short TwistCtrlOption,
    System.bool KeepTangency,
    System.bool ForceNonRational,
    System.short StartMatchingType,
    System.short EndMatchingType
)
```

C++/CLI

```
void InsertProtrusionSwept3(
    & System.bool Propagate,
    & System.bool Alignment,
    & System.short TwistCtrlOption,
    & System.bool KeepTangency,
    & System.bool ForceNonRational,
    & System.short StartMatchingType,
    & System.short EndMatchingType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

Alignment

TwistCtrlOption

KeepTangency

ForceNonRational

StartMatchingType

EndMatchingType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::InsertProtrusionSwept3](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertProtrusionSwept4 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertProtrusionSwept4 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertProtrusionSwept4](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertProtrusionSwept4( _  
    ByVal Propagate As System.Boolean, _  
    ByVal Alignment As System.Boolean, _  
    ByVal TwistCtrlOption As System.Short, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean, _  
    ByVal StartMatchingType As System.Short, _  
    ByVal EndMatchingType As System.Short, _  
    ByVal IsThinBody As System.Boolean, _  
    ByVal Thickness1 As System.Double, _  
    ByVal Thickness2 As System.Double, _  
    ByVal ThinType As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Propagate As System.Boolean  
Dim Alignment As System.Boolean  
Dim TwistCtrlOption As System.Short  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
Dim StartMatchingType As System.Short  
Dim EndMatchingType As System.Short  
Dim IsThinBody As System.Boolean  
Dim Thickness1 As System.Double  
Dim Thickness2 As System.Double  
Dim ThinType As System.Short
```

```
instance.InsertProtrusionSwept4(Propagate, Alignment, TwistCtrlOption, KeepTangency,  
ForceNonRational, StartMatchingType, EndMatchingType, IsThinBody, Thickness1, Thickness2,  
ThinType)
```

C#

```
void InsertProtrusionSwept4(  
    System.bool Propagate,  
    System.bool Alignment,  
    System.short TwistCtrlOption,  
    System.bool KeepTangency,  
    System.bool ForceNonRational,  
    System.short StartMatchingType,  
    System.short EndMatchingType,  
    System.bool IsThinBody,  
    System.double Thickness1,  
    System.double Thickness2,
```

```
System.short ThinType  
)
```

C++/CLI

```
void InsertProtrusionSwept4(  
& System.bool Propagate,  
& System.bool Alignment,  
& System.short TwistCtrlOption,  
& System.bool KeepTangency,  
& System.bool ForceNonRational,  
& System.short StartMatchingType,  
& System.short EndMatchingType,  
& System.bool IsThinBody,  
& System.double Thickness1,  
& System.double Thickness2,  
& System.short ThinType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

Alignment

TwistCtrlOption

KeepTangency

ForceNonRational

StartMatchingType

EndMatchingType

IsThinBody

Thickness1

Thickness2

ThinType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertProtrusionSwept4](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRadiateSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertRadiateSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertRadiateSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertRadiateSurface( _  
    ByVal Distance As System.Double, _  
    ByVal FlipDir As System.Boolean, _  
    ByVal TangentPropagate As System.Boolean _  
)
```

Visual Basic (Usage)

```
Dim instance As IModelDoc  
Dim Distance As System.Double
```



```
Dim FlipDir As System.Boolean
Dim TangentPropagate As System.Boolean

instance.InsertRadiateSurface(Distance, FlipDir, TangentPropagate)
```

C#

```
void InsertRadiateSurface(
    System.double Distance,
    System.bool FlipDir,
    System.bool TangentPropagate
)
```

C++/CLI

```
void InsertRadiateSurface(
    & System.double Distance,
    & System.bool FlipDir,
    & System.bool TangentPropagate
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Distance

FlipDir

TangentPropagate

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertRadiateSurface](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRefPoint Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertRefPoint Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertRefPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertRefPoint() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As System.Boolean

value = instance.InsertRefPoint()
```

C#

```
System.bool InsertRefPoint()
```

C++/CLI

```
System.bool InsertRefPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertRefPoint](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertRevolvedRefSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertRevolvedRefSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertRevolvedRefSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertRevolvedRefSurface( _  
    ByVal Angle As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal Angle2 As System.Double, _  
    ByVal RevType As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Angle As System.Double  
Dim ReverseDir As System.Boolean  
Dim Angle2 As System.Double  
Dim RevType As System.Integer  
  
instance.InsertRevolvedRefSurface(Angle, ReverseDir, Angle2, RevType)
```

C#

```
void InsertRevolvedRefSurface(  
    System.double Angle,  
    System.bool ReverseDir,  
    System.double Angle2,  
    System.int RevType  
)
```

C++/CLI

```
void InsertRevolvedRefSurface(  
& System.double Angle,  
& System.bool ReverseDir,  
& System.double Angle2,  
& System.int RevType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

ReverseDir

Angle2

RevType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertRevolvedRefSurface](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertRib Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertRib Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertRib](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertRib( _  
    ByVal Is2Sided As System.Boolean, _  
    ByVal ReverseThicknessDir As System.Boolean, _  
    ByVal Thickness As System.Double, _  
    ByVal ReferenceEdgeIndex As System.Integer, _  
    ByVal ReverseMaterialDir As System.Boolean, _  
    ByVal IsDrafted As System.Boolean, _  
    ByVal DraftOutward As System.Boolean, _  
    ByVal DraftAngle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Is2Sided As System.Boolean  
Dim ReverseThicknessDir As System.Boolean  
Dim Thickness As System.Double  
Dim ReferenceEdgeIndex As System.Integer  
Dim ReverseMaterialDir As System.Boolean  
Dim IsDrafted As System.Boolean  
Dim DraftOutward As System.Boolean  
Dim DraftAngle As System.Double  
  
instance.InsertRib(Is2Sided, ReverseThicknessDir, Thickness, ReferenceEdgeIndex,  
ReverseMaterialDir, IsDrafted, DraftOutward, DraftAngle)
```

C#

```
void InsertRib(  
    System.bool Is2Sided,  
    System.bool ReverseThicknessDir,  
    System.double Thickness,  
    System.int ReferenceEdgeIndex,  
    System.bool ReverseMaterialDir,  
    System.bool IsDrafted,  
    System.bool DraftOutward,  
    System.double DraftAngle  
)
```

C++/CLI

```

void InsertRib(
& System.bool Is2Sided,
& System.bool ReverseThicknessDir,
& System.double Thickness,
& System.int ReferenceEdgeIndex,
& System.bool ReverseMaterialDir,
& System.bool IsDrafted,
& System.bool DraftOutward,
& System.double DraftAngle
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Is2Sided

ReverseThicknessDir

Thickness

ReferenceEdgeIndex

ReverseMaterialDir

IsDrafted

DraftOutward

DraftAngle

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertRib](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertRib2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertRib2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertRib2](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub InsertRib2( _
    ByVal Is2Sided As System.Boolean, _
    ByVal ReverseThicknessDir As System.Boolean, _
    ByVal Thickness As System.Double, _
    ByVal ReferenceEdgeIndex As System.Integer, _
    ByVal ReverseMaterialDir As System.Boolean, _
    ByVal IsDrafted As System.Boolean, _
    ByVal DraftOutward As System.Boolean, _
    ByVal DraftAngle As System.Double, _
    ByVal IsNormToSketch As System.Boolean _
)

```

Visual Basic (Usage)

```

Dim instance As IModelDoc
Dim Is2Sided As System.Boolean
Dim ReverseThicknessDir As System.Boolean
Dim Thickness As System.Double
Dim ReferenceEdgeIndex As System.Integer
Dim ReverseMaterialDir As System.Boolean
Dim IsDrafted As System.Boolean

```



```
Dim DraftOutward As System.Boolean
Dim DraftAngle As System.Double
Dim IsNormToSketch As System.Boolean
```

```
instance.InsertRib2(Is2Sided, ReverseThicknessDir, Thickness, ReferenceEdgeIndex,
ReverseMaterialDir, IsDrafted, DraftOutward, DraftAngle, IsNormToSketch)
```

C#

```
void InsertRib2(
    System.bool Is2Sided,
    System.bool ReverseThicknessDir,
    System.double Thickness,
    System.int ReferenceEdgeIndex,
    System.bool ReverseMaterialDir,
    System.bool IsDrafted,
    System.bool DraftOutward,
    System.double DraftAngle,
    System.bool IsNormToSketch
)
```

C++/CLI

```
void InsertRib2(
    & System.bool Is2Sided,
    & System.bool ReverseThicknessDir,
    & System.double Thickness,
    & System.int ReferenceEdgeIndex,
    & System.bool ReverseMaterialDir,
    & System.bool IsDrafted,
    & System.bool DraftOutward,
    & System.double DraftAngle,
    & System.bool IsNormToSketch
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Is2Sided

ReverseThicknessDir

Thickness

ReferenceEdgeIndex

ReverseMaterialDir

IsDrafted

DraftOutward

DraftAngle

IsNormToSketch

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertRib2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertRoutePoint Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertRoutePoint Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertRoutePoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertRoutePoint()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InsertRoutePoint()
```

C#

```
void InsertRoutePoint()
```

C++/CLI

```
void InsertRoutePoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertRoutePoint](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertScale Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertScale Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertScale](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertScale( _  
    ByVal ScaleFactor\_x As System.Double, _  
    ByVal ScaleFactor\_y As System.Double, _  
    ByVal ScaleFactor\_z As System.Double, _  
    ByVal IsUniform As System.Boolean, _  
    ByVal ScaleType As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim ScaleFactor_x As System.Double  
Dim ScaleFactor_y As System.Double  
Dim ScaleFactor_z As System.Double  
Dim IsUniform As System.Boolean  
Dim ScaleType As System.Integer  
  
instance.InsertScale(ScaleFactor_x, ScaleFactor_y, ScaleFactor_z, IsUniform, ScaleType)
```

C#

```
void InsertScale(
    System.double ScaleFactor\_x,
    System.double ScaleFactor\_y,
    System.double ScaleFactor\_z,
    System.bool IsUniform,
    System.int ScaleType
)
```

C++/CLI

```
void InsertScale(
    & System.double ScaleFactor\_x,
    & System.double ScaleFactor\_y,
    & System.double ScaleFactor\_z,
    & System.bool IsUniform,
    & System.int ScaleType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ScaleFactor_x

ScaleFactor_y

ScaleFactor_z

IsUniform

ScaleType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertScale](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertSewRefSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSewRefSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSewRefSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSewRefSurface()
```

Visual Basic (Usage)

```
Dim instance As IModelDoc
instance.InsertSewRefSurface()
```

C#

```
void InsertSewRefSurface()
```

C++/CLI

```
void InsertSewRefSurface();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).



Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSewRefSurface](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertSheetMetal3dBend Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSheetMetal3dBend Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSheetMetal3dBend](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSheetMetal3dBend( _  
    ByVal Angle As System.Double, _  
    ByVal Radius As System.Double, _  
    ByVal FlipDir As System.Boolean, _  
    ByVal BendPos As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Angle As System.Double  
Dim Radius As System.Double  
Dim FlipDir As System.Boolean  
Dim BendPos As System.Short
```

```
instance.InsertSheetMetal3dBend(Angle, Radius, FlipDir, BendPos)
```

C#

```
void InsertSheetMetal3dBend(  
    System.double Angle,  
    System.double Radius,  
    System.bool FlipDir,  
    System.short BendPos  
)
```

C++/CLI

```
void InsertSheetMetal3dBend(  
& System.double Angle,  
& System.double Radius,  
& System.bool FlipDir,  
& System.short BendPos  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

Radius

FlipDir

BendPos

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSheetMetal3dBend](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertSheetMetalBaseFlange Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSheetMetalBaseFlange Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSheetMetalBaseFlange](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSheetMetalBaseFlange( _  
    ByVal Thickness As System.Double, _  
    ByVal ThickenDir As System.Boolean, _  
    ByVal Radius As System.Double, _  
    ByVal ExtrudeDist1 As System.Double, _  
    ByVal ExtrudeDist2 As System.Double, _  
    ByVal FlipExtruDir As System.Boolean, _  
    ByVal EndCondition1 As System.Integer, _  
    ByVal EndCondition2 As System.Integer, _  
    ByVal DirToUse As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Thickness As System.Double  
Dim ThickenDir As System.Boolean  
Dim Radius As System.Double  
Dim ExtrudeDist1 As System.Double  
Dim ExtrudeDist2 As System.Double  
Dim FlipExtruDir As System.Boolean  
Dim EndCondition1 As System.Integer  
Dim EndCondition2 As System.Integer  
Dim DirToUse As System.Integer
```

```
instance.InsertSheetMetalBaseFlange(Thickness, ThickenDir, Radius, ExtrudeDist1, ExtrudeDist2,  
FlipExtruDir, EndCondition1, EndCondition2, DirToUse)
```

C#

```
void InsertSheetMetalBaseFlange(  
    System.double Thickness,  
    System.bool ThickenDir,  
    System.double Radius,  
    System.double ExtrudeDist1,  
    System.double ExtrudeDist2,  
    System.bool FlipExtruDir,  
    System.int EndCondition1,  
    System.int EndCondition2,  
    System.int DirToUse  
)
```

C++/CLI

```
void InsertSheetMetalBaseFlange(  
& System.double Thickness,  
& System.bool ThickenDir,  
& System.double Radius,  
& System.double ExtrudeDist1,  
& System.double ExtrudeDist2,  
& System.bool FlipExtruDir,
```

```
& System.int EndCondition1,  
& System.int EndCondition2,  
& System.int DirToUse  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

ThickenDir

Radius

ExtrudeDist1

ExtrudeDist2

FlipExtruDir

EndCondition1

EndCondition2

DirToUse

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSheetMetalBaseFlange](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertSheetMetalClosedCorner Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSheetMetalClosedCorner Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSheetMetalClosedCorner](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSheetMetalClosedCorner()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.InsertSheetMetalClosedCorner()
```

C#

```
void InsertSheetMetalClosedCorner()
```

C++/CLI

```
void InsertSheetMetalClosedCorner();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSheetMetalClosedCorner](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

InsertSheetMetalFold Method (IModelDoc)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSheetMetalFold Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSheetMetalFold](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSheetMetalFold()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.InsertSheetMetalFold()
```

C#

```
void InsertSheetMetalFold()
```

C++/CLI

```
void InsertSheetMetalFold();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSheetMetalFold](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

InsertSheetMetalMiterFlange Method (IModelDoc)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSheetMetalMiterFlange Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSheetMetalMiterFlange](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSheetMetalMiterFlange( _  
    ByVal UseReliefRatio As System.Boolean, _  
    ByVal UseDefaultGap As System.Boolean, _  
    ByVal UseAutoRelief As System.Boolean, _  
    ByVal GlobalRadius As System.Double, _  
    ByVal RipGap As System.Double, _  
    ByVal AutoReliefRatio As System.Double, _  
    ByVal AutoReliefWidth As System.Double, _  
    ByVal AutoReliefDepth As System.Double, _  
    ByVal ReliefType As System.Integer, _  
    ByVal RipLocation As System.Integer, _  
    ByVal TrimSideBends As System.Boolean _  
)
```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim UseReliefRatio As System.Boolean
Dim UseDefaultGap As System.Boolean
Dim UseAutoRelief As System.Boolean
Dim GlobalRadius As System.Double
Dim RipGap As System.Double
Dim AutoReliefRatio As System.Double
Dim AutoReliefWidth As System.Double
Dim AutoReliefDepth As System.Double
Dim ReliefType As System.Integer
Dim RipLocation As System.Integer
Dim TrimSideBends As System.Boolean

```

```

instance.InsertSheetMetalMiterFlange(UseReliefRatio, UseDefaultGap, UseAutoRelief, GlobalRadius,
RipGap, AutoReliefRatio, AutoReliefWidth, AutoReliefDepth, ReliefType, RipLocation, TrimSideBends)

```

C#

```

void InsertSheetMetalMiterFlange(
    System.bool UseReliefRatio,
    System.bool UseDefaultGap,
    System.bool UseAutoRelief,
    System.double GlobalRadius,
    System.double RipGap,
    System.double AutoReliefRatio,
    System.double AutoReliefWidth,
    System.double AutoReliefDepth,
    System.int ReliefType,
    System.int RipLocation,
    System.bool TrimSideBends
)

```

C++/CLI

```

void InsertSheetMetalMiterFlange(
& System.bool UseReliefRatio,
& System.bool UseDefaultGap,
& System.bool UseAutoRelief,
& System.double GlobalRadius,
& System.double RipGap,
& System.double AutoReliefRatio,
& System.double AutoReliefWidth,
& System.double AutoReliefDepth,
& System.int ReliefType,
& System.int RipLocation,
& System.bool TrimSideBends
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseReliefRatio

UseDefaultGap

UseAutoRelief

GlobalRadius

RipGap

AutoReliefRatio

AutoReliefWidth

AutoReliefDepth

ReliefType

RipLocation

TrimSideBends

See [ModelDoc::InsertSheetMetalMiterFlange](#).

 See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertSheetMetalUnfold Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSheetMetalUnfold Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSheetMetalUnfold](#).

 .NET Syntax

Visual Basic (Declaration)

```
Sub InsertSheetMetalUnfold()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.InsertSheetMetalUnfold()
```

C#

```
void InsertSheetMetalUnfold()
```

C++/CLI

```
void InsertSheetMetalUnfold();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSheetMetalUnfold](#).

 See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertSketch Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSketch Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSketch](#).

 .NET Syntax

Visual Basic (Declaration)

```
Sub InsertSketch()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.InsertSketch()
```

C#

```
void InsertSketch()
```

C++/CLI

```
void InsertSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSketch](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertSketch2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSketch2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSketch2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSketch2( _  
    ByVal UpdateEditRebuild As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim UpdateEditRebuild As System.Boolean  
  
instance.InsertSketch2(UpdateEditRebuild)
```

C#

```
void InsertSketch2(  
    System.bool UpdateEditRebuild  
)
```

C++/CLI

```
void InsertSketch2(  
& System.bool UpdateEditRebuild  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UpdateEditRebuild

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSketch2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertSplinePoint Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSplinePoint Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSplinePoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSplinePoint( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
  
instance.InsertSplinePoint(X, Y, Z)
```

C#

```
void InsertSplinePoint(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
void InsertSplinePoint(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSplinePoint](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertSplitLineProject Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSplitLineProject Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSplitLineProject](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSplitLineProject( _  
    ByVal IsDirectional As System.Boolean, _  
    ByVal FlipDir As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim IsDirectional As System.Boolean  
Dim FlipDir As System.Boolean  
  
instance.InsertSplitLineProject(IsDirectional, FlipDir)
```

C#

```
void InsertSplitLineProject(  
    System.bool IsDirectional,  
    System.bool FlipDir  
)
```

C++/CLI

```
void InsertSplitLineProject(  
& System.bool IsDirectional,  
& System.bool FlipDir  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IsDirectional

FlipDir

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSplitLineProject](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertSplitLineSil Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSplitLineSil Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSplitLineSil](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSplitLineSil()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.InsertSplitLineSil()
```

C#

```
void InsertSplitLineSil()
```

```
void InsertSplitLineSil();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSplitLineSil](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertSurfaceFinishSymbol2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSurfaceFinishSymbol2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSurfaceFinishSymbol2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertSurfaceFinishSymbol2( _
    ByVal SymType As System.Integer, _
    ByVal LeaderType As System.Integer, _
    ByVal LocX As System.Double, _
    ByVal LocY As System.Double, _
    ByVal LocZ As System.Double, _
    ByVal LaySymbol As System.Integer, _
    ByVal ArrowType As System.Integer, _
    ByVal MachAllowance As System.String, _
    ByVal OtherVals As System.String, _
    ByVal ProdMethod As System.String, _
    ByVal SampleLen As System.String, _
    ByVal MaxRoughness As System.String, _
    ByVal MinRoughness As System.String, _
    ByVal RoughnessSpacing As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim SymType As System.Integer
Dim LeaderType As System.Integer
Dim LocX As System.Double
Dim LocY As System.Double
Dim LocZ As System.Double
Dim LaySymbol As System.Integer
Dim ArrowType As System.Integer
Dim MachAllowance As System.String
Dim OtherVals As System.String
Dim ProdMethod As System.String
Dim SampleLen As System.String
Dim MaxRoughness As System.String
Dim MinRoughness As System.String
Dim RoughnessSpacing As System.String
Dim value As System.Boolean
```

```
value = instance.InsertSurfaceFinishSymbol2(SymType, LeaderType, LocX, LocY, LocZ, LaySymbol,
ArrowType, MachAllowance, OtherVals, ProdMethod, SampleLen, MaxRoughness, MinRoughness,
RoughnessSpacing)
```

C#

```

System.bool InsertSurfaceFinishSymbol2(
    System.int SymType,
    System.int LeaderType,
    System.double LocX,
    System.double LocY,
    System.double LocZ,
    System.int LaySymbol,
    System.int ArrowType,
    System.string MachAllowance,
    System.string OtherVals,
    System.string ProdMethod,
    System.string SampleLen,
    System.string MaxRoughness,
    System.string MinRoughness,
    System.string RoughnessSpacing
)

```

C++/CLI

```

System.bool InsertSurfaceFinishSymbol2(
    & System.int SymType,
    & System.int LeaderType,
    & System.double LocX,
    & System.double LocY,
    & System.double LocZ,
    & System.int LaySymbol,
    & System.int ArrowType,
    & System.String^ MachAllowance,
    & System.String^ OtherVals,
    & System.String^ ProdMethod,
    & System.String^ SampleLen,
    & System.String^ MaxRoughness,
    & System.String^ MinRoughness,
    & System.String^ RoughnessSpacing
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SymType

LeaderType

LocX

LocY

LocZ

LaySymbol

ArrowType

MachAllowance

OtherVals

ProdMethod

SampleLen

MaxRoughness

MinRoughness

RoughnessSpacing

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSurfaceFinishSymbol2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

InsertSweepRefSurface Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertSweepRefSurface Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertSweepRefSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertSweepRefSurface( _
    ByVal Propagate As System.Boolean, _
    ByVal TwistCtrlOption As System.Short, _
    ByVal KeepTangency As System.Boolean, _
    ByVal ForceNonRational As System.Boolean _
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim Propagate As System.Boolean
Dim TwistCtrlOption As System.Short
Dim KeepTangency As System.Boolean
Dim ForceNonRational As System.Boolean

instance.InsertSweepRefSurface(Propagate, TwistCtrlOption, KeepTangency, ForceNonRational)
```

C#

```
void InsertSweepRefSurface(
    System.bool Propagate,
    System.short TwistCtrlOption,
    System.bool KeepTangency,
    System.bool ForceNonRational
)
```

C++/CLI

```
void InsertSweepRefSurface(
    & System.bool Propagate,
    & System.short TwistCtrlOption,
    & System.bool KeepTangency,
    & System.bool ForceNonRational
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

TwistCtrlOption

KeepTangency

ForceNonRational

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSweepRefSurface](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

InsertSweepRefSurface2 Method (IModelDoc)

[See Also](#)



Obsolete. Superseded by [IModelDoc2::InsertSweepRefSurface2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub InsertSweepRefSurface2( _  
    ByVal Propagate As System.Boolean, _  
    ByVal TwistCtrlOption As System.Short, _  
    ByVal KeepTangency As System.Boolean, _  
    ByVal ForceNonRational As System.Boolean, _  
    ByVal StartMatchingType As System.Short, _  
    ByVal EndMatchingType As System.Short _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Propagate As System.Boolean  
Dim TwistCtrlOption As System.Short  
Dim KeepTangency As System.Boolean  
Dim ForceNonRational As System.Boolean  
Dim StartMatchingType As System.Short  
Dim EndMatchingType As System.Short  
  
instance.InsertSweepRefSurface2(Propagate, TwistCtrlOption, KeepTangency, ForceNonRational,  
StartMatchingType, EndMatchingType)
```

C#

```
void InsertSweepRefSurface2(  
    System.bool Propagate,  
    System.short TwistCtrlOption,  
    System.bool KeepTangency,  
    System.bool ForceNonRational,  
    System.short StartMatchingType,  
    System.short EndMatchingType  
)
```

C++/CLI

```
void InsertSweepRefSurface2(  
& System.bool Propagate,  
& System.short TwistCtrlOption,  
& System.bool KeepTangency,  
& System.bool ForceNonRational,  
& System.short StartMatchingType,  
& System.short EndMatchingType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Propagate

TwistCtrlOption

KeepTangency

ForceNonRational

StartMatchingType

EndMatchingType

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertSweepRefSurface2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InsertWeldSymbol2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertWeldSymbol2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertWeldSymbol2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InsertWeldSymbol2( _  
    ByVal Dim1 As System.String, _  
    ByVal Symbol As System.String, _  
    ByVal Dim2 As System.String, _  
    ByVal Symmetric As System.Boolean, _  
    ByVal FieldWeld As System.Boolean, _  
    ByVal ShowOtherSide As System.Boolean, _  
    ByVal DashOnTop As System.Boolean, _  
    ByVal Peripheral As System.Boolean, _  
    ByVal HasProcess As System.Boolean, _  
    ByVal ProcessValue As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Dim1 As System.String  
Dim Symbol As System.String  
Dim Dim2 As System.String  
Dim Symmetric As System.Boolean  
Dim FieldWeld As System.Boolean  
Dim ShowOtherSide As System.Boolean  
Dim DashOnTop As System.Boolean  
Dim Peripheral As System.Boolean  
Dim HasProcess As System.Boolean  
Dim ProcessValue As System.String
```

```
instance.InsertWeldSymbol2(Dim1, Symbol, Dim2, Symmetric, FieldWeld, ShowOtherSide, DashOnTop,  
Peripheral, HasProcess, ProcessValue)
```

C#

```
void InsertWeldSymbol2(  
    System.string Dim1,  
    System.string Symbol,  
    System.string Dim2,  
    System.bool Symmetric,  
    System.bool FieldWeld,  
    System.bool ShowOtherSide,  
    System.bool DashOnTop,  
    System.bool Peripheral,  
    System.bool HasProcess,  
    System.string ProcessValue  
)
```

C++/CLI

```
void InsertWeldSymbol2(  
& System.String^ Dim1,  
& System.String^ Symbol,  
& System.String^ Dim2,  
& System.bool Symmetric,  
& System.bool FieldWeld,
```

```
& System.bool ShowOtherSide,  
& System.bool DashOnTop,  
& System.bool Peripheral,  
& System.bool HasProcess,  
& System.String^ ProcessValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Dim1

Symbol

Dim2

Symmetric

FieldWeld

ShowOtherSide

DashOnTop

Peripheral

HasProcess

ProcessValue

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertWeldSymbol2](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertWeldSymbol3 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InsertWeldSymbol3 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InsertWeldSymbol3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertWeldSymbol3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim value As System.Object
```

```
value = instance.InsertWeldSymbol3()
```

C#

```
System.object InsertWeldSymbol3()
```

C++/CLI

```
System.Object^ InsertWeldSymbol3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InsertWeldSymbol3](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

InspectCurvature Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : InspectCurvature Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::InspectCurvature](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub InspectCurvature()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.InspectCurvature()
```

C#

```
void InspectCurvature()
```

C++/CLI

```
void InspectCurvature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::InspectCurvature](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IParameter Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IParameter Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IParameter](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IParameter( _  
    ByVal StringIn As System.String _  
) As Dimension
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim StringIn As System.String  
Dim value As Dimension  
  
value = instance.IParameter(StringIn)
```

C#

```
Dimension IParameter(  
    System.string StringIn  
)
```

C++/CLI

```
Dimension^ IParameter(  
& System.String^ StringIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StringIn

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IParameter](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRayIntersections Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IRayIntersections Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IRayIntersections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IRayIntersections( _  
    ByRef BodiesIn As Body, _  
    ByVal NumBodies As System.Integer, _  
    ByRef BasePointsIn As System.Double, _  
    ByRef VectorsIn As System.Double, _  
    ByVal NumRays As System.Integer, _  
    ByVal Options As System.Integer, _  
    ByVal HitRadius As System.Double, _  
    ByVal Offset As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim BodiesIn As Body  
Dim NumBodies As System.Integer  
Dim BasePointsIn As System.Double  
Dim VectorsIn As System.Double  
Dim NumRays As System.Integer  
Dim Options As System.Integer  
Dim HitRadius As System.Double  
Dim Offset As System.Double  
Dim value As System.Integer
```

```
value = instance.IRayIntersections(BodiesIn, NumBodies, BasePointsIn, VectorsIn, NumRays, Options,  
HitRadius, Offset)
```

C#

```
System.int IRayIntersections(  
    ref Body BodiesIn,
```

```

System.int NumBodies,
ref System.double BasePointsIn,
ref System.double VectorsIn,
System.int NumRays,
System.int Options,
System.double HitRadius,
System.double Offset
)

```

C++/CLI

```

System.int IRayIntersections(
& Body^% BodiesIn,
& System.int NumBodies,
& System.double% BasePointsIn,
& System.double% VectorsIn,
& System.int NumRays,
& System.int Options,
& System.double HitRadius,
& System.double Offset
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodiesIn

NumBodies

BasePointsIn

VectorsIn

NumRays

Options

HitRadius

Offset

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2::IRayIntersections](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRelease3rdPartyStorage Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IRelease3rdPartyStorage Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IRelease3rdPartyStorage](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub IRelease3rdPartyStorage( _
    ByVal StringIn As System.String _
)

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim StringIn As System.String

instance.IRelease3rdPartyStorage(StringIn)

```

C#

```
void IRelease3rdPartyStorage(  
    System.string StringIn  
)
```

C++/CLI

```
void IRelease3rdPartyStorage(  
& System.String^ StringIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StringIn

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IRelease3rdPartyStorage](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsActive Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IsActive Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IsActive](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsActive(  
    ByVal CompStr As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim CompStr As System.String  
Dim value As System.Boolean  
  
value = instance.IsActive(CompStr)
```

C#

```
System.bool IsActive(  
    System.string CompStr  
)
```

C++/CLI

```
System.bool IsActive(  
& System.String^ CompStr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CompStr

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IsActive](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsEditingSelf Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : IsEditingSelf Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::IsEditingSelf](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsEditingSelf() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim value As System.Boolean  
  
value = instance.IsEditingSelf()
```

C#

```
System.bool IsEditingSelf()
```

C++/CLI

```
System.bool IsEditingSelf();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::IsEditingSelf](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISelectByRay Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ISelectByRay Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ISelectByRay](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISelectByRay( _  
    ByRef PointIn As System.Double, _  
    ByRef VectorIn As System.Double, _  
    ByVal RadiusIn As System.Double, _  
    ByVal TypeWanted As System.Integer _  
) As System.Boolean
```

```

Dim instance As IModelDoc
Dim PointIn As System.Double
Dim VectorIn As System.Double
Dim RadiusIn As System.Double
Dim TypeWanted As System.Integer
Dim value As System.Boolean

value = instance.ISelectByRay(PointIn, VectorIn, RadiusIn, TypeWanted)

```

C#

```

System.bool ISelectByRay(
    ref System.double PointIn,
    ref System.double VectorIn,
    System.double RadiusIn,
    System.int TypeWanted
)

```

C++/CLI

```

System.bool ISelectByRay(
    & System.double% PointIn,
    & System.double% VectorIn,
    & System.double RadiusIn,
    & System.int TypeWanted
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointIn

VectorIn

RadiusIn

TypeWanted

Visual Basic for Applications (VBA) Syntax

See [ModelDoc2.ISelectByRay](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISelectionManager Property (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ISelectionManager Property (IModelDoc)

Obsolete. Superseded by [IModelDoc2.ISelectionManager](#).

.NET Syntax

Visual Basic (Declaration)

```

ReadOnly Property ISelectionManager As SelectionMgr

```

Visual Basic (Usage)

Copy Code

```

Dim instance As IModelDoc
Dim value As SelectionMgr

value = instance.ISelectionManager

```

C#

```
SelectionMgr ISelectionManager {get;}
```

C++/CLI

```
property SelectionMgr^ ISelectionManager {  
    SelectionMgr^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ISelectionManager](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)