

SOLIDWORKS API (.NET VBA C#) — Reference (176/337): IModelDoc (part 12 of 13)

SOLIDWORKS API Documentation (converted from CHM)

IModelDoc (part 12 of 13) (Type)

ShowCosmeticThread Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ShowCosmeticThread Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ShowCosmeticThread](#).

.NET Syntax

Visual Basic (Declaration)

Sub ShowCosmeticThread()

Visual Basic (Usage)

Copy Code

Dim instance As [IModelDoc](#)
instance.ShowCosmeticThread()

C#

void ShowCosmeticThread()

C++/CLI

void ShowCosmeticThread();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ShowCosmeticThread](#).

See Also

- [IModelDoc Interface](#)
- [IModelDoc Members](#)

ShowFeatureDimensions Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ShowFeatureDimensions Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ShowFeatureDimensions](#).

.NET Syntax

Visual Basic (Declaration)

Sub ShowFeatureDimensions()

Visual Basic (Usage)

Copy Code

Dim instance As [IModelDoc](#)
instance.ShowFeatureDimensions()

C#

void ShowFeatureDimensions()

C++/CLI

```
void ShowFeatureDimensions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ShowFeatureDimensions](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowFeatureErrorDialog Property (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ShowFeatureErrorDialog Property (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ShowFeatureErrorDialog](#).

.NET Syntax

Visual Basic (Declaration)

Property ShowFeatureErrorDialog As System.Boolean

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim value As System.Boolean

instance.ShowFeatureErrorDialog = value

value = instance.ShowFeatureErrorDialog
```

C#

```
System.bool ShowFeatureErrorDialog {get; set;}
```

C++/CLI

```
property System.bool ShowFeatureErrorDialog {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ShowFeatureErrorDialog](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowNamedView Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ShowNamedView Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ShowNamedView](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ShowNamedView( _  
    ByVal VName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim VName As System.String  
  
instance.ShowNamedView(VName)
```

C#

```
void ShowNamedView(  
    System.string VName  
)
```

C++/CLI

```
void ShowNamedView(  
& System.String^ VName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VName

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ShowNamedView](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowNamedView2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ShowNamedView2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ShowNamedView2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ShowNamedView2( _  
    ByVal VName As System.String, _  
    ByVal ViewId As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim VName As System.String  
Dim ViewId As System.Integer  
  
instance.ShowNamedView2(VName, ViewId)
```

C#

```
void ShowNamedView2(  
    System.string VName,  
    System.integer ViewId)
```

```
        System.int ViewId
    )
```

C++/CLI

```
void ShowNamedView2(
&    System.String^ VName,
&    System.int ViewId
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VName

ViewId

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ShowNamedView2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowSolidBody Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ShowSolidBody Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ShowSolidBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ShowSolidBody()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
instance.ShowSolidBody()
```

C#

```
void ShowSolidBody()
```

C++/CLI

```
void ShowSolidBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ShowSolidBody](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SimpleHole Method (IModelDoc)

[See Also](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Sub SimpleHole( _  
    ByVal Sd As System.Boolean, _  
    ByVal Flip As System.Boolean, _  
    ByVal Dir As System.Boolean, _  
    ByVal T1 As System.Integer, _  
    ByVal T2 As System.Integer, _  
    ByVal D1 As System.Double, _  
    ByVal D2 As System.Double, _  
    ByVal Dchk1 As System.Boolean, _  
    ByVal Dchk2 As System.Boolean, _  
    ByVal Ddir1 As System.Boolean, _  
    ByVal Ddir2 As System.Boolean, _  
    ByVal Dang1 As System.Double, _  
    ByVal Dang2 As System.Double, _  
    ByVal OffsetReverse1 As System.Boolean, _  
    ByVal OffsetReverse2 As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Sd As System.Boolean  
Dim Flip As System.Boolean  
Dim Dir As System.Boolean  
Dim T1 As System.Integer  
Dim T2 As System.Integer  
Dim D1 As System.Double  
Dim D2 As System.Double  
Dim Dchk1 As System.Boolean  
Dim Dchk2 As System.Boolean  
Dim Ddir1 As System.Boolean  
Dim Ddir2 As System.Boolean  
Dim Dang1 As System.Double  
Dim Dang2 As System.Double  
Dim OffsetReverse1 As System.Boolean  
Dim OffsetReverse2 As System.Boolean  
  
instance.SimpleHole(Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1, Dang2, OffsetReverse1, OffsetReverse2)
```

C#

```
void SimpleHole(  
    System.bool Sd,  
    System.bool Flip,  
    System.bool Dir,  
    System.int T1,  
    System.int T2,  
    System.double D1,  
    System.double D2,  
    System.bool Dchk1,  
    System.bool Dchk2,  
    System.bool Ddir1,  
    System.bool Ddir2,  
    System.double Dang1,  
    System.double Dang2,  
    System.bool OffsetReverse1,  
    System.bool OffsetReverse2  
)
```

C++/CLI

```

void SimpleHole(
& System.bool Sd,
& System.bool Flip,
& System.bool Dir,
& System.int T1,
& System.int T2,
& System.double D1,
& System.double D2,
& System.bool Dchk1,
& System.bool Dchk2,
& System.bool Ddir1,
& System.bool Ddir2,
& System.double Dang1,
& System.double Dang2,
& System.bool OffsetReverse1,
& System.bool OffsetReverse2
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sd

Flip

Dir

T1

T2

D1

D2

Dchk1

Dchk2

Ddir1

Ddir2

Dang1

Dang2

OffsetReverse1

OffsetReverse2

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SimpleHole](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SimpleHole2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SimpleHole2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SimpleHole2](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub SimpleHole2( _
    ByVal Dia As System.Double, _
    ByVal Sd As System.Boolean, _
    ByVal Flip As System.Boolean, _
    ByVal Dir As System.Boolean, _

```

```

ByVal T1 As System.Integer, _
ByVal T2 As System.Integer, _
ByVal D1 As System.Double, _
ByVal D2 As System.Double, _
ByVal Dchk1 As System.Boolean, _
ByVal Dchk2 As System.Boolean, _
ByVal Ddir1 As System.Boolean, _
ByVal Ddir2 As System.Boolean, _
ByVal Dang1 As System.Double, _
ByVal Dang2 As System.Double, _
ByVal OffsetReverse1 As System.Boolean, _
ByVal OffsetReverse2 As System.Boolean _
)

```

Visual Basic (Usage)



```

Dim instance As IModelDoc
Dim Dia As System.Double
Dim Sd As System.Boolean
Dim Flip As System.Boolean
Dim Dir As System.Boolean
Dim T1 As System.Integer
Dim T2 As System.Integer
Dim D1 As System.Double
Dim D2 As System.Double
Dim Dchk1 As System.Boolean
Dim Dchk2 As System.Boolean
Dim Ddir1 As System.Boolean
Dim Ddir2 As System.Boolean
Dim Dang1 As System.Double
Dim Dang2 As System.Double
Dim OffsetReverse1 As System.Boolean
Dim OffsetReverse2 As System.Boolean

```

```

instance.SimpleHole2(Dia, Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1, Dang2,
OffsetReverse1, OffsetReverse2)

```

C#

```

void SimpleHole2(
    System.double Dia,
    System.bool Sd,
    System.bool Flip,
    System.bool Dir,
    System.int T1,
    System.int T2,
    System.double D1,
    System.double D2,
    System.bool Dchk1,
    System.bool Dchk2,
    System.bool Ddir1,
    System.bool Ddir2,
    System.double Dang1,
    System.double Dang2,
    System.bool OffsetReverse1,
    System.bool OffsetReverse2
)

```

C++/CLI

```

void SimpleHole2(
& System.double Dia,
& System.bool Sd,
& System.bool Flip,
& System.bool Dir,
& System.int T1,
& System.int T2,
& System.double D1,
& System.double D2,
& System.bool Dchk1,

```

```

& System.bool Dchk2,
& System.bool Ddir1,
& System.bool Ddir2,
& System.double Dang1,
& System.double Dang2,
& System.bool OffsetReverse1,
& System.bool OffsetReverse2
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Dia

Sd

Flip

Dir

T1

T2

D1

D2

Dchk1

Dchk2

Ddir1

Ddir2

Dang1

Dang2

OffsetReverse1

OffsetReverse2

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SimpleHole2](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SimplifySpline Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SimplifySpline Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SimplifySpline](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub SimplifySpline( _
    ByVal ToleranceIn As System.Double _
)

```

Visual Basic (Usage)

```

Dim instance As IModelDoc
Dim ToleranceIn As System.Double

instance.SimplifySpline(ToleranceIn)

```

C#



```
void SimplifySpline(  
    System.double ToleranceIn  
)
```

C++/CLI

```
void SimplifySpline(  
&    System.double ToleranceIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ToleranceIn

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SimplifySpline](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Sketch3DIntersections Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : Sketch3DIntersections Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::Sketch3DIntersections](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub Sketch3DIntersections()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.Sketch3DIntersections()
```

C#

```
void Sketch3DIntersections()
```

C++/CLI

```
void Sketch3DIntersections();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::Sketch3DIntersections](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchAddConstraints Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchAddConstraints Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchAddConstraints](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchAddConstraints( _  
    ByVal IdStr As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim IdStr As System.String  
  
instance.SketchAddConstraints(IdStr)
```

C#

```
void SketchAddConstraints(  
    System.string IdStr  
)
```

C++/CLI

```
void SketchAddConstraints(  
    & System.String^ IdStr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdStr

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchAddConstraints](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchAlign Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchAlign Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchAlign](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchAlign()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.SketchAlign()
```

C#

```
void SketchAlign()
```

C++/CLI

```
void SketchAlign();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchAlign](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchArc Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchArc Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchArc](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchArc()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.SketchArc()
```

C#

```
void SketchArc()
```

C++/CLI

```
void SketchArc();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchArc](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchCenterline Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchCenterline Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchCenterline](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchCenterline()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.SketchCenterline()
```

C#

```
void SketchCenterline()
```

C++/CLI

```
void SketchCenterline();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchCenterline](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchChamfer Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchChamfer Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchChamfer](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchChamfer( _  
    ByVal AngleORdist As System.Double, _  
    ByVal Dist1 As System.Double, _  
    ByVal Options As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim AngleORdist As System.Double  
Dim Dist1 As System.Double  
Dim Options As System.Integer  
  
instance.SketchChamfer(AngleORdist, Dist1, Options)
```

C#

```
void SketchChamfer(  
    System.double AngleORdist,  
    System.double Dist1,  
    System.int Options  
)
```

C++/CLI

```
void SketchChamfer(  
& System.double AngleORdist,  
& System.double Dist1,
```

```
& System.int Options
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AngleORdist

Dist1

Options

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchChamfer](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchCircle Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchCircle Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchCircle](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchCircle()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.SketchCircle()
```

C#

```
void SketchCircle()
```

C++/CLI

```
void SketchCircle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchCircle](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchConstrainCoincident Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchConstrainCoincident Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchConstrainCoincident](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchConstrainCoincident()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.SketchConstrainCoincident()
```

C#

```
void SketchConstrainCoincident()
```

C++/CLI

```
void SketchConstrainCoincident();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchConstrainCoincident](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchConstrainConcentric Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchConstrainConcentric Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchConstrainConcentric](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchConstrainConcentric()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.SketchConstrainConcentric()
```

C#

```
void SketchConstrainConcentric()
```

C++/CLI

```
void SketchConstrainConcentric();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchConstrainConcentric](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SketchConstrainParallel Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchConstrainParallel Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchConstrainParallel](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchConstrainParallel()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.SketchConstrainParallel()
```

C#

```
void SketchConstrainParallel()
```

C++/CLI

```
void SketchConstrainParallel();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchConstrainParallel](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SketchConstrainPerp Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchConstrainPerp Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchConstrainPerp](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchConstrainPerp()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.SketchConstrainPerp()
```

C#

```
void SketchConstrainPerp()
```

C++/CLI

```
void SketchConstrainPerp();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchConstrainPerp](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchConstrainTangent Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchConstrainTangent Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchConstrainTangent](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchConstrainTangent()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.SketchConstrainTangent()
```

C#

```
void SketchConstrainTangent()
```

C++/CLI

```
void SketchConstrainTangent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchConstrainTangent](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchConstraintsDel Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchConstraintsDel Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchConstraintsDel](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchConstraintsDel( _  
    ByVal ConstrInd As System.Integer, _  
    ByVal IdStr As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim ConstrInd As System.Integer  
Dim IdStr As System.String  
  
instance.SketchConstraintsDel(ConstrInd, IdStr)
```

C#

```
void SketchConstraintsDel(  
    System.int ConstrInd,  
    System.string IdStr  
)
```

C++/CLI

```
void SketchConstraintsDel(  
& System.int ConstrInd,  
& System.String^ IdStr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConstrInd

IdStr

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchConstraintsDel](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchConstraintsDelAll Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchConstraintsDelAll Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchConstraintsDelAll](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchConstraintsDelAll()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.SketchConstraintsDelAll()
```

C#

```
void SketchConstraintsDelAll()
```

C++/CLI

```
void SketchConstraintsDelAll();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchConstraintsDelAll](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchConvertIsoCurves Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchConvertIsoCurves Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchConvertIsoCurves](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchConvertIsoCurves( _  
    ByVal PercentRatio As System.Double, _  
    ByVal VORuDir As System.Boolean, _  
    ByVal DoConstrain As System.Boolean, _  
    ByVal SkipHoles As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim PercentRatio As System.Double  
Dim VORuDir As System.Boolean  
Dim DoConstrain As System.Boolean  
Dim SkipHoles As System.Boolean  
  
instance.SketchConvertIsoCurves(PercentRatio, VORuDir, DoConstrain, SkipHoles)
```

C#

```
void SketchConvertIsoCurves(  
    System.double PercentRatio,  
    System.bool VORuDir,  
    System.bool DoConstrain,  
    System.bool SkipHoles  
)
```

C++/CLI

```
void SketchConvertIsoCurves(  
& System.double PercentRatio,  
& System.bool VORuDir,  
& System.bool DoConstrain,  
& System.bool SkipHoles  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PercentRatio

VORuDir

DoConstrain

SkipHoles

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchConvertIsoCurves](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchFillet Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchFillet Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchFillet](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchFillet( _  
    ByVal Rad As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Rad As System.Double  
  
instance.SketchFillet(Rad)
```

C#

```
void SketchFillet(  
    System.double Rad  
)
```

C++/CLI

```
void SketchFillet(  
&    System.double Rad  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Rad

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchFillet](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchFillet1 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchFillet1 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchFillet1](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchFillet1( _  
    ByVal Rad As System.Double _
```

)

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Rad As System.Double  
  
instance.SketchFillet1(Rad)
```

C#

```
void SketchFillet1(  
    System.double Rad  
)
```

C++/CLI

```
void SketchFillet1(  
& System.double Rad  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Rad

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchFillet1](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchFillet2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchFillet2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchFillet2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SketchFillet2( _  
    ByVal Rad As System.Double, _  
    ByVal ConstrainedCorners As System.Short _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Rad As System.Double  
Dim ConstrainedCorners As System.Short  
Dim value As System.Boolean  
  
value = instance.SketchFillet2(Rad, ConstrainedCorners)
```

C#

```
System.bool SketchFillet2(  
    System.double Rad,  
    System.short ConstrainedCorners  
)
```

C++/CLI

```
System.bool SketchFillet2(  
& System.double Rad,  
& System.short ConstrainedCorners  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Rad

ConstrainedCorners

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchFillet2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchMirror Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchMirror Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchMirror](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchMirror()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
```

```
instance.SketchMirror()
```

C#

```
void SketchMirror()
```

C++/CLI

```
void SketchMirror();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchMirror](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchModifyFlip Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchModifyFlip Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchModifyFlip](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchModifyFlip( _  
    ByVal AxisFlag As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim AxisFlag As System.Integer  
  
instance.SketchModifyFlip(AxisFlag)
```

C#

```
void SketchModifyFlip(  
    System.int AxisFlag  
)
```

C++/CLI

```
void SketchModifyFlip(  
&    System.int AxisFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AxisFlag

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchModifyFlip](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchModifyRotate Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchModifyRotate Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchModifyRotate](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchModifyRotate( _  
    ByVal CenterX As System.Double, _  
    ByVal CenterY As System.Double, _  
    ByVal Angle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim CenterX As System.Double  
Dim CenterY As System.Double  
Dim Angle As System.Double  
  
instance.SketchModifyRotate(CenterX, CenterY, Angle)
```

C#

```
void SketchModifyRotate(  
    System.double CenterX,  
    System.double CenterY,  
    System.double Angle  
)
```

C++/CLI

```
void SketchModifyRotate(  
&    System.double CenterX,  
&    System.double CenterY,  
&    System.double Angle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CenterX

CenterY

Angle

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchModifyRotate](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchModifyScale Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchModifyScale Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchModifyScale](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SketchModifyScale( _  
    ByVal ScaleFactor As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim ScaleFactor As System.Double  
Dim value As System.Boolean
```

```
value = instance.SketchModifyScale(ScaleFactor)
```

C#

```
System.bool SketchModifyScale(  
    System.double ScaleFactor  
)
```

C++/CLI

```
System.bool SketchModifyScale(  
&    System.double ScaleFactor  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ScaleFactor

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchModifyScale](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchModifyTranslate Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchModifyTranslate Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchModifyTranslate](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchModifyTranslate(  
    ByVal StartX As System.Double, _  
    ByVal StartY As System.Double, _  
    ByVal EndX As System.Double, _  
    ByVal EndY As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim StartX As System.Double  
Dim StartY As System.Double  
Dim EndX As System.Double  
Dim EndY As System.Double  
  
instance.SketchModifyTranslate(StartX, StartY, EndX, EndY)
```

C#

```
void SketchModifyTranslate(  
    System.double StartX,  
    System.double StartY,  
    System.double EndX,  
    System.double EndY  
)
```

C++/CLI

```
void SketchModifyTranslate(  
& System.double StartX,  
& System.double StartY,  
& System.double EndX,  
& System.double EndY  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartX

StartY

EndX

EndY

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchModifyTranslate](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchOffset Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchOffset Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchOffset](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchOffset( _  
    ByVal Offset As System.Double, _  
    ByVal ContourMode As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Offset As System.Double  
Dim ContourMode As System.Boolean  
  
instance.SketchOffset(Offset, ContourMode)
```

C#

```
void SketchOffset(  
    System.double Offset,  
    System.bool ContourMode  
)
```

C++/CLI

```
void SketchOffset(  
& System.double Offset,  
& System.bool ContourMode  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Offset

ContourMode

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchOffset](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchOffset2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchOffset2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchOffset2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SketchOffset2( _  
    ByVal Offset As System.Double, _  
    ByVal BothDirections As System.Boolean, _  
    ByVal Chain As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Offset As System.Double  
Dim BothDirections As System.Boolean  
Dim Chain As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SketchOffset2(Offset, BothDirections, Chain)
```

C#

```
System.bool SketchOffset2(  
    System.double Offset,  
    System.bool BothDirections,  
    System.bool Chain  
)
```

C++/CLI

```
System.bool SketchOffset2(  
& System.double Offset,  
& System.bool BothDirections,  
& System.bool Chain  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Offset

BothDirections

Chain

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchOffset2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchOffsetEdges Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchOffsetEdges Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchOffsetEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchOffsetEdges( _  
    ByVal Val As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Val As System.Double  
  
instance.SketchOffsetEdges(Val)
```

C#

```
void SketchOffsetEdges(  
    System.double Val  
)
```

C++/CLI

```
void SketchOffsetEdges(  
& System.double Val  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Val

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchOffsetEdges](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchOffsetEntities Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchOffsetEntities Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchOffsetEntities](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchOffsetEntities( _  
    ByVal Offset As System.Double, _  
    ByVal Flip As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Offset As System.Double  
Dim Flip As System.Boolean  
  
instance.SketchOffsetEntities(Offset, Flip)
```

C#

```
void SketchOffsetEntities(  
    System.double Offset,
```

```
        System.bool Flip
    )
```

C++/CLI

```
void SketchOffsetEntities(
&    System.double Offset,
&    System.bool Flip
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Offset

Flip

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchOffsetEntities](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchOffsetEntities2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchOffsetEntities2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchOffsetEntities2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SketchOffsetEntities2( _
    ByVal Offset As System.Double, _
    ByVal BothDirections As System.Boolean, _
    ByVal Chain As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim Offset As System.Double
Dim BothDirections As System.Boolean
Dim Chain As System.Boolean
Dim value As System.Boolean
```

```
value = instance.SketchOffsetEntities2(Offset, BothDirections, Chain)
```

C#

```
System.bool SketchOffsetEntities2(
    System.double Offset,
    System.bool BothDirections,
    System.bool Chain
)
```

C++/CLI

```
System.bool SketchOffsetEntities2(
&    System.double Offset,
&    System.bool BothDirections,
&    System.bool Chain
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Offset

BothDirections

Chain

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchOffsetEntities2](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchParabola Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchParabola Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchParabola](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchParabola( _  
    ByVal Val1 As System.Double, _  
    ByVal Val2 As System.Double, _  
    ByVal Z1 As System.Double, _  
    ByVal Val3 As System.Double, _  
    ByVal Val4 As System.Double, _  
    ByVal Z2 As System.Double, _  
    ByVal Val5 As System.Double, _  
    ByVal Val6 As System.Double, _  
    ByVal Z3 As System.Double, _  
    ByVal Val7 As System.Double, _  
    ByVal Val8 As System.Double, _  
    ByVal Z4 As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Val1 As System.Double  
Dim Val2 As System.Double  
Dim Z1 As System.Double  
Dim Val3 As System.Double  
Dim Val4 As System.Double  
Dim Z2 As System.Double  
Dim Val5 As System.Double  
Dim Val6 As System.Double  
Dim Z3 As System.Double  
Dim Val7 As System.Double  
Dim Val8 As System.Double  
Dim Z4 As System.Double  
  
instance.SketchParabola(Val1, Val2, Z1, Val3, Val4, Z2, Val5, Val6, Z3, Val7, Val8, Z4)
```

C#

```
void SketchParabola(  
    System.double Val1,  
    System.double Val2,  
    System.double Z1,
```

```
System.double Val3,  
System.double Val4,  
System.double Z2,  
System.double Val5,  
System.double Val6,  
System.double Z3,  
System.double Val7,  
System.double Val8,  
System.double Z4  
)
```

C++/CLI

```
void SketchParabola(  
& System.double Val1,  
& System.double Val2,  
& System.double Z1,  
& System.double Val3,  
& System.double Val4,  
& System.double Z2,  
& System.double Val5,  
& System.double Val6,  
& System.double Z3,  
& System.double Val7,  
& System.double Val8,  
& System.double Z4  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Val1

Val2

Z1

Val3

Val4

Z2

Val5

Val6

Z3

Val7

Val8

Z4

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchParabola](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchPoint Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchPoint Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchPoint( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
  
instance.SketchPoint(X, Y, Z)
```

C#

```
void SketchPoint(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
void SketchPoint(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchPoint](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchPolygon Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchPolygon Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchPolygon](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SketchPolygon( _  
    ByVal XCenter As System.Double, _  
    ByVal YCenter As System.Double, _  
    ByVal XEdge As System.Double, _  
    ByVal YEdge As System.Double, _  
    ByVal NSides As System.Integer, _
```

```
ByVal BInscribed As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim XCenter As System.Double  
Dim YCenter As System.Double  
Dim XEdge As System.Double  
Dim YEdge As System.Double  
Dim NSides As System.Integer  
Dim BInscribed As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SketchPolygon(XCenter, YCenter, XEdge, YEdge, NSides, BInscribed)
```

C#

```
System.bool SketchPolygon(  
    System.double XCenter,  
    System.double YCenter,  
    System.double XEdge,  
    System.double YEdge,  
    System.int NSides,  
    System.bool BInscribed  
)
```

C++/CLI

```
System.bool SketchPolygon(  
& System.double XCenter,  
& System.double YCenter,  
& System.double XEdge,  
& System.double YEdge,  
& System.int NSides,  
& System.bool BInscribed  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XCenter

YCenter

XEdge

YEdge

NSides

BInscribed

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchPolygon](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchRectangle Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchRectangle Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchRectangle](#).

.NET Syntax

```

Sub SketchRectangle( _
    ByVal Val1 As System.Double, _
    ByVal Val2 As System.Double, _
    ByVal Z1 As System.Double, _
    ByVal Val3 As System.Double, _
    ByVal Val4 As System.Double, _
    ByVal Z2 As System.Double, _
    ByVal Val5 As System.Boolean _
)

```



```

Dim instance As IModelDoc
Dim Val1 As System.Double
Dim Val2 As System.Double
Dim Z1 As System.Double
Dim Val3 As System.Double
Dim Val4 As System.Double
Dim Z2 As System.Double
Dim Val5 As System.Boolean

```

```
instance.SketchRectangle(Val1, Val2, Z1, Val3, Val4, Z2, Val5)
```

```

void SketchRectangle(
    System.double Val1,
    System.double Val2,
    System.double Z1,
    System.double Val3,
    System.double Val4,
    System.double Z2,
    System.bool Val5
)

```

```

void SketchRectangle(
    & System.double Val1,
    & System.double Val2,
    & System.double Z1,
    & System.double Val3,
    & System.double Val4,
    & System.double Z2,
    & System.bool Val5
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[Val1](#)

[Val2](#)

[Z1](#)

[Val3](#)

[Val4](#)

[Z2](#)

[Val5](#)

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchRectangle](#).

See Also

SketchRectangleAtAnyAngle Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchRectangleAtAnyAngle Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchRectangleAtAnyAngle](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchRectangleAtAnyAngle( _  
    ByVal Val1 As System.Double, _  
    ByVal Val2 As System.Double, _  
    ByVal Z1 As System.Double, _  
    ByVal Val3 As System.Double, _  
    ByVal Val4 As System.Double, _  
    ByVal Z2 As System.Double, _  
    ByVal Val3x As System.Double, _  
    ByVal Val3y As System.Double, _  
    ByVal Z3 As System.Double, _  
    ByVal Val5 As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Val1 As System.Double  
Dim Val2 As System.Double  
Dim Z1 As System.Double  
Dim Val3 As System.Double  
Dim Val4 As System.Double  
Dim Z2 As System.Double  
Dim Val3x As System.Double  
Dim Val3y As System.Double  
Dim Z3 As System.Double  
Dim Val5 As System.Boolean
```

```
instance.SketchRectangleAtAnyAngle(Val1, Val2, Z1, Val3, Val4, Z2, Val3x, Val3y, Z3, Val5)
```

C#

```
void SketchRectangleAtAnyAngle(  
    System.double Val1,  
    System.double Val2,  
    System.double Z1,  
    System.double Val3,  
    System.double Val4,  
    System.double Z2,  
    System.double Val3x,  
    System.double Val3y,  
    System.double Z3,  
    System.bool Val5  
)
```

C++/CLI

```
void SketchRectangleAtAnyAngle(  
& System.double Val1,  
& System.double Val2,  
& System.double Z1,  
& System.double Val3,  
& System.double Val4,  
& System.double Z2,  
& System.double Val3x,  
& System.double Val3y,
```

```
& System.double Z3,  
& System.bool Val5  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Val1

Val2

Z1

Val3

Val4

Z2

Val3x

Val3y

Z3

Val5

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchRectangleAtAnyAngle](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchSpline Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchSpline Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchSpline](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchSpline( _  
    ByVal MorePts As System.Integer, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim MorePts As System.Integer  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double
```

```
instance.SketchSpline(MorePts, X, Y, Z)
```

C#

```
void SketchSpline(  
    System.int MorePts,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
void SketchSpline(
& System.int MorePts,
& System.double X,
& System.double Y,
& System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MorePts

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchSpline](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchSplineByEqnParams Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchSplineByEqnParams Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchSplineByDqnParams](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SketchSplineByEqnParams( _
    ByVal ParamsIn As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
Dim ParamsIn As System.Object
Dim value As System.Boolean
```

```
value = instance.SketchSplineByEqnParams(ParamsIn)
```

C#

```
System.bool SketchSplineByEqnParams(
    System.object ParamsIn
)
```

C++/CLI

```
System.bool SketchSplineByEqnParams(
& System.Object^ ParamsIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ParamsIn

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchSplineByEqnParams](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchSplineByEqnParams2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchSplineByEqnParams2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchSplineByEqnParams2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SketchSplineByEqnParams2( _  
    ByVal ParamsIn As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim ParamsIn As System.Object  
Dim value As System.Boolean  
  
value = instance.SketchSplineByEqnParams2(ParamsIn)
```

C#

```
System.bool SketchSplineByEqnParams2(  
    System.object ParamsIn  
)
```

C++/CLI

```
System.bool SketchSplineByEqnParams2(  
& System.Object^ ParamsIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ParamsIn

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchSplineByEqnParams2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchTangentArc Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchTangentArc Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchTangentArc](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchTangentArc()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.SketchTangentArc()
```

C#

```
void SketchTangentArc()
```

C++/CLI

```
void SketchTangentArc();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchTangentArc](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchTrim Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchTrim Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchTrim](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchTrim( _  
    ByVal Op As System.Integer, _  
    ByVal SelEnd As System.Integer, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Op As System.Integer  
Dim SelEnd As System.Integer  
Dim X As System.Double  
Dim Y As System.Double  
  
instance.SketchTrim(Op, SelEnd, X, Y)
```

C#

```
void SketchTrim(
    System.int Op,
    System.int SelEnd,
    System.double X,
    System.double Y
)
```

C++/CLI

```
void SketchTrim(
    & System.int Op,
    & System.int SelEnd,
    & System.double X,
    & System.double Y
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Op

SelEnd

X

Y

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchTrim](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchUndo Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchUndo Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchUndo](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchUndo()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc
instance.SketchUndo()
```

C#

```
void SketchUndo()
```

C++/CLI

```
void SketchUndo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchUndo](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchUseEdge Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchUseEdge Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchUseEdge](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchUseEdge()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.SketchUseEdge()
```

C#

```
void SketchUseEdge()
```

C++/CLI

```
void SketchUseEdge();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchUseEdge](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchUseEdge2 Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchUseEdge2 Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchUseEdge2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SketchUseEdge2( _  
    ByVal Chain As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim Chain As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SketchUseEdge2(Chain)
```

C#

```
System.bool SketchUseEdge2(  
    System.bool Chain  
)
```

C++/CLI

```
System.bool SketchUseEdge2(  
& System.bool Chain  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Chain

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchUseEdge2](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchUseEdgeCtrline Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SketchUseEdgeCtrline Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SketchUseEdgeCtrline](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SketchUseEdgeCtrline()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
  
instance.SketchUseEdgeCtrline()
```

C#

```
void SketchUseEdgeCtrline()
```

C++/CLI

```
void SketchUseEdgeCtrline();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SketchUseEdgeCtrline](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SkToolsAutoConstr Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SkToolsAutoConstr Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SkToolsAutoConstr](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SkToolsAutoConstr()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.SkToolsAutoConstr()
```

C#

```
void SkToolsAutoConstr()
```

C++/CLI

```
void SkToolsAutoConstr();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SkToolsAutoConstr](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SplitClosedSegment Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SplitClosedSegment Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SplitClosedSegment](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SplitClosedSegment( _  
    ByVal X0 As System.Double, _  
    ByVal Y0 As System.Double, _  
    ByVal Z0 As System.Double, _  
    ByVal X1 As System.Double, _  
    ByVal Y1 As System.Double, _  
    ByVal Z1 As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim X0 As System.Double  
Dim Y0 As System.Double  
Dim Z0 As System.Double  
Dim X1 As System.Double  
Dim Y1 As System.Double  
Dim Z1 As System.Double  
  
instance.SplitClosedSegment(X0, Y0, Z0, X1, Y1, Z1)
```

C#

```
void SplitClosedSegment(  
    System.double X0,  
    System.double Y0,  
    System.double Z0,  
    System.double X1,  
    System.double Y1,  
    System.double Z1  
)
```

C++/CLI

```
void SplitClosedSegment(  
& System.double X0,  
& System.double Y0,  
& System.double Z0,  
& System.double X1,  
& System.double Y1,  
& System.double Z1  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X0

Y0

Z0

X1

Y1

Z1

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SplitClosedSegment](#).

See Also

[IModelDoc Interface](#)

[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SplitOpenSegment Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SplitOpenSegment Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SplitOpenSegment](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SplitOpenSegment( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
)
```

Visual Basic (Usage)



Copy Code

```
Dim instance As IModelDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
  
instance.SplitOpenSegment(X, Y, Z)
```

C#

```
void SplitOpenSegment(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
void SplitOpenSegment(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SplitOpenSegment](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SummaryInfo Property (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : SummaryInfo Property (IModelDoc)

Obsolete. Superseded by [IModelDoc2::SummaryInfo](#).

.NET Syntax

Visual Basic (Declaration)

```
Property SummaryInfo( _  
    ByVal FieldId As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim FieldId As System.Integer  
Dim value As System.String  
  
instance.SummaryInfo(FieldId) = value  
  
value = instance.SummaryInfo(FieldId)
```

C#

```
System.string SummaryInfo(  
    System.int FieldId  
) {get; set;}
```

C++/CLI

```
property System.String^ SummaryInfo {  
    System.String^ get(System.int FieldId);  
    void set (System.int FieldId, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldId

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::SummaryInfo](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Toolbars Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : Toolbars Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::Toolbars](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub Toolbars(  
    ByVal M As System.Boolean, _  
    ByVal Vw As System.Boolean, _  
    ByVal SkMain As System.Boolean, _  
    ByVal Sk As System.Boolean, _  
    ByVal Feat As System.Boolean, _  
    ByVal Constr As System.Boolean, _  
    ByVal Macro As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
Dim M As System.Boolean  
Dim Vw As System.Boolean  
Dim SkMain As System.Boolean  
Dim Sk As System.Boolean  
Dim Feat As System.Boolean  
Dim Constr As System.Boolean  
Dim Macro As System.Boolean
```

```
instance.Toolbars(M, Vw, SkMain, Sk, Feat, Constr, Macro)
```

C#

```
void Toolbars(  
    System.bool M,  
    System.bool Vw,  
    System.bool SkMain,  
    System.bool Sk,  
    System.bool Feat,
```

```
System.bool Constr,  
System.bool Macro  
)
```

C++/CLI

```
void Toolbars(  
& System.bool M,  
& System.bool Vw,  
& System.bool SkMain,  
& System.bool Sk,  
& System.bool Feat,  
& System.bool Constr,  
& System.bool Macro  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

M

Vw

SkMain

Sk

Feat

Constr

Macro

 Visual Basic for Applications (VBA) Syntax

See [ModelDoc::Toolbars](#).

 See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ToolsDistance Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ToolsDistance Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ToolsDistance](#).

 .NET Syntax

Visual Basic (Declaration)

```
Sub ToolsDistance()
```

Visual Basic (Usage)

```
Dim instance As IModelDoc  
instance.ToolsDistance()
```

C#

```
void ToolsDistance()
```

C++/CLI

```
void ToolsDistance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ToolsDistance](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ToolsGrid Method (IModelDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IModelDoc Interface](#) : ToolsGrid Method (IModelDoc)

Obsolete. Superseded by [IModelDoc2::ToolsGrid](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ToolsGrid()
```

Visual Basic (Usage)



```
Dim instance As IModelDoc  
instance.ToolsGrid()
```

C#

```
void ToolsGrid()
```

C++/CLI

```
void ToolsGrid();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ModelDoc::ToolsGrid](#).

See Also

[IModelDoc Interface](#)
[IModelDoc Members](#)