

SOLIDWORKS API (.NET VBA C#) — Reference (218/337): IPartDoc (part 1 of 4)

SOLIDWORKS API Documentation (converted from CHM)

IPartDoc (part 1 of 4) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPartDoc Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartDoc Interface

Provides access to functions that perform operations on parts in part documents.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPartDoc
```

Visual Basic (Usage)



```
Dim instance As IPartDoc
```

C#

```
public interface IPartDoc
```

C++/CLI

```
public interface class IPartDoc
```

Visual Basic for Applications (VBA) Syntax

See [PartDoc](#).

Example

[Get Sketches \(C++\)](#)
[Traverse Bodies \(C++\)](#)
[Create Imported Surface Body From Sketch \(C#\)](#)
[Get Differences Between Parts \(VBA\)](#)
[Import Step File \(C#\)](#)
[Import Step File \(VB.NET\)](#)
[Import Step File \(VBA\)](#)

Remarks

This interface provides functions that allow you to:

- create bodies and features.
- perform suppress operations.
- obtain part extents and tessellation.
- locate entities by name.

The SOLIDWORKS API also has functions that are common to all document types. For example, determining the file name associated with a document would be a common operation. To expose common document-level functions, the SOLIDWORKS API uses the [IModelDoc2](#) object.

Events are implemented with delegates in the Microsoft .NET Framework. See the [Overview](#) topic for a list of delegates for this interface.

Accessors

[IBeltChainFeatureData::AccessBeltPart](#)

Access Diagram

[PartDoc](#)

See Also

IPartDoc Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartDoc Interface

For a list of all members of this type, see [IPartDoc members](#).

Public Methods

Name	Description
AddPropertyExtension	Adds a property extension to this part.
Body	Obsolete. Superseded by IPartDoc::GetBodies2 and IPartDoc::EnumBodies3 .
CreateExplodedView	Creates an explode view of this multibody part.
CreateFeatureFromBody	Obsolete. Superseded by IPartDoc::CreateFeatureFromBody3 .
CreateFeatureFromBody2	Obsolete. Superseded by IPartDoc::CreateFeatureFromBody3 .
CreateFeatureFromBody3	Creates a new imported feature from the specified temporary body.
CreateNewBody	Creates a new body to use for import sewing operations and returns it to the caller.
CreateSurfaceFeatureFromBody	Creates a surface feature from a body.
DeleteEntityName	Deletes the name associated with the specified entity.
EditRebuild	Obsolete. Superseded by IModelDoc2::EditRebuild3 .
EditRollback	Rolls back the part's history to the feature just before the currently selected feature in the FeatureManager design tree.
EditSuppress	Obsolete. Superseded by IModelDoc2::EditSuppress2 .
EditUnsuppress	Obsolete. Superseded by IModelDoc2::EditUnsuppress2 .
EditUnsuppressDependent	Obsolete. Superseded by IModelDoc2::EditUnsuppressDependent2 .
EnumBodies	Obsolete. Superseded by IPartDoc::EnumBodies3 .
EnumBodies2	Obsolete. Superseded by IPartDoc::EnumBodies3 .
EnumBodies3	Enumerates the bodies in this part.
EnumRelatedBodies	Obsolete. Superseded by IPartDoc::EnumRelatedBodies2 .
EnumRelatedBodies2	Creates an enumerated list of bodies.
EnumRelatedSectionedBodies	Obsolete. Superseded by IPartDoc::EnumRelatedSectionedBodies .
EnumRelatedSectionedBodies2	Gets an enumeration of the related sectioned bodies in a part.
ExportFlatPatternView	Obsolete. Superseded by IPartDoc::ExportToDWG2 .
ExportToDWG	Obsolete. Superseded by IPartDoc::ExportToDWG2 .
ExportToDWG2	Saves various aspects of a part (sheet metal, faces, loops, and annotation views) to one or more DXF/DWG files, preserving the specified file name.
FeatureById	Gets the feature with the specified ID in the part.
FeatureByName	Gets the named feature in the part.
FeatureExtrusion	Obsolete. Superseded by IFeatureManager::FeatureExtrusion2 .
FeatureExtrusion2	Obsolete. Superseded by IFeatureManager::FeatureExtrusion2 .
FeatureExtrusion3	Obsolete. Superseded by IFeatureManager::FeatureExtrusion2 .
FeatureExtrusionThin	Obsolete. Superseded by IFeatureManager::FeatureExtrusionThin2 .
FeatureExtrusionThin2	Obsolete. Superseded by IFeatureManager::FeatureExtrusionThin2 .
FeatureExtrusionThin3	Obsolete. Superseded by IFeatureManager::FeatureExtrusionThin2 .
FeatureRevolve	Obsolete. Superseded by IFeatureManager::FeatureRevolve .
FeatureRevolve2	Obsolete. Superseded by IFeatureManager::FeatureRevolve .
FeatureRevolveCut	Obsolete. Superseded by IFeatureManager::FeatureRevolveCut .

		
	FeatureRevolveThin	Obsolete. Superseded by IFeatureManager.FeatureRevolveThin .
	FeatureRevolveThin2	Obsolete. Superseded by IFeatureManager.FeatureRevolveThin .
	FeatureRevolveThinCut	Obsolete. Superseded by IFeatureManager.FeatureRevolveThinCut .
	FeatureXpert	Executes FeatureXpert, powered by SOLIDWORKS Intelligent Feature Technology (SWIFT), in parts.
	FirstFeature	Gets the first feature in the part.
	ForceRebuild	Obsolete. Superseded by IModelDoc2_ForceRebuild3 .
	GetBodies	Obsolete. Superseded by IPartDoc.GetBodies2 .
	GetBodies2	Gets the bodies in this part.
	GetCorresponding	Obsolete. Superseded by IModelDocExtension.GetCorresponding .
	GetCorrespondingEntity	Obsolete. Superseded by IModelDocExtension.GetCorrespondingEntity .
	GetEntityByName	Gets an entity (face, edge, vertex) by name.
	GetEntityName	Gets the name of the specified entity.
	GetExplodedViewConfigurationName	Gets the name of the configuration for the specified explode view of this multibody part.
	GetExplodedViewCount	Gets the number of explode views in the specified configuration of this multibody part.
	GetExplodedViewNames	Gets the names of all the explode views in the specified configuration of this multibody part.
	GetMateReferenceEntity	Gets the mate reference entity.
	GetMaterialPropertyName	Obsolete. Superseded by IPartDoc.GetMaterialPropertyName2 .
	GetMaterialPropertyName2	Gets the names of the material database and the material for the specified configuration.
	GetMaterialVisualProperties	Gets the material visual properties for this part.
	GetNamedEntities	Gets an array of names of named entities (face, edge, vertex, and so on) in this part.
	GetNamedEntitiesCount	Gets the number of named entities (face, edge, vertex, and so on) in this part.
	GetPartBox	Gets the box enclosing the part.
	GetProcessedBody	Obsolete. Superseded by IBody2.GetProcessedBody2 and IPartDoc.IGetProcessedBody2 .
	GetPropertyExtension	Gets the specified property extension on this part document.
	GetRelatedBodies	Creates a list of all the related bodies in a part.
	GetRelatedSectionedBodies	Gets all of the related sectioned bodies in a part.
	GetSectionedBody	Gets the sectioned body seen in the specified drawing view.
	GetTessNorms	Gets the normal vector for each of the triangles, which make up the shaded picture tessellation.
	GetTessTriangleCount	Gets the number of triangles that make up the shaded picture tessellation for this part.
	GetTessTriangles	Gets the triangles that make up the shaded picture tessellation for this part.
	GetTessTriStripEdges	Gets the edge ID for each of the edges in the triangles that make up the tessellation for this part.
	GetTessTriStripNorms	Gets the normal vector for each of the triangles, which make up the shaded picture tessellation for this part.
	GetTessTriStrips	Gets the vertices that make up the shaded picture tessellation for this part.
	GetTessTriStripSize	Gets the size of the array floats required to contain the data returned when calling IPartDoc.GetTessTriStrips and IPartDoc.IGetTessTriStrips .
	GetTessTriStripTextures	Gets the texture coordinate components for each vertex on each triangle strip on each face of this part.
	IBodyObject	Obsolete. Superseded by IPartDoc.GetBodies2 and IPartDoc.EnumBodies3 .
	IBodyObject2	Obsolete. Superseded by IPartDoc.GetBodies2 and IPartDoc.EnumBodies3 .
	ICreateFeatureFromBody	Obsolete. Superseded by IPartDoc.ICreateFeatureFromBody4 .
	ICreateFeatureFromBody2	Obsolete. Superseded by IPartDoc.ICreateFeatureFromBody4 .
	ICreateFeatureFromBody3	Obsolete. Superseded by IPartDoc.ICreateFeatureFromBody4 .
	ICreateFeatureFromBody4	Creates a new imported feature from the specified temporary body.
	ICreateNewBody	Obsolete. Superseded by IPartDoc.ICreateNewBody2 .

	ICreateNewBody2	Creates a new body to use for import sewing operations and returns it to the caller.
	ICreateSurfaceFeatureFromBody	Creates a surface feature from a body.
	ICreateSurfaceFeatureFromBodyCount	Obsolete. Superseded by IPartDoc:ICreateSurfaceFeatureFromBodyCount2 .
	ICreateSurfaceFeatureFromBodyCount2	Gets the number of surface features to create from the body.
	IDeleteEntityName	Deletes the name associated with the specified entity.
	IExportToDWG	Obsolete. Superseded by IPartDoc:IExportToDWG2
	IExportToDWG2	Saves various aspects of a part (sheet metal, faces, loops, and annotation views) to one or more DXF/DWG files, preserving the specified filename.
	IFeatureById	Gets the feature with the specified ID in the part.
	IFeatureByName	Gets the named feature in the part.
	IFirstFeature	Gets the first feature in the part.
	IGetCorrespondingEntity	Obsolete. Superseded by IModelDocExtension:GetCorrespondingEntity
	IGetEntityByName	Gets an entity (face, edge, vertex) by name.
	IGetEntityName	Gets the name of the specified entity.
	IGetNamedEntities	Gets an array of names of named entities (face, edge, vertex, and so on) in this part.
	IGetPartBox	Gets the box enclosing the part.
	IGetProcessedBody	Obsolete. Superseded by IPartDoc:IGetProcessedBody2 .
	IGetProcessedBody2	Pre-processes the geometry of a body so that: • Closed periodic faces (for example, the lateral face of a cylinder) are split into two faces. • Faces that straddle the seam, if any, of the underlying surface are split into two faces.
	IGetProcessedBodyWithSelfFace	Obsolete. Superseded by IPartDoc:IGetProcessedBodyWithSelfFace2 .
	IGetProcessedBodyWithSelfFace2	Gets a processed body.
	IGetSectionedBody	Obsolete. Superseded by IPartDoc:IGetSectionedBody2 .
	IGetSectionedBody2	Gets the sectioned body seen in the specified drawing view.
	IGetTessNorms	Gets the normal vector for each of the triangles, which make up the shaded picture tessellation.
	IGetTessTriangles	Gets the triangles that make up the shaded picture tessellation for this part.
	IGetTessTriStripEdges	Gets the edge ID for each of the edges in the triangles that make up the tessellation for this part.
	IGetTessTriStripEdgeSize	Gets the size of the array returned by IPartDoc:IGetTessTriStripEdges and IPartDoc:IGetTessTriStripEdges .
	IGetTessTriStripNorms	Gets the normal vector for each of the triangles, which make up the shaded picture tessellation for this part.
	IGetTessTriStrips	Gets the vertices that make up the shaded picture tessellation for this part.
	ImportDiagnosis	Diagnoses and repairs any gaps or bad faces on imported features.
	ImportDiagnosisGapCloser	Allows you to repair a gap by moving the vertices on the edges surrounding the gap to new positions to close the gap on the imported model.
	InsertBasePart	Obsolete. Superseded by IPartDoc:InsertPart
	InsertBendNotes	Inserts bend notes for the specified flat-pattern feature of this sheet metal part.
	InsertBends	Obsolete. Superseded by IPartDoc:InsertBends2
	InsertBends2	Creates bends in a thin-feature part.
	InsertBendTable	Creates a bend table annotation for the flat pattern of this sheet metal part.
	InsertImportedFeature	Inserts a third-party native CAD file into this part.
	InsertMirrorAll	Mirrors the part about a selected planar face.
	InsertMirrorFeature	Obsolete. Superseded by IFeatureManager:InsertMirrorFeature .
	InsertPart	Obsolete. Superseded by IPartDoc:InsertPart2 .
	InsertPart2	Obsolete. Superseded by IPartDoc:InsertPart3 .

 InsertPart3	Inserts the specified part in the specified configuration into this part.
 ISetEntityName	Sets the name of the entity if the entity does not have a name.
 IsMirrored	Gets whether this part is mirrored.
 IsWeldment	Gets whether this part contains a weldment feature.
 MakeSection	Saves sketch profiles for use in the wizard.
 MirrorFeature	Displays a dialog that allows the end-user to mirror a feature about a selected plane or planar face.
 MirrorPart	Obsolete. Superseded by IPartDoc.MirrorPart2 .
 MirrorPart2	Creates a new part document that mirrors this part about a selected reference plane or planar face.
 RemoveAllDisplayStates	Removes all display states and appearances from this part document.
 ReorderFeature	Reorders features and their operations.
 ResetPropertyExtension	Clears all values stored in the property extension.
 SaveToFile	Obsolete. Superseded by IPartDoc.SaveToFile2 .
 SaveToFile2	Obsolete. Superseded by IPartDoc.SaveToFile3 .
 SaveToFile3	Saves the selected weldment member, surface body, or solid body to another part document.
 SetCosmosWorksMaterial	Assigns the material to use during analysis to this part.
 SetDroppedFileName	Sets the filename for a recently dropped file.
 SetEntityName	Sets the name of the entity if the entity does not have a name and the name is unique to the part.
 SetLineColor	Sets the color for the lines in the part document.
 SetLineStyle	Sets the style or font for the lines in the part document.
 SetLineWidth	Sets the thickness or weight for the lines in the part document.
 SetMaterialPropertyName	Obsolete. Superseded by IPartDoc.SetMaterialPropertyName2 .
 SetMaterialPropertyName2	Sets the name of the material property for the specified configuration.
 SetMaterialVisualProperties	Sets the material visual properties for the active configuration and any specified configurations of this part.
 ShowExploded	Displays the specified explode view for this multibody part.

[Top](#)

 See Also

[IPartDoc Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPartDoc Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IPartDoc Interface

The following tables list the members exposed by [IPartDoc](#).

 Public Properties

Name	Description
 IMaterialPropertyValues	Gets or sets a material's properties in the active configuration.
 MaterialIdName	Gets or sets the material name.
 MaterialPropertyValues	Gets or sets a material's properties in the active configuration.
 MaterialUserName	Gets or sets the material name. This name is visible to the user.

[Top](#)

 Public Methods

Name	Description
------	-------------

	AddPropertyExtension	Adds a property extension to this part.
	Body	Obsolete. Superseded by IPartDoc::GetBodies2 and IPartDoc::EnumBodies3 .
	CreateExplodedView	Creates an explode view of this multibody part.
	CreateFeatureFromBody	Obsolete. Superseded by IPartDoc::CreateFeatureFromBody3 .
	CreateFeatureFromBody2	Obsolete. Superseded by IPartDoc::CreateFeatureFromBody3 .
	CreateFeatureFromBody3	Creates a new imported feature from the specified temporary body.
	CreateNewBody	Creates a new body to use for import sewing operations and returns it to the caller.
	CreateSurfaceFeatureFromBody	Creates a surface feature from a body.
	DeleteEntityName	Deletes the name associated with the specified entity.
	EditRebuild	Obsolete. Superseded by IModelDoc2::EditRebuild3 .
	EditRollback	Rolls back the part's history to the feature just before the currently selected feature in the FeatureManager design tree.
	EditSuppress	Obsolete. Superseded by IModelDoc2::EditSuppress2 .
	EditUnsuppress	Obsolete. Superseded by IModelDoc2::EditUnsuppress2 .
	EditUnsuppressDependent	Obsolete. Superseded by IModelDoc2::EditUnsuppressDependent2 .
	EnumBodies	Obsolete. Superseded by IPartDoc::EnumBodies3 .
	EnumBodies2	Obsolete. Superseded by IPartDoc::EnumBodies3 .
	EnumBodies3	Enumerates the bodies in this part.
	EnumRelatedBodies	Obsolete. Superseded by IPartDoc::EnumRelatedBodies2 .
	EnumRelatedBodies2	Creates an enumerated list of bodies.
	EnumRelatedSectionedBodies	Obsolete. Superseded by IPartDoc::EnumRelatedSectionedBodies .
	EnumRelatedSectionedBodies2	Gets an enumeration of the related sectioned bodies in a part.
	ExportFlatPatternView	Obsolete. Superseded by IPartDoc::ExportToDWG2 .
	ExportToDWG	Obsolete. Superseded by IPartDoc::ExportToDWG2 .
	ExportToDWG2	Saves various aspects of a part (sheet metal, faces, loops, and annotation views) to one or more DXF/DWG files, preserving the specified file name.
	FeatureById	Gets the feature with the specified ID in the part.
	FeatureByName	Gets the named feature in the part.
	FeatureExtrusion	Obsolete. Superseded by IFeatureManager::FeatureExtrusion2 .
	FeatureExtrusion2	Obsolete. Superseded by IFeatureManager::FeatureExtrusion2 .
	FeatureExtrusion3	Obsolete. Superseded by IFeatureManager::FeatureExtrusion2 .
	FeatureExtrusionThin	Obsolete. Superseded by IFeatureManager::FeatureExtrusionThin2 .
	FeatureExtrusionThin2	Obsolete. Superseded by IFeatureManager::FeatureExtrusionThin2 .
	FeatureExtrusionThin3	Obsolete. Superseded by IFeatureManager::FeatureExtrusionThin2 .
	FeatureRevolve	Obsolete. Superseded by IFeatureManager::FeatureRevolve .
	FeatureRevolve2	Obsolete. Superseded by IFeatureManager::FeatureRevolve .
	FeatureRevolveCut	Obsolete. Superseded by IFeatureManager::FeatureRevolveCut .
	FeatureRevolveThin	Obsolete. Superseded by IFeatureManager::FeatureRevolveThin .
	FeatureRevolveThin2	Obsolete. Superseded by IFeatureManager::FeatureRevolveThin .
	FeatureRevolveThinCut	Obsolete. Superseded by IFeatureManager::FeatureRevolveThinCut .
	FeatureXpert	Executes FeatureXpert, powered by SOLIDWORKS Intelligent Feature Technology (SWIFT), in parts.
	FirstFeature	Gets the first feature in the part.
	ForceRebuild	Obsolete. Superseded by IModelDoc2::ForceRebuild3 .
	GetBodies	Obsolete. Superseded by IPartDoc::GetBodies2 .
	GetBodies2	Gets the bodies in this part.

		
	GetCorresponding	Obsolete. Superseded by IModelDocExtension::GetCorresponding
	GetCorrespondingEntity	Obsolete. Superseded by IModelDocExtension::GetCorrespondingEntity
	GetEntityByName	Gets an entity (face, edge, vertex) by name.
	GetEntityName	Gets the name of the specified entity.
	GetExplodedViewConfigurationName	Gets the name of the configuration for the specified explode view of this multibody part.
	GetExplodedViewCount	Gets the number of explode views in the specified configuration of this multibody part.
	GetExplodedViewNames	Gets the names of all the explode views in the specified configuration of this multibody part.
	GetMateReferenceEntity	Gets the mate reference entity.
	GetMaterialPropertyName	Obsolete. Superseded by IPartDoc::GetMaterialPropertyName2 .
	GetMaterialPropertyName2	Gets the names of the material database and the material for the specified configuration.
	GetMaterialVisualProperties	Gets the material visual properties for this part.
	GetNamedEntities	Gets an array of names of named entities (face, edge, vertex, and so on) in this part.
	GetNamedEntitiesCount	Gets the number of named entities (face, edge, vertex, and so on) in this part.
	GetPartBox	Gets the box enclosing the part.
	GetProcessedBody	Obsolete. Superseded by IBody2::GetProcessedBody2 and IPartDoc::IGetProcessedBody2 .
	GetPropertyExtension	Gets the specified property extension on this part document.
	GetRelatedBodies	Creates a list of all the related bodies in a part.
	GetRelatedSectionedBodies	Gets all of the related sectioned bodies in a part.
	GetSectionedBody	Gets the sectioned body seen in the specified drawing view.
	GetTessNorms	Gets the normal vector for each of the triangles, which make up the shaded picture tessellation.
	GetTessTriangleCount	Gets the number of triangles that make up the shaded picture tessellation for this part.
	GetTessTriangles	Gets the triangles that make up the shaded picture tessellation for this part.
	GetTessTriStripEdges	Gets the edge ID for each of the edges in the triangles that make up the tessellation for this part.
	GetTessTriStripNorms	Gets the normal vector for each of the triangles, which make up the shaded picture tessellation for this part.
	GetTessTriStrips	Gets the vertices that make up the shaded picture tessellation for this part.
	GetTessTriStripSize	Gets the size of the array floats required to contain the data returned when calling IPartDoc::GetTessTriStrips and IPartDoc::IGetTessTriStrips .
	GetTessTriStripTextures	Gets the texture coordinate components for each vertex on each triangle strip on each face of this part.
	IBodyObject	Obsolete. Superseded by IPartDoc::GetBodies2 and IPartDoc::EnumBodies3 .
	IBodyObject2	Obsolete. Superseded by IPartDoc::GetBodies2 and IPartDoc::EnumBodies3 .
	ICreateFeatureFromBody	Obsolete. Superseded by IPartDoc::ICreateFeatureFromBody4 .
	ICreateFeatureFromBody2	Obsolete. Superseded by IPartDoc::ICreateFeatureFromBody4 .
	ICreateFeatureFromBody3	Obsolete. Superseded by IPartDoc::ICreateFeatureFromBody4 .
	ICreateFeatureFromBody4	Creates a new imported feature from the specified temporary body.
	ICreateNewBody	Obsolete. Superseded by IPartDoc::ICreateNewBody2 .
	ICreateNewBody2	Creates a new body to use for import sewing operations and returns it to the caller.
	ICreateSurfaceFeatureFromBody	Creates a surface feature from a body.
	ICreateSurfaceFeatureFromBodyCount	Obsolete. Superseded by IPartDoc::ICreateSurfaceFeatureFromBodyCount2 .
	ICreateSurfaceFeatureFromBodyCount2	Gets the number of surface features to create from the body.
	IDeleteEntityName	Deletes the name associated with the specified entity.
	IExportToDWG	Obsolete. Superseded by IPartDoc::IExportToDWG2 .
	IExportToDWG2	Saves various aspects of a part (sheet metal, faces, loops, and annotation views) to one or more DXF/DWG files, preserving the specified filename.
	IFeatureById	Gets the feature with the specified ID in the part.

	IFeatureByName	Gets the named feature in the part.
	IFirstFeature	Gets the first feature in the part.
	IGetCorrespondingEntity	Obsolete. Superseded by IModelDocExtension::GetCorrespondingEntity
	IGetEntityByName	Gets an entity (face, edge, vertex) by name.
	IGetEntityName	Gets the name of the specified entity.
	IGetNamedEntities	Gets an array of names of named entities (face, edge, vertex, and so on) in this part.
	IGetPartBox	Gets the box enclosing the part.
	IGetProcessedBody	Obsolete. Superseded by IPartDoc::IGetProcessedBody2 .
	IGetProcessedBody2	Pre-processes the geometry of a body so that: • Closed periodic faces (for example, the lateral face of a cylinder) are split into two faces. • Faces that straddle the seam, if any, of the underlying surface are split into two faces.
	IGetProcessedBodyWithSelfFace	Obsolete. Superseded by IPartDoc::IGetProcessedBodyWithSelfFace2 .
	IGetProcessedBodyWithSelfFace2	Gets a processed body.
	IGetSectionedBody	Obsolete. Superseded by IPartDoc::IGetSectionedBody2 .
	IGetSectionedBody2	Gets the sectioned body seen in the specified drawing view.
	IGetTessNorms	Gets the normal vector for each of the triangles, which make up the shaded picture tessellation.
	IGetTessTriangles	Gets the triangles that make up the shaded picture tessellation for this part.
	IGetTessTriStripEdges	Gets the edge ID for each of the edges in the triangles that make up the tessellation for this part.
	IGetTessTriStripEdgeSize	Gets the size of the array returned by IPartDoc::GetTessTriStripEdges and IPartDoc::IGetTessTriStripEdges .
	IGetTessTriStripNorms	Gets the normal vector for each of the triangles, which make up the shaded picture tessellation for this part.
	IGetTessTriStrips	Gets the vertices that make up the shaded picture tessellation for this part.
	ImportDiagnosis	Diagnoses and repairs any gaps or bad faces on imported features.
	ImportDiagnosisGapCloser	Allows you to repair a gap by moving the vertices on the edges surrounding the gap to new positions to close the gap on the imported model.
	InsertBasePart	Obsolete. Superseded by IPartDoc::InsertPart .
	InsertBendNotes	Inserts bend notes for the specified flat-pattern feature of this sheet metal part.
	InsertBends	Obsolete. Superseded by IPartDoc::InsertBends2 .
	InsertBends2	Creates bends in a thin-feature part.
	InsertBendTable	Creates a bend table annotation for the flat pattern of this sheet metal part.
	InsertImportedFeature	Inserts a third-party native CAD file into this part.
	InsertMirrorAll	Mirrors the part about a selected planar face.
	InsertMirrorFeature	Obsolete. Superseded by IFeatureManager::InsertMirrorFeature .
	InsertPart	Obsolete. Superseded by IPartDoc::InsertPart2 .
	InsertPart2	Obsolete. Superseded by IPartDoc::InsertPart3 .
	InsertPart3	Inserts the specified part in the specified configuration into this part.
	ISetEntityName	Sets the name of the entity if the entity does not have a name.
	IsMirrored	Gets whether this part is mirrored.
	IsWeldment	Gets whether this part contains a weldment feature.
	MakeSection	Saves sketch profiles for use in the wizard.
	MirrorFeature	Displays a dialog that allows the end-user to mirror a feature about a selected plane or planar face.
	MirrorPart	Obsolete. Superseded by IPartDoc::MirrorPart2 .
	MirrorPart2	Creates a new part document that mirrors this part about a selected reference plane or planar face.

	RemoveAllDisplayStates	Removes all display states and appearances from this part document.
	ReorderFeature	Reorders features and their operations.
	ResetPropertyExtension	Clears all values stored in the property extension.
	SaveToFile	Obsolete. Superseded by IPartDoc.SaveToFile2 .
	SaveToFile2	Obsolete. Superseded by IPartDoc.SaveToFile3 .
	SaveToFile3	Saves the selected weldment member, surface body, or solid body to another part document.
	SetCosmosWorksMaterial	Assigns the material to use during analysis to this part.
	SetDroppedFileName	Sets the filename for a recently dropped file.
	SetEntityName	Sets the name of the entity if the entity does not have a name and the name is unique to the part.
	SetLineColor	Sets the color for the lines in the part document.
	SetLineStyle	Sets the style or font for the lines in the part document.
	SetLineWidth	Sets the thickness or weight for the lines in the part document.
	SetMaterialPropertyName	Obsolete. Superseded by IPartDoc.SetMaterialPropertyName2 .
	SetMaterialPropertyName2	Sets the name of the material property for the specified configuration.
	SetMaterialVisualProperties	Sets the material visual properties for the active configuration and any specified configurations of this part.
	ShowExploded	Displays the specified explode view for this multibody part.

[Top](#)

See Also

[IPartDoc Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPartDoc Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPartDoc Interface

For a list of all members of this type, see [IPartDoc members](#).

Public Properties

Name	Description
 IMaterialPropertyValues	Gets or sets a material's properties in the active configuration.
 MaterialIdName	Gets or sets the material name.
 MaterialPropertyValues	Gets or sets a material's properties in the active configuration.
 MaterialUserName	Gets or sets the material name. This name is visible to the user.

[Top](#)

See Also

[IPartDoc Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddPropertyExtension Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : AddPropertyExtension Method (IPartDoc)

Adds a property extension to this part.

.NET Syntax

Visual Basic (Declaration)

```
Function AddPropertyExtension( _
    ByVal PropertyExtension As System.Object _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPartDoc
Dim PropertyExtension As System.Object
Dim value As System.Integer

value = instance.AddPropertyExtension(PropertyExtension)
```

C#

```
System.int AddPropertyExtension(
    System.object PropertyExtension
)
```

C++/CLI

```
System.int AddPropertyExtension(
    & System.Object^ PropertyExtension
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropertyExtension

Value of the property extension to add to this part (see **Remarks**)

Return Value

Size of the array to which the property extension value is added

Visual Basic for Applications (VBA) Syntax

See [PartDoc::AddPropertyExtension](#).

Example

[Add and Get Property Extensions \(C#\)](#)
[Add and Get Property Extensions \(VB.NET\)](#)
[Add and Get Property Extensions \(VBA\)](#)

Remarks

To use this method:

1. Declare the variable.
2. Assign the variable a value: float, integer, or string.
3. Call this method to add the value to the part.

The 1-based array is a first-in-last-out structured list, whose size is used by [IPartDoc::GetPropertyExtension](#) to access the property extension. See the examples in **Example**.

NOTE: SOLIDWORKS recommends that you use the [IAttribute](#), [IAttributeDef](#), and [IParameter](#) interfaces instead of this method. These interface provide more flexibility.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::ResetPropertyExtension Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Body Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : Body Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::GetBodies2](#) and [IPartDoc::EnumBodies3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Body() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim value As System.Object  
  
value = instance.Body()
```

C#

```
System.object Body()
```

C++/CLI

```
System.Object^ Body();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartDoc::Body](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateExplodedView Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : CreateExplodedView Method (IPartDoc)

Creates an explode view of this multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateExplodedView() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim value As System.Boolean  
  
value = instance.CreateExplodedView()
```

C#

```
System.bool CreateExplodedView()
```

C++/CLI

```
System.bool CreateExplodedView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the explode view is successfully created, false if not

Visual Basic for Applications (VBA) Syntax

See [PartDoc::CreateExplodedView](#).

Example

See the [IPartExplodeStep](#) example.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IConfiguration::AddPartExplodeStep Method \(\)](#)
[IConfiguration::GetPartExplodeStep Method \(\)](#)
[IPartDoc::GetExplodedViewNames Method \(\)](#)
[IPartDoc::GetExplodedViewConfigurationName Method \(\)](#)
[IPartDoc::ShowExploded Method \(\)](#)
[IPartDoc::GetExplodedViewCount Method \(\)](#)
[IPartExplodeStep Interface](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateFeatureFromBody Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : CreateFeatureFromBody Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::CreateFeatureFromBody3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateFeatureFromBody( _  
    ByVal Body As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Body As System.Object  
Dim value As System.Object
```

```
value = instance.CreateFeatureFromBody(Body)
```

C#

```
System.object CreateFeatureFromBody(  
    System.object Body  
)
```

C++/CLI

```
System.Object^ CreateFeatureFromBody(  
& System.Object^ Body  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Body

Visual Basic for Applications (VBA) Syntax

See [PartDoc::CreateFeatureFromBody](#).

See Also

CreateFeatureFromBody2 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : CreateFeatureFromBody2 Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::CreateFeatureFromBody3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateFeatureFromBody2( _  
    ByVal Body As System.Object, _  
    ByVal MakeRefSurface As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Body As System.Object  
Dim MakeRefSurface As System.Boolean  
Dim value As System.Object  
  
value = instance.CreateFeatureFromBody2(Body, MakeRefSurface)
```

C#

```
System.object CreateFeatureFromBody2(  
    System.object Body,  
    System.bool MakeRefSurface  
)
```

C++/CLI

```
System.Object^ CreateFeatureFromBody2(  
& System.Object^ Body,  
& System.bool MakeRefSurface  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Body

MakeRefSurface

Visual Basic for Applications (VBA) Syntax

See [PartDoc::CreateFeatureFromBody2](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

CreateFeatureFromBody3 Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : CreateFeatureFromBody3 Method (IPartDoc)

Creates a new imported feature from the specified temporary body.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateFeatureFromBody3( _
    ByVal Body As System.Object, _
    ByVal MakeRefSurface As System.Boolean, _
    ByVal Options As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartDoc
Dim Body As System.Object
Dim MakeRefSurface As System.Boolean
Dim Options As System.Integer
Dim value As System.Object
```

```
value = instance.CreateFeatureFromBody3(Body, MakeRefSurface, Options)
```

C#

```
System.object CreateFeatureFromBody3(
    System.object Body,
    System.bool MakeRefSurface,
    System.int Options
)
```

C++/CLI

```
System.Object^ CreateFeatureFromBody3(
    & System.Object^ Body,
    & System.bool MakeRefSurface,
    & System.int Options
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Body

Temporary [body](#)

MakeRefSurface

If the body cannot be knitted to a solid or if a solid body already exists in this model, then True creates a reference surface feature

Options

Options as defined in [swCreateFeatureBodyOptions_e](#)

Return Value

Newly created imported [feature](#) or Nothing or NULL if the operation fails

Visual Basic for Applications (VBA) Syntax

See [PartDoc::CreateFeatureFromBody3](#).

Example

[Combine Assembly Components Into Part \(VBA\)](#)

[Delete Faces \(VBA\)](#)

[Get Differences Between Parts \(VBA\)](#)

[Get Sectioned Bodies \(VBA\)](#)

[Save Rollbacked Part as Parasolid File \(VBA\)](#)

[Create Sheet Body From Faces and Feature From Sheet Body \(VBA\)](#)

[Process Body \(C#\)](#)

[Process Body \(VB.NET\)](#)

[Process Body \(VBA\)](#)

[Delete Blended Faces \(C#\)](#)

[Delete Blended Faces \(VB.NET\)](#)

[Delete Blended Faces \(VBA\)](#)

Remarks

This method is intended to be the final call in a knitting operation. The body that results from your knitting efforts can be converted into an imported body feature in the SOLIDWORKS model. This method is not limited to body objects obtained from knitting operations.

This method allows the application to decide how much additional work needs to be done to the model before creating the feature. The options listed in the [swCreateFeatureBodyOptions_e](#) enumeration can be OR'd together to provide additional checking or simplification of the model. If you specify [swCreateFeatureBodySimplify](#) for Options, then [swCreateFeatureBodyCheck](#) is implied.

If the application passes 0 for the options argument, then the options are disabled and the model is passed without any checking. If so, it is up to the application to ensure that the model is a valid model.

If this method fails, the error might be caused by creating a sheet (surface) body from a multiple shells body. If so, replace this method with [IPartDoc::CreateSurfaceFeatureFromBody](#) or [IPartDoc::ICreateSurfaceFeatureFromBody](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::ICreateFeatureFromBody4 Method](#)

Availability

SOLIDWORKS 2000 SP1, Revision Number 8.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateNewBody Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : CreateNewBody Method (IPartDoc)

Creates a new body to use for import sewing operations and returns it to the caller.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateNewBody() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim value As System.Object  
  
value = instance.CreateNewBody()
```

C#

```
System.object CreateNewBody()
```

C++/CLI

```
System.Object^ CreateNewBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

New [body](#)

Visual Basic for Applications (VBA) Syntax

See [PartDoc::CreateNewBody](#).

Example

[Create Body Using Trimmed Surfaces \(VBA\)](#)
[Create Reference Curve \(C#\)](#)
[Create Reference Curve \(VB.NET\)](#)
[Create Reference Curve \(VBA\)](#)
[Create Imported Solid Body \(C#\)](#)
[Create Imported Solid Body \(VB.NET\)](#)
[Create Imported Solid Body \(VBA\)](#)

Remarks

The intention is that with a handle on such a (initially empty) body, appropriate construction methods (for example, [IBody2::CreateTrimmedSurface](#)) can be called that eventually amount to a non-trivial object.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::ICreateNewBody2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateSurfaceFeatureFromBody Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : CreateSurfaceFeatureFromBody Method (IPartDoc)

Creates a surface feature from a body.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSurfaceFeatureFromBody( _  
    ByVal Body As System.Object, _  
    ByVal Options As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Body As System.Object  
Dim Options As System.Integer  
Dim value As System.Object  
  
value = instance.CreateSurfaceFeatureFromBody(Body, Options)
```

C#

```
System.object CreateSurfaceFeatureFromBody(  
    System.object Body,  
    System.int Options  
)
```

C++/CLI

```
System.Object^ CreateSurfaceFeatureFromBody(  
& System.Object^ Body,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Body
[Body](#) from which to create surface feature
Options
Surface feature options as defined in [swCreateFeatureBodyOpts_e](#)

Return Value

Surface [feature](#) array

Visual Basic for Applications (VBA) Syntax

See [PartDoc::CreateSurfaceFeatureFromBody](#).

Example

[Create Loft Surface Body and Change Into Feature \(VBA\)](#)

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::ICreateSurfaceFeatureFromBody Method](#)

[IPartDoc::ICreateSurfaceFeatureFromBodyCount2 Method](#)
[IPartDoc::ICreateFeatureFromBody4 Method](#)
[IPartDoc::CreateFeatureFromBody3 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteEntityName Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : DeleteEntityName Method (IPartDoc)

Deletes the name associated with the specified entity.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteEntityName( _  
    ByVal Entity As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Entity As System.Object  
Dim value As System.Boolean  
  
value = instance.DeleteEntityName(Entity)
```

C#

```
System.bool DeleteEntityName(  
    System.object Entity  
)
```

C++/CLI

```
System.bool DeleteEntityName(  
    & System.Object^ Entity  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entity
[Entity](#) whose name to remove

Return Value

True if the name is removed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [PartDoc::DeleteEntityName](#).

Example

[Get Entity By Name \(VBA\)](#)

Remarks

Deleting an entity name can cause references to fail.

For example, if an assembly contains a mate to a part face, then a name may automatically be assigned to that face. If you delete that name, then there is no guarantee that the mate will still be valid. This method was provided because the action is available in the core product. However, you should recognize the possibility of reference failures as just described.

Entity names are kept with the part document, so this method resides on the [IPartDoc](#) object.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::GetEntityByName Method](#)
[IPartDoc::GetEntityName Method](#)
[IPartDoc::GetNamedEntities Method](#)
[IPartDoc::GetNamedEntitiesCount Method](#)
[IPartDoc::IDeleteEntityName Method](#)
[IPartDoc::IGetEntityByName Method](#)
[IPartDoc::IGetEntityName Method](#)
[IPartDoc::IGetNamedEntities Method](#)
[IPartDoc::SetEntityName Method](#)
[IPartDoc::IDeleteEntityName Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditRebuild Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EditRebuild Method (IPartDoc)

Obsolete. Superseded by [IModelDoc2::EditRebuild3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub EditRebuild()
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
  
instance.EditRebuild()
```

C#

```
void EditRebuild()
```

C++/CLI

```
void EditRebuild();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EditRebuild](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditRollback Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EditRollback Method (IPartDoc)

Rolls back the part's history to the feature just before the currently selected feature in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Sub EditRollback()
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
instance.EditRollback()
```

C#

```
void EditRollback()
```

C++/CLI

```
void EditRollback();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EditRollback](#).

Example

[Move Rollback Bar Using Feature \(C#\)](#)
[Move Rollback Bar Using Feature \(VB.NET\)](#)
[Move Rollback Bar Using Feature \(VBA\)](#)

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IFeatureManager::EditRollback Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditSuppress Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EditSuppress Method (IPartDoc)

Obsolete. Superseded by [IModelDoc2::EditSuppress2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub EditSuppress()
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
instance.EditSuppress()
```

C#

```
void EditSuppress()
```

C++/CLI

```
void EditSuppress();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EditSuppress](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditUnsuppress Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EditUnsuppress Method (IPartDoc)

Obsolete. Superseded by [IModelDoc2::EditUnsuppress2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub EditUnsuppress()
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
instance.EditUnsuppress()
```

C#

```
void EditUnsuppress()
```

C++/CLI

```
void EditUnsuppress();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EditUnsuppress](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditUnsuppressDependent Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EditUnsuppressDependent Method (IPartDoc)

Obsolete. Superseded by [IModelDoc2::EditUnsuppressDependent2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub EditUnsuppressDependent()
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
instance.EditUnsuppressDependent()
```

C#

```
void EditUnsuppressDependent()
```

C++/CLI

```
void EditUnsuppressDependent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EditUnsuppressDependent](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EnumBodies Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EnumBodies Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::EnumBodies3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EnumBodies(  
    ByVal BodyType As System.Integer _  
) As EnumBodies
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim BodyType As System.Integer  
Dim value As EnumBodies  
  
value = instance.EnumBodies(BodyType)
```

C#

```
EnumBodies EnumBodies(  
    System.int BodyType  
)
```

C++/CLI

```
EnumBodies^ EnumBodies(  
& System.int BodyType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyType

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EnumBodies](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EnumBodies2 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EnumBodies2 Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::EnumBodies3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EnumBodies2( _  
    ByVal BodyType As System.Integer _  
) As EnumBodies2
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim BodyType As System.Integer  
Dim value As EnumBodies2  
  
value = instance.EnumBodies2(BodyType)
```

C#

```
EnumBodies2 EnumBodies2(  
    System.int BodyType  
)
```

C++/CLI

```
EnumBodies2^ EnumBodies2(  
& System.int BodyType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyType

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EnumBodies2](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EnumBodies3 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EnumBodies3 Method (IPartDoc)

Enumerates the bodies in this part.

.NET Syntax

Visual Basic (Declaration)

```
Function EnumBodies3( _  
    ByVal BodyType As System.Integer, _  
    ByVal BVisibleOnly As System.Boolean _  
) As EnumBodies2
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim BodyType As System.Integer
```

```
Dim BVisibleOnly As System.Boolean
Dim value As EnumBodies2

value = instance.EnumBodies3(BodyType, BVisibleOnly)
```

C#

```
EnumBodies2 EnumBodies3(
    System.int BodyType,
    System.bool BVisibleOnly
)
```

C++/CLI

```
EnumBodies2^ EnumBodies3(
    & System.int BodyType,
    & System.bool BVisibleOnly
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyType

Type of body as defined in [swBodyType_e](#)

BVisibleOnly

True gets only visible bodies, false gets all bodies

Return Value

[Enumerated list of bodies](#)

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EnumBodies3](#).

Remarks

To use the enumerated list, see [IEnumBodies2](#) functions.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::EnumRelatedBodies2 Method](#)
[IPartDoc::EnumRelatedSectionedBodies2 Method](#)
[IPartDoc::GetRelatedBodies Method](#)
[IPartDoc::GetRelatedSectionedBodies Method](#)
[IBody2 Interface](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnumRelatedBodies Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EnumRelatedBodies Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::EnumRelatedBodies2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EnumRelatedBodies() As EnumBodies
```

Visual Basic (Usage)



```
Dim instance As IPartDoc
Dim value As EnumBodies

value = instance.EnumRelatedBodies()
```

C#

```
EnumBodies EnumRelatedBodies()
```

C++/CLI

```
EnumBodies^ EnumRelatedBodies();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EnumRelatedBodies](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnumRelatedBodies2 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EnumRelatedBodies2 Method (IPartDoc)

Creates an enumerated list of bodies.

.NET Syntax

Visual Basic (Declaration)

```
Function EnumRelatedBodies2() As EnumBodies2
```

Visual Basic (Usage)



```
Dim instance As IPartDoc
Dim value As EnumBodies2

value = instance.EnumRelatedBodies2()
```

C#

```
EnumBodies2 EnumRelatedBodies2()
```

C++/CLI

```
EnumBodies2^ EnumRelatedBodies2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Enumerated list of bodies](#)

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EnumRelatedBodies2](#).

Remarks

The list contains only those bodies associated with reference surfaces. The list does not include the part body itself.

A reference surface feature can consist of one or more surfaces sewn together. Each reference surface feature has two [IBody2](#) objects:

- One represents the front face or faces
- One represents the back face or faces

Each IBody2 object has one or more faces depending on whether the reference surface feature is a set of knitted surfaces or a single underlying surface. The corresponding faces for each body pair should have normal vectors that are opposite.

To use the enumerated list, see [IEnumBodies2](#) functions.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::EnumBodies3 Method](#)
[IPartDoc::EnumRelatedSectionedBodies2 Method](#)
[IPartDoc::GetRelatedBodies Method](#)
[IPartDoc::GetRelatedSectionedBodies Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnumRelatedSectionedBodies Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EnumRelatedSectionedBodies Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::EnumRelatedSectionedBodies](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EnumRelatedSectionedBodies( _
    ByVal ViewIn As ModelView _
) As EnumBodies
```

Visual Basic (Usage)



```
Dim instance As IPartDoc
Dim ViewIn As ModelView
Dim value As EnumBodies
```

```
value = instance.EnumRelatedSectionedBodies(ViewIn)
```

C#

```
EnumBodies EnumRelatedSectionedBodies(
    ModelView ViewIn
)
```

C++/CLI

```
EnumBodies^ EnumRelatedSectionedBodies(
    & ModelView^ ViewIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ViewIn

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EnumRelatedSectionedBodies](#).

See Also

EnumRelatedSectionedBodies2 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : EnumRelatedSectionedBodies2 Method (IPartDoc)

Gets an enumeration of the related sectioned bodies in a part.

.NET Syntax

Visual Basic (Declaration)

```
Function EnumRelatedSectionedBodies2( _  
    ByVal ViewIn As ModelView _  
) As EnumBodies2
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim ViewIn As ModelView  
Dim value As EnumBodies2  
  
value = instance.EnumRelatedSectionedBodies2(ViewIn)
```

C#

```
EnumBodies2 EnumRelatedSectionedBodies2(  
    ModelView ViewIn  
)
```

C++/CLI

```
EnumBodies2^ EnumRelatedSectionedBodies2(  
& ModelView^ ViewIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ViewIn
[Model view](#)

Return Value

[Enumeration of the related sectioned bodies](#)

Visual Basic for Applications (VBA) Syntax

See [PartDoc::EnumRelatedSectionedBodies2](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::EnumRelatedBodies2 Method](#)
[IPartDoc::EnumBodies3 Method](#)
[IPartDoc::GetRelatedBodies Method](#)
[IPartDoc::GetRelatedSectionedBodies Method](#)
[IBody2 Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number

ExportFlatPatternView Method (IPartDoc)

[See Also](#)



Obsolete. Superseded by [IPartDoc::ExportToDWG2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ExportFlatPatternView( _  
    ByVal FilePath As System.String, _  
    ByVal Options As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim FilePath As System.String  
Dim Options As System.Integer  
Dim value As System.Boolean
```

```
value = instance.ExportFlatPatternView(FilePath, Options)
```

C#

```
System.bool ExportFlatPatternView(  
    System.string FilePath,  
    System.int Options  
)
```

C++/CLI

```
System.bool ExportFlatPatternView(  
& System.String^ FilePath,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePath

Path and filename to which to save the sheet metal part in its flattened state to a DXF/DWG file

Options

Option as described in [swExportFlatPatternViewOptions_e](#)

Return Value

True if the sheet metal part is enabled to be saved in its flattened state to a DXF/DWG file at the specified path and filename, false if not

Visual Basic for Applications (VBA) Syntax

See [PartDoc::ExportFlatPatternView](#).

Example

Option Explicit

```
Dim swApp As SldWorks.SldWorks  
Dim swModel As SldWorks.ModelDoc2  
Dim swModelDocExt As SldWorks.ModelDocExtension  
Dim boolstatus As Boolean  
Dim longstatus As Long, longwarnings As Long
```

```
Sub main()  
    Set swApp = Application.SldWorks  
    Set swModel = swApp.ActiveDoc
```

```
Set swModelDocExt = swModel.Extension
```

```
boolstatus = swModel.ExportFlatPatternView("F:\Test\Flat pattern -  
sheet_metal_cover.DXF", swExportFlatPatternOption_None)  
  
swModelDocExt.SaveAs "F:\Test\Flat pattern - sheet_metal_cover.DXF", 0, 0,  
Nothing, longstatus, longwarnings
```

End Sub

Remarks

Call this method before calling [IModelDocExtension::SaveAs](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::ExportToDWG2 Method \(\)](#)
[IPartDoc::IExportToDWG2 Method \(\)](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExportToDWG Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : ExportToDWG Method (IPartDoc)

Obsolete. Superseded by [IPartDoc::ExportToDWG2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ExportToDWG( _  
    ByVal FilePath As System.String, _  
    ByVal ModelName As System.String, _  
    ByVal Action As System.Integer, _  
    ByVal ExportToSingleFile As System.Boolean, _  
    ByVal Alignment As System.Object, _  
    ByVal IsXDirFlipped As System.Boolean, _  
    ByVal IsYDirFlipped As System.Boolean, _  
    ByVal SheetMetalOptions As System.Integer, _  
    ByVal Views As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IPartDoc  
Dim FilePath As System.String  
Dim ModelName As System.String  
Dim Action As System.Integer  
Dim ExportToSingleFile As System.Boolean  
Dim Alignment As System.Object  
Dim IsXDirFlipped As System.Boolean  
Dim IsYDirFlipped As System.Boolean  
Dim SheetMetalOptions As System.Integer  
Dim Views As System.Object  
Dim value As System.Boolean
```

```
value = instance.ExportToDWG(FilePath, ModelName, Action, ExportToSingleFile, Alignment,  
IsXDirFlipped, IsYDirFlipped, SheetMetalOptions, Views)
```



Copy Code

C#

```
System.bool ExportToDWG(  
    System.string FilePath,  
    System.string ModelName,  
    System.int Action,  
    System.bool ExportToSingleFile,  
    System.object Alignment,  
    System.bool IsXDirFlipped,  
    System.bool IsYDirFlipped,  
    System.int SheetMetalOptions,  
    System.object Views  
)
```

C++/CLI

```
System.bool ExportToDWG(  
& System.String^ FilePath,  
& System.String^ ModelName,  
& System.int Action,  
& System.bool ExportToSingleFile,  
& System.Object^ Alignment,  
& System.bool IsXDirFlipped,  
& System.bool IsYDirFlipped,  
& System.int SheetMetalOptions,  
& System.Object^ Views  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePath

Full path to the directory of the exported DXF/DWG file

ModelName

File and path name of the active part document

Action

- 1 - export sheet metal (valid only if active document contains sheet metal)
- 2 - export selected faces or loops
- 3 - export annotation views

ExportToSingleFile

True to save as one file; false to save in separate files

Alignment

Array of twelve double values that contain information related to output alignment:

Array[0], Array[1], Array[2] - XYZ coordinates of new origin

Array[3], Array[4], Array[5] - coordinates of new x direction vector

Array[6], Array[7], Array[8] - coordinates of new y direction vector

Array[9], Array[10], Array[11] - coordinates of the vector that is normal to the selected faces or loops

The last three elements of the array are valid only if Action = 2

IsXDirFlipped

True to flip the x direction; false otherwise

IsYDirFlipped

True to flip the y direction; false otherwise

SheetMetalOptions

[Bitmask](#) that contains sheet metal export options; valid only if Action = 1:

The bitmask is {7 6 5 4 3 2 1}, where each bit is either 0 or 1 as follows:

Bit #1: 1 to export geometry; 0 to not

Bit #2: 1 to include hidden edges; 0 to not

Bit #3: 1 to export bend lines; 0 to not

Bit #4: 1 to include sketches; 0 to not

Bit #5: 1 to merge coplanar faces; 0 to not

Bit #6: 1 to export library features; 0 to not

Bit #7: 1 to export forming tools; 0 to not

Example

If you want to export flat pattern geometry, bend lines, and sketches, then Bits 1, 3, and 4 are 1, the bitmask is 0001101, and you need to set SheetMetalOptions = $2^0 + 2^2 + 2^3 = 1 + 4 + 8 = 13$.

Views

Array of annotation view names to export; valid only if Action = 3

Return Value

True if export is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [PartDoc::ExportToDWG](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::IExportToDWG Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExportToDWG2 Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : ExportToDWG2 Method (IPartDoc)

Saves various aspects of a part (sheet metal, faces, loops, and annotation views) to one or more DXF/DWG files, preserving the specified file name.

.NET Syntax

Visual Basic (Declaration)

```
Function ExportToDWG2( _  
    ByVal FilePath As System.String, _  
    ByVal ModelName As System.String, _  
    ByVal Action As System.Integer, _  
    ByVal ExportToSingleFile As System.Boolean, _  
    ByVal Alignment As System.Object, _  
    ByVal IsXDirFlipped As System.Boolean, _  
    ByVal IsYDirFlipped As System.Boolean, _  
    ByVal SheetMetalOptions As System.Integer, _  
    ByVal Views As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim FilePath As System.String  
Dim ModelName As System.String  
Dim Action As System.Integer  
Dim ExportToSingleFile As System.Boolean  
Dim Alignment As System.Object  
Dim IsXDirFlipped As System.Boolean  
Dim IsYDirFlipped As System.Boolean  
Dim SheetMetalOptions As System.Integer  
Dim Views As System.Object  
Dim value As System.Boolean
```

```
value = instance.ExportToDWG2(FilePath, ModelName, Action, ExportToSingleFile, Alignment,  
IsXDirFlipped, IsYDirFlipped, SheetMetalOptions, Views)
```

C#

```
System.bool ExportToDWG2(  
    System.string FilePath,  
    System.string ModelName,  
    System.int Action,  
    System.bool ExportToSingleFile,  
    System.object Alignment,  
    System.bool IsXDirFlipped,  
    System.bool IsYDirFlipped,
```

```

        System.int SheetMetalOptions,
        System.object Views
    )

```

C++/CLI

```

System.bool ExportToDWG2(
& System.String^ FilePath,
& System.String^ ModelName,
& System.int Action,
& System.bool ExportToSingleFile,
& System.Object^ Alignment,
& System.bool IsXDirFlipped,
& System.bool IsYDirFlipped,
& System.int SheetMetalOptions,
& System.Object^ Views
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePath

Path and file name of the exported DXF/DWG file

ModelName

Path and file name of the active part document

Action

Export action as defined in [swExportToDWG_e](#) (see **Remarks**)

ExportToSingleFile

True to save as one file; false to save as multiple files

Alignment

Array of 12 double values that contain information related to output alignment (see **Remarks**)

IsXDirFlipped

True to flip the x direction; false otherwise

IsYDirFlipped

True to flip the y direction; false otherwise

SheetMetalOptions

[Bitmask](#) that contains sheet metal export options; valid only if Action = swExportToDWG_e.swExportToDWG_ExportSheetMetal (see **Remarks**)

Views

Array of annotation view names to export; valid only if Action = swExportToDWG_e.swExportToDWG_ExportAnnotationViews

Return Value

True if export is successful; false if not

Visual Basic for Applications (VBA) Syntax

See [PartDoc::ExportToDWG2](#).

Example

[Export Part to DWG \(VBA\)](#)

[Export Part to DWG \(VB.NET\)](#)

[Export Part to DWG \(C#\)](#)

Remarks

This method supersedes IPartDoc::IExportToDWG by:

- Adding an option to SheetMetalOptions to export a sheet metal bounding box.
- Not pre-pending the flat-pattern name to the FilePath file name of the exported DXF/DWG when ExportToSingleFile is false.

Alignment array is as follows:

Array[0], Array[1], Array[2] - x,y,z coordinates of new origin

Array[3], Array[4], Array[5] - coordinates of new x direction vector

Array[6], Array[7], Array[8] - coordinates of new y direction vector

Array[9], Array[10], Array[11] - coordinates of the vector that is normal to the selected faces or loops

NOTE:

- Passing an array of 12 zeros results in a default orientation being used. This is equivalent to not selecting any edges to be used for axis alignment in the user interface.
- Sheet-metal part exports are automatically constrained to align the flat-pattern normal to the 2D sheet normal, thereby limiting the degrees of freedom available to the API caller.
- The last three elements of the array are valid only if Action = swExportToDWG_e.swExportToDW_ExportSelectedFacesOrLoops.

SheetMetalOptions bitmask is {14 13 12 11 10 9 8 7 6 5 4 3 2 1}, where each bit is either 0 or 1 as follows:

Bit #1: 1 to export flat-pattern geometry; 0 to not

Bit #2: 1 to include hidden edges; 0 to not

Bit #3: 1 to export bend lines; 0 to not

Bit #4: 1 to include sketches; 0 to not

Bit #5: 1 to merge coplanar faces; 0 to not

Bit #6: 1 to export library features; 0 to not

Bit #7: 1 to export forming tools; 0 to not

Bit #8: 0

Bit #9: 0

Bit #10: 0

Bit #11: 0

Bit #12: 1 to export bounding box; 0 to not

Bit #13: 1 to export cosmetic threads; 0 to not

Bit #14: 1 to export hidden sketches; 0 to not

For example, if you want to export:

- flat-pattern geometry, bend lines, and sketches, then Bits 1, 3, and 4 are 1, the bitmask is 0001101, and you need to set SheetMetalOptions = $2^0 + 2^2 + 2^3 = 1 + 4 + 8 = 13$.
- only the bounding box, then Bit 12 is 1, the bitmask is 100000000000, and you need to set SheetMetalOptions = $2^{11} = 2048$.

You must select multi-body sheet-metal features (i.e., multiple flat-pattern features) before calling this method.

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::IExportToDWG2 Method \(\)](#)
[IPartDoc::ExportFlatPatternView Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureById Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureById Method (IPartDoc)

Gets the feature with the specified ID in the part.

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureById(  
    ByVal ID As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IPartDoc  
Dim ID As System.Integer  
Dim value As System.Object  
  
value = instance.FeatureById(ID)
```

C#

```
System.object FeatureById(  
    System.int ID  
)
```

C++/CLI

```
System.Object^ FeatureById(  
& System.int ID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

ID of feature

Return Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureById](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::IFeatureById Method](#)
[IPartDoc::IFeatureByName Method](#)
[IPartDoc::FeatureByName Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureByName Method (IPartDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureByName Method (IPartDoc)

Gets the named feature in the part.

.NET Syntax

Visual Basic (Declaration)

```
Function FeatureByName(  
    ByVal Name As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Name As System.String  
Dim value As System.Object  
  
value = instance.FeatureByName(Name)
```

C#

```
System.object FeatureByName(  
    System.string Name  
)
```

C++/CLI

```
System.Object^ FeatureByName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of feature

Return Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureByName](#).

Example

[Autodimension All Sketches \(VBA\)](#)
[Get and Set Constraint for Dome Feature \(VBA\)](#)
[Move Copy Sketch Entities \(C#\)](#)
[Move Copy Sketch Entities \(VB.NET\)](#)
[Move Copy Sketch Entities \(VBA\)](#)
[Roll Back Model \(C#\)](#)
[Roll Back Model \(VB.NET\)](#)
[Roll Back Model \(VBA\)](#)
[Suppress Component Feature \(C#\)](#)
[Suppress Component Feature \(VB.NET\)](#)
[Suppress Component Feature \(VBA\)](#)

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)
[IPartDoc::IFeatureByName Method](#)
[IPartDoc::IFeatureById Method](#)
[IPartDoc::FeatureById Method](#)
[IAssemblyDoc::FeatureByName Method](#)
[IAssemblyDoc::IFeatureByName Method](#)
[IComponent2::FeatureByName Method](#)
[IDrawingDoc::FeatureByName Method](#)
[IDrawingDoc::IFeatureByName Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureExtrusion Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureExtrusion Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureExtrusion2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureExtrusion( _  
    ByVal Sd As System.Boolean, _  
    ByVal Flip As System.Boolean, _  
    ByVal Dir As System.Boolean, _  
    ByVal T1 As System.Integer, _  
    ByVal T2 As System.Integer, _  
    ByVal D1 As System.Double, _  
    ByVal D2 As System.Double, _  
    ByVal Dchk1 As System.Boolean, _  
    ByVal Dchk2 As System.Boolean, _  
    ByVal Ddir1 As System.Boolean, _  
    ByVal Ddir2 As System.Boolean, _  
    ByVal Dang1 As System.Double, _  
    ByVal Dang2 As System.Double, _  
    ByVal OffsetReverse1 As System.Boolean, _  
    ByVal OffsetReverse2 As System.Boolean _  
)
```

Visual Basic (Usage)

```
Dim instance As IPartDoc  
Dim Sd As System.Boolean  
Dim Flip As System.Boolean  
Dim Dir As System.Boolean  
Dim T1 As System.Integer  
Dim T2 As System.Integer  
Dim D1 As System.Double  
Dim D2 As System.Double  
Dim Dchk1 As System.Boolean  
Dim Dchk2 As System.Boolean  
Dim Ddir1 As System.Boolean  
Dim Ddir2 As System.Boolean  
Dim Dang1 As System.Double  
Dim Dang2 As System.Double  
Dim OffsetReverse1 As System.Boolean  
Dim OffsetReverse2 As System.Boolean
```



```
instance.FeatureExtrusion(Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1, Dang2, OffsetReverse1, OffsetReverse2)
```

C#

```
void FeatureExtrusion(  
    System.bool Sd,  
    System.bool Flip,  
    System.bool Dir,  
    System.int T1,  
    System.int T2,  
    System.double D1,  
    System.double D2,  
    System.bool Dchk1,  
    System.bool Dchk2,  
    System.bool Ddir1,  
    System.bool Ddir2,  
    System.double Dang1,  
    System.double Dang2,  
    System.bool OffsetReverse1,  
    System.bool OffsetReverse2  
)
```

C++/CLI

```
void FeatureExtrusion(  
& System.bool Sd,  
& System.bool Flip,  
& System.bool Dir,  
& System.int T1,  
& System.int T2,  
& System.double D1,  
& System.double D2,  
& System.bool Dchk1,  
& System.bool Dchk2,  
& System.bool Ddir1,  
& System.bool Ddir2,  
& System.double Dang1,  
& System.double Dang2,  
& System.bool OffsetReverse1,  
& System.bool OffsetReverse2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sd

Flip

Dir

T1

T2

D1

D2

Dchk1

Dchk2

Ddir1

Ddir2

Dang1

Dang2

OffsetReverse1

OffsetReverse2

 Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureExtrusion](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureExtrusion2 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureExtrusion2 Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureExtrusion2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureExtrusion2( _  
    ByVal Sd As System.Boolean, _  
    ByVal Flip As System.Boolean, _  
    ByVal Dir As System.Boolean, _  
    ByVal T1 As System.Integer, _  
    ByVal T2 As System.Integer, _  
    ByVal D1 As System.Double, _  
    ByVal D2 As System.Double, _  
    ByVal Dchk1 As System.Boolean, _  
    ByVal Dchk2 As System.Boolean, _  
    ByVal Ddir1 As System.Boolean, _  
    ByVal Ddir2 As System.Boolean, _  
    ByVal Dang1 As System.Double, _  
    ByVal Dang2 As System.Double, _  
    ByVal OffsetReverse1 As System.Boolean, _  
    ByVal OffsetReverse2 As System.Boolean, _  
    ByVal Merge As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Sd As System.Boolean  
Dim Flip As System.Boolean  
Dim Dir As System.Boolean  
Dim T1 As System.Integer  
Dim T2 As System.Integer  
Dim D1 As System.Double  
Dim D2 As System.Double  
Dim Dchk1 As System.Boolean  
Dim Dchk2 As System.Boolean  
Dim Ddir1 As System.Boolean  
Dim Ddir2 As System.Boolean  
Dim Dang1 As System.Double  
Dim Dang2 As System.Double  
Dim OffsetReverse1 As System.Boolean  
Dim OffsetReverse2 As System.Boolean  
Dim Merge As System.Boolean
```

```
instance.FeatureExtrusion2(Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1,  
Dang2, OffsetReverse1, OffsetReverse2, Merge)
```

C#

```
void FeatureExtrusion2(  
    System.bool Sd,  
    System.bool Flip,  
    System.bool Dir,  
    System.int T1,  
    System.int T2,  
    System.double D1,  
    System.double D2,
```

```

        System.bool Dchk1,
        System.bool Dchk2,
        System.bool Ddir1,
        System.bool Ddir2,
        System.double Dang1,
        System.double Dang2,
        System.bool OffsetReverse1,
        System.bool OffsetReverse2,
        System.bool Merge
    )

```

C++/CLI

```

void FeatureExtrusion2(
& System.bool Sd,
& System.bool Flip,
& System.bool Dir,
& System.int T1,
& System.int T2,
& System.double D1,
& System.double D2,
& System.bool Dchk1,
& System.bool Dchk2,
& System.bool Ddir1,
& System.bool Ddir2,
& System.double Dang1,
& System.double Dang2,
& System.bool OffsetReverse1,
& System.bool OffsetReverse2,
& System.bool Merge
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sd

Flip

Dir

T1

T2

D1

D2

Dchk1

Dchk2

Ddir1

Ddir2

Dang1

Dang2

OffsetReverse1

OffsetReverse2

Merge

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureExtrusion2](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Sub FeatureExtrusion3( _  
    ByVal Sd As System.Boolean, _  
    ByVal Flip As System.Boolean, _  
    ByVal Dir As System.Boolean, _  
    ByVal T1 As System.Integer, _  
    ByVal T2 As System.Integer, _  
    ByVal D1 As System.Double, _  
    ByVal D2 As System.Double, _  
    ByVal Dchk1 As System.Boolean, _  
    ByVal Dchk2 As System.Boolean, _  
    ByVal Ddir1 As System.Boolean, _  
    ByVal Ddir2 As System.Boolean, _  
    ByVal Dang1 As System.Double, _  
    ByVal Dang2 As System.Double, _  
    ByVal OffsetReverse1 As System.Boolean, _  
    ByVal OffsetReverse2 As System.Boolean, _  
    ByVal TranslateSurface1 As System.Boolean, _  
    ByVal TranslateSurface2 As System.Boolean, _  
    ByVal Merge As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Sd As System.Boolean  
Dim Flip As System.Boolean  
Dim Dir As System.Boolean  
Dim T1 As System.Integer  
Dim T2 As System.Integer  
Dim D1 As System.Double  
Dim D2 As System.Double  
Dim Dchk1 As System.Boolean  
Dim Dchk2 As System.Boolean  
Dim Ddir1 As System.Boolean  
Dim Ddir2 As System.Boolean  
Dim Dang1 As System.Double  
Dim Dang2 As System.Double  
Dim OffsetReverse1 As System.Boolean  
Dim OffsetReverse2 As System.Boolean  
Dim TranslateSurface1 As System.Boolean  
Dim TranslateSurface2 As System.Boolean  
Dim Merge As System.Boolean
```

```
instance.FeatureExtrusion3(Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1,  
Dang2, OffsetReverse1, OffsetReverse2, TranslateSurface1, TranslateSurface2, Merge)
```

C#

```
void FeatureExtrusion3(  
    System.bool Sd,  
    System.bool Flip,  
    System.bool Dir,  
    System.int T1,  
    System.int T2,  
    System.double D1,  
    System.double D2,  
    System.bool Dchk1,  
    System.bool Dchk2,  
    System.bool Ddir1,  
    System.bool Ddir2,  
    System.double Dang1,
```

```
System.double Dang2,  
System.bool OffsetReverse1,  
System.bool OffsetReverse2,  
System.bool TranslateSurface1,  
System.bool TranslateSurface2,  
System.bool Merge  
)
```

C++/CLI

```
void FeatureExtrusion3(  
& System.bool Sd,  
& System.bool Flip,  
& System.bool Dir,  
& System.int T1,  
& System.int T2,  
& System.double D1,  
& System.double D2,  
& System.bool Dchk1,  
& System.bool Dchk2,  
& System.bool Ddir1,  
& System.bool Ddir2,  
& System.double Dang1,  
& System.double Dang2,  
& System.bool OffsetReverse1,  
& System.bool OffsetReverse2,  
& System.bool TranslateSurface1,  
& System.bool TranslateSurface2,  
& System.bool Merge  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sd

Flip

Dir

T1

T2

D1

D2

Dchk1

Dchk2

Ddir1

Ddir2

Dang1

Dang2

OffsetReverse1

OffsetReverse2

TranslateSurface1

TranslateSurface2

Merge

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureExtrusion3](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

FeatureExtrusionThin Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureExtrusionThin Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureExtrusionThin2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureExtrusionThin( _  
    ByVal Sd As System.Boolean, _  
    ByVal Flip As System.Boolean, _  
    ByVal Dir As System.Boolean, _  
    ByVal T1 As System.Integer, _  
    ByVal T2 As System.Integer, _  
    ByVal D1 As System.Double, _  
    ByVal D2 As System.Double, _  
    ByVal Dchk1 As System.Boolean, _  
    ByVal Dchk2 As System.Boolean, _  
    ByVal Ddir1 As System.Boolean, _  
    ByVal Ddir2 As System.Boolean, _  
    ByVal Dang1 As System.Double, _  
    ByVal Dang2 As System.Double, _  
    ByVal OffsetReverse1 As System.Boolean, _  
    ByVal OffsetReverse2 As System.Boolean, _  
    ByVal Thk1 As System.Double, _  
    ByVal Thk2 As System.Double, _  
    ByVal EndThk As System.Double, _  
    ByVal RevThinDir As System.Integer, _  
    ByVal CapEnds As System.Integer, _  
    ByVal AddBends As System.Boolean, _  
    ByVal BendRad As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Sd As System.Boolean  
Dim Flip As System.Boolean  
Dim Dir As System.Boolean  
Dim T1 As System.Integer  
Dim T2 As System.Integer  
Dim D1 As System.Double  
Dim D2 As System.Double  
Dim Dchk1 As System.Boolean  
Dim Dchk2 As System.Boolean  
Dim Ddir1 As System.Boolean  
Dim Ddir2 As System.Boolean  
Dim Dang1 As System.Double  
Dim Dang2 As System.Double  
Dim OffsetReverse1 As System.Boolean  
Dim OffsetReverse2 As System.Boolean  
Dim Thk1 As System.Double  
Dim Thk2 As System.Double  
Dim EndThk As System.Double  
Dim RevThinDir As System.Integer  
Dim CapEnds As System.Integer  
Dim AddBends As System.Boolean  
Dim BendRad As System.Double
```

```
instance.FeatureExtrusionThin(Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1,  
Dang2, OffsetReverse1, OffsetReverse2, Thk1, Thk2, EndThk, RevThinDir, CapEnds, AddBends, BendRad)
```

C#

```
void FeatureExtrusionThin(  
    System.bool Sd,
```

```

System.bool Flip,
System.bool Dir,
System.int T1,
System.int T2,
System.double D1,
System.double D2,
System.bool Dchk1,
System.bool Dchk2,
System.bool Ddir1,
System.bool Ddir2,
System.double Dang1,
System.double Dang2,
System.bool OffsetReverse1,
System.bool OffsetReverse2,
System.double Thk1,
System.double Thk2,
System.double EndThk,
System.int RevThinDir,
System.int CapEnds,
System.bool AddBends,
System.double BendRad
)

```

C++/CLI

```

void FeatureExtrusionThin(
& System.bool Sd,
& System.bool Flip,
& System.bool Dir,
& System.int T1,
& System.int T2,
& System.double D1,
& System.double D2,
& System.bool Dchk1,
& System.bool Dchk2,
& System.bool Ddir1,
& System.bool Ddir2,
& System.double Dang1,
& System.double Dang2,
& System.bool OffsetReverse1,
& System.bool OffsetReverse2,
& System.double Thk1,
& System.double Thk2,
& System.double EndThk,
& System.int RevThinDir,
& System.int CapEnds,
& System.bool AddBends,
& System.double BendRad
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sd

Flip

Dir

T1

T2

D1

D2

Dchk1

Dchk2

Ddir1

Ddir2

Dang1

Dang2

OffsetReverse1
OffsetReverse2
Thk1
Thk2
EndThk
RevThinDir
CapEnds
AddBends
BendRad

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureExtrusionThin](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureExtrusionThin2 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureExtrusionThin2 Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureExtrusionThin2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureExtrusionThin2( _  
    ByVal Sd As System.Boolean, _  
    ByVal Flip As System.Boolean, _  
    ByVal Dir As System.Boolean, _  
    ByVal T1 As System.Integer, _  
    ByVal T2 As System.Integer, _  
    ByVal D1 As System.Double, _  
    ByVal D2 As System.Double, _  
    ByVal Dchk1 As System.Boolean, _  
    ByVal Dchk2 As System.Boolean, _  
    ByVal Ddir1 As System.Boolean, _  
    ByVal Ddir2 As System.Boolean, _  
    ByVal Dang1 As System.Double, _  
    ByVal Dang2 As System.Double, _  
    ByVal OffsetReverse1 As System.Boolean, _  
    ByVal OffsetReverse2 As System.Boolean, _  
    ByVal Merge As System.Boolean, _  
    ByVal Thk1 As System.Double, _  
    ByVal Thk2 As System.Double, _  
    ByVal EndThk As System.Double, _  
    ByVal RevThinDir As System.Integer, _  
    ByVal CapEnds As System.Integer, _  
    ByVal AddBends As System.Boolean, _  
    ByVal BendRad As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Sd As System.Boolean  
Dim Flip As System.Boolean  
Dim Dir As System.Boolean  
Dim T1 As System.Integer  
Dim T2 As System.Integer
```

```

Dim D1 As System.Double
Dim D2 As System.Double
Dim Dchk1 As System.Boolean
Dim Dchk2 As System.Boolean
Dim Ddir1 As System.Boolean
Dim Ddir2 As System.Boolean
Dim Dang1 As System.Double
Dim Dang2 As System.Double
Dim OffsetReverse1 As System.Boolean
Dim OffsetReverse2 As System.Boolean
Dim Merge As System.Boolean
Dim Thk1 As System.Double
Dim Thk2 As System.Double
Dim EndThk As System.Double
Dim RevThinDir As System.Integer
Dim CapEnds As System.Integer
Dim AddBends As System.Boolean
Dim BendRad As System.Double

```

```

instance.FeatureExtrusionThin2(Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1,
Dang2, OffsetReverse1, OffsetReverse2, Merge, Thk1, Thk2, EndThk, RevThinDir, CapEnds, AddBends,
BendRad)

```

C#

```

void FeatureExtrusionThin2(
    System.bool Sd,
    System.bool Flip,
    System.bool Dir,
    System.int T1,
    System.int T2,
    System.double D1,
    System.double D2,
    System.bool Dchk1,
    System.bool Dchk2,
    System.bool Ddir1,
    System.bool Ddir2,
    System.double Dang1,
    System.double Dang2,
    System.bool OffsetReverse1,
    System.bool OffsetReverse2,
    System.bool Merge,
    System.double Thk1,
    System.double Thk2,
    System.double EndThk,
    System.int RevThinDir,
    System.int CapEnds,
    System.bool AddBends,
    System.double BendRad
)

```

C++/CLI

```

void FeatureExtrusionThin2(
& System.bool Sd,
& System.bool Flip,
& System.bool Dir,
& System.int T1,
& System.int T2,
& System.double D1,
& System.double D2,
& System.bool Dchk1,
& System.bool Dchk2,
& System.bool Ddir1,
& System.bool Ddir2,
& System.double Dang1,
& System.double Dang2,
& System.bool OffsetReverse1,
& System.bool OffsetReverse2,
& System.bool Merge,

```

```
& System.double Thk1,  
& System.double Thk2,  
& System.double EndThk,  
& System.int RevThinDir,  
& System.int CapEnds,  
& System.bool AddBends,  
& System.double BendRad  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sd

Flip

Dir

T1

T2

D1

D2

Dchk1

Dchk2

Ddir1

Ddir2

Dang1

Dang2

OffsetReverse1

OffsetReverse2

Merge

Thk1

Thk2

EndThk

RevThinDir

CapEnds

AddBends

BendRad

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureExtrusionThin2](#).

See Also

[IPartDoc Interface](#)

[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureExtrusionThin3 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureExtrusionThin3 Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureExtrusionThin2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureExtrusionThin3( _  
    ByVal Sd As System.Boolean, _  
    ByVal Flip As System.Boolean, _  
    ByVal Dir As System.Boolean, _  
    ByVal T1 As System.Integer, _
```

```

ByVal T2 As System.Integer, _
ByVal D1 As System.Double, _
ByVal D2 As System.Double, _
ByVal Dchk1 As System.Boolean, _
ByVal Dchk2 As System.Boolean, _
ByVal Ddir1 As System.Boolean, _
ByVal Ddir2 As System.Boolean, _
ByVal Dang1 As System.Double, _
ByVal Dang2 As System.Double, _
ByVal OffsetReverse1 As System.Boolean, _
ByVal OffsetReverse2 As System.Boolean, _
ByVal TranslateSurface1 As System.Boolean, _
ByVal TranslateSurface2 As System.Boolean, _
ByVal Merge As System.Boolean, _
ByVal Thk1 As System.Double, _
ByVal Thk2 As System.Double, _
ByVal EndThk As System.Double, _
ByVal RevThinDir As System.Integer, _
ByVal CapEnds As System.Integer, _
ByVal AddBends As System.Boolean, _
ByVal BendRad As System.Double _
)

```

Visual Basic (Usage)



```

Dim instance As IPartDoc
Dim Sd As System.Boolean
Dim Flip As System.Boolean
Dim Dir As System.Boolean
Dim T1 As System.Integer
Dim T2 As System.Integer
Dim D1 As System.Double
Dim D2 As System.Double
Dim Dchk1 As System.Boolean
Dim Dchk2 As System.Boolean
Dim Ddir1 As System.Boolean
Dim Ddir2 As System.Boolean
Dim Dang1 As System.Double
Dim Dang2 As System.Double
Dim OffsetReverse1 As System.Boolean
Dim OffsetReverse2 As System.Boolean
Dim TranslateSurface1 As System.Boolean
Dim TranslateSurface2 As System.Boolean
Dim Merge As System.Boolean
Dim Thk1 As System.Double
Dim Thk2 As System.Double
Dim EndThk As System.Double
Dim RevThinDir As System.Integer
Dim CapEnds As System.Integer
Dim AddBends As System.Boolean
Dim BendRad As System.Double

```

```

instance.FeatureExtrusionThin3(Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1,
Dang2, OffsetReverse1, OffsetReverse2, TranslateSurface1, TranslateSurface2, Merge, Thk1, Thk2,
EndThk, RevThinDir, CapEnds, AddBends, BendRad)

```

C#

```

void FeatureExtrusionThin3(
    System.bool Sd,
    System.bool Flip,
    System.bool Dir,
    System.int T1,
    System.int T2,
    System.double D1,
    System.double D2,
    System.bool Dchk1,
    System.bool Dchk2,
    System.bool Ddir1,

```

```

        System.bool Ddir2,
        System.double Dang1,
        System.double Dang2,
        System.bool OffsetReverse1,
        System.bool OffsetReverse2,
        System.bool TranslateSurface1,
        System.bool TranslateSurface2,
        System.bool Merge,
        System.double Thk1,
        System.double Thk2,
        System.double EndThk,
        System.int RevThinDir,
        System.int CapEnds,
        System.bool AddBends,
        System.double BendRad
    )

```

C++/CLI

```

void FeatureExtrusionThin3(
& System.bool Sd,
& System.bool Flip,
& System.bool Dir,
& System.int T1,
& System.int T2,
& System.double D1,
& System.double D2,
& System.bool Dchk1,
& System.bool Dchk2,
& System.bool Ddir1,
& System.bool Ddir2,
& System.double Dang1,
& System.double Dang2,
& System.bool OffsetReverse1,
& System.bool OffsetReverse2,
& System.bool TranslateSurface1,
& System.bool TranslateSurface2,
& System.bool Merge,
& System.double Thk1,
& System.double Thk2,
& System.double EndThk,
& System.int RevThinDir,
& System.int CapEnds,
& System.bool AddBends,
& System.double BendRad
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sd

Flip

Dir

T1

T2

D1

D2

Dchk1

Dchk2

Ddir1

Ddir2

Dang1

Dang2

OffsetReverse1

OffsetReverse2

TranslateSurface1

TranslateSurface2

Merge

Thk1

Thk2

EndThk

RevThinDir

CapEnds

AddBends

BendRad

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureExtrusionThin3](#).

See Also

[IPartDoc Interface](#)

[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureRevolve Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureRevolve Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureRevolve](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureRevolve( _  
    ByVal Angle As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal Angle2 As System.Double, _  
    ByVal RevType As System.Integer _  
)
```

Visual Basic (Usage)

```
Dim instance As IPartDoc  
Dim Angle As System.Double  
Dim ReverseDir As System.Boolean  
Dim Angle2 As System.Double  
Dim RevType As System.Integer
```

```
instance.FeatureRevolve(Angle, ReverseDir, Angle2, RevType)
```

C#

```
void FeatureRevolve(  
    System.double Angle,  
    System.bool ReverseDir,  
    System.double Angle2,  
    System.int RevType  
)
```

C++/CLI

```
void FeatureRevolve(  
& System.double Angle,  
& System.bool ReverseDir,  
& System.double Angle2,  
& System.int RevType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

ReverseDir

Angle2

RevType

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureRevolve](#).

See Also

[IPartDoc Interface](#)

[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureRevolve2 Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureRevolve2 Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureRevolve](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureRevolve2( _  
    ByVal Angle As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal Angle2 As System.Double, _  
    ByVal RevType As System.Integer, _  
    ByVal Merge As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Angle As System.Double  
Dim ReverseDir As System.Boolean  
Dim Angle2 As System.Double  
Dim RevType As System.Integer  
Dim Merge As System.Boolean  
  
instance.FeatureRevolve2(Angle, ReverseDir, Angle2, RevType, Merge)
```

C#

```
void FeatureRevolve2(  
    System.double Angle,  
    System.bool ReverseDir,  
    System.double Angle2,  
    System.int RevType,  
    System.bool Merge  
)
```

C++/CLI

```
void FeatureRevolve2(  
& System.double Angle,  
& System.bool ReverseDir,  
& System.double Angle2,  
& System.int RevType,  
& System.bool Merge  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

ReverseDir

Angle2

RevType

Merge

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureRevolve2](#).

See Also

[IPartDoc Interface](#)

[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureRevolveCut Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureRevolveCut Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureRevolveCut](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureRevolveCut( _  
    ByVal Angle As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal Angle2 As System.Double, _  
    ByVal RevType As System.Integer _  
)
```

Visual Basic (Usage)

```
Dim instance As IPartDoc  
Dim Angle As System.Double  
Dim ReverseDir As System.Boolean  
Dim Angle2 As System.Double  
Dim RevType As System.Integer  
  
instance.FeatureRevolveCut(Angle, ReverseDir, Angle2, RevType)
```

C#

```
void FeatureRevolveCut(  
    System.double Angle,  
    System.bool ReverseDir,  
    System.double Angle2,  
    System.int RevType  
)
```

C++/CLI

```
void FeatureRevolveCut(  
& System.double Angle,  
& System.bool ReverseDir,  
& System.double Angle2,  
& System.int RevType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle
ReverseDir
Angle2
RevType

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureRevolveCut](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureRevolveThin Method (IPartDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPartDoc Interface](#) : FeatureRevolveThin Method (IPartDoc)

Obsolete. Superseded by [IFeatureManager::FeatureRevolveThin](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub FeatureRevolveThin( _  
    ByVal Angle As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal Angle2 As System.Double, _  
    ByVal RevType As System.Integer, _  
    ByVal Thickness1 As System.Double, _  
    ByVal Thickness2 As System.Double, _  
    ByVal ReverseThinDir As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IPartDoc  
Dim Angle As System.Double  
Dim ReverseDir As System.Boolean  
Dim Angle2 As System.Double  
Dim RevType As System.Integer  
Dim Thickness1 As System.Double  
Dim Thickness2 As System.Double  
Dim ReverseThinDir As System.Integer  
  
instance.FeatureRevolveThin(Angle, ReverseDir, Angle2, RevType, Thickness1, Thickness2,  
ReverseThinDir)
```

C#

```
void FeatureRevolveThin(  
    System.double Angle,  
    System.bool ReverseDir,  
    System.double Angle2,  
    System.int RevType,  
    System.double Thickness1,  
    System.double Thickness2,  
    System.int ReverseThinDir  
)
```

C++/CLI

```
void FeatureRevolveThin(  
& System.double Angle,  
& System.bool ReverseDir,
```

```
& System.double Angle2,  
& System.int RevType,  
& System.double Thickness1,  
& System.double Thickness2,  
& System.int ReverseThinDir  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Angle

ReverseDir

Angle2

RevType

Thickness1

Thickness2

ReverseThinDir

Visual Basic for Applications (VBA) Syntax

See [PartDoc::FeatureRevolveThin](#).

See Also

[IPartDoc Interface](#)
[IPartDoc Members](#)