

SOLIDWORKS API (.NET VBA C#) — Reference

(229/337): IPropertyManagerPage2-
IPropertyManagerPageBitmap

SOLIDWORKS API Documentation (converted from CHM)

IPropertyManagerPage2 (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPage2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPage2 Interface

Provides add-in applications the ability to display and use views that have the look and feel of SOLIDWORKS PropertyManager pages.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPage2
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2
```

C#

```
public interface IPropertyManagerPage2
```

C++/CLI

```
public interface class IPropertyManagerPage2
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2](#).

Example

To create a .NET add-in that implements this interface, start with one of these Visual Studio projects:

- Visual Basic - SwVBAddin
- Visual C# - SwCSharpAddin

Example

[Create PropertyManager Page \(VBA\)](#)

Remarks

OK and Cancel buttons are optional for IPropertyManagerPage2 objects, but a Help button is always displayed. If you do not want to implement help for your add-in, return false on help notification to display SOLIDWORKS Help.

PropertyManager controls are displayed in a single, left-aligned column. Slight vertical spacing adjustment is available with the [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::IAddControl](#) or the [PropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#) Options argument.

Use [IModelDocExtension::GetUserPreferenceInteger](#)(swPropertyManagerColorDivider,UserPrefOption) to get the color of the PropertyManager divider box backgrounds for custom bitmap color blending purposes. The returned integer value is the COLORREF value.

The add-in application must implement the [IPropertyManagerPage2Handler8](#) interface for data to be exchanged with the add-in application. The add-in application owns the IPropertyManagerPage2 object, which owns the IPropertyManagerPage2Handler8 for that page.

The limits on the number of controls on a PropertyManager page are:

- Total number of controls = 300 (This number does not include group and selection boxes.)
- Total number of group boxes = 20
- Total number of selection boxes = 15

NOTE: Number boxes count as 2 controls. All other controls count as 1 control.

SOLIDWORKS does not allow suppressing components or features while a PropertyManager page is open.

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[ISldWorks::CreatePropertyManagerPage](#) and [ISldWorks::ICreatePropertyManagerPage](#)

Access Diagram

[PropertyManagerPage2](#)

See Also

[IPropertyManagerPage2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPropertyManagerPageActiveX Interface](#)
[IPropertyManagerPageBitmap Interface](#)
[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageButton Interface](#)
[IPropertyManagerPageCheckbox Interface](#)
[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageNumberbox Interface](#)
[IPropertyManagerPageOption Interface](#)
[IPropertyManagerPageSelectionbox Interface](#)
[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTextbox Interface](#)
[IPropertyManagerPageWindowFromHandle Interface](#)
[IModelDocExtension::GetActivePropertyManagerPage Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPage2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPage2 Interface

For a list of all members of this type, see [IPropertyManagerPage2 members](#).

Public Methods

Name	Description
 AddControl	Obsolete. Superseded by IPropertyManagerPage2::AddControl2 .
 AddControl2	Adds a control to this PropertyManager page.
 AddGroupBox	Adds a group box to a PropertyManager page.
 AddMenuPopUpItem	Adds a menu item to the pop-up menu for this PropertyManager page.
 AddTab	Adds a tab to a PropertyManager page.
 Close	Closes the current page in the PropertyManager.
 EnableButton	Sets whether to enable the buttons on the PropertyManager.
 GetFocus	Gets the ID of the control that has focus on this PropertyManager page.
 IAddControl	Obsolete. Superseded by IPropertyManagerPage2::AddControl2 .
 IAddGroupBox	Adds a group box to a PropertyManager page.
 SetCursor	Sets the cursor after a selection is made in the SOLIDWORKS graphics area.
 SetExitConfirmationCursor	Obsolete. Superseded by IPropertyManagerPage2::SetCursor .
 SetFocus	Sets focus on the specified control on this PropertyManager page.
 SetMessage	Obsolete. Superseded by IPropertyManagerPage2::SetMessage2 .
 SetMessage2	Obsolete. Superseded by PropertyManagerPage2::SetMessage3 .
 SetMessage3	Sets the message in this PropertyManager page.
 SetTitleBitmap	Obsolete. Superseded by IPropertyManagerPage2::SetTitleBitmapx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets the bitmap to display in the title of this PropertyManager page.

 SetTitleBitmap2	Obsolete. Superseded by IPropertyManagerPage2::SetTitleBitmapx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets the bitmap to display in the title of this PropertyManager page.
 SetTitleBitmapx64	Sets the bitmap to display in the title of this PropertyManager page.
 Show	Obsolete. Superseded by IPropertyManagerPage2::Show2.
 Show2	Shows the PropertyManager page.

[Top](#)

See Also

[IPropertyManagerPage2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPropertyManagerPageActiveX Interface](#)
[IPropertyManagerPageBitmap Interface](#)
[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageButton Interface](#)
[IPropertyManagerPageCheckbox Interface](#)
[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageNumberbox Interface](#)
[IPropertyManagerPageOption Interface](#)
[IPropertyManagerPageSelectionbox Interface](#)
[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTextbox Interface](#)
[IPropertyManagerPageWindowFromHandle Interface](#)
[IModelDocExtension::GetActivePropertyManagerPage Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPage2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPage2 Interface

The following tables list the members exposed by [IPropertyManagerPage2](#).

Public Properties

Name	Description
 Pinned	Gets or sets the state of the pushpin on a PropertyManager page.
 Title	Gets or sets the title of the PropertyManager page.

[Top](#)

Public Methods

Name	Description
 AddControl	Obsolete. Superseded by IPropertyManagerPage2::AddControl2.
 AddControl2	Adds a control to this PropertyManager page.
 AddGroupBox	Adds a group box to a PropertyManager page.
 AddMenuPopUpItem	Adds a menu item to the pop-up menu for this PropertyManager page.
 AddTab	Adds a tab to a PropertyManager page.
 Close	Closes the current page in the PropertyManager.
 EnableButton	Sets whether to enable the buttons on the PropertyManager.
 GetFocus	Gets the ID of the control that has focus on this PropertyManager page.
 IAddControl	Obsolete. Superseded by IPropertyManagerPage2::AddControl2.
 IAddGroupBox	Adds a group box to a PropertyManager page.
 SetCursor	Sets the cursor after a selection is made in the SOLIDWORKS graphics area.

	SetExitConfirmationCursor	Obsolete. Superseded by IPropertyManagerPage2::SetCursor .
	SetFocus	Sets focus on the specified control on this PropertyManager page.
	SetMessage	Obsolete. Superseded by IPropertyManagerPage2::SetMessage2 .
	SetMessage2	Obsolete. Superseded by PropertyManagerPage2::SetMessage3 .
	SetMessage3	Sets the message in this PropertyManager page.
	SetTitleBitmap	Obsolete. Superseded by IPropertyManagerPage2::SetTitleBitmapx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets the bitmap to display in the title of this PropertyManager page.
	SetTitleBitmap2	Obsolete. Superseded by IPropertyManagerPage2::SetTitleBitmapx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets the bitmap to display in the title of this PropertyManager page.
	SetTitleBitmapx64	Sets the bitmap to display in the title of this PropertyManager page.
	Show	Obsolete. Superseded by IPropertyManagerPage2::Show2 .
	Show2	Shows the PropertyManager page.

[Top](#)

 See Also

[IPropertyManagerPage2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPropertyManagerPageActiveX Interface](#)
[IPropertyManagerPageBitmap Interface](#)
[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageButton Interface](#)
[IPropertyManagerPageCheckbox Interface](#)
[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageNumberbox Interface](#)
[IPropertyManagerPageOption Interface](#)
[IPropertyManagerPageSelectionbox Interface](#)
[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTextbox Interface](#)
[IPropertyManagerPageWindowFromHandle Interface](#)
[IModelDocExtension::GetActivePropertyManagerPage Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPage2 Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [IPropertyManagerPage2 Interface](#)

For a list of all members of this type, see [IPropertyManagerPage2 members](#).

 Public Properties

Name	Description
 Pinned	Gets or sets the state of the pushpin on a PropertyManager page.
 Title	Gets or sets the title of the PropertyManager page.

[Top](#)

 See Also

[IPropertyManagerPage2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPropertyManagerPageActiveX Interface](#)
[IPropertyManagerPageBitmap Interface](#)
[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageButton Interface](#)

[IPropertyManagerPageCheckbox Interface](#)
[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageNumberbox Interface](#)
[IPropertyManagerPageOption Interface](#)
[IPropertyManagerPageSelectionbox Interface](#)
[IPropertyManagerPageSlider Interface](#)
[IPropertyManagerPageTab Interface](#)
[IPropertyManagerPageTextbox Interface](#)
[IPropertyManagerPageWindowFromHandle Interface](#)
[IModelDocExtension::GetActivePropertyManagerPage Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddControl Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : AddControl Method (IPropertyManagerPage2)

Obsolete. Superseded by [IPropertyManagerPage2::AddControl2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddControl( _  
    ByVal ID As System.Integer, _  
    ByVal ControlType As System.Short, _  
    ByVal Caption As System.String, _  
    ByVal LeftAlign As System.Short, _  
    ByVal Options As System.Integer, _  
    ByVal Tip As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim ID As System.Integer  
Dim ControlType As System.Short  
Dim Caption As System.String  
Dim LeftAlign As System.Short  
Dim Options As System.Integer  
Dim Tip As System.String  
Dim value As System.Object  
  
value = instance.AddControl(ID, ControlType, Caption, LeftAlign, Options, Tip)
```

C#

```
System.object AddControl(  
    System.int ID,  
    System.short ControlType,  
    System.string Caption,  
    System.short LeftAlign,  
    System.int Options,  
    System.string Tip  
)
```

C++/CLI

```
System.Object^ AddControl(  
& System.int ID,  
& System.short ControlType,  
& System.String^ Caption,  
& System.short LeftAlign,  
& System.int Options,  
& System.String^ Tip  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

Resource ID of this control; API passes this user-defined value back to the add-in through the [IPropertyManagerPage2Handler8](#) interface

ControlType

Type of control as defined in [swPropertyManagerPageControlType_e](#)

Caption

Caption of this control

LeftAlign

Left-align property of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)

Options

Options as defined in [swAddControlOptions_e](#)

Tip

ToolTip for this control

Return Value

Newly created [PropertyManager page control](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::AddControl](#).

Remarks

You can only use this method to set properties on the PropertyManager before the page is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

To follow the SOLIDWORKS standards when designing a new PropertyManager page, it is a good idea to use [IPropertyManagerPage2::AddGroupBox](#) or [IPropertyManagerPage2::!AddGroupBox](#) and [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::!AddControl](#) to add controls for the page inside group boxes.

When you specify `swControlOptions_SmallGapAbove` for the Options parameter, a gap, smaller than the typical gap, is used between a new control and the previous control.

See Also

[IPropertyManagerPage2 Interface](#)

[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddControl2 Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : AddControl2 Method (IPropertyManagerPage2)

Adds a control to this PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function AddControl2( _  
    ByVal ID As System.Integer, _  
    ByVal ControlType As System.Short, _  
    ByVal Caption As System.String, _  
    ByVal LeftAlign As System.Short, _  
    ByVal Options As System.Integer, _  
    ByVal Tip As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim ID As System.Integer  
Dim ControlType As System.Short  
Dim Caption As System.String  
Dim LeftAlign As System.Short
```

```

Dim Options As System.Integer
Dim Tip As System.String
Dim value As System.Object

value = instance.AddControl2(ID, ControlType, Caption, LeftAlign, Options, Tip)

```

C#

```

System.Object AddControl2(
    System.int ID,
    System.short ControlType,
    System.string Caption,
    System.short LeftAlign,
    System.int Options,
    System.string Tip
)

```

C++/CLI

```

System.Object^ AddControl2(
    & System.int ID,
    & System.short ControlType,
    & System.String^ Caption,
    & System.short LeftAlign,
    & System.int Options,
    & System.String^ Tip
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

Resource ID of this control whose value is passed back to the add-in through the [IPropertyManagerPage2Handler9](#) interface

ControlType

Type of control as defined in [swPropertyManagerPageControlType_e](#)

Caption

Caption of this control

LeftAlign

Left alignment of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)

Options

Options as defined in [swAddControlOptions_e](#) (see **Remarks**)

Tip

ToolTip for this control

Return Value

Newly created [PropertyManager page control](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::AddControl2](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

You can only use this method to set properties on the PropertyManager before the page is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

To follow the SOLIDWORKS standards when designing a new PropertyManager page, it is a good idea to use [IPropertyManagerPage2::AddGroupBox](#) or [IPropertyManagerPage2::IAddGroupBox](#) and [IPropertyManagerPageGroup::AddControl2](#) to add controls for the page inside group boxes.

When you specify `swAddControlOptions_e.swControlOptions_SmallGapAbove` for the Options parameter, the gap created between the new control and the previous control is smaller than a typical gap. Also, the control is hidden unless you specify `swAddControlOptions_e.swControlOptions_Visible` for the Options parameter. In the previous versions of this method, `IPropertyManagerPage2::AddControl` and `IPropertyManagerPage2::IAddControl`, the control was visible regardless if the Options parameter was set or not set to `swAddControlOptions_e.swControlOptions_Visible`.

See Also

Availability

SOLIDWORKS 2014 SP1, Revision Number 22.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddGroupBox Method (IPropertyManagerPage2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : AddGroupBox Method (IPropertyManagerPage2)

Adds a group box to a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function AddGroupBox( _  
    ByVal ID As System.Integer, _  
    ByVal Caption As System.String, _  
    ByVal Options As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim ID As System.Integer  
Dim Caption As System.String  
Dim Options As System.Integer  
Dim value As System.Object  
  
value = instance.AddGroupBox(ID, Caption, Options)
```

C#

```
System.object AddGroupBox(  
    System.int ID,  
    System.string Caption,  
    System.int Options  
)
```

C++/CLI

```
System.Object^ AddGroupBox(  
& System.int ID,  
& System.String^ Caption,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Resource ID of the group box
Caption
Title of the group box
Options
Options as defined in [swAddGroupBoxOptions_e](#)

Return Value

Newly created [PropertyManager page group box](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::AddGroupBox](#).

Example

See the [IPropertyManagerPage2](#) examples.

Example

[Cut Body in Half Using Macro Feature \(VBA\)](#)

Remarks

Use this method to set properties on the PropertyManager page before the page is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [PropertyManagerPage2::Close](#) for details.

To change the title of an existing group box, use [IPropertyManagerPageGroup::Caption](#).

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)
[IPropertyManagerPage2::AddGroupBox Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddMenuPopupItem Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : AddMenuPopupItem Method (IPropertyManagerPage2)

Adds a menu item to the pop-up menu for this PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function AddMenuPopupItem( _  
    ByVal ID As System.Integer, _  
    ByVal ItemText As System.String, _  
    ByVal DocumentType As System.Integer, _  
    ByVal HintText As System.String _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim ID As System.Integer  
Dim ItemText As System.String  
Dim DocumentType As System.Integer  
Dim HintText As System.String  
Dim value As System.Boolean  
  
value = instance.AddMenuPopupItem(ID, ItemText, DocumentType, HintText)
```

C#

```
System.bool AddMenuPopupItem(  
    System.int ID,  
    System.string ItemText,  
    System.int DocumentType,  
    System.string HintText  
)
```

C++/CLI

```
System.bool AddMenuPopupItem(  
& System.int ID,  
& System.String^ ItemText,  
& System.int DocumentType,  
& System.String^ HintText  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

Unique user-defined value for this pop-up menu item

ItemText

Text for pop-up menu item

DocumentType

Document types for which this pop-up menu item is displayed as defined in [swDocumentTypes_e](#)

HintText

Text displayed in the SOLIDWORKS status bar when the user moves the cursor over this pop-up menu item

Return Value

True if the pop-up menu item is added, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::AddMenuPopupItem](#).

Remarks

This method requires that you implement these `IPropertyManagerPage2Handler8` methods:

- [IPropertyManagerPage2Handler8::OnPopupMenuItem](#). When the user selects a pop-up menu item, this method determines which item was selected. The add-in should then perform the appropriate action.
- [IPropertyManagerPage2Handler8::OnPopupMenuItemUpdate](#). When Windows attempts to select or deselect and enable or disable the pop-up menu item, SOLIDWORKS calls `IPropertyManagerPage2Handler8::OnPopupMenuItemUpdate` to get the state of the pop-up menu item from the add-in. Thus, `IPropertyManagerPage2Handler8::OnPopupMenuItemUpdate`:
 - Processes a request for the state of the specified pop-up menu item associated with the PropertyManager page.
 - Passes the state back to SOLIDWORKS.

See Also

[IPropertyManagerPage2 Interface](#)

[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddTab Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : AddTab Method (IPropertyManagerPage2)

Adds a tab to a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function AddTab(  
    ByVal ID As System.Integer, _  
    ByVal Caption As System.String, _  
    ByVal Bitmap As System.String, _  
    ByVal Options As System.Integer _  
) As PropertyManagerPageTab
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPage2  
Dim ID As System.Integer
```



```
Dim Caption As System.String
Dim Bitmap As System.String
Dim Options As System.Integer
Dim value As PropertyManagerPageTab

value = instance.AddTab(ID, Caption, Bitmap, Options)
```

C#

```
PropertyManagerPageTab AddTab(
    System.int ID,
    System.string Caption,
    System.string Bitmap,
    System.int Options
)
```

C++/CLI

```
PropertyManagerPageTab^ AddTab(
    & System.int ID,
    & System.String^ Caption,
    & System.String^ Bitmap,
    & System.int Options
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Identifier defined by the add-in for this tab

Caption
Text for tab

Bitmap
Bitmap for tab

Options
Not used; specify 0

Return Value

Newly created [PropertyManager page tab](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::AddTab](#).

Remarks

The ID argument provides an add-in with a way of identifying which tab is being handled when one of the callbacks is called; for example, when [IPropertyManagerPage2Handler8::OnTabClicked](#) is called. The ID is passed as an argument, identifying the tab clicked.

The Bitmap argument allows you to place a bitmap before the text on the tab. The argument is the full path and filename to a bitmap on disk. The bitmap should be 16 x 18 (width x height) pixels. It can be either 16 or 256 colors. Any portions of the bitmap that are RGB(255,255,255) will be transparent, letting the tab background show through. If this argument is an empty string or not the name of a valid bitmap file, no bitmap is placed on the tab.

Use this method to add tabs to your PropertyManager page before the page is displayed. It cannot be used if the page is already displayed.

Use [IPropertyManagerPageTab::Caption](#) to add a caption to the tab.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Close Method (IPropertyManagerPage2)

[See Also](#)



 .NET Syntax

Visual Basic (Declaration)

```
Sub Close( _  
    ByVal Okay As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim Okay As System.Boolean  
  
instance.Close(Okay)
```

C#

```
void Close(  
    System.bool Okay  
)
```

C++/CLI

```
void Close(  
& System.bool Okay  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Okay
VARIANT_True or VARIANT_false

Return Value

When you call...	Then...
Close(VARIANT_True)	IPropertyManagerPage2Handler8::OnClose is called with argument swPropertyManagerPageClose_Okay, regardless of which buttons are displayed at the top of the page.
Close(VARIANT_false)	IPropertyManagerPage2Handler8::OnClose is called with argument swPropertyManagerPageClose_Cancel, regardless of which buttons are displayed at the top of the page.

 Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::Close](#).

 See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)
[IPropertyManagerPage2::Show2 Method](#)
[IPropertyManagerPage2::AddControl Method](#)
[IPropertyManagerPage2::AddGroupBox Method](#)
[IPropertyManagerPage2::SetTitleBitmap2 Method](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

EnableButton Method (IPropertyManagerPage2)

[See Also](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Function EnableButton( _  
    ByVal WhichOne As System.Integer, _  
    ByVal Enable As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim WhichOne As System.Integer  
Dim Enable As System.Boolean  
Dim value As System.Boolean  
  
value = instance.EnableButton(WhichOne, Enable)
```

C#

```
System.bool EnableButton(  
    System.int WhichOne,  
    System.bool Enable  
)
```

C++/CLI

```
System.bool EnableButton(  
    & System.int WhichOne,  
    & System.bool Enable  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

Button as defined in [swPropertyManagerPageButtons e](#)

Enable

True enables the button, false disables it

Return Value

True if the button was enabled or disabled, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::EnableButton](#).

Remarks

You can only call this method after the page is displayed.

By default, all of the specified buttons that appear at the top of the PropertyManager are initially enabled, except for the Previous Page button.

NOTE: The intended use of this method is to disable the Previous Page button when the first of multiple pages is displayed and to disable the Next Page button when the last of multiple pages is displayed. However, you can use it whenever you want.

See Also

[IPropertyManagerPage2 Interface](#)

[IPropertyManagerPage2 Members](#)

[IPropertyManagerPageButton Interface](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : GetFocus Method (IPropertyManagerPage2)

Gets the ID of the control that has focus on this PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFocus() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim value As System.Integer  
  
value = instance.GetFocus()
```

C#

```
System.int GetFocus()
```

C++/CLI

```
System.int GetFocus();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

User-defined ID of the control that has focus

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::GetFocus](#).

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)
[IPropertyManagerPage2::SetFocus Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddControl Method (IPropertyManagerPage2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : IAddControl Method (IPropertyManagerPage2)

Obsolete. Superseded by [IPropertyManagerPage2::AddControl2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddControl(  
    ByVal ID As System.Integer, _  
    ByVal ControlType As System.Short, _  
    ByVal Caption As System.String, _  
    ByVal LeftAlign As System.Short, _  
    ByVal Options As System.Integer, _  
    ByVal Tip As System.String _  
) As PropertyManagerPageControl
```

Visual Basic (Usage)



```

Dim instance As IPropertyManagerPage2
Dim ID As System.Integer
Dim ControlType As System.Short
Dim Caption As System.String
Dim LeftAlign As System.Short
Dim Options As System.Integer
Dim Tip As System.String
Dim value As PropertyManagerPageControl

```

```
value = instance.IAddControl(ID, ControlType, Caption, LeftAlign, Options, Tip)
```

C#

```

PropertyManagerPageControl IAddControl(
    System.int ID,
    System.short ControlType,
    System.string Caption,
    System.short LeftAlign,
    System.int Options,
    System.string Tip
)

```

C++/CLI

```

PropertyManagerPageControl^ IAddControl(
    & System.int ID,
    & System.short ControlType,
    & System.String^ Caption,
    & System.short LeftAlign,
    & System.int Options,
    & System.String^ Tip
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

Resource ID of this control; API passes this user-defined value back to the add-in through the [IPropertyManagerPage2Handler8](#) interface

ControlType

Type of control as defined in [swPropertyManagerPageControlType_e](#)

Caption

Caption of this control

LeftAlign

Left-align property of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)

Options

Options as defined in [swAddControlOptions_e](#)

Tip

ToolTip for this control

Return Value

Newly created [PropertyManager page control](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::IAddControl](#).

Example

[Set Up PropertyManager Page Slider Control \(C++\)](#)

Remarks

You can only use this method to set properties on the PropertyManager before the page is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

To follow the SOLIDWORKS standards when designing a new PropertyManager page, it is a good idea to use [IPropertyManagerPage2::AddGroupBox](#) or [IPropertyManagerPage2::IAddGroupBox](#) and [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::IAddControl](#) to add controls for the page inside group boxes.

When you specify `swControlOptions_SmallGapAbove` for the `Options` parameter, a gap, smaller than the typical gap, is used between a new control and the previous control.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddGroupBox Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : IAddGroupBox Method (IPropertyManagerPage2)

Adds a group box to a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddGroupBox( _  
    ByVal ID As System.Integer, _  
    ByVal Caption As System.String, _  
    ByVal Options As System.Integer _  
) As PropertyManagerPageGroup
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim ID As System.Integer  
Dim Caption As System.String  
Dim Options As System.Integer  
Dim value As PropertyManagerPageGroup  
  
value = instance.IAddGroupBox(ID, Caption, Options)
```

C#

```
PropertyManagerPageGroup IAddGroupBox(  
    System.int ID,  
    System.string Caption,  
    System.int Options  
)
```

C++/CLI

```
PropertyManagerPageGroup^ IAddGroupBox(  
& System.int ID,  
& System.String^ Caption,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Resource ID of the group box
Caption
Title of the group box
Options
Options as defined in [swAddGroupBoxOptions_e](#)

Return Value

Newly created [PropertyManager page group box](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::AddGroupBox](#).

Remarks

Use this method to set properties on the PropertyManager page before the page is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [PropertyManagerPage2::Close](#) for details.

To change the title of an existing group box, use [IPropertyManagerPageGroup::Caption](#).

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)
[IPropertyManagerPage2::AddGroupBox Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Pinned Property (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : Pinned Property (IPropertyManagerPage2)

Gets or sets the state of the pushpin on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property Pinned As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2
Dim value As System.Boolean

instance.Pinned = value
value = instance.Pinned
```

C#

```
System.bool Pinned {get; set;}
```

C++/CLI

```
property System.bool Pinned {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if pushpin is pressed, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::Pinned](#).

Remarks

If the user clicks...	And PropertyManagerPage2::GetPinned is...	Then...
x	True or false	IPropertyManagerPage2Handler8::OnClose (swPropertyManagerPageClose_Closed) is called, the dialog closes, and IPropertyManagerPage2Handler8::AfterClose is called.
check mark	True	IPropertyManagerPage2Handler8::OnClose (swPropertyManagerPageClose_Apply) is called, the dialog is not closed, IPropertyManagerPage2Handler8::AfterClose is not called.
	false	IPropertyManagerPage2Handler8::OnClose (swPropertyManagerPageClose_Okay) is called, the dialog is closed, and IPropertyManagerPage2Handler8::AfterClose is called.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCursor Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SetCursor Method (IPropertyManagerPage2)

Sets the cursor after a selection is made in the SOLIDWORKS graphics area.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCursor( _
    ByVal Mode As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2
Dim Mode As System.Integer

instance.SetCursor(Mode)
```

C#

```
void SetCursor(
    System.int Mode
)
```

C++/CLI

```
void SetCursor(
    & System.int Mode
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Mode

Cursor as defined by [swPropertyManagerPageCursors_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SetCursor](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

Calling this method in [IPropertyManagerPage2Handler8::OnSelectionboxListChanged](#) enables the right-mouse button and cursor and allows an interactive user to:

- move to the next selection box on the PropertyManager page
- okay and close a PropertyManager page

after making a selection in the SOLIDWORKS graphics area.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetExitConfirmationCursor Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SetExitConfirmationCursor Method (IPropertyManagerPage2)

Obsolete. Superseded by [IPropertyManagerPage2::SetCursor](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetExitConfirmationCursor( _  
    ByVal Enable As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim Enable As System.Boolean  
  
instance.SetExitConfirmationCursor(Enable)
```

C#

```
void SetExitConfirmationCursor(  
    System.bool Enable  
)
```

C++/CLI

```
void SetExitConfirmationCursor(  
& System.bool Enable  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Enable

True to enable OK cursor, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SetExitConfirmationCursor](#).

Remarks

This method should only be used if your PropertyManager page has selection lists. For example, this cursor is displayed in the SOLIDWORKS Design user-interface when selecting one or more edges to fillet.

After enabling this cursor, you most likely should not disable it; instead, you should let SOLIDWORKS determine when to disable it. SOLIDWORKS disables this cursor when the cursor has moved even just a bit and replaces it with the cursor appropriate for the operation in progress.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFocus Method (IPropertyManagerPage2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SetFocus Method (IPropertyManagerPage2)

Sets focus on the specified control on this PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFocus( _  
    ByVal ID As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim ID As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetFocus(ID)
```

C#

```
System.bool SetFocus(  
    System.int ID  
)
```

C++/CLI

```
System.bool SetFocus(  
& System.int ID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
User-defined ID of the control where to set focus

Return Value

True if focus is set on the control, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SetFocus](#).

Example

[Set Focus on PropertyManager Page Control \(C#\)](#)
[Set Focus on PropertyManager Page Control \(VB.NET\)](#)
[Set Focus on PropertyManager Page Control \(VBA\)](#)

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)
[IPropertyManagerPage2::GetFocus Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SendMessage Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SendMessage Method (IPropertyManagerPage2)

Obsolete. Superseded by [IPropertyManagerPage2::SendMessage2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SendMessage( _  
    ByVal Message As System.String, _  
    ByVal Visibility As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim Message As System.String  
Dim Visibility As System.Integer  
Dim value As System.Boolean  
  
value = instance.SendMessage(Message, Visibility)
```

C#

```
System.bool SendMessage(  
    System.string Message,  
    System.int Visibility  
)
```

C++/CLI

```
System.bool SendMessage(  
    & System.String^ Message,  
    & System.int Visibility  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Message

Visibility

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SendMessage](#).

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

SetMessage2 Method (IPropertyManagerPage2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SetMessage2 Method (IPropertyManagerPage2)**Obsolete.** Superseded by [PropertyManagerPage2::SetMessage3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetMessage2( _
    ByVal Message As System.String, _
    ByVal Visibility As System.Integer, _
    ByVal Caption As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2
Dim Message As System.String
Dim Visibility As System.Integer
Dim Caption As System.String
Dim value As System.Boolean

value = instance.SetMessage2(Message, Visibility, Caption)
```

C#

```
System.bool SetMessage2(
    System.string Message,
    System.int Visibility,
    System.string Caption
)
```

C++/CLI

```
System.bool SetMessage2(
    & System.String^ Message,
    & System.int Visibility,
    & System.String^ Caption
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Parameters***Message*

Message text

*Visibility*Visibility state of this message as defined by [swPropertyManagerPageMessageVisibility](#).*Caption*

Caption for message

Return Value

True if the message is set, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SetMessage2](#).

Remarks

If Caption is empty, then the current caption is not changed.

This method should be useful when creating multi-page PropertyManager pages where you want different informational messages on each page

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetMessage3 Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SetMessage3 Method (IPropertyManagerPage2)

Sets the message in this PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMessage3( _  
    ByVal Message As System.String, _  
    ByVal Visibility As System.Integer, _  
    ByVal Expanded As System.Integer, _  
    ByVal Caption As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim Message As System.String  
Dim Visibility As System.Integer  
Dim Expanded As System.Integer  
Dim Caption As System.String  
Dim value As System.Boolean  
  
value = instance.SetMessage3(Message, Visibility, Expanded, Caption)
```

C#

```
System.bool SetMessage3(  
    System.string Message,  
    System.int Visibility,  
    System.int Expanded,  
    System.string Caption  
)
```

C++/CLI

```
System.bool SetMessage3(  
& System.String^ Message,  
& System.int Visibility,  
& System.int Expanded,  
& System.String^ Caption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Message
Message text

Visibility
Visibility state of this message as defined by [swPropertyManagerPageMessageVisibility](#)

Expanded
Expand, compress, or leave the state of the message as is, as defined by [swPropertyManagerPageMessageExpanded](#)

Caption
Caption for message

Return Value

True if the message is set, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SetMessage3](#).

Remarks

If Caption is empty, then the current caption is not changed.

This method should be useful when creating multi-page PropertyManager pages where you want different informational messages on each page

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTitleBitmap Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SetTitleBitmap Method (IPropertyManagerPage2)

Obsolete. Superseded by [IPropertyManagerPage2::SetTitleBitmapx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Sets the bitmap to display in the title of this PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTitleBitmap( _  
    ByVal ModuleHandle As System.Integer, _  
    ByVal Identifier As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim ModuleHandle As System.Integer  
Dim Identifier As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetTitleBitmap(ModuleHandle, Identifier)
```

C#

```
System.bool SetTitleBitmap(  
    System.int ModuleHandle,  
    System.int Identifier  
)
```

C++/CLI

```
System.bool SetTitleBitmap(  
& System.int ModuleHandle,  
& System.int Identifier  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModuleHandle

Identifier

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SetTitleBitmap](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

See Also

[IPropertyManagerPage2 Interface](#)

[IPropertyManagerPage2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTitleBitmap2 Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SetTitleBitmap2 Method (IPropertyManagerPage2)

Obsolete. Superseded by [IPropertyManagerPage2::SetTitleBitmapx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Sets the bitmap to display in the title of this PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTitleBitmap2( _  
    ByVal FilePathName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim FilePathName As System.String  
  
instance.SetTitleBitmap2(FilePathName)
```

C#

```
void SetTitleBitmap2(  
    System.string FilePathName  
)
```

C++/CLI

```
void SetTitleBitmap2(  
    & System.String^ FilePathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePathName

Path and filename of the bitmap to display in the title of this PropertyManager page

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SetTitleBitmap2](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#) for details.

Create the bitmap in the resources of your application. The bitmap must have less than 256 colors. It is accessed via the path and filename passed into this method. The recommended size for bitmaps is a square from 18- to 22-cells wide. However, the bitmap can be any size, as long as it fits on the title bar.

The bitmap appears transparent by mapping any white (RGB(255,255,255)) cells to the current PropertyManager page title bar background color. Remember the special use of this color as you design your bitmap.

If this method is...	Then the title bar contains...
Used	Specified bitmap starting at the left edge of the PropertyManager title bar, followed by the title bar text (see ISldWorks::CreatePropertyManagerPage or ISldWorks::ICreatePropertyManagerPage).
Not used	Only the text, centered on the title bar.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)
[IPropertyManagerPage2::Title Property](#)

Availability

SOLIDWORKS 2005 SP2, Revision Number 13.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTitleBitmapx64 Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : SetTitleBitmapx64 Method (IPropertyManagerPage2)

Sets the bitmap to display in the title of this PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTitleBitmapx64( _  
    ByVal ModuleHandle As System.Long, _  
    ByVal Identifier As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim ModuleHandle As System.Long  
Dim Identifier As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetTitleBitmapx64(ModuleHandle, Identifier)
```

C#

```
System.bool SetTitleBitmapx64(
    System.long ModuleHandle,
    System.int Identifier
)
```

C++/CLI

```
System.bool SetTitleBitmapx64(
    & System.int64 ModuleHandle,
    & System.int Identifier
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModuleHandle

Module handle of the application instance that contains the bitmap resource (see **Remarks**)

Identifier

Resource ID of the bitmap (see **Remarks**)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::SetTitleBitmapx64](#).

Remarks

This method is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software. Its intended use is for SOLIDWORKS PropertyManager .NET add-ins. For VBA PropertyManager pages, use [IPropertyManagerPage2::SetTitleBitmap2](#).

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#) for details.

The bitmap:

- must have less than 256 colors. Its recommended size is 18 - 22 cells wide. However, the bitmap can be any size, as long as it fits on the title bar.
- appears transparent by mapping any white (RGB(255,255,255)) cells to the current PropertyManager page title bar background color. Remember the special use of this color as you design your bitmap.
- must be a resource in your Visual Studio application. You must discover its resource ID before you can specify Identifier.

Specify ModuleHandle using the add-in ID.

If this method is...	Then the title bar contains...
Used	Specified bitmap starting at the left edge of the PropertyManager title bar, followed by the title bar text (see ISldWorks::CreatePropertyManagerPage or ISldWorks::ICreatePropertyManagerPage).
Not used	Only the text, centered on the title bar.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

Availability

SOLIDWORKS 2010 SP3, Revision Number 18.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

Show Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : Show Method (IPropertyManagerPage2)

Obsolete. Superseded by [IPropertyManagerPage2::Show2](#).

.NET Syntax

Visual Basic (Declaration)

Function Show() As System.Integer

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim value As System.Integer  
  
value = instance.Show()
```

C#

```
System.int Show()
```

C++/CLI

```
System.int Show();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2.Show](#).

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Show2 Method (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : Show2 Method (IPropertyManagerPage2)

Shows the PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function Show2( _  
    ByVal Options As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim Options As System.Integer  
Dim value As System.Integer  
  
value = instance.Show2(Options)
```

C#

```
System.int Show2(  
    System.int Options  
)
```

C++/CLI

```
System.int Show2(  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Options

Options as defined in [swPropertyManagerPageShowOptions_e](#)

Return Value

Status as defined by [swPropertyManagerPageStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::Show2](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

If another PropertyManager page is already displayed and that page is receptive to being stacked upon, then setting swPropertyManagerPageShowOptions_e to swPropertyManagerPageShowOptions_StackPage will stack your PropertyManager page on it. When the user closes your PropertyManager page, the previous PropertyManager page is shown automatically.

NOTE: Typically SOLIDWORKS does not stack PropertyManager pages, and in the couple instances where SOLIDWORKS does, it is an agreement between the PropertyManager pages. The first PropertyManager page agrees that it can be stacked upon and allows the other know PropertyManager page to stack upon it. The mechanism is not a case of one PropertyManager page allowing any other generic PropertyManager page to be stacked upon it. It is assumed that the two pages are in agreement about what is going on and deal with it.

Using the API to stack PropertyManager pages is the same -- an add-in is the owner of both PropertyManager pages and knows what is going on and deals with it. The concept of an API PropertyManager page wanting to know if it can stack upon the currently displayed PropertyManager page, whatever it might be, does not work because of the assumption that the first API PropertyManager page has knowledge of and allows another API PropertyManager page to stack on it.

If the PropertyManager page is locked, then stacking PropertyManager pages is not allowed. A PropertyManager page is locked if the Options argument of [ISldWorks::CreatePropertyManagerPage](#) or [ISldWorks::ICreatePropertyManagerPage](#) was set to swPropertyManagerOptions_LockedPage when the PropertyManager page was created.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)
[IPropertyManagerPage2::AddControl Method](#)
[IPropertyManagerPage2::AddGroupBox Method](#)
[IPropertyManagerPage2::Close Method](#)
[IPropertyManagerPage2::SetTitleBitmap2 Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Title Property (IPropertyManagerPage2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPage2 Interface](#) : Title Property (IPropertyManagerPage2)

Gets or sets the title of the PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property Title As System.String

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPage2  
Dim value As System.String
```

```
instance.Title = value
```

```
value = instance.Title
```

C#

```
System.string Title {get; set;}
```

C++/CLI

```
property System.String^ Title {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Title of PropertyManager page

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPage2::Title](#).

Remarks

You can use this method whether the page is displayed or not.

See Also

[IPropertyManagerPage2 Interface](#)
[IPropertyManagerPage2 Members](#)
[IPropertyManagerPage2::SetTitleBitmap2 Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

IPropertyManagerPageActiveX (Type)

IPropertyManagerPageActiveX Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageActiveX Interface

Allows you to access a [PropertyManager page](#) ActiveX control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageActiveX
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageActiveX
```

C#

```
public interface IPropertyManagerPageActiveX
```

C++/CLI

```
public interface class IPropertyManagerPageActiveX
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageActiveX](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

See [Using PropertyManagerPage2 and the Related Objects](#) for more information. See also [Keystrokes and Accelerator Keys to Handle ActiveX Modeless Dialogs and PropertyManager pages](#).

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::IAddControl](#)

Access Diagram

[PropertyManagerPageActiveX](#)

See Also

[IPropertyManagerPageActiveX Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageActiveX Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageActiveX Interface

For a list of all members of this type, see [IPropertyManagerPageActiveX members](#).

Public Methods

Name	Description
GetControl	Gets the interface to this ActiveX control.

		
	IGetControl	Gets the interface to this ActiveX control.
	SetClass	Sets the interface to this ActiveX control.

[Top](#)

See Also

[IPropertyManagerPageActiveX Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageActiveX Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageActiveX Interface

The following tables list the members exposed by [IPropertyManagerPageActiveX](#).

Public Properties

Name	Description
 Height	Gets or sets the height of this ActiveX control.

[Top](#)

Public Methods

Name	Description
 GetControl	Gets the interface to this ActiveX control.
 IGetControl	Gets the interface to this ActiveX control.
 SetClass	Sets the interface to this ActiveX control.

[Top](#)

See Also

[IPropertyManagerPageActiveX Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageActiveX Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageActiveX Interface

For a list of all members of this type, see [IPropertyManagerPageActiveX members](#).

Public Properties

Name	Description
 Height	Gets or sets the height of this ActiveX control.

[Top](#)

See Also

[IPropertyManagerPageActiveX Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControl Method (IPropertyManagerPageActiveX)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageActiveX Interface](#) : GetControl Method (IPropertyManagerPageActiveX)

Gets the interface to this ActiveX control.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControl() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageActiveX  
Dim value As System.Object  
  
value = instance.GetControl()
```

C#

```
System.object GetControl()
```

C++/CLI

```
System.Object^ GetControl();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

ActiveX control

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageActiveX::GetControl](#).

Remarks

Do not call this method until the PropertyManager page is displayed. If you call this method before the PropertyManager page is displayed, then the method will fail and retval is NULL.

When the ActiveX control is created, the program creating the PropertyManager page should receive notification from the `IPropertyManagerPage2Handler5::OnActiveXControlCreated` method. Your program should not call `IPropertyManagerPageActiveX::GetControl` or [IPropertyManagerPageActiveX::IGetControl](#) to get the interface object for this ActiveX control, because the PropertyManager page is not displayed when this notification is sent.

When the page is displayed, your program can now initialize the control properties so that the control looks how you want it to appear when it the PropertyManager page is initially displayed. You can set up the event sink for the control so that you receive notification when certain events happen to the control.

See Also

[IPropertyManagerPageActiveX Interface](#)
[IPropertyManagerPageActiveX Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IPropertyManagerPageActiveX)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageActiveX Interface](#) : Height Property (IPropertyManagerPageActiveX)

Gets or sets the height of this ActiveX control.

.NET Syntax

Visual Basic (Declaration)

```
Property Height As System.Short
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageActiveX
Dim value As System.Short

instance.Height = value
value = instance.Height
```

C#

```
System.short Height {get; set;}
```

C++/CLI

```
property System.short Height {
    System.short get();
    void set ( & System.short value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height of the control

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageActiveX::Height](#).

Remarks

This property only applies to some ActiveX controls. If the height does not apply to an ActiveX control, then this property does not affect the API PropertyManager page.

The height is in dialog-box units. You can convert these values to screen units (pixels) by using the MapDialogRect function.

See Also

[IPropertyManagerPageActiveX Interface](#)
[IPropertyManagerPageActiveX Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetControl Method (IPropertyManagerPageActiveX)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageActiveX Interface](#) : IGetControl Method (IPropertyManagerPageActiveX)

Gets the interface to this ActiveX control.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetControl() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageActiveX
Dim value As System.Object

value = instance.IGetControl()
```

C#

```
System.object IGetControl()
```



C++/CLI

```
System.Object^ IGetControl();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

ActiveX control

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageActiveX::IGetControl](#).

Remarks

Do not call this method until the PropertyManager page is displayed. If you call this method before the PropertyManager page is displayed, then the method will fail and return is NULL.

When the ActiveX control is created, the program creating the PropertyManager page should receive notification from the `IPropertyManagerPage2Handler5::OnActiveXControlCreated` method. Your program should not call [IPropertyManagerPageActiveX::GetControl](#) or `IPropertyManagerPageActiveX::IGetControl` to get the interface object for this ActiveX control, because the PropertyManager page is not displayed when this notification is sent.

When the page is displayed, your program can now initialize the control properties so that the control looks how you want it to appear when it the PropertyManager page is initially displayed. You can set up the event sink for the control so that you receive notification when certain events happen to the control.

See Also

[IPropertyManagerPageActiveX Interface](#)
[IPropertyManagerPageActiveX Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetClass Method (IPropertyManagerPageActiveX)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageActiveX Interface](#) : SetClass Method (IPropertyManagerPageActiveX)

Sets the interface to this ActiveX control.

.NET Syntax

Visual Basic (Declaration)

```
Function SetClass( _  
    ByVal ClassID As System.String, _  
    ByVal LicenseKey As System.String _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageActiveX  
Dim ClassID As System.String  
Dim LicenseKey As System.String  
Dim value As System.Boolean  
  
value = instance.SetClass(ClassID, LicenseKey)
```

C#

```
System.bool SetClass(  
    System.string ClassID,  
    System.string LicenseKey  
)
```

C++/CLI

```
System.bool SetClass(  
& System.String^ ClassID,  
& System.String^ LicenseKey  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ClassID

Class ID for the control

LicenseKey

License key for the control

Return Value

Always returns true

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageActiveX::SetClass](#).

Example

See the [IPropertyManagerPageActiveX](#) examples.

Remarks

This method sets the class ID and license key information for the ActiveX control when a PropertyManager page created using the API is shown and the ActiveX control is created. ClassId can be either the name of the control (ProgID) or the class ID (CLSID), for example, "MSCAL.calendar" or "{8E27C92B-1264-101C-8A2F-040224009C02}". Both provide the calendar protocol. You can obtain these strings using a combination of the Microsoft OLE/COM Object Viewer and the registry editor.

VBA example:

```
' ProgID  
bRet = m_pActiveXControl.SetClass("MSCAL.Calendar", "")  
bRet = m_pActiveXControl2.SetClass("MSComctlLib.ListViewCtrl", "")  
  
' CLSID  
bRet = m_pActiveXControl.SetClass("{8E27C92B-1264-101C-8A2F-040224009C02}", "")  
bRet = m_pActiveXControl2.SetClass("{BDD1F04B-858B-11D1-B16A-00C0F0283628}", "")
```

This method does not check to determine if the creation of the control worked. Instead, the [IPropertyManagerPage2Handler5::OnActiveXControlCreated](#) sends notification when an attempt to create the ActiveX control occurs, regardless if it is created or not. Use the IPropertyManagerPage2Handler5::OnActiveXControlCreated method's return value to indicate what action to take the creation of the control failed.

See Also

[IPropertyManagerPageActiveX Interface](#)
[IPropertyManagerPageActiveX Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IPropertyManagerPageBitmap (Type)

IPropertyManagerPageBitmap Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageBitmap Interface

Allows you to access a [PropertyManager page](#) bitmap.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageBitmap
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmap
```

C#

```
public interface IPropertyManagerPageBitmap
```

C++/CLI

```
public interface class IPropertyManagerPageBitmap
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmap](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::IAddControl](#)

Access Diagram

[PropertyManagerPageBitmap](#)

See Also

[IPropertyManagerPageBitmap Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageBitmap Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageBitmap Interface

The following tables list the members exposed by [IPropertyManagerPageBitmap](#).

Public Methods

Name	Description
SetBitmapByName	Sets the bitmap for this control.



[SetStandardBitmap](#)

Sets the bitmap or PNG image for this control.

[Top](#)

See Also

[IPropertyManagerPageBitmap Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageBitmap Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [IPropertyManagerPageBitmap Interface](#)

For a list of all members of this type, see [IPropertyManagerPageBitmap members](#).

Public Methods

Name	Description
 SetBitmapByName	Sets the bitmap for this control.
 SetStandardBitmap	Sets the bitmap or PNG image for this control.

[Top](#)

See Also

[IPropertyManagerPageBitmap Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBitmapByName Method (IPropertyManagerPageBitmap)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmap Interface](#) : [SetBitmapByName Method \(IPropertyManagerPageBitmap\)](#)

Sets the bitmap for this control.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBitmapByName( _  
    ByVal ColorBitmap As System.String, _  
    ByVal MaskBitmap As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmap  
Dim ColorBitmap As System.String  
Dim MaskBitmap As System.String  
Dim value As System.Boolean
```

```
value = instance.SetBitmapByName(ColorBitmap, MaskBitmap)
```

C#

```
System.bool SetBitmapByName(  
    System.string ColorBitmap,  
    System.string MaskBitmap  
)
```

C++/CLI

```
System.bool SetBitmapByName(
& System.String^ ColorBitmap,
& System.String^ MaskBitmap
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ColorBitmap

Full path and filename of the bitmap on disk

MaskBitmap

Full path and filename of the alpha mask bitmap on disk

Return Value

True if the bitmap is set for this control, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmap::SetBitmapByName](#).

Remarks

If you are creating a PropertyManager page add-in and ColorBitmap is either invalid or has the wrong path, this method displays an alternative image and returns false.

The typical image format for the two SOLIDWORKS bitmaps is 18 x 18 pixels x 256 colors. Using this method, you can specify a bigger bitmap, e.g., 24 x 24 pixels, to get extra detail. The pixels in MaskBitmap specify transparency through shades of grey with boundaries of black pixels = 100% opaque and white pixels = 100% transparent.

Use [IPropertyManagerPageControl::Top](#) to set the top of the control and use [IPropertyManagerPageControl::Tip](#) to set the ToolTip.

You can use this method before, during, or after the PropertyManager page is displayed or closed. If you use this method when the PropertyManager page is displayed, use bitmaps that are the same size.

See Also

[IPropertyManagerPageBitmap Interface](#)

[IPropertyManagerPageBitmap Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetStandardBitmap Method (IPropertyManagerPageBitmap)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmap Interface](#) : SetStandardBitmap Method (IPropertyManagerPageBitmap)

Sets the bitmap or PNG image for this control.

.NET Syntax

Visual Basic (Declaration)

```
Function SetStandardBitmap( _
    ByVal Bitmap As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageBitmap
Dim Bitmap As System.Integer
Dim value As System.Boolean

value = instance.SetStandardBitmap(Bitmap)
```

C#



```
System.bool SetStandardBitmap(  
    System.int Bitmap  
)
```

C++/CLI

```
System.bool SetStandardBitmap(  
& System.int Bitmap  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Bitmap

Control standard type as defined in [swBitmapControlStandardTypes_e](#)

Return Value

True if the bitmap or PNG image is set, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmap::SetStandardBitmap](#).

Example

See the [IPropertyManagerPageBitmap](#) examples.

Remarks

You can use this method before, during, or after the PropertyManager page is displayed or closed. If you use this method when the PropertyManager page is displayed, use a bitmap or PNG image that is the same size.

See Also

[IPropertyManagerPageBitmap Interface](#)
[IPropertyManagerPageBitmap Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0