

SOLIDWORKS API (NET VBA C#) — Reference (230/337): IPropertyManagerPageBitmapButton- IPROPERTYMANAGERPAGECONTROL

SOLIDWORKS API Documentation (converted from CHM)

IPropertyManagerPageBitmapButton (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPropertyManagerPageBitmapButton Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageBitmapButton Interface

Allows you to access a [PropertyManager page](#) bitmap button control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageBitmapButton
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmapButton
```

C#

```
public interface IPropertyManagerPageBitmapButton
```

C++/CLI

```
public interface class IPropertyManagerPageBitmapButton
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

Bitmaps are 256 colors. The standard bitmap buttons are 23 pixels wide x 23 pixels high; however, you can make them larger.

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::!AddControl](#)

Access Diagram

[PropertyManagerPageBitmapButton](#)

See Also

[IPropertyManagerPageBitmapButton Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPropertyManagerPageBitmapButton Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageBitmapButton Interface

For a list of all members of this type, see [IPropertyManagerPageBitmapButton members](#).

Public Methods

Name	Description
 SetBitmaps	Obsolete. Superseded by IPropertyManagerPageBitmapButton::SetBitmapsx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets the images for this button.
 SetBitmapsByName	Obsolete. Superseded by IPropertyManagerPageBitmapButton::SetBitmapsByName2.
 SetBitmapsByName2	Obsolete. Superseded by IPropertyManagerPageBitmapButton::SetBitmapsByName3.
 SetBitmapsByName3	Inserts the specified image for this button.
 SetBitmapsx64	Sets the images for this button in 64-bit applications.
 SetStandardBitmaps	Sets the standard images for this button.

[Top](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageBitmapButton Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageBitmapButton Interface

The following tables list the members exposed by [IPropertyManagerPageBitmapButton](#).

Public Properties

Name	Description
 Checked	Gets or sets the state of the bitmap button.
 IsCheckable	Gets whether the bitmap button is clickable.

[Top](#)

Public Methods

Name	Description
 SetBitmaps	Obsolete. Superseded by IPropertyManagerPageBitmapButton::SetBitmapsx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Sets the images for this button.
 SetBitmapsByName	Obsolete. Superseded by IPropertyManagerPageBitmapButton::SetBitmapsByName2.
 SetBitmapsByName2	Obsolete. Superseded by IPropertyManagerPageBitmapButton::SetBitmapsByName3.
 SetBitmapsByName3	Inserts the specified image for this button.
 SetBitmapsx64	Sets the images for this button in 64-bit applications.
 SetStandardBitmaps	Sets the standard images for this button.

[Top](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageBitmapButton Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageBitmapButton Interface

For a list of all members of this type, see [IPropertyManagerPageBitmapButton members](#).

Public Properties

Name	Description
 Checked	Gets or sets the state of the bitmap button.
 IsCheckable	Gets whether the bitmap button is clickable.

[Top](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Checked Property (IPropertyManagerPageBitmapButton)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmapButton Interface](#) : Checked Property (IPropertyManagerPageBitmapButton)

Gets or sets the state of the bitmap button.

.NET Syntax

Visual Basic (Declaration)

Property Checked As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmapButton  
Dim value As System.Boolean
```

```
instance.Checked = value
```

```
value = instance.Checked
```

C#

```
System.bool Checked {get; set;}
```

C++/CLI

```
property System.bool Checked {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if bitmap button is clicked, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton::Checked](#).

Remarks

This property is only meaningful and used by the SOLIDWORKS Design application when the bitmap button control is of type swControlType_CheckableBitmapButton.

You can create a bitmap button control using either of these methods:

- [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#)
- [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::IAddControl](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageBitmapButton Members](#)
[IPropertyManagerPageBitmapButton::IsCheckable Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsCheckable Property (IPropertyManagerPageBitmapButton)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmapButton Interface](#) : IsCheckable Property (IPropertyManagerPageBitmapButton)

Gets whether the bitmap button is clickable.

.NET Syntax

Visual Basic (Declaration)

Property IsCheckable As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmapButton  
Dim value As System.Boolean
```

```
instance.IsCheckable = value
```

```
value = instance.IsCheckable
```

C#

```
System.bool IsCheckable {get; set;}
```

C++/CLI

```
property System.bool IsCheckable {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if bitmap button is clickable, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton::IsCheckable](#).

Remarks

This property is only meaningful and used by the SOLIDWORKS Design application when the bitmap button control is of type `swControlType_CheckableBitmapButton`.

You can create a bitmap button control using either of these methods:

- [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#)
- [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::IAddControl](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageBitmapButton Members](#)
[IPropertyManagerPageBitmapButton::Checked Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBitmaps Method (IPropertyManagerPageBitmapButton)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmapButton Interface](#) : SetBitmaps Method (IPropertyManagerPageBitmapButton)

Obsolete. Superseded by [IPropertyManagerPageBitmapButton::SetBitmapsx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Sets the images for this button.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBitmaps( _  
    ByVal ModuleHandle As System.Integer, _  
    ByVal BitmapUp As System.Integer, _  
    ByVal BitmapDown As System.Integer, _  
    ByVal BitmapDisabled As System.Integer _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmapButton  
Dim ModuleHandle As System.Integer  
Dim BitmapUp As System.Integer  
Dim BitmapDown As System.Integer  
Dim BitmapDisabled As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetBitmaps(ModuleHandle, BitmapUp, BitmapDown, BitmapDisabled)
```

C#

```
System.bool SetBitmaps(  
    System.int ModuleHandle,  
    System.int BitmapUp,  
    System.int BitmapDown,  
    System.int BitmapDisabled  
)
```

C++/CLI

```
System.bool SetBitmaps(  
& System.int ModuleHandle,  
& System.int BitmapUp,  
& System.int BitmapDown,  
& System.int BitmapDisabled  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModuleHandle
Module handle of the application instance that contains the image resource
BitmapUp
Resource ID of the not-clicked state image resource
BitmapDown
Resource ID of the clicked state image resource
BitmapDisabled
Resource ID of the disabled state image resource

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton::SetBitmaps](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

The ModuleHandle argument for this method is the handle to the instance (HINSTANCE) of the user DLL, and the resource IDs for the not-clicked, clicked, and disabled states are the image resource integers. The SOLIDWORKS Design application loads the images from the user DL and uses them on this bitmap button control.

You must call this method after calling either of the following methods to create the button control:

- [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#)
- [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::IAddControl](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageBitmapButton Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBitmapsByName Method (IPropertyManagerPageBitmapButton)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmapButton Interface](#) : SetBitmapsByName Method (IPropertyManagerPageBitmapButton)

Obsolete. Superseded by [IPropertyManagerPageBitmapButton::SetBitmapsByName2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetBitmapsByName( _  
    ByVal BitmapUp As System.String, _  
    ByVal BitmapDown As System.String, _  
    ByVal BitmapDisabled As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageBitmapButton  
Dim BitmapUp As System.String  
Dim BitmapDown As System.String  
Dim BitmapDisabled As System.String  
Dim value As System.Boolean
```

```
value = instance.SetBitmapsByName(BitmapUp, BitmapDown, BitmapDisabled)
```

C#

```
System.bool SetBitmapsByName(  
    System.string BitmapUp,  
    System.string BitmapDown,  
    System.string BitmapDisabled  
)
```

C++/CLI

```
System.bool SetBitmapsByName(  
& System.String^ BitmapUp,  
& System.String^ BitmapDown,
```



```
& System.String^ BitmapDisabled
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BitmapUp

BitmapDown

BitmapDisabled

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton::SetBitmapsByName](#).

See Also

[IPropertyManagerPageBitmapButton Interface](#)

[IPropertyManagerPageBitmapButton Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetBitmapsByName2 Method (IPropertyManagerPageBitmapButton)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmapButton Interface](#) : SetBitmapsByName2 Method (IPropertyManagerPageBitmapButton)

Obsolete. Superseded by [IPropertyManagerPageBitmapButton::SetBitmapsByName3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetBitmapsByName2( _
    ByVal BitmapOrig As System.String, _
    ByVal BitmapMaskOrig As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmapButton
Dim BitmapOrig As System.String
Dim BitmapMaskOrig As System.String
Dim value As System.Boolean
```

```
value = instance.SetBitmapsByName2(BitmapOrig, BitmapMaskOrig)
```

C#

```
System.bool SetBitmapsByName2(
    System.string BitmapOrig,
    System.string BitmapMaskOrig
)
```

C++/CLI

```
System.bool SetBitmapsByName2(
    & System.String^ BitmapOrig,
    & System.String^ BitmapMaskOrig
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BitmapOrig

Full path and filename to the image in its non-selected state (see **Remarks**)

BitmapMaskOrig

Full path and filename to the image mask (see **Remarks**)

Return Value

True if the image is inserted, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton::SetBitmapsByName2](#).

Remarks

The rest of the images (selected, highlight regular, highlight selected, and disabled) are automatically generated by SOLIDWORKS. The size of the image is not restricted; you can insert an image of any size. However, the standard image size is 24-pixels wide and 24-pixels high with a margin of at least 3 blank pixels on all sides of the bitmap because this is where the button borders are drawn; i.e., any pixels in the image in these 3 outer rows and columns of pixels are obscured by the button borders.

You can specify your own image mask using the `BitmapMaskOrig` argument, which should display the image exactly as you created it. If you specify an empty string for `BitmapMaskOrig`, then SOLIDWORKS generates what it needs; however, your image might appear blurred.

NOTE: Portable Network Graphics images (.png) do not support masking. To use this method with a .png file, pass the .png file name to `BitmapOrig` and an empty string to `BitmapMaskOrig`.

You must call this method after calling either of the following methods to create the button control:

- [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#)
- [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::IAddControl](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageBitmapButton Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBitmapsByName3 Method (IPropertyManagerPageBitmapButton)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmapButton Interface](#) : SetBitmapsByName3 Method (IPropertyManagerPageBitmapButton)

Inserts the specified image for this button.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBitmapsByName3( _  
    ByVal ImageList As System.Object, _  
    ByVal MaskImageList As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmapButton  
Dim ImageList As System.Object  
Dim MaskImageList As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetBitmapsByName3(ImageList, MaskImageList)
```

C#

```
System.bool SetBitmapsByName3(  
    System.object ImageList,  
    System.object MaskImageList  
)
```

C++/CLI

```
System.bool SetBitmapsByName3(  
& System.Object^ ImageList,  
& System.Object^ MaskImageList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ImageList

Array of strings for the paths for the image files for the button in its non-selected state (see **Remarks**)

MaskImageList

Array of strings for the paths for the image files for the image masks (see **Remarks**)

Return Value

True if the image is inserted, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton::SetBitmapsByName3](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

This method supports scaling for high resolution screens with high resolution operating system scaling options.

ImageList and MaskImageList images can be:

- 20 x 20 pixels
- 32 x 32 pixels
- 40 x 40 pixels
- 64 x 64 pixels
- 96 x 96 pixels
- 128 x 128 pixels

Images should use:

- 256-color palette.
- margin of at least 3 blank pixels on all sides of the image because this is where the button borders are drawn; i.e., any pixels in the image in these 3 outer rows and columns of pixels are obscured by the button borders.

You can specify your own image masks using the MaskImageList argument, which should display the images exactly as you created them. If you specify an empty array for MaskImageList, then SOLIDWORKS generates what it needs; however, the images might appear blurred.

The order in which you specify the image files must be the same for ImageList and MaskImageList. For example, if you specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels images for ImageList, then you must specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels images for MaskImageList.

NOTES:

- The rest of the images (selected, highlight regular, highlight selected, and disabled) for this button are automatically generated by SOLIDWORKS.
- Portable Network Graphics images (.png) do not support masking. To use this method with .png files, pass an array of .png file names to ImageList and a blank string for each item in MaskImageList that corresponds to an item in ImageList.

You must call this method after calling either of the following methods to create the bitmap button control:

- [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#)
- [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::IAddControl](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)

[IPropertyManagerPageBitmapButton Members](#)

[ISldWorks::GetImageSize Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBitmapsx64 Method (IPropertyManagerPageBitmapButton)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmapButton Interface](#) : SetBitmapsx64 Method (IPropertyManagerPageBitmapButton)

Sets the images for this button in 64-bit applications.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBitmapsx64( _  
    ByVal ModuleHandle As System.Long, _  
    ByVal BitmapUp As System.Integer, _
```

```
ByVal BitmapDown As System.Integer, _  
    ByVal BitmapDisabled As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmapButton  
Dim ModuleHandle As System.Long  
Dim BitmapUp As System.Integer  
Dim BitmapDown As System.Integer  
Dim BitmapDisabled As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetBitmaps64(ModuleHandle, BitmapUp, BitmapDown, BitmapDisabled)
```

C#

```
System.bool SetBitmaps64(  
    System.long ModuleHandle,  
    System.int BitmapUp,  
    System.int BitmapDown,  
    System.int BitmapDisabled  
)
```

C++/CLI

```
System.bool SetBitmaps64(  
& System.int64 ModuleHandle,  
& System.int BitmapUp,  
& System.int BitmapDown,  
& System.int BitmapDisabled  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModuleHandle
Module handle of the application instance that contains the image resource
BitmapUp
Resource ID of the not-clicked state image resource
BitmapDown
Resource ID of the clicked state image resource
BitmapDisabled
Resource ID of the disabled state image resource

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton::SetBitmaps64](#).

Remarks

This method is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software.

The ModuleHandle argument for this method is the handle to the instance (HINSTANCE) of the user DLL, and the resource IDs for the not-clicked, clicked, and disabled states are the image resource integers. The SOLIDWORKS Design application loads the images from the user DL and uses them on this bitmap button control.

You must call this method after calling either of the following methods to create the bitmap button control:

- [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::!AddControl](#)
- [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::!AddControl](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageBitmapButton Members](#)
[IPropertyManagerPageBitmapButton::SetBitmaps Method](#)

Availability

SetStandardBitmaps Method (IPropertyManagerPageBitmapButton)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageBitmapButton Interface](#) : SetStandardBitmaps Method (IPropertyManagerPageBitmapButton)

Sets the standard images for this button.

.NET Syntax

Visual Basic (Declaration)

```
Function SetStandardBitmaps( _
    ByVal Bitmap As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageBitmapButton
Dim Bitmap As System.Integer
Dim value As System.Boolean
```

```
value = instance.SetStandardBitmaps(Bitmap)
```

C#

```
System.bool SetStandardBitmaps(
    System.int Bitmap
)
```

C++/CLI

```
System.bool SetStandardBitmaps(
    & System.int Bitmap
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*Bitmap*Standard images as defined by [swPropertyManagerPageBitmapButtons_e](#)

Return Value

True if standard images are set, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageBitmapButton::SetStandardBitmaps](#).

Example

See the [IPropertyManagerPageBitmapButton](#) examples.

Remarks

This is the quickest and easiest way to set images on a bitmap button control after the control is created. The not-clicked, clicked, and disabled states for the control are automatically set by the SOLIDWORKS Design application.

You must call this method after calling either of the following methods to create the bitmap button control:

- [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::IAddControl](#)
- [IPropertyManagerPageGroup::AddControl](#) or [IPropertyManagerPageGroup::IAddControl](#)

See Also

[IPropertyManagerPageBitmapButton Interface](#)
[IPropertyManagerPageBitmapButton Members](#)

IPropertyManagerPageButton (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageButton Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageButton Interface

Allows you to access a [PropertyManager page](#) button control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IPropertyManagerPageButton

Visual Basic (Usage)



Dim instance As [IPropertyManagerPageButton](#)

C#

public interface IPropertyManagerPageButton

C++/CLI

public interface class IPropertyManagerPageButton

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageButton](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

Users can resize PropertyManager pages horizontally in SOLIDWORKS 2006 and later. This change in functionality affects the appearance of the buttons on PropertyManager pages created in SOLIDWORKS 2005 and earlier.

In SOLIDWORKS 2005 and earlier, buttons remained aligned vertically at an indented position when a user resized a PropertyManager page. In most instances, these buttons are now centered when a user resizes a PropertyManager page. However, if a button on a PropertyManager page was aligned at the very left edge of the page and it was the only button on that line, then it is assumed that it was intentionally placed at that position and it will stay at that position if a user resizes the page. Any text on the button will also be left justified inside the button. If a button has a bitmap as its label, then the button remains next to the label instead of being centered.

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::IAddControl](#)

Access Diagram

[PropertyManagerPageButton](#)

See Also

[IPropertyManagerPageButton Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageButton Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [IPropertyManagerPageButton](#).

Public Properties

Name	Description
 Caption	Gets or sets the caption for this button.

[Top](#)

See Also

[IPropertyManagerPageButton Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageButton Interface Properties

[See Also](#)



For a list of all members of this type, see [IPropertyManagerPageButton members](#).

Public Properties

Name	Description
 Caption	Gets or sets the caption for this button.

[Top](#)

See Also

[IPropertyManagerPageButton Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

Caption Property (IPropertyManagerPageButton)

[See Also](#)



Gets or sets the caption for this button.

.NET Syntax

Visual Basic (Declaration)

Property Caption As System.String

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageButton
Dim value As System.String

instance.Caption = value
value = instance.Caption
```

C#

```
System.string Caption {get; set;}
```

C++/CLI

```
property System.String^ Caption {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Button text

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageButton::Caption](#).

See Also

[IPropertyManagerPageButton Interface](#)
[IPropertyManagerPageButton Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

IPropertyManagerPageCheckbox (Type)

IPropertyManagerPageCheckbox Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageCheckbox Interface

Allows you to access a [PropertyManager page](#) check box.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageCheckbox
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCheckbox
```

C#

```
public interface IPropertyManagerPageCheckbox
```

C++/CLI

```
public interface class IPropertyManagerPageCheckbox
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCheckbox](#).

Example

[Set Focus on PropertyManager Page Control \(VBA\)](#)

Remarks

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::IAddControl](#)

Access Diagram

[PropertyManagerPageCheckbox](#)

See Also

[IPropertyManagerPageCheckbox Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageCheckbox Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageCheckbox Interface

The following tables list the members exposed by [IPropertyManagerPageCheckbox](#).

Public Properties

Name	Description
------	-------------

 Caption	Gets or sets the label for this check box.
 Checked	Gets or sets this check box as selected.
 State	Gets or sets the state of this check box.

[Top](#)

 See Also

[IPropertyManagerPageCheckbox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPropertyManagerPageCheckbox Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageCheckbox Interface

For a list of all members of this type, see [IPropertyManagerPageCheckbox members](#).

 Public Properties

Name	Description
 Caption	Gets or sets the label for this check box.
 Checked	Gets or sets this check box as selected.
 State	Gets or sets the state of this check box.

[Top](#)

 See Also

[IPropertyManagerPageCheckbox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Caption Property (IPropertyManagerPageCheckbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCheckbox Interface](#) : Caption Property (IPropertyManagerPageCheckbox)

Gets or sets the label for this check box.

 .NET Syntax

Visual Basic (Declaration)

Property Caption As System.String

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCheckbox
Dim value As System.String

instance.Caption = value
value = instance.Caption
```

C#

System.string Caption {get; set;}

C++/CLI

```
property System.String^ Caption {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Check box label

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCheckbox::Caption](#).

See Also

[IPropertyManagerPageCheckbox Interface](#)
[IPropertyManagerPageCheckbox Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Checked Property (IPropertyManagerPageCheckbox)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCheckbox Interface](#) : Checked Property (IPropertyManagerPageCheckbox)

Gets or sets this check box as selected.

.NET Syntax

Visual Basic (Declaration)

Property Checked As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCheckbox  
Dim value As System.Boolean
```

```
instance.Checked = value
```

```
value = instance.Checked
```

C#

```
System.bool Checked {get; set;}
```

C++/CLI

```
property System.bool Checked {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the check box is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCheckbox::Checked](#).

Example

[Set Focus on PropertyManager Page Control \(C#\)](#)
[Set Focus on PropertyManager Page Control \(VB.NET\)](#)
[Set Focus on PropertyManager Page Control \(VBA\)](#)

See Also

Availability

SOLIDWORKS 2001Plus FCS, Revision number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

State Property (IPropertyManagerPageCheckbox)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCheckbox Interface](#) : State Property (IPropertyManagerPageCheckbox)

Gets or sets the state of this check box.

.NET Syntax

Visual Basic (Declaration)

Property State As System.Integer

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCheckbox  
Dim value As System.Integer
```

```
instance.State = value
```

```
value = instance.State
```

C#

```
System.int State {get; set;}
```

C++/CLI

```
property System.int State {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

State of this check box as defined in [swPropertyManagerCheckboxState_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCheckbox::State](#).

Example

[Set Focus on PropertyManager Page Control \(C#\)](#)
[Set Focus on PropertyManager Page Control \(VB.NET\)](#)
[Set Focus on PropertyManager Page Control \(VBA\)](#)

Remarks

If you use this property to set the state of a check box, then you must use this property to modify the state of the check box.

See Also

[IPropertyManagerPageCheckbox Interface](#)
[IPropertyManagerPageCheckbox Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

IPropertyManagerPageCombobox (Type)

IPropertyManagerPageCombobox Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageCombobox Interface

Allows you to access a [PropertyManager page](#) combo box control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageCombobox
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox
```

C#

```
public interface IPropertyManagerPageCombobox
```

C++/CLI

```
public interface class IPropertyManagerPageCombobox
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::IAddControl](#)

Access Diagram

[PropertyManagerPageCombobox](#)

See Also

[IPropertyManagerPageCombobox Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageCombobox Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageCombobox Interface

The following tables list the members exposed by [IPropertyManagerPageCombobox](#).

Public Properties

Name	Description
CurrentSelection	Gets and sets the item that is currently selected for this combo box.

[EditText](#)

Gets or sets the text in the combo box.

[Height](#)

Gets and sets the maximum height of the attached drop-down combo box.

[ItemText](#)

Gets the text from the attached drop-down list for this combo box.

[Style](#)

Gets or sets the style for the attached drop-down list for this combo box.

[Top](#)

Public Methods

Name	Description
AddItems	Adds items to the attached drop-down list for this combo box.
Clear	Clears all items from the attached drop-down list for this combo box.
DeleteItem	Deletes an item from the attached drop-down list of this combo box.
IAddItems	Adds items to the attached drop-down list for this combo box.
InsertItem	Inserts an item in the attached drop-down list of this combo box.

[Top](#)

See Also

[IPropertyManagerPageCombobox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageCombobox Interface Methods

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageCombobox Interface

For a list of all members of this type, see [IPropertyManagerPageCombobox members](#).

Public Methods

Name	Description
AddItems	Adds items to the attached drop-down list for this combo box.
Clear	Clears all items from the attached drop-down list for this combo box.
DeleteItem	Deletes an item from the attached drop-down list of this combo box.
IAddItems	Adds items to the attached drop-down list for this combo box.
InsertItem	Inserts an item in the attached drop-down list of this combo box.

[Top](#)

See Also

[IPropertyManagerPageCombobox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageCombobox Interface Properties

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageCombobox Interface

For a list of all members of this type, see [IPropertyManagerPageCombobox members](#).

Public Properties

Name	Description
CurrentSelection	Gets and sets the item that is currently selected for this combo box.
EditText	Gets or sets the text in the combo box.

 Height	Gets and sets the maximum height of the attached drop-down combo box.
 ItemText	Gets the text from the attached drop-down list for this combo box.
 Style	Gets or sets the style for the attached drop-down list for this combo box.

[Top](#)

See Also

[IPropertyManagerPageCombobox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddItems Method (IPropertyManagerPageCombobox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : AddItems Method (IPropertyManagerPageCombobox)

Adds items to the attached drop-down list for this combo box.

.NET Syntax

Visual Basic (Declaration)

```
Sub AddItems( _
    ByVal Texts As System.Object _
)
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageCombobox
Dim Texts As System.Object

instance.AddItems(Texts)
```

C#

```
void AddItems(
    System.object Texts
)
```

C++/CLI

```
void AddItems(
    & System.Object^ Texts
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Texts
Array of strings of items

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox::AddItems](#).

Example

See the [IPropertyManagerPageCombobox](#) examples.

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)
[IPropertyManagerPageCombobox::IAddItems Method](#)

Availability

Clear Method (IPropertyManagerPageCombobox)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : Clear Method (IPropertyManagerPageCombobox)

Clears all items from the attached drop-down list for this combo box.

.NET Syntax

Visual Basic (Declaration)

```
Sub Clear()
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
instance.Clear()
```

C#

```
void Clear()
```

C++/CLI

```
void Clear();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox::Clear](#).

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

CurrentSelection Property (IPropertyManagerPageCombobox)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : CurrentSelection Property (IPropertyManagerPageCombobox)

Gets and sets the item that is currently selected for this combo box.

.NET Syntax

Visual Basic (Declaration)

```
Property CurrentSelection As System.Short
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
Dim value As System.Short  
  
instance.CurrentSelection = value  
  
value = instance.CurrentSelection
```

C#

```
System.short CurrentSelection {get; set;}
```

C++/CLI

```
property System.short CurrentSelection {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Index number of the currently selected item in the 0-based list of items

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox::CurrentSelection](#).

Example

See the [IPropertyManagerPageCombobox](#) examples.

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteItem Method (IPropertyManagerPageCombobox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : DeleteItem Method (IPropertyManagerPageCombobox)

Deletes an item from the attached drop-down list of this combo box.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteItem( _  
    ByVal Item As System.Short _  
) As System.Short
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
Dim Item As System.Short  
Dim value As System.Short
```

```
value = instance.DeleteItem(Item)
```

C#

```
System.short DeleteItem(  
    System.short Item  
)
```

C++/CLI

```
System.short DeleteItem(  
& System.short Item  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Item

Index number of the item to delete from the 0-based list of items

Return Value

Number of items remaining in the list or -1 if the item is not deleted

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox::DeleteItem](#).

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EditText Property (IPropertyManagerPageCombobox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : EditText Property (IPropertyManagerPageCombobox)

Gets or sets the text in the combo box.

.NET Syntax

Visual Basic (Declaration)

Property EditText As System.String

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
Dim value As System.String
```

```
instance.EditText = value
```

```
value = instance.EditText
```

C#

```
System.string EditText {get; set;}
```

C++/CLI

```
property System.String^ EditText {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for or in combo box

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox::EditText](#).

Remarks

[IPropertyManagerPageCombobox::Style](#) must be set to swPropMgrPageComboBoxStyle_EditableText to edit text in a combo box.

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IPropertyManagerPageCombobox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : Height Property (IPropertyManagerPageCombobox)

Gets and sets the maximum height of the attached drop-down combo box.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Short

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
Dim value As System.Short
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.short Height {get; set;}
```

C++/CLI

```
property System.short Height {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum drop-down height

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox::Height](#).

Example

See the [IPropertyManagerPageCombobox](#) examples.

Remarks

Only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

The height is in dialog-box units. You can convert these values to screen units (pixels) by using the MapDialogRect function.

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddItems Method (IPropertyManagerPageCombobox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : IAddItems Method (IPropertyManagerPageCombobox)

Adds items to the attached drop-down list for this combo box.

.NET Syntax

Visual Basic (Declaration)

```
Sub IAddItems( _  
    ByVal TextCount As System.Short, _  
    ByRef Texts As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
Dim TextCount As System.Short  
Dim Texts As System.String  
  
instance.IAddItems(TextCount, Texts)
```

C#

```
void IAddItems(  
    System.short TextCount,  
    ref System.string Texts  
)
```

C++/CLI

```
void IAddItems(  
& System.short TextCount,  
& System.String^% Texts  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextCount

Number of items to add

Texts

- in-process, unmanaged C++: Pointer to an array of strings of the items of size TextCount
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)
[IPropertyManagerPageCombobox.AddItems Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertItem Method (IPropertyManagerPageCombobox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : InsertItem Method (IPropertyManagerPageCombobox)

Inserts an item in the attached drop-down list of this combo box.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertItem( _  
    ByVal Item As System.Short, _  
    ByVal Text As System.String _  
) As System.Short
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
Dim Item As System.Short  
Dim Text As System.String  
Dim value As System.Short  
  
value = instance.InsertItem(Item, Text)
```

C#

```
System.short InsertItem(  
    System.short Item,  
    System.string Text  
)
```

C++/CLI

```
System.short InsertItem(  
& System.short Item,  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Item

Position where to add the item in the 0-based list or -1 to put the item at the end of the list

Text

Text for item

Return Value

Position in the 0-based list where the item is added or -1 if the item is not added to the list

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox.InsertItem](#).

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemText Property (IPropertyManagerPageCombobox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : ItemText Property (IPropertyManagerPageCombobox)

Gets the text from the attached drop-down list for this combo box.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ItemText( _  
    ByVal Item As System.Short _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
Dim Item As System.Short  
Dim value As System.String  
  
value = instance.ItemText(Item)
```

C#

```
System.string ItemText(  
    System.short Item  
) {get;}
```

C++/CLI

```
property System.String^ ItemText {  
    System.String^ get(System.short Item);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Item

Position of the item where to get the text in the 0-based list of items or -1 to get the text of the currently selected item

Property Value

Text of the specified item

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox.ItemText](#).

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IPropertyManagerPageCombobox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageCombobox Interface](#) : Style Property (IPropertyManagerPageCombobox)

Gets or sets the style for the attached drop-down list for this combo box.

.NET Syntax

Visual Basic (Declaration)

```
Property Style As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageCombobox  
Dim value As System.Integer  
  
instance.Style = value
```

```
value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Combo-box style as defined in [swPropMgrPageComboBoxStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageCombobox::Style](#).

Remarks

Style is a combination of Boolean values, each represented by a bit in this long value. The different Boolean values are represented in the `swPropMgrPageComboBoxStyle_e` enumeration. For example, to set the attached drop-down list of a combo box so that the items are sorted, set Style to `swPropMgrPageComboBoxStyle_Sorted`.

The control style must be set before the PropertyManager page is displayed except if setting Style to `swPropMgrPageComboBoxStyle_EditBoxReadOnly`. You can set `swPropMgrPageComboBoxStyle_EditBoxReadOnly` either before or after the PropertyManager page is displayed.

See Also

[IPropertyManagerPageCombobox Interface](#)
[IPropertyManagerPageCombobox Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IPropertyManagerPageControl (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPropertyManagerPageControl Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageControl Interface

Provides a set of methods and properties common to all [PropertyManager page](#) controls.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageControl
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageControl
```

C#

```
public interface IPropertyManagerPageControl
```

C++/CLI

```
public interface class IPropertyManagerPageControl
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl](#).

Example

[Show Bubble ToolTip for PropertyManager Page Control \(VBA\)](#).

Remarks

These controls include:

- [IPropertyManagerPageActiveX](#)
- [IPropertyManagerPageBitmap](#)
- [IPropertyManagerPageBitmapButton](#)
- [IPropertyManagerPageButton](#)
- [IPropertyManagerPageCheckbox](#)
- [IPropertyManagerPageCombobox](#)
- [IPropertyManagerPageLabel](#)
- [IPropertyManagerPageListbox](#)
- [IPropertyManagerPageNumberbox](#)
- [IPropertyManagerPageOption](#)
- [IPropertyManagerPageSelectionbox](#)
- [IPropertyManagerPageSlider](#)
- [IPropertyManagerPageTab](#)
- [IPropertyManagerPageTextbox](#)
- [IPropertyManagerPageWindowFromHandle](#)

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::IAddControl](#)

Access Diagram

[PropertyManagerPageControl](#)

See Also

[IPropertyManagerPageControl Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageControl Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageControl Interface

The following tables list the members exposed by [IPropertyManagerPageControl](#).

Public Properties

Name	Description
 BackgroundColor	Gets or sets the background color of an edit box or label on the PropertyManager page.
 Enabled	Gets or sets the state of the PropertyManager page.
 Left	Gets or sets the left edge of the control on a PropertyManager page.
 OptionsForResize	Gets or sets how to override the SOLIDWORKS default behavior when changing the width of a PropertyManager page.
 TextColor	Gets or sets color of the text of a label on a PropertyManager page.
 Tip	Gets or sets the ToolTip for this control on a PropertyManager page.
 Top	Gets or sets the top edge of the control on a PropertyManager page.
 Visible	Gets or sets visibility state of a PropertyManager page.
 Width	Gets or sets the width of the control on a PropertyManager page.

[Top](#)

Public Methods

Name	Description
 GetGroupBox	Gets the PropertyManager group box to which this control belongs.
 SetPictureLabelByName	Sets the bitmap label for this control on a PropertyManager page.
 SetStandardPictureLabel	Sets the bitmap's or PNG image's label for this control on a PropertyManager page.
 ShowBubbleTooltip	Displays a bubble ToolTip containing the specified title, message, and bitmap.

[Top](#)

See Also

[IPropertyManagerPageControl Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageControl Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageControl Interface

For a list of all members of this type, see [IPropertyManagerPageControl members](#).

Public Methods

Name	Description
 GetGroupBox	Gets the PropertyManager group box to which this control belongs.
 SetPictureLabelByName	Sets the bitmap label for this control on a PropertyManager page.



[SetStandardPictureLabel](#)

Sets the bitmap's or PNG image's label for this control on a PropertyManager page.

[ShowBubbleTooltip](#)

Displays a bubble ToolTip containing the specified title, message, and bitmap.

[Top](#)

See Also

[IPropertyManagerPageControl Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageControl Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageControl Interface

For a list of all members of this type, see [IPropertyManagerPageControl members](#).

Public Properties

Name	Description
 BackgroundColor	Gets or sets the background color of an edit box or label on the PropertyManager page.
 Enabled	Gets or sets the state of the PropertyManager page.
 Left	Gets or sets the left edge of the control on a PropertyManager page.
 OptionsForResize	Gets or sets how to override the SOLIDWORKS default behavior when changing the width of a PropertyManager page.
 TextColor	Gets or sets color of the text of a label on a PropertyManager page.
 Tip	Gets or sets the ToolTip for this control on a PropertyManager page.
 Top	Gets or sets the top edge of the control on a PropertyManager page.
 Visible	Gets or sets visibility state of a PropertyManager page.
 Width	Gets or sets the width of the control on a PropertyManager page.

[Top](#)

See Also

[IPropertyManagerPageControl Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BackgroundColor Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : BackgroundColor Property (IPropertyManagerPageControl)

Gets or sets the background color of an edit box or label on the PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property BackgroundColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageControl  
Dim value As System.Integer
```

```
instance.BackgroundColor = value
```

```
value = instance.BackgroundColor
```

C#

```
System.int BackgroundColor {get; set;}
```

C++/CLI

```
property System.int BackgroundColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB value for the color of an edit box, a list box, or a label on the PropertyManager page

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::BackgroundColor](#).

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Enabled Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : Enabled Property (IPropertyManagerPageControl)

Gets or sets the state of the PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property Enabled As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageControl  
Dim value As System.Boolean
```

```
instance.Enabled = value
```

```
value = instance.Enabled
```

C#

```
System.bool Enabled {get; set;}
```

C++/CLI

```
property System.bool Enabled {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable the page, false to not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::Enabled](#).

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGroupBox Method (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : GetGroupBox Method (IPropertyManagerPageControl)

Gets the PropertyManager group box to which this control belongs.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGroupBox() As PropertyManagerPageGroup
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageControl  
Dim value As PropertyManagerPageGroup  
  
value = instance.GetGroupBox()
```

C#

```
PropertyManagerPageGroup GetGroupBox()
```

C++/CLI

```
PropertyManagerPageGroup^ GetGroupBox();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[PropertyManager page group box](#) or NULL if the control is not in a PropertyManager group box

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::GetGroupBox](#).

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Left Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : Left Property (IPropertyManagerPageControl)

Gets or sets the left edge of the control on a PropertyManager page.

.NET Syntax

```
Property Left As System.Short
```



```
Dim instance As IPropertyManagerPageControl
Dim value As System.Short
```

```
instance.Left = value
```

```
value = instance.Left
```

```
System.short Left {get; set;}
```

```
property System.short Left {
    System.short get();
    void set ( & System.short value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Left edge of the control

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::Left](#).

Remarks

This property must be set before the control is displayed.

If you do not specify the position and size of the controls on the PropertyManager page, the controls are created using a default size and placed in a computed default position so that your page matches the look-and-feel of a SOLIDWORKS PropertyManager page. This is generally the best way to go, whenever possible. However, while there are no limitations on how you create the layout of your page, it is recommended that you only use this method if you want to place controls on the page.

By default, the left edge of a control is either the left edge of its group box or indented a certain distance. This is determined by the LeftAlign argument of the [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::!AddControl](#) method. Using [IPropertyManagerPage2::AddControl](#) or [IPropertyManagerPage2::!AddControl](#) overrides that default. The value is in dialog units relative to the group box that the control is in. The left edge of the group box is 0; the right edge of the group box is 100.

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

OptionsForResize Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : OptionsForResize Property (IPropertyManagerPageControl)

Gets or sets how to override the SOLIDWORKS default behavior when changing the width of a PropertyManager page.

.NET Syntax

```
Property OptionsForResize As System.Integer
```

```
Dim instance As IPropertyManagerPageControl
Dim value As System.Integer

instance.OptionsForResize = value

value = instance.OptionsForResize
```

C#

```
System.int OptionsForResize {get; set;}
```

C++/CLI

```
property System.int OptionsForResize {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Resize the PropertyManager page as defined in [swPropMgrPageControlOnResizeOptions_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::OptionsForResize](#).

Remarks

If...	Then...
swControlOptionsOnResize_LockLeft specified	the control is locked in place relative to the left edge of the PropertyManager page. When the page width is changed, the control stays in place and its width does not change.
swControlOptionsOnResize_LockRight specified	the control is locked in place relative to the right edge of the PropertyManager page. When the page width is changed, the control shifts to the right, but its width does not change.
swControlOptionsOnResize_LockLeft and swControlOptionsOnResize_LockRight specified	the left edge of the control stays in place relative to the left edge and the right edge of the control stays in place relative to the right edge of the PropertyManager page, giving the effect that the control grows and shrinks with the PropertyManager page.

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2008 SP4, Revision Number 16.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPictureLabelByName Method (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : SetPictureLabelByName Method (IPropertyManagerPageControl)

Sets the bitmap label for this control on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPictureLabelByName( _
    ByVal ColorBitmap As System.String, _
    ByVal MaskBitmap As System.String _
) As System.Boolean
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IPropertyManagerPageControl
Dim ColorBitmap As System.String
Dim MaskBitmap As System.String
```

```
Dim value As System.Boolean
```

```
value = instance.SetPictureLabelByName(ColorBitmap, MaskBitmap)
```

C#

```
System.bool SetPictureLabelByName(  
    System.string ColorBitmap,  
    System.string MaskBitmap  
)
```

C++/CLI

```
System.bool SetPictureLabelByName(  
& System.String^ ColorBitmap,  
& System.String^ MaskBitmap  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ColorBitmap

Fully qualified path to the location of the bitmap (i.e., the graphic to use) on disk

MaskBitmap

Fully qualified path to the location of the alpha mask bitmap on disk

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::SetPictureLabelByName](#).

Remarks

The image format for the two bitmaps is 18 x 18 pixels x 256 colors. The pixels in MaskBitmap specify transparency through shades of grey with boundaries of black pixels = 100% opaque and white pixels = 100% transparent.

You can only use this method on a PropertyManager page before the page is displayed, while it is displayed, or when it is closed.

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetStandardPictureLabel Method (IPropertyManagerPageControl)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : SetStandardPictureLabel Method (IPropertyManagerPageControl)

Sets the bitmap's or PNG image's label for this control on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Function SetStandardPictureLabel( _  
    ByVal Bitmap As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageControl
Dim Bitmap As System.Integer
Dim value As System.Boolean

value = instance.SetStandardPictureLabel(Bitmap)
```

C#

```
System.bool SetStandardPictureLabel(
    System.int Bitmap
)
```

C++/CLI

```
System.bool SetStandardPictureLabel(
    & System.int Bitmap
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Bitmap

Label type as defined in [swControlBitmapLabelType_e](#)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::SetStandardPictureLabel](#).

Example

[Cut Body in Half Using Macro Feature \(VBA\)](#)

Remarks

You can only use this method on a PropertyManager page before the page is displayed, while it is displayed, or when it is closed.

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowBubbleTooltip Method (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : ShowBubbleTooltip Method (IPropertyManagerPageControl)

Displays a bubble ToolTip containing the specified title, message, and bitmap.

.NET Syntax

Visual Basic (Declaration)

```
Sub ShowBubbleTooltip( _
    ByVal Title As System.String, _
    ByVal Message As System.String, _
    ByVal BmpFile As System.String _
)
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IPropertyManagerPageControl
Dim Title As System.String
Dim Message As System.String
Dim BmpFile As System.String

instance.ShowBubbleTooltip(Title, Message, BmpFile)
```

C#

```
void ShowBubbleTooltip(
    System.string Title,
    System.string Message,
    System.string BmpFile
)
```

C++/CLI

```
void ShowBubbleTooltip(
    & System.String^ Title,
    & System.String^ Message,
    & System.String^ BmpFile
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Title
Title to display in bubble ToolTip

Message
Message to display in bubble ToolTip

BmpFile
Path and filename of bitmap to display in bubble ToolTip

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::ShowBubbleTooltip](#).

Example

See the [IPropertyManagerPageControl](#) examples.

Remarks

A bubble ToolTip is useful for validating data typed or selected by users in controls on a PropertyManager page.

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextColor Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : TextColor Property (IPropertyManagerPageControl)

Gets or sets color of the text of a label on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Property TextColor As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageControl
Dim value As System.Integer

instance.TextColor = value

value = instance.TextColor
```

C#

```
System.int TextColor {get; set;}
```

C++/CLI

```
property System.int TextColor {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RGB color value for the text of a label on a PropertyManager page

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::TextColor](#).

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Tip Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : Tip Property (IPropertyManagerPageControl)

Gets or sets the ToolTip for this control on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Property Tip As System.String
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageControl
Dim value As System.String

instance.Tip = value

value = instance.Tip
```

C#

```
System.string Tip {get; set;}
```

C++/CLI

```
property System.String^ Tip {
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

ToolTip text

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::Tip](#).

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Top Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : Top Property (IPropertyManagerPageControl)

Gets or sets the top edge of the control on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property Top As System.Short

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageControl  
Dim value As System.Short
```

```
instance.Top = value
```

```
value = instance.Top
```

C#

```
System.short Top {get; set;}
```

C++/CLI

```
property System.short Top {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Top edge of the control

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl::Top](#).

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Visible Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : Visible Property (IPropertyManagerPageControl)

Gets or sets visibility state of a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property Visible As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageControl  
Dim value As System.Boolean
```

```
instance.Visible = value
```

```
value = instance.Visible
```

C#

```
System.bool Visible {get; set;}
```

C++/CLI

```
property System.bool Visible {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable visibility, false to not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl.Visible](#).

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Width Property (IPropertyManagerPageControl)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageControl Interface](#) : Width Property (IPropertyManagerPageControl)

Gets or sets the width of the control on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property Width As System.Short

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageControl  
Dim value As System.Short
```

```
instance.Width = value
```

```
value = instance.Width
```

C#

```
System.short Width {get; set;}
```

C++/CLI

```
property System.short Width {  
    System.short get();  
    void set ( &    System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Width of the control

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageControl.Width](#).

Remarks

This property must be set before the control is displayed.

If you do not specify the position and size of the controls on the PropertyManager page, the controls are created using a default size and placed in a computed default position so that your page matches the look-and-feel of a SOLIDWORKS page. This is generally the best way to go, whenever possible. However, while there are no limitations on how you create the layout of your page, it is recommended that you only use this API if you want to explicitly place controls on the page.

By default, the width of the control is usually set so that it extends to the right edge of its group box. Using this API overrides that default. The value is in dialog units relative to the group box that the control is in. The width of the group box is 100.

See Also

[IPropertyManagerPageControl Interface](#)
[IPropertyManagerPageControl Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0