

SOLIDWORKS API (.NET VBA C#) — Reference

(231/337): IPropertyManagerPageGroup- IPropertyManagerPageListbox

SOLIDWORKS API Documentation (converted from CHM)

IPropertyManagerPageGroup (Type)

IPropertyManagerPageGroup Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageGroup Interface

Allows you to access a [PropertyManager page](#) group control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageGroup
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup
```

C#

```
public interface IPropertyManagerPageGroup
```

C++/CLI

```
public interface class IPropertyManagerPageGroup
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

You can have a maximum of 15 controls per PropertyManager page group.
See [Using PropertyManagerPage2](#) and the [Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddGroupBox](#) and [IPropertyManagerPage2::IAddGroupBox](#)

Access Diagram

[PropertyManagerPageGroup](#)

See Also

[IPropertyManagerPageGroup Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageGroup Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageGroup Interface

For a list of all members of this type, see [IPropertyManagerPageGroup members](#).

Public Methods

Name	Description
 AddControl	Obsolete. Superseded by IPropertyManagerPageGroup.AddControl2 .
 AddControl2	Adds a control to this PropertyManager page group box.
 IAddControl	Obsolete. Superseded by IPropertyManagerPageGroup.AddControl2 .

[Top](#)

See Also

[IPropertyManagerPageGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageGroup Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageGroup Interface

The following tables list the members exposed by [IPropertyManagerPageGroup](#).

Public Properties

Name	Description
 BackgroundColor	Gets or sets the backgroundColor of this PropertyManager group box.
 Caption	Gets or sets the title for this group box.
 Checked	Gets or sets the setting of a check box in the title of a group box on a PropertyManager page.
 Expanded	Gets or sets the group box expansion state.
 Visible	Gets or sets the group box visibility state.

[Top](#)

Public Methods

Name	Description
 AddControl	Obsolete. Superseded by IPropertyManagerPageGroup.AddControl2 .
 AddControl2	Adds a control to this PropertyManager page group box.
 IAddControl	Obsolete. Superseded by IPropertyManagerPageGroup.AddControl2 .

[Top](#)

See Also

[IPropertyManagerPageGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageGroup Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageGroup Interface

For a list of all members of this type, see [IPropertyManagerPageGroup members](#).

Public Properties

Name	Description
 BackgroundColor	Gets or sets the backgroundColor of this PropertyManager group box.
 Caption	Gets or sets the title for this group box.
 Checked	Gets or sets the setting of a check box in the title of a group box on a PropertyManager page.
 Expanded	Gets or sets the group box expansion state.
 Visible	Gets or sets the group box visibility state.

[Top](#)

See Also

[IPropertyManagerPageGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddControl Method (IPropertyManagerPageGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageGroup Interface](#) : AddControl Method (IPropertyManagerPageGroup)

Obsolete. Superseded by [IPropertyManagerPageGroup::AddControl2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddControl( _  
    ByVal ID As System.Integer, _  
    ByVal ControlType As System.Short, _  
    ByVal Caption As System.String, _  
    ByVal LeftAlign As System.Short, _  
    ByVal Options As System.Integer, _  
    ByVal Tip As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup  
Dim ID As System.Integer  
Dim ControlType As System.Short  
Dim Caption As System.String  
Dim LeftAlign As System.Short  
Dim Options As System.Integer  
Dim Tip As System.String  
Dim value As System.Object  
  
value = instance.AddControl(ID, ControlType, Caption, LeftAlign, Options, Tip)
```

C#

```
System.object AddControl(  
    System.int ID,  
    System.short ControlType,  
    System.string Caption,  
    System.short LeftAlign,  
    System.int Options,  
    System.string Tip  
)
```

C++/CLI

```
System.Object^ AddControl(  
& System.int ID,  
& System.short ControlType,  
& System.String^ Caption,  
& System.short LeftAlign,  
& System.int Options,  
& System.String^ Tip  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Resource ID of the control

ControlType
Type of control as defined in [swPropertyManagerPageControlType_e](#)

Caption
Caption of the control

LeftAlign

Left align property of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)

Options

Options as defined in [swAddControlOptions_e](#)

Tip

ToolTip text for the control

Return Value

Newly created [control for this PropertyManager page group box](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup::AddControl](#).

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

When you specify `swControlOptions_SmallGapAbove` for the Options parameter, gap is used between a new control and the previous control that is smaller than the typical gap.

See Also

[IPropertyManagerPageGroup Interface](#)

[IPropertyManagerPageGroup Members](#)

[IPropertyManagerPageGroup::IAddControl Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddControl2 Method (IPropertyManagerPageGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageGroup Interface](#) : AddControl2 Method (IPropertyManagerPageGroup)

Adds a control to this PropertyManager page group box.

.NET Syntax

Visual Basic (Declaration)

```
Function AddControl2(  
    ByVal ID As System.Integer, _  
    ByVal ControlType As System.Short, _  
    ByVal Caption As System.String, _  
    ByVal LeftAlign As System.Short, _  
    ByVal Options As System.Integer, _  
    ByVal Tip As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup  
Dim ID As System.Integer  
Dim ControlType As System.Short  
Dim Caption As System.String  
Dim LeftAlign As System.Short  
Dim Options As System.Integer  
Dim Tip As System.String  
Dim value As System.Object
```

```
value = instance.AddControl2(ID, ControlType, Caption, LeftAlign, Options, Tip)
```

C#

```
System.object AddControl2(
    System.int ID,
    System.short ControlType,
    System.string Caption,
    System.short LeftAlign,
    System.int Options,
    System.string Tip
)
```

C++/CLI

```
System.Object^ AddControl2(
    & System.int ID,
    & System.short ControlType,
    & System.String^ Caption,
    & System.short LeftAlign,
    & System.int Options,
    & System.String^ Tip
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
Resource ID of the control
ControlType
Type of control as defined in [swPropertyManagerPageControlType_e](#)
Caption
Caption of the control
LeftAlign
Left alignment of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)
Options
Options as defined in [swAddControlOptions_e](#) (see **Remarks**)
Tip
ToolTip text for the control

Return Value

Newly created [control for this PropertyManager page group box](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup::AddControl2](#).

Example

See the [IPropertyManagerPageGroup](#) examples.

Example

[Cut Body in Half Using Macro Feature \(VBA\)](#)

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

When you specify `swAddControlOptions_e.swControlOptions_SmallGapAbove` for the Options parameter, the gap created between a new control and the previous control is smaller than the typical gap. Also, the control is hidden unless you specify `swAddControlOptions_e.swControlOptions_Visible` for the Options parameter. In the previous versions of this method, `IPropertyManagerPageGroup::AddControl` and `IPropertyManagerGroup::IAddControl`, the control was visible regardless if the Options parameter was set or not set to `swAddControlOptions_e.swControlOptions_Visible`.

See Also

[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageGroup Members](#)

Availability

BackgroundColor Property (IPropertyManagerPageGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageGroup Interface](#) : BackgroundColor Property (IPropertyManagerPageGroup)

Gets or sets the background color of this PropertyManager group box.

.NET Syntax

Visual Basic (Declaration)

Property BackgroundColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup  
Dim value As System.Integer
```

```
instance.BackgroundColor = value
```

```
value = instance.BackgroundColor
```

C#

```
System.int BackgroundColor {get; set;}
```

C++/CLI

```
property System.int BackgroundColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

COLORREF value

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup::BackgroundColor](#).

Remarks

You can use a group box with just a [label](#) to look like a [message box](#) on a PropertyManager page. Set the background of the group box and the [background of the label](#) to the same color and the [label text](#) to a different color. You can also position the group box anywhere on the PropertyManager page.

NOTE: If you want to set the background color of the message box to be the same as the color typically used by SOLIDWORKS for a message box, use [ISldWorks::GetUserPreferenceIntegerValue](#) swPropertyManagerColorImportantMessage to get the COLORREF value.

See Also

[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageGroup Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

Caption Property (IPropertyManagerPageGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageGroup Interface](#) : Caption Property (IPropertyManagerPageGroup)

Gets or sets the title for this group box.

.NET Syntax

Visual Basic (Declaration)

Property Caption As System.String

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup  
Dim value As System.String  
  
instance.Caption = value  
value = instance.Caption
```

C#

```
System.string Caption {get; set;}
```

C++/CLI

```
property System.String^ Caption {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text for the title for this group box

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup::Caption](#).

Remarks

See [IPropertyManagerPage2::AddGroupBox](#) or [IPropertyManagerPage2::!AddGroupBox](#) to add a group box.

See Also

[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageGroup Members](#)

Availability

SOLIDWORKS 2005 SP2, Revision Number 13.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

Checked Property (IPropertyManagerPageGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageGroup Interface](#) : Checked Property (IPropertyManagerPageGroup)

Gets or sets the setting of a check box in the title of a group box on a PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

Property Checked As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup  
Dim value As System.Boolean
```

```
instance.Checked = value
```

```
value = instance.Checked
```

C#

```
System.bool Checked {get; set;}
```

C++/CLI

```
property System.bool Checked {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the check box is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup::Checked](#).

Remarks

A group box on PropertyManager page can be created with a check box in its title. Selecting the check box causes the group box to expand so that all of the controls on that group box can be seen by the end-user. Clearing the check box causes the group box to close, or compress, so that all of the controls on that group box are hidden.

When a group box is expanded, the states of the controls within the group are not changed. For example, if all of the controls are disabled, they remain disabled when the group box is expanded. The owner of the PropertyManager page is responsible for setting the control states.

When the end-user selects or clears the check box of a group box, the [IPropertyManagerPage2Handler5::OnGroupCheck](#) method is called, so that your program can react to this event and do things such as enabling the appropriate controls. However, if your program is using this property to set the check box, then this method is not called and your program should set the controls after setting this property.

This property does not control whether or not there is a check box on your group box. That is determined when the group box is added. See [IPropertyManagerPage2::AddGroupBox](#) or [IPropertyManagerPage2::IAddGroupBox](#), specifically the Options argument.

See Also

[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageGroup Members](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Expanded Property (IPropertyManagerPageGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageGroup Interface](#) : Expanded Property (IPropertyManagerPageGroup)

Gets or sets the group box expansion state.

.NET Syntax

Visual Basic (Declaration)

Property Expanded As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup  
Dim value As System.Boolean
```

```
instance.Expanded = value
```

```
value = instance.Expanded
```

C#

```
System.bool Expanded {get; set;}
```

C++/CLI

```
property System.bool Expanded {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to expand, false to not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup::Expanded](#).

See Also

[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageGroup Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddControl Method (IPropertyManagerPageGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageGroup Interface](#) : IAddControl Method (IPropertyManagerPageGroup)

Obsolete. Superseded by [IPropertyManagerPageGroup::AddControl2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddControl( _  
    ByVal ID As System.Integer, _  
    ByVal ControlType As System.Short, _  
    ByVal Caption As System.String, _  
    ByVal LeftAlign As System.Short, _  
    ByVal Options As System.Integer, _  
    ByVal Tip As System.String _  
    ) As PropertyManagerPageControl
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup  
Dim ID As System.Integer  
Dim ControlType As System.Short  
Dim Caption As System.String  
Dim LeftAlign As System.Short  
Dim Options As System.Integer  
Dim Tip As System.String  
Dim value As PropertyManagerPageControl
```

```
value = instance.IAddControl(ID, ControlType, Caption, LeftAlign, Options, Tip)
```

C#

```
PropertyManagerPageControl IAddControl(
    System.int ID,
    System.short ControlType,
    System.string Caption,
    System.short LeftAlign,
    System.int Options,
    System.string Tip
)
```

C++/CLI

```
PropertyManagerPageControl^ IAddControl(
    & System.int ID,
    & System.short ControlType,
    & System.String^ Caption,
    & System.short LeftAlign,
    & System.int Options,
    & System.String^ Tip
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

Resource ID of the control

ControlType

Type of control as defined in [swPropertyManagerPageControlType_e](#)

Caption

Caption of the control

LeftAlign

Left align property of this control as defined in [swPropertyManagerPageControlLeftAlign_e](#)

Options

Options as defined in [swAddControlOptions_e](#)

Tip

ToolTip text for the control

Return Value

Newly created [control for this PropertyManager page group box](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup::IAddControl](#).

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

When you specify `swControlOptions_SmallGapAbove` for the Options parameter, gap is used between a new control and the previous control that is smaller than the typical gap.

See Also

[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageGroup Members](#)
[IPropertyManagerPageGroup::AddControl Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Visible Property (IPropertyManagerPageGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageGroup Interface](#) : Visible Property (IPropertyManagerPageGroup)

Gets or sets the group box visibility state.

.NET Syntax

Visual Basic (Declaration)

Property Visible As System.Boolean

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageGroup  
Dim value As System.Boolean  
  
instance.Visible = value  
value = instance.Visible
```

C#

```
System.bool Visible {get; set;}
```

C++/CLI

```
property System.bool Visible {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable visibility, false to not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageGroup.Visible](#).

See Also

[IPropertyManagerPageGroup Interface](#)
[IPropertyManagerPageGroup Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IPropertyManagerPageLabel (Type)

IPropertyManagerPageLabel Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageLabel Interface

Allows you to access a [PropertyManager page](#) label control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageLabel
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageLabel
```

C#

```
public interface IPropertyManagerPageLabel
```

C++/CLI

```
public interface class IPropertyManagerPageLabel
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::IAddControl](#)

Access Diagram

[PropertyManagerPageLabel](#)

See Also

[IPropertyManagerPageLabel Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageLabel Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageLabel Interface

The following tables list the members exposed by [IPropertyManagerPageLabel](#).

Public Properties

Name	Description
Bold	Gets or sets whether the range of specified characters are bolded in this PropertyManager label.

[Caption](#)

Gets or sets the caption for this label.

[CharacterBackgroundColor](#)

Gets or sets the background color for the specified range of characters in this PropertyManager label.

[CharacterColor](#)

Gets or sets the color of the specified characters in this PropertyManager label.

[Font](#)

Gets or sets the font for the specified characters in this PropertyManager label.

[Height](#)

Gets or sets the height of this label.

[Italic](#)

Gets or sets whether to italicize the specified range of characters in this PropertyManager label.

[LineOffset](#)

Gets or sets whether to raise or lower the specified characters above or below their baselines, relative to their heights, in this PropertyManager label.

[SizeRatio](#)

Gets or sets the size of the specified characters in this PropertyManager label.

[Style](#)

Gets or sets style-related properties of this label.

[Underline](#)

Gets or sets whether to apply the specified underline style to the specified range of characters in this PropertyManager label.

[Top](#)

See Also

[IPropertyManagerPageLabel Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageLabel Interface Properties

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageLabel InterfaceFor a list of all members of this type, see [IPropertyManagerPageLabel members](#).

Public Properties

Name	Description
Bold	Gets or sets whether the range of specified characters are bolded in this PropertyManager label.
Caption	Gets or sets the caption for this label.
CharacterBackgroundColor	Gets or sets the background color for the specified range of characters in this PropertyManager label.
CharacterColor	Gets or sets the color of the specified characters in this PropertyManager label.
Font	Gets or sets the font for the specified characters in this PropertyManager label.
Height	Gets or sets the height of this label.
Italic	Gets or sets whether to italicize the specified range of characters in this PropertyManager label.
LineOffset	Gets or sets whether to raise or lower the specified characters above or below their baselines, relative to their heights, in this PropertyManager label.
SizeRatio	Gets or sets the size of the specified characters in this PropertyManager label.
Style	Gets or sets style-related properties of this label.
Underline	Gets or sets whether to apply the specified underline style to the specified range of characters in this PropertyManager label.

[Top](#)

See Also

[IPropertyManagerPageLabel Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Bold Property (IPropertyManagerPageLabel)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : Bold Property (IPropertyManagerPageLabel)

Gets or sets whether the range of specified characters are bolded in this PropertyManager label.

.NET Syntax

Visual Basic (Declaration)

```
Property Bold( _  
    ByVal StartChar As System.Short, _  
    ByVal EndChar As System.Short _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel  
Dim StartChar As System.Short  
Dim EndChar As System.Short  
Dim value As System.Boolean  
  
instance.Bold(StartChar, EndChar) = value  
  
value = instance.Bold(StartChar, EndChar)
```

C#

```
System.bool Bold(  
    System.short StartChar,  
    System.short EndChar  
) {get; set;}
```

C++/CLI

```
property System.bool Bold {  
    System.bool get(System.short StartChar, System.short EndChar);  
    void set (System.short StartChar, System.short EndChar, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartChar
0-based index value of start character
EndChar
0-based index value of end character

Property Value

TRUE to bold the specified range of characters, FALSE to not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel::Bold](#).

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Caption Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : Caption Property (IPropertyManagerPageLabel)

Gets or sets the caption for this label.

.NET Syntax

Visual Basic (Declaration)

```
Property Caption As System.String
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageLabel
Dim value As System.String

instance.Caption = value

value = instance.Caption
```

C#

```
System.string Caption {get; set;}
```

C++/CLI

```
property System.String^ Caption {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Caption text

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel::Caption](#).

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2001Plus SP2, Revision Number 10.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

CharacterBackgroundColor Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : CharacterBackgroundColor Property (IPropertyManagerPageLabel)

Gets or sets the background color for the specified range of characters in this PropertyManager label.

.NET Syntax

Visual Basic (Declaration)

```
Property CharacterBackgroundColor( _
    ByVal StartChar As System.Short, _
    ByVal EndChar As System.Short _
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageLabel
Dim StartChar As System.Short
Dim EndChar As System.Short
Dim value As System.Integer

instance.CharacterBackgroundColor(StartChar, EndChar) = value

value = instance.CharacterBackgroundColor(StartChar, EndChar)
```

C#

```
System.int CharacterBackgroundColor(  
    System.short StartChar,  
    System.short EndChar  
) {get; set;}
```

C++/CLI

```
property System.int CharacterBackgroundColor {  
    System.int get(System.short StartChar, System.short EndChar);  
    void set (System.short StartChar, System.short EndChar, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartChar
0-based index value of start character
EndChar
0-based index value of end character

Property Value

RGB value for the text background color for the specified characters; if not specified, then the background color for this control is used

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel.CharacterBackgroundColor](#).

Remarks

You can use a [group box](#) with just a [label](#) to look like a [message box](#) on a PropertyManager page. Set the [background of the group box](#) and the background of the label to the same color and the [label text](#) to a different color. You can also position the group box anywhere on the PropertyManager page.

NOTE: If you want to set the background color of the message box to be the same as the color typically used by SOLIDWORKS for a message box, use [ISldWorks::GetUserPreferenceIntegerValue](#) swPropertyManagerColorImportantMessage to get the COLORREF value.

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CharacterColor Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : CharacterColor Property (IPropertyManagerPageLabel)

Gets or sets the color of the specified characters in this PropertyManager label.

.NET Syntax

Visual Basic (Declaration)

```
Property CharacterColor( _  
    ByVal StartChar As System.Short, _  
    ByVal EndChar As System.Short _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel  
Dim StartChar As System.Short  
Dim EndChar As System.Short  
Dim value As System.Integer
```

```
instance.CharacterColor(StartChar, EndChar) = value
```

```
value = instance.CharacterColor(StartChar, EndChar)
```

C#

```
System.int CharacterColor(  
    System.short StartChar,  
    System.short EndChar  
) {get; set;}
```

C++/CLI

```
property System.int CharacterColor {  
    System.int get(System.short StartChar, System.short EndChar);  
    void set (System.short StartChar, System.short EndChar, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartChar
0-based index value of start character
EndChar
0-based index value of end character

Property Value

RGB value for the text color for the specified characters; if not specified, then the system default setting for text color is used

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel::CharacterColor](#).

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Font Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : Font Property (IPropertyManagerPageLabel)

Gets or sets the font for the specified characters in this PropertyManager label.

.NET Syntax

Visual Basic (Declaration)

```
Property Font( _  
    ByVal StartChar As System.Short, _  
    ByVal EndChar As System.Short _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel  
Dim StartChar As System.Short  
Dim EndChar As System.Short  
Dim value As System.String
```

```
instance.Font(StartChar, EndChar) = value
```

```
value = instance.Font(StartChar, EndChar)
```

C#

```
System.string Font(  
    System.short StartChar,  
    System.short EndChar  
) {get; set;}
```

C++/CLI

```
property System.String^ Font {  
    System.String^ get(System.short StartChar, System.short EndChar);  
    void set (System.short StartChar, System.short EndChar, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartChar

0-based index value of start character

EndChar

0-based index value of end character

Property Value

Name of the font to use for the specified characters

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel::Font](#).

See Also

[IPropertyManagerPageLabel Interface](#)

[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : Height Property (IPropertyManagerPageLabel)

Gets or sets the height of this label.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Short

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel
```

```
Dim value As System.Short
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.short Height {get; set;}
```

C++/CLI

```
property System.short Height {  
    System.short get();
```

```
void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height of label in dialog box units; defaults to 8

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel.Height](#).

Remarks

You can only set this property before the PropertyManager page is displayed.

Because SOLIDWORKS sizes the label appropriately based on the text it contains, you should not have to use this property. However, if the label does not contain text, then using this property might be useful.

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Italic Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : Italic Property (IPropertyManagerPageLabel)

Gets or sets whether to italicize the specified range of characters in this PropertyManager label.

.NET Syntax

Visual Basic (Declaration)

```
Property Italic( _  
    ByVal StartChar As System.Short, _  
    ByVal EndChar As System.Short _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel  
Dim StartChar As System.Short  
Dim EndChar As System.Short  
Dim value As System.Boolean  
  
instance.Italic(StartChar, EndChar) = value  
  
value = instance.Italic(StartChar, EndChar)
```

C#

```
System.bool Italic(  
    System.short StartChar,  
    System.short EndChar  
    ) {get; set;}
```

C++/CLI

```
property System.bool Italic {
    System.bool get(System.short StartChar, System.short EndChar);
    void set (System.short StartChar, System.short EndChar, System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartChar
0-based index value of start character
EndChar
0-based index value of end character

Property Value

True to italicize the specified range of characters, false to not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel::Italic](#).

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LineOffset Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : LineOffset Property (IPropertyManagerPageLabel)

Gets or sets whether to raise or lower the specified characters above or below their baselines, relative to their heights, in this PropertyManager label.

.NET Syntax

Visual Basic (Declaration)

```
Property LineOffset( _
    ByVal StartChar As System.Short, _
    ByVal EndChar As System.Short _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel
Dim StartChar As System.Short
Dim EndChar As System.Short
Dim value As System.Double
```

```
instance.LineOffset(StartChar, EndChar) = value
```

```
value = instance.LineOffset(StartChar, EndChar)
```

C#

```
System.double LineOffset(
    System.short StartChar,
    System.short EndChar
) {get; set;}
```

C++/CLI

```
property System.double LineOffset {
    System.double get(System.short StartChar, System.short EndChar);
```

```
void set (System.short StartChar, System.short EndChar, System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartChar
0-based index value of start character
EndChar
0-based index value of end character

Property Value

Specify:

- 0.0 to show the character on its baseline
- -1.0 to show the character 1 character below its baseline
- +1.0 to show the character 1 character above its baseline

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel.LineOffset](#).

Remarks

Offsetting (i.e., raising or lowering a character above or below its baseline, relative to its height) a character allows you to show that character as a subscript or exponent in an equation.

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SizeRatio Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : SizeRatio Property (IPropertyManagerPageLabel)

Gets or sets the size of the specified characters in this PropertyManager label.

.NET Syntax

Visual Basic (Declaration)

```
Property SizeRatio( _
    ByVal StartChar As System.Short, _
    ByVal EndChar As System.Short _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel
Dim StartChar As System.Short
Dim EndChar As System.Short
Dim value As System.Double
```

```
instance.SizeRatio(StartChar, EndChar) = value
```

```
value = instance.SizeRatio(StartChar, EndChar)
```

C#

```
System.double SizeRatio(
    System.short StartChar,
    System.short EndChar
) {get; set;}
```

C++/CLI

```
property System.double SizeRatio {  
    System.double get(System.short StartChar, System.short EndChar);  
    void set (System.short StartChar, System.short EndChar, System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartChar
0-based index value of start character
EndChar
0-based index value of end character

Property Value

Ratio for the height of the characters relative to their expected heights; >0 increases their heights and <0 decreases their height

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel::SizeRatio](#).

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : Style Property (IPropertyManagerPageLabel)

Gets or sets style-related properties of this label.

.NET Syntax

Visual Basic (Declaration)

```
Property Style As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel  
Dim value As System.Integer
```

```
instance.Style = value
```

```
value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Control style as defined in [swPropMgrPageLabelStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel::Style](#).

Remarks

You can only set this property before the PropertyManager is displayed.

This property value is a combination of several boolean values, each represented by a bit in this long value. The different values are represented in the [swPropMgrPageLabelStyle_e](#) enumeration. For example, to set a label control to have its text right-justified, you should set the Style argument to swPropMgrPageLabelStyle_RightText. By default, the text in PropertyManagerPageLabel is left-justified.

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Underline Property (IPropertyManagerPageLabel)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageLabel Interface](#) : Underline Property (IPropertyManagerPageLabel)

Gets or sets whether to apply the specified underline style to the specified range of characters in this PropertyManager label.

.NET Syntax

Visual Basic (Declaration)

```
Property Underline( _  
    ByVal StartChar As System.Short, _  
    ByVal EndChar As System.Short _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageLabel  
Dim StartChar As System.Short  
Dim EndChar As System.Short  
Dim value As System.Integer  
  
instance.Underline(StartChar, EndChar) = value  
  
value = instance.Underline(StartChar, EndChar)
```

C#

```
System.int Underline(  
    System.short StartChar,  
    System.short EndChar  
) {get; set;}
```

C++/CLI

```
property System.int Underline {  
    System.int get(System.short StartChar, System.short EndChar);  
    void set (System.short StartChar, System.short EndChar, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StartChar
0-based index value of start character
EndChar
0-based index value of end character

Property Value

Underline style as defined in [swPropMgrPageLabelUnderlineStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageLabel::Underline](#).

See Also

[IPropertyManagerPageLabel Interface](#)
[IPropertyManagerPageLabel Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

IPropertyManagerPageListbox (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IPropertyManagerPageListbox Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageListbox Interface

Allows you to access a [PropertyManager page](#) list box control.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IPropertyManagerPageListbox
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox
```

C#

```
public interface IPropertyManagerPageListbox
```

C++/CLI

```
public interface class IPropertyManagerPageListbox
```

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListbox](#).

Example

See the [IPropertyManagerPage2](#) examples.

Remarks

Implement the event handler [IPropertyManagerPage2Handler8::OnListBoxRMBUp](#) to position and display a menu when the right mouse button is released.

By default, only one list item can be selected at a time. When another list item is selected, that item becomes the active item, and the previously selected item is cleared. To enable multi-selection, use `swPropMgrPageListBoxStyle_MultipleItemSelect` with [IPropertyManagerPageListbox.Style](#).

These methods support multi-selection:

- [IPropertyManagerPageListbox::GetSelectedItems](#) or [IPropertyManagerPageListbox::!GetSelectedItems](#)
- [IPropertyManagerPageListbox::GetSelectedItemsCount](#)
- [IPropertyManagerPageListbox::SetSelectedItem](#)

See [Using PropertyManagerPage2 and the Related Objects](#) for more information.

Accessors

[IPropertyManagerPage2::AddControl](#) and [IPropertyManagerPage2::!AddControl](#)

Access Diagram

[PropertyManagerPageListbox](#)

See Also

[IPropertyManagerPageListbox Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageListbox Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageListbox Interface

For a list of all members of this type, see [IPropertyManagerPageListbox members](#).

Public Methods

Name	Description
 AddItems	Adds items to the attached drop-down list for this list box.
 Clear	Clears all items from attached drop-down list for this list box.
 DeleteItem	Removes the specified item from the attached drop-down list for this list box.
 GetSelectedItems	Gets the items selected in a list box enabled for multiple selections.
 GetSelectedItemsCount	Gets the number of items currently selected in a list box enabled for multiple selection.
 IAddItems	Adds items to the attached drop-down list for this list box.
 IGetSelectedItems	Gets the items selected in a list box enabled for multiple selections.
 InsertItem	Inserts an item in the attached drop-down list of this list box.
 SetSelectedItem	Sets whether an item is selected or cleared in a list box enabled for multiple selection.

[Top](#)

See Also

[IPropertyManagerPageListbox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IPropertyManagerPageListbox Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageListbox Interface

The following tables list the members exposed by [IPropertyManagerPageListbox](#).

Public Properties

Name	Description
 CurrentSelection	Gets and sets the item that is currently selected in this list box.
 Height	Gets and sets the height of the attached drop-down list for this list box.
 ItemCount	Gets the number of items in the attached drop-down list for this list box.
 ItemText	Gets the text for the specified item in this list box.
 Style	Gets or sets style for this list box.

[Top](#)

Public Methods

Name	Description
 AddItems	Adds items to the attached drop-down list for this list box.
 Clear	Clears all items from attached drop-down list for this list box.
 DeleteItem	Removes the specified item from the attached drop-down list for this list box.
 GetSelectedItems	Gets the items selected in a list box enabled for multiple selections.
 GetSelectedItemsCount	Gets the number of items currently selected in a list box enabled for multiple selection.
 IAddItems	Adds items to the attached drop-down list for this list box.
 IGetSelectedItems	Gets the items selected in a list box enabled for multiple selections.
 InsertItem	Inserts an item in the attached drop-down list of this list box.



[SetSelectedItem](#)

Sets whether an item is selected or cleared in a list box enabled for multiple selection.

[Top](#)

See Also

[IPropertyManagerPageListbox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IPropertyManagerPageListbox Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IPropertyManagerPageListbox Interface

For a list of all members of this type, see [IPropertyManagerPageListbox members](#).

Public Properties

Name	Description
 CurrentSelection	Gets and sets the item that is currently selected in this list box.
 Height	Gets and sets the height of the attached drop-down list for this list box.
 ItemCount	Gets the number of items in the attached drop-down list for this list box.
 ItemText	Gets the text for the specified item in this list box.
 Style	Gets or sets style for this list box.

[Top](#)

See Also

[IPropertyManagerPageListbox Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddItems Method (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : AddItems Method (IPropertyManagerPageListbox)

Adds items to the attached drop-down list for this list box.

.NET Syntax

Visual Basic (Declaration)

```
Sub AddItems( _  
    ByVal Texts As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageListbox  
Dim Texts As System.Object  
  
instance.AddItems(Texts)
```

C#

```
void AddItems(  
    System.object Texts  
)
```

C++/CLI



Copy Code

```
void AddItems(  
& System.Object^ Texts  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Texts
Array of strings of the items

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListBox::AddItems](#).

Example

See the [IPropertyManagerPageListBox](#) examples.

See Also

[IPropertyManagerPageListBox Interface](#)
[IPropertyManagerPageListBox Members](#)
[IPropertyManagerPageListBox::IAddItems Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Clear Method (IPropertyManagerPageListBox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListBox Interface](#) : Clear Method (IPropertyManagerPageListBox)

Clears all items from attached drop-down list for this list box.

.NET Syntax

Visual Basic (Declaration)

```
Sub Clear()
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListBox  
instance.Clear()
```

C#

```
void Clear()
```

C++/CLI

```
void Clear();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListBox::Clear](#).

See Also

[IPropertyManagerPageListBox Interface](#)
[IPropertyManagerPageListBox Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CurrentSelection Property (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : CurrentSelection Property (IPropertyManagerPageListbox)

Gets and sets the item that is currently selected in this list box.

.NET Syntax

Visual Basic (Declaration)

```
Property CurrentSelection As System.Short
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox  
Dim value As System.Short
```

```
instance.CurrentSelection = value
```

```
value = instance.CurrentSelection
```

C#

```
System.short CurrentSelection {get; set;}
```

C++/CLI

```
property System.short CurrentSelection {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Index number of the item in the 0-based list

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListbox::CurrentSelection](#).

Remarks

If you use this property with a list box enabled for [multiple selections](#), then this method returns -1 and does not affect the list box.

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteItem Method (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : DeleteItem Method (IPropertyManagerPageListbox)

Removes the specified item from the attached drop-down list for this list box.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function DeleteItem( _  
    ByVal Item As System.Short _  
) As System.Short
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox  
Dim Item As System.Short  
Dim value As System.Short  
  
value = instance.DeleteItem(Item)
```

C#

```
System.short DeleteItem(  
    System.short Item  
)
```

C++/CLI

```
System.short DeleteItem(  
& System.short Item  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Item

Index number of the item to delete from the 0-based list of items

Return Value

Number of items remaining in the list or -1 if the item is not deleted

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListbox::DeleteItem](#).

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSelectedItems Method (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : GetSelectedItems Method (IPropertyManagerPageListbox)

Gets the items selected in a list box enabled for multiple selections.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSelectedItems() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox  
Dim value As System.Object
```

```
value = instance.GetSelectedItems()
```

C#

```
System.object GetSelectedItems()
```

C++/CLI

```
System.Object^ GetSelectedItems();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of shorts of the currently selected items in this list box

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListBox::GetSelectedItems](#).

Remarks

Each item is a 0-based index into the list of items.

See Also

[IPropertyManagerPageListBox Interface](#)
[IPropertyManagerPageListBox Members](#)
[IPropertyManagerPageListBox::IGetSelectedItems Method](#)
[IPropertyManagerPageListBox::GetSelectedItemsCount Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSelectedItemsCount Method (IPropertyManagerPageListBox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListBox Interface](#) : GetSelectedItemsCount Method (IPropertyManagerPageListBox)

Gets the number of items currently selected in a list box enabled for multiple selection.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelectedItemsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListBox  
Dim value As System.Integer
```

```
value = instance.GetSelectedItemsCount()
```

C#

```
System.int GetSelectedItemsCount()
```

C++/CLI

```
System.int GetSelectedItemsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of items currently selected in this list box

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListbox::GetSelectedItemsCount](#).

Remarks

Call this method before calling [IPropertyManagerPageListbox::IGetSelectedItems](#) to size the array of selected items.

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)
[IPropertyManagerPageListbox::GetSelectedItems Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : Height Property (IPropertyManagerPageListbox)

Gets and sets the height of the attached drop-down list for this list box.

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Short

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox  
Dim value As System.Short
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.short Height {get; set;}
```

C++/CLI

```
property System.short Height {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListbox::Height](#).

Example

See the [IPropertyManagerPageListbox](#) examples.

Remarks

You can only use this method to set properties on the PropertyManager page before it is displayed or while it is closed. See [IPropertyManagerPage2::Show2](#) and [IPropertyManagerPage2::Close](#).

Value	Result
0	Default height with no scrolling
1 < 30	Specified height and no scrolling
>30	Specified height and scrolling, but no auto sizing

The height is in dialog-box units. You can convert these values to screen units (pixels) by using the Windows MapDialogRect function.

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddItems Method (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : IAddItems Method (IPropertyManagerPageListbox)

Adds items to the attached drop-down list for this list box.

.NET Syntax

Visual Basic (Declaration)

```
Sub IAddItems( _  
    ByVal TextCount As System.Short, _  
    ByRef Texts As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox  
Dim TextCount As System.Short  
Dim Texts As System.String  
  
instance.IAddItems(TextCount, Texts)
```

C#

```
void IAddItems(  
    System.short TextCount,  
    ref System.string Texts  
)
```

C++/CLI

```
void IAddItems(  
& System.short TextCount,  
& System.String^% Texts  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextCount

Number of items to add to the listbox

Texts

- in-process, unmanaged C++: Pointer to an array of strings of items of size TextCount
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)
[IPropertyManagerPageListbox::AddItems Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

[SOLIDWORKS API Help](#)

[Send comments](#) on this topic.

IGetSelectedItems Method (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : IGetSelectedItems Method (IPropertyManagerPageListbox)

Gets the items selected in a list box enabled for multiple selections.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSelectedItems( _  
    ByVal Count As System.Integer _  
) As System.Short
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox  
Dim Count As System.Integer  
Dim value As System.Short
```

```
value = instance.IGetSelectedItems(Count)
```

C#

```
System.short IGetSelectedItems(  
    System.int Count  
)
```

C++/CLI

```
System.short IGetSelectedItems(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of selected items

Return Value

- in-process, unmanaged C++: Pointer to an array of shorts of the currently selected items in this list box
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Each item is a 0-based index into the list of items.

Call [IPropertyManagerPageListbox::GetSelectedItemsCount](#) to size the returned array.

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)
[IPropertyManagerPageListbox::GetSelectedItems Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertItem Method (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : InsertItem Method (IPropertyManagerPageListbox)

Inserts an item in the attached drop-down list of this list box.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function InsertItem( _  
    ByVal Item As System.Short, _  
    ByVal Text As System.String _  
) As System.Short
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox  
Dim Item As System.Short  
Dim Text As System.String  
Dim value As System.Short  
  
value = instance.InsertItem(Item, Text)
```

C#

```
System.short InsertItem(  
    System.short Item,  
    System.string Text  
)
```

C++/CLI

```
System.short InsertItem(  
& System.short Item,  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Item

Position where to add the item in the 0-based list or -1 to put the item at the end of the list

Text

Text for item

Return Value

Position in the 0-based list where the item is added or -1 if the item is not added to the list

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListbox::InsertItem](#).

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemCount Property (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : ItemCount Property (IPropertyManagerPageListbox)

Gets the number of items in the attached drop-down list for this list box.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ItemCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox
Dim value As System.Integer

value = instance.ItemCount
```

C#

```
System.int ItemCount {get;}
```

C++/CLI

```
property System.int ItemCount {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of items in the attached drop-down list for this list box

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListbox::ItemCount](#).

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemText Property (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : ItemText Property (IPropertyManagerPageListbox)

Gets the text for the specified item in this list box.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ItemText( _
    ByVal Item As System.Short _
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox
Dim Item As System.Short
Dim value As System.String
```

```
value = instance.ItemText(Item)
```

C#

```
System.string ItemText(  
    System.short Item  
) {get;}
```

C++/CLI

```
property System.String^ ItemText {  
    System.String^ get(System.short Item);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Item

Position of the item where to get the text in the 0-based list or -1 to get the text of the currently selected item

Property Value

Text for the specified item

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListbox::ItemText](#).

See Also

[IPropertyManagerPageListbox Interface](#)
[IPropertyManagerPageListbox Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSelectedItem Method (IPropertyManagerPageListbox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListbox Interface](#) : SetSelectedItem Method (IPropertyManagerPageListbox)

Sets whether an item is selected or cleared in a list box enabled for multiple selection.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSelectedItem( _  
    ByVal Item As System.Short, _  
    ByVal Selected As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IPropertyManagerPageListbox  
Dim Item As System.Short  
Dim Selected As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.SetSelectedItem(Item, Selected)
```

C#

```
System.bool SetSelectedItem(  
    System.short Item,  
    System.bool Selected  
)
```

```
System.bool SetSelectedItem(
    & System.short Item,
    & System.bool Selected
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Item

Index of the item to select or clear

Selected

True to select the item, false to not

Return Value

True if the item was selected or cleared, false if not

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListBox::SetSelectedItem](#).

Example

See the [IPropertyManagerPageListBox](#) examples.

Remarks

The value specified for *Item* must be a valid index number. If it is not, then this method returns false. Thus, set up your list item index before using this method.

If you use this method to set a selected item in a single-selection style list box and another item in the list box is already selected, then that item is automatically cleared. You can use this method to clear a selection in a single-selection style list box, which results in no current selection in that list box.

See Also

[IPropertyManagerPageListBox Interface](#)
[IPropertyManagerPageListBox Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IPropertyManagerPageListBox)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IPropertyManagerPageListBox Interface](#) : Style Property (IPropertyManagerPageListBox)

Gets or sets style for this list box.

.NET Syntax

Visual Basic (Declaration)

```
Property Style As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IPropertyManagerPageListBox
Dim value As System.Integer
```

```
instance.Style = value
```

```
value = instance.Style
```

C#



```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style as defined in [swPropMgrPageListBoxStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [PropertyManagerPageListBox::Style](#).

Example

See the [IPropertyManagerPageListBox](#) examples.

Remarks

By default, only one list item can be selected at a time. When another list item is selected, that item becomes the active item and the previously selected item is cleared. To enable multi-selection, use `swPropMgrPageListBoxStyle_MultipleItemSelect` with [IPropertyManagerPageListBox::Style](#).

These methods support multi-selection:

- [IPropertyManagerPageListBox::GetSelectedItems](#) or [IPropertyManagerPageListBox::!GetSelectedItems](#)
- [IPropertyManagerPageListBox::GetSelectedItemsCount](#)
- [IPropertyManagerPageListBox::SetSelectedItem](#)

See Also

[IPropertyManagerPageListBox Interface](#)
[IPropertyManagerPageListBox Members](#)