

SOLIDWORKS API (.NET, VBA, C#) — Reference

(251/337): ISelectionSet-ISensor

SOLIDWORKS API Documentation (converted from CHM)

ISelectionSet (Type)

ISelectionSet Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSet Interface

Allows access to a selection set.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISelectionSet
```

Visual Basic (Usage)



```
Dim instance As ISelectionSet
```

C#

```
public interface ISelectionSet
```

C++/CLI

```
public interface class ISelectionSet
```

Visual Basic for Applications (VBA) Syntax

See [SelectionSet](#).

Example

[Create and Delete Selection Sets \(C#\)](#)
[Create and Delete Selection Sets \(VB.NET\)](#)
[Create and Delete Selection Sets \(VBA\)](#)
[Get Dispatch Objects for Selection Set Items \(C#\)](#)
[Get Dispatch Objects for Selection Set Items \(VB.NET\)](#)
[Get Dispatch Objects for Selection Set Items \(VBA\)](#)

Accessors

[IModelDocExtension::SaveSelection](#)
[ISelectionSetFolder::GetSelectionSetByName](#)
[ISelectionSetFolder::GetSelectionSets](#)

Access Diagram

[SelectionSet](#)

See Also

[ISelectionSet Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSetFolder Interface](#)
[ISelectionSetItem Interface](#)

ISelectionSet Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSet Interface

For a list of all members of this type, see [ISelectionSet members](#).

Public Methods

Name	Description
 GetName	Gets the name of the selection set.
 GetSelectionSetItems	Gets the selection set items in this selection set.
 GetSelectionSetItemTypes	Gets the types of entities in this selection set.
 RemoveSelectionSet	Deletes this selection set from the Selection Sets folder .
 Select	Selects all of the objects in this selection set.

[Top](#)

See Also

[ISelectionSet Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSetFolder Interface](#)
[ISelectionSetItem Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISelectionSet Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSet Interface

The following tables list the members exposed by [ISelectionSet](#).

Public Methods

Name	Description
 GetName	Gets the name of the selection set.
 GetSelectionSetItems	Gets the selection set items in this selection set.
 GetSelectionSetItemTypes	Gets the types of entities in this selection set.
 RemoveSelectionSet	Deletes this selection set from the Selection Sets folder .
 Select	Selects all of the objects in this selection set.

[Top](#)

See Also

[ISelectionSet Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSetFolder Interface](#)
[ISelectionSetItem Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetName Method (ISelectionSet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSet Interface](#) : GetName Method (ISelectionSet)

Gets the name of the selection set.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)

```
Dim instance As ISelectionSet  
Dim value As System.String  
  
value = instance.GetName()
```

C#



```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the selection set

Visual Basic for Applications (VBA) Syntax

See [SelectionSet::GetName](#).

Example

[Create and Delete Selection Sets \(C#\)](#)
[Create and Delete Selection Sets \(VB.NET\)](#)
[Create and Delete Selection Sets \(VBA\)](#)

See Also

[ISelectionSet Interface](#)
[ISelectionSet Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSelectionSetItems Method (ISelectionSet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSet Interface](#) : GetSelectionSetItems Method (ISelectionSet)

Gets the selection set items in this selection set.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelectionSetItems() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISelectionSet
Dim value As System.Object

value = instance.GetSelectionSetItems()
```

C#

```
System.object GetSelectionSetItems()
```

C++/CLI

```
System.Object^ GetSelectionSetItems();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [selection set items](#)

Visual Basic for Applications (VBA) Syntax

See [SelectionSet::GetSelectionSetItems](#).

Example

[Create and Delete Selection Sets \(C#\)](#)
[Create and Delete Selection Sets \(VB.NET\)](#)
[Create and Delete Selection Sets \(VBA\)](#)
[Get Dispatch Objects for Selection Set Items \(C#\)](#)
[Get Dispatch Objects for Selection Set Items \(VB.NET\)](#)
[Get Dispatch Objects for Selection Set Items \(VBA\)](#)

Remarks

To get the types of entities in the selection set, call [ISelectionSet::GetSelectionSetItemTypes](#).

See Also

[ISelectionSet Interface](#)
[ISelectionSet Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSelectionSetItemTypes Method (ISelectionSet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSet Interface](#) : GetSelectionSetItemTypes Method (ISelectionSet)

Gets the types of entities in this selection set.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelectionSetItemTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISelectionSet  
Dim value As System.Object  
  
value = instance.GetSelectionSetItemTypes()
```

C#

```
System.object GetSelectionSetItemTypes()
```

C++/CLI

```
System.Object^ GetSelectionSetItemTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of longs or integers of the types of entities in this selection set as defined in [swSelectType_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SelectionSet::GetSelectionSetItemTypes](#).

Example

[Create and Delete Selection Sets \(C#\)](#)
[Create and Delete Selection Sets \(VB.NET\)](#)
[Create and Delete Selection Sets \(VBA\)](#)
[Get Dispatch Objects for Selection Set Items \(C#\)](#)
[Get Dispatch Objects for Selection Set Items \(VB.NET\)](#)
[Get Dispatch Objects for Selection Set Items \(VBA\)](#)

Remarks

The order of the array of the types of entities returned by this method matches the order of the array of selection set items returned by [ISelectionSet::GetSelectionSetItems](#).

See Also

[ISelectionSet Interface](#)
[ISelectionSet Members](#)
[ISelectionSetItem::GetCorrespondingItem Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveSelectionSet Method (ISelectionSet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSet Interface](#) : RemoveSelectionSet Method (ISelectionSet)

Deletes this selection set from the [Selection Sets folder](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveSelectionSet() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISelectionSet  
Dim value As System.Boolean  
  
value = instance.RemoveSelectionSet()
```

C#

```
System.bool RemoveSelectionSet()
```

C++/CLI

```
System.bool RemoveSelectionSet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this selection set is deleted from the Selection Sets folder, false if not

Visual Basic for Applications (VBA) Syntax

See [SelectionSet::RemoveSelectionSet](#).

See Also

[ISelectionSet Interface](#)
[ISelectionSet Members](#)
[IModelDocExtension::SaveSelection Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (ISelectionSet)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSet Interface](#) : Select Method (ISelectionSet)

Selects all of the objects in this selection set.

.NET Syntax

Visual Basic (Declaration)

```
Function Select() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISelectionSet  
Dim value As System.Boolean
```

```
value = instance.Select()
```

C#

```
System.bool Select()
```

C++/CLI

```
System.bool Select();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if all of the objects in this selection set are selected, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SelectionSet.Select](#).

Example

[Get Objects in Selection Set \(C#\)](#)
[Get Objects in Selection Set \(VB.NET\)](#)
[Get Objects in Selection Set \(VBA\)](#)

Remarks

To use this method:

1. Call [ISelectionMgr::SuspendSelectionList](#) to suspend the current selection list, preserving its contents and starting a new selection list.
2. Call [ISelectionSet::Select](#) to add the objects in the selection set to the new selection list.
3. Process the objects in the new selection list.
4. Call [ISelectionMgr::ResumeSelectionList](#) to reinstate the suspended selection list.

See Also

[ISelectionSet Interface](#)
[ISelectionSet Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

ISelectionSetFolder (Type)

ISelectionSetFolder Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSetFolder Interface

Allows access to the Selection Sets folder.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISelectionSetFolder
```

Visual Basic (Usage)



```
Dim instance As ISelectionSetFolder
```

C#

```
public interface ISelectionSetFolder
```

C++/CLI

```
public interface class ISelectionSetFolder
```

Visual Basic for Applications (VBA) Syntax

See [SelectionSetFolder](#).

Example

[Create and Delete Selection Sets \(C#\)](#)
[Create and Delete Selection Sets \(VB.NET\)](#)
[Create and Delete Selection Sets \(VBA\)](#)
[Get Objects in Selection Set \(C#\)](#)
[Get Objects in Selection Set \(VB.NET\)](#)
[Get Objects in Selection Set \(VBA\)](#)
[Get Dispatch Objects for Selection Set Items \(C#\)](#)
[Get Dispatch Objects for Selection Set Items \(VB.NET\)](#)
[Get Dispatch Objects for Selection Set Items \(VBA\)](#)

Accessors

[IFeature::GetSpecificFeature2](#)
[IFeatureManager::GetSelectionSetFolder](#)

Access Diagram

[SelectionSetFolder](#)

See Also

[ISelectionSetFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSet Interface](#)
[ISelectionSetItem Interface](#)

ISelectionSetFolder Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSetFolder Interface

For a list of all members of this type, see [ISelectionSetFolder members](#).

Public Methods

Name	Description
 GetSelectionSetByName	Gets the specified selection set.
 GetSelectionSets	Gets the selection sets in the Selection Sets folder.

[Top](#)

See Also

[ISelectionSetFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSet Interface](#)
[ISelectionSetItem Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISelectionSetFolder Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSetFolder Interface

The following tables list the members exposed by [ISelectionSetFolder](#).

Public Methods

Name	Description
 GetSelectionSetByName	Gets the specified selection set.
 GetSelectionSets	Gets the selection sets in the Selection Sets folder.

[Top](#)

See Also

[ISelectionSetFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSet Interface](#)
[ISelectionSetItem Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSelectionSetByName Method (ISelectionSetFolder)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSetFolder Interface](#) : GetSelectionSetByName Method (ISelectionSetFolder)

Gets the specified selection set.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelectionSetByName( _  
    ByVal Name As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISelectionSetFolder  
Dim Name As System.String  
Dim value As System.Object
```

```
value = instance.GetSelectionSetByName(Name)
```

C#

```
System.object GetSelectionSetByName(  
    System.string Name  
)
```

C++/CLI

```
System.Object^ GetSelectionSetByName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Name of the selection set

Return Value

[Selection set](#)

Visual Basic for Applications (VBA) Syntax

See [SelectionSetFolder::GetSelectionSetByName](#).

Example

[Get Objects in Selection Set \(C#\)](#)
[Get Objects in Selection Set \(VB.NET\)](#)
[Get Objects in Selection Set \(VBA\)](#)

Remarks

To get the name of a selection folder to pass to this method, you can traverse [items in the FeatureManager design tree](#). See the examples.

See Also

[ISelectionSetFolder Interface](#)
[ISelectionSetFolder Members](#)
[ISelectionSetFolder::GetSelectionSets Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSelectionSets Method (ISelectionSetFolder)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSetFolder Interface](#) : GetSelectionSets Method (ISelectionSetFolder)

Gets the selection sets in the Selection Sets folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelectionSets() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISelectionSetFolder  
Dim value As System.Object  
  
value = instance.GetSelectionSets()
```

C#

```
System.object GetSelectionSets()
```

C++/CLI

```
System.Object^ GetSelectionSets();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [selection sets](#)

Visual Basic for Applications (VBA) Syntax

See [SelectionSetFolder::GetSelectionSets](#).

Example

[Create and Delete Selection Sets \(C#\)](#)
[Create and Delete Selection Sets \(VB.NET\)](#)
[Create and Delete Selection Sets \(VBA\)](#)
[Get Dispatch Objects for Selection Set Items \(C#\)](#)
[Get Dispatch Objects for Selection Set Items \(VB.NET\)](#)
[Get Dispatch Objects for Selection Set Items \(VBA\)](#)

See Also

[ISelectionSetFolder Interface](#)
[ISelectionSetFolder Members](#)
[ISelectionSetFolder::GetSelectionSetByName Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

ISelectionSetItem (Type)

ISelectionSetItem Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSetItem Interface

Allows access to a selection set item.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISelectionSetItem
```

Visual Basic (Usage)



```
Dim instance As ISelectionSetItem
```

C#

```
public interface ISelectionSetItem
```

C++/CLI

```
public interface class ISelectionSetItem
```

Visual Basic for Applications (VBA) Syntax

See [SelectionSetItem](#).

Example

[Create and Delete Selection Sets \(C#\)](#)
[Create and Delete Selection Sets \(VB.NET\)](#)
[Create and Delete Selection Sets \(VBA\)](#)
[Get Dispatch Objects for Selection Set Items \(C#\)](#)
[Get Dispatch Objects for Selection Set Items \(VB.NET\)](#)
[Get Dispatch Objects for Selection Set Items \(VBA\)](#)

Accessors

[ISelectionSet::GetSelectionSetItems](#)

Access Diagram

[SelectionSetItem](#)

See Also

[ISelectionSetItem Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSetFolder Interface](#)
[ISelectionSet Interface](#)

ISelectionSetItem Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSetItem Interface

For a list of all members of this type, see [ISelectionSetItem members](#).

Public Methods

Name	Description
GetCorrespondingItem	Gets the Dispatch object for this selection set item.



[RemoveFromSelectionSet](#)

Deletes this selection set item from this selection set.

[Top](#)

See Also

[ISelectionSetItem Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSetFolder Interface](#)
[ISelectionSet Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISelectionSetItem Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISelectionSetItem Interface

The following tables list the members exposed by [ISelectionSetItem](#).

Public Methods

Name	Description
 GetCorrespondingItem	Gets the Dispatch object for this selection set item.
 RemoveFromSelectionSet	Deletes this selection set item from this selection set.

[Top](#)

See Also

[ISelectionSetItem Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISelectionSetFolder Interface](#)
[ISelectionSet Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCorrespondingItem Method (ISelectionSetItem)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSetItem Interface](#) : GetCorrespondingItem Method (ISelectionSetItem)

Gets the Dispatch object for this selection set item.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCorrespondingItem() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISelectionSetItem  
Dim value As System.Object
```

```
value = instance.GetCorrespondingItem()
```

C#

```
System.object GetCorrespondingItem()
```

C++/CLI

```
System.Object^ GetCorrespondingItem();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the Dispatch object for this selection set item (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SelectionSetItem::GetCorrespondingItem](#).

Example

[Get Dispatch Objects for Selection Set Items \(C#\)](#)
[Get Dispatch Objects for Selection Set Items \(VB.NET\)](#)
[Get Dispatch Objects for Selection Set Items \(VBA\)](#)

Remarks

You can use this method to:

- pass the Dispatch object to [ISelectionMgr::AddSelectionListObject](#) or [ISelectionMgr::AddSelectionListObjects](#).
- typecast each element in [an array containing selection set item types](#). See the examples.

See Also

[ISelectionSetItem Interface](#)
[ISelectionSetItem Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveFromSelectionSet Method (ISelectionSetItem)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISelectionSetItem Interface](#) : RemoveFromSelectionSet Method (ISelectionSetItem)

Deletes this selection set item from this selection set.

.NET Syntax

Visual Basic (Declaration)

```
Sub RemoveFromSelectionSet()
```

Visual Basic (Usage)



```
Dim instance As ISelectionSetItem  
instance.RemoveFromSelectionSet()
```

C#

```
void RemoveFromSelectionSet()
```

C++/CLI

```
void RemoveFromSelectionSet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SelectionSetItem::RemoveFromSelectionSet](#).

Example

[Create and Delete Selection Sets \(C#\)](#)
[Create and Delete Selection Sets \(VB.NET\)](#)
[Create and Delete Selection Sets \(VBA\)](#)

See Also

[ISelectionSetItem Interface](#)
[ISelectionSetItem Members](#)

ISensor (Type)

ISensor Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISensor Interface

Allows access to a sensor, which can monitor selected properties of parts and assemblies and alert you when the sensor's values deviate from the specified limits.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISensor
```

Visual Basic (Usage)



```
Dim instance As ISensor
```

C#

```
public interface ISensor
```

C++/CLI

```
public interface class ISensor
```

Visual Basic for Applications (VBA) Syntax

See [Sensor](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

Accessors

[IFeature::GetSpecificFeature2](#)

Access Diagram

[Sensor](#)

See Also

[ISensor Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDimensionSensorData Interface](#)
[DPartDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)
[DAssemblyDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)

ISensor Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISensor Interface

The following tables list the members exposed by [ISensor](#).

Public Properties

Name	Description
 SensorAlertEnabled	Gets or sets whether an alert is triggered when the limits of the sensor deviate from its specified values.

	SensorAlertState	Gets whether an alert is currently triggered for this sensor.
	SensorAlertType	Gets or sets the type of alert for this sensor.
	SensorAlertValue1	Gets or sets the alert value for this sensor.
	SensorAlertValue2	Gets or sets alert value for this sensor; only in effect when sensor alert type set to swSensorAlert_Between.
	SensorType	Gets the type of this sensor.

[Top](#)

Public Methods

Name	Description
 GetSensorFeatureData	Gets a sensor feature data.
 GetSensorValue	Gets the value and units of this sensor.
 UpdateSensor	Updates the sensor.

[Top](#)

See Also

[ISensor Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDimensionSensorData Interface](#)
[DPartDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)
[DAssemblyDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISensor Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISensor Interface

For a list of all members of this type, see [ISensor members](#).

Public Methods

Name	Description
 GetSensorFeatureData	Gets a sensor feature data.
 GetSensorValue	Gets the value and units of this sensor.
 UpdateSensor	Updates the sensor.

[Top](#)

See Also

[ISensor Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDimensionSensorData Interface](#)
[DPartDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)
[DAssemblyDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISensor Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISensor Interface

For a list of all members of this type, see [ISensor members](#).

Public Properties

Name	Description
 SensorAlertEnabled	Gets or sets whether an alert is triggered when the limits of the sensor deviate from its specified values.
 SensorAlertState	Gets whether an alert is currently triggered for this sensor.
 SensorAlertType	Gets or sets the type of alert for this sensor.
 SensorAlertValue1	Gets or sets the alert value for this sensor.

 SensorAlertValue?	Gets or sets alert value for this sensor; only in effect when sensor alert type set to swSensorAlert_Between.
 SensorType	Gets the type of this sensor.

[Top](#)

See Also

[ISensor Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDimensionSensorData Interface](#)
[DPartDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)
[DAssemblyDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSensorFeatureData Method (ISensor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : GetSensorFeatureData Method (ISensor)

Gets a sensor feature data.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSensorFeatureData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISensor
Dim value As System.Object

value = instance.GetSensorFeatureData()
```

C#

```
System.object GetSensorFeatureData()
```

C++/CLI

```
System.Object^ GetSensorFeatureData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sensor feature data](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Sensor::GetSensorFeatureData](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

Remarks

Currently only Measurement (dimension) sensors are supported.

See Also

[ISensor Interface](#)
[ISensor Members](#)

Availability

GetSensorValue Method (ISensor)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : GetSensorValue Method (ISensor)

Gets the value and units of this sensor.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSensorValue( _
    ByRef Value As System.Double, _
    ByRef Units As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISensor
Dim Value As System.Double
Dim Units As System.String
Dim value As System.Boolean

value = instance.GetSensorValue(Value, Units)
```

C#

```
System.bool GetSensorValue(
    out System.double Value,
    out System.string Units
)
```

C++/CLI

```
System.bool GetSensorValue(
    & [Out] System.double Value,
    & [Out] System.String^ Units
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Value
Value of the sensor

Units
Units of the sensor

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Sensor::GetSensorValue](#).

See Also

[ISensor Interface](#)

[ISensor Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SensorAlertEnabled Property (ISensor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : SensorAlertEnabled Property (ISensor)

Gets or sets whether an alert is triggered when the limits of the sensor deviate from its specified values.

.NET Syntax

Visual Basic (Declaration)

```
Property SensorAlertEnabled As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISensor  
Dim value As System.Boolean  
  
instance.SensorAlertEnabled = value  
  
value = instance.SensorAlertEnabled
```

C#

```
System.bool SensorAlertEnabled {get; set;}
```

C++/CLI

```
property System.bool SensorAlertEnabled {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for an alert to be triggered when the limits of the sensor deviate from its specified values, false for it to not

Visual Basic for Applications (VBA) Syntax

See [Sensor::SensorAlertEnabled](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

See Also

[ISensor Interface](#)
[ISensor Members](#)
[ISensor::SensorAlertState Property](#)
[ISensor::SensorAlertType Property](#)
[ISensor::SensorAlertValue1 Property](#)
[ISensor::SensorAlertValue2 Property](#)
[DAssemblyDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)
[DPartDocEvents_SensorAlertPreNotifyEventHandler Delegate](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SensorAlertState Property (ISensor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : SensorAlertState Property (ISensor)

Gets whether an alert is currently triggered for this sensor.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property SensorAlertState As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISensor
Dim value As System.Boolean

value = instance.SensorAlertState
```

C#

```
System.bool SensorAlertState {get;}
```

C++/CLI

```
property System.bool SensorAlertState {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if an alert is currently triggered for this sensor, false if not

Visual Basic for Applications (VBA) Syntax

See [Sensor::SensorAlertState](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

See Also

[ISensor Interface](#)
[ISensor Members](#)
[ISensor::SensorAlertType Property](#)
[ISensor::SensorAlertValue1 Property](#)
[ISensor::SensorAlertValue2 Property](#)
[ISensor::SensorAlertEnabled Property](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SensorAlertType Property (ISensor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : SensorAlertType Property (ISensor)

Gets or sets the type of alert for this sensor.

.NET Syntax

Visual Basic (Declaration)

```
Property SensorAlertType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISensor
Dim value As System.Integer

instance.SensorAlertType = value

value = instance.SensorAlertType
```

C#

```
System.int SensorAlertType {get; set;}
```

C++/CLI

```
property System.int SensorAlertType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of sensor as defined by [swSensorAlertType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Sensor::SensorAlertType](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

See Also

[ISensor Interface](#)
[ISensor Members](#)
[ISensor::SensorAlertEnabled Property](#)
[ISensor::SensorAlertState Property](#)
[ISensor::SensorAlertValue1 Property](#)
[ISensor::SensorAlertValue2 Property](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

SensorAlertValue1 Property (ISensor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : SensorAlertValue1 Property (ISensor)

Gets or sets the alert value for this sensor.

.NET Syntax

Visual Basic (Declaration)

```
Property SensorAlertValue1 As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISensor
Dim value As System.Double

instance.SensorAlertValue1 = value

value = instance.SensorAlertValue1
```

C#

```
System.double SensorAlertValue1 {get; set;}
```

C++/CLI

```
property System.double SensorAlertValue1 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Alert value

Visual Basic for Applications (VBA) Syntax

See [Sensor::SensorAlertValue1](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

See Also

[ISensor Interface](#)
[ISensor Members](#)
[ISensor::SensorAlertValue2 Property](#)
[ISensor::SensorAlertEnabled Property](#)
[ISensor::SensorAlertState Property](#)
[ISensor::SensorAlertType Property](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

SensorAlertValue2 Property (ISensor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : SensorAlertValue2 Property (ISensor)

Gets or sets alert value for this sensor; only in effect when [sensor alert type](#) set to swSensorAlert_Between.

.NET Syntax

Visual Basic (Declaration)

```
Property SensorAlertValue2 As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISensor  
Dim value As System.Double  
  
instance.SensorAlertValue2 = value  
value = instance.SensorAlertValue2
```

C#

```
System.double SensorAlertValue2 {get; set;}
```

C++/CLI

```
property System.double SensorAlertValue2 {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Alert value

Visual Basic for Applications (VBA) Syntax

See [Sensor::SensorAlertValue2](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

See Also

[ISensor Interface](#)
[ISensor Members](#)
[ISensor::SensorAlertValue1 Property](#)
[ISensor::SensorAlertState Property](#)
[ISensor::SensorAlertEnabled Property](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

SensorType Property (ISensor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : SensorType Property (ISensor)

Gets the type of this sensor.

.NET Syntax

Visual Basic (Declaration)

```
Property SensorType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISensor
Dim value As System.Integer

instance.SensorType = value

value = instance.SensorType
```

C#

```
System.int SensorType {get; set;}
```

C++/CLI

```
property System.int SensorType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of sensor as defined in [swSensorType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Sensor::SensorType](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

Requirements

As of SOLIDWORKS 2009 SP02, only measurement (dimension) sensors of type swSensorType_e.swSensorDimension are supported.

See Also

[ISensor Interface](#)
[ISensor Members](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdateSensor Method (ISensor)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISensor Interface](#) : UpdateSensor Method (ISensor)

Updates the sensor.

.NET Syntax

Visual Basic (Declaration)

Function UpdateSensor() As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISensor  
Dim value As System.Boolean  
  
value = instance.UpdateSensor()
```

C#

```
System.bool UpdateSensor()
```

C++/CLI

```
System.bool UpdateSensor();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the sensor is updated, false if not

Visual Basic for Applications (VBA) Syntax

See [Sensor::UpdateSensor](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

See Also

[ISensor Interface](#)
[ISensor Members](#)
[ISensor::SensorType Property](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2