

SOLIDWORKS API (.NET VBA C#) — Reference (258/337): ISimpleFilletFeatureData2 (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

ISimpleFilletFeatureData2 (part 2 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetHoldLines Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ISetHoldLines Method (ISimpleFilletFeatureData2)

Sets the hold lines (boundaries) for this face blend fillet feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetHoldLines( _  
    ByVal Count As System.Integer, _  
    ByRef PList As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim PList As System.Object  
  
instance.ISetHoldLines(Count, PList)
```

C#

```
void ISetHoldLines(  
    System.int Count,  
    ref System.object PList  
)
```

C++/CLI

```
void ISetHoldLines(  
& System.int Count,  
& System.Object^% PList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of hold lines

PList

- in-process, unmanaged C++: Pointer to an array of hold lines of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

This method corresponds to the **Hold lines** selection box available when creating face-blend fillets. See the SOLIDWORKS Help for more information about face-blend fillets and hold lines.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetHoldLineCount Method](#)
[ISimpleFilletFeatureData2::GetHoldLines Method](#)
[ISimpleFilletFeatureData2::HoldLines Property](#)
[ISimpleFilletFeatureData2::CurvatureContinuous Property](#)
[ISimpleFilletFeatureData2::HelpPoint Property](#)

Availability

ISetLoops Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ISetLoops Method (ISimpleFilletFeatureData2)

Sets the loops on which to put a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetLoops( _
    ByVal Count As System.Integer, _
    ByRef LoopList As Loop2 _
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim Count As System.Integer
Dim LoopList As Loop2

instance.ISetLoops(Count, LoopList)
```

C#

```
void ISetLoops(
    System.int Count,
    ref Loop2 LoopList
)
```

C++/CLI

```
void ISetLoops(
    & System.int Count,
    & Loop2^% LoopList
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of loops

LoopList

- in-process, unmanaged C++: Pointer to an array of [loops](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetLoopCount Method](#)
[ISimpleFilletFeatureData2::ISetLoops Method](#)
[ISimpleFilletFeatureData2::Loops Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

ISetRadius Method (ISimpleFilletFeatureData2)

[See Also](#)



Sets the radius value for specified fillet item.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetRadius( _
    ByVal PFilletItem As System.Object, _
    ByVal Radius As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim PFilletItem As System.Object
Dim Radius As System.Double

instance.ISetRadius(PFilletItem, Radius)
```

C#

```
void ISetRadius(
    System.object PFilletItem,
    System.double Radius
)
```

C++/CLI

```
void ISetRadius(
    & System.Object^ PFilletItem,
    & System.double Radius
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem
Fillet item whose radius you want
Radius
Radius value

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::ISetRadius](#).

Remarks

To obtain a pointer to a fillet item, see [ISimpleFilletFeatureData2::GetFilletItemAtIndex](#) and [ISimpleFilletFeatureData2::FilletItemsCount](#). Fillets can be made from multiple edges or faces and these methods get a pointer to any of the entities that helped to create the particular fillet and pass it into the PFilletItem parameter of this method.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetRadius Method](#)
[ISimpleFilletFeatureData2::IGetRadius Method](#)
[ISimpleFilletFeatureData2::SetRadius Method](#)
[ISimpleFilletFeatureData2::DefaultRadius Property](#)
[ISimpleFilletFeatureData2::IsMultipleRadius Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Sets the setback distance for the specified vertex and its edges on this simple fillet feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ISetSetbackVertexDistance( _  
    ByVal Count As System.Integer, _  
    ByVal Vtx As Vertex, _  
    ByRef EdgeArr As Edge, _  
    ByRef DistArr As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim Vtx As Vertex  
Dim EdgeArr As Edge  
Dim DistArr As System.Double  
Dim value As System.Boolean  
  
value = instance.ISetSetbackVertexDistance(Count, Vtx, EdgeArr, DistArr)
```

C#

```
System.bool ISetSetbackVertexDistance(  
    System.int Count,  
    Vertex Vtx,  
    ref Edge EdgeArr,  
    ref System.double DistArr  
)
```

C++/CLI

```
System.bool ISetSetbackVertexDistance(  
& System.int Count,  
& Vertex^ Vtx,  
& Edge^% EdgeArr,  
& System.double% DistArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of setback distances

Vtx

[Vertex](#) for which to set setback distance

EdgeArr

- in-process, unmanaged C++: Pointer to an array of [edges](#) for this vertex
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

DistArr

- in-process, unmanaged C++: Pointer to an array of distances
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Return Value

True if the setback distance is set, false if not

Remarks

There is a one-to-one correspondence between the edge array and the distance array.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackDistanceCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::GetSetbackVerticesCount Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSetbackVertices Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ISetSetbackVertices Method (ISimpleFilletFeatureData2)

Sets the setback vertices for this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetSetbackVertices( _  
    ByVal Count As System.Integer, _  
    ByRef VertArr As Vertex _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim VertArr As Vertex  
Dim value As System.Boolean  
  
value = instance.ISetSetbackVertices(Count, VertArr)
```

C#

```
System.bool ISetSetbackVertices(  
    System.int Count,  
    ref Vertex VertArr  
)
```

C++/CLI

```
System.bool ISetSetbackVertices(  
& System.int Count,  
& Vertex^% VertArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of vertices

VertArr

- in-process, unmanaged C++: Pointer to an array of setback [vertices](#)

VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if all edges of the vertex are filleted, false if not

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackDistanceCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)

[ISimpleFilletFeatureData2::GetSetbackVerticesCount Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsMultipleRadius Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IsMultipleRadius Property (ISimpleFilletFeatureData2)

Gets or sets whether this symmetric fillet or chamfer feature is a multiple radius fillet.

.NET Syntax

Visual Basic (Declaration)

Property IsMultipleRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Boolean
```

```
instance.IsMultipleRadius = value
```

```
value = instance.IsMultipleRadius
```

C#

```
System.bool IsMultipleRadius {get; set;}
```

C++/CLI

```
property System.bool IsMultipleRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this symmetric fillet/chamfer feature has multiple radii, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::IsMultipleRadius](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

Remarks

This property is valid only for symmetric constant radius fillets and symmetric offset face chamfers.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetRadius Method](#)
[ISimpleFilletFeatureData2::IGetRadius Method](#)
[ISimpleFilletFeatureData2::ISetRadius Method](#)
[ISimpleFilletFeatureData2::SetRadius Method](#)
[ISimpleFilletFeatureData2::DefaultRadius Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepFeatures Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : KeepFeatures Property (ISimpleFilletFeatureData2)

Gets or sets whether to keep existing features on the entities selected for the fillet.

.NET Syntax

Visual Basic (Declaration)

Property KeepFeatures As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Boolean
```

```
instance.KeepFeatures = value
```

```
value = instance.KeepFeatures
```

C#

```
System.bool KeepFeatures {get; set;}
```

C++/CLI

```
property System.bool KeepFeatures {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True keeps the existing features, false does not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::KeepFeatures](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Loops Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : Loops Property (ISimpleFilletFeatureData2)

Gets or sets the loops on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

Property Loops As System.Object

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Object

instance.Loops = value

value = instance.Loops
```

C#

```
System.object Loops {get; set;}
```

C++/CLI

```
property System.Object^ Loops {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Loops](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::Loops](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetLoopCount Method](#)
[ISimpleFilletFeatureData2::IGetLoops Method](#)
[ISimpleFilletFeatureData2::ISetLoops Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

OmitAttachedEdges Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : OmitAttachedEdges Property (ISimpleFilletFeatureData2)

Gets whether the simple fillet feature is not applied to the attachment edges of the feature.

.NET Syntax

Visual Basic (Declaration)

Property OmitAttachedEdges As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Boolean

instance.OmitAttachedEdges = value

value = instance.OmitAttachedEdges
```

C#

```
System.bool OmitAttachedEdges {get; set;}
```

C++/CLI

```
property System.bool OmitAttachedEdges {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if fillet is not applied to the attachment edges, false if it is

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::OmitAttachedEdges](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverflowType Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : OverflowType Property (ISimpleFilletFeatureData2)

Gets or sets the overflow type of the simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OverflowType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Integer

instance.OverflowType = value

value = instance.OverflowType
```

C#

```
System.int OverflowType {get; set;}
```

C++/CLI

```
property System.int OverflowType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Overflow type as defined in [swFilletOverFlowType](#) e

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::OverflowType](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateFeatureToParts Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : PropagateFeatureToParts Property (ISimpleFilletFeatureData2)

Gets or sets whether to extend the assembly simple fillet feature to all affected parts.

.NET Syntax

Visual Basic (Declaration)

```
Property PropagateFeatureToParts As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Boolean
```

```
instance.PropagateFeatureToParts = value
```

```
value = instance.PropagateFeatureToParts
```

C#

```
System.bool PropagateFeatureToParts {get; set;}
```

C++/CLI

```
property System.bool PropagateFeatureToParts {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to extend the assembly simple fillet feature to all affected parts, false to not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::PropagateFeatureToParts](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::AutoSelect Property](#)
[ISimpleFilletFeatureData2::AutoSelectComponents Property](#)
[ISimpleFilletFeatureData2::AssemblyFeatureScope Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateToTangentFaces Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : PropagateToTangentFaces Property (ISimpleFilletFeatureData2)

Gets or sets whether to extend fillet to all faces tangent to the selected face or edge.

.NET Syntax

Visual Basic (Declaration)

Property PropagateToTangentFaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Boolean
```

```
instance.PropagateToTangentFaces = value
```

```
value = instance.PropagateToTangentFaces
```

C#

```
System.bool PropagateToTangentFaces {get; set;}
```

C++/CLI

```
property System.bool PropagateToTangentFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if simple fillet feature should extend fillet to all faces tangent to the selected face or edge, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::PropagateToTangentFaces](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ReleaseSelectionAccess Method (ISimpleFilletFeatureData2)

Releases access to the selections used to define the simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::ReleaseSelectionAccess](#).

Remarks

[ISimpleFilletFeatureData2::AccessSelections](#) and [ISimpleFilletFeatureData2::!AccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the feature.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RepairMissingReferences Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : RepairMissingReferences Method (ISimpleFilletFeatureData2)

Finds missing references in this fillet/chamfer and reassigns them to new edges.

.NET Syntax

Visual Basic (Declaration)

```
Sub RepairMissingReferences()
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
instance.RepairMissingReferences()
```

C#

```
void RepairMissingReferences()
```

C++/CLI

```
void RepairMissingReferences();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::RepairMissingReferences](#).

Remarks

If you delete a feature that this fillet or chamfer is referencing and then create a similar feature with the same geometry, the references do not reattach. The missing references appear in the **Items To Fillet** list box of the Fillet PropertyManager, but finding the valid edges to reattach is difficult. Call this method to find all missing references and reassign them to new edges.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseFaceNormal Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ReverseFaceNormal Property (ISimpleFilletFeatureData2)

Gets or sets the **Reverse Face Normal** option when creating a face fillet between surface bodies.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseFaceNormal( _  
    ByVal WhichFaceList As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim WhichFaceList As System.Integer  
Dim value As System.Boolean  
  
instance.ReverseFaceNormal(WhichFaceList) = value  
  
value = instance.ReverseFaceNormal(WhichFaceList)
```

C#

```
System.bool ReverseFaceNormal(  
    System.int WhichFaceList  
) {get; set;}
```

C++/CLI

```
property System.bool ReverseFaceNormal {  
    System.bool get(System.int WhichFaceList);  
    void set (System.int WhichFaceList, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichFaceList
Face for **Reverse Face Normal** option as defined in [swSimpleFilletWhichFaces_e](#)

Property Value

True if the **Reverse Face Normal** option is enabled, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::ReverseFaceNormal](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RoundCorners Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : RoundCorners Property (ISimpleFilletFeatureData2)

Gets or sets whether to round the corners of this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Property RoundCorners As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Boolean
```

```
instance.RoundCorners = value
```

```
value = instance.RoundCorners
```

C#

```
System.bool RoundCorners {get; set;}
```

C++/CLI

```
property System.bool RoundCorners {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if simple fillet feature has round corners, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::RoundCorners](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

Remarks

This property is valid only if [ISimpleFilletFeatureData2::CurvatureContinuous](#) is false, and at least two adjacent edges to fillet are selected.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetConicRhoOrRadius Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : SetConicRhoOrRadius Method (ISimpleFilletFeatureData2)

Sets the conic rho or radius of this fillet/chamfer.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetConicRhoOrRadius( _  
    ByVal PFilletItem As System.Object, _  
    ByVal ConicRhoVal As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim ConicRhoVal As System.Double  
  
instance.SetConicRhoOrRadius(PFilletItem, ConicRhoVal)
```

C#

```
void SetConicRhoOrRadius(  
    System.object PFilletItem,  
    System.double ConicRhoVal  
)
```

C++/CLI

```
void SetConicRhoOrRadius(  
& System.Object^ PFilletItem,  
& System.double ConicRhoVal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Fillet item for which to set ConicRhoVal (see **Remarks**)

ConicRhoVal

Conic rho or radius (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::SetConicRhoOrRadius](#).

Remarks

Before calling this method, call [ISimpleFilletFeatureData2::GetFilletItemAtIndex](#) to get the pointer with which to specify PFilletItem.

The value specified in ConicRhoVal must match the [ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting.

If setting the conic rho value, it must be in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)

[ISimpleFilletFeatureData2 Members](#)

[ISimpleFilletFeatureData2::ISetConicRhoOrRadius Method \(\)](#)

[ISimpleFilletFeatureData2::GetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDistance Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : SetDistance Method (ISimpleFilletFeatureData2)

Sets the Distance 2 radius at the specified item of this asymmetric fillet/chamfer.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDistance( _  
    ByVal PFilletItem As System.Object, _  
    ByVal Dist2 As System.Double _  
)
```

Visual Basic (Usage)

```
Dim instance As ISimpleFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim Dist2 As System.Double  
  
instance.SetDistance(PFilletItem, Dist2)
```

C#

```
void SetDistance(  
    System.object PFilletItem,  
    System.double Dist2  
)
```

C++/CLI

```
void SetDistance(  
& System.Object^ PFilletItem,
```



```
& System.double Dist2
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Item at which to set the Distance 2 radius

Dist2

Distance 2 radius of the asymmetric fillet/chamfer at PFilletItem

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::SetDistance](#).

Remarks

Call [ISimpleFilletFeatureData2::SetRadius](#) to set the Distance 1 radius.

See Also

[ISimpleFilletFeatureData2 Interface](#)

[ISimpleFilletFeatureData2 Members](#)

[ISimpleFilletFeatureData2::GetDistance Method \(\)](#)

[ISimpleFilletFeatureData2::AsymmetricFillet Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFaces Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : SetFaces Method (ISimpleFilletFeatureData2)

Sets the faces on which to create a simple fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFaces( _
    ByVal WhichFaceList As System.Integer, _
    ByVal FaceList As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim WhichFaceList As System.Integer
Dim FaceList As System.Object

instance.SetFaces(WhichFaceList, FaceList)
```

C#

```
void SetFaces(
    System.int WhichFaceList,
    System.object FaceList
)
```

C++/CLI

```
void SetFaces(
    & System.int WhichFaceList,
    & System.Object^ FaceList
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichFaceList

Face as defined in [swSimpleFilletWhichFaces_e](#)

FaceList

Array of [faces](#) of size Count

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::SetFaces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetFaceCount Method](#)
[ISimpleFilletFeatureData2::GetFaces Method](#)
[ISimpleFilletFeatureData2::IGetFaces Method](#)
[ISimpleFilletFeatureData2::ISetFaces Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPartialEdgeFilletData Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : SetPartialEdgeFilletData Method (ISimpleFilletFeatureData2)

Sets the partial edge fillet data for the specified edge.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPartialEdgeFilletData( _  
    ByVal FilletItem As System.Object, _  
    ByVal PartialEdgeFilletData As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim FilletItem As System.Object  
Dim PartialEdgeFilletData As System.Object  
Dim value As System.Boolean  
  
value = instance.SetPartialEdgeFilletData(FilletItem, PartialEdgeFilletData)
```

C#

```
System.bool SetPartialEdgeFilletData(  
    System.object FilletItem,  
    System.object PartialEdgeFilletData  
)
```

C++/CLI

```
System.bool SetPartialEdgeFilletData(  
& System.Object^ FilletItem,  
& System.Object^ PartialEdgeFilletData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilletItem

[IEdge](#)

PartialEdgeFilletData

[IPartialEdgeFilletData](#); null to remove existing partial edge fillet data from FilletItem

Return Value

True if partial edge fillet data successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::SetPartialEdgeFilletData](#).

Remarks

This method is valid only if [ISimpleFilletFeatureData2::EnablePartialEdgeParameters](#) is true.

See Also

[ISimpleFilletFeatureData2 Interface](#)

[ISimpleFilletFeatureData2 Members](#)

[ISimpleFilletFeatureData2::GetPartialEdgeFilletData Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRadius Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : SetRadius Method (ISimpleFilletFeatureData2)

Sets the radius at the specified fillet item.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetRadius( _  
    ByVal PFilletItem As System.Object, _  
    ByVal Radius As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim Radius As System.Double  
  
instance.SetRadius(PFilletItem, Radius)
```

C#

```
void SetRadius(  
    System.object PFilletItem,  
    System.double Radius  
)
```

C++/CLI

```
void SetRadius(  
& System.Object^ PFilletItem,  
& System.double Radius  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem
Fillet item at which to set the radius
Radius
Radius of the symmetric fillet at PFilletItem; Distance 1 radius of the asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::SetRadius](#).

Remarks

Before calling this method, call [ISimpleFilletFeatureData2::GetFilletItemAtIndex](#) to get the pointer with which to specify PFilletItem.

Call [ISimpleFilletFeatureData2::SetDistance](#) to set the Distance 2 radius at PFilletItem of the asymmetric fillet.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetRadius Method](#)
[ISimpleFilletFeatureData2::GetRadius Method](#)
[ISimpleFilletFeatureData2::ISetRadius Method](#)
[ISimpleFilletFeatureData2::DefaultRadius Property](#)
[ISimpleFilletFeatureData2::IsMultipleRadius Property](#)
[ISimpleFilletFeatureData2::AsymmetricFillet Property\(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSetbackVertexDistance Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : SetSetbackVertexDistance Method (ISimpleFilletFeatureData2)

Sets the setback distances on fillet edges from the specified fillet corner vertex on this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSetbackVertexDistance( _  
    ByVal Vtx As System.Object, _  
    ByVal EdgeVar As System.Object, _  
    ByVal DistVar As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Vtx As System.Object  
Dim EdgeVar As System.Object  
Dim DistVar As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetSetbackVertexDistance(Vtx, EdgeVar, DistVar)
```

C#

```
System.bool SetSetbackVertexDistance(  
    System.object Vtx,  
    System.object EdgeVar,  
    System.object DistVar  
)
```

C++/CLI

```
System.bool SetSetbackVertexDistance(  
& System.Object^ Vtx,  
& System.Object^ EdgeVar,
```

```
& System.Object^ DistVar
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Vtx
[Vertex](#) for which to set setback distance
EdgeVar
Array of [edges](#) for this vertex
DistVar
Array of distances

Return Value

True if the setback distances are set, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::SetSetbackVertexDistance](#).

Remarks

There is a one-to-one correspondence between the members of the EdgeVar and DistVar arrays.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackDistanceCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::GetSetbackVerticesCount Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSetbackVertices Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : SetSetbackVertices Method (ISimpleFilletFeatureData2)

Sets the setback vertices for this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSetbackVertices( _  
    ByVal VertVar As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim VertVar As System.Object  
Dim value As System.Boolean  
  
value = instance.SetSetbackVertices(VertVar)
```

C#

```
System.bool SetSetbackVertices(  
    System.object VertVar  
)
```

C++/CLI

```
System.bool SetSetbackVertices(  
& System.Object^ VertVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertVar
Array of setback [vertices](#)

Return Value

True if setback vertices are set, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::SetSetbackVertices](#).

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackDistanceCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::GetSetbackVerticesCount Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TrimAndAttachSurfaces Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : TrimAndAttachSurfaces Property (ISimpleFilletFeatureData2)

Gets or sets the **Trim surfaces** option for surface face fillets.

.NET Syntax

Visual Basic (Declaration)

```
Property TrimAndAttachSurfaces As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Integer  
  
instance.TrimAndAttachSurfaces = value  
value = instance.TrimAndAttachSurfaces
```

C#

```
System.int TrimAndAttachSurfaces {get; set;}
```

C++/CLI

```
property System.int TrimAndAttachSurfaces {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 0 = Trim and attach (trims the filleted face and knits the surfaces into one surface body)

- 1 = Don't trim or attach (adds a new fillet surface, but does not trim the faces or knit the surfaces)
- -1 = Not applicable

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::TrimAndAttachSurfaces](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : Type Property (ISimpleFilletFeatureData2)

Gets the type of simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Integer
```

```
value = instance.Type
```

C#

```
System.int Type {get;}
```

C++/CLI

```
property System.int Type {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of simple fillet feature as defined in [swSimpleFilletType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::Type](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

