

SOLIDWORKS API (.NET VBA C#) — Reference (274/337): ISketchParabola-ISketchPath

SOLIDWORKS API Documentation (converted from CHM)

ISketchParabola (Type)

ISketchParabola Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchParabola Interface

Provides access to sketched parabolas.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchParabola
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola
```

C#

```
public interface ISketchParabola
```

C++/CLI

```
public interface class ISketchParabola
```

Visual Basic for Applications (VBA) Syntax

See [SketchParabola](#).

Example

[Create Parabola \(VBA\)](#)
[Create Parabola \(VB.NET\)](#)
[Create Parabola \(C#\)](#)

Accessors

[ISketchManager::CreateParabola](#)

Access Diagram

[SketchParabola](#)

See Also

[ISketchParabola Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISketchParabola Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchParabola Interface

For a list of all members of this type, see [ISketchParabola members](#).

Public Methods

Name	Description
GetApexPoint	Obsolete. Superseded by ISketchParabola::GetApexPoint2 and ISketchParabola::IGetApexPoint2 .
GetApexPoint2	Gets the sketch point for the apex point of the parabola.
GetEndPoint	Obsolete. Superseded by ISketchParabola::GetEndPoint2 and ISketchParabola::IGetEndPoint2 .

		
	GetEndPoint	Gets the sketch point for the end point of the parabola.
	GetFocalPoint	Obsolete. Superseded by ISketchParabola::GetFocalPoint2 and ISketchParabola::IGetFocalPoint2
	GetFocalPoint2	Gets the sketch point for the focal point of the parabola.
	GetStartPoint	Obsolete. Superseded by ISketchParabola::GetStartPoint2 and ISketchParabola::IGetStartPoint2
	GetStartPoint2	Gets the sketch point for the start point of the parabola.
	IGetApexPoint	Obsolete. Superseded by ISketchParabola::GetApexPoint2 and ISketchParabola::IGetApexPoint2
	IGetApexPoint2	Gets the sketch point for the apex point of the parabola.
	IGetEndPoint	Obsolete. Superseded by ISketchParabola::GetEndPoint2 and ISketchParabola::IGetEndPoint2
	IGetEndPoint2	Gets the sketch point for the end point of the parabola.
	IGetFocalPoint	Obsolete. Superseded by ISketchParabola::GetFocalPoint2 and ISketchParabola::IGetFocalPoint2
	IGetFocalPoint2	Gets the sketch point for the focal point of the parabola.
	IGetStartPoint	Obsolete. Superseded by ISketchParabola::GetStartPoint2 and ISketchParabola::IGetStartPoint2
	IGetStartPoint2	Gets the sketch point for the start point of the parabola.
	SetPoints	Sets all four sketch points for a parabola.

[Top](#)

See Also

[ISketchParabola Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchParabola Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : [ISketchParabola Interface](#)

The following tables list the members exposed by [ISketchParabola](#).

Public Methods

Name	Description
	Obsolete. Superseded by ISketchParabola::GetApexPoint2 and ISketchParabola::IGetApexPoint2
	GetApexPoint2
	Gets the sketch point for the apex point of the parabola.
	Obsolete. Superseded by ISketchParabola::GetEndPoint2 and ISketchParabola::IGetEndPoint2
	GetEndPoint2
	Gets the sketch point for the end point of the parabola.
	Obsolete. Superseded by ISketchParabola::GetFocalPoint2 and ISketchParabola::IGetFocalPoint2
	GetFocalPoint2
	Gets the sketch point for the focal point of the parabola.
	Obsolete. Superseded by ISketchParabola::GetStartPoint2 and ISketchParabola::IGetStartPoint2
	GetStartPoint2
	Gets the sketch point for the start point of the parabola.
	Obsolete. Superseded by ISketchParabola::GetApexPoint2 and ISketchParabola::IGetApexPoint2
	IGetApexPoint2
	Gets the sketch point for the apex point of the parabola.
	Obsolete. Superseded by ISketchParabola::GetEndPoint2 and ISketchParabola::IGetEndPoint2
	IGetEndPoint2
	Gets the sketch point for the end point of the parabola.
	Obsolete. Superseded by ISketchParabola::GetFocalPoint2 and ISketchParabola::IGetFocalPoint2
	IGetFocalPoint2
	Gets the sketch point for the focal point of the parabola.
	Obsolete. Superseded by ISketchParabola::GetStartPoint2 and ISketchParabola::IGetStartPoint2
	IGetStartPoint2
	Gets the sketch point for the start point of the parabola.



Sets all four sketch points for a parabola.

[Top](#)

See Also

[ISketchParabola Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetApexPoint Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : GetApexPoint Method (ISketchParabola)

Obsolete. Superseded by [ISketchParabola::GetApexPoint2](#) and [ISketchParabola::IGetApexPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetApexPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As System.Object  
  
value = instance.GetApexPoint()
```

C#

```
System.object GetApexPoint()
```

C++/CLI

```
System.Object^ GetApexPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::GetApexPoint](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetApexPoint2 Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : GetApexPoint2 Method (ISketchParabola)

Gets the sketch point for the apex point of the parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function GetApexPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola
Dim value As System.Object

value = instance.GetApexPoint2()
```

C#

```
System.Object GetApexPoint2()
```

C++/CLI

```
System.Object^ GetApexPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Apex [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::GetApexPoint2](#).

Example

See the [ISketchParabola](#) examples.

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)
[ISketchParabola::IGetApexPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEndPoint Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : GetEndPoint Method (ISketchParabola)

Obsolete. Superseded by [ISketchParabola::GetEndPoint2](#) and [ISketchParabola::IGetEndPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola
Dim value As System.Object

value = instance.GetEndPoint()
```

C#

```
System.Object GetEndPoint()
```

C++/CLI

```
System.Object^ GetEndPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::GetEndPoint](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEndPoint2 Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : GetEndPoint2 Method (ISketchParabola)

Gets the sketch point for the end point of the parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As System.Object  
  
value = instance.GetEndPoint2()
```

C#

```
System.object GetEndPoint2()
```

C++/CLI

```
System.Object^ GetEndPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

End [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::GetEndPoint2](#).

Example

See the [ISketchParabola](#) examples.

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)
[ISketchParabola::IGetEndPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFocalPoint Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : GetFocalPoint Method (ISketchParabola)

Obsolete. Superseded by [ISketchParabola::GetFocalPoint2](#) and [ISketchParabola::IGetFocalPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFocalPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As System.Object  
  
value = instance.GetFocalPoint()
```

C#

```
System.object GetFocalPoint()
```

C++/CLI

```
System.Object^ GetFocalPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::GetFocalPoint](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFocalPoint2 Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : GetFocalPoint2 Method (ISketchParabola)

Gets the sketch point for the focal point of the parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFocalPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As System.Object  
  
value = instance.GetFocalPoint2()
```

C#

```
System.object GetFocalPoint2()
```

C++/CLI

```
System.Object^ GetFocalPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Focal [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::GetFocalPoint2](#).

Example

See the [ISketchParabola](#) examples.

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)
[ISketchParabola::IGetFocalPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetStartPoint Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : GetStartPoint Method (ISketchParabola)

Obsolete. Superseded by [ISketchParabola::GetStartPoint2](#) and [ISketchParabola::IGetStartPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetStartPoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As System.Object
```

```
value = instance.GetStartPoint()
```

C#

```
System.Object GetStartPoint()
```

C++/CLI

```
System.Object^ GetStartPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::GetStartPoint](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetStartPoint2 Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : GetStartPoint2 Method (ISketchParabola)

Gets the sketch point for the start point of the parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStartPoint2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola
Dim value As System.Object

value = instance.GetStartPoint2()
```

C#

```
System.object GetStartPoint2()
```

C++/CLI

```
System.Object^ GetStartPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Start [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::GetStartPoint2](#).

Example

See the [ISketchParabola](#) examples.

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)
[ISketchParabola::IGetStartPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetApexPoint Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : IGetApexPoint Method (ISketchParabola)

Obsolete. Superseded by [ISketchParabola::GetApexPoint2](#) and [ISketchParabola::IGetApexPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetApexPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola
Dim value As System.Double

value = instance.IGetApexPoint()
```

C#

```
System.double IGetApexPoint()
```

C++/CLI

```
System.double IGetApexPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::IGetApexPoint](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetApexPoint2 Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : IGetApexPoint2 Method (ISketchParabola)

Gets the sketch point for the apex point of the parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetApexPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As SketchPoint  
  
value = instance.IGetApexPoint2()
```

C#

```
SketchPoint IGetApexPoint2()
```

C++/CLI

```
SketchPoint^ IGetApexPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Apex [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::IGetApexPoint2](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)
[ISketchParabola::GetApexPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEndPoint Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : IGetEndPoint Method (ISketchParabola)

Obsolete. Superseded by [ISketchParabola::GetEndPoint2](#) and [ISketchParabola::IGetEndPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEndPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As System.Double  
  
value = instance.IGetEndPoint()
```

C#

```
System.double IGetEndPoint()
```

C++/CLI

```
System.double IGetEndPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchParabola.IGetEndPoint](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEndPoint2 Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : IGetEndPoint2 Method (ISketchParabola)

Gets the sketch point for the end point of the parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEndPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As SketchPoint  
  
value = instance.IGetEndPoint2()
```

C#

```
SketchPoint IGetEndPoint2()
```

C++/CLI

```
SketchPoint^ IGetEndPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

End [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::IGetEndPoint2](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)
[ISketchParabola::GetEndPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFocalPoint Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : IGetFocalPoint Method (ISketchParabola)

Obsolete. Superseded by [ISketchParabola::GetFocalPoint2](#) and [ISketchParabola::IGetFocalPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFocalPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As System.Double  
  
value = instance.IGetFocalPoint()
```

C#

```
System.double IGetFocalPoint()
```

C++/CLI

```
System.double IGetFocalPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::IGetFocalPoint](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFocalPoint2 Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : IGetFocalPoint2 Method (ISketchParabola)

Gets the sketch point for the focal point of the parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFocalPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola
Dim value As SketchPoint

value = instance.IGetFocalPoint2()
```

C#

```
SketchPoint IGetFocalPoint2()
```

C++/CLI

```
SketchPoint^ IGetFocalPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Focal [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::IGetFocalPoint2](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)
[ISketchParabola::IGetFocalPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetStartPoint Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : IGetStartPoint Method (ISketchParabola)

Obsolete. Superseded by [ISketchParabola::IGetStartPoint2](#) and [ISketchParabola::IGetStartPoint2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetStartPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola
Dim value As System.Double

value = instance.IGetStartPoint()
```

C#

```
System.double IGetStartPoint()
```

C++/CLI

```
System.double IGetStartPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::IGetStartPoint](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetStartPoint2 Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : IGetStartPoint2 Method (ISketchParabola)

Gets the sketch point for the start point of the parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetStartPoint2() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchParabola  
Dim value As SketchPoint  
  
value = instance.IGetStartPoint2()
```

C#

```
SketchPoint IGetStartPoint2()
```

C++/CLI

```
SketchPoint^ IGetStartPoint2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Start [sketch point](#) or null if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::IGetStartPoint2](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)
[ISketchParabola::GetStartPoint2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPoints Method (ISketchParabola)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchParabola Interface](#) : SetPoints Method (ISketchParabola)

Sets all four sketch points for a parabola.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPoints(  
    ByVal CenterX As System.Double, _  
    ByVal CenterY As System.Double, _  
    ByVal CenterZ As System.Double, _
```

```

    ByVal ApexX As System.Double, _
    ByVal ApexY As System.Double, _
    ByVal ApexZ As System.Double, _
    ByVal StartX As System.Double, _
    ByVal StartY As System.Double, _
    ByVal StartZ As System.Double, _
    ByVal EndX As System.Double, _
    ByVal EndY As System.Double, _
    ByVal EndZ As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As ISketchParabola
Dim CenterX As System.Double
Dim CenterY As System.Double
Dim CenterZ As System.Double
Dim ApexX As System.Double
Dim ApexY As System.Double
Dim ApexZ As System.Double
Dim StartX As System.Double
Dim StartY As System.Double
Dim StartZ As System.Double
Dim EndX As System.Double
Dim EndY As System.Double
Dim EndZ As System.Double
Dim value As System.Boolean

```

```

value = instance.SetPoints(CenterX, CenterY, CenterZ, ApexX, ApexY, ApexZ, StartX, StartY, StartZ,
EndX, EndY, EndZ)

```

C#

```

System.bool SetPoints(
    System.double CenterX,
    System.double CenterY,
    System.double CenterZ,
    System.double ApexX,
    System.double ApexY,
    System.double ApexZ,
    System.double StartX,
    System.double StartY,
    System.double StartZ,
    System.double EndX,
    System.double EndY,
    System.double EndZ
)

```

C++/CLI

```

System.bool SetPoints(
    & System.double CenterX,
    & System.double CenterY,
    & System.double CenterZ,
    & System.double ApexX,
    & System.double ApexY,
    & System.double ApexZ,
    & System.double StartX,
    & System.double StartY,
    & System.double StartZ,
    & System.double EndX,
    & System.double EndY,
    & System.double EndZ
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CenterX
x coordinate of center (focal) sketch point

CenterY

y coordinate of center (focal) sketch point
CenterZ
z coordinate of center (focal) sketch point
ApexX
x coordinate of apex sketch point
ApexY
y coordinate of apex sketch point
ApexZ
z coordinate of apex sketch point
StartX
x coordinate of start sketch point
StartY
y coordinate of start sketch point
StartZ
z coordinate of start sketch point
EndX
x coordinate of end sketch point
EndY
y coordinate of end sketch point
EndZ
z coordinate of end sketch point

Return Value

True if all four sketch points are set, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchParabola::SetPoints](#).

See Also

[ISketchParabola Interface](#)
[ISketchParabola Members](#)

Availability

SOLIDWORKS 2007 SP5, Revision Number 15.5

ISketchPath (Type)

ISketchPath Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPath Interface

Provides access to the methods and properties for paths in sketches.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchPath
```

Visual Basic (Usage)  [Copy Code](#)

```
Dim instance As ISketchPath
```

C#

```
public interface ISketchPath
```

C++/CLI

```
public interface class ISketchPath
```

Visual Basic for Applications (VBA) Syntax

See [SketchPath](#).

Example

[Create Sketch Path \(VBA\)](#)
[Create Sketch Path \(VB.NET\)](#)
[Create Sketch Path \(C#\)](#)

Accessors

[ISketch::GetSketchPaths](#) and [ISketch::IGetSketchPaths](#)
[ISketchSegment::GetSketchPaths](#) and [ISketchSegment::IGetSketchPaths](#)

Access Diagram

[SketchPath](#)

See Also

[ISketchPath Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISketchManager::MakeSketchBlockFromFile Method](#)

ISketchPath Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPath Interface

The following tables list the members exposed by [ISketchPath](#).

Public Methods

Name	Description
GetConstraints	Gets the names of the constraints in this sketch path.

	GetConstraintsCount	Gets the number of constraints in this sketch path.
	GetLength	Gets the length of the sketch path.
	GetRelations	Gets the sketch relations for this sketch path.
	GetRelationsCount	Gets the number of sketch relations in this sketch path.
	GetSketch	Gets the sketch where this sketch path exists.
	GetSketchSegmentCount	Gets the number of sketch segments in this sketch path.
	GetSketchSegments	Gets the sketch segments in this sketch path.
	IGetConstraints	Gets the names of the constraints in this sketch path.
	IGetRelations	Gets the sketch relations for this sketch path.
	IGetSketchSegments	Gets the sketch segments in this sketch path.
	Select	Selects a sketch path.

[Top](#)

 See Also

[ISketchPath Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISketchManager::MakeSketchBlockFromFile Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchPath Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchPath Interface

For a list of all members of this type, see [ISketchPath members](#).

 Public Methods

Name	Description
 GetConstraints	Gets the names of the constraints in this sketch path.
 GetConstraintsCount	Gets the number of constraints in this sketch path.
 GetLength	Gets the length of the sketch path.
 GetRelations	Gets the sketch relations for this sketch path.
 GetRelationsCount	Gets the number of sketch relations in this sketch path.
 GetSketch	Gets the sketch where this sketch path exists.
 GetSketchSegmentCount	Gets the number of sketch segments in this sketch path.
 GetSketchSegments	Gets the sketch segments in this sketch path.
 IGetConstraints	Gets the names of the constraints in this sketch path.
 IGetRelations	Gets the sketch relations for this sketch path.
 IGetSketchSegments	Gets the sketch segments in this sketch path.
 Select	Selects a sketch path.

[Top](#)

 See Also

[ISketchPath Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISketchManager::MakeSketchBlockFromFile Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConstraints Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : GetConstraints Method (ISketchPath)

Gets the names of the constraints in this sketch path.

 **.NET Syntax**

Visual Basic (Declaration)

Function GetConstraints() As System.Object

Visual Basic (Usage)  Copy Code

Dim instance As [ISketchPath](#)
Dim value As System.Object

value = instance.GetConstraints()

C#

System.object GetConstraints()

C++/CLI

System.Object^ GetConstraints();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the names of the sketch constraints

 **Visual Basic for Applications (VBA) Syntax**

See [SketchPath::GetConstraints](#).

 **Example**

See the [ISketchPath](#) examples.

 **See Also**

[ISketchPath Interface](#)
[ISketchPath Members](#)
[ISketchPath::GetConstraintsCount Method](#)
[ISketchPath::IGetConstraints Method](#)

 **Availability**

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help [Send comments on this topic.](#)

GetConstraintsCount Method (ISketchPath)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : GetConstraintsCount Method (ISketchPath)

Gets the number of constraints in this sketch path.

 **.NET Syntax**

Visual Basic (Declaration)

Function GetConstraintsCount() As System.Integer

Visual Basic (Usage)  Copy Code

Dim instance As [ISketchPath](#)
Dim value As System.Integer

value = instance.GetConstraintsCount()

C#

```
System.int GetConstraintsCount()
```

C++/CLI

```
System.int GetConstraintsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of constraints

Visual Basic for Applications (VBA) Syntax

See [SketchPath::GetConstraintsCount](#).

Example

See the [ISketchPath](#) examples.

Remarks

Call this method before calling [ISketchPath::IGetConstraints](#) to get the size of the array for that method.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)
[ISketchPath::GetConstraints Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLength Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : GetLength Method (ISketchPath)

Gets the length of the sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLength() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim value As System.Double  
  
value = instance.GetLength()
```

C#

```
System.double GetLength()
```

C++/CLI

```
System.double GetLength();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Length of the sketch path

Visual Basic for Applications (VBA) Syntax

See [SketchPath::GetLength](#).

Example

See the [ISketchPath](#) examples.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRelations Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : GetRelations Method (ISketchPath)

Gets the sketch relations for this sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRelations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim value As System.Object  
  
value = instance.GetRelations()
```

C#

```
System.object GetRelations()
```

C++/CLI

```
System.Object^ GetRelations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [sketch relations](#)

Visual Basic for Applications (VBA) Syntax

See [SketchPath::GetRelations](#).

Example

See the [ISketchPath](#) examples.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)
[ISketchPath::GetRelationsCount Method](#)
[ISketchPath::!GetRelations Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRelationsCount Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : GetRelationsCount Method (ISketchPath)

Gets the number of sketch relations in this sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRelationsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim value As System.Integer  
  
value = instance.GetRelationsCount()
```

C#

```
System.int GetRelationsCount()
```

C++/CLI

```
System.int GetRelationsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch relations

Visual Basic for Applications (VBA) Syntax

See [SketchPath::GetRelationsCount](#).

Example

See the [ISketchPath](#) examples.

Remarks

Call this method before calling [ISketchPath::IGetRelations](#) to get the size of the array for that method.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)
[ISketchPath::GetRelations Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketch Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : GetSketch Method (ISketchPath)

Gets the sketch where this sketch path exists.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketch() As Sketch
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim value As Sketch  
  
value = instance.GetSketch()
```

C#

```
Sketch GetSketch()
```

C++/CLI

```
Sketch^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [SketchPath::GetSketch](#).

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchSegmentCount Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : GetSketchSegmentCount Method (ISketchPath)

Gets the number of sketch segments in this sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchSegmentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim value As System.Integer  
  
value = instance.GetSketchSegmentCount()
```

C#

```
System.int GetSketchSegmentCount()
```

C++/CLI

```
System.int GetSketchSegmentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch segments

Visual Basic for Applications (VBA) Syntax

See [SketchPath::GetSketchSegmentCount](#).

Example

See the [ISketchPath](#) examples.

Remarks

Call this method before calling [ISketch::IGetSketchSegments](#) to get the size of the array for that method.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)
[SketchPath::GetSketchSegments Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchSegments Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : GetSketchSegments Method (ISketchPath)

Gets the sketch segments in this sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchSegments() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim value As System.Object  
  
value = instance.GetSketchSegments()
```

C#

```
System.object GetSketchSegments()
```

C++/CLI

```
System.Object^ GetSketchSegments();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [sketch segments](#)

Visual Basic for Applications (VBA) Syntax

See [SketchPath::GetSketchSegments](#).

Example

See the [ISketchPath](#) examples.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)
[ISketchPath::GetSketchSegmentCount Method](#)
[ISketchPath::IGetSketchSegments Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetConstraints Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : IGetConstraints Method (ISketchPath)

Gets the names of the constraints in this sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetConstraints( _  
    ByVal Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim Count As System.Integer  
Dim value As System.String  
  
value = instance.IGetConstraints(Count)
```

C#

```
System.string IGetConstraints(  
    System.int Count  
)
```

C++/CLI

```
System.String^ IGetConstraints(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of sketch constraints

Return Value

- in-process, unmanaged C++: Pointer to an array of sketch constraints
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ISketchPath::GetConstraintsCount](#) to get the value of count.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)
[ISketchPath::GetConstraints Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetRelations Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : IGetRelations Method (ISketchPath)

Gets the sketch relations for this sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRelations( _  
    ByVal Count As System.Integer _  
) As SketchRelation
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim Count As System.Integer  
Dim value As SketchRelation  
  
value = instance.IGetRelations(Count)
```

C#

```
SketchRelation IGetRelations(  
    System.int Count  
)
```

C++/CLI

```
SketchRelation^ IGetRelations(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of sketch relations

Return Value

- in-process, unmanaged C++: Pointer to an array of [sketch relations](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ISketchPath::GetRelationsCount](#) to get the value of Count.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)
[ISketchPath::GetRelations Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSketchSegments Method (ISketchPath)

[See Also](#)



Gets the sketch segments in this sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSketchSegments( _  
    ByVal Count As System.Integer _  
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim Count As System.Integer  
Dim value As SketchSegment  
  
value = instance.IGetSketchSegments(Count)
```

C#

```
SketchSegment IGetSketchSegments(  
    System.int Count  
)
```

C++/CLI

```
SketchSegment^ IGetSketchSegments(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of sketch segments

Return Value

- in-process, unmanaged C++: Pointer to an array of [sketch segments](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ISketchPath::GetSketchSegmentCount](#) to get the value of Count.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)
[ISketchPath::GetSketchSegments Method](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (ISketchPath)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchPath Interface](#) : Select Method (ISketchPath)

Selects a sketch path.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchPath  
Dim Append As System.Boolean  
Dim Data As SelectData  
Dim value As System.Boolean  
  
value = instance.Select(Append, Data)
```

C#

```
System.bool Select(  
    System.bool Append,  
    SelectData Data  
)
```

C++/CLI

```
System.bool Select(  
& System.bool Append,  
& SelectData^ Data  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append
True appends the entity to the selection list, false replaces the selection list with this entity
Data
[SelectData](#) object

Return Value

True if the selection is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchPath::Select](#).

Example

See the [ISketchPath](#) examples.

See Also

[ISketchPath Interface](#)
[ISketchPath Members](#)

Availability

SOLIDWORKS 2007 SP4, Revision Number 15.4