

SOLIDWORKS API (.NET VBA C#) — Reference

(278/337): ISketchSegment-ISketchSlot

SOLIDWORKS API Documentation (converted from CHM)

ISketchSegment (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchSegment Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchSegment Interface

Provides access to functions that are common among sketch entities.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchSegment
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment
```

C#

```
public interface ISketchSegment
```

C++/CLI

```
public interface class ISketchSegment
```

Visual Basic for Applications (VBA) Syntax

See [SketchSegment](#).

Example

[Get Sketch Segment Length \(C++\)](#)
[Get Sketch Segment Length \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)
[Select Chain of Entities Attached to a Sketch Segment \(C#\)](#)
[Select Chain of Entities Attached to a Sketch Segment \(VB.NET\)](#)
[Select Chain of Entities Attached to a Sketch Segment \(VBA\)](#)

Remarks

A SketchSegment can represent a sketch arc, line, ellipse, parabola or spline.

ISketchSegment provides functions that are generic to every type of sketch segment. For example, every sketch segment has an ID and can be programmatically selected. Therefore, the ISketchSegment interface provides functions to obtain the ID and to select the item. (For access to sketched points, see the [ISketchPoint](#) object)

Accessors

[IBrokenOutSectionFeatureData::SketchSegment](#) and [IBrokenOutSectionFeatureData::IGetSketchSegment](#)

[IDetailCircle::GetProfileItems](#) and [IDetailCircle::IGetProfileItems](#)

[IEnumSketchSegments::Next](#)

[ILayer::GetItems](#)

[IMirrorComponentFeatureData::AlignmentReferences](#)

[IModelDoc2::CreateArc2](#) and [IModelDoc2::ICreateArc2](#)

[IModelDoc2::CreateCircle2](#) and [IModelDoc2::ICreateCircle2](#)

[IModelDoc2::CreateCircleByRadius2](#) and [IModelDoc2::ICreateCircleByRadius2](#)

[IModelDoc2::CreateEllipse2](#) and [IModelDoc2::ICreateEllipse2](#)

[IModelDoc2::CreateEllipticalArc2](#) and [IModelDoc2::ICreateEllipticalArc2](#)

[IModelDoc2::CreateLine2](#) and [IModelDoc2::ICreateLine2](#)

[IModelDoc2::CreateSpline](#) and [IModelDoc2::ICreateSpline](#)
[IModelDoc2::CreateSplineByEqnParams](#) and [IModelDoc2::ICreateSplineByEqnParams](#)
[IOneBendFeatureData::FlatPatternSketchSegments](#) and [IOneBendFeatureData::IFlatPatternSketchSegments](#)
[IPrimaryMemberPathSegmentFeatureData::GetPathSegments](#)
[IPrimaryMemberPointLengthFeatureData::DirectionReference](#)
[IRevolveFeatureData2::Axis](#)
[ISketch::GetSketchSegments](#)
[ISketch::GetSketchTextSegments](#)
[ISketchContour::GetSketchSegments](#) and [ISketchContour::IGetSketchSegments](#)
[ISketchManager::CreateFillet](#)
[ISketchManager::CreateSpline3](#)
[ISketchManager::CreateSplinesByEqnParams2](#)
[ISketchPath::GetSketchSegments](#) and [ISketchPath::IGetSketchSegments](#)
[ISMGussetFeatureData::ReferenceLine](#)
[IStructuralMemberFeatureData::GetPathSegmentAt](#)
[IStructuralMemberFeatureData::GetSketchSegments](#)
[IStructuralMemberFeatureData::IGetPathSegments](#)
[IStructuralMemberFeatureData::PathSegments](#)
[IStructureSystemMemberProfile::ProfileAlignmentObject](#)
[IView::GetBendLines](#) and [IView::IGetBendLines](#)
[IWrapSketchFeatureData::PullDirection](#)

 Access Diagram

[SketchSegment](#)

 See Also

[ISketchSegment Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchSegment Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchSegment Interface

The following tables list the members exposed by [ISketchSegment](#).

 Public Properties

Name	Description
 Color	Gets or sets the color of this sketch segment. Sketch segment color is only supported in drawing documents.
 ConstructionGeometry	Gets or sets whether this sketch segment is construction geometry, for example, a centerline for a feature revolve operation.
 Layer	gets or sets the layer used by this sketch segment.
 LayerOverride	Gets or sets whether the sketch segment has properties that override the default properties of the layer.
 Status	Gets the constraint status for this sketch segment. NOTE: This property is a get-only property. Set is not implemented.
 Style	Gets or sets the line style for this sketch segment.
 Width	Gets or sets the line width for this sketch segment.

[Top](#)

 Public Methods

Name	Description
 CreateWireBody	Creates a wire body using the selected sketch segment.
 DeSelect	Deselects the sketch segment.
 EqualSegment	Divides this sketch segment into equally spaced sketch segments or points.
 GetConstraints	Gets the constraints for this sketch segment.
 GetCurve	Gets the underlying curve for this sketch segment.
 GetID	Gets the for this sketch segment.
 GetLength	Gets the length of this sketch segment.
 GetName	Gets the name of this sketch segment.
 GetRelations	Gets the sketch relations for this sketch segment.
 GetRelationsCount	Gets the number of sketch relations for this sketch segment.
 GetSketch	Gets the sketch for the current sketch segment.
 GetSketchPathCount	Gets the number of sketch paths for this sketch segment
 GetSketchPaths	Gets the sketch paths for this sketch segment.
 GetSketchSlot	Gets sketch slot with which this sketch segment is associated.
 GetType	Gets the type of sketch segment.
 IGetConstraints	Gets the constraints for this sketch segment.
 IGetConstraintsCount	Gets the number of constraints on the sketch segment.
 IGetCurve	Gets the underlying curve for this sketch segment.
 IGetID	Gets the ID for this sketch segment.
 IGetRelations	Gets the sketch relations for this sketch segment.
 IGetSketchPaths	Gets the sketch paths in this sketch segment.
 IsBendLine	Gets whether the sketch segment is a bendline.
 JogLine	Creates rectangular jog on the specified line.
 Select	Obsolete. Superseded by ISketchSegment.Select4 .
 Select2	Obsolete. Superseded by ISketchSegment.Select4 .
 Select3	Obsolete. Superseded by ISketchSegment.Select4 .
 Select4	Selects this sketch segment and marks it.
 SelectByMark	Obsolete. Superseded by ISketchSegment.Select4 .
 SelectChain	Selects chains of entities attached to this sketch segment.
 SplitEntity	Splits the selected sketch entity at the specified point.

[Top](#)

See Also

[ISketchSegment Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISketchSegment Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchSegment Interface

For a list of all members of this type, see [ISketchSegment members](#).

Public Methods

Name	Description
 CreateWireBody	Creates a wire body using the selected sketch segment.

 DeSelect	Deselects the sketch segment.
 EqualSegment	Divides this sketch segment into equally spaced sketch segments or points.
 GetConstraints	Gets the constraints for this sketch segment.
 GetCurve	Gets the underlying curve for this sketch segment.
 GetID	Gets the ID for this sketch segment.
 GetLength	Gets the length of this sketch segment.
 GetName	Gets the name of this sketch segment.
 GetRelations	Gets the sketch relations for this sketch segment.
 GetRelationsCount	Gets the number of sketch relations for this sketch segment.
 GetSketch	Gets the sketch for the current sketch segment.
 GetSketchPathCount	Gets the number of sketch paths for this sketch segment.
 GetSketchPaths	Gets the sketch paths for this sketch segment.
 GetSketchSlot	Gets sketch slot with which this sketch segment is associated.
 GetType	Gets the type of sketch segment.
 IGetConstraints	Gets the constraints for this sketch segment.
 IGetConstraintsCount	Gets the number of constraints on the sketch segment.
 IGetCurve	Gets the underlying curve for this sketch segment.
 IGetID	Gets the ID for this sketch segment.
 IGetRelations	Gets the sketch relations for this sketch segment.
 IGetSketchPaths	Gets the sketch paths in this sketch segment.
 IsBendLine	Gets whether the sketch segment is a bendline.
 JogLine	Creates rectangular jog on the specified line.
 Select	Obsolete. Superseded by ISketchSegment.Select4 .
 Select2	Obsolete. Superseded by ISketchSegment.Select4 .
 Select3	Obsolete. Superseded by ISketchSegment.Select4 .
 Select4	Selects this sketch segment and marks it.
 SelectByMark	Obsolete. Superseded by ISketchSegment.Select4 .
 SelectChain	Selects chains of entities attached to this sketch segment.
 SplitEntity	Splits the selected sketch entity at the specified point.

[Top](#)

 See Also

[ISketchSegment Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchSegment Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISketchSegment Interface

For a list of all members of this type, see [ISketchSegment members](#).

 Public Properties

Name	Description
 Color	Gets or sets the color of this sketch segment. Sketch segment color is only supported in drawing documents.
 Construction/Geometry	Gets or sets whether this sketch segment is construction geometry, for example, a centerline for a feature revolve operation.
Layer	gets or sets the layer used by this sketch segment.



[LayerOverride](#)

Gets or sets whether the sketch segment has properties that override the default properties of the layer.



[Status](#)

Gets the constraint status for this sketch segment.

NOTE: This property is a get-only property. Set is not implemented.



[Style](#)

Gets or sets the line style for this sketch segment.



[Width](#)

Gets or sets the line width for this sketch segment.

[Top](#)

See Also

[ISketchSegment Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Color Property (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Color Property (ISketchSegment)

Gets or sets the color of this sketch segment. Sketch segment color is only supported in drawing documents.

.NET Syntax

Visual Basic (Declaration)

Property Color As System.Integer

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim value As System.Integer
```

```
instance.Color = value
```

```
value = instance.Color
```

C#

```
System.int Color {get; set;}
```

C++/CLI

```
property System.int Color {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

COLORREF value for this sketch segment

Visual Basic for Applications (VBA) Syntax

See [SketchSegment.Color](#).

Example

[Get Temporary Axes in Each Drawing View \(VBA\)](#)

Remarks

Sketch segment color is only supported in drawing documents.

In drawing documents, sketch segments can be created on a layer that has specific visual properties. The color value specified with this property overrides the layer color.

Use the [ISketchSegment::LayerOverride](#) to determine if this sketch segment is currently using its default layer color.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::Layer Property](#)
[ISketchSegment::Style Property](#)
[ISketchSegment::Width Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConstructionGeometry Property (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : ConstructionGeometry Property (ISketchSegment)

Gets or sets whether this sketch segment is construction geometry, for example, a centerline for a feature revolve operation.

.NET Syntax

Visual Basic (Declaration)

Property ConstructionGeometry As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Boolean  
  
instance.ConstructionGeometry = value  
  
value = instance.ConstructionGeometry
```

C#

```
System.bool ConstructionGeometry {get; set;}
```

C++/CLI

```
property System.bool ConstructionGeometry {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this sketch segment is construction geometry, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::ConstructionGeometry](#).

Example

[Create Imported Surface Body From Sketch \(C#\)](#)
[Find Total Length of Sketch Segments in Sketch \(VBA\)](#)
[Get All Elements of Sketch \(VBA\)](#)
[Get Sketch Segment and Curve Data \(VBA\)](#)
[Get Whether Sketch Segment Is Trimmed \(VBA\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateWireBody Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : CreateWireBody Method (ISketchSegment)

Creates a wire body using the selected sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateWireBody() As Body2
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As Body2  
  
value = instance.CreateWireBody()
```

C#

```
Body2 CreateWireBody()
```

C++/CLI

```
Body2^ CreateWireBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Body2](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment.CreateWireBody](#).

Remarks

Wire bodies contain wires, loops, coedges, edges, and vertices. Wires typically represent profiles, construction lines, and center lines of swept shapes. Wires can also represent wire frames that, when surfaced, form shells.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeSelect Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : DeSelect Method (ISketchSegment)

Deselects the sketch segment.

.NET Syntax

Visual Basic (Declaration)

Function DeSelect() As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Boolean
```

```
value = instance.DeSelect()
```

C#

```
System.bool DeSelect()
```

C++/CLI

```
System.bool DeSelect();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the sketch segment is deselected successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::DeSelect](#).

Remarks

This method does not work well when a PropertyManager page is open or a command is running. Use [IModelDoc2::DeSelectByID](#) instead of using this method. IModelDoc2::DeSelectByID handles selection correctly whether or not a command is running.

To select or deselect a sketch segment, the owning document of that ISketchSegment object needs to be open and visible.

ISketchSegment selections are accessible through the [ISelectionMgr](#) of the owning document of the sketch segment object, even if the owning document is not active.

Selection or deselection does not work for a sketch segment in a document within a drawing. Selection or deselection of sketch segments owned by the drawing does work, but only if the drawing document is active.

If the owning sketch of a sketch segment was active, or inactive, when the sketch segment was obtained, then it must be active, or inactive, to deselect it. For example, if the owning sketch of a sketch segment was active when the sketch segment was obtained, then the owning sketch must be active to select or deselect the sketch segment. Likewise, if the owning sketch of a sketch segment was inactive when the sketch segment was obtained, then the owning sketch must be inactive to select or deselect the sketch segment.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::Select4 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

EqualSegment Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : EqualSegment Method (ISketchSegment)

Divides this sketch segment into equally spaced sketch segments or points.

.NET Syntax

Visual Basic (Declaration)

```
Function EqualSegment( _  
    ByVal SketchType As System.Integer, _
```

```
ByVal SegmentPoints As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim SketchType As System.Integer  
Dim SegmentPoints As System.Integer  
Dim value As System.Boolean  
  
value = instance.EqualSegment(SketchType, SegmentPoints)
```

C#

```
System.bool EqualSegment(  
    System.int SketchType,  
    System.int SegmentPoints  
)
```

C++/CLI

```
System.bool EqualSegment(  
& System.int SketchType,  
& System.int SegmentPoints  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SketchType
Type of entity with which to divide this sketch segment as defined in [swSketchSegmentType_e](#)
SegmentPoints
2 <= Number of sketchType entities into which to divide this sketch segment <= 100

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchSegment.EqualSegment](#).

Example

[Divide Sketch Segment \(VBA\)](#)
[Divide Sketch Segment \(VB.NET\)](#)
[Divide Sketch Segment \(C#\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConstraints Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetConstraints Method (ISketchSegment)

Gets the constraints for this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConstraints() As System.Object
```

```
Dim instance As ISketchSegment
Dim value As System.Object

value = instance.GetConstraints()
```

C#

```
System.Object GetConstraints()
```

C++/CLI

```
System.Object^ GetConstraints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of sketch segment constraints (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetConstraints](#).

Example

[Get Sketch Constraints \(VBA\)](#)

Remarks

The available constraint values are as follows:

- | | | |
|-------------------|------------------|-----------------|
| • sgHORIZONTAL | • sgSYMMETRIC | • sgARCANGRIGHT |
| • sgHORIZPOINTS | • sgATMIDDLE | • sgARCANGTOP |
| • sgVERTICAL | • sgATINTERSECT | • sgDIAMETER |
| • sgVERTPOINTS | • sgATPIERCE | • sgDISTANCE |
| • sgCOLINEAR | • sgFIXED | • sgSAMELENGTH |
| • sgCORADIAL | • sgANGLE | • sgOFFSETEGE |
| • sgPERPENDICULAR | • sgARCANG180 | • sgSNAPANGLE |
| • sgPARALLEL | • sgARCANG270 | • sgSNAPGRID |
| • sgTANGENT | • sgARCANG90 | • sgSNAPLENGTH |
| • sgCONCENTRIC | • sgARCANGBOTTOM | • sgUSEEDGE |
| • sgCOINCIDENT | • sgARCANGLEFT | • sgMERGEPOINTS |

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::IGetConstraints Method](#)
[ISketchSegment::IGetConstraintsCount Method](#)
[IModelDoc2::SketchConstraintsDelAll Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

GetCurve Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetCurve Method (ISketchSegment)

Gets the underlying curve for this sketch segment.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetCurve() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim value As System.Object

value = instance.GetCurve()
```

C#

```
System.Object GetCurve()
```

C++/CLI

```
System.Object^ GetCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Underlying [curve](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetCurve](#).

Example

[Get Curve Spline Points \(VBA\)](#)
[Evaluate Curves Defined in Sketch Space \(VBA\)](#)
[Get Sketch Segment and Curve Data \(VBA\)](#)
[Get Start and End Points of Spline \(VBA\)](#)
[Get Whether Sketch Segment Is Trimmed \(VBA\)](#)

Remarks

This operation only supports for [ellipse](#), [line](#), [arc](#), [spline](#), and [parabola](#) sketch items. All other sketch segment types will return NULL, and S_false for COM applications.

NOTE: Support for ellipse, line, and arc segments was introduced in SOLIDWORKS 2004.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::IGetCurve Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetID Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetID Method (ISketchSegment)

Gets the for this sketch segment.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetID() As System.Object
```

```
Dim instance As ISketchSegment
Dim value As System.Object

value = instance.GetID()
```

C#

```
System.object GetID()
```

C++/CLI

```
System.Object^ GetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array with two longs or integers (see [Long vs. Integer](#)) identifying this sketch segment ID

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetID](#).

Example

[Get All Elements of Sketch \(VBA\)](#)
[Get All Sketch Segments in Drawing Template \(VBA\)](#)
[Get Names of Sketch Segments \(VBA\)](#)
[Get Sketch Segment and Curve Data \(VBA\)](#)
[Get Whether Sketch Segment is Trimmed \(VBA\)](#)
[Get Sketch Relations \(VBA\)](#)
[Get Sketch Relations \(VB.NET\)](#)
[Get Sketch Relations \(C#\)](#)

Remarks

The ID of the sketch segment:

- is an ordered pair (i1, i2). For the specific sketch segment type, for example, line, arc, spline, and so on), the combination of these two numbers is always unique within a specific sketch.
- cannot be assigned by applications or users.
- is not the same as a [persistent reference ID](#).

Each entity within a specific sketch has a unique ID. However, a sketch line may have the same ID values as a sketch arc within the same sketch. Likewise, in a second sketch, you may find a different sketch element with the same ID. Therefore, your application must keep track of:

- sketch element type (that is, point, line, arc, spline, and so on)
- owning sketch name
- sketch element id to uniquely identify a sketched item

You can determine the sketch element type by using [ISketchSegment::GetType](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::IGetID Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

GetLength Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetLength Method (ISketchSegment)

Gets the length of this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLength() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Double  
  
value = instance.GetLength()
```

C#

```
System.double GetLength()
```

C++/CLI

```
System.double GetLength();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Sketch segment length

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetLength](#).

Example

[Find Total Length of Sketch Segments in Sketch \(VBA\)](#)
[Get All Sketch Segments in Drawing Template \(VBA\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetName Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetName Method (ISketchSegment)

Gets the name of this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.String  
  
value = instance.GetName()
```

C#

```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Sketch segment name

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetName](#).

Example

[Get Sketch Segment Names \(C#\)](#)
[Get Sketch Segment Names \(VB.NET\)](#)
[Get Sketch Segment Names \(VBA\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRelations Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetRelations Method (ISketchSegment)

Gets the sketch relations for this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRelations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Object  
  
value = instance.GetRelations()
```

C#

```
System.object GetRelations()
```

C++/CLI

```
System.Object^ GetRelations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [sketch relations](#) for this sketch segment

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetRelations](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetRelationsCount Method](#)
[ISketchSegment::IGetRelations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRelationsCount Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetRelationsCount Method (ISketchSegment)

Gets the number of sketch relations for this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRelationsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Integer
```

```
value = instance.GetRelationsCount()
```

C#

```
System.int GetRelationsCount()
```

C++/CLI

```
System.int GetRelationsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch relations for this sketch segment

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetRelationsCount](#).

Remarks

Call this method before calling [ISketchSegment::IGetRelations](#) to get the size of the array for that method.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetRelations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketch Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetSketch Method (ISketchSegment)

Gets the sketch for the current sketch segment.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSketch() As Sketch
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim value As Sketch

value = instance.GetSketch()
```

C#

```
Sketch GetSketch()
```

C++/CLI

```
Sketch^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetSketch](#).

Example

[Evaluate Curves Defined in Sketch Space \(VBA\)](#)
[Get Names of Sketch Segments \(VBA\)](#)
[Get Sketch Segment and Curve Data \(VBA\)](#)
[Get Whether Sketch Segment Is Trimmed \(VBA\)](#)
[Insert Hatch \(VBA\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSketchPathCount Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetSketchPathCount Method (ISketchSegment)

Gets the number of sketch paths for this sketch segment

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSketchPathCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim value As System.Integer

value = instance.GetSketchPathCount()
```

C#

```
System.int GetSketchPathCount()
```

C++/CLI

```
System.int GetSketchPathCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch paths

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetSketchPathCount](#).

Remarks

Call this method before calling [ISketchSegment::!GetSketchPaths](#) to get the size of the array for that method.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetSketchPaths Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchPaths Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetSketchPaths Method (ISketchSegment)

Gets the sketch paths for this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchPaths() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Object  
  
value = instance.GetSketchPaths()
```

C#

```
System.object GetSketchPaths()
```

C++/CLI

```
System.Object^ GetSketchPaths();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [sketch paths](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetSketchPaths](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetSketchSegmentCount Method](#)
[ISketchSegment::IGetSketchSegments Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchSlot Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : GetSketchSlot Method (ISketchSegment)

Gets sketch slot with which this sketch segment is associated.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchSlot() As SketchSlot
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As SketchSlot  
  
value = instance.GetSketchSlot()
```

C#

```
SketchSlot GetSketchSlot()
```

C++/CLI

```
SketchSlot^ GetSketchSlot();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch slot](#) if the sketch segment is associated with a sketch slot, or null if the sketch segment is not associated with a sketch slot

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetSketchSlot](#).

Example

[Get Sketch Slot Using Sketch Point and Segment \(C#\)](#)
[Get Sketch Slot Using Sketch Point and Segment \(VB.NET\)](#)
[Get Sketch Slot Using Sketch Point and Segment \(VBA\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetType Method (ISketchSegment)

[See Also](#) [Example](#)



Gets the type of sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim value As System.Integer
```

```
value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of sketch segment as defined in [swSketchSegments_e](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetType](#).

Example

[Find Total Length of Sketch Segments in Sketch \(VBA\)](#)
[Get All Elements of Sketch \(VBA\)](#)
[Get All Sketch Segments in Drawing Template \(VBA\)](#)
[Get Sketch Segment and Curve Data \(VBA\)](#)
[Get Whether Sketch Segment Is Trimmed \(VBA\)](#)
[Insert DXF File and Add Dimension \(VBA\)](#)
[Get Spline's Parameters \(C#\)](#)
[Get Spline's Parameters \(VB.NET\)](#)
[Get Spline's Parameters \(VBA\)](#)

Remarks

You can use this method to determine the segment type and the appropriate function calls allowed for the specific type. For example, if you determine that this sketch segment is a spline, then it is appropriate to call [ISketchSpline::GetPoints2](#). VC++ COM implementations can also use QueryInterface to determine the underlying interface supported by this ISketchSegment object.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

IGetConstraints Method (ISketchSegment)

[See Also](#) [Example](#)



Gets the constraints for this sketch segment.

.NET Syntax

Function IGetConstraints() As System.String



```
Dim instance As ISketchSegment
Dim value As System.String

value = instance.IGetConstraints()
```

System.string IGetConstraints()

System.String^ IGetConstraints();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of sketch segment constraints (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Example

[Get Sketch Segment Constraints \(C++\)](#)

Remarks

The available constraint values are as follows:

- | | | |
|-------------------|------------------|-----------------|
| • sgHORIZONTAL | • sgSYMMETRIC | • sgARCANGRIGHT |
| • sgHORIZPOINTS | • sgATMIDDLE | • sgARCANGTOP |
| • sgVERTICAL | • sgATINTERSECT | • sgDIAMETER |
| • sgVERTPOINTS | • sgATPIERCE | • sgDISTANCE |
| • sgCOLINEAR | • sgFIXED | • sgSAMELENGTH |
| • sgCORADIAL | • sgANGLE | • sgOFFSETEDGE |
| • sgPERPENDICULAR | • sgARCANG180 | • sgSNAPANGLE |
| • sgPARALLEL | • sgARCANG270 | • sgSNAPGRID |
| • sgTANGENT | • sgARCANG90 | • sgSNAPLENGTH |
| • sgCONCENTRIC | • sgARCANGBOTTOM | • sgUSEEDGE |
| • sgCOINCIDENT | • sgARCANGLEFT | • sgMERGEPOINTS |

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetConstraints Method](#)
[ISketchSegment::IGetConstraintsCount Method](#)
[IModelDoc2::SketchConstraintsDelAll Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IGetConstraintsCount Method (ISketchSegment)

[See Also](#) [Example](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetConstraintsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim value As System.Integer

value = instance.IGetConstraintsCount()
```

C#

```
System.int IGetConstraintsCount()
```

C++/CLI

```
System.int IGetConstraintsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of constraints on this sketch segment

Visual Basic for Applications (VBA) Syntax

See [SketchSegment.IGetConstraintsCount](#).

Example

[Get Sketch Segment Constraints \(C++\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[IModelDoc2::SketchConstraintsDelAll Method](#)
[ISketchSegment::GetConstraints Method](#)
[ISketchSegment::IGetConstraints Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetCurve Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : IGetCurve Method (ISketchSegment)

Gets the underlying curve for this sketch segment.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetCurve() As Curve
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim value As Curve

value = instance.IGetCurve()
```

C#

Curve IGetCurve()

C++/CLI

Curve^ IGetCurve();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Underlying [curve](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment.IGetCurve](#).

Example

[Get Curve Spline Points \(C++\)](#)

Remarks

This operation only supports for [ellipse](#), [line](#), [arc](#), [spline](#), and [parabola](#) sketch items. All other sketch segment types will return NULL, and S_false for COM applications.

NOTE: Support for ellipse, line, and arc segments was introduced in SOLIDWORKS 2004.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetCurve Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetID Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : IGetID Method (ISketchSegment)

Gets the ID for this sketch segment.

.NET Syntax

Visual Basic (Declaration)

Function IGetID() As System.Integer

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Integer
```

```
value = instance.IGetID()
```

C#

```
System.int IGetID()
```

C++/CLI

```
System.int IGetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array with two longs or integers (see [Long vs. Integer](#)) identifying this sketch segment ID

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::GetID](#).

Remarks

The ID of the sketch segment:

- is an ordered pair (i1, i2). For the specific sketch segment type, for example, line, arc, spline, and so on), the combination of these two numbers is always unique within a specific sketch.
- cannot be assigned by applications or users.
- is not the same as a [persistent reference ID](#).

Each entity within a specific sketch has a unique ID. However, a sketch line may have the same ID values as a sketch arc within the same sketch. Likewise, in a second sketch, you may find a different sketch element with the same ID. Therefore, your application must keep track of:

- sketch element type (that is, point, line, arc, spline, and so on)
- owning sketch name
- sketch element id to uniquely identify a sketched item

You can determine the sketch element type by using [ISketchSegment::GetType](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetID Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetRelations Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : IGetRelations Method (ISketchSegment)

Gets the sketch relations for this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRelations( _  
    ByVal Count As System.Integer _  
) As SketchRelation
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim Count As System.Integer  
Dim value As SketchRelation
```

```
value = instance.IGetRelations(Count)
```

C#

```
SketchRelation IGetRelations(  
    System.int Count  
)
```

C++/CLI

```
SketchRelation^ IGetRelations(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of sketch relations for this sketch segment

Return Value

- in-process, unmanaged C++: Pointer to an array of [sketch relations](#) for this sketch segment
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ISketchSegment::GetRelationsCount](#) to get the value for Count.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetRelations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSketchPaths Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : IGetSketchPaths Method (ISketchSegment)

Gets the sketch paths in this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSketchPaths( _  
    ByVal Count As System.Integer _  
) As SketchPath
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim Count As System.Integer  
Dim value As SketchPath
```

```
value = instance.IGetSketchPaths(Count)
```

C#

```
SketchPath IGetSketchPaths(  
    System.int Count  
)
```

C++/CLI

```
SketchPath^ IGetSketchPaths(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of sketch paths

Return Value

- in-process, unmanaged C++: Pointer to an array of [sketch paths](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ISketchSegment::GetSketchPathCount](#) to get the value of Count.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::GetSketchPaths Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsBendLine Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : IsBendLine Method (ISketchSegment)

Gets whether the sketch segment is a bendline.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBendLine() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Boolean  
  
value = instance.IsBendLine()
```

C#

```
System.bool IsBendLine()
```

C++/CLI

```
System.bool IsBendLine();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the sketch segment is a bendline, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::IsBendLine](#).

Example

[Get Tangent Edges of Bendlines \(VB.NET\)](#)
[Get Tangent Edges of Bendlines \(VBA\)](#)
[Get Tangent Edges of Bendlines \(C#\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[IView::GetBendLineCount Method](#)
[IView::GetBendLines Method](#)
[IView::IGetBendLines Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

JogLine Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : JogLine Method (ISketchSegment)

Creates rectangular jog on the specified line.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub JogLine( _  
    ByVal XOnLine As System.Double, _  
    ByVal YOnLine As System.Double, _  
    ByVal ZOnLine As System.Double, _  
    ByVal XOnJog As System.Double, _  
    ByVal YOnJog As System.Double, _  
    ByVal ZOnJog As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim XOnLine As System.Double  
Dim YOnLine As System.Double  
Dim ZOnLine As System.Double  
Dim XOnJog As System.Double  
Dim YOnJog As System.Double  
Dim ZOnJog As System.Double  
  
instance.JogLine(XOnLine, YOnLine, ZOnLine, XOnJog, YOnJog, ZOnJog)
```

C#

```
void JogLine(  
    System.double XOnLine,  
    System.double YOnLine,  
    System.double ZOnLine,  
    System.double XOnJog,  
    System.double YOnJog,  
    System.double ZOnJog  
)
```

C++/CLI

```
void JogLine(  
& System.double XOnLine,  
& System.double YOnLine,  
& System.double ZOnLine,  
& System.double XOnJog,  
& System.double YOnJog,  
& System.double ZOnJog  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[XOnLine](#)
x coordinate where to begin the jog on the selected line
[YOnLine](#)
y coordinate where to begin the jog on the selected line
[ZOnLine](#)
z coordinate where to begin the jog on the selected line
[XOnJog](#)
x coordinate of the width and depth of the jog
[YOnJog](#)
y coordinate of the width and depth of the jog
[ZOnJog](#)
z coordinate of the width and depth of the jog

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::JogLine](#).

Example

[Insert Explode Line Sketch and Jog Line \(VB.NET\)](#)
[Insert Explode Line Sketch and Jog Line \(VBA\)](#)
[Insert Explode Line Sketch and Jog Line \(C#\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchManager::InsertExplodeLineSketch Method](#)
[ISketchManager::Insert3DSketch Method](#)
[ISketch::InsertRouteLine Method](#)
[ISketchManager::CreateLine Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Layer Property (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Layer Property (ISketchSegment)

gets or sets the layer used by this sketch segment.

.NET Syntax

Visual Basic (Declaration)

Property Layer As System.String

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.String
```

```
instance.Layer = value
```

```
value = instance.Layer
```

C#

```
System.string Layer {get; set;}
```

C++/CLI

```
property System.String^ Layer {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the layer used for this sketch segment

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::Layer](#).

Remarks

Layers are only supported in drawing documents.

Sketch segments can be created on a specific layer. This property gets or sets the layer used by this sketch segment.

The return value may be an empty string because an old document may not contain layers. This also occurs if sketch segments have been generated in a new document that has no layers defined.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::LayerOverride Property](#)
[ISketchSegment::Color Property](#)
[ISketchSegment::Style Property](#)
[ISketchSegment::Width Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

LayerOverride Property (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : LayerOverride Property (ISketchSegment)

Gets or sets whether the sketch segment has properties that override the default properties of the layer.

.NET Syntax

Visual Basic (Declaration)

Property LayerOverride As System.Integer

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim value As System.Integer
```

```
instance.LayerOverride = value
```

```
value = instance.LayerOverride
```

C#

```
System.int LayerOverride {get; set;}
```

C++/CLI

```
property System.int LayerOverride {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Properties that have been overridden or should be overridden as defined in [swLayerOverride_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::LayerOverride](#).

Remarks

Layers are only supported in drawing documents.

Sketch segments can be created on a layer that has specific visual properties. By default, the sketch segment takes on the visual properties defined by the layer. However, for a specific sketch segment, these visual properties can be overridden (see [ISketchSegment::Color](#), [ISketchSegment::Style](#), and [ISketchSegment::Width](#)). This property gets or sets whether the default visual properties of the layer are used by this sketch segment.

When the sketch segment is not on any layer, the value this property returns is undefined. You can use the [ISketchSegment::Layer](#) property to determine the name of the layer, if any, that this sketch segment is on. If an empty string is returned by the [ISketchSegment::Layer](#) property, then

this property is not used.

If getting properties that override the default properties of the layer, the returned bit value indicates which properties have been overridden. The bit indicators are:

- color = 0x1
- style = 0x2
- width = 0x4

Therefore, if the return value is 3, then you know the color and style have been specifically set for this item and may not match the default value associated with this item's layer.

If setting properties that override the default properties of the layer, the input bit value indicates which properties should maintain their current override values. The bit indicators are:

- color = 0x1
- style = 0x2
- width = 0x4

Therefore, if the value is passed is 0x4, then you know the width should keep its current override value and that the color and style visual properties for this sketch segment should be reset to use the color and style settings of the item's layer. If you pass 0, then all visual properties are reset to use the default settings of the item's layer.

Only set this to reset specific visual properties back to the default visual properties of the owning layer. If you want to change or set specific values for the visual property for this item, use [ISketchSegment::Color](#), [ISketchSegment::Style](#), and [ISketchSegment::Width](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Select Method (ISketchSegment)

Obsolete. Superseded by [ISketchSegment::Select4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal AppendFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim AppendFlag As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.Select(AppendFlag)
```

C#

```
System.bool Select(  
    System.bool AppendFlag  
)
```

C++/CLI

```
System.bool Select(  
& System.bool AppendFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::Select](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select2 Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Select2 Method (ISketchSegment)

Obsolete. Superseded by [ISketchSegment::Select4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select2(  
    ByVal Append As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim Append As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean  
  
value = instance.Select2(Append, Mark)
```

C#

```
System.bool Select2(  
    System.bool Append,  
    System.int Mark  
)
```

C++/CLI

```
System.bool Select2(  
& System.bool Append,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

Mark

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::Select2](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Select3 Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Select3 Method (ISketchSegment)

Obsolete. Superseded by [ISketchSegment::Select4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select3( _
    ByVal Append As System.Boolean, _
    ByVal Mark As System.Integer, _
    ByVal Callout As Callout _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim Append As System.Boolean
Dim Mark As System.Integer
Dim Callout As Callout
Dim value As System.Boolean

value = instance.Select3(Append, Mark, Callout)
```

C#

```
System.bool Select3(
    System.bool Append,
    System.int Mark,
    Callout Callout
)
```

C++/CLI

```
System.bool Select3(
    & System.bool Append,
    & System.int Mark,
    & Callout^ Callout
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

Mark

Callout

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::Select3](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Select4 Method (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Select4 Method (ISketchSegment)

Selects this sketch segment and marks it.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function Select4( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim Append As System.Boolean  
Dim Data As SelectData  
Dim value As System.Boolean  
  
value = instance.Select4(Append, Data)
```

C#

```
System.bool Select4(  
    System.bool Append,  
    SelectData Data  
)
```

C++/CLI

```
System.bool Select4(  
& System.bool Append,  
& SelectData^ Data  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True to append this selection to the selection list, false to replace the selection list with this selection

Data

[ISelectData](#) object

Return Value

True if the sketch segment is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::Select4](#).

Example

[Get All Sketch Segments in Drawing Template \(VBA\)](#)
[Get Axis of Revolve Feature \(VBA\)](#)
[Insert Coordinate System at Center of Mass \(VBA\)](#)
[Create Sketch Path \(C#\)](#)
[Create Sketch Path \(VB.NET\)](#)
[Create Sketch Path \(VBA\)](#)
[Rotate and Copy 3D Sketch About Coordinates \(C#\)](#)
[Rotate and Copy 3D Sketch About Coordinates \(VB.NET\)](#)
[Rotate and Copy 3D Sketch About Coordinates \(VBA\)](#)

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : SelectByMark Method (ISketchSegment)

Obsolete. Superseded by [ISketchSegment::Select4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SelectByMark( _  
    ByVal AppendFlag As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISketchSegment  
Dim AppendFlag As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SelectByMark(AppendFlag, Mark)
```

C#

```
System.bool SelectByMark(  
    System.bool AppendFlag,  
    System.int Mark  
)
```

C++/CLI

```
System.bool SelectByMark(  
& System.bool AppendFlag,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

Mark

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::SelectByMark](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SelectChain Method (ISketchSegment)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : SelectChain Method (ISketchSegment)

Selects chains of entities attached to this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Function SelectChain( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
) As System.Boolean
```

```
Dim instance As ISketchSegment
Dim Append As System.Boolean
Dim Data As SelectData
Dim value As System.Boolean

value = instance.SelectChain(Append, Data)
```

C#

```
System.bool SelectChain(
    System.bool Append,
    SelectData Data
)
```

C++/CLI

```
System.bool SelectChain(
    & System.bool Append,
    & SelectData^ Data
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True to append to the current selection list, false to replace the selection list

Data

[ISelectData](#)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SketchSegment.SelectChain](#).

Example

[Select Chains of Entities Attached to a Sketch Segment \(VBA\)](#)

[Select Chains of Entities Attached to a Sketch Segment \(VB.NET\)](#)

[Select Chains of Entities Attached to a Sketch Segment \(C#\)](#)

Remarks

Before calling this method call [ISelectionMgr.CreateSelectData](#) to specify Data.

This method is equivalent to right-clicking a sketch segment and selecting **Select Chain**. The chain of entities in each direction is selected. Selection ends when a branch in the chain is encountered.

See Also

[ISketchSegment Interface](#)

[ISketchSegment Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SplitEntity Method (ISketchSegment)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : SplitEntity Method (ISketchSegment)

Splits the selected sketch entity at the specified point.

.NET Syntax

```

Sub SplitEntity( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal ClosedX As System.Double, _
    ByVal ClosedY As System.Double, _
    ByVal ClosedZ As System.Double _
)

```

```

Dim instance As ISketchSegment
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim ClosedX As System.Double
Dim ClosedY As System.Double
Dim ClosedZ As System.Double

```

```
instance.SplitEntity(X, Y, Z, ClosedX, ClosedY, ClosedZ)
```

```

void SplitEntity(
    System.double X,
    System.double Y,
    System.double Z,
    System.double ClosedX,
    System.double ClosedY,
    System.double ClosedZ
)

```

```

void SplitEntity(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.double ClosedX,
    & System.double ClosedY,
    & System.double ClosedZ
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[X](#)
x coordinate where to split the selected entity

[Y](#)
y coordinate where to split the selected entity

[Z](#)
z coordinate where to split the selected entity

[ClosedX](#)
x coordinate where to close the split entity

[ClosedY](#)
y coordinate where to close the split entity

[ClosedZ](#)
z coordinate where to close the split entity

Visual Basic for Applications (VBA) Syntax

See [SketchSegment.SplitEntity](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

Status Property (ISketchSegment)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Status Property (ISketchSegment)

Gets the constraint status for this sketch segment.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Status As System.Integer

Visual Basic (Usage)



```
Dim instance As ISketchSegment
Dim value As System.Integer
```

```
instance.Status = value
```

```
value = instance.Status
```

C#

```
System.int Status {get; set;}
```

C++/CLI

```
property System.int Status {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sketch segment constraint status as defined in [swConstrainedStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::Status](#).

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14.2

Style Property (ISketchSegment)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Style Property (ISketchSegment)

Gets or sets the line style for this sketch segment.

.NET Syntax

Visual Basic (Declaration)

Property Style As System.Integer

```
Dim instance As ISketchSegment
Dim value As System.Integer

instance.Style = value

value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line style used for this sketch segment as defined in [swLineStyles_e](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment::Style](#).

Example

[Get Temporary Axes in Each Drawing View \(VBA\)](#)

Remarks

This property is only supported in drawing documents.

Sketch segments can be created on a layer that has specific visual properties. By default, the sketch segment takes on the visual properties defined by the layer. The line style value specified with this property overrides the default layer style.

Use the [ISketchSegment::LayerOverride](#) to determine if this sketch segment is currently using its default layer line style.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment::Color Property](#)
[ISketchSegment::Layer Property](#)
[ISketchSegment::Width Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

Width Property (ISketchSegment)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSegment Interface](#) : Width Property (ISketchSegment)

Gets or sets the line width for this sketch segment.

.NET Syntax

Visual Basic (Declaration)

```
Property Width As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISketchSegment  
Dim value As System.Integer
```

```
instance.Width = value
```

```
value = instance.Width
```

C#

```
System.int Width {get; set;}
```

C++/CLI

```
property System.int Width {  
    System.int get();  
    void set ( &    System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line width used for this sketch segment as defined in [swLineWeights_e](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSegment.Width](#).

Example

[Get Sketch Entities with Visual Properties \(VBA\)](#)
[Get Temporary Axes in Each Drawing View \(VBA\)](#)

Remarks

This property is only supported in drawing documents.

Sketch segments can be created on a layer that has specific visual properties. By default, the sketch segment takes on the visual properties defined by the layer. The line width value specified with this property overrides the default layer width.

Use the [ISketchSegment.LayerOverride](#) to determine if this sketch segment is currently using its default layer line width.

See Also

[ISketchSegment Interface](#)
[ISketchSegment Members](#)
[ISketchSegment.Color Property](#)
[ISketchSegment.Layer Property](#)
[ISketchSegment.Style Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

ISketchSlot (Type)

ISketchSlot Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchSlot Interface

Accesses a sketch slot.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISketchSlot
```

Visual Basic (Usage)

```
Dim instance As ISketchSlot
```

C#

```
public interface ISketchSlot
```

C++/CLI

```
public interface class ISketchSlot
```

Visual Basic for Applications (VBA) Syntax

See [SketchSlot](#).

Example

[Insert and Resize Sketch Slot \(C#\)](#)
[Insert and Resize Sketch Slot \(VB.NET\)](#)
[Insert and Resize Sketch Slot \(VBA\)](#)

Accessors

[ISketch::GetSketchSlots](#) and [ISketch::IGetSketchSlots](#)
[ISketchManager::CreateSketchSlot](#)
[ISketchPoint::GetSketchSlot](#)
[ISketchSegment::GetSketchSlot](#)

Access Diagram

[SketchSlot](#)

See Also

[ISketchSlot Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ISketchSlot Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISketchSlot Interface

For a list of all members of this type, see [ISketchSlot members](#).

Public Methods

Name	Description
 GetCenterPoint	Gets the centerpoint in this sketch slot.
 GetCenterPointHandle	Gets the sketch point representing the centerpoint of the sketch slot.
 GetSlotPoints	Gets the points for this slot.

[Top](#)

 See Also

[ISketchSlot Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchSlot Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISketchSlot Interface

The following tables list the members exposed by [ISketchSlot](#).

 Public Properties

Name	Description
 CenterArcDirection	Gets the direction of the slot.
 CreationType	Gets the type of slot.
 Length	Gets the length of the sketch slot.
 LengthType	Gets or sets the type of length of this sketch slot.
 Width	Gets or sets the width of this sketch slot.

[Top](#)

 Public Methods

Name	Description
 GetCenterPoint	Gets the centerpoint in this sketch slot.
 GetCenterPointHandle	Gets the sketch point representing the centerpoint of the sketch slot.
 GetSlotPoints	Gets the points for this slot.

[Top](#)

 See Also

[ISketchSlot Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISketchSlot Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISketchSlot Interface

For a list of all members of this type, see [ISketchSlot members](#).

 Public Properties

Name	Description
 CenterArcDirection	Gets the direction of the slot.
 CreationType	Gets the type of slot.
 Length	Gets the length of the sketch slot.
 LengthType	Gets or sets the type of length of this sketch slot.
 Width	Gets or sets the width of this sketch slot.

[Top](#)

See Also

[ISketchSlot Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CenterArcDirection Property (ISketchSlot)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSlot Interface](#) : CenterArcDirection Property (ISketchSlot)

Gets the direction of the slot.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CenterArcDirection As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchSlot  
Dim value As System.Integer  
  
value = instance.CenterArcDirection
```

C#

```
System.int CenterArcDirection {get;}
```

C++/CLI

```
property System.int CenterArcDirection {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

-1 for clockwise, 1 for counter-clockwise

Visual Basic for Applications (VBA) Syntax

See [SketchSlot.CenterArcDirection](#).

See Also

[ISketchSlot Interface](#)
[ISketchSlot Members](#)
[ISketchSlot::CreationType Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreationType Property (ISketchSlot)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSlot Interface](#) : CreationType Property (ISketchSlot)

Gets the type of slot.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CreationType As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISketchSlot  
Dim value As System.Integer  
  
value = instance.CreationType
```

C#

```
System.int CreationType {get;}
```

C++/CLI

```
property System.int CreationType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of slot as defined in [swSketchSlotCreationType_e](#)

NOTE: Only swSketchSlotCreateType_line or swSketchSlotCreateType_arc are valid return values.

Visual Basic for Applications (VBA) Syntax

See [SketchSlot::CreationType](#).

See Also

[ISketchSlot Interface](#)
[ISketchSlot Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCenterPoint Method (ISketchSlot)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSlot Interface](#) : GetCenterPoint Method (ISketchSlot)

Gets the centerpoint in this sketch slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterPoint() As MathPoint
```

Visual Basic (Usage)

```
Dim instance As ISketchSlot  
Dim value As MathPoint  
  
value = instance.GetCenterPoint()
```

C#

```
MathPoint GetCenterPoint()
```

C++/CLI

```
MathPoint^ GetCenterPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Centerpoint](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSlot::GetCenterPoint](#).

Example

[Get Sketch Slot Data \(VBA\)](#)

See Also

[ISketchSlot Interface](#)
[ISketchSlot Members](#)
[ISketchSlot::GetCenterPointHandle Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCenterPointHandle Method (ISketchSlot)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSlot Interface](#) : GetCenterPointHandle Method (ISketchSlot)

Gets the sketch point representing the centerpoint of the sketch slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCenterPointHandle() As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As ISketchSlot  
Dim value As SketchPoint
```

```
value = instance.GetCenterPointHandle()
```

C#

```
SketchPoint GetCenterPointHandle()
```

C++/CLI

```
SketchPoint^ GetCenterPointHandle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch point](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSlot::GetCenterPointHandle](#).

Example

[Get Sketch Slot Data \(VBA\)](#)

See Also

[ISketchSlot Interface](#)
[ISketchSlot Members](#)
[ISketchSlot::GetCenterPoint Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSlotPoints Method (ISketchSlot)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSlot Interface](#) : GetSlotPoints Method (ISketchSlot)

Gets the points for this slot.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSlotPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISketchSlot  
Dim value As System.Object  
  
value = instance.GetSlotPoints()
```

C#

```
System.object GetSlotPoints()
```

C++/CLI

```
System.Object^ GetSlotPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [sketch points](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSlot::GetSlotPoints](#).

See Also

[ISketchSlot Interface](#)
[ISketchSlot Members](#)
[ISketchSlot::CreationType Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Length Property (ISketchSlot)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSlot Interface](#) : Length Property (ISketchSlot)

Gets the length of the sketch slot.

.NET Syntax

Visual Basic (Declaration)

```
Property Length As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchSlot  
Dim value As System.Double
```

```
instance.Length = value
```

```
value = instance.Length
```

C#

```
System.double Length {get; set;}
```

C++/CLI

```
property System.double Length {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of the sketch slot

Visual Basic for Applications (VBA) Syntax

See [SketchSlot.Length](#).

Example

[Insert and Resize Sketch Slot \(C#\)](#)
[Insert and Resize Sketch Slot \(VB.NET\)](#)
[Insert and Resize Sketch Slot \(VBA\)](#)
[Get Sketch Slot Data \(VBA\)](#)

See Also

[ISketchSlot Interface](#)
[ISketchSlot Members](#)
[ISketchSlot.LengthType Property](#)
[ISketchSlot.Width Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LengthType Property (ISketchSlot)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSlot Interface](#) : LengthType Property (ISketchSlot)

Gets or sets the type of length of this sketch slot.

.NET Syntax

Visual Basic (Declaration)

```
Property LengthType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISketchSlot  
Dim value As System.Integer
```

```
instance.LengthType = value
```

```
value = instance.LengthType
```

C#

```
System.int LengthType {get; set;}
```

C++/CLI

```
property System.int LengthType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of length of this sketch slot as defined in [swSketchSlotLengthType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SketchSlot::LengthType](#).

Example

[Insert and Resize Sketch Slot \(C#\)](#)
[Insert and Resize Sketch Slot \(VB.NET\)](#)
[Insert and Resize Sketch Slot \(VBA\)](#)
[Get Sketch Slot Data \(VBA\)](#)

See Also

[ISketchSlot Interface](#)
[ISketchSlot Members](#)
[ISketchSlot::Length Property](#)
[ISketchSlot::Width Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Width Property (ISketchSlot)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISketchSlot Interface](#) : Width Property (ISketchSlot)

Gets or sets the width of this sketch slot.

.NET Syntax

Visual Basic (Declaration)

```
Property Width As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISketchSlot  
Dim value As System.Double
```

```
instance.Width = value
```

```
value = instance.Width
```

C#

```
System.double Width {get; set;}
```

C++/CLI

```
property System.double Width {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Width of sketch slot

Visual Basic for Applications (VBA) Syntax

See [SketchSlot.Width](#).

Example

[Insert and Resize Sketch Slot \(C#\)](#)
[Insert and Resize Sketch Slot \(VB.NET\)](#)
[Insert and Resize Sketch Slot \(VBA\)](#)
[Get Sketch Slot Data \(VBA\)](#)

See Also

[ISketchSlot Interface](#)
[ISketchSlot Members](#)
[ISketchSlot.Length Property](#)
[ISketchSlot.LengthType Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0