

SOLIDWORKS API (.NET, VBA, C#) — Reference (286/337): ISldWorks (part 6 of 8)

SOLIDWORKS API Documentation (converted from CHM)

ISldWorks (part 6 of 8) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsRapidDraft Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : IsRapidDraft Method (ISldWorks)

Gets whether the specified drawing file is in SOLIDWORKS Detached format.

.NET Syntax

Visual Basic (Declaration)

```
Function IsRapidDraft( _  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim value As System.Boolean  
  
value = instance.IsRapidDraft(FileName)
```

C#

```
System.bool IsRapidDraft(  
    System.string FileName  
)
```

C++/CLI

```
System.bool IsRapidDraft(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Name of the drawing file

Return Value

True if the file is in RapidDraft format, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks.IsRapidDraft](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsSame Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : IsSame Method (ISldWorks)

Gets whether the two specified objects are the same object.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IsSame( _  
    ByVal Object1 As System.Object, _  
    ByVal Object2 As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Object1 As System.Object  
Dim Object2 As System.Object  
Dim value As System.Integer  
  
value = instance.IsSame(Object1, Object2)
```

C#

```
System.int IsSame(  
    System.object Object1,  
    System.object Object2  
)
```

C++/CLI

```
System.int IsSame(  
& System.Object^ Object1,  
& System.Object^ Object2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Object1
Object
Object2
Object

Return Value

Object equality as defined by [swObjectEquality](#).

Visual Basic for Applications (VBA) Syntax

See [SldWorks::IsSame](#).

Example

[Compare Selected Objects and Their Persistent Reference IDs \(VB.NET\)](#)
[Compare Selected Objects and Their Persistent Reference IDs \(VBA\)](#)
[Compare Selected Objects and Their Persistent Reference IDs \(C#\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[IModelDocExtension::IsSamePersistentID Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsTaskPaneExpanded Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : IsTaskPaneExpanded Method (ISldWorks)

Gets whether the Task Pane is expanded.

.NET Syntax

Visual Basic (Declaration)

```
Function IsTaskPaneExpanded() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Boolean  
  
value = instance.IsTaskPaneExpanded()
```

C#

```
System.bool IsTaskPaneExpanded()
```

C++/CLI

```
System.bool IsTaskPaneExpanded();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the Task Pane is expanded, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::IsTaskPaneExpanded](#).

Example

[Create Task Pane View Add-in \(C#\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ITaskpaneView::IsActiveTab Method \(\)](#)
[ISldWorks::IsTaskPaneVisible Method \(\)](#)

Availability

SOLIDWORKS 2024 SP02, Revision Number 32.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsTaskPaneVisible Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : IsTaskPaneVisible Method (ISldWorks)

Gets whether the Task Pane is visible.

.NET Syntax

Visual Basic (Declaration)

```
Function IsTaskPaneVisible() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Boolean  
  
value = instance.IsTaskPaneVisible()
```

C#

```
System.bool IsTaskPaneVisible()
```

C++/CLI

```
System.bool IsTaskPaneVisible();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the Task Pane is visible, false if not

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::IsTaskPaneVisible](#).

Example

[Create Task Pane View Add-in \(C#\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ITaskpaneView::IsActiveTab Method \(\)](#)
[ISldWorks::IsTaskPaneExpanded Method \(\)](#)

Availability

SOLIDWORKS 2024 SP02, Revision Number 32.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

IVersionHistory Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : IVersionHistory Method (ISldWorks)

Gets a list of strings indicating the versions in which a model was saved.

.NET Syntax

Visual Basic (Declaration)

```
Function IVersionHistory( _  
    ByVal FileName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim value As System.String  
  
value = instance.IVersionHistory(FileName)
```

C#

```
System.string IVersionHistory(  
    System.string FileName  
)
```

C++/CLI

```
System.String^ IVersionHistory(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Full path name of the model for which to get the version history

Return Value

Array of strings of the version history

Visual Basic for Applications (VBA) Syntax

See [SldWorks::IVersionHistory](#).

Remarks

This information is retrieved from the file on disk, not from the open document.

There is one array entry for each major release of the SOLIDWORKS Design software in which the document has been saved. The format for each entry is a major release code followed by one or more minor release codes separated by commas:

<major release code>[<minor release code>]

- or -

<major release code>[<minor release code>,<minor release code>...]

where <major release code> equals a number that remains constant through a major release of the SOLIDWORKS Design software. For example, the following values are returned based on the corresponding major SOLIDWORKS Design version:

SOLIDWORKS Release	Version Number
SOLIDWORKS 95	44
SOLIDWORKS 96	243
SOLIDWORKS 97	483
SOLIDWORKS 97Plus	629
SOLIDWORKS 98	822
SOLIDWORKS 98Plus	1008
SOLIDWORKS 99	1137
SOLIDWORKS 2000	1500
SOLIDWORKS 2001	1750
SOLIDWORKS 2001Plus	1950
SOLIDWORKS 2003	2200
SOLIDWORKS 2004	2500
SOLIDWORKS 2005	2800
SOLIDWORKS 2006	3100
SOLIDWORKS 2007	3400
SOLIDWORKS 2008	3800
SOLIDWORKS 2009	4100
SOLIDWORKS 2010	4400
SOLIDWORKS 2011	4700
SOLIDWORKS 2012	5000
SOLIDWORKS 2013	6000
SOLIDWORKS 2014	7000

SOLIDWORKS 2015	8000
SOLIDWORKS 2016	9000
SOLIDWORKS 2017	10000
SOLIDWORKS 2018	11000
SOLIDWORKS 2019	12000
SOLIDWORKS 2020	13000
SOLIDWORKS 2021	14000
SOLIDWORKS 2022	15000
SOLIDWORKS 2023	16000
SOLIDWORKS 2024	17000
SOLIDWORKS 2025	18000
SOLIDWORKS 2026	19000

The <minor release code> equals the year and day of manufacture of a saving version (for example, 1997/320).

To get the size of array needed by this method, call [ISldWorks::IGetVersionHistoryCount](#). If the file is not found or an error occurs, then SldWorks::IGetVersionHistoryCount returns 0, and this method returns VT_EMPTY.

To get the version history of a document that is currently open, use [IModelDoc2::VersionHistory](#).

 See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::VersionHistory Method](#)
[ISldWorks::GetBuildNumbers2 Method](#)
[IModelDocExtension::IsFutureVersion Method](#)

 Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoadAddIn Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : LoadAddIn Method (ISldWorks)

Loads the specified add-in in SOLIDWORKS.

 .NET Syntax

Visual Basic (Declaration)

```
Function LoadAddIn( _  
    ByVal FileName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim value As System.Integer  
  
value = instance.LoadAddIn(FileName)
```

C#

```
System.int LoadAddIn(  
    System.string FileName  
)
```

C++/CLI

```
System.int LoadAddIn(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Fully qualified file name of the add-in

Return Value

Status of loading the add-in as defined in [swLoadAddinError_e](#)

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::LoadAddIn](#).

Example

[Load and Unload Add-in \(C#\)](#)
[Load and Unload Add-in \(VB.NET\)](#)
[Load and Unload Add-in \(VBA\)](#)

Remarks

You cannot load MBD using its add-in path. Instead, load the MBD add-in as follows:

```
status = swApp.LoadAddIn('MBD')
```

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::UnloadAddIn Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoadAdminSettingsFile Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : LoadAdminSettingsFile Method (ISldWorks)

Loads the specified *.sldsettings file into [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function LoadAdminSettingsFile( _  
    ByVal FilePath As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FilePath As System.String  
Dim value As System.Integer  
  
value = instance.LoadAdminSettingsFile(FilePath)
```

C#


```
System.int LoadAdminSettingsFile(  
    System.string FilePath  
)
```

C++/CLI

```
System.int LoadAdminSettingsFile(  
& System.String^ FilePath  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilePath

Full local path name of the *.sldsettings file to load

Return Value

True if settings successfully applied, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::LoadAdminSettingsFile](#).

Remarks

The 3DEXPERIENCE platform Admin authors the *.sldsettings platform file with settings appropriate for SOLIDWORKS Design connected to the 3DEXPERIENCE platform. At launch, SOLIDWORKS Design connected to the 3DEXPERIENCE platform reads a local copy. This method is used primarily by the 3DEXPERIENCE Add-in.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::RestoreSettings Method \(\)](#)
[ISldWorks::SaveSettings Method \(\)](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoadFile Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : LoadFile Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::LoadFile4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function LoadFile(  
    ByVal FileName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim value As System.Boolean
```

```
value = instance.LoadFile(FileName)
```

C#

```
System.bool LoadFile(  
    System.string FileName  
)
```

C++/CLI

```
System.bool LoadFile(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Visual Basic for Applications (VBA) Syntax

See [SldWorks::LoadFile](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

LoadFile2 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : LoadFile2 Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::LoadFile4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function LoadFile2( _  
    ByVal FileName As System.String, _  
    ByVal ArgString As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim ArgString As System.String  
Dim value As System.Boolean
```

```
value = instance.LoadFile2(FileName, ArgString)
```

C#

```
System.bool LoadFile2(  
    System.string FileName,  
    System.string ArgString  
)
```

C++/CLI

```
System.bool LoadFile2(  
& System.String^ FileName,  
& System.String^ ArgString  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

ArgString

Visual Basic for Applications (VBA) Syntax

See [SldWorks::LoadFile2](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

LoadFile3 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : LoadFile3 Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::LoadFile4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function LoadFile3( _  
    ByVal FileName As System.String, _  
    ByVal ArgString As System.String, _  
    ByVal ImportData As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim ArgString As System.String  
Dim ImportData As System.Object  
Dim value As System.Boolean
```

```
value = instance.LoadFile3(FileName, ArgString, ImportData)
```

C#

```
System.bool LoadFile3(  
    System.string FileName,  
    System.string ArgString,  
    System.object ImportData  
)
```

C++/CLI

```
System.bool LoadFile3(  
& System.String^ FileName,  
& System.String^ ArgString,  
& System.Object^ ImportData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

ArgString

ImportData

Visual Basic for Applications (VBA) Syntax

See [SldWorks::LoadFile3](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

LoadFile4 Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : LoadFile4 Method (ISldWorks)

Loads a third-party native CAD file into a new SOLIDWORKS document using 3D Interconnect.

.NET Syntax

Visual Basic (Declaration)

```
Function LoadFile4( _  
    ByVal FileName As System.String, _  
    ByVal ArgString As System.String, _  
    ByVal ImportData As System.Object, _  
    ByRef Errors As System.Integer _  
) As ModelDoc2
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim ArgString As System.String  
Dim ImportData As System.Object  
Dim Errors As System.Integer  
Dim value As ModelDoc2  
  
value = instance.LoadFile4(FileName, ArgString, ImportData, Errors)
```

C#

```
ModelDoc2 LoadFile4(  
    System.string FileName,  
    System.string ArgString,  
    System.object ImportData,  
    out System.int Errors  
)
```

C++/CLI

```
ModelDoc2^ LoadFile4(  
& System.String^ FileName,  
& System.String^ ArgString,  
& System.Object^ ImportData,  
& [Out] System.int Errors  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Full path and file name of the third-party native CAD part or assembly document to import (see **Remarks**)

ArgString

Space-separated string that allows optional arguments to be specified when opening a third-party native CAD file; empty string if 3D Interconnect is enabled (see **Remarks**)

ImportData

[ImportIgesData](#), [ImportDxfDwgData](#), or [ImportStepData](#) object; null or Nothing if 3D Interconnect is not enabled (see **Remarks**)

Errors

Errors as defined in [swFileLoadError_e](#)

Return Value

[Model document](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::LoadFile4](#).

Example

[Import DXF File Into Part Sketch \(VBA\)](#)
[Import IGES File \(VBA\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(C#\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VB.NET\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VBA\)](#)
[Use 3D Interconnect to Import Third-Party Native CAD Files \(C#\)](#)

Remarks

This method:

- Uses 3D Interconnect to load FileName into a new SOLIDWORKS document. Before calling this method, turn on 3D Interconnect by setting **Tools > Options > System Options > Import > Enable 3D Interconnect** or calling [ISldWorks::SetUserPreferenceToggle\(swUserPreferenceToggle_e.swMultiCAD_Enable3DInterconnect, True\)](#). With 3D Interconnect enabled, this method supports the following third-party native CAD formats and versions:
 - ACIS: .sat, .sab, .asat, .asab for r1 - 2018 1.0
 - Autodesk® Inventor: .ipt for V6-V2018, .iam for V11 - V2018
 - CATIA® V5: .CATPart, .CATProduct for V5R8 - V5-6R2017
 - IGES: .igs, .iges for up to 5.3
 - JT: .jt for JT 8.x, 9.x, and 10.x
 - PTC®: .prt, .prt.*, .asm.* for Pro/ENGINEER® 16 - Creo 4.0
 - Solid Edge®: .par, .asm, .psm for V18 - ST10
 - STEP: .stp, .step for AP203, AP214, AP24
 - NX® software: .prt for UG 11 - NX 11
- Imports FileName into the appropriate native SOLIDWORKS part or assembly.
 - For parts, the SOLIDWORKS file created is a copy of the original non-native file. The copy retains an external reference to the original CAD file. If the original third-party native file is modified in its original application, the SOLIDWORKS copy can be updated to import those changes. Changes to the SOLIDWORKS copy do not propagate back to the original file.
 - For assemblies, you must save the new SOLIDWORKS assembly in order for SOLIDWORKS to import the third-party native assembly and create the copy. Only after saving the new SOLIDWORKS assembly can you edit the imported top-level assembly or break its reference link. Editing lower-level components of the imported top-level assembly or individually breaking their reference links is not supported.
 - See the [Import3DInterconnectData](#) Remarks for information about editing imported CAD data and breaking reference links to third-party native CAD parts and assemblies.
- Imports the geometry as a featureless solid body.
- Does not import FileName into any existing SOLIDWORKS file or the active document. To import a third-party native CAD file into an existing SOLIDWORKS:
 - Part, use [IPartDoc::InsertImportedFeature](#).
 - Assembly, use [IAssemblyDoc::InsertImportedComponent](#).
- Imports third-party native CAD files using different behavior if 3D Interconnect is not enabled:

If 3D Interconnect is not enabled and you are importing...

Then...

Third-party native CAD files

Set ArgString to **FWNS** to display a FeatureWorks dialog after opening.

Pro/E files

- To import features, set ArgString to **R**
- To import geometry, set ArgString to:
 - **B** Direct geometry import with knitting
 - **C** Direct geometry import without knitting
 - **D** Geometry import with knitting
 - **E** Geometry import without knitting
 - **S** Surface geometry import with knitting

These arguments are case sensitive. Specifying one of these options suppresses dialog.

Non DXF/DWG and Non Pro/E files

- To import the foreign file into a new SOLIDWORKS document, set ArgString to **r**.
For example, to import an IGES file named **cup.igs** into a new SOLIDWORKS document:
Set swModel = swApp.LoadFile4 "D:\Samples\cup.IGS", "r", importData, Err.
See [IImportIgesData](#) for details about importing IGES data.

NOTES:

- Whether the result is a surface or solid depends on the import options. See [Import and Export File Options](#) for details.
- If ArgString is set to an empty string, then dialogs may be presented to the end-user during translation.

DXF/DWG files

You can:

- Let SOLIDWORKS determine the default values:
 - Paper size and sheet scale are computed to fit the input data.
 - Length unit is determined from the header of the input DXF/DWG file.
 - Sheet name is the same as the layout name in the input DXF/DWG file.
- or -

- Set your own values by using:

1. [ISldWorks::GetImportFileData](#) to obtain the IImportDxfDwgData interface.

2. Use the following methods with a Sheet argument of "" (an empty string) to set up your defaults before loading the file:

- [IImportDxfDwgData::GetPaperSize](#)
- [IImportDxfDwgData::GetPosition](#)
- [IImportDxfDwgData::GetSheetScale](#)
- [IImportDxfDwgData::ImportMethod](#)
- [IImportDxfDwgData::LengthUnit](#)
- [IImportDxfDwgData::SetPaperSize](#)
- [IImportDxfDwgData::SetPosition](#)
- [IImportDxfDwgData::SetSheetScale](#)
- [IImportDxfDwgData::SheetName](#)

See [IImportDxfDwgData](#) for details about importing DXF/DWG data.

NOTES:

- Getting the IImportDxfDwgData interface does not get default values from the input file. Any values not set by you are set to the values computed by SOLIDWORKS.
- If the DWG/DXF file has multiple sheets, use these methods with a valid layout name in the Sheet argument to set up sheet specific settings, which overrides the default settings. If any of the individual items are not specified for a given layout name, the value used is from the defaults (layout name ""). If the default value is not specified, SOLIDWORKS computes and uses a meaningful value for that item.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::OpenDoc6 Method](#)
[IFeatureManager::InsertDwgOrDxfFile2 Method](#)

Availability

SOLIDWORKS 2006 SP1, Revision Number 14.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

MoveDocument Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : MoveDocument Method (ISldWorks)

Moves a document and optionally updates references to it.

.NET Syntax

Visual Basic (Declaration)

```
Function MoveDocument( _  
    ByVal SourceDoc As System.String, _  
    ByVal DestDoc As System.String, _  
    ByVal FromChildren As System.Object, _  
    ByVal ToChildren As System.Object, _  
    ByVal Option As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim SourceDoc As System.String  
Dim DestDoc As System.String  
Dim FromChildren As System.Object  
Dim ToChildren As System.Object  
Dim Option As System.Integer  
Dim value As System.Integer
```

```
value = instance.MoveDocument(SourceDoc, DestDoc, FromChildren, ToChildren, Option)
```

C#

```
System.int MoveDocument(  
    System.string SourceDoc,  
    System.string DestDoc,  
    System.object FromChildren,  
    System.object ToChildren,  
    System.int Option  
)
```

C++/CLI

```
System.int MoveDocument(  
& System.String^ SourceDoc,  
& System.String^ DestDoc,  
& System.Object^ FromChildren,  
& System.Object^ ToChildren,  
& System.int Option  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SourceDoc

Full path and filename of the document to move

DestDoc

Full path and filename of the new document to which to move the document specified for SourceDoc

FromChildren

Array of strings containing the full path and filenames of the child documents dependent on the document specified for SourceDoc

ToChildren

Array of strings containing the new full path and filenames for the child documents to which to move the documents specified for FromChildren

Option

Move options as defined by [swMoveCopyOptions_e](#)

Return Value

Success or error code as defined by [swMoveCopyError_e](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::MoveDocument](#).

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::IMoveDocument Method](#)

[ISldWorks::ICopyDocument Method](#)

[ISldWorks::CopyDocument Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

NewAssembly Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : NewAssembly Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::NewDocument](#) and [ISldWorks::INewDocument2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function NewAssembly() As System.Object
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As ISldWorks  
Dim value As System.Object  
  
value = instance.NewAssembly()
```

C#

```
System.object NewAssembly()
```

C++/CLI

```
System.Object^ NewAssembly();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SldWorks::NewAssembly](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

NewDocument Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : NewDocument Method (ISldWorks)

Creates a new document based on the specified template.

.NET Syntax

Visual Basic (Declaration)

```
Function NewDocument( _  
    ByVal TemplateName As System.String, _  
    ByVal PaperSize As System.Integer, _  
    ByVal Width As System.Double, _  
    ByVal Height As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim TemplateName As System.String  
Dim PaperSize As System.Integer  
Dim Width As System.Double  
Dim Height As System.Double  
Dim value As System.Object  
  
value = instance.NewDocument(TemplateName, PaperSize, Width, Height)
```

C#

```
System.object NewDocument(  
    System.string TemplateName,  
    System.int PaperSize,  
    System.double Width,  
    System.double Height  
)
```

C++/CLI

```
System.Object^ NewDocument(  
& System.String^ TemplateName,  
& System.int PaperSize,
```



```
& System.double Width,  
& System.double Height  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TemplateName

Fully qualified path and name of the template to use for creating the new document

PaperSize

Size of paper as defined in [swDwgPaperSizes_e](#)

Width

Width of paper; used only when PaperSize is swDwgPapersUserDefined

Height

Height of paper; used only when PaperSize is swDwgPapersUserDefined

Return Value

Newly created [document](#) or NULL if the operation fails

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::NewDocument](#).

Example

[Combine Assembly Components Into Part \(VBA\)](#)
[Dimension Edge in Drawing \(VBA\)](#)
[Insert Conic Curve \(C#\)](#)
[Insert Conic Curve \(VB.NET\)](#)
[Insert Conic Curve \(VBA\)](#)
[Insert Model Annotations \(C#\)](#)
[Insert Model Annotations \(VB.NET\)](#)
[Insert Model Annotations \(VBA\)](#)
[Process Body \(C#\)](#)
[Process Body \(VB.NET\)](#)
[Process Body \(VBA\)](#)
[Fill Holes in Part \(C#\)](#)
[Fill Holes in Part \(VB.NET\)](#)
[Fill Holes in Part \(VBA\)](#)

Remarks

To get the default template filename, use [ISldWorks::GetUserPreferenceStringValue](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetDocumentTemplate Method](#)
[ISldWorks::NewDocument2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NewDrawing Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : NewDrawing Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::NewDocument](#) and [ISldWorks::NewDocument2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function NewDrawing( _  
    ByVal TemplateToUse As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim TemplateToUse As System.Integer
Dim value As System.Object

value = instance.NewDrawing(TemplateToUse)
```

C#

```
System.Object NewDrawing(
    System.int TemplateToUse
)
```

C++/CLI

```
System.Object^ NewDrawing(
    & System.int TemplateToUse
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TemplateToUse

Visual Basic for Applications (VBA) Syntax

See [SldWorks::NewDrawing](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

NewDrawing2 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : NewDrawing2 Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::NewDocument](#) and [ISldWorks::INewDocument2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function NewDrawing2( _
    ByVal TemplateToUse As System.Integer, _
    ByVal TemplateName As System.String, _
    ByVal PaperSize As System.Integer, _
    ByVal Width As System.Double, _
    ByVal Height As System.Double _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim TemplateToUse As System.Integer
Dim TemplateName As System.String
Dim PaperSize As System.Integer
Dim Width As System.Double
Dim Height As System.Double
Dim value As System.Object

value = instance.NewDrawing2(TemplateToUse, TemplateName, PaperSize, Width, Height)
```

C#

```
System.object NewDrawing2(
    System.int TemplateToUse,
    System.string TemplateName,
    System.int PaperSize,
    System.double Width,
    System.double Height
)
```

C++/CLI

```
System.Object^ NewDrawing2(
    & System.int TemplateToUse,
    & System.String^ TemplateName,
    & System.int PaperSize,
    & System.double Width,
    & System.double Height
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TemplateToUse

TemplateName

PaperSize

Width

Height

Visual Basic for Applications (VBA) Syntax

See [SldWorks::NewDrawing2](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

NewPart Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : NewPart Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::NewDocument](#) and [ISldWorks::INewDocument2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function NewPart() As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISldWorks
Dim value As System.Object

value = instance.NewPart()
```

C#

```
System.object NewPart()
```

C++/CLI

```
System.Object^ NewPart();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).



Visual Basic for Applications (VBA) Syntax

See [ISldWorks::NewPart](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

OpenDoc Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : OpenDoc Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::OpenDoc6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function OpenDoc( _  
    ByVal Name As System.String, _  
    ByVal Type As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Name As System.String  
Dim Type As System.Integer  
Dim value As System.Object  
  
value = instance.OpenDoc(Name, Type)
```

C#

```
System.object OpenDoc(  
    System.string Name,  
    System.int Type  
)
```

C++/CLI

```
System.Object^ OpenDoc(  
& System.String^ Name,  
& System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Type

Visual Basic for Applications (VBA) Syntax

See [SldWorks::OpenDoc](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

OpenDoc2 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : [OpenDoc2 Method \(ISldWorks\)](#)

Obsolete. Superseded by [ISldWorks::OpenDoc6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function OpenDoc2( _  
    ByVal FileName As System.String, _  
    ByVal Type As System.Integer, _  
    ByVal ReadOnly As System.Boolean, _  
    ByVal ViewOnly As System.Boolean, _  
    ByVal Silent As System.Boolean, _  
    ByRef Errors As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim Type As System.Integer  
Dim ReadOnly As System.Boolean  
Dim ViewOnly As System.Boolean  
Dim Silent As System.Boolean  
Dim Errors As System.Integer  
Dim value As System.Object  
  
value = instance.OpenDoc2(FileName, Type, ReadOnly, ViewOnly, Silent, Errors)
```

C#

```
System.object OpenDoc2(  
    System.string FileName,  
    System.int Type,  
    System.bool ReadOnly,  
    System.bool ViewOnly,  
    System.bool Silent,  
    out System.int Errors  
)
```

C++/CLI

```
System.Object^ OpenDoc2(  
& System.String^ FileName,  
& System.int Type,  
& System.bool ReadOnly,  
& System.bool ViewOnly,  
& System.bool Silent,  
& [Out] System.int Errors  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Type

ReadOnly

ViewOnly

Silent

Errors

Visual Basic for Applications (VBA) Syntax

See [SldWorks::OpenDoc2](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

OpenDoc3 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : OpenDoc3 Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::OpenDoc6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function OpenDoc3( _  
    ByVal FileName As System.String, _  
    ByVal Type As System.Integer, _  
    ByVal ReadOnly As System.Boolean, _  
    ByVal ViewOnly As System.Boolean, _  
    ByVal RapidDraft As System.Boolean, _  
    ByVal Silent As System.Boolean, _  
    ByRef Errors As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim Type As System.Integer  
Dim ReadOnly As System.Boolean  
Dim ViewOnly As System.Boolean  
Dim RapidDraft As System.Boolean  
Dim Silent As System.Boolean  
Dim Errors As System.Integer  
Dim value As System.Object  
  
value = instance.OpenDoc3(FileName, Type, ReadOnly, ViewOnly, RapidDraft, Silent, Errors)
```

C#

```
System.object OpenDoc3(  
    System.string FileName,  
    System.int Type,  
    System.bool ReadOnly,  
    System.bool ViewOnly,  
    System.bool RapidDraft,  
    System.bool Silent,  
    out System.int Errors  
)
```

C++/CLI

```
System.Object^ OpenDoc3(  
& System.String^ FileName,  
& System.int Type,  
& System.bool ReadOnly,  
& System.bool ViewOnly,  
& System.bool RapidDraft,  
& System.bool Silent,  
& [Out] System.int Errors  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Type

ReadOnly
ViewOnly
RapidDraft
Silent
Errors

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::OpenDoc3](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

OpenDoc4 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : OpenDoc4 Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::OpenDoc6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function OpenDoc4( _  
    ByVal FileName As System.String, _  
    ByVal Type As System.Integer, _  
    ByVal Options As System.Integer, _  
    ByVal Configuration As System.String, _  
    ByRef Errors As System.Integer _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim Type As System.Integer  
Dim Options As System.Integer  
Dim Configuration As System.String  
Dim Errors As System.Integer  
Dim value As System.Object  
  
value = instance.OpenDoc4(FileName, Type, Options, Configuration, Errors)
```

C#

```
System.object OpenDoc4(  
    System.string FileName,  
    System.int Type,  
    System.int Options,  
    System.string Configuration,  
    out System.int Errors  
)
```

C++/CLI

```
System.Object^ OpenDoc4(  
& System.String^ FileName,  
& System.int Type,  
& System.int Options,  
& System.String^ Configuration,  
& [Out] System.int Errors  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Type

Options

Configuration

Errors

Visual Basic for Applications (VBA) Syntax

See [SldWorks::OpenDoc4](#).

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

OpenDoc6 Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : OpenDoc6 Method (ISldWorks)

Opens an existing document and returns a pointer to the document object.

.NET Syntax

Visual Basic (Declaration)

```
Function OpenDoc6( _  
    ByVal FileName As System.String, _  
    ByVal Type As System.Integer, _  
    ByVal Options As System.Integer, _  
    ByVal Configuration As System.String, _  
    ByRef Errors As System.Integer, _  
    ByRef Warnings As System.Integer _  
    ) As ModelDoc2
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim Type As System.Integer  
Dim Options As System.Integer  
Dim Configuration As System.String  
Dim Errors As System.Integer  
Dim Warnings As System.Integer  
Dim value As ModelDoc2  
  
value = instance.OpenDoc6(FileName, Type, Options, Configuration, Errors, Warnings)
```

C#

```
ModelDoc2 OpenDoc6(  
    System.string FileName,  
    System.int Type,  
    System.int Options,  
    System.string Configuration,  
    out System.int Errors,  
    out System.int Warnings  
)
```

C++/CLI

```
ModelDoc2^ OpenDoc6(  
& System.String^ FileName,
```



```

& System.int Type,
& System.int Options,
& System.String^ Configuration,
& [Out] System.int Errors,
& [Out] System.int Warnings
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Document name or full path if not in current directory, including extension

Type

Document type as defined in [swDocumentTypes_e](#)

Options

Mode in which to open the document as defined in [swOpenDocOptions_e](#)

Configuration

Model configuration in which to open this document

- Applies to parts and assemblies, not drawings
- If this argument is empty or the specified configuration is not present in the model, the model is opened in the last-used configuration

Errors

Load errors as defined in [swFileLoadError_e](#) (See **Remarks**)

Warnings

Warnings or extra information generated during the open operation as defined in [swFileLoadWarning_e](#)

Return Value

Newly loaded [model document](#) or NULL if document failed to open

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::OpenDoc6](#).

Example

[Add Component and Mate \(C++\)](#)
[Open Document \(VBA\)](#)
[Open Document Silently \(VBA\)](#)
[Open Assembly in Large Design Review Mode \(VBA\)](#)
[Open Assembly in Large Design Review Mode \(VB.NET\)](#)
[Open Assembly in Large Design Review Mode \(C#\)](#)
[Switch Documents \(C#\)](#)
[Switch Documents \(VB.NET\)](#)
[Switch Documents \(VBA\)](#)

Remarks

As of SOLIDWORKS 2020 SP03.1, SOLIDWORKS Design works on the **3DEXPERIENCE** platform as [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#). Use [ISldWorks::OpenDoc7](#) to open documents with SOLIDWORKS Design connected to the 3DEXPERIENCE platform.

As of SOLIDWORKS 2012 SP5, loading future file versions is supported, and `ISldWorks::OpenDoc6` no longer throws a [swFileLoadError_e.swFutureVersion](#) error. Use [IModelDocExtension::IsFutureVersion](#) to determine whether a component is for a future version of SOLIDWORKS.

As of SOLIDWORKS 2008, [ISldWorks::OpenDoc7](#) performs the same work as this method, but also:

- Allows you to open a document with a specified display state.
- Uses [IDocumentSpecification](#) to specify input parameters.

This method also allows control over whether to:

- Suppress displaying dialog boxes
- Open the document read-only
- Open the document in Large Design Review mode
- Convert a drawing to a detached drawing

When opening a parent document (assembly, drawing, and so on):

- SOLIDWORKS Design also opens any additional documents that are referenced in the parent document (parts, subassemblies, and so on).
- SOLIDWORKS Design follows certain rules in trying to locate its referenced documents. If explicit Search Folders have not been set using **Tools, Options, System Options, ExternalReferences**, then the first place SOLIDWORKS Design looks for the referenced documents is in the current working directory. If SOLIDWORKS Design finds the referenced file in the current working directory, then it is loaded from that directory.

Calling `ISldWorks::OpenDoc6` does not change the current working directory to that of the opened file, whereas, interactively using the File Oper dialog box does. This may affect documents with references.

Because the user may have interactively opened files from some random directory, you cannot be certain that the current working directory is pointing to the desired location. This may affect the referenced documents that ultimately get loaded when using `ISldWorks::OpenDoc6` versus performing File Open interactively. You may want to set the current working directory before calling `ISldWorks::OpenDoc6`. This can be done using the [ISldWorks::SetCurrentWorkingDirectory](#) method. To mimic the behavior of the File Open dialog, you set the current working directory to that of the file being opened.

When opening files that contain references, you may also want to consider the current Search Folder settings because they may affect the references that ultimately get loaded. This can be done using [ISldWorks::GetSearchFolders](#) and [ISldWorks::SetSearchFolders](#). If Search Folders are currently in use, SOLIDWORKS Design looks for references in the Search Folders before trying to locate references in the current working directory.

If this method successfully opens an assembly, it still returns `swFileLoadError_e.swFileNotFoundError` in `Errors` if a referenced component file cannot be located.

`ISldWorks::OpenDoc6` does not activate and display the document if the file is already open in memory in an assembly or drawing. However, `ISldWorks::OpenDoc6` should return a valid [IModelDoc2](#) pointer that is usable with functions that do not require a document to be displayed. If you want, [ISldWorks::ActivateDoc2](#) or [ISldWorks::IActivateDoc3](#) will activate and display the document. Because calling `ISldWorks::OpenDoc6` does not activate nor display the file, calling the [ISldWorks::ActiveDoc](#) or [ISldWorks::IActiveDoc2](#) property will not return a pointer to this document.

This method fires the the SOLIDWORKS event [FileOpenNotify2](#) event. Also, the SOLIDWORKS event [ActiveDocChangeNotify](#) and [ActiveModelDocChangeNotify](#) events are sent if the file being loaded is not already open as the active document.

TIPS

To...	Then...
Open an assembly in Large Design Review mode	Set the Options argument to <code>swOpenDocOptions_LDR_EditAssembly</code> . This option opens large assemblies in edit mode without actually loading them. This is useful for conducting a quick walk-through of a large assembly. Call IAssemblyDoc::SelectiveOpen to open selected components after an assembly has been opened in Large Design Review mode.
Avoid warnings when opening the document	Set the Options argument to <code>swOpenDocOptions_Silent</code> . The software uses the last-displayed configuration if it discovers missing configurations or component references.
Open a library feature part	Set the Type argument to <code>swDocPART</code> .
Open foreign files (IGES, STEP, and so on)	Use ISldWorks::LoadFile4 .
Avoid a warning when opening shaded models in views	Set the Options argument to <code>swOpenDocOptions_LoadModel</code> . This option loads the model so that the view comes in shaded automatically.
Avoid large increases in memory usage caused when adding parts to assemblies	Opening a model causes SceneGraph to display the model. SceneGraph uses maps with defaults sizes of 2MB - 3MB for even the simplest model. And, assemblies and parts do not share the same SceneGraph buffer. To avoid large increases in your memory usage: 1. Set the document to invisible. 2. Open the parts. 3. Set the document to visible. 4. Add the part to the assembly. See ISldWorks::DocumentVisible for details.
Open a document with a specified display state	Use <code>ISldWorks::OpenDoc7</code> .

A warning is displayed if you [open a Detached drawing](#) without loading the model, and the model was saved since the drawing was last saved.

This method honors:

- [ISldWorks::GetUserPreferenceToggle](#) `swLargeAsmModeEnabled`
- and -
- [ISldWorks::SetUserPreferenceToggle](#) `swLargeAsmModeEnabled, true/false` (NOTE: if this toggle is set to true, then the file opens in lightweight mode)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::CloseAllDocuments Method](#)
[ISldWorks::CloseDoc Method](#)
[ISldWorks::CopyDocument Method](#)
[ISldWorks::EnumDocuments2 Method](#)
[ISldWorks::GetCurrentWorkingDirectory Method](#)
[ISldWorks::GetDataFolder Method](#)
[ISldWorks::GetDocumentDependencies2 Method](#)

[ISldWorks::GetFirstDocument Method](#)
[ISldWorks::GetOpenDocument Method](#)
[ISldWorks::GetOpenDocumentByName Method](#)
[ISldWorks::GetOpenedFileInfo Method](#)
[ISldWorks::GetOpenFileName Method](#)
[ISldWorks::GetRecentFiles Method](#)
[ISldWorks::ICopyDocument Method](#)
[ISldWorks::IGetDocumentDependencies2 Method](#)
[ISldWorks::IGetFirstDocument2 Method](#)
[ISldWorks::IGetOpenDocumentByName2 Method](#)
[ISldWorks::IMoveDocument Method](#)
[ISldWorks::PreviewDoc Method](#)
[ISldWorks::PreviewDocx64 Method](#)
[ISldWorks::QuitDoc Method](#)
[ISldWorks::SetPromptFilename Method](#)
[ISldWorks::EnableBackgroundProcessing Property](#)
[ISldWorks::IsBackgroundProcessingCompleted Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OpenDoc7 Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : OpenDoc7 Method (ISldWorks)

Opens an existing document and returns a pointer to the document object.

.NET Syntax

Visual Basic (Declaration)

```
Function OpenDoc7( _  
    ByVal Specification As System.Object _  
) As ModelDoc2
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Specification As System.Object  
Dim value As ModelDoc2  
  
value = instance.OpenDoc7(Specification)
```

C#

```
ModelDoc2 OpenDoc7(  
    System.object Specification  
)
```

C++/CLI

```
ModelDoc2^ OpenDoc7(  
& System.Object^ Specification  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Specification
[Document specification](#)

Return Value

[Document](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::OpenDoc7](#).

Example

[Hide All Edges in Drawing \(VBA\)](#)
[Open Drawing Document Read-only \(VBA\)](#)
[Get Whether Components Are Loaded \(C#\)](#)

Remarks

As of SOLIDWORKS 2020 SP03.1, SOLIDWORKS Design can run on the **3DEXPERIENCE** platform as [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#). While running SOLIDWORKS Design connected to the 3DEXPERIENCE platform, this method can be called to either import local SOLIDWORKS documents or open **3DEXPERIENCE** documents. Inspect the Remarks section on each property of `IDocumentSpecification` to see whether it can be used to open a **3DEXPERIENCE** platform document. Also see [IDocumentSpecification::PLMObjectSpecification](#).

The following remarks apply primarily to SOLIDWORKS Design.

When opening a parent document (assembly, drawing, and so on):

- SOLIDWORKS Design also opens any additional documents that are referenced in the parent document (parts, subassemblies, and so on).
- SOLIDWORKS Design follows certain rules in trying to locate its referenced documents. If explicit Search Folders have not been set using **Tools, Options, System Options, ExternalReferences**, then the first place SOLIDWORKS Design looks for the referenced documents is in the current working directory. If SOLIDWORKS Design finds the referenced file in the current working directory, then it is loaded from that directory.

Calling `ISldWorks::OpenDoc7` does not change the current working directory to that of the opened file, whereas, interactively using the File Open dialog box does. This may affect documents with references.

Because the user may have interactively opened files from some random directory, you cannot be certain that the current working directory is pointing to the desired location. This may affect the referenced documents that ultimately get loaded when using `ISldWorks::OpenDoc7` versus performing File Open interactively. You may want to set the current working directory before calling `ISldWorks::OpenDoc7`. This can be done using the [ISldWorks::SetCurrentWorkingDirectory](#) method. To mimic the behavior of the File Open dialog, you set the current working directory to that of the file being opened.

When opening files that contain references, you may also want to consider the current Search Folder settings because they may affect the references that ultimately get loaded. This can be done using [ISldWorks::GetSearchFolders](#) and [ISldWorks::SetSearchFolders](#). If Search Folders are currently in use, SOLIDWORKS looks for references in the Search Folders before trying to locate references in the current working directory.

`ISldWorks::OpenDoc7` does not activate and display the document if the file is already open in memory in an assembly or drawing. However, `ISldWorks::OpenDoc7` should return a valid [IModelDoc2](#) pointer that is usable with functions that do not require a document to be displayed. If you want, [ISldWorks::ActivateDoc2](#) or [ISldWorks::IActivateDoc3](#) will activate and display the document. Because calling `ISldWorks::OpenDoc7` does not activate nor display the file, calling the [ISldWorks::ActiveDoc](#) or [ISldWorks::IActiveDoc2](#) property will not return a pointer to this document.

This method fires the SOLIDWORKS event [FileOpenNotify2](#) event. Also, the SOLIDWORKS event [ActiveDocChangeNotify](#) and [ActiveModelDocChangeNotify](#) events are sent if the file being loaded is not already open as the active document.

TIPS

To...

Open an assembly in Large Design Review mode

Avoid warnings when opening the document

Open a library feature part

Open foreign files (IGES, STEP, and so on)

Avoid a warning when opening shaded models in views

Avoid large increases in memory usage caused when adding parts to assemblies

Then...

Set [IDocumentSpecification::ViewOnly](#) to true. This option displays large assemblies without actually loading them. This is useful for conducting a quick walk-through of a large assembly. Call [IAssemblyDoc::SelectiveOpen](#) to open selected components after an assembly has been opened in Large Design Review mode.

Set [IDocumentSpecification::Silent](#) to true. The software uses the last-displayed configuration if it discovers missing configurations or component references.

Set [IDocumentSpecification::DocumentType](#) to [swDocumentTypes_e.swDocPART](#).

Use [ISldWorks::LoadFile4](#).

Set [IDocumentSpecification::LoadModel](#) to true. This option loads the model so that the view comes in shaded automatically.

Opening a model causes SceneGraph to display the model. SceneGraph uses maps with default sizes of 2MB - 3MB for even the simplest model. And, assemblies and parts do not share the same SceneGraph buffer. To avoid large increases in your memory usage:

1. Set the document to invisible.
2. Open the parts.
3. Set the document to visible.
4. Add the part to the assembly.

See [ISldWorks::DocumentVisible](#) for details.

To open a document without a specified display state

Use [ISldWorks::OpenDoc6](#).

A warning is displayed if you [open a Detached drawing](#) without loading the model, and the model was saved since the drawing was last saved.

This method honors:

- [ISldWorks::GetUserPreferenceToggle](#) swLargeAsmModeEnabled
- and -
- [ISldWorks::SetUserPreferenceToggle](#) swLargeAsmModeEnabled, true/false (NOTE: if this toggle is set to true, then the document opens in lightweight mode)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::CloseAllDocuments Method](#)
[ISldWorks::CloseDoc Method](#)
[ISldWorks::CopyDocument Method](#)
[ISldWorks::EnumDocuments2 Method](#)
[ISldWorks::GetCurrentWorkingDirectory Method](#)
[ISldWorks::GetDataFolder Method](#)
[ISldWorks::GetDocumentDependencies2 Method](#)
[ISldWorks::GetFirstDocument Method](#)
[ISldWorks::GetOpenDocument Method](#)
[ISldWorks::GetOpenDocumentByName Method](#)
[ISldWorks::GetRecentFiles Method](#)
[ISldWorks::ICopyDocument Method](#)
[ISldWorks::IGetDocumentDependencies2 Method](#)
[ISldWorks::IGetFirstDocument2 Method](#)
[ISldWorks::IGetOpenDocumentByName2 Method](#)
[ISldWorks::IMoveDocument Method](#)
[ISldWorks::PreviewDoc Method](#)
[ISldWorks::PreviewDocx64 Method](#)
[ISldWorks::QuitDoc Method](#)
[ISldWorks::SetPromptFilename Method](#)
[ISldWorks::IsBackgroundProcessingCompleted Method](#)
[ISldWorks::EnableBackgroundProcessing Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OpenDocSilent Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : OpenDocSilent Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::OpenDoc6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function OpenDocSilent( _  
    ByVal FileName As System.String, _  
    ByVal Type As System.Integer, _  
    ByRef Errors As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim Type As System.Integer  
Dim Errors As System.Integer  
Dim value As System.Object  
  
value = instance.OpenDocSilent(FileName, Type, Errors)
```

C#

```
System.object OpenDocSilent(
    System.string FileName,
    System.int Type,
    out System.int Errors
)
```

C++/CLI

```
System.Object^ OpenDocSilent(
    & System.String^ FileName,
    & System.int Type,
    & [Out] System.int Errors
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Type

Errors

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::OpenDocSilent](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

PasteAppearance Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : PasteAppearance Method (ISldWorks)

Applies to the specified entity an appearance that has been copied to the clipboard.

.NET Syntax

Visual Basic (Declaration)

```
Function PasteAppearance(
    ByVal Object As System.Object, _
    ByVal AppearanceTarget As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim Object As System.Object
Dim AppearanceTarget As System.Integer
Dim value As System.Boolean
```

```
value = instance.PasteAppearance(Object, AppearanceTarget)
```

C#

```
System.bool PasteAppearance(
    System.object Object,
    System.int AppearanceTarget
)
```

C++/CLI

```
System.bool PasteAppearance(
    & System.Object^ Object,
```

```
& System.int AppearanceTarget  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Object
[Face](#), [body](#), [feature](#), [component](#), or [part](#) to which to apply a copied appearance; if Null, the copied appearance is applied to an entity that is pre-selected in the graphics area
AppearanceTarget
Appearance target type as defined in [swAppearanceTargetType_e](#); only valid if Object is a face

Return Value

True if the copied appearance is successfully applied, false if not

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::PasteAppearance](#).

Example

[Copy and Paste Appearances \(VBA\)](#)
[Copy and Paste Appearances \(VB.NET\)](#)
[Copy and Paste Appearances \(C#\)](#)

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::CopyAppearance Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PostMessageToApplication Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : PostMessageToApplication Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::PostMessageToApplicationx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Posts a message to the application that invoked this method.

.NET Syntax

Visual Basic (Declaration)

```
Sub PostMessageToApplication( _  
    ByVal Cookie As System.Integer, _  
    ByVal UserData As System.Integer _  
)
```

Visual Basic (Usage)

```
Dim instance As ISldWorks  
Dim Cookie As System.Integer  
Dim UserData As System.Integer  
  
instance.PostMessageToApplication(Cookie, UserData)
```

C#



```
void PostMessageToApplication(  
    System.int Cookie,  
    System.int UserData  
)
```

C++/CLI

```
void PostMessageToApplication(  
& System.int Cookie,  
& System.int UserData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Cookie

Cookie specified in [ISwAddin::ConnectToSW](#)

UserData

Additional message-specific information defined by the application

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::PostMessageToApplication](#).

Example

Contact SOLIDWORKS API Support to obtain either the 32-bit or 64-bit version of **C++ 32-bit and 64-bit Add-ins Post Messages After Every Selection**.

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::AddCallback Method](#)

Availability

SOLIDWORKS 2010 SP1, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

PostMessageToApplicationx64 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : PostMessageToApplicationx64 Method (ISldWorks)

Posts a message to the application that invoked this method in 64-bit applications.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub PostMessageToApplicationx64( _  
    ByVal Cookie As System.Integer, _  
    ByVal UserData As System.Long _  
)
```

Visual Basic (Usage)

```
Dim instance As ISldWorks  
Dim Cookie As System.Integer
```




```
Dim UserData As System.Long

instance.PostMessageToApplicationx64(Cookie, UserData)
```

C#

```
void PostMessageToApplicationx64(
    System.int Cookie,
    System.long UserData
)
```

C++/CLI

```
void PostMessageToApplicationx64(
    & System.int Cookie,
    & System.int64 UserData
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Cookie

Cookie specified in [ISwAddin::ConnectToSW](#)

UserData

Additional message-specific information defined by the application

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::PostMessageToApplicationx64](#).

Remarks

This method is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software.

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::PostMessageToApplication Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PreSelectDwgTemplateSize Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : PreSelectDwgTemplateSize Method (ISldWorks)

Establishes which template to use when creating a drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub PreSelectDwgTemplateSize( _
    ByVal TemplateToUse As System.Integer, _
    ByVal TemplateName As System.String _
)
```

Visual Basic (Usage)

```
Dim instance As ISldWorks
Dim TemplateToUse As System.Integer
Dim TemplateName As System.String

instance.PreSelectDwgTemplateSize(TemplateToUse, TemplateName)
```



C#

```
void PreSelectDwgTemplateSize(  
    System.int TemplateToUse,  
    System.string TemplateName  
)
```

C++/CLI

```
void PreSelectDwgTemplateSize(  
& System.int TemplateToUse,  
& System.String^ TemplateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TemplateToUse

Type of template to use as defined in [swDwgTemplates_e](#)

TemplateName

Reserved for future use; use NULL

Visual Basic for Applications (VBA) Syntax

See [SldWorks::PreSelectDwgTemplateSize](#).

Remarks

By calling this method and specifying a template size, no dialog appears when the end-user interactively selects **File, New, Drawing**.

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::GetDocumentTemplate Method](#)

[ISldWorks::GetTemplateSizes Method](#)

[ISldWorks::IGetTemplateSizes Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

PresetNewDrawingParameters Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : PresetNewDrawingParameters Method (ISldWorks)

Presets the drawing template and sheet size parameters to avoid showing the **Sheet Format/Size** dialog when creating a new drawing document in the user-interface.

.NET Syntax

Visual Basic (Declaration)

```
Function PresetNewDrawingParameters( _  
    ByVal DrawingTemplate As System.String, _  
    ByVal ShowTemplate As System.Boolean, _  
    ByVal Width As System.Double, _  
    ByVal Height As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim DrawingTemplate As System.String  
Dim ShowTemplate As System.Boolean  
Dim Width As System.Double  
Dim Height As System.Double  
Dim value As System.Boolean
```

```
value = instance.PresetNewDrawingParameters(DrawingTemplate, ShowTemplate, Width, Height)
```

C#

```
System.bool PresetNewDrawingParameters(  
    System.string DrawingTemplate,  
    System.bool ShowTemplate,  
    System.double Width,  
    System.double Height  
)
```

C++/CLI

```
System.bool PresetNewDrawingParameters(  
& System.String^ DrawingTemplate,  
& System.bool ShowTemplate,  
& System.double Width,  
& System.double Height  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DrawingTemplate

Path and filename (.slddrt) of the drawing template to use

ShowTemplate

True to show the sheet format, false to not

NOTE: Valid only for standard sheet sizes and when Width and Height are set to 0.

Width

Width of the drawing sheet

Height

Height of the drawing sheet

Return Value

True if the specified drawing template and sheet size parameters are set, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::PresetNewDrawingParameters](#).

Example

[Preset and Reset Template and Sheet Parameters for New Drawing Documents \(VBA\)](#)

Remarks

To show the Sheet Format/Size dialog the next time a new drawing document is opened (SOLIDWORKS default behavior), call [ISldWorks::ResetPresetDrawingParameters](#) after calling this method and opening a new drawing document.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PreviewDoc Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : PreviewDoc Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::PreviewDocx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Displays a preview of a document to the specified window.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function PreviewDoc( _  
    ByRef HWnd As System.Integer, _  
    ByVal FullName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim hWnd As System.Integer  
Dim FullName As System.String  
Dim value As System.Boolean  
  
value = instance.PreviewDoc(hWnd, FullName)
```

C#

```
System.bool PreviewDoc(  
    ref System.int HWnd,  
    System.string FullName  
)
```

C++/CLI

```
System.bool PreviewDoc(  
& System.int% HWnd,  
& System.String^ FullName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HWnd

Window handle where you want the preview bitmap to display; this pointer is not valid across processes; therefore, this method only works if your application is implemented as a DLL

FullName

Full path name of document to preview

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::PreviewDoc](#).

Remarks

All applications are required to be compatible with SOLIDWORKS x64. You must replace all calls to 32-bit only APIs with calls to their 64-bit safe counterparts.

See [Eliminating 32-bit only API use](#) for more information.

The bitmap is stored with the fixed size shown with the interactive SOLIDWORKS preview option. If your window is a different size, then the image is scaled appropriately. If scaling is needed, then shaded images may not be as crisp as the original.

This method works well in the WM_PAINT Windows Message handler. If used in WM_ONINITDIALOG the dialog only displays the preview for a brief moment. The reason is that the dialog should be initialized completely before calling SldWorks::PreviewDoc.

C++ programmers can also access this bitmap image from outside SOLIDWORKS. The bitmap was written with CArchive::Write() and is found in the Preview node in SOLIDWORKS part, assembly and drawing files. The format of the Preview node is as follows: DWORD (data size) followed by continues chunk of memory of that size (data). The data being read can be cast to LPBITMAPINFO, which has all of the information required to display the bitmap. You may want to use StretchDIBits() when displaying your image of the bitmap.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::OpenDoc6 Method](#)
[ISldWorks::GetPreviewBitmap Method](#)

PreviewDocx64 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : PreviewDocx64 Method (ISldWorks)

Displays a preview of a document to the specified window in 64-bit applications.

.NET Syntax

Visual Basic (Declaration)

```
Function PreviewDocx64( _
    ByRef HWnd As System.Long, _
    ByVal FullName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim hWnd As System.Long
Dim FullName As System.String
Dim value As System.Boolean

value = instance.PreviewDocx64(hWnd, FullName)
```

C#

```
System.bool PreviewDocx64(
    ref System.long HWnd,
    System.string FullName
)
```

C++/CLI

```
System.bool PreviewDocx64(
    & System.int64% HWnd,
    & System.String^ FullName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HWnd

Window handle where you want the preview bitmap to display; this pointer is not valid across processes; therefore, this method only works if your application is implemented as a DLL.

FullName

Full path name of document to preview

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::PreviewDocx64](#).

Remarks

This method is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software.

The bitmap is stored with the fixed size shown with the interactive SOLIDWORKS Design preview option. If your window is a different size, then the image is scaled appropriately. If scaling is needed, then shaded images may not be as crisp as the original.

This method works well in the WM_PAINT Windows Message handler. If used in WM_ONINITDIALOG the dialog only displays the preview for a brief moment. The reason is that the dialog should be initialized completely before calling SldWorks::PreviewDocx64.

C++ programmers can also access this bitmap image from outside SOLIDWORKS Design. The bitmap was written with CArchive::Write() and is found in the Preview node in SOLIDWORKS Design part, assembly, and drawing files. The format of the Preview node is as follows: DWORD (data size) followed by continues chunk of memory of that size (data). The data being read can be cast to LPBITMAPINFO, which has all of the information required to display the bitmap. You may want to use StretchDIBits() when displaying your image of the bitmap.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::OpenDoc6 Method](#)
[ISldWorks::GetPreviewBitmap Method](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

QuitDoc Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : QuitDoc Method (ISldWorks)

Closes the specified document without saving changes.

.NET Syntax

Visual Basic (Declaration)

```
Sub QuitDoc( _  
    ByVal Name As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Name As System.String  
  
instance.QuitDoc(Name)
```

C#

```
void QuitDoc(  
    System.string Name  
)
```

C++/CLI

```
void QuitDoc(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Name of document to close

Visual Basic for Applications (VBA) Syntax

See [SldWorks::QuitDoc](#).

Example

[Save Rolledback Part as Parasolid File \(VBA\)](#)
[Add and Delete Appearances from Specific Display States \(C#\)](#)
[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)
[Add and Delete Appearances from Specific Display States \(VBA\)](#)

Remarks

If you are closing the only document in the SOLIDWORKS Design session and the SOLIDWORKS Design session is a background session, the calling [ISldWorks::CloseDoc](#) or this method results in the SOLIDWORKS Design session closing.

You can create a background SOLIDWORKS Design session when the starting a SOLIDWORKS Design session in your application and the session is controlled by the user ([ISldWorks::UserControl](#) set to false). To keep the SOLIDWORKS Design session open, set [ISldWorks::UserControl](#) to true, which makes the session visible, or you can close your documents at the end of your application's execution.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::CloseAllDocuments Method](#)
[ISldWorks::ExitApp Method](#)
[ISldWorks::GetFirstDocument Method](#)
[ISldWorks::EnumDocuments2 Method](#)
[ISldWorks::GetOpenDocument Method](#)
[ISldWorks::GetOpenDocumentByName Method](#)
[ISldWorks::GetOpenFileName Method](#)
[ISldWorks::IGetFirstDocument2 Method](#)
[ISldWorks::IGetOpenDocumentByName2 Method](#)
[ISldWorks::LoadFile4 Method](#)
[ISldWorks::OpenDoc6 Method](#)
[ISldWorks::ActiveDoc Property](#)
[ISldWorks::!ActiveDoc2 Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

RecordLine Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RecordLine Method (ISldWorks)

Adds a line of code to a VBA macro and the SOLIDWORKS journal file.

.NET Syntax

Visual Basic (Declaration)

```
Function RecordLine( _  
    ByVal Text As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Text As System.String  
Dim value As System.Boolean  
  
value = instance.RecordLine(Text)
```

C#

```
System.bool RecordLine(  
    System.string Text  
)
```

C++/CLI

```
System.bool RecordLine(  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text

Text to write to a VBA macro and the SOLIDWORKS journal file

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RecordLine](#).

Example

[Record Macros \(VBA\)](#)
[Record Macros \(VB.NET\)](#)
[Record Macros \(C#\)](#)

Remarks

This method is useful if you want your add-in application to record and play back SOLIDWORKS macros or write to the SOLIDWORKS journal file.

For example, if your add-in application allows end users to change the material specifications associated with a model, then end users may want to be able to record and play back the operation in a macro. This might allow them to easily assign material specifications to a large number of files by playing back the macro.

Text is only written to macros if macro recording is enabled when the method is called ([ISldWorks::Run Command](#) swCommands_RecordPauseMacro ""). Users are prompted to select the type of macros to create when recording is stopped (ISldWorks::Run Command swCommands_StopMacro "").

For your add-in functionality to be recorded reliably in all macro formats, you should call all three macro-recording methods:

- [ISldWorks::RecordLine](#) to record to a **SW VBA Macro (*.swp)**.
- [ISldWorks::RecordLineVBNet](#) to record to a **SW VSTA VB Macro (*.vbproj)**.
- [ISldWorks::RecordLineCSharp](#) to record to a **SW VSTA C# Macro (*.csproj)**.

Exercise caution when recording lines that include string literals. String literals are parsed when the add-in application is compiled and again when the macro is compiled.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[DSldWorksEvents.BeginRecordNotify](#)
[DSldWorksEvents.EndRecordNotify](#)
[ISldWorks::RunMacro2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

RecordLineCSharp Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RecordLineCSharp Method (ISldWorks)

Adds a line of code to a C# macro and the SOLIDWORKS journal file.

.NET Syntax

Visual Basic (Declaration)

```
Function RecordLineCSharp( _  
    ByVal StringLine As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim StringLine As System.String  
Dim value As System.Boolean
```

```
value = instance.RecordLineCSharp(StringLine)
```

C#

```
System.bool RecordLineCSharp(  
    System.string StringLine  
)
```

C++/CLI

```
System.bool RecordLineCSharp(  
& System.String^ StringLine  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StringLine

Text to write to a C# macro and the SOLIDWORKS journal file

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::RecordLineCSharp](#).

Example

[Record Macros \(VBA\)](#)
[Record Macros \(VB.NET\)](#)
[Record Macros \(C#\)](#)

Remarks

This method is useful if you want your add-in application to record and play back SOLIDWORKS macros or write to the SOLIDWORKS journal file.

For example, if your add-in application allows end users to change the material specifications associated with a model, then end users may want to be able to record and play back the operation in a macro. This might allow them to easily assign material specifications to a large number of files by playing back the macro.

Text is only written to macros if macro recording is enabled when the method is called ([ISldWorks::Run Command](#) swCommands_RecordPauseMacro ""). Users are prompted to select the type of macros to create when recording is stopped ([ISldWorks::Run Command](#) swCommands_StopMacro "").

For your add-in functionality to be recorded reliably in all macro formats, you should call all three macro-recording methods:

- [ISldWorks::RecordLine](#) to record to a **SW VBA Macro (*.swp)**.
- [ISldWorks::RecordLineVBnet](#) to record to a **SW VSTA VB Macro (*.vbproj)**.
- [ISldWorks::RecordLineCSharp](#) to record to a **SW VSTA C# Macro (*.csproj)**.

Exercise caution when recording lines that include string literals. String literals are parsed when the add-in application is compiled and again when the macro is compiled.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorksEvents.BeginRecordNotifyEventHandler Delegate](#)
[ISldWorksEvents.EndRecordNotifyEventHandler Delegate](#)
[ISldWorks::RunMacro2 Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RecordLineVBnet Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RecordLineVBnet Method (ISldWorks)

Adds a line of code to a VB.NET macro and the SOLIDWORKS journal file.

.NET Syntax

Visual Basic (Declaration)

```
Function RecordLineVBnet( _  
    ByVal StringLine As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim StringLine As System.String  
Dim value As System.Boolean  
  
value = instance.RecordLineVBnet(StringLine)
```

C#

```
System.bool RecordLineVBnet(  
    System.string StringLine  
)
```

C++/CLI

```
System.bool RecordLineVBnet(  
& System.String^ StringLine  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StringLine

Text to write to a VB.NET macro and the SOLIDWORKS journal file

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::RecordLineVBnet](#).

Example

[Record Macros \(VBA\)](#)
[Record Macros \(VB.NET\)](#)
[Record Macros \(C#\)](#)

Remarks

This method is useful if you want your add-in application to record and play back SOLIDWORKS macros or write to the SOLIDWORKS journal file.

For example, if your add-in application allows end users to change the material specifications associated with a model, then end users may want to be able to record and play back the operation in a macro. This might allow them to easily assign material specifications to a large number of files by playing back the macro.

Text is only written to macros if macro recording is enabled when the method is called ([ISldWorks::Run Command](#) swCommands_RecordPauseMacro ""). Users are prompted to select the type of macros to create when recording is stopped ([ISldWorks::Run Command](#) swCommands_StopMacro "").

For your add-in functionality to be recorded reliably in all macro formats, you should call all three macro-recording methods:

- [ISldWorks::RecordLine](#) to record to a **SW VBA Macro (*.swp)**.
- [ISldWorks::RecordLineVBne](#) to record to a **SW VSTA VB Macro (*.vbproj)**.
- [ISldWorks::RecordLineCSharp](#) to record to a **SW VSTA C# Macro (*.csproj)**.

Exercise caution when recording lines that include string literals. String literals are parsed when the add-in application is compiled and again when the macro is compiled.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorksEvents.BeginRecordNotifyEventHandler Delegate](#)
[ISldWorksEvents.EndRecordNotifyEventHandler Delegate](#)
[ISldWorks::RunMacro2 Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RefreshQuickTipWindow Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RefreshQuickTipWindow Method (ISldWorks)

Tells the SOLIDWORKS Design application that your add-in's state has changed and triggers a query for the current URL page.

.NET Syntax

Visual Basic (Declaration)

```
Sub RefreshQuickTipWindow()
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
instance.RefreshQuickTipWindow()
```

C#

```
void RefreshQuickTipWindow()
```

C++/CLI

```
void RefreshQuickTipWindow();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RefreshQuickTipWindow](#).

Remarks

See [Quick Tips and Bubble ToolTips](#) for details.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::InstallQuickTipGuide Method](#)
[ISldWorks::UninstallQuickTipGuide Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RefreshTaskpaneContent Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RefreshTaskpaneContent Method (ISldWorks)

Refreshes the view of the Design Library tab in the Task Pane.

.NET Syntax

Visual Basic (Declaration)

```
Sub RefreshTaskpaneContent()
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
instance.RefreshTaskpaneContent()
```

C#

```
void RefreshTaskpaneContent()
```

C++/CLI

```
void RefreshTaskpaneContent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RefreshTaskpaneContent](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::ActivateTaskPane Method](#)
[ISldWorks::CreateTaskpaneView2 Method](#)
[ISldWorks::TaskPanelsPinned Property](#)
[ITaskpaneView Interface](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

RegisterThirdPartyPopupMenu Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RegisterThirdPartyPopupMenu Method (ISldWorks)

Registers a third-party pop-up (shortcut) menu.

.NET Syntax

Visual Basic (Declaration)

```
Function RegisterThirdPartyPopupMenu() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Integer  
  
value = instance.RegisterThirdPartyPopupMenu()
```

C#

```
System.int RegisterThirdPartyPopupMenu()
```

C++/CLI

```
System.int RegisterThirdPartyPopupMenu();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

ID of this third-party shortcut menu

Example

[Add Shortcut Menus to Add-ins \(VB.NET\)](#)
[Add Shortcut Menus to Add-ins \(C#\)](#)

Remarks

Read about [Add-in Shortcut Menus](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RegisterTrackingDefinition Method (ISldWorks)

[See Also](#) [Example](#)



Registers a tracking definition.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function RegisterTrackingDefinition( _  
    ByVal Name As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Name As System.String  
Dim value As System.Integer  
  
value = instance.RegisterTrackingDefinition(Name)
```

C#

```
System.int RegisterTrackingDefinition(  
    System.string Name  
)
```

C++/CLI

```
System.int RegisterTrackingDefinition(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Prefixed name that uniquely identifies tracking definitions

Return Value

Cookie that represents the tracking definition for use in other methods; a return value of -1 indicates that a tracking cookie was not generated; if a cookie has already been registered for this tracking definition, then that cookie is returned

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RegisterTrackingDefinition](#).

Example

[Get, Set, and Remove Tracking IDs on Body \(VBA\)](#)

Remarks

Applications can use the same prefix as for an [IAttribute](#), [IAttributeDef](#), and third-party storage. The same application can register multiple tracking definitions; for example, **abcMyTrackingDefinition1** and **abcMyTrackingDefinition2**.

This method should typically be called when an application is starting up. See [Tracking IDs](#) for more information.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[IBody2::GetTrackingIDs Method](#)
[IBody2::RemoveTrackingID Method](#)
[IBody2::SetTrackingID Method](#)
[IEdge::GetTrackingIDs Method](#)
[IEdge::RemoveTrackingID Method](#)
[IEdge::SetTrackingID Method](#)
[IFace2::GetTrackingIDs Method](#)
[IFace2::RemoveTrackingID Method](#)
[IFace2::SetTrackingID Method](#)
[ILoop2::GetTrackingIDs Method](#)

[ILoop2::RemoveTrackingID Method](#)
[ILoop2::SetTrackingID Method](#)
[IVertex::GetTrackingIDs Method](#)
[IVertex::RemoveTrackingID Method](#)
[IVertex::SetTrackingID Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveCallback Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RemoveCallback Method (ISldWorks)

Unregisters a general purpose callback handler.

.NET Syntax

Visual Basic (Declaration)

```
Sub RemoveCallback( _  
    ByVal Cookie As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Cookie As System.Integer  
  
instance.RemoveCallback(Cookie)
```

C#

```
void RemoveCallback(  
    System.int Cookie  
)
```

C++/CLI

```
void RemoveCallback(  
& System.int Cookie  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Cookie
Cookie of callback function to unregister

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RemoveCallback](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::CallBack Method](#)
[ISldWorks::SetAddinCallbackInfo Method](#)
[ISldWorks::AddCallback Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveFileOpenItem Method (ISldWorks)

[See Also](#)



Obsolete. Superseded by [ISldWorks::RemoveFileOpenItem2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveFileOpenItem( _  
    ByVal CallbackFcnAndModule As System.String, _  
    ByVal Description As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim CallbackFcnAndModule As System.String  
Dim Description As System.String  
Dim value As System.Boolean  
  
value = instance.RemoveFileOpenItem(CallbackFcnAndModule, Description)
```

C#

```
System.bool RemoveFileOpenItem(  
    System.string CallbackFcnAndModule,  
    System.string Description  
)
```

C++/CLI

```
System.bool RemoveFileOpenItem(  
& System.String^ CallbackFcnAndModule,  
& System.String^ Description  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CallbackFcnAndModule

Description

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RemoveFileOpenItem](#).

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

RemoveFileOpenItem2 Method (ISldWorks)

[See Also](#) [Example](#)



Removes a file type from the **File > Open** dialog box that was added using [ISldWorks::AddFileOpenItem3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveFileOpenItem2( _  
    ByVal Cookie As System.Integer, _  
    ByVal MethodName As System.String, _  
    ByVal Description As System.String, _
```

```
ByVal Extension As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Cookie As System.Integer  
Dim MethodName As System.String  
Dim Description As System.String  
Dim Extension As System.String  
Dim value As System.Boolean  
  
value = instance.RemoveFileOpenItem2(Cookie, MethodName, Description, Extension)
```

C#

```
System.bool RemoveFileOpenItem2(  
    System.int Cookie,  
    System.string MethodName,  
    System.string Description,  
    System.string Extension  
)
```

C++/CLI

```
System.bool RemoveFileOpenItem2(  
& System.int Cookie,  
& System.String^ MethodName,  
& System.String^ Description,  
& System.String^ Extension  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Cookie

Cookie specified in [ISwAddin::ConnectToSW](#)

MethodName

Name of the application function used to open the file as specified in [ISldWorks::AddFileOpenItem3](#)

Description

File description in the **Save as type** list

Extension

File name extension

Return Value

True if the file type is removed from the **Save as type** list, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RemoveFileOpenItem2](#).

Example

[Add and Remove Items to File Save As and Open Menus \(VB.NET\)](#)
[Add and Remove Items to File Save As and Open Menus \(C#\)](#)

Remarks

Call this method in your add-in's DisconnectFromSW method.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::AddFileSaveAsItem2 Method](#)
[ISldWorks::RemoveFileSaveAsItem2 Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveFileSaveAsItem Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RemoveFileSaveAsItem Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::RemoveFileSaveAsItem2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveFileSaveAsItem( _  
    ByVal CallbackFcnAndModule As System.String, _  
    ByVal Description As System.String, _  
    ByVal Type As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim CallbackFcnAndModule As System.String  
Dim Description As System.String  
Dim Type As System.Integer  
Dim value As System.Boolean  
  
value = instance.RemoveFileSaveAsItem(CallbackFcnAndModule, Description, Type)
```

C#

```
System.bool RemoveFileSaveAsItem(  
    System.string CallbackFcnAndModule,  
    System.string Description,  
    System.int Type  
)
```

C++/CLI

```
System.bool RemoveFileSaveAsItem(  
& System.String^ CallbackFcnAndModule,  
& System.String^ Description,  
& System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CallbackFcnAndModule

Description

Type

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RemoveFileSaveAsItem](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveFileSaveAsItem2 Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RemoveFileSaveAsItem2 Method (ISldWorks)

Removes a file type from the **File > Save As** dialog box that was added using [ISldWorks::AddFileSaveAsItem2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveFileSaveAsItem2( _  
    ByVal Cookie As System.Integer, _  
    ByVal MethodName As System.String, _  
    ByVal Description As System.String, _  
    ByVal Extension As System.String, _  
    ByVal DocumentType As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim Cookie As System.Integer  
Dim MethodName As System.String  
Dim Description As System.String  
Dim Extension As System.String  
Dim DocumentType As System.Integer  
Dim value As System.Boolean  
  
value = instance.RemoveFileSaveAsItem2(Cookie, MethodName, Description, Extension, DocumentType)
```

C#

```
System.bool RemoveFileSaveAsItem2(  
    System.int Cookie,  
    System.string MethodName,  
    System.string Description,  
    System.string Extension,  
    System.int DocumentType  
)
```

C++/CLI

```
System.bool RemoveFileSaveAsItem2(  
& System.int Cookie,  
& System.String^ MethodName,  
& System.String^ Description,  
& System.String^ Extension,  
& System.int DocumentType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Cookie

Cookie specified in [ISwAddin::ConnectToSW](#)

MethodName

Name of the application function used to save the file as specified in [ISldWorks::AddFileSaveAsItem2](#)

Description

File description in the **Save as type** list

Extension

File name extension

DocumentType

Type of document to save as defined in [swDocumentTypes_e](#)

Return Value

True if the file type is removed from the **Save as type** list, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RemoveFileSaveAsItem2](#).

Example

[Add and Remove Items to File Save As and Open Menus \(VB.NET\)](#)
[Add and Remove Items to File Save As and Open Menus \(C#\)](#)

Remarks

Call this method in your add-in's DisconnectFromSW method.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::AddFileOpenItem3 Method](#)
[ISldWorks::RemoveFileOpenItem2 Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveFromMenu Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RemoveFromMenu Method (ISldWorks)

Removes:

- the specified command from all main frame menus or a toolbar or both
- the specified command's parent menus

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveFromMenu( _  
    ByVal CommandID As System.Integer, _  
    ByVal DocumentType As System.Integer, _  
    ByVal Option As System.Integer, _  
    ByVal RemoveParentMenu As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim CommandID As System.Integer  
Dim DocumentType As System.Integer  
Dim Option As System.Integer  
Dim RemoveParentMenu As System.Boolean  
Dim value As System.Boolean  
  
value = instance.RemoveFromMenu(CommandID, DocumentType, Option, RemoveParentMenu)
```

C#

```
System.bool RemoveFromMenu(  
    System.int CommandID,  
    System.int DocumentType,  
    System.int Option,  
    System.bool RemoveParentMenu  
)
```

C++/CLI

```
System.bool RemoveFromMenu(  
& System.int CommandID,  
& System.int DocumentType,  
& System.int Option,  
& System.bool RemoveParentMenu  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CommandID

Command ID of the command to remove as defined by [swCommands_e](#)

DocumentType

Document types in which to remove the command as defined in [swDocumentTypes_e](#)

Option

- 1 = Menu
- 2 = Toolbar
- 3 = Both menu and toolbar

RemoveParentMenu

True to remove the specified command's parent menu, false to not

NOTE: This parameter is specific to menus only; it does not affect toolbars.

Return Value

True if the specified items are removed, false if not

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::RemoveFromMenu](#).

Example

[Remove Menu Commands, Menus, and Toolbar Buttons \(VBA\)](#)

Remarks

This method does not affect context-sensitive menus (also called shortcut menus and pop-up menus); this command only affects main frame menus and toolbars. To remove commands and parent menus from context-sensitive menus, use [ISldWorks::RemoveFromPopupMenu](#).

The specified items are removed after this method executes, and their removal can be seen immediately.

This method is not persistent across SOLIDWORKS Design sessions.

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::AddMenu Method](#)

[ISldWorks::AddMenuItem3 Method](#)

[ISldWorks::AddMenuPopupItem2 Method](#)

[ISldWorks::AddToolbar4 Method](#)

[ISldWorks::AddToolbarCommand2 Method](#)

[ISldWorks::DragToolbarButton Method](#)

[ISldWorks::HideToolbar2 Method](#)

[ISldWorks::RemoveMenu Method](#)

[ISldWorks::RemoveMenuPopupItem2 Method](#)

[ISldWorks::RemoveToolbar2 Method](#)

Availability

SOLIDWORKS 2007 SP2, Revision Number 15.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveFromPopupMenu Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RemoveFromPopupMenu Method (ISldWorks)

Removes the specified menu item from one or all specified context-sensitive menus (also called shortcut menus and pop-up menus) for the specified document types.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveFromPopupMenu( _  
    ByVal CommandID As System.Integer, _  
    ByVal DocumentType As System.Integer, _  
    ByVal SelectionType As System.Integer, _  
    ByVal RemoveParentMenu As System.Boolean _  
    ) As System.Boolean
```

```

Dim instance As ISldWorks
Dim CommandID As System.Integer
Dim DocumentType As System.Integer
Dim SelectionType As System.Integer
Dim RemoveParentMenu As System.Boolean
Dim value As System.Boolean

value = instance.RemoveFromPopupMenu(CommandID, DocumentType, SelectionType, RemoveParentMenu)

```

C#

```

System.bool RemoveFromPopupMenu(
    System.int CommandID,
    System.int DocumentType,
    System.int SelectionType,
    System.bool RemoveParentMenu
)

```

C++/CLI

```

System.bool RemoveFromPopupMenu(
    & System.int CommandID,
    & System.int DocumentType,
    & System.int SelectionType,
    & System.bool RemoveParentMenu
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CommandID

Command ID of the command to remove as defined by [swCommands_e](#)

DocumentType

Document types in which to remove the command as defined in [swDocumentTypes_e](#)

SelectionType

Context-sensitive menu from which to remove the command as defined by [swSelectType_e](#)

NOTE: Specifying swSelEVERYTHING will remove the command from all context-sensitive menus

RemoveParentMenu

True to remove the specified command's any parent menus, false to not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::RemoveFromPopupMenu](#).

Example

[Remove Menu commands, Menus, and Toolbar Buttons \(VBA\)](#)

Remarks

The removal of the specified menu item takes affect the next time the context-sensitive menu is displayed.

To remove main frame menu commands and menus, use [ISldWorks::RemoveFromMenu](#).

This method is not persistent across SOLIDWORKS Design sessions.

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::AddMenu Method](#)

[ISldWorks::AddMenuItem3 Method](#)

[ISldWorks::AddMenuPopupItem2 Method](#)

[ISldWorks::RemoveMenu Method](#)

[ISldWorks::RemoveMenuPopupItem2 Method](#)

Availability

RemoveItemFromThirdPartyPopupMenu Method (ISldWorks)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : RemoveItemFromThirdPartyPopupMenu Method (ISldWorks)

Removes a menu item and icon from a third-party pop-up (shortcut) menu.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveItemFromThirdPartyPopupMenu( _
    ByVal RegisterId As System.Integer, _
    ByVal DocType As System.Integer, _
    ByVal Item As System.String, _
    ByVal IconIndex As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim RegisterId As System.Integer
Dim DocType As System.Integer
Dim Item As System.String
Dim IconIndex As System.Integer
Dim value As System.Boolean

value = instance.RemoveItemFromThirdPartyPopupMenu(RegisterId, DocType, Item, IconIndex)
```

C#

```
System.bool RemoveItemFromThirdPartyPopupMenu(
    System.int RegisterId,
    System.int DocType,
    System.string Item,
    System.int IconIndex
)
```

C++/CLI

```
System.bool RemoveItemFromThirdPartyPopupMenu(
    & System.int RegisterId,
    & System.int DocType,
    & System.String^ Item,
    & System.int IconIndex
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*RegisterId*ID of the shortcut menu from [ISldWorks::RegisterThirdPartyPopupMenu](#)*DocType*Document type where to display the shortcut menu, as defined in [swDocumentTypes_e](#)*Item*

Name of the shortcut menu item

*IconIndex*1-based index of the icon (see **Remarks**)

Return Value

True if the shortcut menu item or icon is removed, false if not

Example

[Add Shortcut Menus to Add-ins \(VB.NET\)](#)[Add Shortcut Menus to Add-ins \(C#\)](#)

Remarks

To remove:

- a menu item, specify a valid name for Item only. If you specify both Item and IconIndex, only Item is evaluated; IconIndex is ignored.
- a menu bar icon, specify an empty string for Item and pass the 1-based index value of the icon for IconIndex.

Read about [Add-in Shortcut Menus](#).

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

[ISldWorks::AddItemToThirdPartyPopupMenu Method](#)

[ISldWorks::SetThirdPartyPopupMenuState Method](#)

[ISldWorks::ShowThirdPartyPopupMenu Method](#)

[ISldWorks::AddItemToThirdPartyPopupMenu2 Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0