

SOLIDWORKS API (.NET, VBA, C#) — Reference (288/337): ISldWorks (part 8 of 8)

SOLIDWORKS API Documentation (converted from CHM)

ISldWorks (part 8 of 8) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowBubbleTooltipAt Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ShowBubbleTooltipAt Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::ShowBubbleTooltipAt2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ShowBubbleTooltipAt( _  
    ByVal PointX As System.Integer, _  
    ByVal PointY As System.Integer, _  
    ByVal ArrowPos As System.Integer, _  
    ByVal TitleString As System.String, _  
    ByVal MessageString As System.String, _  
    ByVal UrlLoc As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim PointX As System.Integer  
Dim PointY As System.Integer  
Dim ArrowPos As System.Integer  
Dim TitleString As System.String  
Dim MessageString As System.String  
Dim UrlLoc As System.String  
  
instance.ShowBubbleTooltipAt(PointX, PointY, ArrowPos, TitleString, MessageString, UrlLoc)
```

C#

```
void ShowBubbleTooltipAt(  
    System.int PointX,  
    System.int PointY,  
    System.int ArrowPos,  
    System.string TitleString,  
    System.string MessageString,  
    System.string UrlLoc  
)
```

C++/CLI

```
void ShowBubbleTooltipAt(  
& System.int PointX,  
& System.int PointY,  
& System.int ArrowPos,  
& System.String^ TitleString,  
& System.String^ MessageString,  
& System.String^ UrlLoc  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointX
x coordinate in pixels relative to upper-left corner of screen
PointY
y coordinate in pixels relative to upper-left corner of screen
ArrowPos
Arrow position as defined in [swArrowPosition](#)
TitleString
Title of bubble ToolTip
MessageString
Message string of bubble ToolTip
UrlLoc
Any valid Windows Internet Explorer file (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::ShowBubbleTooltipAt](#).

Example

Visual Basic for Applications (VBA)

```
'-----  
'  
' Preconditions: Specified HTML file exists at the specified location.  
' Postconditions: Contents of the HTML file are displayed in a Bubble ToolTip.  
'-----  
  
Option Explicit  
  
Sub main()  
    ' Substitute a valid HTML file for the string shown below  
    Const sURLpath As String = "path_to_a_gif_jpg_or_jpeg_file_or_a_URL"  
  
    Dim swApp As SldWorks.SldWorks  
    Set swApp = Application.SldWorks  
  
    ' Show Bubble ToolTip  
    swApp.ShowBubbleTooltipAt 300, 400, swArrowLeftTop, "Sample ShowBubbleTooltipAt",  
    "Message of Sample ShowBubbleTooltipAt", sURLpath  
  
End Sub  
  
'-----
```

Remarks

If you specified a ...	Then the ToolTip's bubble...
gif, .jpg, or .jpeg image for urlLoc	Is automatically expanded to accommodate the image
URL for urlLoc	Cannot be resized; if the URL is: • an HTML file, then the contents of the HTML file are displayed in the bubble ToolTip • to a website, then the default or specified web page at that website is displayed in the bubble ToolTip

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::ShowBubbleTooltip Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowBubbleTooltipAt2 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ShowBubbleTooltipAt2 Method (ISldWorks)

Displays a bubble ToolTip at the specified location.

Visual Basic (Declaration)

```
Sub ShowBubbleTooltipAt2( _
    ByVal PointX As System.Integer, _
    ByVal PointY As System.Integer, _
    ByVal ArrowPos As System.Integer, _
    ByVal TitleString As System.String, _
    ByVal MessageString As System.String, _
    ByVal TitleBitmapID As System.Integer, _
    ByVal TitleBitmap As System.String, _
    ByVal UrlLoc As System.String, _
    ByVal Cookie As System.Integer, _
    ByVal LinkStringID As System.Integer, _
    ByVal LinkString As System.String, _
    ByVal CallBack As System.String _
)
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim PointX As System.Integer
Dim PointY As System.Integer
Dim ArrowPos As System.Integer
Dim TitleString As System.String
Dim MessageString As System.String
Dim TitleBitmapID As System.Integer
Dim TitleBitmap As System.String
Dim UrlLoc As System.String
Dim Cookie As System.Integer
Dim LinkStringID As System.Integer
Dim LinkString As System.String
Dim CallBack As System.String
```

```
instance.ShowBubbleTooltipAt2(PointX, PointY, ArrowPos, TitleString, MessageString, TitleBitmapID,
TitleBitmap, UrlLoc, Cookie, LinkStringID, LinkString, CallBack)
```

C#

```
void ShowBubbleTooltipAt2(
    System.int PointX,
    System.int PointY,
    System.int ArrowPos,
    System.string TitleString,
    System.string MessageString,
    System.int TitleBitmapID,
    System.string TitleBitmap,
    System.string UrlLoc,
    System.int Cookie,
    System.int LinkStringID,
    System.string LinkString,
    System.string CallBack
)
```

C++/CLI

```
void ShowBubbleTooltipAt2(
    & System.int PointX,
    & System.int PointY,
    & System.int ArrowPos,
    & System.String^ TitleString,
    & System.String^ MessageString,
    & System.int TitleBitmapID,
    & System.String^ TitleBitmap,
    & System.String^ UrlLoc,
    & System.int Cookie,
    & System.int LinkStringID,
    & System.String^ LinkString,
```

```
& System.String^ Callback
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointX
x coordinate in pixels relative to upper-left corner of the screen (see **Remarks**)

PointY
y coordinate in pixels relative to upper-left corner of the screen (see **Remarks**)

ArrowPos
Arrow position as defined in [swArrowPosition](#)

TitleString
Title of bubble ToolTip

MessageString
Message for bubble ToolTip

TitleBitmapID
ID of the bitmap to display in the bubble ToolTip as defined in [swBitMaps](#) (see **Remarks**)

TitleBitmap
Path and filename of the bitmap to display before TitleString in the bubble ToolTip

UrlLoc
Any valid Windows Internet Explorer file to display in the body of the bubble ToolTip (see **Remarks**)

Cookie
Add-in's application ID specified in [ISwAddin::ConnectToSW](#)

LinkStringID
ID of the hyperlink as defined in [swLinkString](#) (see **Remarks**)

LinkString
String to show as the hyperlink in the bubble ToolTip

CallBack
Name of the callback function for the hyperlink

Visual Basic for Applications (VBA) Syntax

See [SldWorks::ShowBubbleToolTipAt2](#).

Example

The following examples show how to display a bubble ToolTip. Click a link to jump to the example in that programming language.

- [C#](#)
- [VB.NET](#)
- [VBA](#)

C#

```
//-----
// Preconditions: SOLIDWORKS is running.
// Postconditions:
// (1) Bubble ToolTip is shown.
// (2) Bubble ToolTip is hidden.
//-----

using

SOLIDWORKS.Interop.sldworks;
using

SOLIDWORKS.Interop.swconst;
using

System;
namespace

ShowBubbleToolTipAt2SldWorksCSharp.csproj
{
    public partial class SOLIDWORKSMacro
    {
        public void Main()
        {
            // Show bubble ToolTip
            swApp.ShowBubbleToolTipAt2(300, 400, (
int)swArrowPosition.swArrowLeftTop, "Sample Bubble Tooltip", "Message of Sample Bubble
ToolTip", (int)swBitMaps.swBitmapUserDefined, "C:\\Program Files\\SOLIDWORKS
```

```

Corp\\SOLIDWORKS\\data\\user macro icons\\questionmark.bmp", "", 0,
(int)swLinkString.swLinkStringNone, "", "");

    // 1. Insert a breakpoint at next command.
    // 2. Examine the SOLIDWORKS graphics area to see the bubble ToolTip.
    // 3. Toggle the breakpoint to hide the bubble ToolTip.
    swApp.HideBubbleTooltip();
}
    /// <summary>
    /// The SldWorks swApp variable is pre-assigned for you.
    /// </summary>
    public SldWorks swApp;
}
}

```

VB.NET

```

'-----
' Preconditions: SOLIDWORKS is running.
' Postconditions:
'   (1) Bubble ToolTip is shown.
'   (2) Bubble ToolTip is hidden.
'-----

Imports
SOLIDWORKS.Interop.sldworks
Imports
SOLIDWORKS.Interop.swconst
Imports
System
Partial Class SOLIDWORKSMacro
Public Sub main()
    ' Show bubble ToolTip
    swApp.ShowBubbleTooltipAt2(300, 400, swArrowPosition.swArrowLeftTop, "Sample Bubble
ToolTip", "Message of Sample Bubble ToolTip", swBitMaps.swBitmapUserDefined,
"C:\Program Files\SOLIDWORKS Corp\SOLIDWORKS\data\user macro icons\questionmark.bmp",
"", 0, swLinkString.swLinkStringNone, "", "")

    Stop

    swApp.HideBubbleTooltip()

End Sub
    ''' <summary>
    ''' The SldWorks swApp variable is pre-assigned for you.
    ''' </summary>
    Public swApp As SldWorks

```

End Class

VBA

```
'-----  
' Preconditions: SOLIDWORKS is running  
'  
' Postconditions:  
'     (1) Bubble ToolTip is shown.  
'     (2) Bubble ToolTip is hidden.  
'-----
```

Option Explicit

Sub main()

```
    Dim swApp As SldWorks.SldWorks  
    Set swApp = Application.SldWorks  
  
    ' Show Bubble ToolTip  
    swApp.ShowBubbleToolTipAt2 300, 400, swArrowLeftTop, "Sample Bubble Tooltip",  
    "Message of Sample Bubble Tooltip", swBitmapUserDefined, "C:\Program Files\SOLIDWORKS  
    Corp\SOLIDWORKS\data\user macro icons\questionmark.bmp", "", 0, swLinkStringNone, "",  
    ""  
  
    Stop  
  
    swApp.HideBubbleToolTip  
  
End Sub  
'-----
```

Remarks

If PointX and PointY are both set to 0 and TitleBitmapID is swBitmapTreeError and a PropertyManager page is displayed, then the bubble ToolTip will appear in the same location as the SOLIDWORKS Design user-interface Rebuild Errors bubble ToolTip. You must specify both TitleBitmapID and TitleBitmap values.

If you specified a ...	Then the bubble ToolTip...
gif, .jpg, or .jpeg image for UrlLoc	is automatically expanded to accommodate the image.
URL for UrlLoc	cannot be resized; if the URL: • is an HTML file, then the contents of the HTML file are displayed in the bubble ToolTip. • links to a website, then the default or specified web page at that website is displayed in the bubble ToolTip.

The Cookie, LinkStringID, LinkString, and Callback parameters are intended for use by add-in applications to display a hyperlink in the bubble ToolTip that, when clicked, calls a function to do something outside of the application; for example, open the add-in application's Help system.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::ShowBubbleToolTip Method](#)
[ISldWorks::HideBubbleToolTip Method](#)

Availability

ShowHelp Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ShowHelp Method (ISldWorks)

Displays the specified Help topic.

.NET Syntax

Visual Basic (Declaration)

```

Sub ShowHelp( _
    ByVal HelpFile As System.String, _
    ByVal HelpTopic As System.Integer _
)

```

Visual Basic (Usage)



```

Dim instance As ISldWorks
Dim HelpFile As System.String
Dim HelpTopic As System.Integer

instance.ShowHelp(HelpFile, HelpTopic)

```

C#

```

void ShowHelp(
    System.string HelpFile,
    System.int HelpTopic
)

```

C++/CLI

```

void ShowHelp(
    & System.String^ HelpFile,
    & System.int HelpTopic
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HelpFile

Name of the Help file that contains the Help topic

HelpTopic

ID of Help topic to display

Visual Basic for Applications (VBA) Syntax

See [SldWorks::ShowHelp](#).

Example

```

STDMETHODIMP CFuncFeatApp::appCallbackFunction(int cmd,int data,LPDISPATCH dsp, BOOL
*retval)
{
    switch (cmd)
    {
        case swAppIsNewCmd:
            *retval = VARIANT_True; //Set to True if data is new
            break;
        case swAppWhatsNewDescription:
            m_iSldWorks->ShowHelp(_T("name_of_your_Help_system.chm"),
cmd);
    }
}

```

```

        break;
    case swAppHelpContext:
        break;
    }
    return S_OK;
}

```

Example

[Call Compiled HTML Help File \(C#\)](#)

Remarks

You can use this method with [ISldWorks::AddCallback](#) to implement Interactive What's New for your add-in.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::CallBack Method](#)
[ISldWorks::RemoveCallback Method](#)
[ISldWorks::SetAddinCallbackInfo Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowThirdPartyPopupMenu Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ShowThirdPartyPopupMenu Method (ISldWorks)

Sets where to show a third-party pop-up (shortcut) menu.

.NET Syntax

Visual Basic (Declaration)

```

Function ShowThirdPartyPopupMenu( _
    ByVal RegisterId As System.Integer, _
    ByVal Posx As System.Integer, _
    ByVal Posy As System.Integer _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As ISldWorks
Dim RegisterId As System.Integer
Dim Posx As System.Integer
Dim Posy As System.Integer
Dim value As System.Boolean

```

```
value = instance.ShowThirdPartyPopupMenu(RegisterId, Posx, Posy)
```

C#

```

System.bool ShowThirdPartyPopupMenu(
    System.int RegisterId,
    System.int Posx,
    System.int Posy
)

```

C++/CLI

```
System.bool ShowThirdPartyPopupMenu(
& System.int RegisterId,
& System.int PosX,
& System.int Posy
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RegisterId

ID of shortcut menu from [ISldWorks::RegisterThirdPartyPopupMenu](#)

PosX

x coordinate for shortcut menu

Posy

y coordinate for shortcut menu

Return Value

True to show shortcut menu, false to not

Example

[Add Shortcut Menus to Add-ins \(VB.NET\)](#)

[Add Shortcut Menus to Add-ins \(C#\)](#)

Remarks

Read about [Add-in Shortcut Menus](#).

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowToolbar Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ShowToolbar Method (ISldWorks)

Obsolete. Superseded by [ISldWorks::ShowToolbar2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ShowToolbar( _
    ByVal ModuleName As System.String, _
    ByVal ToolbarId As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim ModuleName As System.String
Dim ToolbarId As System.Integer
Dim value As System.Boolean
```

```
value = instance.ShowToolbar(ModuleName, ToolbarId)
```

C#

```
System.bool ShowToolbar(
    System.string ModuleName,
```

```
System.int ToolBarId
)
```

C++/CLI

```
System.bool ShowToolBar(
& System.String^ ModuleName,
& System.int ToolBarId
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModuleName

ToolBarId

Visual Basic for Applications (VBA) Syntax

See [SldWorks::ShowToolBar](#).

See Also

[ISldWorks Interface](#)

[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowToolBar2 Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ShowToolBar2 Method (ISldWorks)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function ShowToolBar2( _
    ByVal Cookie As System.Integer, _
    ByVal ToolBarId As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim Cookie As System.Integer
Dim ToolbarId As System.Integer
Dim value As System.Boolean

value = instance.ShowToolBar2(Cookie, ToolbarId)
```

C#

```
System.bool ShowToolBar2(
    System.int Cookie,
    System.int ToolBarId
)
```

C++/CLI

```
System.bool ShowToolBar2(
& System.int Cookie,
& System.int ToolBarId
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Cookie

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::ShowToolbar2](#).

Remarks

SOLIDWORKS manages the display of the toolbars based on the user's action; therefore, this method is not needed. There are no alternative methods available to use.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowUserNotification Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : ShowUserNotification Method (ISldWorks)

Shows the specified user notification for a SOLIDWORKS add-in.

.NET Syntax

Visual Basic (Declaration)

```
Function ShowUserNotification(
    ByVal Definition As System.Object, _
    ByVal Handler As System.Object _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim Definition As System.Object
Dim Handler As System.Object
Dim value As System.Integer

value = instance.ShowUserNotification(Definition, Handler)
```

C#

```
System.int ShowUserNotification(
    System.object Definition,
    System.object Handler
)
```

C++/CLI

```
System.int ShowUserNotification(
    & System.Object^ Definition,
    & System.Object^ Handler
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Definition
[IUserNotificationDefinition](#)
Handler
[IUserNotificationHandler](#)

Return Value

Result code as defined by [swShowNotificationResult_e](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::ShowUserNotification](#).

Example

See the [IUserNotificationHandler](#) examples.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SolidWorksExplorer Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : SolidWorksExplorer Method (ISldWorks)

Starts SOLIDWORKS Explorer.

.NET Syntax

Visual Basic (Declaration)

```
Sub SolidWorksExplorer()
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
instance.SolidWorksExplorer()
```

C#

```
void SolidWorksExplorer()
```

C++/CLI

```
void SolidWorksExplorer();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [SldWorks::SolidWorksExplorer](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2000 FCS

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartupProcessCompleted Property (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : StartupProcessCompleted Property (ISldWorks)

Gets whether the SOLIDWORKS startup process, including loading all startup add-ins, has completed.

.NET Syntax

ReadOnly Property StartupProcessCompleted As System.Boolean



```
Dim instance As ISldWorks
Dim value As System.Boolean

value = instance.StartupProcessCompleted
```

```
System.bool StartupProcessCompleted {get;}
```

```
property System.bool StartupProcessCompleted {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the SOLIDWORKS startup process, including loading all startup add-ins, has completed, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::StartupProcessCompleted](#)

Remarks

Use this property in out-of-process add-in applications to ensure that SOLIDWORKS, including loading all startup add-ins, is ready to receive additional API calls. For example, call this property before calling [ISldWorks::OpenDoc6](#) in an out-of-process add-in application.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

TaskPanelsPinned Property (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : TaskPanelsPinned Property (ISldWorks)

Gets or sets whether the SOLIDWORKS Task Pane is pinned.

.NET Syntax

Property TaskPaneIsPinned As System.Boolean



```
Dim instance As ISldWorks
Dim value As System.Boolean

instance.TaskPaneIsPinned = value

value = instance.TaskPaneIsPinned
```

```
System.bool TaskPaneIsPinned {get; set;}
```

C++/CLI

```
property System.bool TaskPaneIsPinned {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if SOLIDWORKS Task Pane is pinned, false if not

Visual Basic for Applications (VBA) Syntax

See [SldWorks::TaskPanelsPinned](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::ActivateTaskPane Method](#)
[ISldWorks::CreateTaskpaneView2 Method](#)
[ISldWorks::RefreshTaskpaneContent Method](#)
[ITaskpaneView Interface](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UnInstallQuickTipGuide Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : UnInstallQuickTipGuide Method (ISldWorks)

Uninstalls your add-in's [Quick Tips](#)

.NET Syntax

Visual Basic (Declaration)

```
Sub UnInstallQuickTipGuide( _  
    ByVal PInterface As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim PInterface As System.Object  
  
instance.UnInstallQuickTipGuide(PInterface)
```

C#

```
void UnInstallQuickTipGuide(  
    System.object PInterface  
)
```

C++/CLI

```
void UnInstallQuickTipGuide(  
& System.Object^ PInterface  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PInterface

Your add-in's [Quick Tips](#)

Visual Basic for Applications (VBA) Syntax

See [SldWorks::UninstallQuickTipGuide](#).

Remarks

See [Quick Tips and Bubble ToolTips](#) for details.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::RefreshQuickTipWindow Method](#)
[ISldWorks::InstallQuickTipGuide Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UnloadAddIn Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : UnloadAddIn Method (ISldWorks)

Unloads the specified add-in from SOLIDWORKS.

.NET Syntax

Visual Basic (Declaration)

```
Function UnloadAddIn( _  
    ByVal FileName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim value As System.Integer  
  
value = instance.UnloadAddIn(FileName)
```

C#

```
System.int UnloadAddIn(  
    System.string FileName  
)
```

C++/CLI

```
System.int UnloadAddIn(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Fully qualified file name of the add-in

Return Value

Status of unloading the add-in:

- 0: Successfully unloaded the add-in
- 1: Failed to unload the add-in due to some error condition

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::UnloadAddIn](#).

Example

[Load and Unload Add-in \(C#\)](#)
[Load and Unload Add-in \(VB.NET\)](#)
[Load and Unload Add-in \(VBA\)](#)

Remarks

You cannot unload MBD using its add-in path. Instead, unload the MBD add-in as follows:

```
status = swApp.UnloadAddIn('MBD')
```

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::LoadAddIn Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

UploadToMySolidWorksSettings Method (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : UploadToMySolidWorksSettings Method (ISldWorks)

Uploads the specified SOLIDWORKS Design settings to [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function UploadToMySolidWorksSettings( _  
    ByVal SystemOptions As System.Boolean, _  
    ByVal FileLocations As System.Boolean, _  
    ByVal Customizations As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim SystemOptions As System.Boolean  
Dim FileLocations As System.Boolean  
Dim Customizations As System.Boolean  
Dim value As System.Integer  
  
value = instance.UploadToMySolidWorksSettings(SystemOptions, FileLocations, Customizations)
```

C#

```
System.int UploadToMySolidWorksSettings(  
    System.bool SystemOptions,  
    System.bool FileLocations,  
    System.bool Customizations  
)
```

C++/CLI

```
System.int UploadToMySolidWorksSettings(  
& System.bool SystemOptions,  
& System.bool FileLocations,  
& System.bool Customizations  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SystemOptions
True to upload, false to not
FileLocations
True to upload, false to not
Customizations
True to upload, false to not

Return Value

Return code as defined by [swConnectedSyncSettingsErrors_e](#)

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::UploadToMySolidWorksSettings](#).

Remarks

In order to use this method, you must be logged into SOLIDWORKS Design connected to the 3DEXPERIENCE platform.

To turn on auto synchronization of settings, call:

- [ISldWorks::SetUserPreferenceToggle](#)([swUserPreferenceToggle_e](#).swAutomaticSyncSettings, True)

and then call one, two, or all three of:

- [ISldWorks::SetUserPreferenceToggle](#)([swUserPreferenceToggle_e](#).swAutoSyncSettingsToInclude_SystemOptions, True)
- [ISldWorks::SetUserPreferenceToggle](#)([swUserPreferenceToggle_e](#).swAutoSyncSettingsToInclude_FileLocations, True)
- [ISldWorks::SetUserPreferenceToggle](#)([swUserPreferenceToggle_e](#).swAutoSyncSettingsToInclude_Customizations, True)

To get the timestamp of the last synchronization,

call [ISldWorks::GetUserPreferenceStringValue](#)([swUserPreferenceStringValue_e](#).swLastSynchronizationTimeStamp).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::DownloadFromMySolidWorksSettings Method \(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

UserControl Property (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : UserControl Property (ISldWorks)

Gets and sets whether the user has control over the application.

.NET Syntax

Visual Basic (Declaration)

Property UserControl As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim value As System.Boolean  
  
instance.UserControl = value  
  
value = instance.UserControl
```

C#

```
System.bool UserControl {get; set;}
```

C++/CLI

```
property System.bool UserControl {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the user has control over the application, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::UserControl](#).

Example

[Run or Attach to SOLIDWORKS \(VBA\)](#)
[Traverse Bodies \(C++\)](#)
[Keep SOLIDWORKS Invisible While Activating Documents \(C#\)](#)
[Keep SOLIDWORKS Invisible While Activating Documents \(VB.NET\)](#)
[Keep SOLIDWORKS Invisible While Activating Documents \(VBA\)](#)
[Get Names of Configurations Using Variant \(C++\)](#)

Remarks

If the SOLIDWORKS Design application is started by your program, then the SOLIDWORKS Design application closes when your program ends. However, if you pass control of the SOLIDWORKS Design application to the end-user, then it remains running after your program ends.

Setting this property to true causes the SOLIDWORKS Design application to run in the foreground and be visible. Use [ISldWorks::UserControlBackground](#) if you want to run the SOLIDWORKS Design application in the background and not be visible.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::CloseDoc Method](#)
[ISldWorks::QuitDoc Method](#)
[ISldWorks::Visible Property](#)
[IFrame::KeepInvisible Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

UserControlBackground Property (ISldWorks)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : UserControlBackground Property (ISldWorks)

Gets and sets whether the user has control over the application.

.NET Syntax

Visual Basic (Declaration)

Property UserControlBackground As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.Boolean

instance.UserControlBackground = value
value = instance.UserControlBackground
```

C#

```
System.bool UserControlBackground {get; set;}
```

C++/CLI

```
property System.bool UserControlBackground {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the user has control over the application, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::UserControlBackground](#).

Remarks

Setting this property to true causes the SOLIDWORKS Design application to run in the background and not be visible. Use [ISldWorks::UserControl](#) if you want to run the SOLIDWORKS Design application in the foreground and be visible.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::UserControl Property](#)
[ISldWorks::Visible Property](#)
[IFrame::KeepInvisible Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UserTypeLibReferences Property (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : UserTypeLibReferences Property (ISldWorks)

Gets and sets the user-specified type library references.

.NET Syntax

Visual Basic (Declaration)

Property UserTypeLibReferences As System.Object

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.Object

instance.UserTypeLibReferences = value

value = instance.UserTypeLibReferences
```

C#

```
System.object UserTypeLibReferences {get; set;}
```

C++/CLI

```
property System.Object^ UserTypeLibReferences {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of the user-specified type library references

Visual Basic for Applications (VBA) Syntax

See [SldWorks::UserTypeLibReferences](#).

Example

[Add User-specified Type Library Reference \(VBA\)](#)

Remarks

An add-in can use this property to add its type library references after the add-in is loaded.

A user-specified type library first appears on the list of available references only after adding it and only after recording a macro.

User-specified type library references are not persistent across SOLIDWORKS Design sessions.

Only macros created after adding a user-specified type library reference can reference that type library.

See [Type Libraries](#) for details.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::GetUserTypeLibReferenceCount Method](#)
[ISldWorks::!GetUserTypeLibReferences Method](#)
[ISldWorks::!SetUserTypeLibReferences Method](#)
[ISldWorks::RemoveUserTypeLibReferences Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

VersionHistory Method (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : VersionHistory Method (ISldWorks)

Gets a list of strings indicating the versions in which a model was saved.

.NET Syntax

Visual Basic (Declaration)

```
Function VersionHistory( _  
    ByVal FileName As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISldWorks  
Dim FileName As System.String  
Dim value As System.Object  
  
value = instance.VersionHistory(FileName)
```

C#

```
System.Object VersionHistory(  
    System.string FileName  
)
```

C++/CLI

```
System.Object^ VersionHistory(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Full path name of the model for which to get the version history

Return Value

Array of strings containing the version history

Visual Basic for Applications (VBA) Syntax

See [SldWorks::VersionHistory](#).

Example

[Get Version History \(VBA\)](#)

Remarks

This information is retrieved from the file on disk, not from the open document.

There is one array entry for each major release of the SOLIDWORKS Design software in which the document has been saved. The format for each entry is a major release code followed by one or more minor release codes separated by commas:

<major release code>[<minor release code>]

- or -

<major release code>[<minor release code>,<minor release code>...]

where <major release code> equals a number that remains constant through a major release of the SOLIDWORKS Design software. For example, the following values are returned based on the corresponding major SOLIDWORKS Design version:

SOLIDWORKS Release	Version Number
SOLIDWORKS 95	44
SOLIDWORKS 96	243
SOLIDWORKS 97	483
SOLIDWORKS 97Plus	629
SOLIDWORKS 98	822
SOLIDWORKS 98Plus	1008
SOLIDWORKS 99	1137
SOLIDWORKS 2000	1500
SOLIDWORKS 2001	1750
SOLIDWORKS 2001Plus	1950
SOLIDWORKS 2003	2200
SOLIDWORKS 2004	2500
SOLIDWORKS 2005	2800
SOLIDWORKS 2006	3100
SOLIDWORKS 2007	3400
SOLIDWORKS 2008	3800
SOLIDWORKS 2009	4100
SOLIDWORKS 2010	4400
SOLIDWORKS 2011	4700
SOLIDWORKS 2012	5000
SOLIDWORKS 2013	6000
SOLIDWORKS 2014	7000
SOLIDWORKS 2015	8000
SOLIDWORKS 2016	9000
SOLIDWORKS 2017	10000

SOLIDWORKS 2018	11000
SOLIDWORKS 2019	12000
SOLIDWORKS 2020	13000
SOLIDWORKS 2021	14000
SOLIDWORKS 2022	15000
SOLIDWORKS 2023	16000
SOLIDWORKS 2024	17000
SOLIDWORKS 2025	18000
SOLIDWORKS 2026	19000

The <minor release code> equals the year and day of manufacture of a saving version (for example, 1997/320).

To get the version history of a document that is currently open, use [IModelDoc2::VersionHistory](#).

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[ISldWorks::IVersionHistory Method](#)
[ISldWorks::RevisionNumber Method](#)
[ISldWorks::GetBuildNumbers? Method](#)
[IModelDocExtension::IsFutureVersion Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments](#) on this topic.

Visible Property (ISldWorks)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISldWorks Interface](#) : Visible Property (ISldWorks)

Gets and sets the visibility property of the SOLIDWORKS Design application.

.NET Syntax

Visual Basic (Declaration)

Property Visible As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISldWorks
Dim value As System.Boolean
```

```
instance.Visible = value
```

```
value = instance.Visible
```

C#

```
System.bool Visible {get; set;}
```

C++/CLI

```
property System.bool Visible {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the application is visible, false if not

Visual Basic for Applications (VBA) Syntax

See [ISldWorks::Visible](#).

Example

[Open Document \(VBA\)](#)
[Run or Attach to SOLIDWORKS \(VBA\)](#)
[Traverse Bodies \(C++\)](#)
[Keep SOLIDWORKS Invisible While Activating Documents \(C#\)](#)
[Keep SOLIDWORKS Invisible While Activating Documents \(VB.NET\)](#)
[Keep SOLIDWORKS Invisible While Activating Documents \(VBA\)](#)
[Get Names of Configurations Using Variant \(C++\)](#)

Remarks

If the SOLIDWORKS Design application is started by your program, then the SOLIDWORKS Design application closes when your program ends. It makes no difference whether you make the SOLIDWORKS Design session visible.

However, if your program started the SOLIDWORKS Design application and you assign control of the SOLIDWORKS Design application to the end-user using [ISldWorks::UserControl](#), then it remains running even when your program ends.

Also, the SOLIDWORKS Design application can only be hidden if `ISldWorks::UserControl` is false and there are no visible documents open.

See Also

[ISldWorks Interface](#)
[ISldWorks Members](#)
[IFrame::KeepInvisible Property](#)
[ISldWorks::UserControl Property](#)
[ISldWorks::UserControlBackground Property](#)