

SOLIDWORKS API (.NET VBA C#) — Reference (314/337): IThickenFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IThickenFeatureData (Type)

IThickenFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IThickenFeatureData Interface

Allows access to a thicken feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IThickenFeatureData
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData
```

C#

```
public interface IThickenFeatureData
```

C++/CLI

```
public interface class IThickenFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData](#).

Example

[Create Thicken Feature \(VBA\)](#)
[Thicken Surface and Generate Boss \(VBA\)](#)
[Thicken Surface and Generate Boss \(VB.NET\)](#)
[Thicken Surface and Generate Boss \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[ThickenFeatureData](#)

See Also

[IThickenFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureBossThicken Method](#)
[IFeatureManager::FeatureCutThicken Method](#)

IThickenFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IThickenFeatureData Interface

For a list of all members of this type, see [IThickenFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this thicken feature.

 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the thicken feature in a multibody part.
 IAccessSelections	Gains access to the selections that define this thicken feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the thicken feature affects in a multibody part.
 IsBossFeature	Gets whether this feature is a boss or a cut.
 ISetFeatureScopeBodies	Sets the solid bodies that the thicken feature affects in a multibody part.
 ReleaseSelectionAccess	Releases the selections that created this thicken feature.

[Top](#)

See Also

[IThickenFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureBossThicken Method](#)
[IFeatureManager::FeatureCutThicken Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IThickenFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IThickenFeatureData Interface

The following tables list the members exposed by [IThickenFeatureData](#).

Public Properties

Name	Description
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the thicken feature to affect in a multibody part.
 FeatureScope	Gets or sets whether to use scope for the thicken feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the thicken feature affects in a multibody part.
 FillVolume	Gets or sets whether to fill a volume with this thicken feature.
 Merge	Gets or sets whether to merge the results of this thicken feature in a multibody part.
 Surface	Gets or sets the thickened surface.
 Thickness	Gets or sets the thickness for this thicken feature.
 ThicknessSide	Gets or sets which side to apply thickness.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this thicken feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the thicken feature in a multibody part.
 IAccessSelections	Gains access to the selections that define this thicken feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the thicken feature affects in a multibody part.
 IsBossFeature	Gets whether this feature is a boss or a cut.
 ISetFeatureScopeBodies	Sets the solid bodies that the thicken feature affects in a multibody part.
 ReleaseSelectionAccess	Releases the selections that created this thicken feature.

[Top](#)

See Also

[IThickenFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureBossThicken Method](#)
[IFeatureManager::FeatureCutThicken Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IThickenFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IThickenFeatureData Interface

For a list of all members of this type, see [IThickenFeatureData members](#).

Public Properties

Name	Description
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the thicken feature to affect in a multibody part.
 FeatureScope	Gets or sets whether to use scope for the thicken feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the thicken feature affects in a multibody part.
 FillVolume	Gets or sets whether to fill a volume with this thicken feature.
 Merge	Gets or sets whether to merge the results of this thicken feature in a multibody part.
 Surface	Gets or sets the thickened surface.
 Thickness	Gets or sets the thickness for this thicken feature.
 ThicknessSide	Gets or sets which side to apply thickness.

[Top](#)

See Also

[IThickenFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureBossThicken Method](#)
[IFeatureManager::FeatureCutThicken Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IThickenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : AccessSelections Method (IThickenFeatureData)

Gains access to the selections that define this thicken feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IThickenFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,
```

```
& System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component to which this feature is to be applied

Return Value

True if access is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::AccessSelections](#).

Example

[Create Thicken Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IThickenFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IThickenFeatureData Interface](#)

[IThickenFeatureData Members](#)

[IThickenFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoSelect Property (IThickenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : AutoSelect Property (IThickenFeatureData)

Gets or sets whether to automatically select all or only specific bodies for the thicken feature to affect in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property AutoSelect As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IThickenFeatureData
Dim value As System.Boolean
```

```
instance.AutoSelect = value
```

```
value = instance.AutoSelect
```

C#



```
System.bool AutoSelect {get; set;}
```

C++/CLI

```
property System.bool AutoSelect {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies, false to select specific bodies using [IThickenFeatureData::FeatureScopeBodies](#) or [IThickenFeatureData::ISetFeatureScopeBodies](#).

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::AutoSelect](#).

Example

[Create Thicken Feature \(VBA\)](#)

Remarks

This property is only available when the [IThickenFeatureData::FeatureScope](#) property is true. The thicken feature is expanded along the plane on which the feature is created and selects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::GetFeatureScopeBodies Method](#)
[IThickenFeatureData::FeatureScope Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScope Property (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : FeatureScope Property (IThickenFeatureData)

Gets or sets whether to use scope for the thicken feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureScope As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
Dim value As System.Boolean
```

```
instance.FeatureScope = value
```

```
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get; set;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

When:

- true, only the specified bodies in the multibody part are affected by the thicken feature
- false, all of the bodies in the multibody part are affected by the thicken feature

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData.FeatureScope](#).

Remarks

The thicken feature is expanded along the plane on which the feature is created and affects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::GetFeatureScopeBodiesCount Method](#)
[IThickenFeatureData::IGetFeatureScopeBodies Method](#)
[IThickenFeatureData::ISetFeatureScopeBodies Method](#)
[IThickenFeatureData::AutoSelect Property](#)
[IThickenFeatureData::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScopeBodies Property (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : FeatureScopeBodies Property (IThickenFeatureData)

Gets or sets the solid bodies that the thicken feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property FeatureScopeBodies As System.Object
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
Dim value As System.Object
```

```
instance.FeatureScopeBodies = value
```

```
value = instance.FeatureScopeBodies
```

C#

```
System.object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {  
    System.Object^ get();
```

```
void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of solid [bodies](#) that the feature affects

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::FeatureScopeBodies](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::GetFeatureScopeBodiesCount Method](#)
[IThickenFeatureData::IGetFeatureScopeBodies Method](#)
[IThickenFeatureData::ISetFeatureScopeBodies Method](#)
[IThickenFeatureData::AutoSelect Property](#)
[IThickenFeatureData::FeatureScope Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FillVolume Property (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : FillVolume Property (IThickenFeatureData)

Gets or sets whether to fill a volume with this thicken feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FillVolume As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
Dim value As System.Boolean
```

```
instance.FillVolume = value
```

```
value = instance.FillVolume
```

C#

```
System.bool FillVolume {get; set;}
```

C++/CLI

```
property System.bool FillVolume {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to fill a volume, false to not

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::FillVolume](#).

Example

See the [IThickenFeatureData](#) examples.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeatureScopeBodiesCount Method (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : GetFeatureScopeBodiesCount Method (IThickenFeatureData)

Gets the number of solid bodies affected by the thicken feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureScopeBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
Dim value As System.Integer  
  
value = instance.GetFeatureScopeBodiesCount()
```

C#

```
System.int GetFeatureScopeBodiesCount()
```

C++/CLI

```
System.int GetFeatureScopeBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of solid bodies affected by the thicken feature

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::GetFeatureScopeBodiesCount](#).

Remarks

COM users must call this method before calling the [IThickenFeatureData::!GetFeatureScopeBodies](#) method.

If [IThickenFeatureData::FeatureScope](#) is false, then count is 0.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::!SetFeatureScopeBodies Method](#)

 Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : IAccessSelections Method (IThickenFeatureData)

Gains access to the selections that define this thicken feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
    & ModelDoc2^ TopDoc,  
    & Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component to which this feature is to be applied

Return Value

TRUE if access is successful, FALSE if not

 Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::IAccessSelections](#).

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IThickenFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFeatureScopeBodies Method (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : IGetFeatureScopeBodies Method (IThickenFeatureData)

Gets the solid bodies that the thicken feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeatureScopeBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
Dim Count As System.Integer  
Dim value As Body2
```

```
value = instance.IGetFeatureScopeBodies(Count)
```

C#

```
Body2 IGetFeatureScopeBodies(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetFeatureScopeBodies(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

Return Value

- in-process, unmanaged C++: Pointer to an array of solid bodies that the thicken feature affects in a multibody part of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

COM users must call [IThickenFeatureData::GetFeatureScopeBodiesCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::ISetFeatureScopeBodies Method](#)
[IThickenFeatureData::FeatureScope Property](#)
[IThickenFeatureData::FeatureScopeBodies Property](#)
[IThickenFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsBossFeature Method (IThickenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : IsBossFeature Method (IThickenFeatureData)

Gets whether this feature is a boss or a cut.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBossFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData
Dim value As System.Boolean

value = instance.IsBossFeature()
```

C#

```
System.bool IsBossFeature()
```

C++/CLI

```
System.bool IsBossFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the feature is a boss, false if a cut

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::IsBossFeature](#).

Example

[Create Thicken Feature \(VBA\)](#)

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)

Availability

SOLIDWORKS 2003 SP2, Revision Number 11.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFeatureScopeBodies Method (IThickenFeatureData)

[See Also](#)



Sets the solid bodies that the thicken feature affects in a multibody part.

VB.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFeatureScopeBodies( _
    ByVal Count As System.Integer, _
    ByRef BodyArr As Body2 _
)
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData
Dim Count As System.Integer
Dim BodyArr As Body2
```

```
instance.ISetFeatureScopeBodies(Count, BodyArr)
```

C#

```
void ISetFeatureScopeBodies(
    System.int Count,
    ref Body2 BodyArr
)
```

C++/CLI

```
void ISetFeatureScopeBodies(
    & System.int Count,
    & Body2^% BodyArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

BodyArr

- in-process, unmanaged C++: Pointer to an array of solid bodies that the thicken feature affects in a multibody part of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::GetFeatureScopeBodiesCount Method](#)
[IThickenFeatureData::IGetFeatureScopeBodies Method](#)
[IThickenFeatureData::FeatureScope Property](#)
[IThickenFeatureData::FeatureScopeBodies Property](#)
[IThickenFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

Merge Property (IThickenFeatureData)

[See Also](#) [Example](#)



Gets or sets whether to merge the results of this thicken feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property Merge As System.Boolean

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData
Dim value As System.Boolean

instance.Merge = value
value = instance.Merge
```

C#

```
System.bool Merge {get; set;}
```

C++/CLI

```
property System.bool Merge {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables the merge results option, false disables it

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData.Merge](#).

Example

See the [IThickenFeatureData](#) examples.

Example

[Create Thicken Feature \(VBA\)](#)

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IThickenFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : ReleaseSelectionAccess Method (IThickenFeatureData)

Releases the selections that created this thicken feature.

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::ReleaseSelectionAccess](#).

Example

[Create Thicken Feature \(VBA\)](#)

Remarks

[IThickenFeatureData::AccessSelections](#) and [IThickenFeatureData::IAccessSelections](#) put the model in a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did modify the feature.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Surface Property (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : Surface Property (IThickenFeatureData)

Gets or sets the thickened surface.

.NET Syntax

Visual Basic (Declaration)

```
Property Surface As System.Object
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
Dim value As System.Object
```

```
instance.Surface = value
```

```
value = instance.Surface
```

C#

```
System.object Surface {get; set;}
```

C++/CLI

```
property System.Object^ Surface {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thickened surface, which is an [IBody2](#) object

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::Surface](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Thickness Property (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : Thickness Property (IThickenFeatureData)

Gets or sets the thickness for this thicken feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Thickness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData
Dim value As System.Double
```

```
instance.Thickness = value
```

```
value = instance.Thickness
```

C#

```
System.double Thickness {get; set;}
```

C++/CLI

```
property System.double Thickness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thickness

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::Thickness](#).

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::ThicknessSide Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThicknessSide Property (IThickenFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IThickenFeatureData Interface](#) : ThicknessSide Property (IThickenFeatureData)

Gets or sets which side to apply thickness.

.NET Syntax

Visual Basic (Declaration)

Property ThicknessSide As System.Short

Visual Basic (Usage)



```
Dim instance As IThickenFeatureData  
Dim value As System.Short
```

```
instance.ThicknessSide = value
```

```
value = instance.ThicknessSide
```

C#

```
System.short ThicknessSide {get; set;}
```

C++/CLI

```
property System.short ThicknessSide {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Side thickness type as defined in [swThickenThicknessType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ThickenFeatureData::ThicknessSide](#).

Example

See the [IThickenFeatureData](#) examples.

See Also

[IThickenFeatureData Interface](#)
[IThickenFeatureData Members](#)
[IThickenFeatureData::Thickness Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0