


# **SOLIDWORKS API (VB6 COM) — Reference (2/102): Annotation-AppearanceSetting**

SOLIDWORKS API Documentation (converted from CHM)

# Annotation (Type)

SOLIDWORKS Type Library  
Annotation Object

Object Model



SOLIDWORKS Type Library  
Annotation Object Members

Public Methods

|  |                                                  |
|--|--------------------------------------------------|
|  | <a href="#">AddOrUpdateStyle</a>                 |
|  | <a href="#">ApplyDefaultStyleAttributes</a>      |
|  | <a href="#">CanShowInAnnotationView</a>          |
|  | <a href="#">CanShowInMultipleAnnotationViews</a> |
|  | <a href="#">CheckSpelling</a>                    |
|  | <a href="#">ConvertToMultiJog</a>                |
|  | <a href="#">DeleteStyle</a>                      |
|  | <a href="#">DeSelect</a>                         |
|  | <a href="#">GetArrowHeadCount</a>                |
|  | <a href="#">GetArrowHeadSizeAtIndex</a>          |
|  | <a href="#">GetArrowHeadStyleAtIndex</a>         |
|  | <a href="#">GetAttachedEntities</a>              |
|  | <a href="#">GetAttachedEntities2</a>             |
|  | <a href="#">GetAttachedEntities3</a>             |
|  | <a href="#">GetAttachedEntityCount2</a>          |
|  | <a href="#">GetAttachedEntityCount3</a>          |
|  | <a href="#">GetAttachedEntityType</a>            |
|  | <a href="#">GetBentLeader</a>                    |
|  | <a href="#">GetDashedLeader</a>                  |
|  | <a href="#">GetDimXpertFeature</a>               |
|  | <a href="#">GetDimXpertName</a>                  |

|                                                                                     |                                                |
|-------------------------------------------------------------------------------------|------------------------------------------------|
|    | <a href="#"><u>GetDisplayData</u></a>          |
|    | <a href="#"><u>GetFlipPlaneTransform</u></a>   |
|    | <a href="#"><u>GetLeader</u></a>               |
|    | <a href="#"><u>GetLeaderAllAround</u></a>      |
|    | <a href="#"><u>GetLeaderCount</u></a>          |
|    | <a href="#"><u>GetLeaderPerpendicular</u></a>  |
|    | <a href="#"><u>GetLeaderPointsAtIndex</u></a>  |
|    | <a href="#"><u>GetLeaderSide</u></a>           |
|    | <a href="#"><u>GetLeaderStyle</u></a>          |
|    | <a href="#"><u>GetMultiJogLeaderCount</u></a>  |
|    | <a href="#"><u>GetMultiJogLeaders</u></a>      |
|    | <a href="#"><u>GetName</u></a>                 |
|    | <a href="#"><u>GetNext</u></a>                 |
|    | <a href="#"><u>GetNext2</u></a>                |
|    | <a href="#"><u>GetNext3</u></a>                |
|    | <a href="#"><u>GetParagraphs</u></a>           |
|    | <a href="#"><u>GetPlane</u></a>                |
|    | <a href="#"><u>GetPMIData</u></a>              |
|    | <a href="#"><u>GetPMIType</u></a>              |
|    | <a href="#"><u>GetPosition</u></a>             |
|    | <a href="#"><u>GetSmartArrowHeadStyle</u></a>  |
|   | <a href="#"><u>GetSpecificAnnotation</u></a>   |
|  | <a href="#"><u>GetStyleName</u></a>            |
|  | <a href="#"><u>GetTextFormat</u></a>           |
|  | <a href="#"><u>GetTextFormatCount</u></a>      |
|  | <a href="#"><u>GetType</u></a>                 |
|  | <a href="#"><u>GetUseDocTextFormat</u></a>     |
|  | <a href="#"><u>GetVisualProperties</u></a>     |
|  | <a href="#"><u>IGetAttachedEntities</u></a>    |
|  | <a href="#"><u>IGetAttachedEntityCount</u></a> |
|  | <a href="#"><u>IGetAttachedEntityTypes</u></a> |
|  | <a href="#"><u>IGetDisplayData</u></a>         |
|  | <a href="#"><u>IGetLeaderPointsAtIndex</u></a> |
|  | <a href="#"><u>IGetMultiJogLeaders</u></a>     |
|  | <a href="#"><u>IGetNext</u></a>                |
|  | <a href="#"><u>IGetNext2</u></a>               |
|  | <a href="#"><u>IGetPosition</u></a>            |
|  | <a href="#"><u>IGetSpecificAnnotation</u></a>  |
|  | <a href="#"><u>IGetTextFormat</u></a>          |
|  | <a href="#"><u>IGetVisualProperties</u></a>    |
|  | <a href="#"><u>IsDangling</u></a>              |
|  | <a href="#"><u>IsDimXpert</u></a>              |
|  | <a href="#"><u>ISetAttachedEntities</u></a>    |

|                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">ISetTextFormat</a>                  |
|  <a href="#">LoadStyle</a>                       |
|  <a href="#">SaveStyle</a>                       |
|  <a href="#">Select</a>                          |
|  <a href="#">Select2</a>                         |
|  <a href="#">Select3</a>                         |
|  <a href="#">SelectByMark</a>                    |
|  <a href="#">SetArrowHeadSizeAtIndex</a>         |
|  <a href="#">SetArrowHeadStyleAtIndex</a>        |
|  <a href="#">SetAttachedEntities</a>             |
|  <a href="#">SetLeader</a>                       |
|  <a href="#">SetLeader2</a>                      |
|  <a href="#">SetLeader3</a>                      |
|  <a href="#">SetLeaderAttachmentPointAtIndex</a> |
|  <a href="#">SetName</a>                         |
|  <a href="#">SetPosition</a>                     |
|  <a href="#">SetPosition2</a>                    |
|  <a href="#">SetStyleName</a>                    |
|  <a href="#">SetTextFormat</a>                   |

## Public Properties

|                                                                                                                           |
|---------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">AnnotationView</a>        |
|  <a href="#">BentLeaderLength</a>      |
|  <a href="#">Color</a>                 |
|  <a href="#">FrameLineStyle</a>        |
|  <a href="#">FrameThickness</a>        |
|  <a href="#">FrameThicknessCustom</a>  |
|  <a href="#">Layer</a>                 |
|  <a href="#">LayerOverride</a>         |
|  <a href="#">LeaderLineStyle</a>       |
|  <a href="#">LeaderThickness</a>       |
|  <a href="#">LeaderThicknessCustom</a> |
|  <a href="#">Owner</a>                 |
|  <a href="#">OwnerType</a>             |
|  <a href="#">Style</a>                 |
|  <a href="#">UseDocDispFrame</a>       |
|  <a href="#">UseDocDispLeader</a>      |
|  <a href="#">Visible</a>               |
|  <a href="#">Width</a>                 |

SOLIDWORKS Type Library

## AddOrUpdateStyle Method (Annotation)

## Syntax

Visual Basic for Applications (VBA)

```
Public Function AddOrUpdateStyle( _  
    ByVal StyleName As String, _  
    ByVal BreakLinks As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

#### AnnotationView Property (Annotation)



Syntax

Visual Basic for Applications (VBA)

```
Public Property AnnotationView As AnnotationView
```

SOLIDWORKS Type Library

#### ApplyDefaultStyleAttributes Method (Annotation)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ApplyDefaultStyleAttributes() As Boolean
```

SOLIDWORKS Type Library

#### BentLeaderLength Property (Annotation)



Syntax

Visual Basic for Applications (VBA)

```
Public Property BentLeaderLength As Double
```

SOLIDWORKS Type Library

#### CanShowInAnnotationView Method (Annotation)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CanShowInAnnotationView( _  
    ByVal AnnotationViewName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

#### CanShowInMultipleAnnotationViews Method (Annotation)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CanShowInMultipleAnnotationViews() As Boolean
```

SOLIDWORKS Type Library

#### CheckSpelling Method (Annotation)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CheckSpelling( _  
    ByVal Options As Long, _  
    ByVal Dictionary As String _  
    ) As Variant
```

SOLIDWORKS Type Library

#### Color Property (Annotation)



Syntax

Visual Basic for Applications (VBA)

Public Property Color As Long

SOLIDWORKS Type Library

**ConvertToMultiJog Method (Annotation)**



Visual Basic for Applications (VBA)

```
Public Function ConvertToMultiJog( _  
    ByVal LeaderNumber As Long, _  
    ByVal NumberOfPoints As Long, _  
    ByVal PointsData As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

**DeleteStyle Method (Annotation)**



Visual Basic for Applications (VBA)

```
Public Function DeleteStyle( _  
    ByVal StyleName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

**DeSelect Method (Annotation)**



Visual Basic for Applications (VBA)

```
Public Function DeSelect() As Boolean
```

SOLIDWORKS Type Library

**FrameLineStyle Property (Annotation)**



Visual Basic for Applications (VBA)

```
Public Property FrameLineStyle As Long
```

SOLIDWORKS Type Library

**FrameThickness Property (Annotation)**



Visual Basic for Applications (VBA)

```
Public Property FrameThickness As Long
```

SOLIDWORKS Type Library

**FrameThicknessCustom Property (Annotation)**



Visual Basic for Applications (VBA)

```
Public Property FrameThicknessCustom As Double
```

SOLIDWORKS Type Library

**GetArrowHeadCount Method (Annotation)**



Visual Basic for Applications (VBA)

```
Public Function GetArrowHeadCount() As Long
```

**GetArrowHeadSizeAtIndex Method (Annotation)****Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetArrowHeadSizeAtIndex( _  
    ByVal Index As Long, _  
    ByRef UseDoc As Boolean, _  
    ByRef Length As Double, _  
    ByRef Width As Double, _  
    ByRef Height As Double _  
    ) As Boolean
```

**GetArrowHeadStyleAtIndex Method (Annotation)****Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetArrowHeadStyleAtIndex( _  
    ByVal Index As Long _  
    ) As Long
```

**GetAttachedEntities Method (Annotation)****Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetAttachedEntities() As Variant
```

**GetAttachedEntities2 Method (Annotation)****Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetAttachedEntities2() As Variant
```

**GetAttachedEntities3 Method (Annotation)****Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetAttachedEntities3() As Variant
```

**GetAttachedEntityCount2 Method (Annotation)****Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetAttachedEntityCount2() As Long
```

**GetAttachedEntityCount3 Method (Annotation)****Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetAttachedEntityCount3() As Long
```

## GetAttachedEntityTypes Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAttachedEntityTypes() As Variant
```

SOLIDWORKS Type Library

## GetBentLeader Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBentLeader() As Boolean
```

SOLIDWORKS Type Library

## GetDashedLeader Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDashedLeader() As Boolean
```

SOLIDWORKS Type Library

## GetDimXpertFeature Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDimXpertFeature() As Object
```

SOLIDWORKS Type Library

## GetDimXpertName Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDimXpertName() As String
```

SOLIDWORKS Type Library

## GetDisplayData Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDisplayData() As Object
```

SOLIDWORKS Type Library

## GetFlipPlaneTransform Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFlipPlaneTransform() As MathTransform
```

SOLIDWORKS Type Library

## GetLeader Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLeader() As Boolean
```

SOLIDWORKS Type Library

#### GetLeaderAllAround Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLeaderAllAround() As Boolean
```

SOLIDWORKS Type Library

#### GetLeaderCount Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLeaderCount() As Long
```

SOLIDWORKS Type Library

#### GetLeaderPerpendicular Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLeaderPerpendicular() As Boolean
```

SOLIDWORKS Type Library

#### GetLeaderPointsAtIndex Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLeaderPointsAtIndex( _  
    ByVal Index As Long _  
) As Variant
```

SOLIDWORKS Type Library

#### GetLeaderSide Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLeaderSide() As Long
```

SOLIDWORKS Type Library

#### GetLeaderStyle Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLeaderStyle() As Long
```

SOLIDWORKS Type Library

#### GetMultiJogLeaderCount Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMultiJogLeaderCount() As Long
```

SOLIDWORKS Type Library

#### GetMultiJogLeaders Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMultiJogLeaders() As Variant
```

SOLIDWORKS Type Library

### GetName Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetName() As String
```

SOLIDWORKS Type Library

### GetNext Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetNext() As Object
```

SOLIDWORKS Type Library

### GetNext2 Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetNext2() As Object
```

SOLIDWORKS Type Library

### GetNext3 Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetNext3() As Annotation
```

SOLIDWORKS Type Library

### GetParagraphs Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetParagraphs() As Object
```

SOLIDWORKS Type Library

### GetPlane Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetPlane() As Variant
```

SOLIDWORKS Type Library

### GetPMIData Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetPMIData() As Object
```

SOLIDWORKS Type Library

### GetPMIType Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetPMIType() As Long
```

SOLIDWORKS Type Library

## GetPosition Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetPosition() As Variant
```

SOLIDWORKS Type Library

## GetSmartArrowHeadStyle Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetSmartArrowHeadStyle() As Boolean
```

SOLIDWORKS Type Library

## GetSpecificAnnotation Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetSpecificAnnotation() As Object
```

SOLIDWORKS Type Library

## GetStyleName Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetStyleName() As String
```

SOLIDWORKS Type Library

## GetTextFormat Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetTextFormat( _  
    ByVal Index As Long _  
) As Object
```

SOLIDWORKS Type Library

## GetTextFormatCount Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetTextFormatCount() As Long
```

SOLIDWORKS Type Library

## GetType Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetType() As Long
```

SOLIDWORKS Type Library

## GetUseDocTextFormat Method (Annotation)



Visual Basic for Applications (VBA)

```
Public Function GetUseDocTextFormat( _  
    ByVal Index As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

**GetVisualProperties Method (Annotation)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetVisualProperties() As Variant
```

SOLIDWORKS Type Library

**IGetAttachedEntities Method (Annotation)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAttachedEntities() As Unknown
```

SOLIDWORKS Type Library

**IGetAttachedEntityCount Method (Annotation)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAttachedEntityCount() As Long
```

SOLIDWORKS Type Library

**IGetAttachedEntityTypes Method (Annotation)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAttachedEntityTypes() As Long
```

SOLIDWORKS Type Library

**IGetDisplayData Method (Annotation)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetDisplayData() As DisplayData
```

SOLIDWORKS Type Library

**IGetLeaderPointsAtIndex Method (Annotation)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetLeaderPointsAtIndex( _  
    ByVal Index As Long, _  
    ByVal PointCount As Long _  
    ) As Double
```

SOLIDWORKS Type Library

**IGetMultiJogLeaders Method (Annotation)**



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetMultiJogLeaders( _  
    ByVal Count As Long _  
) As MultiJogLeader
```

SOLIDWORKS Type Library

#### IGetNext Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNext() As Annotation
```

SOLIDWORKS Type Library

#### IGetNext2 Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNext2() As Annotation
```

SOLIDWORKS Type Library

#### IGetPosition Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPosition() As Double
```

SOLIDWORKS Type Library

#### IGetSpecificAnnotation Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSpecificAnnotation() As Unknown
```

SOLIDWORKS Type Library

#### IGetTextFormat Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTextFormat( _  
    ByVal Index As Long _  
) As TextFormat
```

SOLIDWORKS Type Library

#### IGetVisualProperties Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetVisualProperties() As Long
```

SOLIDWORKS Type Library

#### IsDangling Method (Annotation)

##### Syntax

Visual Basic for Applications (VBA)

```
Public Function IsDangling() As Boolean
```

SOLIDWORKS Type Library

## IsDimXpert Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function IsDimXpert() As Boolean
```

SOLIDWORKS Type Library

## ISetAttachedEntities Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetAttachedEntities( _  
    ByVal Count As Long, _  
    ByRef LpArr As Object _  
) As Boolean
```

SOLIDWORKS Type Library

## ISetTextFormat Method (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetTextFormat( _  
    ByVal Index As Long, _  
    ByVal UseDoc As Boolean, _  
    ByVal TextFormat As TextFormat _  
) As Boolean
```

SOLIDWORKS Type Library

## Layer Property (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property Layer As String
```

SOLIDWORKS Type Library

## LayerOverride Property (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property LayerOverride As Integer
```

SOLIDWORKS Type Library

## LeaderLineStyle Property (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property LeaderLineStyle As Long
```

SOLIDWORKS Type Library

## LeaderThickness Property (Annotation)

### Syntax

Visual Basic for Applications (VBA)

```
Public Property LeaderThickness As Long
```

SOLIDWORKS Type Library

## LeaderThicknessCustom Property (Annotation)



Visual Basic for Applications (VBA)

```
Public Property LeaderThicknessCustom As Double
```

SOLIDWORKS Type Library

**LoadStyle Method (Annotation)**



Visual Basic for Applications (VBA)

```
Public Function LoadStyle( _  
    ByVal PathName As String _  
) As Boolean
```

SOLIDWORKS Type Library

**Owner Property (Annotation)**



Visual Basic for Applications (VBA)

```
Public Property Owner As Object
```

SOLIDWORKS Type Library

**OwnerType Property (Annotation)**



Visual Basic for Applications (VBA)

```
Public Property OwnerType As Long
```

SOLIDWORKS Type Library

**SaveStyle Method (Annotation)**



Visual Basic for Applications (VBA)

```
Public Function SaveStyle( _  
    ByVal StyleName As String, _  
    ByVal PathName As String _  
) As Boolean
```

SOLIDWORKS Type Library

**Select Method (Annotation)**



Visual Basic for Applications (VBA)

```
Public Function Select( _  
    ByVal AppendFlag As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

**Select2 Method (Annotation)**



Visual Basic for Applications (VBA)

```
Public Function Select2( _  
    ByVal Append As Boolean, _  
    ByVal Mark As Long _  
) As Boolean
```

SOLIDWORKS Type Library

**Select3 Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function Select3( _  
    ByVal Append As Boolean, _  
    ByVal Data As SelectData _  
) As Boolean
```

SOLIDWORKS Type Library

**SelectByMark Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function SelectByMark( _  
    ByVal AppendFlag As Boolean, _  
    ByVal Mark As Long _  
) As Boolean
```

SOLIDWORKS Type Library

**SetArrowHeadSizeAtIndex Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function SetArrowHeadSizeAtIndex( _  
    ByVal Index As Long, _  
    ByVal UseDoc As Boolean, _  
    ByVal Length As Double, _  
    ByVal Width As Double, _  
    ByVal Height As Double _  
) As Boolean
```

SOLIDWORKS Type Library

**SetArrowHeadStyleAtIndex Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function SetArrowHeadStyleAtIndex( _  
    ByVal Index As Long, _  
    ByVal ArrowHeadStyle As Long _  
) As Long
```

SOLIDWORKS Type Library

**SetAttachedEntities Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function SetAttachedEntities( _  
    ByVal AttachedEnts As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

**SetLeader Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function SetLeader( _  
    ByVal Leader As Boolean, _  
    ByVal LeaderSide As Long, _  
    ByVal SmartArrowHeadStyle As Boolean, _  
    ByVal BentLeader As Boolean _  
) As Long
```

**SetLeader2 Method (Annotation)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetLeader2( _  
    ByVal Leader As Boolean, _  
    ByVal LeaderSide As Long, _  
    ByVal SmartArrowHeadStyle As Boolean, _  
    ByVal BentLeader As Boolean, _  
    ByVal Perpendicular As Boolean, _  
    ByVal AllAround As Boolean _  
) As Long
```

**SetLeader3 Method (Annotation)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetLeader3( _  
    ByVal LeaderStyle As Long, _  
    ByVal LeaderSide As Long, _  
    ByVal SmartArrowHeadStyle As Boolean, _  
    ByVal Perpendicular As Boolean, _  
    ByVal AllAround As Boolean, _  
    ByVal Dashed As Boolean _  
) As Long
```

**SetLeaderAttachmentPointAtIndex Method (Annotation)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetLeaderAttachmentPointAtIndex( _  
    ByVal Index As Long, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

**SetName Method (Annotation)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetName( _  
    ByVal NameIn As String _  
) As Boolean
```

**SetPosition Method (Annotation)** **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetPosition( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

**SetPosition2 Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function SetPosition2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

**SetStyleName Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function SetStyleName( _  
    ByVal StyleName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

**SetTextFormat Method (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTextFormat( _  
    ByVal Index As Long, _  
    ByVal UseDoc As Boolean, _  
    ByVal TextFormat As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

**Style Property (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Property Style As Long
```

SOLIDWORKS Type Library

**UseDocDispFrame Property (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Property UseDocDispFrame As Boolean
```

SOLIDWORKS Type Library

**UseDocDispLeader Property (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Property UseDocDispLeader As Boolean
```

SOLIDWORKS Type Library

**Visible Property (Annotation)**

## Syntax

Visual Basic for Applications (VBA)

```
Public Property Visible As Long
```

SOLIDWORKS Type Library

**Width Property (Annotation)**

Public Property Width As Long

# AnnotationView (Type)

SOLIDWORKS Type Library  
AnnotationView Object

Object Model

AnnotationView

IGetAnnotations (Annotation)

SOLIDWORKS Type Library  
AnnotationView Object Members

Public Methods

|                                                                                     |                                     |
|-------------------------------------------------------------------------------------|-------------------------------------|
|    | <a href="#">Activate</a>            |
|    | <a href="#">ActivateAndReorient</a> |
|    | <a href="#">GetAnnotations2</a>     |
|    | <a href="#">GetViewRotation</a>     |
|    | <a href="#">Hide</a>                |
|    | <a href="#">IGetAnnotations</a>     |
|    | <a href="#">IGetViewRotation</a>    |
|    | <a href="#">IsShown</a>             |
|   | <a href="#">MoveAnnotations</a>     |
|  | <a href="#">Orient</a>              |
|  | <a href="#">Show</a>                |

Public Properties

|                                                                                     |                                             |
|-------------------------------------------------------------------------------------|---------------------------------------------|
|  | <a href="#">Always2D</a>                    |
|  | <a href="#">AngleMadeWithViewHorizontal</a> |
|  | <a href="#">AnnotationCount</a>             |
|  | <a href="#">Annotations</a>                 |
|  | <a href="#">FlatPatternView</a>             |
|  | <a href="#">UnassignedView</a>              |

SOLIDWORKS Type Library  
Activate Method (AnnotationView)

Syntax

|                                       |
|---------------------------------------|
| Visual Basic for Applications (VBA)   |
| Public Function Activate() As Boolean |

SOLIDWORKS Type Library  
ActivateAndReorient Method (AnnotationView)

Syntax

|                                                  |
|--------------------------------------------------|
| Visual Basic for Applications (VBA)              |
| Public Function ActivateAndReorient() As Boolean |

SOLIDWORKS Type Library

## Always2D Property (AnnotationView)



Visual Basic for Applications (VBA)

```
Public Property Always2D As Boolean
```

## SOLIDWORKS Type Library

### AngleMadeWithViewHorizontal Property (AnnotationView)



Visual Basic for Applications (VBA)

```
Public Property AngleMadeWithViewHorizontal As Double
```

## SOLIDWORKS Type Library

### AnnotationCount Property (AnnotationView)



Visual Basic for Applications (VBA)

```
Public Property AnnotationCount As Long
```

## SOLIDWORKS Type Library

### Annotations Property (AnnotationView)



Visual Basic for Applications (VBA)

```
Public Property Annotations As Variant
```

## SOLIDWORKS Type Library

### FlatPatternView Property (AnnotationView)



Visual Basic for Applications (VBA)

```
Public Property FlatPatternView As Boolean
```

## SOLIDWORKS Type Library

### GetAnnotations2 Method (AnnotationView)



Visual Basic for Applications (VBA)

```
Public Function GetAnnotations2( _  
    ByVal DimXpertOnly As Boolean, _  
    ByVal UnassignedInPlane As Boolean _  
    ) As Variant
```

## SOLIDWORKS Type Library

### GetViewRotation Method (AnnotationView)



Visual Basic for Applications (VBA)

```
Public Function GetViewRotation() As Variant
```

## SOLIDWORKS Type Library

### Hide Method (AnnotationView)



Visual Basic for Applications (VBA)

```
Public Function Hide() As Boolean
```

SOLIDWORKS Type Library

**IGetAnnotations Method (AnnotationView)**



Visual Basic for Applications (VBA)

```
Public Function IGetAnnotations( _  
    ByVal AnnotationCount As Long _  
) As Annotation
```

SOLIDWORKS Type Library

**IGetViewRotation Method (AnnotationView)**



Visual Basic for Applications (VBA)

```
Public Function IGetViewRotation() As Double
```

SOLIDWORKS Type Library

**IsShown Method (AnnotationView)**



Visual Basic for Applications (VBA)

```
Public Function IsShown() As Boolean
```

SOLIDWORKS Type Library

**MoveAnnotations Method (AnnotationView)**



Visual Basic for Applications (VBA)

```
Public Function MoveAnnotations( _  
    ByVal AnnotationsToMove As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

**Orient Method (AnnotationView)**



Visual Basic for Applications (VBA)

```
Public Function Orient() As Boolean
```

SOLIDWORKS Type Library

**Show Method (AnnotationView)**



Visual Basic for Applications (VBA)

```
Public Function Show() As Boolean
```

SOLIDWORKS Type Library

**UnassignedView Property (AnnotationView)**



Visual Basic for Applications (VBA)

```
Public Property UnassignedView As Boolean
```

# AppearanceSetting (Type)

SOLIDWORKS Type Library  
AppearanceSetting Object

Object Model

AppearanceSetting

SOLIDWORKS Type Library  
AppearanceSetting Object Members

Public Properties

- BlurryReflection
- Color
- Diffuse
- DoubleSided
- Luminous
- Reflection
- RoundSharpEdges
- Specular
- SpecularColor
- SpecularSpread
- Transparent

SOLIDWORKS Type Library  
BlurryReflection Property (AppearanceSetting)

Syntax

Visual Basic for Applications (VBA)

Public Property BlurryReflection As Boolean

SOLIDWORKS Type Library  
Color Property (AppearanceSetting)

Syntax

Visual Basic for Applications (VBA)

Public Property Color As Long

SOLIDWORKS Type Library  
Diffuse Property (AppearanceSetting)

Syntax

Visual Basic for Applications (VBA)

Public Property Diffuse As Double

SOLIDWORKS Type Library  
DoubleSided Property (AppearanceSetting)

Syntax

Visual Basic for Applications (VBA)

Public Property DoubleSided As Boolean

SOLIDWORKS Type Library

**Luminous Property (AppearanceSetting)**



Visual Basic for Applications (VBA)

Public Property Luminous As Double

SOLIDWORKS Type Library

**Reflection Property (AppearanceSetting)**



Visual Basic for Applications (VBA)

Public Property Reflection As Double

SOLIDWORKS Type Library

**RoundSharpEdges Property (AppearanceSetting)**



Visual Basic for Applications (VBA)

Public Property RoundSharpEdges As Double

SOLIDWORKS Type Library

**Specular Property (AppearanceSetting)**



Visual Basic for Applications (VBA)

Public Property Specular As Double

SOLIDWORKS Type Library

**SpecularColor Property (AppearanceSetting)**



Visual Basic for Applications (VBA)

Public Property SpecularColor As Long

SOLIDWORKS Type Library

**SpecularSpread Property (AppearanceSetting)**



Visual Basic for Applications (VBA)

Public Property SpecularSpread As Double

SOLIDWORKS Type Library

**Transparent Property (AppearanceSetting)**



Visual Basic for Applications (VBA)

Public Property Transparent As Double