

SOLIDWORKS API (VB6 COM) — Reference (4/102): AssemblyDoc (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

AssemblyDoc (part 2 of 2) (Type)

SOLIDWORKS Type Library

GetExplodedViewCount2 Method (AssemblyDoc)



Visual Basic for Applications (VBA)

```
Public Function GetExplodedViewCount2( _  
    ByVal ConfigurationName As String _  
) As Long
```

SOLIDWORKS Type Library

GetExplodedViewNames Method (AssemblyDoc)



Visual Basic for Applications (VBA)

```
Public Function GetExplodedViewNames() As Variant
```

SOLIDWORKS Type Library

GetExplodedViewNames2 Method (AssemblyDoc)



Visual Basic for Applications (VBA)

```
Public Function GetExplodedViewNames2( _  
    ByVal ConfigurationName As String _  
) As Variant
```

SOLIDWORKS Type Library

GetFeatureScope Method (AssemblyDoc)



Visual Basic for Applications (VBA)

```
Public Function GetFeatureScope( _  
    ByVal FeatureIn As Feature _  
) As Variant
```

SOLIDWORKS Type Library

GetFeatureScopeCount Method (AssemblyDoc)



Visual Basic for Applications (VBA)

```
Public Function GetFeatureScopeCount( _  
    ByVal FeatureIn As Feature _  
) As Long
```

SOLIDWORKS Type Library

GetFirstMember Method (AssemblyDoc)



Visual Basic for Applications (VBA)

```
Public Function GetFirstMember() As Object
```

SOLIDWORKS Type Library

GetLargeDesignReviewState Method (AssemblyDoc)



Visual Basic for Applications (VBA)

```
Public Function GetLargeDesignReviewState() As Long
```

SOLIDWORKS Type Library

GetLightWeightComponentCount Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLightWeightComponentCount() As Long
```

SOLIDWORKS Type Library

GetPhysicalSimulationComponents Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetPhysicalSimulationComponents( _  
    ByVal InDuration As Double, _  
    ByRef OutCount As Long, _  
    ByRef OutComponents As Variant, _  
    ByRef OutTransforms As Variant, _  
    ByRef OutStepStartTimes As Variant, _  
    ByRef OutStepDurations As Variant, _  
    ByRef OutTotalPhysSimDuration As Double _  
)
```

SOLIDWORKS Type Library

GetRouteManager Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRouteManager() As Object
```

SOLIDWORKS Type Library

GetSelectedMember Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSelectedMember() As Object
```

SOLIDWORKS Type Library

GetSimulation Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSimulation() As Simulation
```

SOLIDWORKS Type Library

GetUnloadedComponentNames Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUnloadedComponentNames( _  
    ByRef UnloadedComponentPathNames As Variant, _  
    ByRef UnloadedComponentReferencedConfigurationNames As Variant, _  
    ByRef ReasonForUnloadingComponents As Variant, _  
    ByRef DocTypes As Variant _  
) As Variant
```

SOLIDWORKS Type Library

GetVisibleComponentsInView Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetVisibleComponentsInView() As Variant
```

SOLIDWORKS Type Library

GetVisibleComponentsInViewCount Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetVisibleComponentsInViewCount() As Long
```

SOLIDWORKS Type Library

HasUnloadedComponents Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function HasUnloadedComponents() As Boolean
```

SOLIDWORKS Type Library

HideComponent Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub HideComponent()
```

SOLIDWORKS Type Library

IAddComponent2 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddComponent2( _  
    ByVal CompName As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Component
```

SOLIDWORKS Type Library

IAddComponent3 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddComponent3( _  
    ByVal CompName As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Component2
```

SOLIDWORKS Type Library

IAddComponents Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddComponents( _  
    ByRef Count As Long, _  
    ByRef Names As String, _
```

ByRef *Transforms* As Double _
) As [Component](#)

SOLIDWORKS Type Library

IAddComponents2 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddComponents2( _  
    ByRef Count As Long, _  
    ByRef Names As String, _  
    ByRef Transforms As Double _  
) As Component2
```

SOLIDWORKS Type Library

IAddComponents3 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddComponents3( _  
    ByVal Count As Long, _  
    ByRef Names As String, _  
    ByRef Transforms As Double, _  
    ByVal CoordinateSystemNameCount As Long, _  
    ByRef CoordinateSystemNames As String _  
) As Component2
```

SOLIDWORKS Type Library

IComponentReload2 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IComponentReload2( _  
    ByVal Component As Component, _  
    ByVal ReadOnly As Boolean, _  
    ByVal Options As Long _  
) As Long
```

SOLIDWORKS Type Library

IComponentReload3 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IComponentReload3( _  
    ByVal Component As Component2, _  
    ByVal ReadOnly As Boolean, _  
    ByVal Options As Long _  
) As Long
```

SOLIDWORKS Type Library

IFeatureByName Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IFeatureByName( _  
    ByVal Name As String _  
) As Feature
```

SOLIDWORKS Type Library

IGetBox Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBox( _  
    ByVal Options As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetComponents Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetComponents( _  
    ByVal ToplevelOnly As Boolean, _  
    ByVal Count As Long _  
) As Component2
```

SOLIDWORKS Type Library

IGetDragOperator Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetDragOperator() As DragOperator
```

SOLIDWORKS Type Library

IGetEditTarget Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEditTarget() As ModelDoc
```

SOLIDWORKS Type Library

IGetEditTarget2 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEditTarget2() As ModelDoc2
```

SOLIDWORKS Type Library

IGetExplodedViewNames Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetExplodedViewNames( _  
    ByVal Count As Long _  
) As String
```

SOLIDWORKS Type Library

IGetFeatureScope Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFeatureScope( _  
    ByVal FeatureIn As Feature, _  
    ByVal NumComponents As Long _  
) As Component2
```

SOLIDWORKS Type Library

IGetFirstMember Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFirstMember() As Member
```

SOLIDWORKS Type Library

IGetSelectedMember Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSelectedMember() As Member
```

SOLIDWORKS Type Library

IGetVisibleComponentsInView Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetVisibleComponentsInView( _  
    ByVal Count As Long _  
) As Component2
```

SOLIDWORKS Type Library

IMirrorComponents Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IMirrorComponents( _  
    ByVal Plane As Object, _  
    ByVal InstanceCount As Long, _  
    ByVal ComponentsToInstance As Component2, _  
    ByVal MirrorCount As Long, _  
    ByVal ComponentsToMirror As Component2, _  
    ByVal NameCount As Long, _  
    ByRef MirroredComponentFilenames As String, _  
    ByVal RecreateMates As Boolean, _  
    ByVal ComponentModifier As Long, _  
    ByVal ComponentNameModifier As String, _  
    ByVal MirroredFileLocation As String, _  
    ByVal CopyCustomProperties As Boolean _  
) As Component2
```

SOLIDWORKS Type Library

InsertCavity Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCavity()
```

SOLIDWORKS Type Library

InsertCavity2 Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCavity2( _  
    ByVal ScaleFactor As Double, _  
    ByVal ScaleType As Long _  
)
```

SOLIDWORKS Type Library

InsertCavity3 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCavity3( _  
    ByVal ScaleFactor As Double, _  
    ByVal ScaleType As Long, _  
    ByVal KeepPieceIndex As Long _  
)
```

SOLIDWORKS Type Library

InsertCavity4 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCavity4( _  
    ByVal ScaleFactor_x As Double, _  
    ByVal ScaleFactor_y As Double, _  
    ByVal ScaleFactor_z As Double, _  
    ByVal IsUniform As Boolean, _  
    ByVal ScaleType As Long, _  
    ByVal KeepPieceIndex As Long _  
)
```

SOLIDWORKS Type Library

InsertDerivedPattern Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertDerivedPattern() As Boolean
```

SOLIDWORKS Type Library

InsertEnvelope Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertEnvelope( _  
    ByVal CompName As String, _  
    ByVal ConfigName As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Component2
```

SOLIDWORKS Type Library

InsertImportedComponent Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertImportedComponent( _  
    ByVal FileName As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByRef CompInserted As Object _  
) As Long
```

SOLIDWORKS Type Library

InsertJoin Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertJoin()
```

SOLIDWORKS Type Library

InsertJoin2 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertJoin2( _  
    ByVal HideParts As Boolean, _  
    ByVal ForceContact As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

InsertLoadReference Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertLoadReference( _  
    ByVal Mate As Mate2 _  
    ) As MateLoadReference
```

SOLIDWORKS Type Library

InsertNewAssembly Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertNewAssembly( _  
    ByVal FileName As String _  
    ) As Long
```

SOLIDWORKS Type Library

InsertNewPart Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertNewPart()
```

SOLIDWORKS Type Library

InsertNewPart2 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertNewPart2( _  
    ByVal FilePathIn As String, _  
    ByVal Face_or_Plane_to_select As Object _  
    ) As Long
```

SOLIDWORKS Type Library

InsertNewVirtualAssembly Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertNewVirtualAssembly( _  
    ByRef InsertedComponent As Component2 _  
    ) As Long
```

SOLIDWORKS Type Library

InsertNewVirtualPart Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertNewVirtualPart( _  
    ByVal FaceOrPlaneToSelect As Object, _  
    ByRef InsertedComponent As Component2 _  
    ) As Long
```

SOLIDWORKS Type Library

InsertTableNotify Event (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Event InsertTableNotify( _  
    ByVal TableAnnotation As TableAnnotation, _  
    ByVal TableType As String, _  
    ByVal TemplatePath As String _  
    )
```

SOLIDWORKS Type Library

InsertWeld Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertWeld( _  
    ByVal Type As String, _  
    ByVal Shape As String, _  
    ByVal TopDelta As Double, _  
    ByVal BottomDelta As Double, _  
    ByVal Radius As Double, _  
    ByVal Part As String _  
    )
```

SOLIDWORKS Type Library

InsertWeld2 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertWeld2( _  
    ByVal Type As String, _  
    ByVal Shape As String, _  
    ByVal TopDelta As Double, _  
    ByVal BottomDelta As Double, _  
    ByVal Radius As Double, _  
    ByVal Part As String, _  
    ByVal TopFaces As Variant, _  
    ByVal StopFace As Variant, _  
    ByVal ContactFaces As Variant _  
    )
```

SOLIDWORKS Type Library

InterferenceDetectionManager Property (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property InterferenceDetectionManager As InterferenceDetectionMgr
```

SOLIDWORKS Type Library

InterferenceNotify Event (AssemblyDoc)





Syntax

Visual Basic for Applications (VBA)

```
Public Event InterferenceNotify( _  
    ByRef PComp As Variant, _  
    ByRef PFace As Variant _  
)
```

SOLIDWORKS Type Library

IReorderComponents Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IReorderComponents( _  
    ByVal Count As Long, _  
    ByVal Source As Component2, _  
    ByVal Target As Object, _  
    ByVal Where As Long _  
) As Boolean
```

SOLIDWORKS Type Library

IReorganizeComponents Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IReorganizeComponents( _  
    ByVal Count As Long, _  
    ByVal Source As Component2, _  
    ByVal Target As Object _  
) As Boolean
```

SOLIDWORKS Type Library

IsComponentTreeValid Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsComponentTreeValid() As Boolean
```

SOLIDWORKS Type Library

ISetComponentState Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetComponentState( _  
    ByVal SuppressionState As Long, _  
    ByVal NumComps As Long, _  
    ByVal CompArr As Component2, _  
    ByVal ConfigOption As Long, _  
    ByVal WhichConfig As String, _  
    ByVal SaveClosedDocs As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

ISetComponentVisibility Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetComponentVisibility( _  
    ByVal Visibility As Boolean, _  
    ByVal Config_opt As Long, _  
    ByVal Config_count As Long, _
```

```
ByRef Config_names As String _  
)
```

SOLIDWORKS Type Library

Isolate Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Isolate() As Boolean
```

SOLIDWORKS Type Library

IsRouteAssembly Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsRouteAssembly() As Boolean
```

SOLIDWORKS Type Library

IsSupportedMatesAvailable Property (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IsSupportedMatesAvailable As Boolean
```

SOLIDWORKS Type Library

IToolsCheckInterference2 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IToolsCheckInterference2( _  
    ByVal NumComponents As Long, _  
    ByVal LpComponents As Component, _  
    ByVal CoincidentInterference As Boolean, _  
    ByRef PComp As Variant, _  
    ByRef PFace As Variant _  
)
```

SOLIDWORKS Type Library

IToolsCheckInterference3 Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IToolsCheckInterference3( _  
    ByVal NumComponents As Long, _  
    ByVal LpComponents As Component2, _  
    ByVal CoincidentInterference As Boolean, _  
    ByRef PComp As Variant, _  
    ByRef PFace As Variant _  
)
```

SOLIDWORKS Type Library

LargeDesignReviewStateChangeNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event LargeDesignReviewStateChangeNotify( _  
    ByVal PreviousState As Integer, _
```

```
ByVal newState As Integer _  
)
```

SOLIDWORKS Type Library

LargeDesignReviewTransparencyLevel Property (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Property LargeDesignReviewTransparencyLevel As Double
```

SOLIDWORKS Type Library

LargeDesignReviewTransparencyLevelDynamic Property (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Property LargeDesignReviewTransparencyLevelDynamic As Boolean
```

SOLIDWORKS Type Library

LargeDesignReviewTransparencyLevelEnabled Property (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Property LargeDesignReviewTransparencyLevelEnabled As Boolean
```

SOLIDWORKS Type Library

LightingDialogCreateNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event LightingDialogCreateNotify( _  
    ByVal dialog As Object _  
)
```

SOLIDWORKS Type Library

LightweightAllResolved Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function LightweightAllResolved() As Boolean
```

SOLIDWORKS Type Library

LoadFromStorageNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event LoadFromStorageNotify()
```

SOLIDWORKS Type Library

LoadFromStorageStoreNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event LoadFromStorageStoreNotify()
```

MakeAssemblyFromSelectedComponents Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function MakeAssemblyFromSelectedComponents( _
    ByVal FileName As String _
) As Boolean
```

MakeIndependent Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function MakeIndependent( _
    ByVal FileName As String _
) As Boolean
```

MakeLightWeight Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub MakeLightWeight()
```

MirrorComponents Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function MirrorComponents( _
    ByVal Plane As Object, _
    ByVal ComponentsToInstance As Variant, _
    ByVal ComponentsToMirror As Variant, _
    ByVal MirroredComponentFileNames As Variant, _
    ByVal RecreateMates As Boolean, _
    ByVal ComponentModifier As Long, _
    ByVal ComponentNameModifier As String, _
    ByVal MirroredFileLocation As String, _
    ByVal CopyCustomProperties As Boolean _
) As Variant
```

MirrorComponents2 Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function MirrorComponents2( _
    ByVal MirrorPlane As Object, _
    ByVal ComponentsToInstance As Variant, _
    ByVal ComponentOrientations As Variant, _
    ByVal OrientAboutCenterOfMass As Boolean, _
    ByVal ComponentsToMirror As Variant, _
    ByVal CreateDerivedConfigurations As Boolean, _
    ByVal MirroredComponentFileNames As Variant, _
    ByVal NameModifierType As Long, _
    ByVal NameModifier As String, _
    ByVal MirroredComponentFileLocation As String, _
    ByVal ImportOptions As Long, _
    ByVal BreakLinks As Boolean, _
    ByVal PreserveZAxis As Boolean _
) As Variant
```

MirrorComponents3 Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function MirrorComponents3( _  
    ByVal MirrorPlane As Object, _  
    ByVal ComponentsToInstance As Variant, _  
    ByVal ComponentOrientations As Variant, _  
    ByVal OrientAboutCenterOfMass As Boolean, _  
    ByVal ComponentsToMirror As Variant, _  
    ByVal CreateDerivedConfigurations As Boolean, _  
    ByVal MirroredComponentFileNames As Variant, _  
    ByVal NameModifierType As Long, _  
    ByVal NameModifier As String, _  
    ByVal MirroredComponentFileLocation As String, _  
    ByVal ImportOptions As Long, _  
    ByVal BreakLinks As Boolean, _  
    ByVal PreserveZAxis As Boolean, _  
    ByVal SyncFlexibleSubAssemblies As Boolean _  
) As Variant
```

ModifyNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event ModifyNotify()
```

ModifyTableNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event ModifyTableNotify( _  
    ByVal TableAnnotation As TableAnnotation, _  
    ByVal TableType As Long, _  
    ByVal reason As Long, _  
    ByVal RowInfo As Long, _  
    ByVal ColumnInfo As Long, _  
    ByVal DataInfo As String _  
)
```

NewSelectionNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event NewSelectionNotify()
```

OpenCompFile Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub OpenCompFile()
```

OpenDesignTableNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event OpenDesignTableNotify( _  
    ByVal DesignTable As Object _  
)
```

PreRenameItemNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event PreRenameItemNotify( _  
    ByVal EntityType As Long, _  
    ByVal oldName As String, _  
    ByVal NewName As String _  
)
```

PromptBodiesToKeepNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event PromptBodiesToKeepNotify( _  
    ByVal Feature As Object, _  
    ByRef Bodies As Variant _  
)
```

PublishTo3DPDFNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event PublishTo3DPDFNotify( _  
    ByVal Path As String _  
)
```

RedoPostNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event RedoPostNotify()
```

RedoPreNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

Public Event RedoPreNotify()

SOLIDWORKS Type Library

RegenNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

Public Event RegenNotify()

SOLIDWORKS Type Library

RegenPostNotify2 Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event RegenPostNotify2( _  
    ByVal stopFeature As Object _  
)
```

SOLIDWORKS Type Library

RegenPostNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

Public Event RegenPostNotify()

SOLIDWORKS Type Library

RemoveFromFeatureScope Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveFromFeatureScope( _  
    ByVal CompName As String _  
) As Boolean
```

SOLIDWORKS Type Library

RenamedDocumentNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event RenamedDocumentNotify( _  
    ByRef RenamedDocumentInterface As Object _  
)
```

SOLIDWORKS Type Library

RenameDisplayTitleNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event RenameDisplayTitleNotify( _  
    ByVal oldName As String, _
```

```
    ByVal NewItem As String _  
)
```

SOLIDWORKS Type Library

RenameItemNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event RenameItemNotify( _  
    ByVal EntityType As Long, _  
    ByVal oldName As String, _  
    ByVal NewItem As String _  
)
```

SOLIDWORKS Type Library

ReorderComponents Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ReorderComponents( _  
    ByVal Source As Variant, _  
    ByVal Target As Object, _  
    ByVal Where As Long _  
) As Boolean
```

SOLIDWORKS Type Library

ReorganizeComponents Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ReorganizeComponents( _  
    ByVal Source As Variant, _  
    ByVal Target As Object _  
) As Boolean
```

SOLIDWORKS Type Library

ReplaceComponents Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ReplaceComponents( _  
    ByVal FileName As String, _  
    ByVal ConfigName As String, _  
    ByVal ReplaceAllInstance As Boolean, _  
    ByVal ReAttachMates As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

ReplaceComponents2 Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ReplaceComponents2( _  
    ByVal FileName As String, _  
    ByVal ConfigName As String, _  
    ByVal ReplaceAllInstance As Boolean, _  
    ByVal UseConfigChoice As Long, _  
    ByVal ReAttachMates As Boolean _  
) As Boolean
```

ReplacePLMComponents Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ReplacePLMComponents( _  
    ByVal PLMID As String, _  
    ByVal ConfigName As String, _  
    ByVal ReplaceAllInstance As Boolean, _  
    ByVal UseConfigChoice As Long, _  
    ByVal ReAttachMates As Boolean _  
) As Boolean
```

ResolveAllLightweight Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ResolveAllLightweight() As Boolean
```

ResolveAllLightWeightComponents Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ResolveAllLightWeightComponents( _  
    ByVal WarnUser As Boolean _  
) As Long
```

ResolveOutOfDateLightWeightComponents Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ResolveOutOfDateLightWeightComponents() As Boolean
```

RotateComponent Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub RotateComponent()
```

RotateComponentAxis Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub RotateComponentAxis()
```

SaveIsolate Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SaveIsolate( _  
    ByVal Name As String _  
) As Boolean
```

SaveToStorageNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event SaveToStorageNotify()
```

SaveToStorageStoreNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event SaveToStorageStoreNotify()
```

SelectComponentsBySize Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SelectComponentsBySize( _  
    ByVal Percent As Double _  
) As Boolean
```

SelectiveOpen Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SelectiveOpen( _  
    ByVal SelectedComponents As Boolean, _  
    ByVal OpenLightWeight As Boolean _  
) As Boolean
```

SelectiveOpenPostNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event SelectiveOpenPostNotify( _  
    ByVal NewAddedDisplayStateName As String, _  
    ByRef SelectedComponentNames As Variant _  
)
```

SensorAlertPreNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event SensorAlertPreNotify( _  
    ByVal SensorIn As Object, _  
    ByVal SensorAlertType As Long _  
)
```

SetComponentState Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetComponentState( _  
    ByVal SuppressionState As Long, _  
    ByVal CompArr As Variant, _  
    ByVal ConfigOption As Long, _  
    ByVal WhichConfig As String, _  
    ByVal SaveClosedDocs As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetComponentSuppression Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetComponentSuppression( _  
    ByVal State As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetComponentTransparent Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetComponentTransparent( _  
    ByVal State As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetComponentVisibility Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetComponentVisibility( _  
    ByVal Visibility As Boolean, _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
    )
```

SOLIDWORKS Type Library

SetDroppedFileConfigName Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetDroppedFileConfigName( _  
    ByVal ConfigName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetDroppedFileFeatureName Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetDroppedFileFeatureName( _  
    ByVal FeatureName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetDroppedFileName Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetDroppedFileName( _  
    ByVal FileName As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetForceResetConfigName Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetForceResetConfigName( _  
    ByVal Set As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

SetIsolateVisibility Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetIsolateVisibility( _  
    ByVal Option As Long _  
)
```

SOLIDWORKS Type Library

SetSpeedPakConfigurations Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetSpeedPakConfigurations( _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SetSpeedPakToParent Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetSpeedPakToParent() As Boolean
```

SOLIDWORKS Type Library

ShowComponent Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ShowComponent()
```

SOLIDWORKS Type Library

ShowExploded Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ShowExploded( _  
    ByVal ShowIt As Boolean _  
) As Boolean
```

ShowExploded2 Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ShowExploded2( _  
    ByVal ShowIt As Boolean, _  
    ByVal ExplodeViewName As String _  
) As Boolean
```

SketchSolveNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event SketchSolveNotify( _  
    ByVal featName As String _  
)
```

SolidBodyFolderReorderNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event SolidBodyFolderReorderNotify( _  
    ByVal Component As String, _  
    ByVal Source As String, _  
    ByVal Target As String, _  
    ByVal ReorderLocation As Integer _  
)
```

SuppressionStateChangeNotify Event (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event SuppressionStateChangeNotify( _  
    ByVal Feature As Feature, _  
    ByVal NewSuppressionState As Long, _  
    ByVal PreviousSuppressionState As Long, _  
    ByVal ConfigurationOption As Long, _  
    ByRef ConfigurationNames As Variant _  
)
```

TemporaryFixGroup Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub TemporaryFixGroup()
```

TemporaryFixGroupExit Method (AssemblyDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub TemporaryFixGroupExit()
```

SOLIDWORKS Type Library

ToolsCheckInterference Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ToolsCheckInterference()
```

SOLIDWORKS Type Library

ToolsCheckInterference2 Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ToolsCheckInterference2( _  
    ByVal NumComponents As Long, _  
    ByVal LpComponents As Variant, _  
    ByVal CoincidentInterference As Boolean, _  
    ByRef PComp As Variant, _  
    ByRef PFace As Variant _  
)
```

SOLIDWORKS Type Library

TranslateComponent Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub TranslateComponent()
```

SOLIDWORKS Type Library

UndoPostNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event UndoPostNotify()
```

SOLIDWORKS Type Library

UndoPreNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event UndoPreNotify()
```

SOLIDWORKS Type Library

UnfixComponent Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub UnfixComponent()
```

SOLIDWORKS Type Library

UngroupComponents Method (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function UngroupComponents() As Boolean
```

SOLIDWORKS Type Library

UnitsChangeNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event UnitsChangeNotify()
```

SOLIDWORKS Type Library

UpdateBox Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub UpdateBox()
```

SOLIDWORKS Type Library

UpdateFeatureScope Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub UpdateFeatureScope()
```

SOLIDWORKS Type Library

UpdateSpeedPak Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function UpdateSpeedPak() As Boolean
```

SOLIDWORKS Type Library

UpdateToolboxComponent Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function UpdateToolboxComponent( _  
    ByVal AssemblyLevelToUpdate As Long _  
) As Long
```

SOLIDWORKS Type Library

UserSelectionPostNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event UserSelectionPostNotify()
```

SOLIDWORKS Type Library

UserSelectionPreNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event UserSelectionPreNotify( _  
    ByVal SelfType As Long _  
)
```

SOLIDWORKS Type Library

UseSpeedPak Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function UseSpeedPak() As Boolean
```

SOLIDWORKS Type Library

ViewCollapseAssembly Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ViewCollapseAssembly()
```

SOLIDWORKS Type Library

ViewExplodeAssembly Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ViewExplodeAssembly()
```

SOLIDWORKS Type Library

ViewFeatureManagerByDependencies Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ViewFeatureManagerByDependencies()
```

SOLIDWORKS Type Library

ViewFeatureManagerByFeatures Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ViewFeatureManagerByFeatures()
```

SOLIDWORKS Type Library

ViewFeatureManagerFeatureDetail Method (AssemblyDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ViewFeatureManagerFeatureDetail( _  
    ByVal Detail As Boolean _  
)
```

SOLIDWORKS Type Library

ViewNewNotify2 Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ViewNewNotify2( _  
    ByVal viewBeingAdded As Object _
```

)

SOLIDWORKS Type Library

ViewNewNotify Event (AssemblyDoc)



Syntax

Visual Basic for Applications (VBA)

Public Event ViewNewNotify()