

SOLIDWORKS API (VB6 COM) — Reference (7/102): Body2

SOLIDWORKS API Documentation (converted from CHM)

Body2 (Type)

SOLIDWORKS Type Library

Body2 Object

 Object Model

Body2

Check3 (FaultEntity)

Diagnose (DiagnoseResult)

EnumFaces (EnumFaces2)

ExtendSurface (Body2)

FindAttribute (Attribute)

GetOriginalPatternedBody (Body2)

GetProcessedBody2 (Body2)

GetSafeBody (Body2)

GetTexture (Texture)

IAddProfileArc (Curve)

IAddProfileArcDLL (Curve)

IAddProfileBspine (Curve)

IAddProfileBspineByPts (Curve)

IAddProfileBspineDLL (Curve)

IAddProfileLine (Curve)

IAddProfileLineDLL (Curve)

IAddVertexPoint (Vertex)

ICopy (Body2)

ICreateBlendSurface (Surface)

ICreateBodyFromFaces (Body2)

ICreateBspineSurface (Surface)

ICreateBspineSurfaceDLL (Surface)

ICreateExtrusionSurface (Surface)

ICreateExtrusionSurfaceDLL (Surface)

ICreateNewSurface (Surface)

ICreateOffsetSurface (Surface)

ICreatePlanarSurface (Surface)

ICreatePlanarSurfaceDLL (Surface)

ICreatePsplineSurfaceDLL (Surface)

ICreateRevolutionSurface (Surface)

- ICreateRevolutionSurfaceDLL (Surface)
- ICreateRuledSurface (Surface)
- ICreateTempBodyFromSurfaces (Body2)
- IDeleteFacesMakeSheetBodies (Body2)
- IExtendSurface (Body2)
- IGetEdges (Edge)
- IGetExcessBodyArray (Body2)
- IGetFaces (Face2)
- IGetFeatures (Feature)
- IGetFirstFace (Face2)
- IGetFirstSelectedFace (Face2)
- IGetIntersectionEdges (Edge)
- IGetNextSelectedFace (Face2)
- IGetProcessedBody (Body2)
- IGetProcessedBodyWithSelfFace (Body2)
- IGetSelectedFaces (Face2)
- IGetSheetBody (Body2)
- IGetTessellation (Tessellation)
- IGetVertices (Vertex)
- IMatchedBoolean (EnumBodies2)
- IMatchedBoolean2 (EnumBodies2)
- IMatchedBoolean3 (EnumBodies2)
- IMatchedBoolean4 (EnumBodies2)
- IOperations2 (EnumBodies2)
- MakeOffset (Body2)
- OffsetPlanarWireBody (Body2)

SOLIDWORKS Type Library
Body2 Object Members

Public Methods

- [AddConstantFillet](#)
- [AddProfileArc](#)
- [AddProfileB spline](#)

 AddProfileBsplinesByPts
 AddProfileLine
 AddPropertyExtension
 AddPropertyExtension2
 AddVertexPoint
 ApplyTransform
 Check
 Check2
 ConvertToMeshBody
 Copy
 Copy2
 CreateBaseFeature
 CreateBlendSurface
 CreateBodyFromFaces
 CreateBodyFromSurfaces
 CreateBoundedSurface
 CreateBsplinesSurface
 CreateExtrusionSurface
 CreateNewSurface
 CreateOffsetSurface
 CreatePlanarSurface
 CreatePlanarTrimSurfaceDLL
 CreateRevolutionSurface
 CreateRuledSurface
 CreateTempBodyFromSurfaces
 CreateTrimmedSurface
 DeleteBlends
 DeleteBlends2
 DeleteBlends3
 DeleteFaces
 DeleteFaces2
 DeleteFaces3
 DeleteFaces4
 DeleteFaces5
 DeleteFacesMakeSheetBodies
 DeSelect
 Dispose
 Display
 Display2
 Display3
 DisplayWireFrameXOR
 DraftBody
 DraftBody2

 EnumFaces
 ExtendSurface
 FindAttribute
 GetBodyBox
 GetCoincidenceTransform
 GetCoincidenceTransform2
 GetEdgeCount
 GetEdges
 GetExcessBodyArray
 GetExtremePoint
 GetFaceCount
 GetFaces
 GetFeatureCount
 GetFeatures
 GetFirstFace
 GetFirstSelectedFace
 GetGraphicsBody
 GetigesErrorCode
 GetigesErrorCount
 GetIntersectionEdges
 GetIntersectionEdges2
 GetMassProperties
 GetMaterialIdName
 GetMaterialIdName2
 GetMaterialPropertyName
 GetMaterialUserName
 GetMaterialUserName2
 GetMeshBody
 GetMiddleSurface
 GetNextSelectedFace
 GetOriginalPatternedBody
 GetProcessedBody
 GetProcessedBody2
 GetProcessedBodyWithSelfFace
 GetPropertyExtension
 GetPropertyExtension2
 GetSafeBody
 GetSelectedFaceCount
 GetSelectedFaces
 GetSelectionId
 GetSheetBody
 GetTessellation
 GetTexture

	<u>GetTrackingIDs</u>
	<u>GetTrackingIDsCount</u>
	<u>GetType</u>
	<u>GetUpdateStamp</u>
	<u>GetVertexCount</u>
	<u>GetVertices</u>
	<u>HasMaterialPropertyValues</u>
	<u>Hide</u>
	<u>HideBody</u>
	<u>IAddProfileArc</u>
	<u>IAddProfileArcDLL</u>
	<u>IAddProfileBspine</u>
	<u>IAddProfileBspineByPts</u>
	<u>IAddProfileBspineDLL</u>
	<u>IAddProfileLine</u>
	<u>IAddProfileLineDLL</u>
	<u>IAddVertexPoint</u>
	<u>ICombineVolumes</u>
	<u>ICopy</u>
	<u>ICreateBaseFeature</u>
	<u>ICreateBlendSurface</u>
	<u>ICreateBodyFromFaces</u>
	<u>ICreateBoundedSurface</u>
	<u>ICreateBspineSurface</u>
	<u>ICreateBspineSurfaceDLL</u>
	<u>ICreateExtrusionSurface</u>
	<u>ICreateExtrusionSurfaceDLL</u>
	<u>ICreateNewSurface</u>
	<u>ICreateOffsetSurface</u>
	<u>ICreatePlanarSurface</u>
	<u>ICreatePlanarSurfaceDLL</u>
	<u>ICreatePlanarTrimSurfaceDLL</u>
	<u>ICreatePspineSurfaceDLL</u>
	<u>ICreateRevolutionSurface</u>
	<u>ICreateRevolutionSurfaceDLL</u>
	<u>ICreateRuledSurface</u>
	<u>ICreateTempBodyFromSurfaces</u>
	<u>IDeleteBlends</u>
	<u>IDeleteBlends2</u>
	<u>IDeleteBlends3</u>
	<u>IDeleteFaces2</u>
	<u>IDeleteFaces3</u>
	<u>IDeleteFacesMakeSheetBodies</u>

	<u>IDeleteFacesMakeSheetBodiesCount</u>
	<u>IDisplay</u>
	<u>IDisplayWireFrameXOR</u>
	<u>IDraftBody</u>
	<u>IDraftBody2</u>
	<u>IExtendSurface</u>
	<u>IGetBodyBox</u>
	<u>IGetEdges</u>
	<u>IGetExcessBodyArray</u>
	<u>IGetExcessBodyCount</u>
	<u>IGetFaces</u>
	<u>IGetFeatures</u>
	<u>IGetFirstFace</u>
	<u>IGetFirstSelectedFace</u>
	<u>IGetIntersectionEdgeCount</u>
	<u>IGetIntersectionEdges</u>
	<u>IGetMassProperties</u>
	<u>IGetMaterialPropertyValuesForFace</u>
	<u>IGetMiddleSurface</u>
	<u>IGetNextSelectedFace</u>
	<u>IGetProcessedBody</u>
	<u>IGetProcessedBodyWithSelFace</u>
	<u>IGetSelectedFaces</u>
	<u>IGetSheetBody</u>
	<u>IGetTessellation</u>
	<u>IGetTrackingIDs</u>
	<u>IGetVertices</u>
	<u>IHide</u>
	<u>IMatchedBoolean</u>
	<u>IMatchedBoolean2</u>
	<u>IMatchedBoolean3</u>
	<u>IMatchedBoolean4</u>
	<u>IOperations</u>
	<u>IOperations2</u>
	<u>IRemoveFacesFromSheet</u>
	<u>IRemoveMaterialProperty</u>
	<u>ISave</u>
	<u>ISectionBySheet</u>
	<u>ISetCurrentSurface</u>
	<u>ISetXform</u>
	<u>IsGraphicsBody</u>
	<u>IsMeshBody</u>
	<u>IsPatternSeed</u>

	IsSheetMetal
	IsTemporaryBody
	MakeOffset
	MatchedBoolean
	MatchedBoolean2
	MatchedBoolean3
	MatchedBoolean4
	MinimumRadius
	Negate
	OffsetPlanarWireBody
	Operations
	Operations2
	RemoveFacesFromSheet
	RemoveMaterialProperty
	RemoveRedundantTopology
	RemoveTexture
	RemoveTextureByDisplayState
	RemoveTrackingID
	ResetEdgeTolerances
	ResetPropertyExtension
	ResetPropertyExtension2
	Save
	Select
	Select2
	SetCurrentSurface
	Setigesinfo
	SetMaterialIdName
	SetMaterialIdName2
	SetMaterialProperty
	SetMaterialUserName
	SetMaterialUserName2
	SetTexture
	SetTextureByDisplayState
	SetTrackingID
	SetXform

Public Properties

	Check3
	DisableDisplay
	DisableHighlight
	IMaterialPropertyValues
	IMaterialPropertyValues2
	IsSafe

 [MaterialPropertyValues](#)

 [MaterialPropertyValues2](#)

 [Name](#)

 [Visible](#)

SOLIDWORKS Type Library

AddConstantFillet Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddConstantFillet( _  
    ByVal Radius As Double, _  
    ByVal EdgesToFillet As Variant _  
) As Variant
```

SOLIDWORKS Type Library

AddProfileArc Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddProfileArc( _  
    ByVal Center As Variant, _  
    ByVal Axis As Variant, _  
    ByVal Radius As Double, _  
    ByVal StartPoint As Variant, _  
    ByVal EndPoint As Variant _  
) As Object
```

SOLIDWORKS Type Library

AddProfileBspline Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddProfileBspline( _  
    ByVal Props As Variant, _  
    ByVal Knots As Variant, _  
    ByVal CtrlPtCoords As Variant _  
) As Object
```

SOLIDWORKS Type Library

AddProfileBsplineByPts Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddProfileBsplineByPts( _  
    ByVal NumPoints As Long, _  
    ByVal PointArray As Variant _  
) As Object
```

SOLIDWORKS Type Library

AddProfileLine Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddProfileLine( _  
    ByVal RootPoint As Variant, _  
    ByVal Direction As Variant _  
) As Object
```

AddPropertyExtension Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddPropertyExtension( _  
    ByVal PropertyExtension As Variant _  
) As Long
```

AddPropertyExtension2 Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddPropertyExtension2( _  
    ByVal PropertyExtension As Variant _  
) As Long
```

AddVertexPoint Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddVertexPoint( _  
    ByVal Point As Variant _  
) As Object
```

ApplyTransform Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ApplyTransform( _  
    ByVal Xform As MathTransform _  
) As Boolean
```

Check Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Check() As Long
```

Check2 Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Check2() As Long
```

Check3 Property (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property Check3 As FaultEntity
```

ConvertToMeshBody Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ConvertToMeshBody( _  
    ByVal GroupFacetsIntoFaces As Boolean, _  
    ByVal KeepOriginalBody As Boolean, _  
    ByVal HideOriginalBody As Boolean, _  
    ByVal MeshRefinement As Double, _  
    ByVal AdvancedMeshRefinement As Boolean, _  
    ByVal MaximumDistance As Double, _  
    ByVal MaximumAngle As Double, _  
    ByVal DefineMaxElementSize As Boolean, _  
    ByVal ElementSize As Double, _  
    ByRef ErrorCode As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

Copy Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Copy() As Object
```

SOLIDWORKS Type Library

Copy2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Copy2( _  
    ByVal PreserveFaceIDs As Boolean _  
    ) As Object
```

SOLIDWORKS Type Library

CreateBaseFeature Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateBaseFeature( _  
    ByVal BodyIn As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateBlendSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateBlendSurface( _  
    ByVal Surface1 As Object, _  
    ByVal Range1 As Double, _  
    ByVal Surface2 As Object, _  
    ByVal Range2 As Double, _  
    ByVal StartVec As Variant, _  
    ByVal EndVec As Variant, _  
    ByVal HaveHelpVec As Integer, _  
    ByVal HelpVec As Variant, _  
    ByVal HaveHelpBox As Integer, _  
    ByVal HelpBox As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreateBodyFromFaces Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateBodyFromFaces( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreateBodyFromSurfaces Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateBodyFromSurfaces() As Boolean
```

SOLIDWORKS Type Library

CreateBoundedSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateBoundedSurface( _  
    ByVal UOpt As Boolean, _  
    ByVal VOpt As Boolean, _  
    ByVal UvParams As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateBsplineSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateBsplineSurface( _  
    ByVal Props As Variant, _  
    ByVal UKnots As Variant, _  
    ByVal VKnots As Variant, _  
    ByVal CtrlPtCoords As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreateExtrusionSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateExtrusionSurface( _  
    ByVal ProfileCurve As Object, _  
    ByVal AxisDirection As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreateNewSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateNewSurface() As Object
```

SOLIDWORKS Type Library

CreateOffsetSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateOffsetSurface( _  
    ByVal SurfaceIn As Object, _  
    ByVal Distance As Double _  
    ) As Object
```

SOLIDWORKS Type Library

CreatePlanarSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlanarSurface( _  
    ByVal VRootPoint As Variant, _  
    ByVal VNormal As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreatePlanarTrimSurfaceDLL Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlanarTrimSurfaceDLL( _  
    ByVal Points As Variant, _  
    ByVal Normal As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateRevolutionSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateRevolutionSurface( _  
    ByVal ProfileCurve As Object, _  
    ByVal AxisPoint As Variant, _  
    ByVal AxisDirection As Variant, _  
    ByVal ProfileEndPtParams As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreateRuledSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateRuledSurface( _  
    ByVal Curve1 As Object, _  
    ByVal Curve2 As Object, _  
    ByVal ApexPoint As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreateTempBodyFromSurfaces Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTempBodyFromSurfaces() As Object
```

SOLIDWORKS Type Library

CreateTrimmedSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTrimmedSurface() As Boolean
```

SOLIDWORKS Type Library

DeleteBlends Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteBlends( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteBlends2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteBlends2( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Variant, _  
    ByVal DoLocalCheck As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteBlends3 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteBlends3( _  
    ByVal FaceList As Variant, _  
    ByVal DoLocalCheck As Boolean, _  
    ByVal UsePlanarCap As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteFaces Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteFaces( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteFaces2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteFaces2( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Variant, _  
    ByVal Option As Integer _  
) As Long
```

SOLIDWORKS Type Library

DeleteFaces3 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteFaces3( _  
    ByVal FaceList As Variant, _  
    ByVal Option As Long, _  
    ByVal DoLocalCheck As Boolean, _  
    ByRef LocalCheckResult As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

DeleteFaces4 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteFaces4( _  
    ByVal FaceList As Variant, _  
    ByVal Option As Long, _  
    ByVal DoLocalCheck As Boolean, _  
    ByRef BodyList As Variant, _  
    ByRef LocalCheckResult As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

DeleteFaces5 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteFaces5( _  
    ByVal FaceList As Variant, _  
    ByVal HealAction As Long, _  
    ByVal LoopProcessOption As Long, _  
    ByVal DoLocalCheck As Boolean, _  
    ByRef BodyList As Variant, _  
    ByRef LocalCheckResult As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

DeleteFacesMakeSheetBodies Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteFacesMakeSheetBodies( _  
    ByVal FaceList As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

DeSelect Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeSelect() As Boolean
```

SOLIDWORKS Type Library

Diagnose Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Diagnose() As DiagnoseResult
```

SOLIDWORKS Type Library

DisableDisplay Property (Body2)



Visual Basic for Applications (VBA)

```
Public Property DisableDisplay As Boolean
```

SOLIDWORKS Type Library

DisableHighlight Property (Body2)



Visual Basic for Applications (VBA)

```
Public Property DisableHighlight As Boolean
```

SOLIDWORKS Type Library

Display Method (Body2)



Visual Basic for Applications (VBA)

```
Public Sub Display( _  
    ByVal Part As Object, _  
    ByVal Color As Long _  
)
```

SOLIDWORKS Type Library

Display2 Method (Body2)



Visual Basic for Applications (VBA)

```
Public Sub Display2( _  
    ByVal Part As PartDoc, _  
    ByVal Color As Long, _  
    ByVal Option As Long _  
)
```

SOLIDWORKS Type Library

Display3 Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function Display3( _  
    ByVal Component As Object, _  
    ByVal Color As Long, _  
    ByVal Option As Long _  
) As Long
```

SOLIDWORKS Type Library

DisplayWireFrameXOR Method (Body2)



Visual Basic for Applications (VBA)

```
Public Sub DisplayWireFrameXOR( _  
    ByVal Part As Object, _  
    ByVal Color As Long _  
)
```

SOLIDWORKS Type Library

DraftBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function DraftBody( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Variant, _  
    ByVal EdgeList As Variant, _  
    ByVal DraftAngle As Double, _  
    ByVal Dir As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

DraftBody2 Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function DraftBody2( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Variant, _  
    ByVal EdgeList As Variant, _  
    ByVal BasePoint As Object, _  
    ByVal DraftAngle As Double, _  
    ByVal Dir As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

EnumFaces Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function EnumFaces() As EnumFaces2
```

SOLIDWORKS Type Library

ExtendSurface Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function ExtendSurface( _  
    ByVal EdgesToExtend As Variant, _  
    ByVal ExtendLinear As Boolean, _  
    ByVal EndCondition As Long, _  
    ByVal Dist As Double, _  
    ByVal PUpToVtx As Vertex, _  
    ByVal PUpToFace As Face _  
) As Body2
```

SOLIDWORKS Type Library

FindAttribute Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function FindAttribute( _  
    ByVal AttributeDef As AttributeDef, _  
    ByVal WhichOne As Long _  
) As Attribute
```

SOLIDWORKS Type Library

GetBodyBox Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetBodyBox() As Variant
```

SOLIDWORKS Type Library

GetCoincidenceTransform Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCoincidenceTransform( _  
    ByVal BodyDispIn As Object, _  
    ByRef Xform As MathTransform _  
) As Boolean
```

SOLIDWORKS Type Library

GetCoincidenceTransform2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCoincidenceTransform2( _  
    ByVal BodyDispIn As Object, _  
    ByRef Xform As MathTransform _  
) As Boolean
```

SOLIDWORKS Type Library

GetEdgeCount Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEdgeCount() As Long
```

SOLIDWORKS Type Library

GetEdges Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEdges() As Variant
```

SOLIDWORKS Type Library

GetExcessBodyArray Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetExcessBodyArray() As Variant
```

SOLIDWORKS Type Library

GetExtremePoint Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetExtremePoint( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByRef Outx As Double, _  
    ByRef Outy As Double, _  
    ByRef Outz As Double _  
) As Boolean
```

SOLIDWORKS Type Library

GetFaceCount Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFaceCount() As Long
```

SOLIDWORKS Type Library

GetFaces Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetFaces() As Variant
```

SOLIDWORKS Type Library

GetFeatureCount Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetFeatureCount() As Long
```

SOLIDWORKS Type Library

GetFeatures Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetFeatures() As Variant
```

SOLIDWORKS Type Library

GetFirstFace Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetFirstFace() As Object
```

SOLIDWORKS Type Library

GetFirstSelectedFace Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetFirstSelectedFace() As Object
```

SOLIDWORKS Type Library

GetGraphicsBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetGraphicsBody() As Object
```

SOLIDWORKS Type Library

GetIgesErrorCode Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetIgesErrorCode( _  
    ByVal Index As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetIgesErrorCount Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetIgesErrorCount() As Long
```

SOLIDWORKS Type Library

GetIntersectionEdges Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetIntersectionEdges( _  
    ByVal ToolBodyIn As Object _  
) As Variant
```

SOLIDWORKS Type Library

GetIntersectionEdges2 Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetIntersectionEdges2( _  
    ByVal ToolBodyIn As Object, _  
    ByVal AddFaceIds As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetMassProperties Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetMassProperties( _  
    ByVal Density As Double _  
) As Variant
```

SOLIDWORKS Type Library

GetMaterialIdName Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetMaterialIdName() As String
```

SOLIDWORKS Type Library

GetMaterialIdName2 Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetMaterialIdName2() As String
```

SOLIDWORKS Type Library

GetMaterialPropertyName Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetMaterialPropertyName( _  
    ByVal ConfigName As String, _  
    ByRef Database As String _  
) As String
```

SOLIDWORKS Type Library

GetMaterialUserName Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetMaterialUserName() As String
```

SOLIDWORKS Type Library

GetMaterialUserName2 Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetMaterialUserName2() As String
```

SOLIDWORKS Type Library

GetMeshBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetMeshBody() As Object
```

SOLIDWORKS Type Library

GetMiddleSurface Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetMiddleSurface( _  
    ByVal PlacementPercentage As Double, _  
    ByRef Face1List As Variant, _  
    ByRef Face2List As Variant, _  
    ByRef Thickness As Variant, _  
    ByRef MiddleSurfaceBody As Object _  
    ) As Long
```

SOLIDWORKS Type Library

GetNextSelectedFace Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetNextSelectedFace() As Object
```

SOLIDWORKS Type Library

GetOriginalPatternedBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetOriginalPatternedBody( _  
    ByRef Xform As MathTransform _  
    ) As Body2
```

SOLIDWORKS Type Library

GetProcessedBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetProcessedBody() As Object
```

SOLIDWORKS Type Library

GetProcessedBody2 Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetProcessedBody2( _  
    ByVal MaxUAngle As Double, _  
    ByVal MaxVAngle As Double _  
    ) As Body2
```

SOLIDWORKS Type Library

GetProcessedBodyWithSelFace Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetProcessedBodyWithSelFace() As Object
```

SOLIDWORKS Type Library

GetPropertyExtension Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetPropertyExtension( _  
    ByVal ID As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

GetPropertyExtension2 Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetPropertyExtension2( _  
    ByVal ID As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

GetSafeBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetSafeBody() As Body2
```

SOLIDWORKS Type Library

GetSelectedFaceCount Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetSelectedFaceCount() As Long
```

SOLIDWORKS Type Library

GetSelectedFaces Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetSelectedFaces() As Variant
```

SOLIDWORKS Type Library

GetSelectionId Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetSelectionId() As String
```

SOLIDWORKS Type Library

GetSheetBody Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSheetBody( _  
    ByVal Index As Integer _  
) As Object
```

SOLIDWORKS Type Library

GetTessellation Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessellation( _  
    ByVal FaceList As Variant _  
) As Object
```

SOLIDWORKS Type Library

GetTexture Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTexture( _  
    ByVal Config_name As String _  
) As Texture
```

SOLIDWORKS Type Library

GetTrackingIDs Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTrackingIDs( _  
    ByVal TrackingCookie As Long, _  
    ByRef TrackingIDs As Variant _  
) As Long
```

SOLIDWORKS Type Library

GetTrackingIDsCount Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTrackingIDsCount( _  
    ByVal TrackingCookie As Long _  
) As Long
```

SOLIDWORKS Type Library

GetType Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetType() As Long
```

SOLIDWORKS Type Library

GetUpdateStamp Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetUpdateStamp() As Long
```

SOLIDWORKS Type Library

GetVertexCount Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetVertexCount() As Long
```

SOLIDWORKS Type Library

GetVertices Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function GetVertices() As Variant
```

SOLIDWORKS Type Library

HasMaterialPropertyValues Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function HasMaterialPropertyValues() As Boolean
```

SOLIDWORKS Type Library

Hide Method (Body2)



Visual Basic for Applications (VBA)

```
Public Sub Hide(  
    ByVal Part As Object _  
)
```

SOLIDWORKS Type Library

HideBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Sub HideBody(  
    ByVal BHide As Boolean _  
)
```

SOLIDWORKS Type Library

IAddProfileArc Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function IAddProfileArc(  
    ByVal Center As Variant, _  
    ByVal Axis As Variant, _  
    ByVal Radius As Double, _  
    ByVal StartPoint As Variant, _  
    ByVal EndPoint As Variant _  
) As Curve
```

SOLIDWORKS Type Library

IAddProfileArcDLL Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddProfileArcDLL( _  
    ByRef Center As Double, _  
    ByRef Axis As Double, _  
    ByVal Radius As Double, _  
    ByRef StartPoint As Double, _  
    ByRef EndPoint As Double _  
) As Curve
```

SOLIDWORKS Type Library

IAddProfileBspline Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddProfileBspline( _  
    ByVal Props As Variant, _  
    ByVal Knots As Variant, _  
    ByVal CtrlPtCoords As Variant _  
) As Curve
```

SOLIDWORKS Type Library

IAddProfileBsplineByPts Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddProfileBsplineByPts( _  
    ByVal NumPoints As Long, _  
    ByRef PointArray As Double _  
) As Curve
```

SOLIDWORKS Type Library

IAddProfileBsplineDLL Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddProfileBsplineDLL( _  
    ByRef Properties As Long, _  
    ByRef KnotArray As Double, _  
    ByRef ControlPointCoordArray As Double _  
) As Curve
```

SOLIDWORKS Type Library

IAddProfileLine Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddProfileLine( _  
    ByVal RootPoint As Variant, _  
    ByVal Direction As Variant _  
) As Curve
```

SOLIDWORKS Type Library

IAddProfileLineDLL Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddProfileLineDLL( _  
    ByRef RootPoint As Double, _  
    ByRef Direction As Double _  
) As Curve
```

SOLIDWORKS Type Library

IAddVertexPoint Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddVertexPoint( _  
    ByRef Point As Double _  
) As Vertex
```

SOLIDWORKS Type Library

ICombineVolumes Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ICombineVolumes( _  
    ByVal ToolBody As Body2 _  
)
```

SOLIDWORKS Type Library

ICopy Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICopy() As Body2
```

SOLIDWORKS Type Library

ICreateBaseFeature Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateBaseFeature( _  
    ByVal BodyIn As Body2 _  
) As Boolean
```

SOLIDWORKS Type Library

ICreateBlendSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateBlendSurface( _  
    ByVal Surface1 As Surface, _  
    ByVal Range1 As Double, _  
    ByVal Surface2 As Surface, _  
    ByVal Range2 As Double, _  
    ByRef StartVec As Double, _  
    ByRef EndVec As Double, _  
    ByVal HaveHelpVec As Integer, _  
    ByRef HelpVec As Double, _  
    ByVal HaveHelpBox As Integer, _  
    ByRef HelpBox As Double _  
) As Surface
```

SOLIDWORKS Type Library

ICreateBodyFromFaces Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateBodyFromFaces( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Variant _  
) As Body2
```

SOLIDWORKS Type Library

ICreateBoundedSurface Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ICreateBoundedSurface( _  
    ByVal UOpt As Boolean, _  
    ByVal VOpt As Boolean, _  
    ByRef UvParams As Double _  
)
```

SOLIDWORKS Type Library

ICreateBsplineSurface Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateBsplineSurface( _  
    ByVal Props As Variant, _  
    ByVal UKnots As Variant, _  
    ByVal VKnots As Variant, _  
    ByVal CtrlPtCoords As Variant _  
) As Surface
```

SOLIDWORKS Type Library

ICreateBsplineSurfaceDLL Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateBsplineSurfaceDLL( _  
    ByRef Properties As Long, _  
    ByRef UKnotArray As Double, _  
    ByRef VKnotArray As Double, _  
    ByRef ControlPointCoordArray As Double _  
) As Surface
```

SOLIDWORKS Type Library

ICreateExtrusionSurface Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateExtrusionSurface( _  
    ByVal ProfileCurve As Curve, _  
    ByVal AxisDirection As Variant _  
) As Surface
```

SOLIDWORKS Type Library

ICreateExtrusionSurfaceDLL Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateExtrusionSurfaceDLL( _  
    ByVal ProfileCurve As Curve, _  
    ByRef AxisDirection As Double _  
    ) As Surface
```

SOLIDWORKS Type Library

ICreateNewSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateNewSurface() As Surface
```

SOLIDWORKS Type Library

ICreateOffsetSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateOffsetSurface( _  
    ByVal SurfaceIn As Surface, _  
    ByVal Distance As Double _  
    ) As Surface
```

SOLIDWORKS Type Library

ICreatePlanarSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreatePlanarSurface( _  
    ByVal VRootPoint As Variant, _  
    ByVal VNormal As Variant _  
    ) As Surface
```

SOLIDWORKS Type Library

ICreatePlanarSurfaceDLL Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreatePlanarSurfaceDLL( _  
    ByRef RootPoint As Double, _  
    ByRef Normal As Double _  
    ) As Surface
```

SOLIDWORKS Type Library

ICreatePlanarTrimSurfaceDLL Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ICreatePlanarTrimSurfaceDLL( _  
    ByVal VertexCount As Long, _  
    ByRef Points As Double, _  
    ByRef Normal As Double _  
    )
```

SOLIDWORKS Type Library

ICreatePsplineSurfaceDLL Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreatePsplineSurfaceDLL( _
    ByVal Dim As Long, _
    ByVal UOrder As Long, _
    ByVal VOrder As Long, _
    ByVal Ncol As Long, _
    ByVal Nrow As Long, _
    ByRef Coeffs As Double, _
    ByVal Basis As Long, _
    ByRef Xform As Double, _
    ByVal ScaleFactor As Double _
) As Surface
```

SOLIDWORKS Type Library

ICreateRevolutionSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateRevolutionSurface( _
    ByVal ProfileCurve As Curve, _
    ByVal AxisPoint As Variant, _
    ByVal AxisDirection As Variant, _
    ByVal ProfileEndPtParams As Variant _
) As Surface
```

SOLIDWORKS Type Library

ICreateRevolutionSurfaceDLL Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateRevolutionSurfaceDLL( _
    ByVal ProfileCurve As Curve, _
    ByRef AxisPoint As Double, _
    ByRef AxisDirection As Double, _
    ByRef ProfileEndPtParams As Double _
) As Surface
```

SOLIDWORKS Type Library

ICreateRuledSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateRuledSurface( _
    ByVal Curve1 As Curve, _
    ByVal Curve2 As Curve, _
    ByRef ApexPoint As Double _
) As Surface
```

SOLIDWORKS Type Library

ICreateTempBodyFromSurfaces Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateTempBodyFromSurfaces() As Body2
```

SOLIDWORKS Type Library

IDeleteBlends Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IDeleteBlends( _
    ByVal NumOfFaces As Long, _
```

```
    ByVal FaceList As Face2 _  
  ) As Boolean
```

SOLIDWORKS Type Library

IDeleteBlends2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IDeleteBlends2( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Face2, _  
    ByVal DoLocalCheck As Boolean _  
  ) As Boolean
```

SOLIDWORKS Type Library

IDeleteBlends3 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IDeleteBlends3( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Face2, _  
    ByVal DoLocalCheck As Boolean, _  
    ByVal UsePlanarCap As Boolean _  
  ) As Boolean
```

SOLIDWORKS Type Library

IDeleteFaces2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IDeleteFaces2( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Face2, _  
    ByVal Option As Integer _  
  ) As Long
```

SOLIDWORKS Type Library

IDeleteFaces3 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IDeleteFaces3( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Face2, _  
    ByVal Option As Long, _  
    ByVal DoLocalCheck As Boolean, _  
    ByRef LocalCheckResult As Boolean _  
  )
```

SOLIDWORKS Type Library

IDeleteFacesMakeSheetBodies Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IDeleteFacesMakeSheetBodies( _  
    ByVal FaceCount As Long, _  
    ByVal FaceList As Face2, _  
    ByVal SheetCount As Long _  
  ) As Body2
```

IDeleteFacesMakeSheetBodiesCount Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function IDeleteFacesMakeSheetBodiesCount( _  
    ByVal FaceCount As Long, _  
    ByVal FaceList As Face2 _  
    ) As Long
```

IDisplay Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub IDisplay( _  
    ByVal Part As PartDoc, _  
    ByVal Color As Long _  
    )
```

IDisplayWireFrameXOR Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub IDisplayWireFrameXOR( _  
    ByVal Part As PartDoc, _  
    ByVal Color As Long _  
    )
```

IDraftBody Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function IDraftBody( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Face2, _  
    ByVal EdgeList As Edge, _  
    ByVal DraftAngle As Double, _  
    ByRef Dir As Double _  
    ) As Boolean
```

IDraftBody2 Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function IDraftBody2( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Face2, _  
    ByVal EdgeList As Edge, _  
    ByVal BasePoint As MathPoint, _  
    ByVal DraftAngle As Double, _  
    ByRef Dir As Double _  
    ) As Boolean
```

IExtendSurface Method (Body2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function IExtendSurface( _  
    ByVal EdgeCount As Long, _  
    ByVal EdgesToExtend As Edge, _  
    ByVal ExtendLinear As Boolean, _  
    ByVal EndCondition As Long, _  
    ByVal Dist As Double, _  
    ByVal PUpToVtx As Vertex, _  
    ByVal PUpToFace As Face _  
) As Body2
```

SOLIDWORKS Type Library

IGetBodyBox Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetBodyBox( _  
    ByRef BoxCorners As Double _  
)
```

SOLIDWORKS Type Library

IGetEdges Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEdges( _  
    ByVal Count As Long _  
) As Edge
```

SOLIDWORKS Type Library

IGetExcessBodyArray Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetExcessBodyArray() As Body2
```

SOLIDWORKS Type Library

IGetExcessBodyCount Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetExcessBodyCount() As Integer
```

SOLIDWORKS Type Library

IGetFaces Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFaces( _  
    ByVal Count As Long _  
) As Face2
```

SOLIDWORKS Type Library

IGetFeatures Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFeatures( _  
    ByVal NumberOfFeatures As Long _  
    ) As Feature
```

SOLIDWORKS Type Library

IGetFirstFace Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFirstFace() As Face2
```

SOLIDWORKS Type Library

IGetFirstSelectedFace Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFirstSelectedFace() As Face2
```

SOLIDWORKS Type Library

IGetIntersectionEdgeCount Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetIntersectionEdgeCount( _  
    ByVal ToolBodyIn As Body2 _  
    ) As Long
```

SOLIDWORKS Type Library

IGetIntersectionEdges Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetIntersectionEdges( _  
    ByVal ToolBodyIn As Body2 _  
    ) As Edge
```

SOLIDWORKS Type Library

IGetMassProperties Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetMassProperties( _  
    ByVal Density As Double _  
    ) As Double
```

SOLIDWORKS Type Library

IGetMaterialPropertyValuesForFace Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetMaterialPropertyValuesForFace( _  
    ByVal FaceIn As Object _  
    ) As Double
```

SOLIDWORKS Type Library

IGetMiddleSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetMiddleSurface( _  
    ByVal PlacementPercentage As Double, _  
    ByRef Face1List As Variant, _  
    ByRef Face2List As Variant, _  
    ByRef Thickness As Variant, _  
    ByRef MiddleSurfaceBody As Body2 _  
) As Long
```

SOLIDWORKS Type Library

IGetNextSelectedFace Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function IGetNextSelectedFace() As Face2
```

SOLIDWORKS Type Library

IGetProcessedBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function IGetProcessedBody() As Body2
```

SOLIDWORKS Type Library

IGetProcessedBodyWithSelFace Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function IGetProcessedBodyWithSelFace() As Body2
```

SOLIDWORKS Type Library

IGetSelectedFaces Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function IGetSelectedFaces( _  
    ByVal SelectedFaceCount As Long _  
) As Face2
```

SOLIDWORKS Type Library

IGetSheetBody Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function IGetSheetBody( _  
    ByVal Index As Integer _  
) As Body2
```

SOLIDWORKS Type Library

IGetTessellation Method (Body2)



Visual Basic for Applications (VBA)

```
Public Function IGetTessellation( _  
    ByVal NumOfFaces As Long, _  
    ByVal FaceList As Face2 _  
) As Tessellation
```

SOLIDWORKS Type Library

IGetTrackingIDs Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTrackingIDs( _  
    ByVal TrackingCookie As Long, _  
    ByVal Count As Long, _  
    ByRef TrackingIDs As Long _  
    ) As Long
```

SOLIDWORKS Type Library

IGetVertices Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetVertices( _  
    ByVal Count As Long _  
    ) As Vertex
```

SOLIDWORKS Type Library

IHide Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IHide( _  
    ByVal Part As PartDoc _  
    )
```

SOLIDWORKS Type Library

IMatchedBoolean Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IMatchedBoolean( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Body2, _  
    ByVal NumOfMatchingFaces As Long, _  
    ByVal FaceList1 As Face2, _  
    ByVal FaceList2 As Face2, _  
    ByRef ErrorCode As Long _  
    ) As EnumBodies2
```

SOLIDWORKS Type Library

IMatchedBoolean2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IMatchedBoolean2( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBodyCount As Long, _  
    ByVal ToolBodyArr As Body2, _  
    ByVal NumOfMatchingFaces As Long, _  
    ByVal FaceList1 As Face2, _  
    ByVal FaceList2 As Face2, _  
    ByRef ErrorCode As Long _  
    ) As EnumBodies2
```

SOLIDWORKS Type Library

IMatchedBoolean3 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IMatchedBoolean3( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBodyCount As Long, _  
    ByVal ToolBodyArr As Body2, _  
    ByVal NumOfMatchingFaces As Long, _  
    ByVal FaceList1 As Face2, _  
    ByVal FaceList2 As Face2, _  
    ByRef ErrorCode As Long _  
) As EnumBodies2
```

SOLIDWORKS Type Library

IMatchedBoolean4 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IMatchedBoolean4( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBodyCount As Long, _  
    ByVal ToolBodyArr As Body2, _  
    ByVal NumOfMatchingFaces As Long, _  
    ByVal FaceList1 As Face2, _  
    ByVal FaceList2 As Face2, _  
    ByVal MatchingTolerance As Double, _  
    ByRef ErrorCode As Long _  
) As EnumBodies2
```

SOLIDWORKS Type Library

IMaterialPropertyValues Property (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IMaterialPropertyValues As Double
```

SOLIDWORKS Type Library

IMaterialPropertyValues2 Property (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IMaterialPropertyValues2 As Double
```

SOLIDWORKS Type Library

IOperations Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IOperations( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Body2, _  
    ByVal NumMaxSections As Long, _  
    ByVal ResultingBodies As Body2 _  
) As Long
```

SOLIDWORKS Type Library

IOperations2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IOperations2( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Body2, _
```

```
ByRef ErrorCode As Long _  
) As EnumBodies2
```

SOLIDWORKS Type Library

IRemoveFacesFromSheet Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IRemoveFacesFromSheet( _  
    ByVal NumOfFaces As Long, _  
    ByVal FacesToRemove As Face2 _  
)
```

SOLIDWORKS Type Library

IRemoveMaterialProperty Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IRemoveMaterialProperty( _  
    ByVal Config_opt As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
) As Boolean
```

SOLIDWORKS Type Library

ISave Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISave( _  
    ByVal StreamIn As Unknown _  
)
```

SOLIDWORKS Type Library

ISectionBySheet Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISectionBySheet( _  
    ByVal Sheet As Body2, _  
    ByVal NumMaxSections As Long, _  
    ByVal SectionedBodies As Body2 _  
) As Long
```

SOLIDWORKS Type Library

ISetCurrentSurface Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetCurrentSurface( _  
    ByVal SurfaceIn As Surface _  
)
```

SOLIDWORKS Type Library

ISetXform Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetXform( _  
    ByRef XformIn As Double _
```

) As Boolean

SOLIDWORKS Type Library

IsGraphicsBody Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsGraphicsBody() As Boolean
```

SOLIDWORKS Type Library

IsMeshBody Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsMeshBody() As Boolean
```

SOLIDWORKS Type Library

IsPatternSeed Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsPatternSeed( _  
    ByVal BodyDispIn As Object _  
) As Boolean
```

SOLIDWORKS Type Library

IsSafe Property (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property IsSafe As Boolean
```

SOLIDWORKS Type Library

IsSheetMetal Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsSheetMetal() As Boolean
```

SOLIDWORKS Type Library

IsTemporaryBody Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsTemporaryBody() As Boolean
```

SOLIDWORKS Type Library

MakeOffset Method (Body2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function MakeOffset( _  
    ByVal Distance As Double, _  
    ByVal Direction As Boolean _  
) As Body2
```

SOLIDWORKS Type Library

MatchedBoolean Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MatchedBoolean( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Object, _  
    ByVal NumOfMatchingFaces As Long, _  
    ByVal FaceList1 As Variant, _  
    ByVal FaceList2 As Variant, _  
    ByRef ErrorCode As Long _  
) As Variant
```

SOLIDWORKS Type Library

MatchedBoolean2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MatchedBoolean2( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Variant, _  
    ByVal NumOfMatchingFaces As Long, _  
    ByVal FaceList1 As Variant, _  
    ByVal FaceList2 As Variant, _  
    ByRef ErrorCode As Long _  
) As Variant
```

SOLIDWORKS Type Library

MatchedBoolean3 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MatchedBoolean3( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Variant, _  
    ByVal NumOfMatchingFaces As Long, _  
    ByVal FaceList1 As Variant, _  
    ByVal FaceList2 As Variant, _  
    ByRef ErrorCode As Long _  
) As Variant
```

SOLIDWORKS Type Library

MatchedBoolean4 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MatchedBoolean4( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Variant, _  
    ByVal NumOfMatchingFaces As Long, _  
    ByVal FaceList1 As Variant, _  
    ByVal FaceList2 As Variant, _  
    ByVal MatchingTolerance As Double, _  
    ByRef ErrorCode As Long _  
) As Variant
```

SOLIDWORKS Type Library

MaterialPropertyValues Property (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaterialPropertyValues As Variant
```

SOLIDWORKS Type Library

MaterialPropertyValues2 Property (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaterialPropertyValues2 As Variant
```

SOLIDWORKS Type Library

MinimumRadius Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MinimumRadius() As Double
```

SOLIDWORKS Type Library

Name Property (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Name As String
```

SOLIDWORKS Type Library

Negate Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Negate() As Boolean
```

SOLIDWORKS Type Library

OffsetPlanarWireBody Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function OffsetPlanarWireBody( _  
    ByVal Distance As Double, _  
    ByVal Normal As MathVector, _  
    ByVal Option As Long _  
) As Body2
```

SOLIDWORKS Type Library

Operations Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Operations( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Object, _  
    ByVal NumMaxSections As Long _  
) As Variant
```

SOLIDWORKS Type Library

Operations2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Operations2( _  
    ByVal OperationType As Integer, _  
    ByVal ToolBody As Object, _  
    ByRef ErrorCode As Long _  
) As Variant
```

SOLIDWORKS Type Library

RemoveFacesFromSheet Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveFacesFromSheet( _  
    ByVal NumOfFaces As Long, _  
    ByVal FacesToRemove As Variant _  
)
```

SOLIDWORKS Type Library

RemoveMaterialProperty Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveMaterialProperty( _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

RemoveRedundantTopology Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveRedundantTopology() As Boolean
```

SOLIDWORKS Type Library

RemoveTexture Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTexture( _  
    ByVal Config_name As String _  
) As Boolean
```

SOLIDWORKS Type Library

RemoveTextureByDisplayState Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTextureByDisplayState( _  
    ByVal DisplayStateName As String _  
) As Boolean
```

SOLIDWORKS Type Library

RemoveTrackingID Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTrackingID( _  
    ByVal TrackingCookie As Long _  
    ) As Long
```

SOLIDWORKS Type Library

ResetEdgeTolerances Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ResetEdgeTolerances()
```

SOLIDWORKS Type Library

ResetPropertyExtension Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ResetPropertyExtension()
```

SOLIDWORKS Type Library

ResetPropertyExtension2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ResetPropertyExtension2()
```

SOLIDWORKS Type Library

Save Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Save( _  
    ByVal StreamIn As Unknown _  
    )
```

SOLIDWORKS Type Library

Select Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Select( _  
    ByVal Append As Boolean, _  
    ByVal Mark As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

Select2 Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Select2( _  
    ByVal Append As Boolean, _  
    ByVal Data As SelectData _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetCurrentSurface Method (Body2)

Syntax

```
Public Sub SetCurrentSurface( _  
    ByVal SurfaceIn As Object _  
)
```

SetIgesInfo Method (Body2) **Syntax**

```
Public Sub SetIgesInfo( _  
    ByVal SystemName As String, _  
    ByVal Granularity As Double, _  
    ByVal AttemptKnitting As Boolean _  
)
```

SetMaterialIdName Method (Body2) **Syntax**

```
Public Function SetMaterialIdName( _  
    ByVal Name As String _  
) As Boolean
```

SetMaterialIdName2 Method (Body2) **Syntax**

```
Public Function SetMaterialIdName2( _  
    ByVal Name As String _  
) As Boolean
```

SetMaterialProperty Method (Body2) **Syntax**

```
Public Function SetMaterialProperty( _  
    ByVal ConfigName As String, _  
    ByVal Database As String, _  
    ByVal MaterialName As String _  
) As Long
```

SetMaterialUserName Method (Body2) **Syntax**

```
Public Function SetMaterialUserName( _  
    ByVal Name As String _  
) As Boolean
```

SetMaterialUserName2 Method (Body2) **Syntax**

```
Public Function SetMaterialUserName2( _  
    ByVal Name As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetTexture Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTexture( _  
    ByVal Config_name As String, _  
    ByVal TextureIn As Texture _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetTextureByDisplayState Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTextureByDisplayState( _  
    ByVal DisplayStateName As String, _  
    ByVal TextureIn As Texture _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetTrackingID Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTrackingID( _  
    ByVal TrackingCookie As Long, _  
    ByVal TrackingID As Long _  
    ) As Long
```

SOLIDWORKS Type Library

SetXform Method (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetXform( _  
    ByVal XformIn As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

Visible Property (Body2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Visible As Boolean
```