

SOLIDWORKS API (VB6 COM) — Reference (15/102): Curve-CustomPropertyManager

SOLIDWORKS API Documentation (converted from CHM)

Curve (Type)

SOLIDWORKS Type Library

Curve Object

Object Model

Curve

CreateSurfaceCurve (Curve)

CreateTrimmedCurve2 (Curve)

CreateWireBody (Body2)

ExtentCurve (Curve)

GetBaseCurve (Curve)

GetBCurveParams5 (SplineParamData)

GetPCurveParams2 (SplineParamData)

ICopy (Curve)

ICreateTrimmedCurve (Curve)

IJoinCurves (Curve)

IRreverseCurve (Curve)

MakeBsplineCurve (Curve)

MakeBsplineCurve2 (Curve)

SimplifyBCurve (Curve)

SOLIDWORKS Type Library

Curve Object Members

Public Methods

 ApplyTransform
 ConvertArcToBcurve
 ConvertLineToBcurve
 Copy
 CreateSurfaceCurve
 CreateTrimmedCurve
 CreateTrimmedCurve2
 CreateWireBody
 Evaluate
 Evaluate2
 ExtentCurve
 FindMinimumRadius

	<u>GetBaseCurve</u>
	<u>GetBCurveParams</u>
	<u>GetBCurveParams3</u>
	<u>GetBCurveParams4</u>
	<u>GetBCurveParams5</u>
	<u>GetClosestPointOn</u>
	<u>GetEllipseParams</u>
	<u>GetEndParams</u>
	<u>GetLength</u>
	<u>GetLength2</u>
	<u>GetLength3</u>
	<u>GetPCurveParams</u>
	<u>GetPCurveParams2</u>
	<u>GetSplinePts</u>
	<u>GetTessPts</u>
	<u>IConvertArcToBcurveSize</u>
	<u>IConvertLineToBcurveSize</u>
	<u>IConvertPCurveToBcurveSize</u>
	<u>ICopy</u>
	<u>ICreateTrimmedCurve</u>
	<u>Identity</u>
	<u>IEvaluate</u>
	<u>IEvaluate2</u>
	<u>IFindMinimumRadius</u>
	<u>IGetBCurveParams</u>
	<u>IGetBCurveParams3</u>
	<u>IGetBCurveParamsSize</u>
	<u>IGetBCurveParamsSize2</u>
	<u>IGetBCurveParamsSize3</u>
	<u>IGetClosestPointOn</u>
	<u>IGetEllipseParams</u>
	<u>IGetPCurveParams</u>
	<u>IGetPCurveParamsSize</u>
	<u>IGetSplinePts</u>
	<u>IGetSplinePtsSize</u>
	<u>IGetTessPts</u>
	<u>IGetTessPtsSize</u>
	<u>IIntersectCurve</u>
	<u>IIntersectCurveSize</u>
	<u>IJoinCurves</u>
	<u>IntersectCurve</u>
	<u>IReverseCurve</u>
	<u>IsBcurve</u>

 IsCircle
 IsEllipse
 IsLine
 IsTrimmedCurve
 JoinCurves
 MakeBsplineCurve
 MakeBsplineCurve2
 ReverseCurve
 ReverseEvaluate
 SimplifyBCurve

Public Properties

 CircleParams
 ICircleParams
 ILineParams
 LineParams

SOLIDWORKS Type Library

ApplyTransform Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ApplyTransform( _
    ByVal Xform As MathTransform _
)
```

SOLIDWORKS Type Library

CircleParams Property (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CircleParams As Variant
```

SOLIDWORKS Type Library

ConvertArcToBcurve Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ConvertArcToBcurve( _
    ByVal Center As Variant, _
    ByVal Axis As Variant, _
    ByVal Start As Variant, _
    ByVal End As Variant _
) As Variant
```

SOLIDWORKS Type Library

ConvertLineToBcurve Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ConvertLineToBcurve( _
    ByVal StartPoint As Variant, _
    ByVal EndPoint As Variant _
) As Variant
```

Copy Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Copy() As Object
```

CreateSurfaceCurve Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateSurfaceCurve( _  
    ByVal Surf As Surface, _  
    ByRef Error As Long _  
) As Curve
```

CreateTrimmedCurve Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateTrimmedCurve( _  
    ByVal X1 As Double, _  
    ByVal Y1 As Double, _  
    ByVal Z1 As Double, _  
    ByVal X2 As Double, _  
    ByVal Y2 As Double, _  
    ByVal Z2 As Double _  
) As Object
```

CreateTrimmedCurve2 Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateTrimmedCurve2( _  
    ByVal X1 As Double, _  
    ByVal Y1 As Double, _  
    ByVal Z1 As Double, _  
    ByVal X2 As Double, _  
    ByVal Y2 As Double, _  
    ByVal Z2 As Double _  
) As Curve
```

CreateWireBody Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateWireBody() As Body2
```

Evaluate Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Evaluate( _  
    ByVal Parameter As Double _  
) As Variant
```

Evaluate2 Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function Evaluate2( _  
    ByVal Parameter As Double, _  
    ByVal NumberOfDerivatives As Long _  
    ) As Variant
```

ExtentCurve Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ExtentCurve( _  
    ByVal AtStart As Boolean, _  
    ByVal Length As Double, _  
    ByVal LinearExt As Boolean _  
    ) As Curve
```

FindMinimumRadius Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function FindMinimumRadius( _  
    ByVal Bound As Variant, _  
    ByRef NumOfRadius As Long, _  
    ByRef Radius As Variant, _  
    ByRef Location As Variant, _  
    ByRef Parameter As Variant _  
    ) As Boolean
```

GetBaseCurve Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetBaseCurve() As Curve
```

GetBCurveParams Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetBCurveParams( _  
    ByVal WantCubicIn As Boolean _  
    ) As Variant
```

GetBCurveParams3 Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetBCurveParams3( _  
    ByVal WantCubicIn As Boolean, _  
    ByVal WantNRRational As Boolean, _  
    ByVal ForceNonPeriodic As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetBCurveParams4 Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBCurveParams4( _  
    ByVal WantCubicIn As Boolean, _  
    ByVal WantNRRational As Boolean, _  
    ByVal ForceNonPeriodic As Boolean, _  
    ByVal IsClosed As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetBCurveParams5 Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBCurveParams5( _  
    ByVal WantCubicIn As Boolean, _  
    ByVal WantNRRational As Boolean, _  
    ByVal ForceNonPeriodic As Boolean, _  
    ByVal IsClosed As Boolean _  
) As SplineParamData
```

SOLIDWORKS Type Library

GetClosestPointOn Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetClosestPointOn( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Variant
```

SOLIDWORKS Type Library

GetEllipseParams Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEllipseParams() As Variant
```

SOLIDWORKS Type Library

GetEndParams Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEndParams( _  
    ByRef Start As Double, _  
    ByRef End As Double, _  
    ByRef IsClosed As Boolean, _  
    ByRef IsPeriodic As Boolean _  
) As Boolean
```

GetLength Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetLength( _  
    ByVal StartParam As Double, _  
    ByVal EndParam As Double _  
    ) As Double
```

GetLength2 Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetLength2( _  
    ByVal StartParam As Double, _  
    ByVal EndParam As Double _  
    ) As Double
```

GetLength3 Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetLength3( _  
    ByVal StartParam As Double, _  
    ByVal EndParam As Double _  
    ) As Double
```

GetPCurveParams Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetPCurveParams() As Variant
```

GetPCurveParams2 Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetPCurveParams2() As SplineParamData
```

GetSplinePts Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetSplinePts( _  
    ByVal ParamsArrayIn As Variant _  
    ) As Variant
```

GetTessPts Method (Curve) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetTessPts( _  
    ByVal ChordTolerance As Double, _  
    ByVal LengthTolerance As Double, _  
    ByVal StartPoint As Variant, _  
    ByVal EndPoint As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

ICircleParams Property (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ICircleParams As Double
```

SOLIDWORKS Type Library

IConvertArcToBcurveSize Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IConvertArcToBcurveSize( _  
    ByRef Center As Double, _  
    ByRef Axis As Double, _  
    ByRef Start As Double, _  
    ByRef End As Double _  
    ) As Long
```

SOLIDWORKS Type Library

IConvertLineToBcurveSize Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IConvertLineToBcurveSize( _  
    ByRef StartPoint As Double, _  
    ByRef EndPoint As Double _  
    ) As Long
```

SOLIDWORKS Type Library

IConvertPcurveToBcurveSize Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IConvertPcurveToBcurveSize( _  
    ByVal Dim As Long, _  
    ByVal Order As Long, _  
    ByVal Nsegs As Long, _  
    ByRef Coeffs As Double, _  
    ByVal Basis As Long, _  
    ByRef Xform As Double, _  
    ByVal ScaleFactor As Double _  
    ) As Long
```

SOLIDWORKS Type Library

ICopy Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICopy() As Curve
```

SOLIDWORKS Type Library

ICreateTrimmedCurve Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateTrimmedCurve( _  
    ByRef Start As Double, _  
    ByRef End As Double _  
    ) As Curve
```

SOLIDWORKS Type Library

Identity Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Identity() As Long
```

SOLIDWORKS Type Library

IEvaluate Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IEvaluate( _  
    ByVal Parameter As Double _  
    ) As Double
```

SOLIDWORKS Type Library

IEvaluate2 Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IEvaluate2( _  
    ByVal Parameter As Double, _  
    ByVal NumberOfDerivatives As Long _  
    ) As Double
```

SOLIDWORKS Type Library

IFindMinimumRadius Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IFindMinimumRadius( _  
    ByRef Bound As Double, _  
    ByRef NumOfRadius As Long, _  
    ByRef Radius As Variant, _  
    ByRef Location As Variant, _  
    ByRef Parameter As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetBCurveParams Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBCurveParams() As Double
```

SOLIDWORKS Type Library

IGetBCurveParams3 Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBCurveParams3( _  
    ByVal ArraySize As Long _  
    ) As Double
```

SOLIDWORKS Type Library

IGetBCurveParamsSize Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBCurveParamsSize( _  
    ByVal WantCubicIn As Boolean _  
    ) As Long
```

SOLIDWORKS Type Library

IGetBCurveParamsSize2 Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBCurveParamsSize2( _  
    ByVal WantCubic As Boolean, _  
    ByVal WantNRational As Boolean _  
    ) As Long
```

SOLIDWORKS Type Library

IGetBCurveParamsSize3 Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetBCurveParamsSize3( _  
    ByVal WantCubicIn As Boolean, _  
    ByVal WantNRational As Boolean, _  
    ByVal ForceNonPeriodic As Boolean _  
    ) As Long
```

SOLIDWORKS Type Library

IGetClosestPointOn Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetClosestPointOn( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Double
```

SOLIDWORKS Type Library

IGetEllipseParams Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetEllipseParams( _  
    ByRef ParamArray As Double _  
    )
```

SOLIDWORKS Type Library

IGetPCurveParams Method (Curve)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPCurveParams() As Double
```

SOLIDWORKS Type Library

IGetPCurveParamsSize Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IGetPCurveParamsSize() As Long
```

SOLIDWORKS Type Library

IGetSplinePts Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IGetSplinePts() As Double
```

SOLIDWORKS Type Library

IGetSplinePtsSize Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IGetSplinePtsSize( _  
    ByRef PropArray As Integer, _  
    ByRef KnotsArray As Double, _  
    ByRef CntrlPntCoordArray As Double _  
    ) As Long
```

SOLIDWORKS Type Library

IGetTessPts Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IGetTessPts( _  
    ByVal ChordTolerance As Double, _  
    ByVal LengthTolerance As Double, _  
    ByRef StartPoint As Double, _  
    ByRef EndPoint As Double _  
    ) As Double
```

SOLIDWORKS Type Library

IGetTessPtsSize Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IGetTessPtsSize( _  
    ByVal ChordTolerance As Double, _  
    ByVal LengthTolerance As Double, _  
    ByRef StartPoint As Double, _  
    ByRef EndPoint As Double _  
    ) As Long
```

SOLIDWORKS Type Library

IIntersectCurve Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IIntersectCurve( _  
    ByVal OtherCurve As Curve, _  
    ByRef ThisStartPoint As Double, _
```

```
ByRef ThisEndPoint As Double, _  
ByRef OtherStartPoint As Double, _  
ByRef OtherEndPoint As Double _  
) As Double
```

SOLIDWORKS Type Library

IIntersectCurveSize Method (Curve)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IIntersectCurveSize( _  
    ByVal OtherCurve As Curve, _  
    ByRef ThisStartPoint As Double, _  
    ByRef ThisEndPoint As Double, _  
    ByRef OtherStartPoint As Double, _  
    ByRef OtherEndPoint As Double _  
) As Long
```

SOLIDWORKS Type Library

IJoinCurves Method (Curve)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IJoinCurves( _  
    ByVal NCurves As Long, _  
    ByVal Curves As Curve _  
) As Curve
```

SOLIDWORKS Type Library

ILineParams Property (Curve)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ILineParams As Double
```

SOLIDWORKS Type Library

IntersectCurve Method (Curve)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IntersectCurve( _  
    ByVal OtherCurve As Object, _  
    ByVal ThisStartPoint As Variant, _  
    ByVal ThisEndPoint As Variant, _  
    ByVal OtherStartPoint As Variant, _  
    ByVal OtherEndPoint As Variant _  
) As Variant
```

SOLIDWORKS Type Library

IRreverseCurve Method (Curve)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IRreverseCurve() As Curve
```

SOLIDWORKS Type Library

IsBcurve Method (Curve)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsBcurve() As Boolean
```

SOLIDWORKS Type Library

IsCircle Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IsCircle() As Boolean
```

SOLIDWORKS Type Library

IsEllipse Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IsEllipse() As Boolean
```

SOLIDWORKS Type Library

IsLine Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IsLine() As Boolean
```

SOLIDWORKS Type Library

IsTrimmedCurve Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function IsTrimmedCurve() As Boolean
```

SOLIDWORKS Type Library

JoinCurves Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function JoinCurves( _  
    ByVal Curves As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

LineParams Property (Curve)



Visual Basic for Applications (VBA)

```
Public Property LineParams As Variant
```

SOLIDWORKS Type Library

MakeBsplineCurve Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function MakeBsplineCurve() As Curve
```

SOLIDWORKS Type Library

MakeBsplineCurve2 Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function MakeBsplineCurve2() As Curve
```

SOLIDWORKS Type Library

ReverseCurve Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function ReverseCurve() As Object
```

SOLIDWORKS Type Library

ReverseEvaluate Method (Curve)



Visual Basic for Applications (VBA)

```
Public Function ReverseEvaluate( _  
    ByVal PositionX As Double, _  
    ByVal PositionY As Double, _  
    ByVal PositionZ As Double _  
) As Double
```

SOLIDWORKS Type Library

SimplifyBCurve Method (Curve)



Visual Basic for Applications (VBA)


```
Public Function SimplifyBCurve( _  
    ByVal TolIn As Double _  
) As Curve
```

CurveDrivenPatternFeatureData (Type)

SOLIDWORKS Type Library

CurveDrivenPatternFeatureData Object

Object Model



SOLIDWORKS Type Library

CurveDrivenPatternFeatureData Object Members

Public Methods

	AccessSelections
	GetPatternBodyCount
	GetPatternFaceCount
	GetPatternFeatureCount
	GetSkippedItemCount
	GetTransform
	IAccessSelections
	IGetPatternBodyArray
	IGetPatternFaceArray
	IGetPatternFeatureArray
	IGetSkippedItemArray
	ISetPatternBodyArray
	ISetPatternFaceArray
	ISetPatternFeatureArray
	ISetSkippedItemArray
	ReleaseSelectionAccess
	SetFeatureScope

Public Properties

	AutoSelect
	BodyPattern
	D1AlignmentMethod
	D1CurveMethod
	D1Direction
	D1FaceNormal
	D1InstanceCount
	D1IsEqualSpaced
	D1ReverseDirection
	D1Spacing
	D2Direction

 D2InstanceCount
 D2IsEqualSpaced
 D2PatternSeedOnly
 D2ReverseDirection
 D2Spacing
 Dir2Specified
 FeatureScope
 FeatureScopeBodies
 GeometryPattern
 PatternBodyArray
 PatternElement
 PatternFaceArray
 PatternFeatureArray
 PropagateVisualProperty
 SkippedItemArray
 VarySketch

SOLIDWORKS Type Library

AccessSelections Method (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

AutoSelect Property (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AutoSelect As Boolean
```

SOLIDWORKS Type Library

BodyPattern Property (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property BodyPattern As Boolean
```

SOLIDWORKS Type Library

D1AlignmentMethod Property (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property D1AlignmentMethod As Long
```

SOLIDWORKS Type Library

D1CurveMethod Property (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property D1CurveMethod As Long

SOLIDWORKS Type Library

D1Direction Property (CurveDrivenPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D1Direction As Object

SOLIDWORKS Type Library

D1FaceNormal Property (CurveDrivenPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D1FaceNormal As Object

SOLIDWORKS Type Library

D1InstanceCount Property (CurveDrivenPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D1InstanceCount As Long

SOLIDWORKS Type Library

D1IsEqualSpaced Property (CurveDrivenPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D1IsEqualSpaced As Boolean

SOLIDWORKS Type Library

D1ReverseDirection Property (CurveDrivenPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D1ReverseDirection As Boolean

SOLIDWORKS Type Library

D1Spacing Property (CurveDrivenPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D1Spacing As Double

SOLIDWORKS Type Library

D2Direction Property (CurveDrivenPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D2Direction As Object

SOLIDWORKS Type Library

D2InstanceCount Property (CurveDrivenPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D2InstanceCount As Long

SOLIDWORKS Type Library

D2IsEqualSpaced Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property D2IsEqualSpaced As Boolean

SOLIDWORKS Type Library

D2PatternSeedOnly Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property D2PatternSeedOnly As Boolean

SOLIDWORKS Type Library

D2ReverseDirection Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property D2ReverseDirection As Boolean

SOLIDWORKS Type Library

D2Spacing Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property D2Spacing As Double

SOLIDWORKS Type Library

Dir2Specified Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property Dir2Specified As Boolean

SOLIDWORKS Type Library

FeatureScope Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property FeatureScope As Boolean

SOLIDWORKS Type Library

FeatureScopeBodies Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property FeatureScopeBodies As Variant

SOLIDWORKS Type Library

GeometryPattern Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property GeometryPattern As Boolean

SOLIDWORKS Type Library

GetPatternBodyCount Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPatternBodyCount() As Long
```

SOLIDWORKS Type Library

GetPatternFaceCount Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPatternFaceCount() As Long
```

SOLIDWORKS Type Library

GetPatternFeatureCount Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPatternFeatureCount() As Long
```

SOLIDWORKS Type Library

GetSkippedItemCount Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSkippedItemCount() As Long
```

SOLIDWORKS Type Library

GetTransform Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTransform( _  
    ByVal Instance As Long _  
    ) As MathTransform
```

SOLIDWORKS Type Library

IAccessSelections Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetPatternBodyArray Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPatternBodyArray() As Body2
```

SOLIDWORKS Type Library

IGetPatternFaceArray Method (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPatternFaceArray() As Object
```

SOLIDWORKS Type Library

IGetPatternFeatureArray Method (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPatternFeatureArray() As Object
```

SOLIDWORKS Type Library

IGetSkippedItemArray Method (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSkippedItemArray() As Long
```

SOLIDWORKS Type Library

ISetPatternBodyArray Method (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetPatternBodyArray( _  
    ByVal BodyCount As Long, _  
    ByVal ArrayDataIn As Body2 _  
)
```

SOLIDWORKS Type Library

ISetPatternFaceArray Method (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetPatternFaceArray( _  
    ByVal FaceCount As Long, _  
    ByRef ArrayDataIn As Object _  
)
```

SOLIDWORKS Type Library

ISetPatternFeatureArray Method (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetPatternFeatureArray( _  
    ByVal FeatCount As Long, _  
    ByRef ArrayDataIn As Object _  
)
```

SOLIDWORKS Type Library

ISetSkippedItemArray Method (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetSkippedItemArray( _  
    ByVal FeatCount As Long, _  
    ByRef ArrayDataIn As Long _  
)
```

SOLIDWORKS Type Library

PatternBodyArray Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PatternBodyArray As Variant
```

SOLIDWORKS Type Library

PatternElement Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PatternElement As Long
```

SOLIDWORKS Type Library

PatternFaceArray Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PatternFaceArray As Variant
```

SOLIDWORKS Type Library

PatternFeatureArray Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PatternFeatureArray As Variant
```

SOLIDWORKS Type Library

PropagateVisualProperty Property (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PropagateVisualProperty As Boolean
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SetFeatureScope Method (CurveDrivenPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetFeatureScope( _  
    ByVal FeatureScopeOption As Boolean, _  
    ByVal AutoSelectBodies As Boolean, _  
    ByVal Bodies As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SkippedItemArray Property (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SkippedItemArray As Variant
```

SOLIDWORKS Type Library

VarySketch Property (CurveDrivenPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property VarySketch As Boolean
```

CurveParamData (Type)

SOLIDWORKS Type Library
CurveParamData Object

Object Model

CurveParamData

SOLIDWORKS Type Library
CurveParamData Object Members

Public Properties

- CurveTag
- CurveType
- EndPoint
- Sense
- StartPoint
- UMaxValue
- UMinValue

SOLIDWORKS Type Library
CurveTag Property (CurveParamData)

Syntax

Visual Basic for Applications (VBA)

Public Property CurveTag As Long

SOLIDWORKS Type Library
CurveType Property (CurveParamData)

Syntax

Visual Basic for Applications (VBA)

Public Property CurveType As Long

SOLIDWORKS Type Library
EndPoint Property (CurveParamData)

Syntax

Visual Basic for Applications (VBA)

Public Property EndPoint As Variant

SOLIDWORKS Type Library
Sense Property (CurveParamData)

Syntax

Visual Basic for Applications (VBA)

Public Property Sense As Boolean

SOLIDWORKS Type Library
StartPoint Property (CurveParamData)

Syntax

Visual Basic for Applications (VBA)

Public Property StartPoint As Variant

SOLIDWORKS Type Library

UMaxValue Property (CurveParamData)



Visual Basic for Applications (VBA)

Public Property UMaxValue As Double

SOLIDWORKS Type Library

UMinValue Property (CurveParamData)



Visual Basic for Applications (VBA)

Public Property UMinValue As Double

CustomBendAllowance (Type)

SOLIDWORKS Type Library
CustomBendAllowance Object

Object Model

CustomBendAllowance

SOLIDWORKS Type Library
CustomBendAllowance Object Members

Public Properties

- BendAllowance
- BendCalculationTableFile
- BendDeduction
- BendTableFile
- KFactor
- Type

SOLIDWORKS Type Library
BendAllowance Property (CustomBendAllowance)

Syntax

Visual Basic for Applications (VBA)

Public Property BendAllowance As Double

SOLIDWORKS Type Library
BendCalculationTableFile Property (CustomBendAllowance)

Syntax

Visual Basic for Applications (VBA)

Public Property BendCalculationTableFile As String

SOLIDWORKS Type Library
BendDeduction Property (CustomBendAllowance)

Syntax

Visual Basic for Applications (VBA)

Public Property BendDeduction As Double

SOLIDWORKS Type Library
BendTableFile Property (CustomBendAllowance)

Syntax

Visual Basic for Applications (VBA)

Public Property BendTableFile As String

SOLIDWORKS Type Library
KFactor Property (CustomBendAllowance)

Syntax

Visual Basic for Applications (VBA)

Public Property KFactor As Double

SOLIDWORKS Type Library

Type Property (CustomBendAllowance)



Visual Basic for Applications (VBA)

Public Property Type As Long

CustomPropertyManager (Type)

SOLIDWORKS Type Library

CustomPropertyManager Object

Object Model

CustomPropertyManager

SOLIDWORKS Type Library

CustomPropertyManager Object Members

Public Methods

	Add
	Add2
	Add3
	Delete
	Delete2
	Get
	Get2
	Get3
	Get4
	Get5
	Get6
	GetAll
	GetAll2
	GetAll3
	GetNames
	GetType
	GetType2
	IGetAll
	IGetNames
	IsCustomPropertyEditable
	LinkProperty
	Set
	Set2

Public Properties

	Count
	LinkAll
	Owner

SOLIDWORKS Type Library

Add Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Add( _  
    ByVal FieldName As String, _  
    ByVal FieldType As String, _  
    ByVal FieldValue As String _  
) As Long
```

SOLIDWORKS Type Library

Add2 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Add2( _  
    ByVal FieldName As String, _  
    ByVal FieldType As Long, _  
    ByVal FieldValue As String _  
) As Long
```

SOLIDWORKS Type Library

Add3 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Add3( _  
    ByVal FieldName As String, _  
    ByVal FieldType As Long, _  
    ByVal FieldValue As String, _  
    ByVal OverwriteExisting As Long _  
) As Long
```

SOLIDWORKS Type Library

Count Property (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Count As Long
```

SOLIDWORKS Type Library

Delete Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Delete( _  
    ByVal FieldName As String _  
) As Long
```

SOLIDWORKS Type Library

Delete2 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Delete2( _  
    ByVal FieldName As String _  
) As Long
```

SOLIDWORKS Type Library

Get Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get( _  
    ByVal FieldName As String _  
    ) As String
```

SOLIDWORKS Type Library

Get2 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Get2( _  
    ByVal FieldName As String, _  
    ByRef ValOut As String, _  
    ByRef ReesolvedValOut As String _  
    )
```

SOLIDWORKS Type Library

Get3 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get3( _  
    ByVal FieldName As String, _  
    ByVal UseCached As Boolean, _  
    ByRef ValOut As String, _  
    ByRef ResolvedValOut As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

Get4 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get4( _  
    ByVal FieldName As String, _  
    ByVal UseCached As Boolean, _  
    ByRef ValOut As String, _  
    ByRef ResolvedValOut As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

Get5 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get5( _  
    ByVal FieldName As String, _  
    ByVal UseCached As Boolean, _  
    ByRef ValOut As String, _  
    ByRef ResolvedValOut As String, _  
    ByRef WasResolved As Boolean _  
    ) As Long
```

SOLIDWORKS Type Library

Get6 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Get6( _  
    ByVal FieldName As String, _  
    ByVal UseCached As Boolean, _  
    ByRef ValOut As String, _
```

```
ByRef ResolvedValOut As String, _  
ByRef WasResolved As Boolean, _  
ByRef LinkToProperty As Boolean _  
) As Long
```

SOLIDWORKS Type Library

GetAll Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAll( _  
ByRef PropNames As Variant, _  
ByRef PropTypes As Variant, _  
ByRef PropValues As Variant _  
) As Long
```

SOLIDWORKS Type Library

GetAll2 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAll2( _  
ByRef PropNames As Variant, _  
ByRef PropTypes As Variant, _  
ByRef PropValues As Variant, _  
ByRef Resolved As Variant _  
) As Long
```

SOLIDWORKS Type Library

GetAll3 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAll3( _  
ByRef PropNames As Variant, _  
ByRef PropTypes As Variant, _  
ByRef PropValues As Variant, _  
ByRef Resolved As Variant, _  
ByRef PropLink As Variant _  
) As Long
```

SOLIDWORKS Type Library

GetNames Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNames() As Variant
```

SOLIDWORKS Type Library

GetType Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetType( _  
ByVal FieldName As String _  
) As String
```

SOLIDWORKS Type Library

GetType2 Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetType2( _  
    ByVal FieldName As String _  
    ) As Long
```

SOLIDWORKS Type Library

IGetAll Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetAll( _  
    ByVal Count As Long, _  
    ByRef PropNames As String, _  
    ByRef PropTypes As Long, _  
    ByRef PropValues As String _  
    )
```

SOLIDWORKS Type Library

IGetNames Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNames( _  
    ByVal Count As Long _  
    ) As String
```

SOLIDWORKS Type Library

IsCustomPropertyEditable Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsCustomPropertyEditable( _  
    ByVal PropertyName As String, _  
    ByVal ConfigurationName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

LinkAll Property (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Property LinkAll As Boolean
```

SOLIDWORKS Type Library

LinkProperty Method (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function LinkProperty( _  
    ByVal FieldName As String, _  
    ByVal FieldLink As Boolean _  
    ) As Long
```

SOLIDWORKS Type Library

Owner Property (CustomPropertyManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Owner As Object
```

Set Method (CustomPropertyManager)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function Set( _  
    ByVal FieldName As String, _  
    ByVal FieldValue As String _  
    ) As Long
```

Set2 Method (CustomPropertyManager)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function Set2( _  
    ByVal FieldName As String, _  
    ByVal FieldValue As String _  
    ) As Long
```