

SOLIDWORKS API (VB6 COM) — Reference (17/102): DerivedPartFeatureData- DimensionSensorData

SOLIDWORKS API Documentation (converted from CHM)

DerivedPartFeatureData (Type)

SOLIDWORKS Type Library

DerivedPartFeatureData Object

Object Model

DerivedPartFeatureData

GetModelDoc (ModelDoc2)

GetMoveFeature (Feature)

SOLIDWORKS Type Library

DerivedPartFeatureData Object Members

Public Methods

	AccessSelections
	GetModelDoc
	GetMoveFeature
	IAccessSelections
	ReleaseSelectionAccess

Public Properties

	ImportAbsorbedSketches
	ImportAxis
	ImportCoordinateSystems
	ImportCThread
	ImportCustomProperties
	ImportCuttListProperties
	ImportHoleWizardData
	ImportMaterial
	ImportModelDimensions
	ImportPlane
	ImportSheetMetalInformation
	ImportSolidBodies
	ImportSurf
	ImportUnAbsorbedSketches
	PartConfiguration
	PathName

SOLIDWORKS Type Library

AccessSelections Method (DerivedPartFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetModelDoc Method (DerivedPartFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetModelDoc() As ModelDoc2
```

SOLIDWORKS Type Library

GetMoveFeature Method (DerivedPartFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMoveFeature() As Feature
```

SOLIDWORKS Type Library

IAccessSelections Method (DerivedPartFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

ImportAbsorbedSketches Property (DerivedPartFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ImportAbsorbedSketches As Boolean
```

SOLIDWORKS Type Library

ImportAxis Property (DerivedPartFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ImportAxis As Boolean
```

SOLIDWORKS Type Library

ImportCoordinateSystems Property (DerivedPartFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ImportCoordinateSystems As Boolean
```

SOLIDWORKS Type Library

ImportCThread Property (DerivedPartFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ImportCThread As Boolean
```

SOLIDWORKS Type Library

ImportCustomProperties Property (DerivedPartFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ImportCustomProperties As Long
```

SOLIDWORKS Type Library

ImportCutListProperties Property (DerivedPartFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ImportCutListProperties As Boolean
```

SOLIDWORKS Type Library

ImportHoleWizardData Property (DerivedPartFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ImportHoleWizardData As Boolean
```

SOLIDWORKS Type Library

ImportMaterial Property (DerivedPartFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ImportMaterial As Boolean
```

SOLIDWORKS Type Library

ImportModelDimensions Property (DerivedPartFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ImportModelDimensions As Boolean
```

SOLIDWORKS Type Library

ImportPlane Property (DerivedPartFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ImportPlane As Boolean
```

SOLIDWORKS Type Library

ImportSheetMetalInformation Property (DerivedPartFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ImportSheetMetalInformation As Long
```

SOLIDWORKS Type Library

ImportSolidBodies Property (DerivedPartFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ImportSolidBodies As Boolean
```

SOLIDWORKS Type Library

ImportSurf Property (DerivedPartFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ImportSurf As Boolean
```

SOLIDWORKS Type Library

ImportUnAbsorbedSketches Property (DerivedPartFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ImportUnAbsorbedSketches As Boolean
```

SOLIDWORKS Type Library

PartConfiguration Property (DerivedPartFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PartConfiguration As String
```

SOLIDWORKS Type Library

PathName Property (DerivedPartFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PathName As String
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (DerivedPartFeatureData)




Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

DerivedPatternFeatureData (Type)

SOLIDWORKS Type Library
DerivedPatternFeatureData Object



SOLIDWORKS Type Library
DerivedPatternFeatureData Object Members

Public Methods

	AccessSelections
	GetSeedComponentCount
	GetSkippedItemCount
	GetTransform
	IAccessSelections
	IAccessSelections2
	IGetSeedComponentArray
	IGetSkippedItemArray
	ISetSeedComponentArray
	ISetSkippedItemArray
	ReleaseSelectionAccess

Public Properties

	DrivingFeatureSkippedItemArray
	ForceUseSeedConfiguration
	PatternFeature
	PropagateVisualProperty
	SeedComponentArray
	SeedPosition
	SkippedItemArray

SOLIDWORKS Type Library
AccessSelections Method (DerivedPatternFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library
DrivingFeatureSkippedItemArray Property (DerivedPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property DrivingFeatureSkippedItemArray As Variant

SOLIDWORKS Type Library

ForceUseSeedConfiguration Property (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property ForceUseSeedConfiguration As Boolean

SOLIDWORKS Type Library

GetSeedComponentCount Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

Public Function GetSeedComponentCount() As Long

SOLIDWORKS Type Library

GetSkippedItemCount Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

Public Function GetSkippedItemCount() As Long

SOLIDWORKS Type Library

GetTransform Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetTransform( _  
    ByVal Instance As Long _  
) As MathTransform
```

SOLIDWORKS Type Library

IAccessSelections Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As Boolean
```

SOLIDWORKS Type Library

IAccessSelections2 Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As Boolean
```

SOLIDWORKS Type Library

IGetSeedComponentArray Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IGetSeedComponentArray() As Object
```

SOLIDWORKS Type Library

IGetSkippedItemArray Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IGetSkippedItemArray() As Long
```

SOLIDWORKS Type Library

ISetSeedComponentArray Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub ISetSeedComponentArray( _  
    ByVal FeatCount As Long, _  
    ByRef ArrayDataIn As Object _  
)
```

SOLIDWORKS Type Library

ISetSkippedItemArray Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub ISetSkippedItemArray( _  
    ByVal FeatCount As Long, _  
    ByRef ArrayDataIn As Long _  
)
```

SOLIDWORKS Type Library

PatternFeature Property (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property PatternFeature As Object
```

SOLIDWORKS Type Library

PropagateVisualProperty Property (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property PropagateVisualProperty As Boolean
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SeedComponentArray Property (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property SeedComponentArray As Variant
```

SeedPosition Property (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SeedPosition As Long

SkippedItemArray Property (DerivedPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SkippedItemArray As Variant

DesignTable (Type)

SOLIDWORKS Type Library

DesignTable Object

Object Model

DesignTable

SOLIDWORKS Type Library

DesignTable Object Members

Public Methods

	AddRow
	Attach
	Detach
	EditFeature
	EditTable
	EditTable2
	GetColumnCount
	GetEntryText
	GetEntryValue
	GetHeaderText
	GetRowCount
	GetStartColumnNumber
	GetStartRowNumber
	GetTitle
	GetTotalColumnCount
	GetTotalRowCount
	GetVisibleColumnCount
	GetVisibleLeftColumnNumber
	GetVisibleRowCount
	GetVisibleTopRowNumber
	IsActive
	SaveAsExcelFile
	SetEntryText
	SetEntryValue
	SetRowChanged
	UpdateFeature
	UpdateModel
	UpdateTable

Public Properties

	AutoAddNewConfigs
	AutoAddNewParams

 ColumnHidden
 EnableCellDropdownLists
 FileName
 LastError
 LinkToFile
 RowHidden
 SourceType
 Updatable
 Warn
 Worksheet

SOLIDWORKS Type Library

AddRow Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddRow( _  
    ByVal CellValues As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

Attach Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Attach() As Boolean
```

SOLIDWORKS Type Library

AutoAddNewConfigs Property (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AutoAddNewConfigs As Boolean
```

SOLIDWORKS Type Library

AutoAddNewParams Property (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AutoAddNewParams As Boolean
```

SOLIDWORKS Type Library

ColumnHidden Property (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ColumnHidden( _  
    ByVal Col As Long _  
) As Boolean
```

SOLIDWORKS Type Library

Detach Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Detach()
```

SOLIDWORKS Type Library

EditFeature Method (DesignTable)

 Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditFeature()
```

SOLIDWORKS Type Library

EditTable Method (DesignTable)

 Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditTable()
```

SOLIDWORKS Type Library

EditTable2 Method (DesignTable)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function EditTable2( _  
    ByVal NewWindow As Boolean _  
    ) As Object
```

SOLIDWORKS Type Library

EnableCellDropdownLists Property (DesignTable)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property EnableCellDropdownLists As Boolean
```

SOLIDWORKS Type Library

FileName Property (DesignTable)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property FileName As String
```

SOLIDWORKS Type Library

GetColumnCount Method (DesignTable)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetColumnCount() As Long
```

SOLIDWORKS Type Library

GetEntryText Method (DesignTable)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEntryText( _  
    ByVal Row As Long, _  
    ByVal Col As Long _  
    ) As String
```

SOLIDWORKS Type Library

GetEntryValue Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEntryValue( _  
    ByVal Row As Long, _  
    ByVal Col As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetHeaderText Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetHeaderText( _  
    ByVal Col As Long _  
) As String
```

SOLIDWORKS Type Library

GetRowCount Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRowCount() As Long
```

SOLIDWORKS Type Library

GetStartColumnNumber Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetStartColumnNumber() As Long
```

SOLIDWORKS Type Library

GetStartRowNumber Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetStartRowNumber() As Long
```

SOLIDWORKS Type Library

GetTitle Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTitle() As String
```

SOLIDWORKS Type Library

GetTotalColumnCount Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTotalColumnCount() As Long
```

SOLIDWORKS Type Library

GetTotalRowCount Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTotalRowCount() As Long
```

SOLIDWORKS Type Library

GetVisibleColumnCount Method (DesignTable)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetVisibleColumnCount() As Long
```

SOLIDWORKS Type Library

GetVisibleLeftColumnNumber Method (DesignTable)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetVisibleLeftColumnNumber() As Long
```

SOLIDWORKS Type Library

GetVisibleRowCount Method (DesignTable)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetVisibleRowCount() As Long
```

SOLIDWORKS Type Library

GetVisibleTopRowNumber Method (DesignTable)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetVisibleTopRowNumber() As Long
```

SOLIDWORKS Type Library

IsActive Method (DesignTable)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function IsActive() As Boolean
```

SOLIDWORKS Type Library

LastError Property (DesignTable)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property LastError As Long
```

SOLIDWORKS Type Library

LinkToFile Property (DesignTable)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property LinkToFile As Boolean
```

SOLIDWORKS Type Library

RowHidden Property (DesignTable)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property RowHidden( _  
    ByVal Row As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SaveAsExcelFile Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SaveAsExcelFile( _  
    ByVal Value As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetEntryText Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetEntryText( _  
    ByVal Row As Long, _  
    ByVal Col As Long, _  
    ByVal TextIn As String _  
)
```

SOLIDWORKS Type Library

SetEntryValue Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetEntryValue( _  
    ByVal Row As Long, _  
    ByVal Col As Long, _  
    ByVal IsText As Boolean, _  
    ByVal Retval As String _  
)
```

SOLIDWORKS Type Library

SetRowChanged Method (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetRowChanged( _  
    ByVal RowIndex As Long _  
)
```

SOLIDWORKS Type Library

SourceType Property (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SourceType As Long
```

SOLIDWORKS Type Library

Updatable Property (DesignTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Updatable As Boolean
```

SOLIDWORKS Type Library

UpdateFeature Method (DesignTable)



Visual Basic for Applications (VBA)

```
Public Function UpdateFeature() As Boolean
```

SOLIDWORKS Type Library

UpdateModel Method (DesignTable)



Visual Basic for Applications (VBA)

```
Public Function UpdateModel() As Boolean
```

SOLIDWORKS Type Library

UpdateTable Method (DesignTable)



Visual Basic for Applications (VBA)

```
Public Function UpdateTable( _  
    ByVal Type As Long, _  
    ByVal Close As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

Warn Property (DesignTable)



Visual Basic for Applications (VBA)

```
Public Property Warn As Boolean
```

SOLIDWORKS Type Library

Worksheet Property (DesignTable)




Visual Basic for Applications (VBA)

```
Public Property Worksheet As Object
```

DetailCircle (Type)

SOLIDWORKS Type Library
DetailCircle Object

Object Model



SOLIDWORKS Type Library
DetailCircle Object Members

Public Methods

	GetArrowInfo
	GetConnectingLine
	GetDetailView
	GetDisplay
	GetLabel
	GetLabelPosition
	GetLeaderInfo
	GetName
	GetProfileItems
	GetProfileItemsCount
	GetStyle
	GetTextFormat
	GetUseDocTextFormat
	GetView
	HasFullOutline
	IGetArrowInfo
	IGetConnectingLine
	IGetLeaderInfo
	IGetProfileItems
	Select
	SetDisplay
	SetFullOutline
	SetLabel
	SetLabelPosition
	SetName
	SetParameters
	SetStyle



[SetTextFormat](#)

Public Properties



[JaggedOutline](#)



[Layer](#)



[NoOutline](#)



[PinPosition](#)



[ScaleHatchPattern](#)



[ShapeIntensity](#)

SOLIDWORKS Type Library

GetArrowInfo Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetArrowInfo() As Variant
```

SOLIDWORKS Type Library

GetConnectingLine Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetConnectingLine() As Variant
```

SOLIDWORKS Type Library

GetDetailView Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDetailView() As View
```

SOLIDWORKS Type Library

GetDisplay Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDisplay() As Long
```

SOLIDWORKS Type Library

GetLabel Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLabel() As String
```

SOLIDWORKS Type Library

GetLabelPosition Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetLabelPosition( _  
    ByRef XPosition As Double, _  
    ByRef YPosition As Double _  
)
```

SOLIDWORKS Type Library

GetLeaderInfo Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLeaderInfo() As Variant
```

SOLIDWORKS Type Library

GetName Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetName() As String
```

SOLIDWORKS Type Library

GetProfileItems Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProfileItems() As Variant
```

SOLIDWORKS Type Library

GetProfileItemsCount Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProfileItemsCount() As Long
```

SOLIDWORKS Type Library

GetStyle Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetStyle() As Long
```

SOLIDWORKS Type Library

GetTextFormat Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTextFormat() As TextFormat
```

SOLIDWORKS Type Library

GetUseDocTextFormat Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUseDocTextFormat() As Boolean
```

SOLIDWORKS Type Library

GetView Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetView() As View
```

SOLIDWORKS Type Library

HasFullOutline Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function HasFullOutline() As Boolean
```

SOLIDWORKS Type Library

IGetArrowInfo Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetArrowInfo() As Double
```

SOLIDWORKS Type Library

IGetConnectingLine Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetConnectingLine() As Double
```

SOLIDWORKS Type Library

IGetLeaderInfo Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetLeaderInfo() As Double
```

SOLIDWORKS Type Library

IGetProfileItems Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetProfileItems( _  
    ByVal Count As Long _  
) As SketchSegment
```

SOLIDWORKS Type Library

JaggedOutline Property (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Property JaggedOutline As Boolean
```

SOLIDWORKS Type Library

Layer Property (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Layer As String
```

SOLIDWORKS Type Library

NoOutline Property (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Property NoOutline As Boolean
```

SOLIDWORKS Type Library

PinPosition Property (DetailCircle)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property PinPosition As Boolean
```

SOLIDWORKS Type Library

ScaleHatchPattern Property (DetailCircle)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property ScaleHatchPattern As Boolean
```

SOLIDWORKS Type Library

Select Method (DetailCircle)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function Select( _  
    ByVal Append As Boolean, _  
    ByVal Data As SelectData _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetDisplay Method (DetailCircle)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function SetDisplay( _  
    ByVal Display As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetFullOutline Method (DetailCircle)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function SetFullOutline( _  
    ByVal FullOutline As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetLabel Method (DetailCircle)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function SetLabel( _  
    ByVal Label As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetLabelPosition Method (DetailCircle)

 Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetLabelPosition( _  
    ByVal XPosition As Double, _  
    ByVal YPosition As Double _  
)
```

SOLIDWORKS Type Library

SetName Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetName( _  
    ByVal Name As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetParameters Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetParameters( _  
    ByVal XPosition As Double, _  
    ByVal YPosition As Double, _  
    ByVal Radius As Double _  
) As Boolean
```

SOLIDWORKS Type Library

SetStyle Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetStyle( _  
    ByVal Style As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetTextFormat Method (DetailCircle)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTextFormat( _  
    ByVal UseDoc As Boolean, _  
    ByVal TextFormat As TextFormat _  
) As Boolean
```

SOLIDWORKS Type Library

ShapeIntensity Property (DetailCircle)

Syntax


Visual Basic for Applications (VBA)

```
Public Property ShapeIntensity As Long
```

DiagnoseResult (Type)

SOLIDWORKS Type Library
DiagnoseResult Object

Object Model



SOLIDWORKS Type Library
DiagnoseResult Object Members

Public Methods

	GetCoEdgesAtGap
	GetCoEdgesCountAtGap
	GetGapsCount
	IGetCoEdgesAtGap

SOLIDWORKS Type Library
GetCoEdgesAtGap Method (DiagnoseResult)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetCoEdgesAtGap( _
    ByVal Index As Long _
) As Variant
```

SOLIDWORKS Type Library
GetCoEdgesCountAtGap Method (DiagnoseResult)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetCoEdgesCountAtGap( _
    ByVal Index As Long _
) As Long
```

SOLIDWORKS Type Library
GetGapsCount Method (DiagnoseResult)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetGapsCount() As Long
```

SOLIDWORKS Type Library
IGetCoEdgesAtGap Method (DiagnoseResult)

Syntax

```
Visual Basic for Applications (VBA)


Public Function IGetCoEdgesAtGap( _
    ByVal Index As Long, _
    ByVal CoEdgeCount As Long _
) As CoEdge
```

Dimension (Type)

SOLIDWORKS Type Library

Dimension Object

Object Model



SOLIDWORKS Type Library

Dimension Object Members

Public Methods

	GetArcEndCondition
	GetFeatureOwner
	GetNameForSelection
	GetReferencePointsCount
	GetSystemChamferValues
	GetSystemValue2
	GetSystemValue3
	GetToleranceFitValues
	GetToleranceFontInfo
	GetToleranceType
	GetToleranceValues
	GetType
	GetUserValueIn
	GetValue2
	GetValue3
	IGetReferencePoints
	IGetSystemValue3
	IGetToleranceFontInfo
	IGetToleranceValues
	IGetUserValueIn
	IGetUserValueIn2
	IGetValue3
	IsAppliedToAllConfigurations
	IsDesignTableDimension
	ISetReferencePoints

 ISetSystemValue3
 ISetUserValueIn
 ISetUserValueIn2
 ISetUserValueIn3
 ISetValue3
 IsReference
 SetArcEndCondition
 SetSystemValue2
 SetSystemValue3
 SetToleranceFitValues
 SetToleranceFontInfo
 SetToleranceType
 SetToleranceValues
 SetUserValueIn
 SetUserValueIn2
 SetValue2
 SetValue3

Public Properties

 DimensionLineDirection
 DrivenState
 ExtensionLineDirection
 FullName
 Name
 ReadOnly
 ReferencePoints
 SystemValue
 Tolerance
 Value

SOLIDWORKS Type Library

DimensionLineDirection Property (Dimension)

Syntax

Visual Basic for Applications (VBA)

Public Property DimensionLineDirection As [MathVector](#)

SOLIDWORKS Type Library

DrivenState Property (Dimension)

Syntax

Visual Basic for Applications (VBA)

Public Property DrivenState As Long

SOLIDWORKS Type Library

ExtensionLineDirection Property (Dimension)

Syntax

Visual Basic for Applications (VBA)

Public Property ExtensionLineDirection As [MathVector](#)

SOLIDWORKS Type Library

FullName Property (Dimension)



Visual Basic for Applications (VBA)

Public Property FullName As String

SOLIDWORKS Type Library

GetArcEndCondition Method (Dimension)



Visual Basic for Applications (VBA)

```
Public Function GetArcEndCondition( _  
    ByVal Index As Long _  
) As Long
```

SOLIDWORKS Type Library

GetFeatureOwner Method (Dimension)



Visual Basic for Applications (VBA)

Public Function GetFeatureOwner() As [Feature](#)

SOLIDWORKS Type Library

GetNameForSelection Method (Dimension)



Visual Basic for Applications (VBA)

Public Function GetNameForSelection() As String

SOLIDWORKS Type Library

GetReferencePointsCount Method (Dimension)



Visual Basic for Applications (VBA)

Public Function GetReferencePointsCount() As Long

SOLIDWORKS Type Library

GetSystemChamferValues Method (Dimension)



Visual Basic for Applications (VBA)

```
Public Function GetSystemChamferValues( _  
    ByRef Length As Double, _  
    ByRef Angle As Double _  
) As Boolean
```

SOLIDWORKS Type Library

GetSystemValue2 Method (Dimension)



Visual Basic for Applications (VBA)

```
Public Function GetSystemValue2( _  
    ByVal ConfigName As String _  
) As Double
```

SOLIDWORKS Type Library

GetSystemValue3 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSystemValue3( _  
    ByVal WhichConfigurations As Long, _  
    ByVal Config_names As Variant _  
) As Variant
```

SOLIDWORKS Type Library

GetToleranceFitValues Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetToleranceFitValues() As String
```

SOLIDWORKS Type Library

GetToleranceFontInfo Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetToleranceFontInfo() As Variant
```

SOLIDWORKS Type Library

GetToleranceType Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetToleranceType() As Long
```

SOLIDWORKS Type Library

GetToleranceValues Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetToleranceValues() As Variant
```

SOLIDWORKS Type Library

GetType Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetType() As Long
```

SOLIDWORKS Type Library

GetUserValueIn Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUserValueIn( _  
    ByVal Doc As Object _  
    ) As Double
```

SOLIDWORKS Type Library

GetValue2 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetValue2( _  
    ByVal ConfigName As String _  
    ) As Double
```

SOLIDWORKS Type Library

GetValue3 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetValue3( _  
    ByVal WhichConfigurations As Long, _  
    ByVal Config_names As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

IGetReferencePoints Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetReferencePoints( _  
    ByVal PointsCount As Long _  
    ) As MathPoint
```

SOLIDWORKS Type Library

IGetSystemValue3 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSystemValue3( _  
    ByVal WhichConfigurations As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
    ) As Double
```

SOLIDWORKS Type Library

IGetToleranceFontInfo Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetToleranceFontInfo() As Double
```

SOLIDWORKS Type Library

IGetToleranceValues Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetToleranceValues() As Double
```

SOLIDWORKS Type Library

IGetUserValueIn Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUserValueIn( _  
    ByVal Doc As ModelDoc _  
) As Double
```

SOLIDWORKS Type Library

IGetUserValueIn2 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUserValueIn2( _  
    ByVal Doc As ModelDoc2 _  
) As Double
```

SOLIDWORKS Type Library

IGetValue3 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetValue3( _  
    ByVal WhichConfigurations As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
) As Double
```

SOLIDWORKS Type Library

IsAppliedToAllConfigurations Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsAppliedToAllConfigurations() As Boolean
```

SOLIDWORKS Type Library

IsDesignTableDimension Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsDesignTableDimension() As Boolean
```

SOLIDWORKS Type Library

ISetReferencePoints Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetReferencePoints( _  
    ByVal PointsCount As Long, _  
    ByVal RefPoints As MathPoint _  
)
```

SOLIDWORKS Type Library

ISetSystemValue3 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetSystemValue3( _  
    ByVal NewValue As Double, _
```

```
ByVal WhichConfigurations As Long, _  
ByVal Config_count As Long, _  
ByRef Config_names As String _  
) As Long
```

SOLIDWORKS Type Library

ISetUserValueIn Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetUserValueIn( _  
    ByVal Doc As ModelDoc, _  
    ByVal NewValue As Double _  
)
```

SOLIDWORKS Type Library

ISetUserValueIn2 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetUserValueIn2( _  
    ByVal Doc As ModelDoc, _  
    ByVal NewValue As Double, _  
    ByVal WhichConfigurations As Long _  
) As Long
```

SOLIDWORKS Type Library

ISetUserValueIn3 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetUserValueIn3( _  
    ByVal Doc As ModelDoc2, _  
    ByVal NewValue As Double, _  
    ByVal WhichConfigurations As Long _  
) As Long
```

SOLIDWORKS Type Library

ISetValue3 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetValue3( _  
    ByVal NewValue As Double, _  
    ByVal WhichConfigurations As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
) As Long
```

SOLIDWORKS Type Library

IsReference Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsReference() As Boolean
```

SOLIDWORKS Type Library

Name Property (Dimension)

Syntax

Visual Basic for Applications (VBA)

Public Property Name As String

SOLIDWORKS Type Library

ReadOnly Property (Dimension)



Visual Basic for Applications (VBA)

Public Property ReadOnly As Boolean

SOLIDWORKS Type Library

ReferencePoints Property (Dimension)



Visual Basic for Applications (VBA)

Public Property ReferencePoints As Variant

SOLIDWORKS Type Library

SetArcEndCondition Method (Dimension)



Visual Basic for Applications (VBA)

```
Public Function SetArcEndCondition( _  
    ByVal Index As Long, _  
    ByVal Condition As Long _  
) As Long
```

SOLIDWORKS Type Library

SetSystemValue2 Method (Dimension)



Visual Basic for Applications (VBA)

```
Public Function SetSystemValue2( _  
    ByVal NewValue As Double, _  
    ByVal WhichConfigurations As Long _  
) As Long
```

SOLIDWORKS Type Library

SetSystemValue3 Method (Dimension)



Visual Basic for Applications (VBA)

```
Public Function SetSystemValue3( _  
    ByVal NewValue As Double, _  
    ByVal WhichConfigurations As Long, _  
    ByVal Config_names As Variant _  
) As Long
```

SOLIDWORKS Type Library

SetToleranceFitValues Method (Dimension)



Visual Basic for Applications (VBA)

```
Public Function SetToleranceFitValues( _  
    ByVal NewLValue As String, _  
    ByVal NewUValue As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetToleranceFontInfo Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetToleranceFontInfo( _  
    ByVal UseFontScale As Long, _  
    ByVal TolScale As Double, _  
    ByVal TolHeight As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetToleranceType Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetToleranceType( _  
    ByVal NewType As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetToleranceValues Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetToleranceValues( _  
    ByVal TolMin As Double, _  
    ByVal TolMax As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetUserValueIn Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetUserValueIn( _  
    ByVal Doc As Object, _  
    ByVal NewValue As Double _  
    )
```

SOLIDWORKS Type Library

SetUserValueIn2 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetUserValueIn2( _  
    ByVal Doc As Object, _  
    ByVal NewValue As Double, _  
    ByVal WhichConfigurations As Long _  
    ) As Long
```

SOLIDWORKS Type Library

SetValue2 Method (Dimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetValue2( _  
    ByVal NewValue As Double, _  
    ByVal WhichConfigurations As Long _  
    ) As Long
```

SetValue3 Method (Dimension)

Visual Basic for Applications (VBA)

```
Public Function SetValue3( _  
    ByVal NewValue As Double, _  
    ByVal WhichConfigurations As Long, _  
    ByVal Config_names As Variant _  
    ) As Long
```

SystemValue Property (Dimension)

Visual Basic for Applications (VBA)

```
Public Property SystemValue As Double
```

Tolerance Property (Dimension)

Visual Basic for Applications (VBA)

```
Public Property Tolerance As DimensionTolerance
```

Value Property (Dimension)


Visual Basic for Applications (VBA)

```
Public Property Value As Double
```

DimensionSensorData (Type)

SOLIDWORKS Type Library
DimensionSensorData Object

Object Model



SOLIDWORKS Type Library
DimensionSensorData Object Members

Public Methods

 [GetDisplayDimension](#)

Public Properties

 [SensorValue](#)

SOLIDWORKS Type Library
GetDisplayDimension Method (DimensionSensorData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDisplayDimension() As DisplayDimension
```

SOLIDWORKS Type Library
SensorValue Property (DimensionSensorData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SensorValue As Double
```