


SOLIDWORKS API (VB6 COM) — Reference (19/102): DisplayDimension- DistanceMateFeatureData

SOLIDWORKS API Documentation (converted from CHM)

DisplayDimension (Type)

SOLIDWORKS Type Library
DisplayDimension Object

Object Model



SOLIDWORKS Type Library
DisplayDimension Object Members

Public Methods

	AddDisplayEnt
	AddDisplayText
	AlignToEdge
	AutoJogOrdinate
	ExplementaryAngle
	GetAlternatePrecision
	GetAlternatePrecision2
	GetAlternateTolPrecision
	GetAlternateTolPrecision2
	GetAnnotation
	GetArcLengthLeader
	GetArrowHeadStyle
	GetArrowHeadStyle2
	GetAutoArcLengthLeader
	GetBentLeaderLength
	GetBrokenLeader2
	GetChamferUnits

	<u>GetDefinitionTransform</u>
	<u>GetDimension</u>
	<u>GetDimension2</u>
	<u>GetDisplayData</u>
	<u>GetExtensionLineAsCenterline</u>
	<u>GetFractionBase</u>
	<u>GetFractionValue</u>
	<u>GetHoleCalloutVariables</u>
	<u>GetJogParameters</u>
	<u>GetLinkedText</u>
	<u>GetLowerText</u>
	<u>GetNameForSelection</u>
	<u>GetNext</u>
	<u>GetNext2</u>
	<u>GetNext3</u>
	<u>GetNext4</u>
	<u>GetNext5</u>
	<u>GetOrdinateDimensionArrowSize</u>
	<u>GetOverride</u>
	<u>GetOverrideValue</u>
	<u>GetPrimaryPrecision</u>
	<u>GetPrimaryPrecision2</u>
	<u>GetPrimaryTolPrecision</u>
	<u>GetPrimaryTolPrecision2</u>
	<u>GetRoundToFraction</u>
	<u>GetSecondArrow</u>
	<u>GetSupportsGenericText</u>
	<u>GetText</u>
	<u>GetTextFormat</u>
	<u>GetTextFormatItems</u>
	<u>GetType</u>
	<u>GetUnits</u>
	<u>GetUseDocArrowHeadStyle</u>
	<u>GetUseDocBentLeaderLength</u>
	<u>GetUseDocBrokenLeader</u>
	<u>GetUseDocDual</u>
	<u>GetUseDocPrecision</u>
	<u>GetUseDocSecondArrow</u>
	<u>GetUseDocTextFormat</u>
	<u>GetUseDocUnits</u>
	<u>GetWitnessLineGap</u>
	<u>IAddDisplayEnt</u>
	<u>IAddDisplayText</u>

	<u>IGetAnnotation</u>
	<u>IGetDimension</u>
	<u>IGetDisplayData</u>
	<u>IGetNext</u>
	<u>IGetNext2</u>
	<u>IGetNext3</u>
	<u>IGetTextFormat</u>
	<u>IsDimXpert</u>
	<u>ISetTextFormat</u>
	<u>IsHoleCallout</u>
	<u>IsReferenceDim</u>
	<u>ResetExtensionLineStyle</u>
	<u>SetArcLengthLeader</u>
	<u>SetArrowHeadStyle</u>
	<u>SetArrowHeadStyle2</u>
	<u>SetBentLeaderLength</u>
	<u>SetBrokenLeader2</u>
	<u>SetDual</u>
	<u>SetDual2</u>
	<u>SetExtensionLineAsCenterline</u>
	<u>SetHorizontal</u>
	<u>SetLogParameters</u>
	<u>SetLineFontDimensionStyle</u>
	<u>SetLineFontDimensionThickness</u>
	<u>SetLineFontExtensionStyle</u>
	<u>SetLineFontExtensionThickness</u>
	<u>SetLinkedText</u>
	<u>SetLowerText</u>
	<u>SetOrdinateDimensionArrowSize</u>
	<u>SetOverride</u>
	<u>SetPrecision</u>
	<u>SetPrecision2</u>
	<u>SetPrecision3</u>
	<u>SetSecondArrow</u>
	<u>SetText</u>
	<u>SetTextFormat</u>
	<u>SetUnits</u>
	<u>SetUnits2</u>
	<u>SetVertical</u>
	<u>SetWitnessLineGap</u>
	<u>SupplementaryAngle</u>
	<u>Unlink</u>
	<u>VerticallyOppositeAngle</u>

Public Properties

 ArcExtensionLineOrOppositeSide
 ArrowSide
 BrokenLeader
 CenterText
 ChamferPrecision
 ChamferTextStyle
 Diametric
 DimensionToInside
 DisplayAsChain
 DisplayAsLinear
 Elevation
 EndSymbol
 ExtensionLineExtendsFromCenterOfSet
 ExtensionLineSameAsLeaderStyle
 ExtensionLineUseDocumentDisplay
 Foreshortened
 GridBubble
 HorizontalJustification
 Inspection
 IsLinked
 Jogged
 LeaderVisibility
 LowerInspection
 MarkedForDrawing
 MaxWitnessLineLength
 OffsetText
 RunBidirectionally
 Scale2
 ShortenedRadius
 ShowDimensionValue
 ShowLowerParenthesis
 ShowParenthesis
 ShowTolParenthesis
 SmartWitness
 SolidLeader
 Split
 Type2
 VerticalJustification
 WitnessVisibility

SOLIDWORKS Type Library

AddDisplayEnt Method (DisplayDimension)

Visual Basic for Applications (VBA)

```
Public Function AddDisplayEnt( _  
    ByVal Type As Integer, _  
    ByVal Data As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddDisplayText Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function AddDisplayText( _  
    ByVal Text As String, _  
    ByVal Position As Variant, _  
    ByVal Format As Object, _  
    ByVal Attachment As Integer, _  
    ByVal WidthFactor As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

AlignToEdge Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function AlignToEdge( _  
    ByVal AlignmentEdge As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

ArcExtensionLineOrOppositeSide Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property ArcExtensionLineOrOppositeSide As Boolean
```

SOLIDWORKS Type Library

ArrowSide Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property ArrowSide As Long
```

SOLIDWORKS Type Library

AutoJogOrdinate Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function AutoJogOrdinate() As Boolean
```

SOLIDWORKS Type Library

BrokenLeader Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property BrokenLeader As Boolean
```

SOLIDWORKS Type Library

CenterText Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property CenterText As Boolean
```

SOLIDWORKS Type Library

ChamferPrecision Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ChamferPrecision( _  
    ByVal Index As Long _  
) As Long
```

SOLIDWORKS Type Library

ChamferTextStyle Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ChamferTextStyle As Long
```

SOLIDWORKS Type Library

Diametric Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Diametric As Boolean
```

SOLIDWORKS Type Library

DimensionToInside Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property DimensionToInside As Boolean
```

SOLIDWORKS Type Library

DisplayAsChain Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property DisplayAsChain As Boolean
```

SOLIDWORKS Type Library

DisplayAsLinear Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property DisplayAsLinear As Boolean
```

SOLIDWORKS Type Library

Elevation Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Elevation As Boolean
```

SOLIDWORKS Type Library

SOLIDWORKS Type Library

EndSymbol Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property EndSymbol As Long
```

SOLIDWORKS Type Library

ExplementaryAngle Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ExplementaryAngle() As Boolean
```

SOLIDWORKS Type Library

ExtensionLineExtendsFromCenterOfSet Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ExtensionLineExtendsFromCenterOfSet As Boolean
```

SOLIDWORKS Type Library

ExtensionLineSameAsLeaderStyle Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ExtensionLineSameAsLeaderStyle As Boolean
```

SOLIDWORKS Type Library

ExtensionLineUseDocumentDisplay Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ExtensionLineUseDocumentDisplay As Boolean
```

SOLIDWORKS Type Library

Foreshortened Property (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Foreshortened As Boolean
```

SOLIDWORKS Type Library

GetAlternatePrecision Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAlternatePrecision() As Long
```

SOLIDWORKS Type Library

GetAlternatePrecision2 Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAlternatePrecision2() As Long
```

SOLIDWORKS Type Library

GetAlternateTolPrecision Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAlternateTolPrecision() As Long
```

SOLIDWORKS Type Library

GetAlternateTolPrecision2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAlternateTolPrecision2() As Long
```

SOLIDWORKS Type Library

GetAnnotation Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotation() As Object
```

SOLIDWORKS Type Library

GetArcLengthLeader Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetArcLengthLeader() As Long
```

SOLIDWORKS Type Library

GetArrowHeadStyle Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetArrowHeadStyle() As Long
```

SOLIDWORKS Type Library

GetArrowHeadStyle2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetArrowHeadStyle2( _  
    ByRef Style1 As Long, _  
    ByRef Style2 As Long _  
) As Boolean
```

SOLIDWORKS Type Library

GetAutoArcLengthLeader Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAutoArcLengthLeader() As Boolean
```

SOLIDWORKS Type Library

GetBentLeaderLength Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBentLeaderLength() As Double
```

SOLIDWORKS Type Library

GetBrokenLeader2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBrokenLeader2() As Long
```

SOLIDWORKS Type Library

GetChamferUnits Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetChamferUnits( _  
    ByRef LengthUnit As Long, _  
    ByRef AngularUnit As Long _  
) As Boolean
```

SOLIDWORKS Type Library

GetDefinitionTransform Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDefinitionTransform() As MathTransform
```

SOLIDWORKS Type Library

GetDimension Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDimension() As Object
```

SOLIDWORKS Type Library

GetDimension2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDimension2( _  
    ByVal Index As Long _  
) As Dimension
```

SOLIDWORKS Type Library

GetDisplayData Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDisplayData() As Object
```

SOLIDWORKS Type Library

GetExtensionLineAsCenterline Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetExtensionLineAsCenterline( _  
    ByVal ExtIndex As Integer, _
```

```
ByRef Centerline As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

GetFractionBase Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFractionBase() As Long
```

SOLIDWORKS Type Library

GetFractionValue Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFractionValue() As Long
```

SOLIDWORKS Type Library

GetHoleCalloutVariables Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetHoleCalloutVariables() As Variant
```

SOLIDWORKS Type Library

GetJogParameters Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetJogParameters( _  
    ByVal WitnessIndex As Integer, _  
    ByRef Jogged As Boolean, _  
    ByRef Offset1 As Double, _  
    ByRef Offset2 As Double, _  
    ByRef Offset1to2 As Double _  
) As Boolean
```

SOLIDWORKS Type Library

GetLinkedText Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLinkedText() As String
```

SOLIDWORKS Type Library

GetLowerText Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLowerText() As String
```

SOLIDWORKS Type Library

GetNameForSelection Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNameForSelection() As String
```

SOLIDWORKS Type Library

GetNext Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext() As Object
```

SOLIDWORKS Type Library

GetNext2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext2() As Object
```

SOLIDWORKS Type Library

GetNext3 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext3() As Object
```

SOLIDWORKS Type Library

GetNext4 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext4() As DisplayDimension
```

SOLIDWORKS Type Library

GetNext5 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext5() As DisplayDimension
```

SOLIDWORKS Type Library

GetOrdinateDimensionArrowSize Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetOrdinateDimensionArrowSize( _  
    ByRef UseDoc As Boolean, _  
    ByRef ArrowSize As Double _  
)
```

SOLIDWORKS Type Library

GetOverride Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOverride() As Boolean
```

SOLIDWORKS Type Library

GetOverrideValue Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOverrideValue() As Double
```

SOLIDWORKS Type Library

GetPrimaryPrecision Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetPrimaryPrecision() As Long
```

SOLIDWORKS Type Library

GetPrimaryPrecision2 Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetPrimaryPrecision2() As Long
```

SOLIDWORKS Type Library

GetPrimaryTolPrecision Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetPrimaryTolPrecision() As Long
```

SOLIDWORKS Type Library

GetPrimaryTolPrecision2 Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetPrimaryTolPrecision2() As Long
```

SOLIDWORKS Type Library

GetRoundToFraction Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetRoundToFraction() As Boolean
```

SOLIDWORKS Type Library

GetSecondArrow Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetSecondArrow() As Boolean
```

SOLIDWORKS Type Library

GetSupportsGenericText Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetSupportsGenericText() As Boolean
```

SOLIDWORKS Type Library

GetText Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetText( _  
    ByVal WhichText As Long _  
) As String
```

SOLIDWORKS Type Library

GetTextFormat Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTextFormat() As Object
```

SOLIDWORKS Type Library

GetTextFormatItems Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTextFormatItems( _  
    ByVal WhichText As Long, _  
    ByRef TokensDefinition As Variant, _  
    ByRef TokensEvaluated As Variant _  
) As Long
```

SOLIDWORKS Type Library

GetType Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetType() As Long
```

SOLIDWORKS Type Library

GetUnits Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUnits() As Long
```

SOLIDWORKS Type Library

GetUseDocArrowHeadStyle Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUseDocArrowHeadStyle() As Boolean
```

SOLIDWORKS Type Library

GetUseDocBentLeaderLength Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUseDocBentLeaderLength() As Boolean
```

SOLIDWORKS Type Library

GetUseDocBrokenLeader Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUseDocBrokenLeader() As Boolean
```

SOLIDWORKS Type Library

GetUseDocDual Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetUseDocDual() As Boolean
```

SOLIDWORKS Type Library

GetUseDocPrecision Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetUseDocPrecision() As Boolean
```

SOLIDWORKS Type Library

GetUseDocSecondArrow Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetUseDocSecondArrow() As Boolean
```

SOLIDWORKS Type Library

GetUseDocTextFormat Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetUseDocTextFormat() As Boolean
```

SOLIDWORKS Type Library

GetUseDocUnits Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetUseDocUnits() As Boolean
```

SOLIDWORKS Type Library

GetWitnessLineGap Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function GetWitnessLineGap( _  
    ByVal WitnessIndex As Integer, _  
    ByRef UseDoc As Boolean, _  
    ByRef Gap As Double _  
) As Boolean
```

SOLIDWORKS Type Library

GridBubble Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property GridBubble As Boolean
```

SOLIDWORKS Type Library

HorizontalJustification Property (DisplayDimension)



Visual Basic for Applications (VBA)

Public Property HorizontalJustification As Long

SOLIDWORKS Type Library

IAddDisplayEnt Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddDisplayEnt( _  
    ByVal Type As Integer, _  
    ByRef Data As Double _  
) As Boolean
```

SOLIDWORKS Type Library

IAddDisplayText Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAddDisplayText( _  
    ByVal Text As String, _  
    ByRef Position As Double, _  
    ByVal Format As TextFormat, _  
    ByVal Attachment As Integer, _  
    ByVal WidthFactor As Double _  
) As Boolean
```

SOLIDWORKS Type Library

IGetAnnotation Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAnnotation() As Annotation
```

SOLIDWORKS Type Library

IGetDimension Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetDimension() As Dimension
```

SOLIDWORKS Type Library

IGetDisplayData Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetDisplayData() As DisplayData
```

SOLIDWORKS Type Library

IGetNext Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNext() As DisplayDimension
```

SOLIDWORKS Type Library

IGetNext2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNext2() As DisplayDimension
```

SOLIDWORKS Type Library

IGetNext3 Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function IGetNext3() As DisplayDimension
```

SOLIDWORKS Type Library

IGetTextFormat Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function IGetTextFormat() As TextFormat
```

SOLIDWORKS Type Library

Inspection Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property Inspection As Boolean
```

SOLIDWORKS Type Library

IsDimXpert Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function IsDimXpert() As Boolean
```

SOLIDWORKS Type Library

ISetTextFormat Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function ISetTextFormat( _  
    ByVal TextFormatType As Long, _  
    ByVal TextFormat As TextFormat _  
    ) As Boolean
```

SOLIDWORKS Type Library

IsHoleCallout Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function IsHoleCallout() As Boolean
```

SOLIDWORKS Type Library

IsLinked Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property IsLinked As Boolean
```

SOLIDWORKS Type Library

IsReferenceDim Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function IsReferenceDim() As Boolean
```

SOLIDWORKS Type Library

Jogged Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property Jogged As Boolean
```

SOLIDWORKS Type Library

LeaderVisibility Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property LeaderVisibility As Long
```

SOLIDWORKS Type Library

LowerInspection Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property LowerInspection As Boolean
```

SOLIDWORKS Type Library

MarkedForDrawing Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property MarkedForDrawing As Boolean
```

SOLIDWORKS Type Library

MaxWitnessLineLength Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property MaxWitnessLineLength As Double
```

SOLIDWORKS Type Library

OffsetText Property (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Property OffsetText As Boolean
```

SOLIDWORKS Type Library

ResetExtensionLineStyle Method (DisplayDimension)



Visual Basic for Applications (VBA)

```
Public Function ResetExtensionLineStyle( _  
    ByVal ExtIndex As Integer _  
) As Boolean
```

SOLIDWORKS Type Library

RunBidirectionally Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property RunBidirectionally As Boolean
```

SOLIDWORKS Type Library

Scale2 Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Scale2 As Double
```

SOLIDWORKS Type Library

SetArcLengthLeader Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetArcLengthLeader( _  
    ByVal AutoLeader As Boolean, _  
    ByVal LeaderType As Long _  
    ) As Long
```

SOLIDWORKS Type Library

SetArrowHeadStyle Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetArrowHeadStyle( _  
    ByVal UseDoc As Boolean, _  
    ByVal ArrowHeadStyle As Long _  
    )
```

SOLIDWORKS Type Library

SetArrowHeadStyle2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetArrowHeadStyle2( _  
    ByVal UseDoc As Boolean, _  
    ByVal Style1 As Long, _  
    ByVal Style2 As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetBentLeaderLength Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetBentLeaderLength( _  
    ByVal UseDoc As Boolean, _  
    ByVal Length As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetBrokenLeader2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetBrokenLeader2( _  
    ByVal UseDoc As Boolean, _  
    ByVal Broken As Long _  
) As Long
```

SOLIDWORKS Type Library

SetDual Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetDual( _  
    ByVal UseDoc As Boolean _  
)
```

SOLIDWORKS Type Library

SetDual2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetDual2( _  
    ByVal UseDoc As Boolean, _  
    ByVal InwardRounding As Boolean _  
)
```

SOLIDWORKS Type Library

SetExtensionLineAsCenterline Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetExtensionLineAsCenterline( _  
    ByVal ExtIndex As Integer, _  
    ByVal Centerline As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

SetHorizontal Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetHorizontal() As Boolean
```

SOLIDWORKS Type Library

SetJogParameters Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetJogParameters( _  
    ByVal WitnessIndex As Integer, _  
    ByVal Jogged As Boolean, _  
    ByVal Offset1 As Double, _  
    ByVal Offset2 As Double, _  
    ByVal Offset1to2 As Double _  
) As Boolean
```

SOLIDWORKS Type Library

SetLineFontDimensionStyle Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetLineFontDimensionStyle( _  
    ByVal UseDoc As Boolean, _  
    ByVal Style As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetLineFontDimensionThickness Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetLineFontDimensionThickness( _  
    ByVal UseDoc As Boolean, _  
    ByVal Style As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetLineFontExtensionStyle Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetLineFontExtensionStyle( _  
    ByVal UseDoc As Boolean, _  
    ByVal Style As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetLineFontExtensionThickness Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetLineFontExtensionThickness( _  
    ByVal UseDoc As Boolean, _  
    ByVal Style As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetLinkedText Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetLinkedText( _  
    ByVal BstrLinkedText As String _  
) As Long
```

SOLIDWORKS Type Library

SetLowerText Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetLowerText( _  
    ByVal Text As String _  
)
```

SOLIDWORKS Type Library

SetOrdinateDimensionArrowSize Method (DisplayDimension)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetOrdinateDimensionArrowSize( _  
    ByVal UseDoc As Boolean, _  
    ByVal ArrowSize As Double _  
)
```

SOLIDWORKS Type Library

SetOverride Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetOverride( _  
    ByVal Override As Boolean, _  
    ByVal Value As Double _  
) As Boolean
```

SOLIDWORKS Type Library

SetPrecision Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetPrecision( _  
    ByVal UseDoc As Boolean, _  
    ByVal Primary As Long, _  
    ByVal Alternate As Long, _  
    ByVal PrimaryTol As Long, _  
    ByVal AlternateTol As Long _  
) As Long
```

SOLIDWORKS Type Library

SetPrecision2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetPrecision2( _  
    ByVal Primary As Long, _  
    ByVal Dual As Long, _  
    ByVal PrimaryTol As Long, _  
    ByVal DualTol As Long _  
) As Long
```

SOLIDWORKS Type Library

SetPrecision3 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetPrecision3( _  
    ByVal Primary As Long, _  
    ByVal Dual As Long, _  
    ByVal PrimaryTol As Long, _  
    ByVal DualTol As Long _  
) As Long
```

SOLIDWORKS Type Library

SetSecondArrow Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetSecondArrow( _  
    ByVal UseDoc As Boolean, _  
    ByVal SecondArrow As Boolean _  
)
```

SOLIDWORKS Type Library

SetText Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetText( _  
    ByVal WhichText As Long, _  
    ByVal Text As String _  
)
```

SOLIDWORKS Type Library

SetTextFormat Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTextFormat( _  
    ByVal TextFormatType As Long, _  
    ByVal TextFormat As Object _  
) As Boolean
```

SOLIDWORKS Type Library

SetUnits Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetUnits( _  
    ByVal UseDoc As Boolean, _  
    ByVal UType As Long, _  
    ByVal FractBase As Long, _  
    ByVal FractDenom As Long, _  
    ByVal RoundToFraction As Boolean _  
) As Long
```

SOLIDWORKS Type Library

SetUnits2 Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetUnits2( _  
    ByVal UseDoc As Boolean, _  
    ByVal UType As Long, _  
    ByVal FractBase As Long, _  
    ByVal FractDenom As Long, _  
    ByVal RoundToFraction As Boolean, _  
    ByVal DecimalRounding As Long _  
) As Long
```

SOLIDWORKS Type Library

SetVertical Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetVertical() As Boolean
```

SOLIDWORKS Type Library

SetWitnessLineGap Method (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetWitnessLineGap( _  
    ByVal WitnessIndex As Integer, _  
    ByVal UseDoc As Boolean, _  
    ByVal Gap As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

ShortenedRadius Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShortenedRadius As Boolean
```

SOLIDWORKS Type Library

ShowDimensionValue Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowDimensionValue As Boolean
```

SOLIDWORKS Type Library

ShowLowerParenthesis Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowLowerParenthesis As Boolean
```

SOLIDWORKS Type Library

ShowParenthesis Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowParenthesis As Boolean
```

SOLIDWORKS Type Library

ShowTolParenthesis Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowTolParenthesis As Boolean
```

SOLIDWORKS Type Library

SmartWitness Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SmartWitness As Boolean
```

SOLIDWORKS Type Library

SolidLeader Property (DisplayDimension)

Syntax

Visual Basic for Applications (VBA)

Public Property SolidLeader As Boolean

SOLIDWORKS Type Library

Split Property (DisplayDimension)



Visual Basic for Applications (VBA)

Public Property Split As Boolean

SOLIDWORKS Type Library

SupplementaryAngle Method (DisplayDimension)



Visual Basic for Applications (VBA)

Public Function SupplementaryAngle() As Boolean

SOLIDWORKS Type Library

Type2 Property (DisplayDimension)



Visual Basic for Applications (VBA)

Public Property Type2 As Long

SOLIDWORKS Type Library

Unlink Method (DisplayDimension)



Visual Basic for Applications (VBA)

Public Function Unlink() As Long

SOLIDWORKS Type Library

VerticalJustification Property (DisplayDimension)



Visual Basic for Applications (VBA)

Public Property VerticalJustification As Long

SOLIDWORKS Type Library

VerticallyOppositeAngle Method (DisplayDimension)



Visual Basic for Applications (VBA)

Public Function VerticallyOppositeAngle() As Boolean

SOLIDWORKS Type Library

WitnessVisibility Property (DisplayDimension)



Visual Basic for Applications (VBA)

Public Property WitnessVisibility As Long

DisplayStateSetting (Type)

SOLIDWORKS Type Library

DisplayStateSetting Object

Object Model

DisplayStateSetting

SOLIDWORKS Type Library

DisplayStateSetting Object Members

Public Methods

GetEntityCount

GetNameCount

IGetEntities

IGetNames

ISetEntities

ISetNames

Public Properties

Entities

Names

Option

PartLevel

RemoveAppearance

SOLIDWORKS Type Library

Entities Property (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

Public Property Entities As Variant

SOLIDWORKS Type Library

GetEntityCount Method (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

Public Function GetEntityCount() As Long

SOLIDWORKS Type Library

GetNameCount Method (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

Public Function GetNameCount() As Long

SOLIDWORKS Type Library

IGetEntities Method (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEntities( _  
    ByVal EntityCount As Long _  
    ) As Object
```

SOLIDWORKS Type Library

IGetNames Method (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNames( _  
    ByVal DsNameCount As Long _  
    ) As String
```

SOLIDWORKS Type Library

ISetEntities Method (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetEntities( _  
    ByVal EntityCount As Long, _  
    ByRef Entities As Object _  
    )
```

SOLIDWORKS Type Library

ISetNames Method (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetNames( _  
    ByVal DsNameCount As Long, _  
    ByRef DSNames As String _  
    )
```

SOLIDWORKS Type Library

Names Property (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Names As Variant
```

SOLIDWORKS Type Library

Option Property (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Option As Long
```

SOLIDWORKS Type Library

PartLevel Property (DisplayStateSetting)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PartLevel As Boolean
```

SOLIDWORKS Type Library

RemoveAppearance Property (DisplayStateSetting)

Syntax

Public Property RemoveAppearance As Boolean

DistanceMateFeatureData (Type)

SOLIDWORKS Type Library

DistanceMateFeatureData Object

Object Model

DistanceMateFeatureData

SOLIDWORKS Type Library

DistanceMateFeatureData Object Members

Public Properties

-  [Distance](#)
-  [EntitiesToMate](#)
-  [FlipDimension](#)
-  [IsAdvancedMate](#)
-  [MateAlignment](#)
-  [MaximumDistance](#)
-  [MinimumDistance](#)

SOLIDWORKS Type Library

Distance Property (DistanceMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Distance As Double

SOLIDWORKS Type Library

EntitiesToMate Property (DistanceMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property EntitiesToMate As Variant

SOLIDWORKS Type Library

FlipDimension Property (DistanceMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property FlipDimension As Boolean

SOLIDWORKS Type Library

IsAdvancedMate Property (DistanceMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property IsAdvancedMate As Boolean

SOLIDWORKS Type Library

MateAlignment Property (DistanceMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MateAlignment As Long

SOLIDWORKS Type Library
MaximumDistance Property (DistanceMateFeatureData)



Visual Basic for Applications (VBA)

Public Property MaximumDistance As Double

SOLIDWORKS Type Library
MinimumDistance Property (DistanceMateFeatureData)



Visual Basic for Applications (VBA)

Public Property MinimumDistance As Double