

SOLIDWORKS API (VB6 COM) — Reference (22/102): DrawingDoc (part 1 of 3)

SOLIDWORKS API Documentation (converted from CHM)

DrawingDoc (part 1 of 3) (Type)

SOLIDWORKS Type Library

DrawingDoc Object

 Object Model

DrawingDoc

- CreateAutoBalloonOptions (AutoBalloonOptions)
- CreateDrawViewFromModeView2 (View)
- CreateDrawViewFromModeView3 (View)
- CreateFlatPatternViewFromModeView3 (View)
- CreateRelativeView (View)
- CreateSectionViewAt3 (View)
- CreateSectionViewAt4 (View)
- CreateSectionViewAt5 (View)
- CreateUnfoldedViewAt3 (View)
- CreateViewport3 (View)
- DropDrawingViewFromPalette (View)
- DropDrawingViewFromPalette2 (View)
- GetBlockDefinition (BlockDefinition)
- IActiveDrawingView (View)
- IAddChamferDim (DisplayDimension)
- IAddHoleCallout2 (DisplayDimension)
- ICreateAngDim3 (DisplayDimension)
- ICreateAngDim4 (DisplayDimension)
- ICreateAuxiliaryViewAt2 (View)
- ICreateBlockDefinition (BlockDefinition)
- ICreateCompoundNote (Note)
- ICreateCustomSymbol (CustomSymbol)
- ICreateDetailViewAt3 (View)
- ICreateDiamDim3 (DisplayDimension)
- ICreateDiamDim4 (DisplayDimension)
- ICreateLinearDim3 (DisplayDimension)
- ICreateLinearDim4 (DisplayDimension)
- ICreateOrdinateDim3 (DisplayDimension)
- ICreateOrdinateDim4 (DisplayDimension)
- ICreateSectionViewAt2 (View)

- ICreateSectionViewAt3 (View)
- ICreateSectionViewAt4 (View)
- ICreateSectionViewAt5 (View)
- ICreateText2 (Note)
- IEditSelectedGtol (Gtol)
- IFeatureByName (Feature)
- IGetBlockDefinitions (BlockDefinition)
- IGetCurrentSheet (Sheet)
- IGetFirstView (View)
- IInsertCustomSymbol2 (CustomSymbol)
- IInsertDowelSymbol (DowelSymbol)
- IInsertMultiJogLeader2 (MultiJogLeader)
- IInsertMultiJogLeader3 (MultiJogLeader)
- IInsertRevisionCloud (RevisionCloud)
- IMakeCustomSymbol2 (CustomSymbol)
- INewGtol (Gtol)
- InsertBlock (BlockInstance)
- InsertCenterLine2 (CenterLine)
- InsertCenterMark (CenterMark)
- InsertCenterMark2 (CenterMark)
- InsertCenterMark3 (CenterMark)
- InsertRevisionSymbol (Note)
- InsertTableAnnotation (TableAnnotation)
- InsertTableAnnotation2 (TableAnnotation)
- MakeBlockDefinition (BlockDefinition)
- Sheet

SOLIDWORKS Type Library

DrawingDoc Object Members

Public Methods

 [ActivateSheet](#)

 [ActivateView](#)

 [AddCenterMark](#)

	<u>AddChamferDim</u>
	<u>AddHoleCallout</u>
	<u>AddHoleCallout2</u>
	<u>AddLineStyle</u>
	<u>AddOrdinateDimension</u>
	<u>AddOrdinateDimension2</u>
	<u>AlignHorz</u>
	<u>AlignOrdinate</u>
	<u>AlignVert</u>
	<u>AttachAnnotation</u>
	<u>AttachDimensions</u>
	<u>AutoBalloon</u>
	<u>AutoBalloon2</u>
	<u>AutoBalloon3</u>
	<u>AutoBalloon4</u>
	<u>AutoBalloon5</u>
	<u>AutoDimension</u>
	<u>BreakLineSplineCut</u>
	<u>BreakLineStraightCut</u>
	<u>BreakLineZigZagCut</u>
	<u>BreakView</u>
	<u>CenterMark</u>
	<u>ChangeComponentLayer</u>
	<u>ChangeOrdDir</u>
	<u>ChangeRefConfigurationOfFlatPatternView</u>
	<u>Create1stAngleViews</u>
	<u>Create1stAngleViews2</u>
	<u>Create3rdAngleViews</u>
	<u>Create3rdAngleViews2</u>
	<u>CreateAngDim</u>
	<u>CreateAngDim2</u>
	<u>CreateAngDim3</u>
	<u>CreateAngDim4</u>
	<u>CreateAutoBalloonOptions</u>
	<u>CreateAuxiliaryView</u>
	<u>CreateAuxiliaryViewAt</u>
	<u>CreateAuxiliaryViewAt2</u>
	<u>CreateBlockDefinition</u>
	<u>CreateBreakOutSection</u>
	<u>CreateCompoundNote</u>
	<u>CreateConstructionGeometry</u>
	<u>CreateCustomSymbol</u>
	<u>CreateDetailView</u>

	<u>CreateDetailViewAt</u>
	<u>CreateDetailViewAt2</u>
	<u>CreateDetailViewAt3</u>
	<u>CreateDetailViewAt4</u>
	<u>CreateDiamDim</u>
	<u>CreateDiamDim2</u>
	<u>CreateDiamDim3</u>
	<u>CreateDiamDim4</u>
	<u>CreateDrawViewFromModelView</u>
	<u>CreateDrawViewFromModelView2</u>
	<u>CreateDrawViewFromModelView3</u>
	<u>CreateFlatPatternViewFromModelView</u>
	<u>CreateFlatPatternViewFromModelView2</u>
	<u>CreateFlatPatternViewFromModelView3</u>
	<u>CreateLayer</u>
	<u>CreateLayer2</u>
	<u>CreateLinearDim</u>
	<u>CreateLinearDim2</u>
	<u>CreateLinearDim3</u>
	<u>CreateLinearDim4</u>
	<u>CreateOrdinateDim</u>
	<u>CreateOrdinateDim2</u>
	<u>CreateOrdinateDim3</u>
	<u>CreateOrdinateDim4</u>
	<u>CreateRelativeView</u>
	<u>CreateSectionView</u>
	<u>CreateSectionViewAt</u>
	<u>CreateSectionViewAt2</u>
	<u>CreateSectionViewAt3</u>
	<u>CreateSectionViewAt4</u>
	<u>CreateSectionViewAt5</u>
	<u>CreateText</u>
	<u>CreateText2</u>
	<u>CreateUnfoldedViewAt</u>
	<u>CreateUnfoldedViewAt2</u>
	<u>CreateUnfoldedViewAt3</u>
	<u>CreateViewport</u>
	<u>CreateViewport2</u>
	<u>CreateViewport3</u>
	<u>DeleteAllCosmeticThreads</u>
	<u>DeleteLineStyle</u>
	<u>Dimensions</u>
	<u>DragModelDimension</u>

 DrawingViewRotate
 DropDrawingViewFromPalette
 DropDrawingViewFromPalette2
 EditCenterMarkProperties
 EditOrdinate
 EditRebuild
 EditSelectedGtol
 EditSheet
 EditSheet2
 EditSketch
 EditTemplate
 EndDrawing
 ExplodeBlockInstance
 ExplodeCustomSymbol
 FeatureByName
 FlipSectionLine
 ForceRebuild
 GenerateViewPaletteViews
 GetBlockDefinition
 GetBlockDefinitionCount
 GetBlockDefinitions
 GetCurrentSheet
 GetDrawingPaletteViewNames
 GetEditBlock
 GetEditSheet
 GetFirstView
 GetInsertionPoint
 GetLineFontCount
 GetLineFontCount2
 GetLineFontId
 GetLineFontInfo
 GetLineFontInfo2
 GetLineFontName
 GetLineFontName2
 GetLineStyle
 GetPenCount
 GetPenInfo
 GetSheetCount
 GetSheetNames
 GetViewCount
 GetViews
 HideEdge
 HideShowDimensions

	<u>HideShowDrawingViews</u>
	<u>IAddChamferDim</u>
	<u>IAddHoleCallout2</u>
	<u>ICreateAngDim</u>
	<u>ICreateAngDim2</u>
	<u>ICreateAngDim3</u>
	<u>ICreateAngDim4</u>
	<u>ICreateAuxiliaryViewA12</u>
	<u>ICreateBlockDefinition</u>
	<u>ICreateCompoundNote</u>
	<u>ICreateCustomSymbol</u>
	<u>ICreateDetailViewA13</u>
	<u>ICreateDiamDim</u>
	<u>ICreateDiamDim2</u>
	<u>ICreateDiamDim3</u>
	<u>ICreateDiamDim4</u>
	<u>ICreateLinearDim</u>
	<u>ICreateLinearDim2</u>
	<u>ICreateLinearDim3</u>
	<u>ICreateLinearDim4</u>
	<u>ICreateOrdinateDim</u>
	<u>ICreateOrdinateDim2</u>
	<u>ICreateOrdinateDim3</u>
	<u>ICreateOrdinateDim4</u>
	<u>ICreateSectionViewA12</u>
	<u>ICreateSectionViewA13</u>
	<u>ICreateSectionViewA14</u>
	<u>ICreateSectionViewA15</u>
	<u>ICreateText2</u>
	<u>IEditSelectedGtol</u>
	<u>IFeatureByName</u>
	<u>IGetBlockDefinitions</u>
	<u>IGetCurrentSheet</u>
	<u>IGetFirstView</u>
	<u>IGetInsertionPoint</u>
	<u>IGetPenInfo</u>
	<u>IGetSheetNames</u>
	<u>InsertCustomSymbol2</u>
	<u>InsertDowelSymbol</u>
	<u>InsertMultiJogLeader2</u>
	<u>InsertMultiJogLeader3</u>
	<u>InsertRevisionCloud</u>
	<u>IMakeCustomSymbol2</u>

 INewGtol
 InsertAngularRunningDim
 InsertBaseDim
 InsertBlock
 InsertBreakHorizontal
 InsertBreakVertical
 InsertCenterLine
 InsertCenterLine2
 InsertCenterMark
 InsertCenterMark2
 InsertCenterMark3
 InsertChainDim
 InsertCircularNotePattern
 InsertCustomSymbol
 InsertCustomSymbol2
 InsertDatumTag
 InsertDowelSymbol
 InsertGroup
 InsertHorizontalOrdinate
 InsertLinearNotePattern
 InsertModelAnnotations
 InsertModelAnnotations2
 InsertModelAnnotations3
 InsertModelAnnotations4
 InsertModelDimensions
 InsertModelInPredefinedView
 InsertMultiJogLeader
 InsertMultiJogLeader2
 InsertMultiJogLeader3
 InsertNewNote
 InsertNewNote2
 InsertOrdinate
 InsertRefDim
 InsertRevisionCloud
 InsertRevisionSymbol
 InsertSurfaceFinishSymbol
 InsertTableAnnotation
 InsertTableAnnotation2
 InsertThreadCallout
 InsertVerticalOrdinate
 InsertWeldSymbol
 IReorderSheets
 IsDetailingMode

	IsolateChangedDimensions
	LoadLineStyles
	MakeBlockDefinition
	MakeCustomSymbol
	MakeCustomSymbol2
	MakeSectionLine
	ModifySurfaceFinishSymbol
	NewGtol
	NewNote
	NewSheet
	NewSheet2
	NewSheet3
	NewSheet4
	OnComponentProperties
	PasteSheet
	ReorderSheets
	ReplaceViewModel
	ResolveOutOfDateLightWeightComponents
	RestoreRotation
	SaveBlock
	SaveCustomSymbol
	SaveLineStyles
	SetCurrentLayer
	SetLineColor
	SetLineStyle
	SetLineWidth
	SetLineWidthCustom
	SetSheetsSelected
	SetupSheet
	SetupSheet2
	SetupSheet3
	SetupSheet4
	SetupSheet5
	SetupSheet6
	SheetNext
	SheetPrevious
	ShowEdge
	SketchDim
	StartDrawing
	SuppressView
	ToggleGrid
	TranslateDrawing
	UnBreakView

 UnsuppressView
 ViewDisplayHidden
 ViewDisplayHiddenGreyed
 ViewDisplayShaded
 ViewDisplayWireframe
 ViewFullPage
 ViewHicQuality
 ViewModelEdges
 ViewTangentEdges

Public Properties

 ActiveDrawingView
 AutomaticViewUpdate
 BackgroundProcessingOption
 HiddenViewsVisible
 IActiveDrawingView
 Sheet

Events

 ActivateSheetPostNotify
 ActivateSheetPreNotify
 ActiveConfigChangeNotify
 ActiveConfigChangePostNotify
 AddCustomPropertyNotify
 AddDependencyNotify
 AddDvePagePreNotify
 AddItemNotify
 AutoSaveNotify
 AutoSaveToStorageNotify
 AutoSaveToStorageStoreNotify
 ChangeCustomPropertyNotify
 ClearSelectionsNotify
 CommandManagerTabActivatedPreNotify
 DeleteCustomPropertyNotify
 DeleteDependencyNotify
 DeleteItemNotify
 DeleteItemPreNotify
 DeleteSelectionPreNotify
 DestroyNotify
 DestroyNotify2
 DimensionChangeNotify
 DisplayPaneCollapseNotify
 DisplayPaneExpandNotify
 DrawingStateChangeNotify

 [DynamicHighlightNotify](#)

 [EquationEditorPostNotify](#)

 [EquationEditorPreNotify](#)

 [FeatureManagerTabActivatedNotify](#)

 [FeatureManagerTabActivatedPreNotify](#)

 [FeatureManagerTreeRebuildNotify](#)

 [FileReloadCancelNotify](#)

 [FileReloadNotify](#)

 [FileReloadPreNotify](#)

 [FileSaveAsNotify](#)

 [FileSaveAsNotify2](#)

 [FileSaveNotify](#)

 [FileSavePostCancelNotify](#)

 [FileSavePostNotify](#)

 [InsertTableNotify](#)

 [LoadFromStorageNotify](#)

 [LoadFromStorageStoreNotify](#)

 [ModifyNotify](#)

 [ModifyTableNotify](#)

 [NewSelectionNotify](#)

 [RedoPostNotify](#)

 [RedoPreNotify](#)

 [RegenNotify](#)

 [RegenPostNotify](#)

 [RenameDisplayTitleNotify](#)

 [RenameItemNotify](#)

 [SaveToStorageNotify](#)

 [SaveToStorageStoreNotify](#)

 [SketchSolveNotify](#)

 [UndoPostNotify](#)

 [UndoPreNotify](#)

 [UnitsChangeNotify](#)

 [UserSelectionPostNotify](#)

 [UserSelectionPreNotify](#)

 [ViewCreatePreNotify](#)

 [ViewNewNotify](#)

 [ViewNewNotify2](#)

 [ViewPositionChangeNotify](#)

SOLIDWORKS Type Library

ActivateSheet Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ActivateSheet( _  
    ByVal Name As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

ActivateSheetPostNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ActivateSheetPostNotify( _  
    ByVal SheetName As String _  
    )
```

SOLIDWORKS Type Library

ActivateSheetPreNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ActivateSheetPreNotify( _  
    ByVal SheetName As String _  
    )
```

SOLIDWORKS Type Library

ActivateView Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ActivateView( _  
    ByVal ViewName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

ActiveConfigChangeNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ActiveConfigChangeNotify()
```

SOLIDWORKS Type Library

ActiveConfigChangePostNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ActiveConfigChangePostNotify()
```

SOLIDWORKS Type Library

ActiveDrawingView Property (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ActiveDrawingView As Object
```

AddCenterMark Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddCenterMark( _  
    ByVal CmSize As Double, _  
    ByVal CmShowLines As Boolean _  
    ) As Boolean
```

AddChamferDim Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddChamferDim( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Object
```

AddCustomPropertyNotify Event (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event AddCustomPropertyNotify( _  
    ByVal propName As String, _  
    ByVal Configuration As String, _  
    ByVal Value As String, _  
    ByVal valueType As Long _  
    )
```

AddDependencyNotify Event (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event AddDependencyNotify( _  
    ByVal PathName As String _  
    )
```

AddDvePagePreNotify Event (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Event AddDvePagePreNotify( _  
    ByVal Command As Long, _  
    ByRef PageToAdd As Object _  
    )
```

AddHoleCallout Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub AddHoleCallout()
```

SOLIDWORKS Type Library

AddHoleCallout2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddHoleCallout2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Object
```

SOLIDWORKS Type Library

AddItemNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AddItemNotify( _  
    ByVal EntityType As Long, _  
    ByVal itemName As String _  
    )
```

SOLIDWORKS Type Library

AddLineStyle Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddLineStyle( _  
    ByVal StyleName As String, _  
    ByVal StyleDefinition As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddOrdinateDimension Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddOrdinateDimension( _  
    ByVal DimType As Long, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddOrdinateDimension2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddOrdinateDimension2( _  
    ByVal DimType As Long, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double _  
    ) As Long
```

SOLIDWORKS Type Library

AlignHorz Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AlignHorz()
```

SOLIDWORKS Type Library

AlignOrdinate Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AlignOrdinate()
```

SOLIDWORKS Type Library

AlignVert Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AlignVert()
```

SOLIDWORKS Type Library

AttachAnnotation Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AttachAnnotation( _  
    ByVal Option As Long _  
) As Boolean
```

SOLIDWORKS Type Library

AttachDimensions Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AttachDimensions()
```

SOLIDWORKS Type Library

AutoBalloon Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AutoBalloon( _  
    ByVal Layout As Long _  
) As Variant
```

SOLIDWORKS Type Library

AutoBalloon2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AutoBalloon2( _  
    ByVal Layout As Long, _  
    ByVal IgnoreMultiple As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

AutoBalloon3 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AutoBalloon3( _  
    ByVal Layout As Long, _  
    ByVal IgnoreMultiple As Boolean, _  
    ByVal Style As Long, _  
    ByVal Size As Long, _  
    ByVal UpperTextContent As Long, _  
    ByVal UpperText As String, _  
    ByVal LowerTextContent As Long, _  
    ByVal LowerText As String, _  
    ByVal Layername As String _  
) As Variant
```

SOLIDWORKS Type Library

AutoBalloon4 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AutoBalloon4( _  
    ByVal Layout As Long, _  
    ByVal IgnoreMultiple As Boolean, _  
    ByVal Style As Long, _  
    ByVal Size As Long, _  
    ByVal UpperTextContent As Long, _  
    ByVal UpperText As String, _  
    ByVal LowerTextContent As Long, _  
    ByVal LowerText As String, _  
    ByVal Layername As String, _  
    ByVal BalloonsToFaces As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

AutoBalloon5 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AutoBalloon5( _  
    ByVal BalloonOptions As AutoBalloonOptions _  
) As Variant
```

SOLIDWORKS Type Library

AutoDimension Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AutoDimension( _  
    ByVal EntitiesToDimension As Long, _  
    ByVal HorizontalScheme As Long, _  
    ByVal HorizontalPlacement As Long, _  
    ByVal VerticalScheme As Long, _  
    ByVal VerticalPlacement As Long _  
) As Long
```

SOLIDWORKS Type Library

AutomaticViewUpdate Property (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AutomaticViewUpdate As Boolean
```

SOLIDWORKS Type Library

AutoSaveNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AutoSaveNotify( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

AutoSaveToStorageNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AutoSaveToStorageNotify()
```

SOLIDWORKS Type Library

AutoSaveToStorageStoreNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AutoSaveToStorageStoreNotify()
```

SOLIDWORKS Type Library

BackgroundProcessingOption Property (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property BackgroundProcessingOption As Long
```

SOLIDWORKS Type Library

BreakLineSplineCut Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub BreakLineSplineCut()
```

SOLIDWORKS Type Library

BreakLineStraightCut Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub BreakLineStraightCut()
```

SOLIDWORKS Type Library

BreakLineZigZagCut Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub BreakLineZigZagCut()
```

SOLIDWORKS Type Library

BreakView Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub BreakView()
```

SOLIDWORKS Type Library

CenterMark Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub CenterMark()
```

SOLIDWORKS Type Library

ChangeComponentLayer Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ChangeComponentLayer( _  
    ByVal Layername As String, _  
    ByVal AllViews As Boolean _  
)
```

SOLIDWORKS Type Library

ChangeCustomPropertyNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ChangeCustomPropertyNotify( _  
    ByVal propName As String, _  
    ByVal Configuration As String, _  
    ByVal oldValue As String, _  
    ByVal NewValue As String, _  
    ByVal valueType As Long _  
)
```

SOLIDWORKS Type Library

ChangeOrdDir Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ChangeOrdDir()
```

SOLIDWORKS Type Library

ChangeRefConfigurationOfFlatPatternView Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ChangeRefConfigurationOfFlatPatternView( _  
    ByVal ModelName As String, _  
    ByVal ConfigName As String _  
) As Boolean
```

SOLIDWORKS Type Library

ClearSelectionsNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ClearSelectionsNotify()
```

SOLIDWORKS Type Library

CommandManagerTabActivatedPreNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event CommandManagerTabActivatedPreNotify( _  
    ByVal CommandTabIndex As Long, _  
    ByVal CommandTabName As String _  
)
```

SOLIDWORKS Type Library

Create1stAngleViews Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Create1stAngleViews( _  
    ByVal ModelName As String _  
) As Boolean
```

SOLIDWORKS Type Library

Create1stAngleViews2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Create1stAngleViews2( _  
    ByVal ModelName As String _  
) As Boolean
```

SOLIDWORKS Type Library

Create3rdAngleViews Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Create3rdAngleViews( _  
    ByVal ModelName As String _  
) As Boolean
```

SOLIDWORKS Type Library

Create3rdAngleViews2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Create3rdAngleViews2( _  
    ByVal ModelName As String _  
) As Boolean
```

SOLIDWORKS Type Library

CreateAngDim Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateAngDim( _  
    ByVal VP0 As Variant, _  
    ByVal VP1 As Variant, _  
    ByVal VP2 As Variant, _
```

```

    ByVal VP3 As Variant, _
    ByVal VP4 As Variant, _
    ByVal VP5 As Variant, _
    ByVal VP6 As Variant, _
    ByVal ArrowSize As Double, _
    ByVal Text As String, _
    ByVal TextHeight As Double, _
    ByVal WitnessGap As Double, _
    ByVal WitnessOvershoot As Double _
) As Boolean

```

SOLIDWORKS Type Library

CreateAngDim2 Method (DrawingDoc)



Visual Basic for Applications (VBA)

```

Public Function CreateAngDim2( _
    ByVal VP0 As Variant, _
    ByVal VP1 As Variant, _
    ByVal VP2 As Variant, _
    ByVal VP3 As Variant, _
    ByVal VP4 As Variant, _
    ByVal VP5 As Variant, _
    ByVal VP6 As Variant, _
    ByVal ArrowSize As Double, _
    ByVal Text As String, _
    ByVal TextHeight As Double, _
    ByVal WitnessGap As Double, _
    ByVal WitnessOvershoot As Double, _
    ByVal VTextPoint As Variant _
) As Boolean

```

SOLIDWORKS Type Library

CreateAngDim3 Method (DrawingDoc)



Visual Basic for Applications (VBA)

```

Public Function CreateAngDim3( _
    ByVal VP0 As Variant, _
    ByVal VP1 As Variant, _
    ByVal VP2 As Variant, _
    ByVal VP3 As Variant, _
    ByVal VP4 As Variant, _
    ByVal VP5 As Variant, _
    ByVal VP6 As Variant, _
    ByVal ArrowSize As Double, _
    ByVal Text As String, _
    ByVal TextHeight As Double, _
    ByVal WitnessGap As Double, _
    ByVal WitnessOvershoot As Double, _
    ByVal VTextPoint As Variant _
) As Object

```

SOLIDWORKS Type Library

CreateAngDim4 Method (DrawingDoc)



Visual Basic for Applications (VBA)

```

Public Function CreateAngDim4( _
    ByVal P0 As Variant, _
    ByVal P1 As Variant, _
    ByVal P2 As Variant, _
    ByVal P3 As Variant, _
    ByVal P4 As Variant, _
    ByVal P5 As Variant, _

```

```
ByVal P6 As Variant, _  
ByVal TextPoint As Variant, _  
ByVal TextHeight As Double _  
) As Object
```

SOLIDWORKS Type Library

CreateAutoBalloonOptions Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateAutoBalloonOptions() As AutoBalloonOptions
```

SOLIDWORKS Type Library

CreateAuxiliaryView Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreateAuxiliaryView()
```

SOLIDWORKS Type Library

CreateAuxiliaryViewAt Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateAuxiliaryViewAt( _  
ByVal X As Double, _  
ByVal Y As Double, _  
ByVal Z As Double, _  
ByVal NotAligned As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

CreateAuxiliaryViewAt2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateAuxiliaryViewAt2( _  
ByVal X As Double, _  
ByVal Y As Double, _  
ByVal Z As Double, _  
ByVal NotAligned As Boolean, _  
ByVal Label As String, _  
ByVal Showarrow As Boolean, _  
ByVal Flip As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreateBlockDefinition Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateBlockDefinition( _  
ByVal Name As String, _  
ByVal XRefFileName As String, _  
ByVal Instance As Boolean, _  
ByVal Segments As Variant, _  
ByVal Points As Variant, _  
ByVal Notes As Variant, _  
ByVal Dimensions As Variant, _  
ByVal Blocks As Variant _  
) As Object
```

CreateBreakOutSection Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateBreakOutSection( _  
    ByVal Depth As Double _  
) As Boolean
```

CreateCompoundNote Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateCompoundNote( _  
    ByVal Height As Double, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

CreateConstructionGeometry Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub CreateConstructionGeometry()
```

CreateCustomSymbol Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateCustomSymbol( _  
    ByVal Segments As Variant, _  
    ByVal Points As Variant, _  
    ByVal Notes As Variant _  
) As Object
```

CreateDetailView Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub CreateDetailView()
```

CreateDetailViewAt Method (DrawingDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateDetailViewAt( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

CreateDetailViewAt2 Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDetailViewAt2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateDetailViewAt3 Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDetailViewAt3( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal Style As Long, _  
    ByVal Scale1 As Double, _  
    ByVal Scale2 As Double, _  
    ByVal LabelIn As String, _  
    ByVal Showtype As Long, _  
    ByVal FullOutline As Boolean _  
    ) As Object
```

SOLIDWORKS Type Library

CreateDetailViewAt4 Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDetailViewAt4( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal Style As Long, _  
    ByVal Scale1 As Double, _  
    ByVal Scale2 As Double, _  
    ByVal LabelIn As String, _  
    ByVal Showtype As Long, _  
    ByVal FullOutline As Boolean, _  
    ByVal JaggedOutline As Boolean, _  
    ByVal NoOutline As Boolean, _  
    ByVal ShapeIntensity As Long _  
    ) As Object
```

SOLIDWORKS Type Library

CreateDiamDim Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDiamDim( _  
    ByVal DimVal As Double, _  
    ByVal VP0 As Variant, _  
    ByVal VP1 As Variant, _  
    ByVal VP2 As Variant, _  
    ByVal VP3 As Variant, _  
    ByVal ArrowSize As Double, _  
    ByVal Text As String, _  
    ByVal TextHeight As Double, _  
    ByVal WitnessGap As Double, _  
    ByVal WitnessOvershoot As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateDiamDim2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDiamDim2( _  
    ByVal DimVal As Double, _  
    ByVal VP0 As Variant, _  
    ByVal VP1 As Variant, _  
    ByVal VP2 As Variant, _  
    ByVal VP3 As Variant, _  
    ByVal ArrowSize As Double, _  
    ByVal Text As String, _  
    ByVal TextHeight As Double, _  
    ByVal WitnessGap As Double, _  
    ByVal WitnessOvershoot As Double, _  
    ByVal VTextPoint As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

CreateDiamDim3 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDiamDim3( _  
    ByVal DimVal As Double, _  
    ByVal VP0 As Variant, _  
    ByVal VP1 As Variant, _  
    ByVal VP2 As Variant, _  
    ByVal VP3 As Variant, _  
    ByVal ArrowSize As Double, _  
    ByVal Text As String, _  
    ByVal TextHeight As Double, _  
    ByVal WitnessGap As Double, _  
    ByVal WitnessOvershoot As Double, _  
    ByVal VTextPoint As Variant _  
) As Object
```

SOLIDWORKS Type Library

CreateDiamDim4 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDiamDim4( _  
    ByVal P0 As Variant, _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant, _  
    ByVal P3 As Variant, _  
    ByVal TextPoint As Variant, _  
    ByVal Val As Double, _  
    ByVal TextHeight As Double _  
) As Object
```

SOLIDWORKS Type Library

CreateDrawViewFromModelView Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDrawViewFromModelView( _  
    ByVal ModelName As String, _  
    ByVal ViewName As String, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateDrawViewFromModelView2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDrawViewFromModelView2( _  
    ByVal ModelName As String, _  
    ByVal ViewName As String, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double _  
) As View
```

SOLIDWORKS Type Library

CreateDrawViewFromModelView3 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateDrawViewFromModelView3( _  
    ByVal ModelName As String, _  
    ByVal ViewName As String, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double _  
) As View
```

SOLIDWORKS Type Library

CreateFlatPatternViewFromModelView Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFlatPatternViewFromModelView( _  
    ByVal ModelName As String, _  
    ByVal ConfigName As String, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateFlatPatternViewFromModelView2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFlatPatternViewFromModelView2( _  
    ByVal ModelName As String, _  
    ByVal ConfigName As String, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double, _  
    ByVal HideBendLines As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

CreateFlatPatternViewFromModelView3 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFlatPatternViewFromModelView3( _  
    ByVal ModelName As String, _  
    ByVal ConfigName As String, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double, _  
    ByVal HideBendLines As Boolean, _  
    ByVal FlipView As Boolean _  
) As View
```

SOLIDWORKS Type Library

CreateLayer Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateLayer( _  
    ByVal Layername As String, _  
    ByVal LayerDesc As String, _  
    ByVal LayerColor As Long, _  
    ByVal LayerStyle As Long, _  
    ByVal LayerWidth As Long, _  
    ByVal BOn As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

CreateLayer2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateLayer2( _  
    ByVal Layername As String, _  
    ByVal LayerDesc As String, _  
    ByVal LayerColor As Long, _  
    ByVal LayerStyle As Long, _  
    ByVal LayerWidth As Long, _  
    ByVal BOn As Boolean, _  
    ByVal BPrint As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

CreateLinearDim Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateLinearDim( _  
    ByVal P0 As Variant, _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant, _  
    ByVal P3 As Variant, _  
    ByVal P4 As Variant, _  
    ByVal Angle As Double, _  
    ByVal ArrowSize As Double, _  
    ByVal Text As String, _  
    ByVal TextHeight As Double, _  
    ByVal WitnessGap As Double, _  
    ByVal WitnessOvershoot As Double _  
) As Boolean
```

SOLIDWORKS Type Library

 Syntax

Visual Basic for Applications (VBA)

```

Public Function CreateLinearDim2( _
    ByVal P0 As Variant, _
    ByVal P1 As Variant, _
    ByVal P2 As Variant, _
    ByVal P3 As Variant, _
    ByVal P4 As Variant, _
    ByVal Val As Double, _
    ByVal PrimPrec As Long, _
    ByVal Text As String, _
    ByVal TextPoint As Variant, _
    ByVal Angle As Double, _
    ByVal TextHeight As Double, _
    ByVal Prefix As String, _
    ByVal Suffix As String, _
    ByVal Callout1 As String, _
    ByVal Callout2 As String, _
    ByVal TolType As Long, _
    ByVal TolMin As String, _
    ByVal TolMax As String, _
    ByVal TolPrec As Long, _
    ByVal ArrowSize As Double, _
    ByVal ArrowStyle As Long, _
    ByVal ArrowDir As Long, _
    ByVal WitnessGap As Double, _
    ByVal WitnessOvershoot As Double, _
    ByVal DualDisplay As Boolean, _
    ByVal DualPrec As Long _
) As Boolean

```

 Syntax

Visual Basic for Applications (VBA)

```

Public Function CreateLinearDim3( _
    ByVal P0 As Variant, _
    ByVal P1 As Variant, _
    ByVal P2 As Variant, _
    ByVal P3 As Variant, _
    ByVal P4 As Variant, _
    ByVal Val As Double, _
    ByVal PrimPrec As Long, _
    ByVal Text As String, _
    ByVal TextPoint As Variant, _
    ByVal Angle As Double, _
    ByVal TextHeight As Double, _
    ByVal Prefix As String, _
    ByVal Suffix As String, _
    ByVal Callout1 As String, _
    ByVal Callout2 As String, _
    ByVal TolType As Long, _
    ByVal TolMin As String, _
    ByVal TolMax As String, _
    ByVal TolPrec As Long, _
    ByVal ArrowSize As Double, _
    ByVal ArrowStyle As Long, _
    ByVal ArrowDir As Long, _
    ByVal WitnessGap As Double, _
    ByVal WitnessOvershoot As Double, _
    ByVal DualDisplay As Boolean, _
    ByVal DualPrec As Long _
) As Object

```

 Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateLinearDim4( _
    ByVal P0 As Variant, _
    ByVal P1 As Variant, _
    ByVal P2 As Variant, _
    ByVal P3 As Variant, _
    ByVal P4 As Variant, _
    ByVal TextPoint As Variant, _
    ByVal Val As Double, _
    ByVal Angle As Double, _
    ByVal TextHeight As Double _
) As Object
```

 Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateOrdinateDim( _
    ByVal P0 As Variant, _
    ByVal P1 As Variant, _
    ByVal P2 As Variant, _
    ByVal P3 As Variant, _
    ByVal P4 As Variant, _
    ByVal Angle As Double, _
    ByVal ArrowSize As Double, _
    ByVal Text As String, _
    ByVal TextHeight As Double, _
    ByVal WitnessGap As Double, _
    ByVal WitnessOvershoot As Double _
) As Boolean
```

 Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateOrdinateDim2( _
    ByVal P0 As Variant, _
    ByVal P1 As Variant, _
    ByVal P2 As Variant, _
    ByVal P3 As Variant, _
    ByVal P4 As Variant, _
    ByVal Angle As Double, _
    ByVal ArrowSize As Double, _
    ByVal Text As String, _
    ByVal TextHeight As Double, _
    ByVal WitnessGap As Double, _
    ByVal WitnessOvershoot As Double, _
    ByVal P5 As Variant _
) As Boolean
```

 Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateOrdinateDim3( _
    ByVal P0 As Variant, _
    ByVal P1 As Variant, _
```

```

ByVal P2 As Variant, _
ByVal P3 As Variant, _
ByVal P4 As Variant, _
ByVal Angle As Double, _
ByVal ArrowSize As Double, _
ByVal Text As String, _
ByVal TextHeight As Double, _
ByVal WitnessGap As Double, _
ByVal WitnessOvershoot As Double, _
ByVal P5 As Variant _
) As Object

```

SOLIDWORKS Type Library

CreateOrdinateDim4 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```

Public Function CreateOrdinateDim4( _
    ByVal P0 As Variant, _
    ByVal P1 As Variant, _
    ByVal P2 As Variant, _
    ByVal P3 As Variant, _
    ByVal P4 As Variant, _
    ByVal P5 As Variant, _
    ByVal Val As Double, _
    ByVal Angle As Double, _
    ByVal TextHeight As Double _
) As Object

```

SOLIDWORKS Type Library

CreateRelativeView Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```

Public Function CreateRelativeView( _
    ByVal ModelName As String, _
    ByVal XPos As Double, _
    ByVal YPos As Double, _
    ByVal ViewDirFront As Long, _
    ByVal ViewDirRight As Long _
) As View

```

SOLIDWORKS Type Library

CreateSectionView Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```

Public Sub CreateSectionView()

```

SOLIDWORKS Type Library

CreateSectionViewAt Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```

Public Function CreateSectionViewAt( _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal Z As Double, _
    ByVal NotAligned As Boolean, _
    ByVal IsOffsetSection As Boolean _
) As Boolean

```

SOLIDWORKS Type Library

CreateSectionViewAt2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSectionViewAt2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal NotAligned As Boolean, _  
    ByVal IsOffsetSection As Boolean, _  
    ByVal Label As String, _  
    ByVal Chgdirection As Boolean, _  
    ByVal Scwithmodel As Boolean, _  
    ByVal Partial As Boolean, _  
    ByVal Dispsurfcut As Boolean _  
    ) As Object
```

SOLIDWORKS Type Library

CreateSectionViewAt3 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSectionViewAt3( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal NotAligned As Boolean, _  
    ByVal IsOffsetSection As Boolean, _  
    ByVal Label As String, _  
    ByVal Chgdirection As Boolean, _  
    ByVal Scwithmodel As Boolean, _  
    ByVal Partial As Boolean, _  
    ByVal Dispsurfcut As Boolean, _  
    ByVal ExcludedComponents As Variant _  
    ) As View
```

SOLIDWORKS Type Library

CreateSectionViewAt4 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSectionViewAt4( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal SectionLabel As String, _  
    ByVal Options As Long, _  
    ByVal ExcludedComponents As Variant _  
    ) As View
```

SOLIDWORKS Type Library

CreateSectionViewAt5 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSectionViewAt5( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal SectionLabel As String, _  
    ByVal Options As Long, _  
    ByVal ExcludedComponents As Variant, _  
    ByVal SectionDepth As Double _  
) As View
```

SOLIDWORKS Type Library

CreateText Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateText( _  
    ByVal TextString As String, _  
    ByVal TextX As Double, _  
    ByVal TextY As Double, _  
    ByVal TextZ As Double, _  
    ByVal TextHeight As Double, _  
    ByVal TextAngle As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateText2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateText2( _  
    ByVal TextString As String, _  
    ByVal TextX As Double, _  
    ByVal TextY As Double, _  
    ByVal TextZ As Double, _  
    ByVal TextHeight As Double, _  
    ByVal TextAngle As Double _  
) As Object
```

SOLIDWORKS Type Library

CreateUnfoldedViewAt Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateUnfoldedViewAt( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateUnfoldedViewAt2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateUnfoldedViewAt2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal NotAligned As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

CreateUnfoldedViewAt3 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateUnfoldedViewAt3( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal NotAligned As Boolean _  
    ) As View
```

SOLIDWORKS Type Library

CreateViewport Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateViewport( _  
    ByVal LowerLeftX As Double, _  
    ByVal LowerLeftY As Double, _  
    ByVal UpperRightX As Double, _  
    ByVal UpperRightY As Double, _  
    ByVal SketchSize As Integer _  
    ) As String
```

SOLIDWORKS Type Library

CreateViewport2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateViewport2( _  
    ByVal LowerLeftX As Double, _  
    ByVal LowerLeftY As Double, _  
    ByVal UpperRightX As Double, _  
    ByVal UpperRightY As Double, _  
    ByVal SketchSize As Integer, _  
    ByVal Scale As Double _  
    ) As String
```

SOLIDWORKS Type Library

CreateViewport3 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateViewport3( _  
    ByVal LowerLeftX As Double, _  
    ByVal LowerLeftY As Double, _  
    ByVal SketchSize As Integer, _  
    ByVal Scale As Double _  
    ) As View
```

SOLIDWORKS Type Library

DeleteAllCosmeticThreads Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteAllCosmeticThreads()
```

SOLIDWORKS Type Library

DeleteCustomPropertyNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteCustomPropertyNotify( _  
    ByVal propName As String, _  
    ByVal Configuration As String, _  
    ByVal Value As String, _  
    ByVal valueType As Long _  
)
```

SOLIDWORKS Type Library

DeleteDependencyNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteDependencyNotify( _  
    ByVal PathName As String _  
)
```

SOLIDWORKS Type Library

DeleteItemNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteItemNotify( _  
    ByVal EntityType As Long, _  
    ByVal itemName As String _  
)
```

SOLIDWORKS Type Library

DeleteItemPreNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteItemPreNotify( _  
    ByVal EntityType As Long, _  
    ByVal itemName As String _  
)
```

SOLIDWORKS Type Library

DeleteLineStyle Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteLineStyle( _  
    ByVal StyleName As String, _  
    ByVal ReplaceName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteSelectionPreNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteSelectionPreNotify()
```

SOLIDWORKS Type Library

DestroyNotify2 Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DestroyNotify2( _  
    ByVal DestroyType As Long _  
)
```

SOLIDWORKS Type Library

DestroyNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DestroyNotify()
```

SOLIDWORKS Type Library

DimensionChangeNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DimensionChangeNotify( _  
    ByVal displayDim As Object _  
)
```

SOLIDWORKS Type Library

Dimensions Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Dimensions()
```

SOLIDWORKS Type Library

DisplayPaneCollapseNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DisplayPaneCollapseNotify()
```

SOLIDWORKS Type Library

DisplayPaneExpandNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DisplayPaneExpandNotify()
```

SOLIDWORKS Type Library

DragModelDimension Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DragModelDimension( _  
    ByVal ViewName As String, _  
    ByVal DropEffect As Integer, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
)
```

SOLIDWORKS Type Library

DrawingStateChangeNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DrawingStateChangeNotify( _  
    ByVal PreviousState As Integer, _  
    ByVal newState As Integer _  
)
```

SOLIDWORKS Type Library

DrawingViewRotate Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function DrawingViewRotate( _  
    ByVal NewAngle As Double _  
) As Boolean
```

SOLIDWORKS Type Library

DropDrawingViewFromPalette Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function DropDrawingViewFromPalette( _  
    ByVal Layout As Long, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As View
```

SOLIDWORKS Type Library

DropDrawingViewFromPalette2 Method (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function DropDrawingViewFromPalette2( _  
    ByVal PaletteViewName As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As View
```

SOLIDWORKS Type Library

DynamicHighlightNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DynamicHighlightNotify( _  
    ByVal bHighlightState As Boolean _  
)
```

SOLIDWORKS Type Library

EditCenterMarkProperties Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditCenterMarkProperties( _  
    ByVal Angle As Double, _  
    ByVal Size As Double, _  
    ByVal Lines As Boolean, _  
    ByVal DocSettings As Boolean _  
)
```

SOLIDWORKS Type Library

EditOrdinate Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditOrdinate()
```

SOLIDWORKS Type Library

EditRebuild Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditRebuild()
```

SOLIDWORKS Type Library

EditSelectedGtol Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EditSelectedGtol() As Object
```

SOLIDWORKS Type Library

EditSheet Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditSheet()
```

SOLIDWORKS Type Library

EditSheet2 Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditSheet2()
```

SOLIDWORKS Type Library

EditSketch Method (DrawingDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditSketch()
```

SOLIDWORKS Type Library

EditTemplate Method (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Sub EditTemplate()
```

SOLIDWORKS Type Library

EndDrawing Method (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Sub EndDrawing()
```

SOLIDWORKS Type Library

EquationEditorPostNotify Event (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Event EquationEditorPostNotify( _  
    ByVal Changed As Boolean _  
)
```

SOLIDWORKS Type Library

EquationEditorPreNotify Event (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Event EquationEditorPreNotify()
```

SOLIDWORKS Type Library

ExplodeBlockInstance Method (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Function ExplodeBlockInstance() As Boolean
```

SOLIDWORKS Type Library

ExplodeCustomSymbol Method (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Sub ExplodeCustomSymbol()
```

SOLIDWORKS Type Library

FeatureByName Method (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Function FeatureByName( _  
    ByVal Name As String _  
    ) As Object
```

SOLIDWORKS Type Library

FeatureManagerTabActivatedNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FeatureManagerTabActivatedNotify( _  
    ByVal CommandIndex As Long, _  
    ByVal CommandTabName As String _  
    )
```

SOLIDWORKS Type Library

FeatureManagerTabActivatedPreNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FeatureManagerTabActivatedPreNotify( _  
    ByVal CommandIndex As Long, _  
    ByVal CommandTabName As String _  
    )
```

SOLIDWORKS Type Library

FeatureManagerTreeRebuildNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FeatureManagerTreeRebuildNotify()
```

SOLIDWORKS Type Library

FileReloadCancelNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FileReloadCancelNotify( _  
    ByVal ErrorCode As Long _  
    )
```

SOLIDWORKS Type Library

FileReloadNotify Event (DrawingDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FileReloadNotify()
```

SOLIDWORKS Type Library

FileReloadPreNotify Event (DrawingDoc)





Visual Basic for Applications (VBA)

```
Public Event FileReloadPreNotify()
```

SOLIDWORKS Type Library

FileSaveAsNotify2 Event (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Event FileSaveAsNotify2( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

FileSaveAsNotify Event (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Event FileSaveAsNotify( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

FileSaveNotify Event (DrawingDoc)



Visual Basic for Applications (VBA)

```
Public Event FileSaveNotify( _  
    ByVal FileName As String _  
)
```