

SOLIDWORKS API (VB6 COM) — Reference (29/102): Face2-FaultEntity

SOLIDWORKS API Documentation (converted from CHM)

Face2 (Type)

SOLIDWORKS Type Library

Face2 Object

Object Model

Face2

- Check (FaultEntity)
- EnumEdges
- EnumLoops (EnumLoops2)
- GetProjectedPointOn (MathPoint)
- GetSeedFeature (Feature)
- GetTexture (Texture)
- ICreateSheetBody (Body2)
- ICreateSheetBodyByFaceExtension (Body2)
- IGetAllDecalProperties (FaceDecalProperties)
- IGetBody (Body2)
- IGetEdges (Edge)
- IGetFeature (Feature)
- IGetFirstLoop (Loop2)
- IGetLoops (Loop2)
- IGetNextFace (Face2)
- IGetPatternSeedFeature (Feature)
- IGetSilhoutteEdges (Edge)
- IGetSurface (Surface)
- IRemoveInnerLoops (Face2)

SOLIDWORKS Type Library

Face2 Object Members

Public Methods

	AddPropertyExtension
	AttachSurface
	CreateSheetBody
	CreateSheetBodyByFaceExtension
	DetachSurface

 EnumEdges
 EnumLoops
 FaceInSurfaceSense
 GetAllAssemblyDecalProperties
 GetAllDecalProperties
 GetArea
 GetBody
 GetBox
 GetClosestPointOn
 GetDecalsCount
 GetEdgeCount
 GetEdges
 GetFaceId
 GetFeature
 GetFeatureId
 GetFirstLoop
 GetLoopCount
 GetLoops
 GetMaterialPropertyValues2
 GetNextFace
 GetPatternSeedFeature
 GetProjectedPointOn
 GetPropertyExtension
 GetSeedFeature
 GetShellType
 GetSilhouetteEdges
 GetSilhouetteEdgesVB
 GetSurface
 GetTessNorms
 GetTessTextures
 GetTessTriangleCount
 GetTessTriangles
 GetTessTriStripEdges
 GetTessTriStripNorms
 GetTessTriStrips
 GetTessTriStripSize
 GetTessTriStripTextures
 GetTexture
 GetTrackingIDs
 GetTrackingIDsCount
 GetTrimCurves
 GetTrimCurves2
 GetTrimCurveTopology

	GetTrimCurveTopologyCount
	GetTrimCurveTopologyTypes
	GetUVBounds
	HasMaterialPropertyValues
	HasTextureCoordinates
	Highlight
	ICreateSheetBody
	ICreateSheetBodyByFaceExtension
	IGetAllDecalProperties
	IGetBody
	IGetBox
	IGetClosestPointOn
	IGetDecalProperties
	IGetEdges
	IGetFacetData
	IGetFeature
	IGetFirstLoop
	IGetLoops
	IGetMaterialPropertyValues2
	IGetNextFace
	IGetPatternSeedFeature
	IGetSilhouetteEdgeCount
	IGetSilhouetteEdges
	IGetSurface
	IGetTessNorms
	IGetTessTextures
	IGetTessTriangles
	IGetTessTriStripEdges
	IGetTessTriStripEdgeSize
	IGetTessTriStripNorms
	IGetTessTriStrips
	IGetTrackingIds
	IGetTrimCurve
	IGetTrimCurveSize
	IGetTrimCurveSize2
	IGetTrimCurveTopology
	IGetTrimCurveTopologyTypes
	IGetUVBounds
	IHighlight
	IImprintCurve
	IsCoincident
	IsSame
	ImprintCurve

 ImprintCurveCount
 IRemoveInnerLoops
 IRemoveMaterialProperty2
 IRReverseEvaluate
 IsCoincident
 ISetMaterialPropertyValues2
 IsSame
 RemoveFaceId
 RemoveInnerLoops
 RemoveMaterialProperty
 RemoveMaterialProperty2
 RemoveRedundantTopology
 RemoveTexture
 RemoveTexture2
 RemoveTextureByDisplayState
 RemoveTrackingID
 ResetPropertyExtension
 ReverseEvaluate
 SetFaceId
 SetMaterialPropertyValues2
 SetTexture
 SetTextureByDisplayState
 SetTrackingID

Public Properties

 Check
 MaterialPropertyValues
 INormal
 MaterialIdName
 MaterialPropertyValues
 MaterialUserName
 Normal

SOLIDWORKS Type Library

AddPropertyExtension Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddPropertyExtension( _
    ByVal PropertyExtension As Variant _
) As Long
```

SOLIDWORKS Type Library

AttachSurface Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AttachSurface( _  
    ByVal SurfIn As Surface, _  
    ByVal SenseIn As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

Check Property (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Check As FaultEntity
```

SOLIDWORKS Type Library

CreateSheetBody Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSheetBody() As Object
```

SOLIDWORKS Type Library

CreateSheetBodyByFaceExtension Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSheetBodyByFaceExtension( _  
    ByVal BoxLowIn As Variant, _  
    ByVal BoxHighIn As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

DetachSurface Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DetachSurface() As Boolean
```

SOLIDWORKS Type Library

EnumEdges Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumEdges() As EnumEdges
```

SOLIDWORKS Type Library

EnumLoops Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumLoops() As EnumLoops2
```

SOLIDWORKS Type Library

FaceInSurfaceSense Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function FaceInSurfaceSense() As Boolean
```

SOLIDWORKS Type Library

GetAllAssemblyDecalProperties Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetAllAssemblyDecalProperties() As Variant
```

SOLIDWORKS Type Library

GetAllDecalProperties Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetAllDecalProperties() As Variant
```

SOLIDWORKS Type Library

GetArea Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetArea() As Double
```

SOLIDWORKS Type Library

GetBody Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetBody() As Object
```

SOLIDWORKS Type Library

GetBox Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetBox() As Variant
```

SOLIDWORKS Type Library

GetClosestPointOn Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetClosestPointOn( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Variant
```

SOLIDWORKS Type Library

GetDecalsCount Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetDecalsCount() As Long
```

SOLIDWORKS Type Library

GetEdgeCount Method (Face2)



Visual Basic for Applications (VBA)

Public Function GetEdgeCount() As Long

SOLIDWORKS Type Library

GetEdges Method (Face2)

 Syntax

Visual Basic for Applications (VBA)

Public Function GetEdges() As Variant

SOLIDWORKS Type Library

GetFacelD Method (Face2)

 Syntax

Visual Basic for Applications (VBA)

Public Function GetFaceId() As Integer

SOLIDWORKS Type Library

GetFeature Method (Face2)

 Syntax

Visual Basic for Applications (VBA)

Public Function GetFeature() As Object

SOLIDWORKS Type Library

GetFeatureId Method (Face2)

 Syntax

Visual Basic for Applications (VBA)

Public Function GetFeatureId() As Long

SOLIDWORKS Type Library

GetFirstLoop Method (Face2)

 Syntax

Visual Basic for Applications (VBA)

Public Function GetFirstLoop() As Object

SOLIDWORKS Type Library

GetLoopCount Method (Face2)

 Syntax

Visual Basic for Applications (VBA)

Public Function GetLoopCount() As Long

SOLIDWORKS Type Library

GetLoops Method (Face2)

 Syntax

Visual Basic for Applications (VBA)

Public Function GetLoops() As Variant

SOLIDWORKS Type Library

GetMaterialPropertyValues2 Method (Face2)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMaterialPropertyValues2( _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

GetNextFace Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNextFace() As Object
```

SOLIDWORKS Type Library

GetPatternSeedFeature Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPatternSeedFeature() As Object
```

SOLIDWORKS Type Library

GetProjectedPointOn Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProjectedPointOn( _  
    ByVal Point As MathPoint, _  
    ByVal Direction As MathVector _  
    ) As MathPoint
```

SOLIDWORKS Type Library

GetPropertyExtension Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPropertyExtension( _  
    ByVal ID As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

GetSeedFeature Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSeedFeature() As Feature
```

SOLIDWORKS Type Library

GetShellType Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetShellType() As Integer
```

SOLIDWORKS Type Library

GetSilhouetteEdges Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSilhoutteEdges( _  
    ByRef Root As Double, _  
    ByRef Normal As Double _  
) As Variant
```

SOLIDWORKS Type Library

GetSilhoutteEdgesVB Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSilhoutteEdgesVB( _  
    ByVal Xroot As Double, _  
    ByVal Yroot As Double, _  
    ByVal Zroot As Double, _  
    ByVal Xnormal As Double, _  
    ByVal Ynormal As Double, _  
    ByVal Znormal As Double _  
) As Variant
```

SOLIDWORKS Type Library

GetSurface Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSurface() As Object
```

SOLIDWORKS Type Library

GetTessNorms Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessNorms() As Variant
```

SOLIDWORKS Type Library

GetTessTextures Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTextures() As Variant
```

SOLIDWORKS Type Library

GetTessTriangleCount Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTriangleCount() As Long
```

SOLIDWORKS Type Library

GetTessTriangles Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTriangles( _  
    ByVal NoConversion As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetTessTriStripEdges Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetTessTriStripEdges() As Variant
```

SOLIDWORKS Type Library

GetTessTriStripNorms Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetTessTriStripNorms() As Variant
```

SOLIDWORKS Type Library

GetTessTriStrips Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetTessTriStrips( _  
    ByVal NoConversion As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetTessTriStripSize Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetTessTriStripSize() As Long
```

SOLIDWORKS Type Library

GetTessTriStripTextures Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetTessTriStripTextures() As Variant
```

SOLIDWORKS Type Library

GetTexture Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetTexture( _  
    ByVal Config_name As String _  
) As Texture
```

SOLIDWORKS Type Library

GetTrackingIDs Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetTrackingIDs( _  
    ByVal TrackingCookie As Long, _  
    ByRef TrackingIDs As Variant _  
) As Long
```

SOLIDWORKS Type Library

GetTrackingIDsCount Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function GetTrackingIDsCount( _  
    ByVal TrackingCookie As Long _  
) As Long
```

SOLIDWORKS Type Library

GetTrimCurves Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTrimCurves( _  
    ByVal WantCubic As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetTrimCurves2 Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTrimCurves2( _  
    ByVal WantCubic As Boolean, _  
    ByVal WantNRational As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetTrimCurveTopology Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTrimCurveTopology() As Variant
```

SOLIDWORKS Type Library

GetTrimCurveTopologyCount Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTrimCurveTopologyCount() As Long
```

SOLIDWORKS Type Library

GetTrimCurveTopologyTypes Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTrimCurveTopologyTypes() As Variant
```

SOLIDWORKS Type Library

GetUVBounds Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUVBounds() As Variant
```

SOLIDWORKS Type Library

HasMaterialPropertyValues Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function HasMaterialPropertyValues() As Boolean
```

SOLIDWORKS Type Library

HasTextureCoordinates Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function HasTextureCoordinates() As Boolean
```

SOLIDWORKS Type Library

Highlight Method (Face2)



Visual Basic for Applications (VBA)

```
Public Sub Highlight( _  
    ByVal State As Boolean _  
)
```

SOLIDWORKS Type Library

ICreateSheetBody Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function ICreateSheetBody() As Body2
```

SOLIDWORKS Type Library

ICreateSheetBodyByFaceExtension Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function ICreateSheetBodyByFaceExtension( _  
    ByRef BoxLowIn As Double, _  
    ByRef BoxHighIn As Double _  
) As Body2
```

SOLIDWORKS Type Library

IGetAllDecalProperties Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetAllDecalProperties( _  
    ByVal Count As Long _  
) As FaceDecalProperties
```

SOLIDWORKS Type Library

IGetBody Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetBody() As Body2
```

SOLIDWORKS Type Library

IGetBox Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetBox() As Double
```

SOLIDWORKS Type Library

IGetClosestPointOn Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetClosestPointOn( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Double
```

SOLIDWORKS Type Library

IGetDecalProperties Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetDecalProperties( _  
    ByVal pDecal As Decal, _  
    ByVal pFaceDecalProperties As FaceDecalProperties _  
)
```

SOLIDWORKS Type Library

IGetEdges Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEdges() As Edge
```

SOLIDWORKS Type Library

IGetFacetData Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetFacetData( _  
    ByVal FacetMesh As Integer, _  
    ByRef NFacets As Integer, _  
    ByRef NStrips As Integer, _  
    ByRef StripVertexNums As Integer, _  
    ByRef VertexCoords As Single, _  
    ByRef NormalCoords As Single _  
)
```

SOLIDWORKS Type Library

IGetFeature Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFeature() As Feature
```

SOLIDWORKS Type Library

IGetFirstLoop Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFirstLoop() As Loop2
```

IGetLoops Method (Face2)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetLoops( _  
    ByVal NumberOfLoops As Long _  
) As Loop2
```

IGetMaterialPropertyValues2 Method (Face2)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetMaterialPropertyValues2( _  
    ByVal Config_opt As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
) As Double
```

IGetNextFace Method (Face2)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetNextFace() As Face2
```

IGetPatternSeedFeature Method (Face2)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetPatternSeedFeature() As Feature
```

IGetSilhoutteEdgeCount Method (Face2)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetSilhoutteEdgeCount( _  
    ByRef Root As Double, _  
    ByRef Normal As Double _  
) As Long
```

IGetSilhoutteEdges Method (Face2)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetSilhoutteEdges( _  
    ByRef Root As Double, _  
    ByRef Normal As Double _  
) As Edge
```

IGetSurface Method (Face2)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetSurface() As Surface
```

SOLIDWORKS Type Library

IGetTessNorms Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetTessNorms() As Single
```

SOLIDWORKS Type Library

IGetTessTextures Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTextures() As Single
```

SOLIDWORKS Type Library

IGetTessTriangles Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriangles( _  
    ByVal NoConversion As Boolean _  
    ) As Single
```

SOLIDWORKS Type Library

IGetTessTriStripEdges Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriStripEdges() As Long
```

SOLIDWORKS Type Library

IGetTessTriStripEdgeSize Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriStripEdgeSize() As Long
```

SOLIDWORKS Type Library

IGetTessTriStripNorms Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriStripNorms() As Single
```

SOLIDWORKS Type Library

IGetTessTriStrips Method (Face2)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriStrips( _  
    ByVal NoConversion As Boolean _  
    ) As Single
```

SOLIDWORKS Type Library

IGetTrackingIDs Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTrackingIDs( _  
    ByVal TrackingCookie As Long, _  
    ByVal Count As Long, _  
    ByRef TrackingIDs As Long _  
    ) As Long
```

SOLIDWORKS Type Library

IGetTrimCurve Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTrimCurve() As Double
```

SOLIDWORKS Type Library

IGetTrimCurveSize Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTrimCurveSize( _  
    ByVal WantCubic As Boolean _  
    ) As Long
```

SOLIDWORKS Type Library

IGetTrimCurveSize2 Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTrimCurveSize2( _  
    ByVal WantCubic As Long, _  
    ByVal WantNRational As Long _  
    ) As Long
```

SOLIDWORKS Type Library

IGetTrimCurveTopology Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTrimCurveTopology() As Object
```

SOLIDWORKS Type Library

IGetTrimCurveTopologyTypes Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTrimCurveTopologyTypes() As Long
```

SOLIDWORKS Type Library

IGetUVBounds Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUVBounds() As Double
```

SOLIDWORKS Type Library

IHighlight Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IHighlight( _  
    ByVal State As Boolean _  
)
```

SOLIDWORKS Type Library

ImprintCurve Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IImprintCurve( _  
    ByVal Curve As Curve, _  
    ByVal NewEdgeCount As Long, _  
    ByRef NewEdges As Edge, _  
    ByVal NewFaceCount As Long, _  
    ByRef NewFaces As Face2 _  
)
```

SOLIDWORKS Type Library

IIsCoincident Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IIsCoincident( _  
    ByVal FaceIn As Face2, _  
    ByVal Tolerance As Double _  
) As Long
```

SOLIDWORKS Type Library

IIsSame Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IIsSame( _  
    ByVal FaceIn As Face2 _  
) As Boolean
```

SOLIDWORKS Type Library

IMaterialPropertyValues Property (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IMaterialPropertyValues As Double
```

SOLIDWORKS Type Library

ImprintCurve Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ImprintCurve( _  
    ByVal Curve As Object, _  
    ByRef NewEdges As Variant, _  
    ByRef NewFaces As Variant _  
)
```

SOLIDWORKS Type Library

ImprintCurveCount Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ImprintCurveCount( _  
    ByVal Curve As Curve, _  
    ByRef NewEdgeCount As Long, _  
    ByRef NewFaceCount As Long _  
)
```

SOLIDWORKS Type Library

INormal Property (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property INormal As Double
```

SOLIDWORKS Type Library

IRemoveInnerLoops Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IRemoveInnerLoops( _  
    ByVal NumOfLoops As Long, _  
    ByVal InnerLoopsIn As Loop2 _  
) As Face2
```

SOLIDWORKS Type Library

IRemoveMaterialProperty2 Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IRemoveMaterialProperty2( _  
    ByVal Config_opt As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
) As Boolean
```

SOLIDWORKS Type Library

IRverseEvaluate Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IReverseEvaluate( _  
    ByVal PositionX As Double, _  
    ByVal PositionY As Double, _  
    ByVal PositionZ As Double _  
) As Double
```

SOLIDWORKS Type Library

IsCoincident Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsCoincident( _  
    ByVal FaceIn As Object, _  
    ByVal Tolerance As Double _  
) As Long
```

SOLIDWORKS Type Library

ISetMaterialPropertyValues2 Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetMaterialPropertyValues2( _  
    ByRef Material_values As Double, _  
    ByVal Config_opt As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
)
```

SOLIDWORKS Type Library

IsSame Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsSame( _  
    ByVal FaceIn As Object _  
) As Boolean
```

SOLIDWORKS Type Library

MaterialIdName Property (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaterialIdName As String
```

SOLIDWORKS Type Library

MaterialPropertyValues Property (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaterialPropertyValues As Variant
```

SOLIDWORKS Type Library

MaterialUserName Property (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaterialUserName As String
```

SOLIDWORKS Type Library

Normal Property (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Normal As Variant
```

SOLIDWORKS Type Library

RemoveFaceId Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveFaceId( _  
    ByVal IdIn As Integer _  
)
```

SOLIDWORKS Type Library

RemoveInnerLoops Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveInnerLoops( _  
    ByVal NumOfLoops As Long, _  
    ByVal InnerLoopsIn As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

RemoveMaterialProperty Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveMaterialProperty() As Boolean
```

SOLIDWORKS Type Library

RemoveMaterialProperty2 Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveMaterialProperty2( _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

RemoveRedundantTopology Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveRedundantTopology() As Boolean
```

SOLIDWORKS Type Library

RemoveTexture Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTexture( _  
    ByVal Config_name As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

RemoveTexture2 Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTexture2( _  
    ByVal Config_name As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

RemoveTextureByDisplayState Method (Face2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTextureByDisplayState( _  
    ByVal DisplayStateName As String _  
    ) As Boolean
```

RemoveTrackingID Method (Face2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function RemoveTrackingID( _  
    ByVal TrackingCookie As Long _  
) As Long
```

ResetPropertyExtension Method (Face2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub ResetPropertyExtension()
```

ReverseEvaluate Method (Face2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ReverseEvaluate( _  
    ByVal PositionX As Double, _  
    ByVal PositionY As Double, _  
    ByVal PositionZ As Double _  
) As Variant
```

SetFaceId Method (Face2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub SetFaceId( _  
    ByVal IdIn As Integer _  
)
```

SetMaterialPropertyValues2 Method (Face2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub SetMaterialPropertyValues2( _  
    ByVal Material_values As Variant, _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
)
```

SetTexture Method (Face2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetTexture( _  
    ByVal Config_name As String, _  
    ByVal TextureIn As Texture _  
) As Boolean
```

SetTextureByDisplayState Method (Face2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTextureByDisplayState( _  
    ByVal DisplayStateName As String, _  
    ByVal TextureIn As Texture _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetTrackingID Method (Face2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTrackingID( _  
    ByVal TrackingCookie As Long, _  
    ByVal TrackingID As Long _  
    ) As Long
```

FaceDecalProperties (Type)

SOLIDWORKS Type Library

FaceDecalProperties Object

Object Model

FaceDecalProperties

SOLIDWORKS Type Library

FaceDecalProperties Object Members

Public Properties

 TextureAngle
 TextureAngleUV
 TextureFilename
 TextureFilenameID
 TextureID
 TextureMapID
 TextureMirrored
 TextureRenderMode
 TextureTranslationU
 TextureTranslationV
 TextureTranslationX
 TextureTranslationY
 TextureUScale
 TextureVScale

SOLIDWORKS Type Library

TextureAngle Property (FaceDecalProperties)

Syntax

Visual Basic for Applications (VBA)

```
Public Property TextureAngle As Double
```

SOLIDWORKS Type Library

TextureAngleUV Property (FaceDecalProperties)

Syntax

Visual Basic for Applications (VBA)

```
Public Property TextureAngleUV As Double
```

SOLIDWORKS Type Library

TextureFilename Property (FaceDecalProperties)

Syntax

Visual Basic for Applications (VBA)

```
Public Property TextureFilename As String
```

SOLIDWORKS Type Library

TextureFilenameID Property (FaceDecalProperties)



Syntax

Visual Basic for Applications (VBA)

Public Property TextureFilenameID As Long

SOLIDWORKS Type Library

TextureID Property (FaceDecalProperties)



Syntax

Visual Basic for Applications (VBA)

Public Property TextureID As Long

SOLIDWORKS Type Library

TextureMapID Property (FaceDecalProperties)



Syntax

Visual Basic for Applications (VBA)

Public Property TextureMapID As Long

SOLIDWORKS Type Library

TextureMirrored Property (FaceDecalProperties)



Syntax

Visual Basic for Applications (VBA)

Public Property TextureMirrored As Boolean

SOLIDWORKS Type Library

TextureRenderMode Property (FaceDecalProperties)



Syntax

Visual Basic for Applications (VBA)

Public Property TextureRenderMode As Long

SOLIDWORKS Type Library

TextureTranslationU Property (FaceDecalProperties)



Syntax

Visual Basic for Applications (VBA)

Public Property TextureTranslationU As Double

SOLIDWORKS Type Library

TextureTranslationV Property (FaceDecalProperties)



Syntax

Visual Basic for Applications (VBA)

Public Property TextureTranslationV As Double

SOLIDWORKS Type Library

TextureTranslationX Property (FaceDecalProperties)



Syntax

Visual Basic for Applications (VBA)

Public Property TextureTranslationX As Double

SOLIDWORKS Type Library

TextureTranslationY Property (FaceDecalProperties)



Visual Basic for Applications (VBA)

Public Property TextureTranslationY As Double

SOLIDWORKS Type Library

TextureUScale Property (FaceDecalProperties)



Visual Basic for Applications (VBA)

Public Property TextureUScale As Double

SOLIDWORKS Type Library

TextureVScale Property (FaceDecalProperties)



Visual Basic for Applications (VBA)

Public Property TextureVScale As Double

FaceHatch (Type)

SOLIDWORKS Type Library

FaceHatch Object

Object Model

FaceHatch

Face (Face2)

SOLIDWORKS Type Library

FaceHatch Object Members

Public Properties

- Angle
- Color
- Definition
- Face
- HatchScope
- HatchType
- Layer
- Pattern
- PatternId
- Scale
- Scale2
- SolidFill
- UseMaterialHatch

SOLIDWORKS Type Library

Angle Property (FaceHatch)

Syntax

Visual Basic for Applications (VBA)

Public Property Angle As Double

SOLIDWORKS Type Library

Color Property (FaceHatch)

Syntax

Visual Basic for Applications (VBA)

Public Property Color As Long

SOLIDWORKS Type Library

Definition Property (FaceHatch)

Syntax

Visual Basic for Applications (VBA)

Public Property Definition As String

SOLIDWORKS Type Library

Face Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property Face As [Face2](#)

SOLIDWORKS Type Library

HatchScope Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property HatchScope As Long

SOLIDWORKS Type Library

HatchType Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property HatchType As Long

SOLIDWORKS Type Library

Layer Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property Layer As String

SOLIDWORKS Type Library

Pattern Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property Pattern As String

SOLIDWORKS Type Library

PatternId Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property PatternId As Long

SOLIDWORKS Type Library

Scale Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property Scale As Double

SOLIDWORKS Type Library

Scale2 Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property Scale2 As Double

SOLIDWORKS Type Library

SolidFill Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property SolidFill As Boolean

SOLIDWORKS Type Library

UseMaterialHatch Property (FaceHatch)



Visual Basic for Applications (VBA)

Public Property UseMaterialHatch As Boolean

Facet (Type)

SOLIDWORKS Type Library

Facet Object

Object Model

Facet

SOLIDWORKS Type Library

Facet Object Members

Public Methods

- GetBody
- GetFacetEdges
- GetFacetVertices
- Select

SOLIDWORKS Type Library

GetBody Method (Facet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBody() As Object
```

SOLIDWORKS Type Library

GetFacetEdges Method (Facet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFacetEdges() As Variant
```

SOLIDWORKS Type Library

GetFacetVertices Method (Facet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFacetVertices() As Variant
```

SOLIDWORKS Type Library

Select Method (Facet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Select( _
    ByVal Append As Boolean, _
    ByVal Data As Object _
) As Boolean
```

FamilyTableAnnotation (Type)

SOLIDWORKS Type Library
FamilyTableAnnotation Object

Object Model

FamilyTableAnnotation

SOLIDWORKS Type Library
FamilyTableAnnotation Object Members

Public Methods

GetSheet

Public Properties

FamilyTableFeature

SOLIDWORKS Type Library
FamilyTableFeature Property (FamilyTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Property FamilyTableFeature As Object

SOLIDWORKS Type Library
GetSheet Method (FamilyTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Function GetSheet() As Object

FamilyTableFeature (Type)

SOLIDWORKS Type Library

FamilyTableFeature Object

Object Model

FamilyTableFeature

SOLIDWORKS Type Library

FamilyTableFeature Object Members

Public Methods

	GetConfigurations
	GetFeature
	GetFollowConfigTreeOrder
	GetModelName
	GetSequenceNumberIncrement
	GetSequenceStartNumber
	GetTableAnnotationCount
	GetTableAnnotations
	GetUseAllConfigurations
	SetConfigurations
	SetFollowConfigTreeOrder
	SetSequenceNumberIncrement
	SetSequenceStartNumber
	SetUseAllConfigurations

SOLIDWORKS Type Library

GetConfigurations Method (FamilyTableFeature)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetConfigurations( _
    ByVal Criteria As Long _
) As Variant
```

SOLIDWORKS Type Library

GetFeature Method (FamilyTableFeature)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFeature() As Object
```

SOLIDWORKS Type Library

GetFollowConfigTreeOrder Method (FamilyTableFeature)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFollowConfigTreeOrder() As Boolean
```

SOLIDWORKS Type Library

GetModelName Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetModelName() As String
```

SOLIDWORKS Type Library

GetSequenceNumberIncrement Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSequenceNumberIncrement() As Long
```

SOLIDWORKS Type Library

GetSequenceStartNumber Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSequenceStartNumber() As Long
```

SOLIDWORKS Type Library

GetTableAnnotationCount Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotationCount() As Long
```

SOLIDWORKS Type Library

GetTableAnnotations Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotations() As Variant
```

SOLIDWORKS Type Library

GetUseAllConfigurations Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUseAllConfigurations() As Boolean
```

SOLIDWORKS Type Library

SetConfigurations Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetConfigurations( _  
    ByVal ConfigArray As Variant, _  
    ByVal VisibilityArray As Variant _  
)
```

SOLIDWORKS Type Library

SetFollowConfigTreeOrder Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetFollowConfigTreeOrder( _  
    ByVal Flag As Boolean _  
)
```

SOLIDWORKS Type Library

SetSequenceNumberIncrement Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetSequenceNumberIncrement( _  
    ByVal Increment As Long _  
)
```

SOLIDWORKS Type Library

SetSequenceStartNumber Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetSequenceStartNumber( _  
    ByVal Start As Long _  
)
```

SOLIDWORKS Type Library

SetUseAllConfigurations Method (FamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)


```
Public Sub SetUseAllConfigurations( _  
    ByVal UseAllConfigs As Boolean _  
)
```

FaultEntity (Type)

SOLIDWORKS Type Library

FaultEntity Object

Object Model



SOLIDWORKS Type Library

FaultEntity Object Members

Public Properties

-  [Count](#)
-  [Entity](#)
-  [Entity2](#)
-  [ErrorCode](#)

SOLIDWORKS Type Library

Count Property (FaultEntity)

Syntax

Visual Basic for Applications (VBA)

Public Property Count As Long

SOLIDWORKS Type Library

Entity Property (FaultEntity)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Entity( _  
    ByVal Index As Long _  
) As Entity
```

SOLIDWORKS Type Library

Entity2 Property (FaultEntity)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Entity2( _  
    ByVal Index As Long _  
) As Object
```

SOLIDWORKS Type Library

ErrorCode Property (FaultEntity)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ErrorCode( _  
    ByVal Index As Long _  
) As Long
```