

SOLIDWORKS API (VB6 COM) — Reference (36/102): HelixFeatureData- IAdvancedSaveAsOptions

SOLIDWORKS API Documentation (converted from CHM)

HelixFeatureData (Type)

SOLIDWORKS Type Library
HelixFeatureData Object

Object Model

HelixFeatureData

SOLIDWORKS Type Library
HelixFeatureData Object Members

Public Methods

	AddLastRecord
	DeleteRecord
	GetRegionParameterAtIndex
	InsertRecord
	SetRegionParameterAtIndex

Public Properties

	Clockwise
	DefinedBy
	Height
	Pitch
	PitchCount
	ReverseDirection
	Revolution
	StartingAngle
	Taper
	TaperAngle
	TaperOutward
	VariablePitch

SOLIDWORKS Type Library
AddLastRecord Method (HelixFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AddLastRecord( _
    ByVal HelixPointValue As Variant _
) As Boolean
```

SOLIDWORKS Type Library
Clockwise Property (HelixFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Property Clockwise As Boolean
```

SOLIDWORKS Type Library
DefinedBy Property (HelixFeatureData)



Visual Basic for Applications (VBA)

Public Property DefinedBy As Long

SOLIDWORKS Type Library

DeleteRecord Method (HelixFeatureData)



Visual Basic for Applications (VBA)

```
Public Function DeleteRecord( _  
    ByVal Indices As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetRegionParameterAtIndex Method (HelixFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetRegionParameterAtIndex( _  
    ByVal Index As Long, _  
    ByVal RegionParameter As Long _  
    ) As Double
```

SOLIDWORKS Type Library

Height Property (HelixFeatureData)



Visual Basic for Applications (VBA)

Public Property Height As Double

SOLIDWORKS Type Library

InsertRecord Method (HelixFeatureData)



Visual Basic for Applications (VBA)

```
Public Function InsertRecord( _  
    ByVal Index As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

Pitch Property (HelixFeatureData)



Visual Basic for Applications (VBA)

Public Property Pitch As Double

SOLIDWORKS Type Library

PitchCount Property (HelixFeatureData)



Visual Basic for Applications (VBA)

Public Property PitchCount As Long

SOLIDWORKS Type Library

ReverseDirection Property (HelixFeatureData)



Visual Basic for Applications (VBA)

Public Property ReverseDirection As Boolean

SOLIDWORKS Type Library

Revolution Property (HelixFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Revolution As Double

SOLIDWORKS Type Library

SetRegionParameterAtIndex Method (HelixFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetRegionParameterAtIndex( _  
    ByVal Index As Long, _  
    ByVal Parameter As Long, _  
    ByVal PitchValue As Double _  
    ) As Long
```

SOLIDWORKS Type Library

StartingAngle Property (HelixFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property StartingAngle As Double

SOLIDWORKS Type Library

Taper Property (HelixFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Taper As Boolean

SOLIDWORKS Type Library

TaperAngle Property (HelixFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property TaperAngle As Double

SOLIDWORKS Type Library

TaperOutward Property (HelixFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property TaperOutward As Boolean

SOLIDWORKS Type Library

VariablePitch Property (HelixFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property VariablePitch As Boolean

HemFeatureData (Type)

SOLIDWORKS Type Library
HemFeatureData Object

Object Model

HemFeatureData

GetCustomBendAllowance (CustomBendAllowance)

SOLIDWORKS Type Library
HemFeatureData Object Members

Public Methods

	AccessSelections
	GetCustomBendAllowance
	GetEdgesCount
	IAccessSelections
	IGetEdges
	ISetEdges
	ReleaseSelectionAccess
	SetCustomBendAllowance

Public Properties

	Angle
	BendPosition
	Edges
	GapDistance
	Length
	MiterGap
	Radius
	ReverseDirection
	Type
	UseDefaultBendAllowance

SOLIDWORKS Type Library
AccessSelections Method (HemFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library
Angle Property (HemFeatureData)

Syntax

```
Visual Basic for Applications (VBA)
```

Public Property Angle As Double

SOLIDWORKS Type Library

BendPosition Property (HemFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property BendPosition As Long

SOLIDWORKS Type Library

Edges Property (HemFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property Edges As Variant

SOLIDWORKS Type Library

GapDistance Property (HemFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property GapDistance As Double

SOLIDWORKS Type Library

GetCustomBendAllowance Method (HemFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Function GetCustomBendAllowance() As [CustomBendAllowance](#)

SOLIDWORKS Type Library

GetEdgesCount Method (HemFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Function GetEdgesCount() As Long

SOLIDWORKS Type Library

IAccessSelections Method (HemFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetEdges Method (HemFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function IGetEdges( _  
    ByVal EdgeCount As Long _  
    ) As Object
```

SOLIDWORKS Type Library

ISetEdges Method (HemFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetEdges( _  
    ByVal EdgeCount As Long, _  
    ByRef EdgeArr As Object _  
)
```

SOLIDWORKS Type Library

Length Property (HemFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Length As Double
```

SOLIDWORKS Type Library

MiterGap Property (HemFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MiterGap As Double
```

SOLIDWORKS Type Library

Radius Property (HemFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Radius As Double
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (HemFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

ReverseDirection Property (HemFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ReverseDirection As Boolean
```

SOLIDWORKS Type Library

SetCustomBendAllowance Method (HemFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetCustomBendAllowance( _  
    ByVal PBendData As CustomBendAllowance _  
)
```

SOLIDWORKS Type Library

Type Property (HemFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Type As Long

SOLIDWORKS Type Library

UseDefaultBendAllowance Property (HemFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property UseDefaultBendAllowance As Boolean

HingeMateFeatureData (Type)

SOLIDWORKS Type Library
HingeMateFeatureData Object

Object Model

HingeMateFeatureData

SOLIDWORKS Type Library
HingeMateFeatureData Object Members

Public Properties

- Angle
- AngleSelection
- EntitiesToMate
- MateAlignment
- MaxVal
- MinVal

SOLIDWORKS Type Library
Angle Property (HingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Angle As Double
```

SOLIDWORKS Type Library
AngleSelection Property (HingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AngleSelection As Boolean
```

SOLIDWORKS Type Library
EntitiesToMate Property (HingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property EntitiesToMate( _  
    ByVal EntityType As Long _  
) As Variant
```

SOLIDWORKS Type Library
MateAlignment Property (HingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MateAlignment As Long
```

SOLIDWORKS Type Library
MaxVal Property (HingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MaxVal As Double

SOLIDWORKS Type Library

MinVal Property (HingeMateFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property MinVal As Double

HoleDataTable (Type)

SOLIDWORKS Type Library

HoleDataTable Object

Object Model

HoleDataTable

SOLIDWORKS Type Library

HoleDataTable Object Members

Public Methods

GetCellData

GetColumnNames

GetRowCount

GetRowData

Public Properties

FastenerID

StandardName

TableTypeID

SOLIDWORKS Type Library

FastenerID Property (HoleDataTable)

Syntax

Visual Basic for Applications (VBA)

Public Property FastenerID As Long

SOLIDWORKS Type Library

GetCellData Method (HoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCellData( _  
    ByVal ColumnName As String, _  
    ByVal RowIndex As Long, _  
    ByRef CellData As String _  
) As Boolean
```

SOLIDWORKS Type Library

GetColumnNames Method (HoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetColumnNames( _  
    ByRef ColumnNames As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

GetRowCount Method (HoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRowCount( _  
    ByRef RowCount As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetRowData Method (HoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRowData( _  
    ByVal RowIndex As Long, _  
    ByRef RowData As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

StandardName Property (HoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property StandardName As String
```

SOLIDWORKS Type Library

TableTypeID Property (HoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property TableTypeID As Long
```

HoleSeriesFeatureData (Type)

SOLIDWORKS Type Library

HoleSeriesFeatureData Object

Object Model

HoleSeriesFeatureData

IGetComponents (Component2)

IGetHoleBottomMateEntity (Entity)

IGetHoleTopMateEntity (Entity)

IGetSketchPoints (SketchPoint)

SOLIDWORKS Type Library

HoleSeriesFeatureData Object Members

Public Methods

	AccessSelections
	GetComponents
	GetComponentsCount
	GetHoleBottomMateEntity
	GetHoleTopMateEntity
	GetSketchPoints
	GetSketchPointsCount
	IAccessSelections
	IGetComponents
	IGetHoleBottomMateEntity
	IGetHoleTopMateEntity
	IGetSketchPoints
	ReleaseSelectionAccess

Public Properties

	BoltDiameter
	BoltHeadDiameter
	EndFace
	FastenerBottomHoleType
	FastenerDefaultUnits
	FastenerHoleCount
	FastenerTopHoleType
	Material
	NutDiameter
	Preload
	Size
	Standard



[StartFace](#)



[Type](#)

SOLIDWORKS Type Library

AccessSelections Method (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

BoltDiameter Property (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property BoltDiameter As Double
```

SOLIDWORKS Type Library

BoltHeadDiameter Property (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property BoltHeadDiameter As Double
```

SOLIDWORKS Type Library

EndFace Property (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property EndFace As Object
```

SOLIDWORKS Type Library

FastenerBottomHoleType Property (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerBottomHoleType As Integer
```

SOLIDWORKS Type Library

FastenerDefaultUnits Property (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerDefaultUnits As String
```

SOLIDWORKS Type Library

FastenerHoleCount Property (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerHoleCount As Long
```

SOLIDWORKS Type Library

FastenerTopHoleType Property (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Property FastenerTopHoleType As Integer
```

SOLIDWORKS Type Library

GetComponents Method (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetComponents() As Variant
```

SOLIDWORKS Type Library

GetComponentsCount Method (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetComponentsCount() As Long
```

SOLIDWORKS Type Library

GetHoleBottomMateEntity Method (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetHoleBottomMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Object
```

SOLIDWORKS Type Library

GetHoleTopMateEntity Method (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetHoleTopMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Object
```

SOLIDWORKS Type Library

GetSketchPoints Method (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPoints() As Variant
```

SOLIDWORKS Type Library

GetSketchPointsCount Method (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPointsCount() As Long
```

SOLIDWORKS Type Library

IAccessSelections Method (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetComponents Method (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetComponents( _  
    ByVal NCount As Long _  
    ) As Component2
```

SOLIDWORKS Type Library

IGetHoleBottomMateEntity Method (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetHoleBottomMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Entity
```

SOLIDWORKS Type Library

IGetHoleTopMateEntity Method (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetHoleTopMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Entity
```

SOLIDWORKS Type Library

IGetSketchPoints Method (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchPoints( _  
    ByVal NCount As Long _  
    ) As SketchPoint
```

SOLIDWORKS Type Library

Material Property (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Material As String
```

SOLIDWORKS Type Library

NutDiameter Property (HoleSeriesFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property NutDiameter As Double
```

SOLIDWORKS Type Library

Preload Property (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Preload As String
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

Size Property (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Size( _  
    ByVal HoleSeriesWhichPart As Long _  
    ) As String
```

SOLIDWORKS Type Library

Standard Property (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Standard As Long
```

SOLIDWORKS Type Library

StartFace Property (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)

```
Public Property StartFace As Object
```

SOLIDWORKS Type Library

Type Property (HoleSeriesFeatureData)



Visual Basic for Applications (VBA)


```
Public Property Type( _  
    ByVal HoleSeriesWhichPart As Long _  
    ) As Long
```

HoleSeriesFeatureData2 (Type)

SOLIDWORKS Type Library

HoleSeriesFeatureData2 Object

Object Model



SOLIDWORKS Type Library

HoleSeriesFeatureData2 Object Members

Public Methods

	AccessSelections
	GetComponents
	GetComponentsCount
	GetHoleBottomMateEntity
	GetHoleTopMateEntity
	GetSketchPoints
	GetSketchPointsCount
	IAccessSelections
	IGetComponents
	IGetHoleBottomMateEntity
	IGetHoleTopMateEntity
	IGetSketchPoints
	ReleaseSelectionAccess

Public Properties

	BoltDiameter
	BoltHeadDiameter
	EndFace
	FastenerBottomHoleType
	FastenerDefaultUnits
	FastenerHoleCount
	FastenerTopHoleType
	Material
	NutDiameter
	Preload
	Size
	Standard



[StartFace](#)



[Type](#)

SOLIDWORKS Type Library

AccessSelections Method (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

BoltDiameter Property (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property BoltDiameter As Double
```

SOLIDWORKS Type Library

BoltHeadDiameter Property (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property BoltHeadDiameter As Double
```

SOLIDWORKS Type Library

EndFace Property (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property EndFace As Object
```

SOLIDWORKS Type Library

FastenerBottomHoleType Property (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerBottomHoleType As Integer
```

SOLIDWORKS Type Library

FastenerDefaultUnits Property (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerDefaultUnits As String
```

SOLIDWORKS Type Library

FastenerHoleCount Property (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerHoleCount As Long
```

SOLIDWORKS Type Library

FastenerTopHoleType Property (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Property FastenerTopHoleType As Integer
```

SOLIDWORKS Type Library

GetComponents Method (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetComponents() As Variant
```

SOLIDWORKS Type Library

GetComponentsCount Method (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetComponentsCount() As Long
```

SOLIDWORKS Type Library

GetHoleBottomMateEntity Method (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetHoleBottomMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Object
```

SOLIDWORKS Type Library

GetHoleTopMateEntity Method (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetHoleTopMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Object
```

SOLIDWORKS Type Library

GetSketchPoints Method (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPoints() As Variant
```

SOLIDWORKS Type Library

GetSketchPointsCount Method (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPointsCount() As Long
```

SOLIDWORKS Type Library

IAccessSelections Method (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetComponents Method (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetComponents( _  
    ByVal NCount As Long _  
    ) As Component2
```

SOLIDWORKS Type Library

IGetHoleBottomMateEntity Method (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetHoleBottomMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Entity
```

SOLIDWORKS Type Library

IGetHoleTopMateEntity Method (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetHoleTopMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Entity
```

SOLIDWORKS Type Library

IGetSketchPoints Method (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchPoints( _  
    ByVal NCount As Long _  
    ) As SketchPoint
```

SOLIDWORKS Type Library

Material Property (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Material As String
```

SOLIDWORKS Type Library

NutDiameter Property (HoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property NutDiameter As Double
```

SOLIDWORKS Type Library

Preload Property (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Property Preload As String
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

Size Property (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Property Size( _  
    ByVal HoleSeriesWhichPart As Long _  
) As String
```

SOLIDWORKS Type Library

Standard Property (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Property Standard As Long
```

SOLIDWORKS Type Library

StartFace Property (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Property StartFace As Object
```

SOLIDWORKS Type Library

Type Property (HoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Property Type( _  
    ByVal HoleSeriesWhichPart As Long _  
) As Long
```

HoleStandardsData (Type)

SOLIDWORKS Type Library
HoleStandardsData Object

Object Model

HoleStandardsData

SOLIDWORKS Type Library
HoleStandardsData Object Members

Public Methods

- GetFastenerTable
- GetFastenerTableTypes
- GetFastenerTypes
- GetHoleStandards

SOLIDWORKS Type Library
GetFastenerTable Method (HoleStandardsData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFastenerTable( _
    ByVal StandardName As String, _
    ByVal FastenerID As Long, _
    ByVal TableID As Long, _
    ByRef HoleTable As Object _
) As Boolean
```

SOLIDWORKS Type Library
GetFastenerTableTypes Method (HoleStandardsData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFastenerTableTypes( _
    ByVal StandardName As String, _
    ByVal FastenerID As Long, _
    ByRef FastenerTableTypeIDs As Variant _
) As Boolean
```

SOLIDWORKS Type Library
GetFastenerTypes Method (HoleStandardsData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFastenerTypes( _
    ByVal StandardName As String, _
    ByRef FastenerIndexes As Variant, _
    ByRef FastenerNames As Variant _
) As Boolean
```

SOLIDWORKS Type Library
GetHoleStandards Method (HoleStandardsData)

Syntax

```
Visual Basic for Applications (VBA)
```


```
Public Function GetHoleStandards( _  
    ByRef Indexes As Variant, _  
    ByRef Names As Variant _  
) As Boolean
```

HoleTable (Type)

SOLIDWORKS Type Library

HoleTable Object

Object Model



SOLIDWORKS Type Library

HoleTable Object Members

Public Methods

	AddHole
	AssignTagPrefix
	GetFeature
	GetHoleLocationPrecision
	GetHoleLocationUseDocPrecision
	GetTableAnnotationCount
	GetTableAnnotations
	IGetTableAnnotations
	SetHoleLocationPrecision

Public Properties

	CombineSameSize
	CombineTags
	DatumOrigin
	EnableUpdate
	HoleCentersVisible
	HoleTag
	HoleTagsVisible
	ShowANSIInchLetterNumberDrillSizes
	StartingValue
	TagStyle

SOLIDWORKS Type Library

AddHole Method (HoleTable)

Syntax

Visual Basic for Applications (VBA)
Public Function AddHole() As Long

SOLIDWORKS Type Library

AssignTagPrefix Method (HoleTable)



Visual Basic for Applications (VBA)

```
Public Function AssignTagPrefix( _  
    ByVal Index As Long, _  
    ByVal TagPrefix As String, _  
    ByVal ApplyTo As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

CombineSameSize Property (HoleTable)



Visual Basic for Applications (VBA)

```
Public Property CombineSameSize As Boolean
```

SOLIDWORKS Type Library

CombineTags Property (HoleTable)



Visual Basic for Applications (VBA)

```
Public Property CombineTags As Boolean
```

SOLIDWORKS Type Library

DatumOrigin Property (HoleTable)



Visual Basic for Applications (VBA)

```
Public Property DatumOrigin As DatumOrigin
```

SOLIDWORKS Type Library

EnableUpdate Property (HoleTable)



Visual Basic for Applications (VBA)

```
Public Property EnableUpdate As Boolean
```

SOLIDWORKS Type Library

GetFeature Method (HoleTable)



Visual Basic for Applications (VBA)

```
Public Function GetFeature() As Feature
```

SOLIDWORKS Type Library

GetHoleLocationPrecision Method (HoleTable)



Visual Basic for Applications (VBA)

```
Public Function GetHoleLocationPrecision() As Long
```

SOLIDWORKS Type Library

GetHoleLocationUseDocPrecision Method (HoleTable)



Visual Basic for Applications (VBA)

```
Public Function GetHoleLocationUseDocPrecision() As Boolean
```

SOLIDWORKS Type Library

GetTableAnnotationCount Method (HoleTable)



Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotationCount() As Long
```

SOLIDWORKS Type Library

GetTableAnnotations Method (HoleTable)



Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotations() As Variant
```

SOLIDWORKS Type Library

HoleCentersVisible Property (HoleTable)



Visual Basic for Applications (VBA)

```
Public Property HoleCentersVisible As Boolean
```

SOLIDWORKS Type Library

HoleTag Property (HoleTable)



Visual Basic for Applications (VBA)

```
Public Property HoleTag( _  
    ByVal Row As Long _  
) As String
```

SOLIDWORKS Type Library

HoleTagsVisible Property (HoleTable)



Visual Basic for Applications (VBA)

```
Public Property HoleTagsVisible As Boolean
```

SOLIDWORKS Type Library

IGetTableAnnotations Method (HoleTable)



Visual Basic for Applications (VBA)

```
Public Function IGetTableAnnotations( _  
    ByVal Count As Long _  
) As HoleTableAnnotation
```

SOLIDWORKS Type Library

SetHoleLocationPrecision Method (HoleTable)



Visual Basic for Applications (VBA)

```
Public Function SetHoleLocationPrecision( _  
    ByVal UseDoc As Boolean, _  
    ByVal Precision As Long _  
) As Boolean
```

SOLIDWORKS Type Library

ShowANSInchLetterNumberDrillSizes Property (HoleTable)



Visual Basic for Applications (VBA)

Public Property ShowANSIIInchLetterNumberDrillSizes As Boolean

SOLIDWORKS Type Library

StartingValue Property (HoleTable)



Visual Basic for Applications (VBA)

Public Property StartingValue As String

SOLIDWORKS Type Library

TagStyle Property (HoleTable)




Visual Basic for Applications (VBA)

Public Property TagStyle As Long

HoleTableAnnotation (Type)

SOLIDWORKS Type Library
HoleTableAnnotation Object



SOLIDWORKS Type Library
HoleTableAnnotation Object Members

Public Methods

[Sort](#)

Public Properties

[HoleTable](#)

SOLIDWORKS Type Library
HoleTable Property (HoleTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Property HoleTable As [HoleTable](#)

SOLIDWORKS Type Library
Sort Method (HoleTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Sort( _  
    ByVal ColumnIndex As Long, _  
    ByVal SortAscending As Boolean _  
) As Boolean
```

IAdvancedHoleElementData (Type)

SOLIDWORKS Type Library

IAdvancedHoleElementData Object

Object Model

IAdvancedHoleElementData

SOLIDWORKS Type Library

IAdvancedHoleElementData Object Members

Public Properties

BlindDepth

CalloutString

Diameter

DiameterOverride

ElementType

EndCondition

FastenerType

OffsetDistance

OffsetReverseDirection

Orientation

SelectionEntity

Size

Standard

SOLIDWORKS Type Library

BlindDepth Property (IAdvancedHoleElementData)

Syntax

Visual Basic for Applications (VBA)

Public Property BlindDepth As Double

SOLIDWORKS Type Library

CalloutString Property (IAdvancedHoleElementData)

Syntax

Visual Basic for Applications (VBA)

Public Property CalloutString As String

SOLIDWORKS Type Library

Diameter Property (IAdvancedHoleElementData)

Syntax

Visual Basic for Applications (VBA)

Public Property Diameter As Double

SOLIDWORKS Type Library

DiameterOverride Property (IAdvancedHoleElementData)

Syntax

Public Property DiameterOverride As Boolean

SOLIDWORKS Type Library

ElementType Property (IAdvancedHoleElementData)



Public Property ElementType As Long

SOLIDWORKS Type Library

EndCondition Property (IAdvancedHoleElementData)



Public Property EndCondition As Long

SOLIDWORKS Type Library

FastenerType Property (IAdvancedHoleElementData)



Public Property FastenerType As Long

SOLIDWORKS Type Library

OffsetDistance Property (IAdvancedHoleElementData)



Public Property OffsetDistance As Double

SOLIDWORKS Type Library

OffsetReverseDirection Property (IAdvancedHoleElementData)



Public Property OffsetReverseDirection As Boolean

SOLIDWORKS Type Library

Orientation Property (IAdvancedHoleElementData)



Public Property Orientation As Long

SOLIDWORKS Type Library

SelectionEntity Property (IAdvancedHoleElementData)



Public Property SelectionEntity As Object

SOLIDWORKS Type Library

Size Property (IAdvancedHoleElementData)



Public Property Size As String

SOLIDWORKS Type Library

Standard Property (IAdvancedHoleElementData)



Syntax

Visual Basic for Applications (VBA)

Public Property Standard As Long

IAdvancedHoleFeatureData (Type)

SOLIDWORKS Type Library
IAdvancedHoleFeatureData Object

 Object Model

IAdvancedHoleFeatureData

SOLIDWORKS Type Library
IAdvancedHoleFeatureData Object Members

 Public Methods

 AccessSelections
 GetFarSideElements
 GetNearSideElements
 ReleaseSelectionAccess
 SetFarSideElements
 SetNearSideElements

 Public Properties

 CustomizeCallout
 FarSideElementsCount
 NearSideElementsCount
 UseBaselineDimensions

SOLIDWORKS Type Library
AccessSelections Method (IAdvancedHoleFeatureData)

 Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AccessSelections(_ ByVal TopDoc As Object, _ ByVal Component As Object _) As Boolean</pre>

SOLIDWORKS Type Library
CustomizeCallout Property (IAdvancedHoleFeatureData)

 Syntax

Visual Basic for Applications (VBA)
<pre>Public Property CustomizeCallout As Boolean</pre>

SOLIDWORKS Type Library
FarSideElementsCount Property (IAdvancedHoleFeatureData)

 Syntax

Visual Basic for Applications (VBA)
<pre>Public Property FarSideElementsCount As Long</pre>

SOLIDWORKS Type Library
GetFarSideElements Method (IAdvancedHoleFeatureData)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFarSideElements() As Variant
```

SOLIDWORKS Type Library

GetNearSideElements Method (IAdvancedHoleFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetNearSideElements() As Variant
```

SOLIDWORKS Type Library

NearSideElementsCount Property (IAdvancedHoleFeatureData)



Visual Basic for Applications (VBA)

```
Public Property NearSideElementsCount As Long
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IAdvancedHoleFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SetFarSideElements Method (IAdvancedHoleFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub SetFarSideElements( _  
    ByVal ElmArray As Variant _  
)
```

SOLIDWORKS Type Library

SetNearSideElements Method (IAdvancedHoleFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub SetNearSideElements( _  
    ByVal ElmArray As Variant _  
)
```

SOLIDWORKS Type Library

UseBaselineDimensions Property (IAdvancedHoleFeatureData)



Visual Basic for Applications (VBA)

```
Public Property UseBaselineDimensions As Boolean
```

IAdvancedSaveAsOptions (Type)

SOLIDWORKS Type Library

IAdvancedSaveAsOptions Object

Object Model

IAdvancedSaveAsOptions

SOLIDWORKS Type Library

IAdvancedSaveAsOptions Object Members

Public Methods

 [GetItemsNameAndPath](#)

 [ModifyItemsNameAndPath](#)

 [SetPrefixSuffixToAll](#)

Public Properties

 [ConfigurationsToSave](#)

 [Description](#)

 [GeometryToSave](#)

 [OverrideDefaults](#)

 [PreserveGeometryReferences](#)

 [SaveAllAsCopy](#)

 [SaveAsPreviousVersion](#)

SOLIDWORKS Type Library

ConfigurationsToSave Property (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property ConfigurationsToSave

SOLIDWORKS Type Library

Description Property (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property Description

SOLIDWORKS Type Library

GeometryToSave Property (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property GeometryToSave

SOLIDWORKS Type Library

GetItemsNameAndPath Method (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetItemsNameAndPath( _  
    ByRef IdsList As Variant, _  
    ByRef NamesList As Variant, _  
    ByRef PathsList As Variant _  
)
```

SOLIDWORKS Type Library

ModifyItemsNameAndPath Method (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ModifyItemsNameAndPath( _  
    ByVal IdsList As Variant, _  
    ByVal NamesList As Variant, _  
    ByVal PathsList As Variant _  
) As Long
```

SOLIDWORKS Type Library

OverrideDefaults Property (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OverrideDefaults
```

SOLIDWORKS Type Library

PreserveGeometryReferences Property (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PreserveGeometryReferences
```

SOLIDWORKS Type Library

SaveAllAsCopy Property (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SaveAllAsCopy
```

SOLIDWORKS Type Library

SaveAsPreviousVersion Property (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SaveAsPreviousVersion
```

SOLIDWORKS Type Library

SetPrefixSuffixToAll Method (IAdvancedSaveAsOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetPrefixSuffixToAll( _  
    ByVal PrefixString As String, _  
    ByVal SuffixString As String _  
)
```