

SOLIDWORKS API (VB6 COM) — Reference (38/102): ICalloutVariable-ICornerReliefFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ICalloutVariable (Type)

SOLIDWORKS Type Library

ICalloutVariable Object

Object Model

ICalloutVariable

SOLIDWORKS Type Library

ICalloutVariable Object Members

Public Properties

 FitDisplayStyle
 FitTextHeight
 FitTextScale
 FitType
 FitUseTextScale
 HoleFit
 ShaftFit
 ShowParenthesis
 TextHeight
 TextScale
 ToleranceMax
 ToleranceMin
 ToleranceType
 Type
 UserReadableVariableName
 UseTextScale
 VariableName
 VariableType

SOLIDWORKS Type Library

FitDisplayStyle Property (ICalloutVariable)

Syntax

Visual Basic for Applications (VBA)

Public Property FitDisplayStyle As Long

SOLIDWORKS Type Library

FitTextHeight Property (ICalloutVariable)

Syntax

Visual Basic for Applications (VBA)

Public Property FitTextHeight As Double

SOLIDWORKS Type Library

FitTextScale Property (ICalloutVariable)

Syntax

Visual Basic for Applications (VBA)

Public Property FitTextScale As Double

SOLIDWORKS Type Library

FitType Property (ICalloutVariable)



Visual Basic for Applications (VBA)

Public Property FitType As Long

SOLIDWORKS Type Library

FitUseTextScale Property (ICalloutVariable)



Visual Basic for Applications (VBA)

Public Property FitUseTextScale As Boolean

SOLIDWORKS Type Library

HoleFit Property (ICalloutVariable)



Visual Basic for Applications (VBA)

Public Property HoleFit As String

SOLIDWORKS Type Library

ShaftFit Property (ICalloutVariable)



Visual Basic for Applications (VBA)

Public Property ShaftFit As String

SOLIDWORKS Type Library

ShowParenthesis Property (ICalloutVariable)



Visual Basic for Applications (VBA)

Public Property ShowParenthesis As Boolean

SOLIDWORKS Type Library

TextHeight Property (ICalloutVariable)



Visual Basic for Applications (VBA)

Public Property TextHeight As Double

SOLIDWORKS Type Library

TextScale Property (ICalloutVariable)



Visual Basic for Applications (VBA)

Public Property TextScale As Double

SOLIDWORKS Type Library

ToleranceMax Property (ICalloutVariable)



Visual Basic for Applications (VBA)

Public Property ToleranceMax As Double

SOLIDWORKS Type Library

ToleranceMin Property (ICalloutVariable)



Syntax

Visual Basic for Applications (VBA)

Public Property ToleranceMin As Double

SOLIDWORKS Type Library

ToleranceType Property (ICalloutVariable)



Syntax

Visual Basic for Applications (VBA)

Public Property ToleranceType As Long

SOLIDWORKS Type Library

Type Property (ICalloutVariable)



Syntax

Visual Basic for Applications (VBA)

Public Property Type As Long

SOLIDWORKS Type Library

UserReadableVariableName Property (ICalloutVariable)



Syntax

Visual Basic for Applications (VBA)

Public Property UserReadableVariableName As String

SOLIDWORKS Type Library

UseTextScale Property (ICalloutVariable)



Syntax

Visual Basic for Applications (VBA)

Public Property UseTextScale As Boolean

SOLIDWORKS Type Library

VariableName Property (ICalloutVariable)



Syntax

Visual Basic for Applications (VBA)

Public Property VariableName As String

SOLIDWORKS Type Library

VariableType Property (ICalloutVariable)



Syntax

Visual Basic for Applications (VBA)

Public Property VariableType As Long

ICamFollowerMateFeatureData (Type)

SOLIDWORKS Type Library
ICamFollowerMateFeatureData Object

 Object Model

ICamFollowerMateFeatureData

SOLIDWORKS Type Library
ICamFollowerMateFeatureData Object Members



 Public Properties

 [EntitiesToMate](#)

 [MateAlignment](#)

SOLIDWORKS Type Library
EntitiesToMate Property (ICamFollowerMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property EntitiesToMate( _  
    ByVal EntityType As Long _  
) As Object
```

SOLIDWORKS Type Library
MateAlignment Property (ICamFollowerMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property MateAlignment As Long
```

ICenterOfMass (Type)

SOLIDWORKS Type Library

ICenterOfMass Object

 Object Model

ICenterOfMass

IGetAnnotation (Annotation)

IGetNext (CenterOfMass)

SOLIDWORKS Type Library

ICenterOfMass Object Members



 Public Methods

 [GetAnnotation](#)

 [GetCoordinates](#)

 [GetNext](#)

 [IGetAnnotation](#)

 [IGetCoordinates](#)

 [IGetNext](#)

SOLIDWORKS Type Library

GetAnnotation Method (ICenterOfMass)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotation() As Object
```

SOLIDWORKS Type Library

GetCoordinates Method (ICenterOfMass)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCoordinates() As Variant
```

SOLIDWORKS Type Library

GetNext Method (ICenterOfMass)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext() As Object
```

SOLIDWORKS Type Library

IGetAnnotation Method (ICenterOfMass)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAnnotation() As Annotation
```

SOLIDWORKS Type Library

IGetCoordinates Method (ICenterOfMass)



Visual Basic for Applications (VBA)

```
Public Function IGetCoordinates() As Double
```

SOLIDWORKS Type Library

IGetNext Method (ICenterOfMass)



Visual Basic for Applications (VBA)

```
Public Function IGetNext() As CenterOfMass
```

IChainPatternFeatureData (Type)

SOLIDWORKS Type Library

IChainPatternFeatureData Object

Object Model

IChainPatternFeatureData

SOLIDWORKS Type Library

IChainPatternFeatureData Object Members

Public Methods

	AccessSelections
	ClearGroup2Selections
	ReleaseSelectionAccess
	SetEqualSpacing

Public Properties

	AlignMethod
	FillPath
	ForceUseSeedConfiguration
	Group1FlipPlane
	Group1PathLink1
	Group1PathLink2
	Group1PathPlane
	Group1PatternComponent
	Group2FlipPlane
	Group2PathLink1
	Group2PathLink2
	Group2PathPlane
	Group2PatternComponent
	InstanceCount
	Options
	Path
	PathPlaneReference
	PitchMethod
	ReverseDirection
	Spacing

SOLIDWORKS Type Library

AccessSelections Method (IChainPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

AlignMethod Property (IChainPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property AlignMethod As Long
```

SOLIDWORKS Type Library

ClearGroup2Selections Method (IChainPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ClearGroup2Selections() As Boolean
```

SOLIDWORKS Type Library

FillPath Property (IChainPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property FillPath As Boolean
```

SOLIDWORKS Type Library

ForceUseSeedConfiguration Property (IChainPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property ForceUseSeedConfiguration As Boolean
```

SOLIDWORKS Type Library

Group1FlipPlane Property (IChainPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property Group1FlipPlane As Boolean
```

SOLIDWORKS Type Library

Group1PathLink1 Property (IChainPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property Group1PathLink1 As Object
```

SOLIDWORKS Type Library

Group1PathLink2 Property (IChainPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property Group1PathLink2 As Object
```

SOLIDWORKS Type Library

Group1PathPlane Property (IChainPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Group1PathPlane As Object
```

SOLIDWORKS Type Library

Group1PatternComponent Property (IChainPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Group1PatternComponent As Object
```

SOLIDWORKS Type Library

Group2FlipPlane Property (IChainPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Group2FlipPlane As Boolean
```

SOLIDWORKS Type Library

Group2PathLink1 Property (IChainPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Group2PathLink1 As Object
```

SOLIDWORKS Type Library

Group2PathLink2 Property (IChainPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Group2PathLink2 As Object
```

SOLIDWORKS Type Library

Group2PathPlane Property (IChainPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Group2PathPlane As Object
```

SOLIDWORKS Type Library

Group2PatternComponent Property (IChainPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Group2PatternComponent As Object
```

SOLIDWORKS Type Library

InstanceCount Property (IChainPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property InstanceCount As Long
```

SOLIDWORKS Type Library

Options Property (IChainPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property Options As Long

SOLIDWORKS Type Library

Path Property (IChainPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property Path As Object

SOLIDWORKS Type Library

PathPlaneReference Property (IChainPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property PathPlaneReference As Object

SOLIDWORKS Type Library

PitchMethod Property (IChainPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property PitchMethod As Long

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IChainPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Sub ReleaseSelectionAccess()

SOLIDWORKS Type Library

ReverseDirection Property (IChainPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property ReverseDirection As Boolean

SOLIDWORKS Type Library

SetEqualSpacing Method (IChainPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Function SetEqualSpacing() As Boolean

SOLIDWORKS Type Library

Spacing Property (IChainPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property Spacing As Double

IClearanceResult (Type)

SOLIDWORKS Type Library
IClearanceResult Object

Object Model

IClearanceResult

SOLIDWORKS Type Library
IClearanceResult Object Members

Public Properties

- ClearanceType
- ClearanceValue
- ComponentsOrFaces

SOLIDWORKS Type Library
ClearanceType Property (IClearanceResult)

Syntax

Visual Basic for Applications (VBA)

Public Property ClearanceType As Long

SOLIDWORKS Type Library
ClearanceValue Property (IClearanceResult)

Syntax

Visual Basic for Applications (VBA)

Public Property ClearanceValue As Double

SOLIDWORKS Type Library
ComponentsOrFaces Property (IClearanceResult)

Syntax

Visual Basic for Applications (VBA)

Public Property ComponentsOrFaces As Variant

IClearanceVerificationMgr (Type)

SOLIDWORKS Type Library

IClearanceVerificationMgr Object

Object Model

IClearanceVerificationMgr

SOLIDWORKS Type Library

IClearanceVerificationMgr Object Members

Public Methods

- CalculateClearances
- GetComponentsOrFacesToCheck
- GetMinimumAcceptableClearance
- SetComponentsOrFacesToCheck
- SetMinimumAcceptableClearance

Public Properties

- CheckClearanceBetween
- IgnoreClearanceEqualToSpecifiedValue
- TreatSubAssembliesAsComponents

SOLIDWORKS Type Library

CalculateClearances Method (IClearanceVerificationMgr)

Syntax

Visual Basic for Applications (VBA)

Public Function CalculateClearances() As Variant

SOLIDWORKS Type Library

CheckClearanceBetween Property (IClearanceVerificationMgr)

Syntax

Visual Basic for Applications (VBA)

Public Property CheckClearanceBetween As Long

SOLIDWORKS Type Library

GetComponentsOrFacesToCheck Method (IClearanceVerificationMgr)

Syntax

Visual Basic for Applications (VBA)

Public Function GetComponentsOrFacesToCheck() As Variant

SOLIDWORKS Type Library

GetMinimumAcceptableClearance Method (IClearanceVerificationMgr)

Syntax

Visual Basic for Applications (VBA)

Public Function GetMinimumAcceptableClearance() As Double

SOLIDWORKS Type Library

IgnoreClearanceEqualToSpecifiedValue Property (IClearanceVerificationMgr)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IgnoreClearanceEqualToSpecifiedValue As Boolean
```

SOLIDWORKS Type Library

SetComponentsOrFacesToCheck Method (IClearanceVerificationMgr)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetComponentsOrFacesToCheck( _  
    ByVal Components As Variant, _  
    ByVal Faces As Variant, _  
    ByRef Errors As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetMinimumAcceptableClearance Method (IClearanceVerificationMgr)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetMinimumAcceptableClearance( _  
    ByVal Value As Double _  
) As Boolean
```

SOLIDWORKS Type Library

TreatSubAssembliesAsComponents Property (IClearanceVerificationMgr)

Syntax

Visual Basic for Applications (VBA)

```
Public Property TreatSubAssembliesAsComponents As Boolean
```

ICoincidentMateFeatureData (Type)

SOLIDWORKS Type Library

ICoincidentMateFeatureData Object

 Object Model

ICoincidentMateFeatureData

SOLIDWORKS Type Library

ICoincidentMateFeatureData Object Members



 Public Properties

-  [EntitiesToMate](#)
-  [MateAlignment](#)
-  [PickPoints](#)

SOLIDWORKS Type Library

EntitiesToMate Property (ICoincidentMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property EntitiesToMate As Variant
```

SOLIDWORKS Type Library

MateAlignment Property (ICoincidentMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property MateAlignment As Long
```

SOLIDWORKS Type Library

PickPoints Property (ICoincidentMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property PickPoints As Variant
```

ICollision (Type)

SOLIDWORKS Type Library

ICollision Object

Object Model

ICollision

SOLIDWORKS Type Library

ICollision Object Members

Public Methods

 [GetComponents](#)

 [GetTransforms](#)

 [IsPenetrating](#)

SOLIDWORKS Type Library

GetComponents Method (ICollision)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetComponents() As Variant
```

SOLIDWORKS Type Library

GetTransforms Method (ICollision)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTransforms() As Variant
```

SOLIDWORKS Type Library

IsPenetrating Method (ICollision)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsPenetrating() As Boolean
```

ICollisionDetectionGroup (Type)

SOLIDWORKS Type Library

ICollisionDetectionGroup Object

Object Model

ICollisionDetectionGroup

SOLIDWORKS Type Library

ICollisionDetectionGroup Object Members

Public Methods

ApplyTransforms

GetComponentCount

GetComponents

GetTransforms

RemoveAllTransforms

SetComponents

SOLIDWORKS Type Library

ApplyTransforms Method (ICollisionDetectionGroup)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ApplyTransforms( _  
    ByVal ComponentTransforms As Variant _  
) As Long
```

SOLIDWORKS Type Library

GetComponentCount Method (ICollisionDetectionGroup)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetComponentCount() As Long
```

SOLIDWORKS Type Library

GetComponents Method (ICollisionDetectionGroup)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetComponents() As Variant
```

SOLIDWORKS Type Library

GetTransforms Method (ICollisionDetectionGroup)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTransforms() As Variant
```

SOLIDWORKS Type Library

RemoveAllTransforms Method (ICollisionDetectionGroup)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveAllTransforms()
```

SOLIDWORKS Type Library

SetComponents Method (ICollisionDetectionGroup)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetComponents( _  
    ByVal Components As Variant _  
) As Long
```

ICollisionDetectionManager (Type)

SOLIDWORKS Type Library

ICollisionDetectionManager Object

Object Model

ICollisionDetectionManager

SOLIDWORKS Type Library

ICollisionDetectionManager Object Members

Public Methods

CreateGroup

GetAssembly

GetCollisions

GetGroup

GetGroupCount

IsCollisionPresent

RemoveGroup

SetAssembly

Public Properties

GraphicsRedrawEnabled

SOLIDWORKS Type Library

CreateGroup Method (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

Public Function CreateGroup() As Object

SOLIDWORKS Type Library

GetAssembly Method (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

Public Function GetAssembly() As Object

SOLIDWORKS Type Library

GetCollisions Method (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

Public Function GetCollisions(_
 ByVal *TreatContactAsCollision* As Boolean, _
 ByRef *Collisions* As Variant _
) As Long

SOLIDWORKS Type Library

GetGroup Method (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetGroup( _  
    ByVal GroupIndex As Long _  
) As Object
```

SOLIDWORKS Type Library

GetGroupCount Method (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetGroupCount() As Long
```

SOLIDWORKS Type Library

GraphicsRedrawEnabled Property (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Property GraphicsRedrawEnabled As Boolean
```

SOLIDWORKS Type Library

IsCollisionPresent Method (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsCollisionPresent( _  
    ByVal TreatContactAsCollision As Boolean _  
) As Long
```

SOLIDWORKS Type Library

RemoveGroup Method (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveGroup( _  
    ByVal GroupIndex As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetAssembly Method (ICollisionDetectionManager)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetAssembly( _  
    ByVal OwnerAssem As Object _  
) As Long
```

IComplexCornerTreatmentFeatureData (Type)

SOLIDWORKS Type Library

IComplexCornerTreatmentFeatureData Object

Object Model

IComplexCornerTreatmentFeatureData

SOLIDWORKS Type Library

IComplexCornerTreatmentFeatureData Object Members

Public Methods

 [GetBodyTrimMembers](#)

 [GetPlanarTrimMembers](#)

 [GetTrimToolMember](#)

 [SetBodyTrimMembers](#)

 [SetPlanarTrimMembers](#)

 [SetTrimToolMember](#)

Public Properties

 [PlanarTrimOption](#)

 [PlanarTrimToolType](#)

 [UserDefinedTrimFaces](#)

SOLIDWORKS Type Library

GetBodyTrimMembers Method (IComplexCornerTreatmentFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBodyTrimMembers() As Variant
```

SOLIDWORKS Type Library

GetPlanarTrimMembers Method (IComplexCornerTreatmentFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPlanarTrimMembers() As Variant
```

SOLIDWORKS Type Library

GetTrimToolMember Method (IComplexCornerTreatmentFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTrimToolMember( _  
    ByRef MemberObjType As Long _  
) As Object
```

SOLIDWORKS Type Library

PlanarTrimOption Property (IComplexCornerTreatmentFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property PlanarTrimOption As Long

SOLIDWORKS Type Library

PlanarTrimToolType Property (IComplexCornerTreatmentFeatureData)



Visual Basic for Applications (VBA)

Public Property PlanarTrimToolType As Long

SOLIDWORKS Type Library

SetBodyTrimMembers Method (IComplexCornerTreatmentFeatureData)



Visual Basic for Applications (VBA)

```
Public Function SetBodyTrimMembers( _  
    ByVal BodyMemList As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SetPlanarTrimMembers Method (IComplexCornerTreatmentFeatureData)



Visual Basic for Applications (VBA)

```
Public Function SetPlanarTrimMembers( _  
    ByVal PlanarMemList As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SetTrimToolMember Method (IComplexCornerTreatmentFeatureData)



Visual Basic for Applications (VBA)

```
Public Function SetTrimToolMember( _  
    ByVal Member As Object _  
) As Boolean
```

SOLIDWORKS Type Library

UserDefinedTrimFaces Property (IComplexCornerTreatmentFeatureData)



Visual Basic for Applications (VBA)

Public Property UserDefinedTrimFaces As Variant

IConcentricMateFeatureData (Type)

SOLIDWORKS Type Library

IConcentricMateFeatureData Object

Object Model

IConcentricMateFeatureData

SOLIDWORKS Type Library

IConcentricMateFeatureData Object Members

Public Properties

EntitiesToMate

LockRotation

MateAlignment

PickPoints

SOLIDWORKS Type Library

EntitiesToMate Property (IConcentricMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property EntitiesToMate As Variant

SOLIDWORKS Type Library

LockRotation Property (IConcentricMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property LockRotation As Boolean

SOLIDWORKS Type Library

MateAlignment Property (IConcentricMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MateAlignment As Long

SOLIDWORKS Type Library

PickPoints Property (IConcentricMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property PickPoints As Variant

ICorrelationPointFeatureData (Type)

SOLIDWORKS Type Library

ICorrelationPointFeatureData Object

Object Model

ICorrelationPointFeatureData

SOLIDWORKS Type Library

ICorrelationPointFeatureData Object Members

Public Methods

- AccessSelections
- IAccessSelections
- ReleaseSelectionAccess

Public Properties

- Direction
- ElectricalPinID
- Location
- Name2
- PortID
- RouteDiameter
- RouteSubType
- RouteType
- StubLength

SOLIDWORKS Type Library

AccessSelections Method (ICorrelationPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

Direction Property (ICorrelationPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Direction As Variant
```

SOLIDWORKS Type Library

ElectricalPinID Property (ICorrelationPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ElectricalPinID As String
```

SOLIDWORKS Type Library

IAccessSelections Method (IConnectionPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

Location Property (IConnectionPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Location As Variant
```

SOLIDWORKS Type Library

Name2 Property (IConnectionPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Name2 As String
```

SOLIDWORKS Type Library

PortID Property (IConnectionPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PortID As String
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IConnectionPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

RouteDiameter Property (IConnectionPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property RouteDiameter As Double
```

SOLIDWORKS Type Library

RouteSubType Property (IConnectionPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property RouteSubType As Long
```

SOLIDWORKS Type Library

RouteType Property (IConnectionPointFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property RouteType As Long

SOLIDWORKS Type Library

StubLength Property (IConnectionPointFeatureData)



Syntax

Visual Basic for Applications (VBA)

Public Property StubLength As Double

IConvertSolidFeatureData (Type)

SOLIDWORKS Type Library

IConvertSolidFeatureData Object

Object Model

IConvertSolidFeatureData

SOLIDWORKS Type Library

IConvertSolidFeatureData Object Members

Public Methods

	AccessSelections
	GetBendEdgesCount
	GetCustomBendAllowance
	GetFixedFace
	Initialize
	ReleaseSelectionAccess
	SetFixedFace

Public Properties

	BendEdges
	BendRadius
	CornerDefaults
	GaugeBendRadius
	GaugeTableFile
	GaugeThickness
	KeepBody
	OverrideBendRadius
	OverrideDefaultAutoReliefParameters
	OverrideDefaultBendAllowanceParameters
	OverrideDefaultSheetMetalParameters
	OverrideSheetThickness
	ReliefRatio
	ReliefType
	ReverseThickness
	RipGap
	RipOverlapRatio
	RipSketches
	SheetMetalProcess
	SheetThickness

SOLIDWORKS Type Library

AccessSelections Method (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

BendEdges Property (IConvertSolidFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property BendEdges As Variant
```

SOLIDWORKS Type Library

BendRadius Property (IConvertSolidFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property BendRadius As Double
```

SOLIDWORKS Type Library

CornerDefaults Property (IConvertSolidFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property CornerDefaults As Long
```

SOLIDWORKS Type Library

GaugeBendRadius Property (IConvertSolidFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property GaugeBendRadius As Double
```

SOLIDWORKS Type Library

GaugeTableFile Property (IConvertSolidFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property GaugeTableFile As String
```

SOLIDWORKS Type Library

GaugeThickness Property (IConvertSolidFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property GaugeThickness As String
```

SOLIDWORKS Type Library

GetBendEdgesCount Method (IConvertSolidFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBendEdgesCount() As Long
```

SOLIDWORKS Type Library

GetCustomBendAllowance Method (IConvertSolidFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetCustomBendAllowance() As Object
```

SOLIDWORKS Type Library

GetFixedFace Method (IConvertSolidFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetFixedFace() As Object
```

SOLIDWORKS Type Library

Initialize Method (IConvertSolidFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub Initialize( _  
    ByVal UseMaterialSheetMetalParameters As Boolean, _  
    ByVal UseGaugeTableParameters As Boolean, _  
    ByVal CustomBendAllowance As Object _  
)
```

SOLIDWORKS Type Library

KeepBody Property (IConvertSolidFeatureData)



Visual Basic for Applications (VBA)

```
Public Property KeepBody As Boolean
```

SOLIDWORKS Type Library

OverrideBendRadius Property (IConvertSolidFeatureData)



Visual Basic for Applications (VBA)

```
Public Property OverrideBendRadius As Boolean
```

SOLIDWORKS Type Library

OverrideDefaultAutoReliefParameters Property (IConvertSolidFeatureData)



Visual Basic for Applications (VBA)

```
Public Property OverrideDefaultAutoReliefParameters As Boolean
```

SOLIDWORKS Type Library

OverrideDefaultBendAllowanceParameters Property (IConvertSolidFeatureData)



Visual Basic for Applications (VBA)

```
Public Property OverrideDefaultBendAllowanceParameters As Boolean
```

SOLIDWORKS Type Library

OverrideDefaultSheetMetalParameters Property (IConvertSolidFeatureData)



Visual Basic for Applications (VBA)

```
Public Property OverrideDefaultSheetMetalParameters As Boolean
```

SOLIDWORKS Type Library

OverrideSheetThickness Property (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OverrideSheetThickness As Boolean
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

ReliefRatio Property (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ReliefRatio As Double
```

SOLIDWORKS Type Library

ReliefType Property (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ReliefType As Long
```

SOLIDWORKS Type Library

ReverseThickness Property (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ReverseThickness As Boolean
```

SOLIDWORKS Type Library

RipGap Property (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property RipGap As Double
```

SOLIDWORKS Type Library

RipOverlapRatio Property (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property RipOverlapRatio As Double
```

SOLIDWORKS Type Library

RipSketches Property (IConvertSolidFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property RipSketches As Variant
```

SetFixedFace Method (IConvertSolidFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub SetFixedFace( _  
    ByVal FaceIn As Object _  
)
```

SheetMetalProcess Property (IConvertSolidFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property SheetMetalProcess As String
```

SheetThickness Property (IConvertSolidFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property SheetThickness As Double
```

ICoordinateSystemElement (Type)

SOLIDWORKS Type Library
ICoordinateSystemElement Object

Object Model

ICoordinateSystemElement

SOLIDWORKS Type Library
ICoordinateSystemElement Object Members

Public Methods

-  [GetCoordinateSystem](#)
-  [GetElementType](#)

SOLIDWORKS Type Library
GetCoordinateSystem Method (ICoordinateSystemElement)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCoordinateSystem() As Object
```

SOLIDWORKS Type Library
GetElementType Method (ICoordinateSystemElement)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetElementType() As Long
```

ICornerManagementFolder (Type)

SOLIDWORKS Type Library

ICornerManagementFolder Object

Object Model

ICornerManagementFolder

GetFeature (Feature)

SOLIDWORKS Type Library

ICornerManagementFolder Object Members

Public Methods

GetFeature

GetStructureSystemFolder

GetTreatmentGroupFolderCount

GetTreatmentGroupFolders

SOLIDWORKS Type Library

GetFeature Method (ICornerManagementFolder)

Syntax

Visual Basic for Applications (VBA)

Public Function GetFeature() As [Feature](#)

SOLIDWORKS Type Library

GetStructureSystemFolder Method (ICornerManagementFolder)

Syntax

Visual Basic for Applications (VBA)

Public Function GetStructureSystemFolder() As Object

SOLIDWORKS Type Library

GetTreatmentGroupFolderCount Method (ICornerManagementFolder)

Syntax

Visual Basic for Applications (VBA)

Public Function GetTreatmentGroupFolderCount() As Long

SOLIDWORKS Type Library

GetTreatmentGroupFolders Method (ICornerManagementFolder)

Syntax

Visual Basic for Applications (VBA)

Public Function GetTreatmentGroupFolders() As Variant

ICornerMember (Type)

SOLIDWORKS Type Library

ICornerMember Object

 Object Model

ICornerMember

SOLIDWORKS Type Library

ICornerMember Object Members



 Public Methods

 [GetUnderlyingMemberFeature](#)

 Public Properties

 [TrimOrder](#)

 [WeldGap](#)

SOLIDWORKS Type Library

GetUnderlyingMemberFeature Method (ICornerMember)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUnderlyingMemberFeature() As Object
```

SOLIDWORKS Type Library

TrimOrder Property (ICornerMember)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property TrimOrder As Long
```

SOLIDWORKS Type Library

WeldGap Property (ICornerMember)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property WeldGap As Double
```

ICornerReliefFeatureData (Type)

SOLIDWORKS Type Library
ICornerReliefFeatureData Object

Object Model

ICornerReliefFeatureData

SOLIDWORKS Type Library
ICornerReliefFeatureData Object Members

Public Methods

	AccessSelections
	AddNewCorner
	CollectAllCorners
	GetBodyScope
	GetCornerAtIndex
	GetCorners
	Initialize
	ReleaseSelectionAccess
	RemoveCorner
	SetBodyScope

Public Properties

	CornerCount
	CornerType

SOLIDWORKS Type Library
AccessSelections Method (ICornerReliefFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library
AddNewCorner Method (ICornerReliefFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AddNewCorner( _
    ByVal Face1 As Object, _
    ByVal Face2 As Object, _
    ByVal Face3 As Object, _
    ByVal ReliefType As Long, _
    ByRef Corner As Object _
) As Long
```

SOLIDWORKS Type Library
CollectAllCorners Method (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function CollectAllCorners( _  
    ByVal ReliefType As Long, _  
    ByRef Corners As Variant _  
    ) As Long
```

SOLIDWORKS Type Library

CornerCount Property (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property CornerCount As Long
```

SOLIDWORKS Type Library

CornerType Property (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property CornerType As Long
```

SOLIDWORKS Type Library

GetBodyScope Method (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBodyScope() As Object
```

SOLIDWORKS Type Library

GetCornerAtIndex Method (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCornerAtIndex( _  
    ByVal CornerIndex As Long, _  
    ByRef Corner As Object _  
    ) As Long
```

SOLIDWORKS Type Library

GetCorners Method (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCorners( _  
    ByVal CornerReliefType As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

Initialize Method (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function Initialize( _  
    ByVal CornerType As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

RemoveCorner Method (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveCorner( _  
    ByVal CornerIndex As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetBodyScope Method (ICornerReliefFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetBodyScope( _  
    ByVal SheetBody As Object _  
    ) As Long
```