

SOLIDWORKS API (VB6 COM) — Reference (40/102): IFacet-IHoleStandardsData

SOLIDWORKS API Documentation (converted from CHM)

IFacet (Type)

SOLIDWORKS Type Library

IFacet Object

 Object Model

IFacet

SOLIDWORKS Type Library

IFacet Object Members



 Public Methods

 [GetBody](#)

 [GetFacetEdges](#)

 [GetFacetVertices](#)

 [Select](#)

SOLIDWORKS Type Library

GetBody Method (IFacet)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBody() As Object
```

SOLIDWORKS Type Library

GetFacetEdges Method (IFacet)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFacetEdges() As Variant
```

SOLIDWORKS Type Library

GetFacetVertices Method (IFacet)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFacetVertices() As Variant
```

SOLIDWORKS Type Library

Select Method (IFacet)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function Select( _  
    ByVal Append As Boolean, _  
    ByVal Data As Object _  
) As Boolean
```

IFamilyTableAnnotation (Type)

SOLIDWORKS Type Library

IFamilyTableAnnotation Object

Object Model

IFamilyTableAnnotation

SOLIDWORKS Type Library

IFamilyTableAnnotation Object Members

Public Methods

GetSheet

Public Properties

FamilyTableFeature

SOLIDWORKS Type Library

FamilyTableFeature Property (IFamilyTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Property FamilyTableFeature As Object

SOLIDWORKS Type Library

GetSheet Method (IFamilyTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Function GetSheet() As Object

IFamilyTableFeature (Type)

SOLIDWORKS Type Library
IFamilyTableFeature Object

Object Model

IFamilyTableFeature

SOLIDWORKS Type Library
IFamilyTableFeature Object Members

Public Methods

 GetConfigurations
 GetFeature
 GetFollowConfigTreeOrder
 GetModelName
 GetSequenceNumberIncrement
 GetSequenceStartNumber
 GetTableAnnotationCount
 GetTableAnnotations
 GetUseAllConfigurations
 SetConfigurations
 SetFollowConfigTreeOrder
 SetSequenceNumberIncrement
 SetSequenceStartNumber
 SetUseAllConfigurations

SOLIDWORKS Type Library
GetConfigurations Method (IFamilyTableFeature)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetConfigurations( _
    ByVal Criteria As Long _
) As Variant
```

SOLIDWORKS Type Library
GetFeature Method (IFamilyTableFeature)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFeature() As Object
```

SOLIDWORKS Type Library
GetFollowConfigTreeOrder Method (IFamilyTableFeature)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFollowConfigTreeOrder() As Boolean
```

SOLIDWORKS Type Library

GetModelName Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetModelName() As String
```

SOLIDWORKS Type Library

GetSequenceNumberIncrement Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSequenceNumberIncrement() As Long
```

SOLIDWORKS Type Library

GetSequenceStartNumber Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSequenceStartNumber() As Long
```

SOLIDWORKS Type Library

GetTableAnnotationCount Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotationCount() As Long
```

SOLIDWORKS Type Library

GetTableAnnotations Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotations() As Variant
```

SOLIDWORKS Type Library

GetUseAllConfigurations Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUseAllConfigurations() As Boolean
```

SOLIDWORKS Type Library

SetConfigurations Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetConfigurations( _  
    ByVal ConfigArray As Variant, _  
    ByVal VisibilityArray As Variant _  
)
```

SOLIDWORKS Type Library

SetFollowConfigTreeOrder Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetFollowConfigTreeOrder( _  
    ByVal Flag As Boolean _  
)
```

SOLIDWORKS Type Library

SetSequenceNumberIncrement Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetSequenceNumberIncrement( _  
    ByVal Increment As Long _  
)
```

SOLIDWORKS Type Library

SetSequenceStartNumber Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetSequenceStartNumber( _  
    ByVal Start As Long _  
)
```

SOLIDWORKS Type Library

SetUseAllConfigurations Method (IFamilyTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetUseAllConfigurations( _  
    ByVal UseAllConfigs As Boolean _  
)
```

IFeatureFolder (Type)

SOLIDWORKS Type Library

IFeatureFolder Object

Object Model

IFeatureFolder

IGetFeatures (Feature)

SOLIDWORKS Type Library

IFeatureFolder Object Members

Public Methods

GetFeatureCount

GetFeatures

IGetFeatures

SOLIDWORKS Type Library

GetFeatureCount Method (IFeatureFolder)

Syntax

Visual Basic for Applications (VBA)

Public Function GetFeatureCount() As Long

SOLIDWORKS Type Library

GetFeatures Method (IFeatureFolder)

Syntax

Visual Basic for Applications (VBA)

Public Function GetFeatures() As Variant

SOLIDWORKS Type Library

IGetFeatures Method (IFeatureFolder)

Syntax

Visual Basic for Applications (VBA)

Public Function IGetFeatures(_
 ByVal NumOfFeatures As Long _
) As [Feature](#)

IFillPatternFeatureData (Type)

SOLIDWORKS Type Library

IFillPatternFeatureData Object

 Object Model

IFillPatternFeatureData

SOLIDWORKS Type Library

IFillPatternFeatureData Object Members

 Public Methods

 AccessSelections
 ReleaseSelectionAccess

 Public Properties

 AutoSelect
 CreateSeedCutPolygonSides
 CreateSeedCutType
 Diagonal
 Diameter
 Dimension
 FeatureScope
 FeatureScopeBodies
 FeaturesToPatternType
 GeometryPattern
 InnerRadius
 InstanceSpacing
 LayoutSpacingType
 LoopSpacing
 Margins
 NoOffInstances
 OuterRadius
 PatternBodyArray
 PatternDirection
 PatternDirectionType
 PatternElement
 PatternFaceArray
 PatternFeatureArray
 PatternFillBoundaryArray
 PatternLayoutPolygonSides
 PatternLayoutType
 PropagateVisualProperty
 Rotation

 SeedCutFlipShapeDirection
 SeedFeatureCenter
 SeedFeatureCenterType
 SkippedItemArray
 StaggerAngle

SOLIDWORKS Type Library

AccessSelections Method (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

AutoSelect Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property AutoSelect As Boolean
```

SOLIDWORKS Type Library

CreateSeedCutPolygonSides Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property CreateSeedCutPolygonSides As Long
```

SOLIDWORKS Type Library

CreateSeedCutType Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property CreateSeedCutType As Long
```

SOLIDWORKS Type Library

Diagonal Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Diagonal As Double
```

SOLIDWORKS Type Library

Diameter Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Diameter As Double
```

SOLIDWORKS Type Library

Dimension Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property Dimension As Double

SOLIDWORKS Type Library

FeatureScope Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property FeatureScope As Boolean

SOLIDWORKS Type Library

FeatureScopeBodies Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property FeatureScopeBodies As Variant

SOLIDWORKS Type Library

FeaturesToPatternType Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property FeaturesToPatternType As Long

SOLIDWORKS Type Library

GeometryPattern Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property GeometryPattern As Boolean

SOLIDWORKS Type Library

InnerRadius Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property InnerRadius As Double

SOLIDWORKS Type Library

InstanceSpacing Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property InstanceSpacing As Double

SOLIDWORKS Type Library

LayoutSpacingType Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property LayoutSpacingType As Long

SOLIDWORKS Type Library

LoopSpacing Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property LoopSpacing As Double

SOLIDWORKS Type Library

Margins Property (IFillPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property Margins As Double

SOLIDWORKS Type Library

NoOfInstances Property (IFillPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property NoOfInstances As Long

SOLIDWORKS Type Library

OuterRadius Property (IFillPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property OuterRadius As Double

SOLIDWORKS Type Library

PatternBodyArray Property (IFillPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property PatternBodyArray As Variant

SOLIDWORKS Type Library

PatternDirection Property (IFillPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property PatternDirection As Object

SOLIDWORKS Type Library

PatternDirectionType Property (IFillPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property PatternDirectionType As Long

SOLIDWORKS Type Library

PatternElement Property (IFillPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property PatternElement As Long

SOLIDWORKS Type Library

PatternFaceArray Property (IFillPatternFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property PatternFaceArray As Variant

SOLIDWORKS Type Library

PatternFeatureArray Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property PatternFeatureArray As Variant

SOLIDWORKS Type Library

PatternFillBoundaryArray Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property PatternFillBoundaryArray As Variant

SOLIDWORKS Type Library

PatternLayoutPolygonSides Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property PatternLayoutPolygonSides As Long

SOLIDWORKS Type Library

PatternLayoutType Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property PatternLayoutType As Long

SOLIDWORKS Type Library

PropagateVisualProperty Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property PropagateVisualProperty As Boolean

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Sub ReleaseSelectionAccess()

SOLIDWORKS Type Library

Rotation Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property Rotation As Double

SOLIDWORKS Type Library

SeedCutFlipShapeDirection Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SeedCutFlipShapeDirection As Boolean

SOLIDWORKS Type Library

SeedFeatureCenter Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SeedFeatureCenter As Object

SOLIDWORKS Type Library

SeedFeatureCenterType Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SeedFeatureCenterType As Long

SOLIDWORKS Type Library

SkippedItemArray Property (IFillPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SkippedItemArray As Variant

SOLIDWORKS Type Library

StaggerAngle Property (IFillPatternFeatureData)




Visual Basic for Applications (VBA)

Public Property StaggerAngle As Double

IFlatPatternFolder (Type)

SOLIDWORKS Type Library

IFlatPatternFolder Object



SOLIDWORKS Type Library

IFlatPatternFolder Object Members

Public Methods

	GetFeature
	GetFlatPatternCount
	GetFlatPatterns

SOLIDWORKS Type Library

GetFeature Method (IFlatPatternFolder)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeature() As Feature
```

SOLIDWORKS Type Library

GetFlatPatternCount Method (IFlatPatternFolder)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFlatPatternCount() As Long
```

SOLIDWORKS Type Library

GetFlatPatterns Method (IFlatPatternFolder)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFlatPatterns() As Variant
```

IFlyoutGroup (Type)

SOLIDWORKS Type Library
IFlyoutGroup Object

Object Model

IFlyoutGroup

SOLIDWORKS Type Library
IFlyoutGroup Object Members

Public Methods

- AddCommandItem
- AddContextMenuFlyout
- RemoveAllCommandItems
- RemoveCommandItem
- ReplaceCommandItem

Public Properties

- ButtonCount
- CmdID
- FlyoutType
- IconList
- LargeIconList
- LargeMainIcon
- MainIconList
- SmallIconList
- SmallMainIcon

SOLIDWORKS Type Library
AddCommandItem Method (IFlyoutGroup)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddCommandItem( _  
    ByVal Name As String, _  
    ByVal HintString As String, _  
    ByVal ImageListIndex As Long, _  
    ByVal CallbackFunction As String, _  
    ByVal UpdateCallbackFunction As String _  
) As Long
```

SOLIDWORKS Type Library
AddContextMenuFlyout Method (IFlyoutGroup)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddContextMenuFlyout( _  
    ByVal DocumentType As Long, _  
    ByVal SelectionType As Long _  
) As Boolean
```

SOLIDWORKS Type Library

ButtonCount Property (IFlyoutGroup)



Visual Basic for Applications (VBA)

```
Public Property ButtonCount As Long
```

SOLIDWORKS Type Library

CmdID Property (IFlyoutGroup)



Visual Basic for Applications (VBA)

```
Public Property CmdID As Long
```

SOLIDWORKS Type Library

FlyoutType Property (IFlyoutGroup)



Visual Basic for Applications (VBA)

```
Public Property FlyoutType As Long
```

SOLIDWORKS Type Library

IconList Property (IFlyoutGroup)



Visual Basic for Applications (VBA)

```
Public Property IconList As Variant
```

SOLIDWORKS Type Library

LargeIconList Property (IFlyoutGroup)



Visual Basic for Applications (VBA)

```
Public Property LargeIconList As String
```

SOLIDWORKS Type Library

LargeMainIcon Property (IFlyoutGroup)



Visual Basic for Applications (VBA)

```
Public Property LargeMainIcon As String
```

SOLIDWORKS Type Library

MainIconList Property (IFlyoutGroup)



Visual Basic for Applications (VBA)

```
Public Property MainIconList As Variant
```

SOLIDWORKS Type Library

RemoveAllCommandItems Method (IFlyoutGroup)



Visual Basic for Applications (VBA)

```
Public Sub RemoveAllCommandItems()
```

RemoveCommandItem Method (IFlyoutGroup) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function RemoveCommandItem( _  
    ByVal Position As Long _  
) As Boolean
```

ReplaceCommandItem Method (IFlyoutGroup) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ReplaceCommandItem( _  
    ByVal Position As Long, _  
    ByVal Name As String, _  
    ByVal HintString As String, _  
    ByVal ImageListIndex As Long, _  
    ByVal CallbackFunction As String, _  
    ByVal UpdateCallbackFunction As String _  
) As Long
```

SmallIconList Property (IFlyoutGroup) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property SmallIconList As String
```

SmallMainIcon Property (IFlyoutGroup) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property SmallMainIcon As String
```

IGearMateFeatureData (Type)

SOLIDWORKS Type Library

IGearMateFeatureData Object

 Object Model

IGearMateFeatureData

SOLIDWORKS Type Library

IGearMateFeatureData Object Members



 Public Properties

 EntitiesToMate
 GearRatioDenominator
 GearRatioNumerator
 Reverse

SOLIDWORKS Type Library

EntitiesToMate Property (IGearMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

Public Property EntitiesToMate As Variant

SOLIDWORKS Type Library

GearRatioDenominator Property (IGearMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

Public Property GearRatioDenominator As Double

SOLIDWORKS Type Library

GearRatioNumerator Property (IGearMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

Public Property GearRatioNumerator As Double

SOLIDWORKS Type Library

Reverse Property (IGearMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

Public Property Reverse As Boolean

IGeneralTableAnnotation (Type)

SOLIDWORKS Type Library

IGeneralTableAnnotation Object

Object Model

IGeneralTableAnnotation

GeneralTable (GeneralTableFeature)

SOLIDWORKS Type Library

IGeneralTableAnnotation Object Members

Public Methods

Sort

Public Properties

GeneralTable

SOLIDWORKS Type Library

GeneralTable Property (IGeneralTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Property GeneralTable As [GeneralTableFeature](#)

SOLIDWORKS Type Library

Sort Method (IGeneralTableAnnotation)

Syntax


Visual Basic for Applications (VBA)

```
Public Function Sort( _  
    ByVal ColumnIndex As Long, _  
    ByVal SortAscending As Boolean _  
) As Boolean
```

IGeneralToleranceTableAnnotation (Type)

SOLIDWORKS Type Library
IGeneralToleranceTableAnnotation Object

 Object Model



SOLIDWORKS Type Library
IGeneralToleranceTableAnnotation Object Members



 Public Properties

 [GeneralToleranceTableFeature](#)

SOLIDWORKS Type Library
GeneralToleranceTableFeature Property (IGeneralToleranceTableAnnotation)


 Syntax

Visual Basic for Applications (VBA)

Public Property GeneralToleranceTableFeature As [GeneralToleranceTableFeature](#)

IGeneralToleranceTableFeature (Type)

SOLIDWORKS Type Library
IGeneralToleranceTableFeature Object



SOLIDWORKS Type Library
IGeneralToleranceTableFeature Object Members

Public Methods

- [GetFeature](#)
- [GetTableAnnotations](#)

SOLIDWORKS Type Library
GetFeature Method (IGeneralToleranceTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeature() As Feature
```

SOLIDWORKS Type Library
GetTableAnnotations Method (IGeneralToleranceTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotations() As Variant
```

IGraphicsBody (Type)

SOLIDWORKS Type Library
IGraphicsBody Object

Object Model

IGraphicsBody

SOLIDWORKS Type Library
IGraphicsBody Object Members

Public Methods

 GetBody
 GetFacetCount
 GetFacets
 SurfaceFromMesh

SOLIDWORKS Type Library
GetBody Method (IGraphicsBody)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetBody() As Object
```

SOLIDWORKS Type Library
GetFacetCount Method (IGraphicsBody)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFacetCount() As Long
```

SOLIDWORKS Type Library
GetFacets Method (IGraphicsBody)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFacets() As Variant
```

SOLIDWORKS Type Library
SurfaceFromMesh Method (IGraphicsBody)

Syntax

```
Visual Basic for Applications (VBA)

Public Function SurfaceFromMesh( _
    ByVal SurfaceType As Long, _
    ByVal FacetTolerance As Double, _
    ByVal ExtendSurfaceSize As Double, _
    ByRef ErrorCode As Long _
) As Object
```

IGroundPlaneFeatureData (Type)

SOLIDWORKS Type Library

IGroundPlaneFeatureData Object

Object Model

IGroundPlaneFeatureData

SOLIDWORKS Type Library

IGroundPlaneFeatureData Object Members

Public Methods

AccessSelections

ReleaseSelectionAccess

Public Properties

PlanarEntity

ReverseDirection

SOLIDWORKS Type Library

AccessSelections Method (IGroundPlaneFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

PlanarEntity Property (IGroundPlaneFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property PlanarEntity As Object
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IGroundPlaneFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

ReverseDirection Property (IGroundPlaneFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ReverseDirection As Boolean
```

IGtolFrame (Type)

SOLIDWORKS Type Library

IGtolFrame Object

Object Model

IGtolFrame

SOLIDWORKS Type Library

IGtolFrame Object Members

Public Methods

- AddIndicator
- DeleteIndicator
- GetFrameToleranceType
- GetIndicator
- GetIndicatorCount
- GetSymbolXml
- SetFrameToleranceType
- SetIndicator
- SetSymbolXml

SOLIDWORKS Type Library

AddIndicator Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddIndicator( _  
    ByVal BorderType As Long, _  
    ByVal TolType As Long, _  
    ByVal Datum As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteIndicator Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteIndicator( _  
    ByVal IndicatorIndex As Long _  
) As Boolean
```

SOLIDWORKS Type Library

GetFrameToleranceType Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFrameToleranceType( _  
    ByRef TolType As Long _  
) As Boolean
```

SOLIDWORKS Type Library

GetIndicator Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIndicator( _  
    ByVal IndicatorIndex As Long, _  
    ByRef BorderType As Long, _  
    ByRef TolType As Long, _  
    ByRef Datum As String _  
) As Boolean
```

SOLIDWORKS Type Library

GetIndicatorCount Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIndicatorCount() As Long
```

SOLIDWORKS Type Library

GetSymbolXml Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSymbolXml() As String
```

SOLIDWORKS Type Library

SetFrameToleranceType Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetFrameToleranceType( _  
    ByVal TolType As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetIndicator Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetIndicator( _  
    ByVal IndicatorIndex As Long, _  
    ByVal BorderType As Long, _  
    ByVal TolType As Long, _  
    ByVal Datum As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetSymbolXml Method (IGtolFrame)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetSymbolXml( _  
    ByVal Xmlstring As String _  
) As Boolean
```

IHingeMateFeatureData (Type)

SOLIDWORKS Type Library

IHingeMateFeatureData Object

Object Model

IHingeMateFeatureData

SOLIDWORKS Type Library

IHingeMateFeatureData Object Members

Public Properties

Angle

AngleSelection

EntitiesToMate

MateAlignment

MaxVal

MinVal

SOLIDWORKS Type Library

Angle Property (IHingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Angle As Double

SOLIDWORKS Type Library

AngleSelection Property (IHingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property AngleSelection As Boolean

SOLIDWORKS Type Library

EntitiesToMate Property (IHingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property EntitiesToMate(_
 ByVal *EntityType* As Long _
) As Variant

SOLIDWORKS Type Library

MateAlignment Property (IHingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MateAlignment As Long

SOLIDWORKS Type Library

MaxVal Property (IHingeMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MaxVal As Double

SOLIDWORKS Type Library

MinVal Property (IHingeMateFeatureData)



Visual Basic for Applications (VBA)

Public Property MinVal As Double

IHoleDataTable (Type)

SOLIDWORKS Type Library
IHoleDataTable Object

Object Model

IHoleDataTable

SOLIDWORKS Type Library
IHoleDataTable Object Members

Public Methods

-  [GetCellData](#)
-  [GetColumnNames](#)
-  [GetRowCount](#)
-  [GetRowData](#)

Public Properties

-  [FastenerID](#)
-  [StandardName](#)
-  [TableTypeID](#)

SOLIDWORKS Type Library
FastenerID Property (IHoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerID As Long
```

SOLIDWORKS Type Library
GetCellData Method (IHoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCellData( _  
    ByVal ColumnName As String, _  
    ByVal RowIndex As Long, _  
    ByRef CellData As String _  
) As Boolean
```

SOLIDWORKS Type Library
GetColumnNames Method (IHoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetColumnNames( _  
    ByRef ColumnNames As Variant _  
) As Boolean
```

SOLIDWORKS Type Library
GetRowCount Method (IHoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRowCount( _  
    ByRef RowCount As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetRowData Method (IHoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRowData( _  
    ByVal RowIndex As Long, _  
    ByRef RowData As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

StandardName Property (IHoleDataTable)

Syntax

Visual Basic for Applications (VBA)

```
Public Property StandardName As String
```

SOLIDWORKS Type Library

TableTypeID Property (IHoleDataTable)

Syntax

Visual Basic for Applications (VBA)


```
Public Property TableTypeID As Long
```

IHoleSeriesFeatureData2 (Type)

SOLIDWORKS Type Library

IHoleSeriesFeatureData2 Object

Object Model



SOLIDWORKS Type Library

IHoleSeriesFeatureData2 Object Members

Public Methods

	AccessSelections
	GetComponents
	GetComponentsCount
	GetHoleBottomMateEntity
	GetHoleTopMateEntity
	GetSketchPoints
	GetSketchPointsCount
	IAccessSelections
	IGetComponents
	IGetHoleBottomMateEntity
	IGetHoleTopMateEntity
	IGetSketchPoints
	ReleaseSelectionAccess

Public Properties

	BoltDiameter
	BoltHeadDiameter
	EndFace
	FastenerBottomHoleType
	FastenerDefaultUnits
	FastenerHoleCount
	FastenerTopHoleType
	Material
	NutDiameter
	Preload
	Size
	Standard



[StartFace](#)



[Type](#)

SOLIDWORKS Type Library

AccessSelections Method (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library

BoltDiameter Property (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property BoltDiameter As Double
```

SOLIDWORKS Type Library

BoltHeadDiameter Property (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property BoltHeadDiameter As Double
```

SOLIDWORKS Type Library

EndFace Property (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property EndFace As Object
```

SOLIDWORKS Type Library

FastenerBottomHoleType Property (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerBottomHoleType As Integer
```

SOLIDWORKS Type Library

FastenerDefaultUnits Property (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerDefaultUnits As String
```

SOLIDWORKS Type Library

FastenerHoleCount Property (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FastenerHoleCount As Long
```

SOLIDWORKS Type Library

FastenerTopHoleType Property (IHoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Property FastenerTopHoleType As Integer
```

SOLIDWORKS Type Library

GetComponents Method (IHoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetComponents() As Variant
```

SOLIDWORKS Type Library

GetComponentsCount Method (IHoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetComponentsCount() As Long
```

SOLIDWORKS Type Library

GetHoleBottomMateEntity Method (IHoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetHoleBottomMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Object
```

SOLIDWORKS Type Library

GetHoleTopMateEntity Method (IHoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetHoleTopMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Object
```

SOLIDWORKS Type Library

GetSketchPoints Method (IHoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPoints() As Variant
```

SOLIDWORKS Type Library

GetSketchPointsCount Method (IHoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function GetSketchPointsCount() As Long
```

SOLIDWORKS Type Library

IAccessSelections Method (IHoleSeriesFeatureData2)



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetComponents Method (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetComponents( _  
    ByVal NCount As Long _  
    ) As Component2
```

SOLIDWORKS Type Library

IGetHoleBottomMateEntity Method (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetHoleBottomMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Entity
```

SOLIDWORKS Type Library

IGetHoleTopMateEntity Method (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetHoleTopMateEntity( _  
    ByVal HoleInstance As Long, _  
    ByVal HoleType As Integer _  
    ) As Entity
```

SOLIDWORKS Type Library

IGetSketchPoints Method (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSketchPoints( _  
    ByVal NCount As Long _  
    ) As SketchPoint
```

SOLIDWORKS Type Library

Material Property (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Material As String
```

SOLIDWORKS Type Library

NutDiameter Property (IHoleSeriesFeatureData2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property NutDiameter As Double
```

SOLIDWORKS Type Library

Preload Property (IHoleSeriesFeatureData2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Preload As String
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IHoleSeriesFeatureData2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

Size Property (IHoleSeriesFeatureData2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Size( _  
    ByVal HoleSeriesWhichPart As Long _  
) As String
```

SOLIDWORKS Type Library

Standard Property (IHoleSeriesFeatureData2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Standard As Long
```

SOLIDWORKS Type Library

StartFace Property (IHoleSeriesFeatureData2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property StartFace As Object
```

SOLIDWORKS Type Library

Type Property (IHoleSeriesFeatureData2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Type( _  
    ByVal HoleSeriesWhichPart As Long _  
) As Long
```

IHoleStandardsData (Type)

SOLIDWORKS Type Library

IHoleStandardsData Object

Object Model

IHoleStandardsData

SOLIDWORKS Type Library

IHoleStandardsData Object Members

Public Methods

- GetFastenerTable
- GetFastenerTableTypes
- GetFastenerTypes
- GetHoleStandards

SOLIDWORKS Type Library

GetFastenerTable Method (IHoleStandardsData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFastenerTable( _
    ByVal StandardName As String, _
    ByVal FastenerID As Long, _
    ByVal TableID As Long, _
    ByRef HoleTable As Object _
) As Boolean
```

SOLIDWORKS Type Library

GetFastenerTableTypes Method (IHoleStandardsData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFastenerTableTypes( _
    ByVal StandardName As String, _
    ByVal FastenerID As Long, _
    ByRef FastenerTableTypeIDs As Variant _
) As Boolean
```

SOLIDWORKS Type Library

GetFastenerTypes Method (IHoleStandardsData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFastenerTypes( _
    ByVal StandardName As String, _
    ByRef FastenerIndexes As Variant, _
    ByRef FastenerNames As Variant _
) As Boolean
```

SOLIDWORKS Type Library

GetHoleStandards Method (IHoleStandardsData)

Syntax

```
Visual Basic for Applications (VBA)
```

```
Public Function GetHoleStandards( _  
    ByRef Indexes As Variant, _  
    ByRef Names As Variant _  
) As Boolean
```