

SOLIDWORKS API (VB6 COM) — Reference (41/102): IImport3DInterconnectData- IMateFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IImport3DInterconnectData (Type)

SOLIDWORKS Type Library

IImport3DInterconnectData Object

Object Model

IImport3DInterconnectData

SOLIDWORKS Type Library

IImport3DInterconnectData Object Members

Public Methods

-  [GetAuthoringInfo](#)
-  [GetReferencedFileName](#)
-  [SetReferencedFileName](#)

Public Properties

-  [Axes](#)
-  [CustomProperties](#)
-  [IgnoreHiddenEntities](#)
-  [Material](#)
-  [Planes](#)
-  [SketchesAndCurves](#)
-  [SolidBodies](#)
-  [SurfaceBodies](#)

SOLIDWORKS Type Library

Axes Property (IImport3DInterconnectData)

Syntax

Visual Basic for Applications (VBA)

Public Property Axes As Boolean

SOLIDWORKS Type Library

CustomProperties Property (IImport3DInterconnectData)

Syntax

Visual Basic for Applications (VBA)

Public Property CustomProperties As Boolean

SOLIDWORKS Type Library

GetAuthoringInfo Method (IImport3DInterconnectData)

Syntax

Visual Basic for Applications (VBA)

Public Function GetAuthoringInfo() As String

SOLIDWORKS Type Library

GetReferencedFileName Method (IImport3DInterconnectData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetReferencedFileName() As String
```

SOLIDWORKS Type Library

IgnoreHiddenEntities Property (IImport3DInterconnectData)



Visual Basic for Applications (VBA)

```
Public Property IgnoreHiddenEntities As Boolean
```

SOLIDWORKS Type Library

Material Property (IImport3DInterconnectData)



Visual Basic for Applications (VBA)

```
Public Property Material As Boolean
```

SOLIDWORKS Type Library

Planes Property (IImport3DInterconnectData)



Visual Basic for Applications (VBA)

```
Public Property Planes As Boolean
```

SOLIDWORKS Type Library

SetReferencedFileName Method (IImport3DInterconnectData)



Visual Basic for Applications (VBA)

```
Public Sub SetReferencedFileName( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

SketchesAndCurves Property (IImport3DInterconnectData)



Visual Basic for Applications (VBA)

```
Public Property SketchesAndCurves As Boolean
```

SOLIDWORKS Type Library

SolidBodies Property (IImport3DInterconnectData)



Visual Basic for Applications (VBA)

```
Public Property SolidBodies As Boolean
```

SOLIDWORKS Type Library

SurfaceBodies Property (IImport3DInterconnectData)



Visual Basic for Applications (VBA)

```
Public Property SurfaceBodies As Boolean
```

IIndentFeatureData (Type)

SOLIDWORKS Type Library
IIndentFeatureData Object

Object Model

IIndentFeatureData

SOLIDWORKS Type Library
IIndentFeatureData Object Members

Public Methods

- AccessSelections
- GetBodiesCount
- ReleaseSelectionAccess

Public Properties

- Clearance
- ClearanceDirection
- CutDirection
- IsCut
- SelectionState
- TargetBody
- Thickness
- ToolBodyRegion

SOLIDWORKS Type Library
AccessSelections Method (IIndentFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
) As Boolean
```

SOLIDWORKS Type Library
Clearance Property (IIndentFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Clearance As Double
```

SOLIDWORKS Type Library
ClearanceDirection Property (IIndentFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ClearanceDirection As Boolean
```

SOLIDWORKS Type Library
CutDirection Property (IIndentFeatureData)



Visual Basic for Applications (VBA)

Public Property CutDirection As Boolean

SOLIDWORKS Type Library

GetBodiesCount Method (IIndentFeatureData)



Visual Basic for Applications (VBA)

Public Function GetBodiesCount() As Long

SOLIDWORKS Type Library

IsCut Property (IIndentFeatureData)



Visual Basic for Applications (VBA)

Public Property IsCut As Boolean

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IIndentFeatureData)



Visual Basic for Applications (VBA)

Public Sub ReleaseSelectionAccess()

SOLIDWORKS Type Library

SelectionState Property (IIndentFeatureData)



Visual Basic for Applications (VBA)

Public Property SelectionState As Long

SOLIDWORKS Type Library

TargetBody Property (IIndentFeatureData)



Visual Basic for Applications (VBA)

Public Property TargetBody As Object

SOLIDWORKS Type Library

Thickness Property (IIndentFeatureData)



Visual Basic for Applications (VBA)

Public Property Thickness As Double

SOLIDWORKS Type Library

ToolBodyRegion Property (IIndentFeatureData)



Visual Basic for Applications (VBA)

Public Property ToolBodyRegion As Variant

IInstanceToVaryOptions (Type)

SOLIDWORKS Type Library

IInstanceToVaryOptions Object

Object Model

IInstanceToVaryOptions

SOLIDWORKS Type Library

IInstanceToVaryOptions Object Members

Public Methods

	GetD1IncrementDimensions
	GetD1ModifiedSpacingValue
	GetD2IncrementDimensions
	GetD2ModifiedSpacingValue
	GetModifiedDimensions
	GetModifiedInstances
	ModifyD1SpacingValue
	ModifyD2SpacingValue
	ModifyDimensions
	SetD1IncrementDimensions
	SetD2IncrementDimensions

Public Properties

	D1SpacingIncrement
	D2SpacingIncrement

SOLIDWORKS Type Library

D1SpacingIncrement Property (IInstanceToVaryOptions)

Syntax

Visual Basic for Applications (VBA)
Public Property D1SpacingIncrement As Double

SOLIDWORKS Type Library

D2SpacingIncrement Property (IInstanceToVaryOptions)

Syntax

Visual Basic for Applications (VBA)
Public Property D2SpacingIncrement As Double

SOLIDWORKS Type Library

GetD1IncrementDimensions Method (IInstanceToVaryOptions)

Syntax

Visual Basic for Applications (VBA)
Public Sub GetD1IncrementDimensions(_ ByRef IncrementDimensions As Variant, _ ByRef IncrementDimValues As Variant _)

GetD1ModifiedSpacingValue Method (IInstanceToVaryOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetD1ModifiedSpacingValue( _  
    ByVal Instance As Long _  
) As Double
```

GetD2IncrementDimensions Method (IInstanceToVaryOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub GetD2IncrementDimensions( _  
    ByRef IncrementDimensions As Variant, _  
    ByRef IncrementDimValues As Variant _  
)
```

GetD2ModifiedSpacingValue Method (IInstanceToVaryOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetD2ModifiedSpacingValue( _  
    ByVal Instance As Long _  
) As Double
```

GetModifiedDimensions Method (IInstanceToVaryOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub GetModifiedDimensions( _  
    ByVal Instance As Long, _  
    ByRef Dimensions As Variant, _  
    ByRef Values As Variant _  
)
```

GetModifiedInstances Method (IInstanceToVaryOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function GetModifiedInstances( _  
    ByVal ModificationType As Long _  
) As Variant
```

ModifyD1SpacingValue Method (IInstanceToVaryOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ModifyD1SpacingValue( _  
    ByVal Instance As Long, _  
    ByVal Value As Double _  
) As Boolean
```

ModifyD2SpacingValue Method (IInstanceToVaryOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ModifyD2SpacingValue( _  
    ByVal Instance As Long, _  
    ByVal Value As Double _  
) As Boolean
```

SOLIDWORKS Type Library

ModifyDimensions Method (IInstanceToVaryOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ModifyDimensions( _  
    ByVal Instance As Long, _  
    ByVal Dimensions As Variant, _  
    ByVal Values As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SetD1IncrementDimensions Method (IInstanceToVaryOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetD1IncrementDimensions( _  
    ByVal IncrementDimensions As Variant, _  
    ByVal IncrementDimValues As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SetD2IncrementDimensions Method (IInstanceToVaryOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetD2IncrementDimensions( _  
    ByVal IncrementDimensions As Variant, _  
    ByVal IncrementDimValues As Variant _  
) As Boolean
```

IIntersectFeatureData (Type)

SOLIDWORKS Type Library
IIntersectFeatureData Object

Object Model

IIntersectFeatureData

SOLIDWORKS Type Library
IIntersectFeatureData Object Members

Public Methods

 AccessSelections
 GetIntersections
 GetIntersectionsCount
 GetIntersectionsTools
 GetIntersectionsToolsCount
 ReleaseSelectionAccess
 SetIntersections
 SetIntersectionsTools

Public Properties

 CapPlanar
 Consume
 Merge

SOLIDWORKS Type Library
AccessSelections Method (IIntersectFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As Boolean
```

SOLIDWORKS Type Library
CapPlanar Property (IIntersectFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Property CapPlanar As Boolean
```

SOLIDWORKS Type Library
Consume Property (IIntersectFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Property Consume As Boolean
```

SOLIDWORKS Type Library
GetIntersections Method (IIntersectFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntersections( _  
    ByRef Excluded As Variant _  
) As Variant
```

SOLIDWORKS Type Library

GetIntersectionsCount Method (IIntersectFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntersectionsCount() As Long
```

SOLIDWORKS Type Library

GetIntersectionsTools Method (IIntersectFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntersectionsTools() As Variant
```

SOLIDWORKS Type Library

GetIntersectionsToolsCount Method (IIntersectFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntersectionsToolsCount() As Long
```

SOLIDWORKS Type Library

Merge Property (IIntersectFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Merge As Boolean
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IIntersectFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SetIntersections Method (IIntersectFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetIntersections( _  
    ByVal Intersections As Variant _  
)
```

SOLIDWORKS Type Library

SetIntersectionsTools Method (IIntersectFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetIntersectionsTools( _  
    ByVal Tools As Variant _
```


ILibraryFormToolFeatureData (Type)

SOLIDWORKS Type Library
ILibraryFormToolFeatureData Object

 Object Model

ILibraryFormToolFeatureData

SOLIDWORKS Type Library
ILibraryFormToolFeatureData Object Members

 Public Methods

 AccessSelections
 GetPunchID
 OverrideDocumentSettings
 ReleaseSelectionAccess
 SetPlacementFace

 Public Properties

 FormToolConfiguration
 FormToolPath
 LinkToFormTool
 OverrideSettings
 PickPoint
 PlacementFace
 RotationAngle
 ShowCenter
 ShowProfile
 ShowPunch

SOLIDWORKS Type Library
AccessSelections Method (ILibraryFormToolFeatureData)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library
FormToolConfiguration Property (ILibraryFormToolFeatureData)

 Syntax

```
Visual Basic for Applications (VBA)

Public Property FormToolConfiguration As String
```

SOLIDWORKS Type Library
FormToolPath Property (ILibraryFormToolFeatureData)

 Syntax

Visual Basic for Applications (VBA)

Public Property FormToolPath As String

SOLIDWORKS Type Library

GetPunchID Method (ILibraryFormToolFeatureData)



Visual Basic for Applications (VBA)

Public Function GetPunchID() As String

SOLIDWORKS Type Library

LinkToFormTool Property (ILibraryFormToolFeatureData)



Visual Basic for Applications (VBA)

Public Property LinkToFormTool As Boolean

SOLIDWORKS Type Library

OverrideDocumentSettings Method (ILibraryFormToolFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub OverrideDocumentSettings( _  
    ByVal OverrideSettings As Boolean, _  
    ByVal ShowPunch As Boolean, _  
    ByVal ShowProfile As Boolean, _  
    ByVal ShowCenter As Boolean _  
)
```

SOLIDWORKS Type Library

OverrideSettings Property (ILibraryFormToolFeatureData)



Visual Basic for Applications (VBA)

Public Property OverrideSettings As Boolean

SOLIDWORKS Type Library

PickPoint Property (ILibraryFormToolFeatureData)



Visual Basic for Applications (VBA)

Public Property PickPoint As Object

SOLIDWORKS Type Library

PlacementFace Property (ILibraryFormToolFeatureData)



Visual Basic for Applications (VBA)

Public Property PlacementFace As Object

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (ILibraryFormToolFeatureData)



Visual Basic for Applications (VBA)

Public Sub ReleaseSelectionAccess()

RotationAngle Property (ILibraryFormToolFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property RotationAngle As Double
```

SetPlacementFace Method (ILibraryFormToolFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetPlacementFace( _  
    ByVal Face As Object, _  
    ByVal PickPoint As Object _  
)
```

ShowCenter Property (ILibraryFormToolFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowCenter As Boolean
```

ShowProfile Property (ILibraryFormToolFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowProfile As Boolean
```

ShowPunch Property (ILibraryFormToolFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowPunch As Boolean
```

ILinearCouplerMateFeatureData (Type)

SOLIDWORKS Type Library

ILinearCouplerMateFeatureData Object

Object Model

ILinearCouplerMateFeatureData

SOLIDWORKS Type Library

ILinearCouplerMateFeatureData Object Members

Public Properties

CouplerRatioDenominator

CouplerRatioNumerator

MateEntity1

MateEntity2

ReferenceComponent1

ReferenceComponent2

Reverse

SOLIDWORKS Type Library

CouplerRatioDenominator Property (ILinearCouplerMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property CouplerRatioDenominator As Double

SOLIDWORKS Type Library

CouplerRatioNumerator Property (ILinearCouplerMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property CouplerRatioNumerator As Double

SOLIDWORKS Type Library

MateEntity1 Property (ILinearCouplerMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MateEntity1 As Object

SOLIDWORKS Type Library

MateEntity2 Property (ILinearCouplerMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MateEntity2 As Object

SOLIDWORKS Type Library

ReferenceComponent1 Property (ILinearCouplerMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property ReferenceComponent1 As Object

SOLIDWORKS Type Library

ReferenceComponent2 Property (ILinearCouplerMateFeatureData)



Visual Basic for Applications (VBA)

Public Property ReferenceComponent2 As Object

SOLIDWORKS Type Library

Reverse Property (ILinearCouplerMateFeatureData)




Visual Basic for Applications (VBA)

Public Property Reverse As Boolean

ILocalCurvePatternFeatureData (Type)

SOLIDWORKS Type Library
ILocalCurvePatternFeatureData Object

Object Model



SOLIDWORKS Type Library
ILocalCurvePatternFeatureData Object Members

Public Methods

	AccessSelections
	GetPatternComponentCount
	GetSkippedItemCount
	GetTransform
	ReleaseSelectionAccess

Public Properties

	D1AlignmentMethod
	D1CurveMethod
	D1Direction
	D1FaceNormal
	D1InstanceCount
	D1IsEqualSpaced
	D1ReferencePoint
	D1ReverseDirection
	D1Spacing
	D2Direction
	D2InstanceCount
	D2IsEqualSpaced
	D2PatternSeedOnly
	D2ReverseDirection
	D2Spacing
	Dir2Specified
	ForceUseSeedConfiguration
	PatternComponentArray
	SelectedPoint
	SkippedItemArray

SOLIDWORKS Type Library
AccessSelections Method (ILocalCurvePatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _  
    ByVal TopDoc As Object, _  
    ByVal Component As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

D1AlignmentMethod Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D1AlignmentMethod As Long
```

SOLIDWORKS Type Library

D1CurveMethod Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D1CurveMethod As Long
```

SOLIDWORKS Type Library

D1Direction Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D1Direction As Object
```

SOLIDWORKS Type Library

D1FaceNormal Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D1FaceNormal As Object
```

SOLIDWORKS Type Library

D1InstanceCount Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D1InstanceCount As Long
```

SOLIDWORKS Type Library

D1IsEqualSpaced Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D1IsEqualSpaced As Boolean
```

SOLIDWORKS Type Library

D1ReferencePoint Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D1ReferencePoint As Long
```

SOLIDWORKS Type Library

D1ReverseDirection Property (ILocalCurvePatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D1ReverseDirection As Boolean

SOLIDWORKS Type Library

D1Spacing Property (ILocalCurvePatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D1Spacing As Double

SOLIDWORKS Type Library

D2Direction Property (ILocalCurvePatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D2Direction As Object

SOLIDWORKS Type Library

D2InstanceCount Property (ILocalCurvePatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D2InstanceCount As Long

SOLIDWORKS Type Library

D2IsEqualSpaced Property (ILocalCurvePatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D2IsEqualSpaced As Boolean

SOLIDWORKS Type Library

D2PatternSeedOnly Property (ILocalCurvePatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D2PatternSeedOnly As Boolean

SOLIDWORKS Type Library

D2ReverseDirection Property (ILocalCurvePatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D2ReverseDirection As Boolean

SOLIDWORKS Type Library

D2Spacing Property (ILocalCurvePatternFeatureData)



Visual Basic for Applications (VBA)

Public Property D2Spacing As Double

SOLIDWORKS Type Library

Dir2Specified Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Dir2Specified As Boolean
```

SOLIDWORKS Type Library

ForceUseSeedConfiguration Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ForceUseSeedConfiguration As Boolean
```

SOLIDWORKS Type Library

GetPatternComponentCount Method (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPatternComponentCount() As Long
```

SOLIDWORKS Type Library

GetSkippedItemCount Method (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSkippedItemCount() As Long
```

SOLIDWORKS Type Library

GetTransform Method (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTransform( _  
    ByVal Instance As Long _  
) As MathTransform
```

SOLIDWORKS Type Library

PatternComponentArray Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PatternComponentArray As Variant
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SelectedPoint Property (ILocalCurvePatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property SelectedPoint As Object
```

SOLIDWORKS Type Library



Syntax

Visual Basic for Applications (VBA)


```
Public Property SkippedItemArray As Variant
```

ILocalSketchPatternFeatureData (Type)

SOLIDWORKS Type Library

ILocalSketchPatternFeatureData Object

Object Model



SOLIDWORKS Type Library

ILocalSketchPatternFeatureData Object Members

Public Methods

	AccessSelections
	GetBasePoint
	GetPatternComponentCount
	GetReferencePointType
	GetSkippedItemCount
	GetTransform
	ReleaseSelectionAccess

Public Properties

	ForceUseSeedConfiguration
	PatternComponentArray
	ReferencePoint
	SelectedPoint
	Sketch
	SkippedItemArray

SOLIDWORKS Type Library

AccessSelections Method (ILocalSketchPatternFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

ForceUseSeedConfiguration Property (ILocalSketchPatternFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Property ForceUseSeedConfiguration As Boolean
```

SOLIDWORKS Type Library

GetBasePoint Method (ILocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBasePoint() As Variant
```

SOLIDWORKS Type Library

GetPatternComponentCount Method (ILocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPatternComponentCount() As Long
```

SOLIDWORKS Type Library

GetReferencePointType Method (ILocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetReferencePointType() As Long
```

SOLIDWORKS Type Library

GetSkippedItemCount Method (ILocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSkippedItemCount() As Long
```

SOLIDWORKS Type Library

GetTransform Method (ILocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTransform( _  
    ByVal Instance As Long _  
) As MathTransform
```

SOLIDWORKS Type Library

PatternComponentArray Property (ILocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PatternComponentArray As Variant
```

SOLIDWORKS Type Library

ReferencePoint Property (ILocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ReferencePoint As Long
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (ILocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SelectedPoint Property (ILocalSketchPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property SelectedPoint As SketchPoint
```

SOLIDWORKS Type Library

Sketch Property (ILocalSketchPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Sketch As Object
```

SOLIDWORKS Type Library

SkippedItemArray Property (ILocalSketchPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property SkippedItemArray As Variant
```

ILockMateFeatureData (Type)

SOLIDWORKS Type Library
ILockMateFeatureData Object

Object Model

ILockMateFeatureData

SOLIDWORKS Type Library
ILockMateFeatureData Object Members

Public Properties

EntitiesToMate

SOLIDWORKS Type Library
EntitiesToMate Property (ILockMateFeatureData)

Syntax

Visual Basic for Applications (VBA)


Public Property EntitiesToMate As Variant

IMagneticLine (Type)

SOLIDWORKS Type Library

IMagneticLine Object

Object Model



SOLIDWORKS Type Library

IMagneticLine Object Members

Public Methods

-  [AddNote](#)
-  [GetNotes](#)
-  [GetNotesCount](#)
-  [IGetNotes](#)
-  [RemoveNote](#)

Public Properties

-  [Angle](#)
-  [EndPoint](#)
-  [EqualSpacing](#)
-  [Length](#)
-  [StartPoint](#)

SOLIDWORKS Type Library

AddNote Method (IMagneticLine)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddNote( _  
    ByVal Note As Note, _  
    ByVal Position As Double _  
) As Boolean
```

SOLIDWORKS Type Library

Angle Property (IMagneticLine)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Angle As Double
```

SOLIDWORKS Type Library

EndPoint Property (IMagneticLine)

Syntax

Visual Basic for Applications (VBA)

Public Property EndPoint As [MathPoint](#)

SOLIDWORKS Type Library

EqualSpacing Property (IMagneticLine)



Visual Basic for Applications (VBA)

Public Property EqualSpacing As Boolean

SOLIDWORKS Type Library

GetNotes Method (IMagneticLine)



Visual Basic for Applications (VBA)

Public Function GetNotes() As Variant

SOLIDWORKS Type Library

GetNotesCount Method (IMagneticLine)



Visual Basic for Applications (VBA)

Public Function GetNotesCount() As Long

SOLIDWORKS Type Library

IGetNotes Method (IMagneticLine)



Visual Basic for Applications (VBA)

```
Public Function IGetNotes( _  
    ByVal Count As Long _  
    ) As Note
```

SOLIDWORKS Type Library

Length Property (IMagneticLine)



Visual Basic for Applications (VBA)

Public Property Length As Double

SOLIDWORKS Type Library

RemoveNote Method (IMagneticLine)



Visual Basic for Applications (VBA)

```
Public Function RemoveNote( _  
    ByVal Note As Note, _  
    ByVal Location As MathPoint _  
    ) As Boolean
```

SOLIDWORKS Type Library

StartPoint Property (IMagneticLine)



Visual Basic for Applications (VBA)

Public Property StartPoint As [MathPoint](#)

IMassProperty2 (Type)

SOLIDWORKS Type Library

IMassProperty2 Object

Object Model

IMassProperty2

SOLIDWORKS Type Library

IMassProperty2 Object Members

Public Methods

 [GetMomentOfInertia](#)

 [GetOverrideOptions](#)

 [Recalculate](#)

 [SetCoordinateSystem](#)

 [SetOverrideOptions](#)

Public Properties

 [AccuracyLevel](#)

 [CenterOfMass](#)

 [Density](#)

 [IncludeHiddenBodiesOrComponents](#)

 [Mass](#)

 [PrincipalAxesOfInertia](#)

 [PrincipalMomentsOfInertia](#)

 [SelectedItems](#)

 [ShowWeldBeadMass](#)

 [SurfaceArea](#)

 [UseSystemUnits](#)

 [Volume](#)

 [WeldBeadMass](#)

SOLIDWORKS Type Library

AccuracyLevel Property (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

Public Property AccuracyLevel As Long

SOLIDWORKS Type Library

CenterOfMass Property (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

Public Property CenterOfMass As Variant

SOLIDWORKS Type Library

Density Property (IMassProperty2)



Syntax

Visual Basic for Applications (VBA)

Public Property Density As Double

SOLIDWORKS Type Library

GetMomentOfInertia Method (IMassProperty2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMomentOfInertia( _  
    ByVal WhereTaken As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetOverrideOptions Method (IMassProperty2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOverrideOptions() As Object
```

SOLIDWORKS Type Library

IncludeHiddenBodiesOrComponents Property (IMassProperty2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property IncludeHiddenBodiesOrComponents As Boolean
```

SOLIDWORKS Type Library

Mass Property (IMassProperty2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Mass As Double
```

SOLIDWORKS Type Library

PrincipalAxesOfInertia Property (IMassProperty2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PrincipalAxesOfInertia( _  
    ByVal Axis As Long _  
) As Variant
```

SOLIDWORKS Type Library

PrincipalMomentsOfInertia Property (IMassProperty2)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PrincipalMomentsOfInertia As Variant
```

SOLIDWORKS Type Library

Recalculate Method (IMassProperty2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function Recalculate() As Boolean
```

SOLIDWORKS Type Library

SelectedItems Property (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SelectedItems As Variant
```

SOLIDWORKS Type Library

SetCoordinateSystem Method (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetCoordinateSystem( _  
    ByVal Coords As Object _  
) As Boolean
```

SOLIDWORKS Type Library

SetOverrideOptions Method (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetOverrideOptions( _  
    ByVal Options As Object, _  
    ByVal Config_option As Long, _  
    ByVal Config_names As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

ShowWeldBeadMass Property (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ShowWeldBeadMass As Boolean
```

SOLIDWORKS Type Library

SurfaceArea Property (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SurfaceArea As Double
```

SOLIDWORKS Type Library

UseSystemUnits Property (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property UseSystemUnits As Boolean
```

SOLIDWORKS Type Library

Volume Property (IMassProperty2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Volume As Double
```

SOLIDWORKS Type Library

WeldBeadMass Property (IMassProperty2)

Public Property WeldBeadMass As Double

IMassPropertyOverrideOptions (Type)

SOLIDWORKS Type Library
IMassPropertyOverrideOptions Object

Object Model

IMassPropertyOverrideOptions

SOLIDWORKS Type Library
IMassPropertyOverrideOptions Object Members

Public Methods

	GetOverrideCenterOfMassValue
	GetOverrideMassValue
	GetOverrideMomentsOfInertiaValue
	GetOverridePrincipalAxesOrientation
	GetOverridePrincipalMomentsOfInertia
	SetOverrideCenterOfMassValue
	SetOverrideMassValue
	SetOverrideMomentsOfInertiaValue
	SetOverridePrincipalAxesOrientation
	SetOverridePrincipalMomentsOfInertia

Public Properties

	OverrideCenterOfMass
	OverrideMass
	OverrideMomentsOfInertia

SOLIDWORKS Type Library
GetOverrideCenterOfMassValue Method (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetOverrideCenterOfMassValue(_ ByRef <i>CoordinateSystemName</i> As String _) As Variant</pre>

SOLIDWORKS Type Library
GetOverrideMassValue Method (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetOverrideMassValue() As Double</pre>

SOLIDWORKS Type Library
GetOverrideMomentsOfInertiaValue Method (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetOverrideMomentsOfInertiaValue(_ ByRef <i>IsReferenceFrameSet</i> As Boolean, _</pre>

```
ByRef CoordinateSystemName As String _  
) As Variant
```

SOLIDWORKS Type Library

GetOverridePrincipalAxesOrientation Method (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOverridePrincipalAxesOrientation( _  
    ByVal Axis As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetOverridePrincipalMomentsOfInertia Method (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOverridePrincipalMomentsOfInertia() As Variant
```

SOLIDWORKS Type Library

OverrideCenterOfMass Property (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OverrideCenterOfMass As Boolean
```

SOLIDWORKS Type Library

OverrideMass Property (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OverrideMass As Boolean
```

SOLIDWORKS Type Library

OverrideMomentsOfInertia Property (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Property OverrideMomentsOfInertia As Boolean
```

SOLIDWORKS Type Library

SetOverrideCenterOfMassValue Method (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetOverrideCenterOfMassValue( _  
    ByVal Value As Variant, _  
    ByVal CoordinateSystemName As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetOverrideMassValue Method (IMassPropertyOverrideOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetOverrideMassValue( _  
    ByVal Value As Double _  
) As Boolean
```

SetOverrideMomentsOfInertiaValue Method (IMassPropertyOverrideOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetOverrideMomentsOfInertiaValue( _  
    ByVal ReferenceFrame As Long, _  
    ByVal Value As Variant, _  
    ByVal CoordinateSystemName As String _  
) As Boolean
```

SetOverridePrincipalAxesOrientation Method (IMassPropertyOverrideOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetOverridePrincipalAxesOrientation( _  
    ByVal Axis As Long, _  
    ByVal Value As Variant, _  
    ByVal AutoCorrect As Boolean _  
) As Boolean
```

SetOverridePrincipalMomentsOfInertia Method (IMassPropertyOverrideOptions) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetOverridePrincipalMomentsOfInertia( _  
    ByVal Value As Variant _  
) As Boolean
```

IMateControllerFeatureData (Type)

SOLIDWORKS Type Library
IMateControllerFeatureData Object

 Object Model

IMateControllerFeatureData

SOLIDWORKS Type Library
IMateControllerFeatureData Object Members

 Public Methods

 AccessSelections
 AddConfigurationFromPosition
 AddNewPosition
 DeletePosition
 GetPositions
 GetValues
 Initialize
 ReleaseSelectionAccess
 ReOrderPositions
 SetValues

 Public Properties

 Mates

SOLIDWORKS Type Library
AccessSelections Method (IMateControllerFeatureData)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library
AddConfigurationFromPosition Method (IMateControllerFeatureData)

 Syntax

```
Visual Basic for Applications (VBA)

Public Function AddConfigurationFromPosition( _
    ByVal PositionName As String, _
    ByVal IsUpdate As Boolean _
) As Boolean
```

SOLIDWORKS Type Library
AddNewPosition Method (IMateControllerFeatureData)

 Syntax

```
Visual Basic for Applications (VBA)
```

```
Public Function AddNewPosition( _  
    ByVal PositionName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeletePosition Method (IMateControllerFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeletePosition( _  
    ByVal PositionName As String _  
) As Boolean
```

SOLIDWORKS Type Library

GetPositions Method (IMateControllerFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPositions() As Variant
```

SOLIDWORKS Type Library

GetValues Method (IMateControllerFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetValues( _  
    ByVal PositionName As String _  
) As Variant
```

SOLIDWORKS Type Library

Initialize Method (IMateControllerFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Initialize( _  
    ByVal Mates As Variant _  
)
```

SOLIDWORKS Type Library

Mates Property (IMateControllerFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Mates As Variant
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (IMateControllerFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

ReOrderPositions Method (IMateControllerFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReOrderPositions( _  
    ByVal Positions As Variant _  
)
```

SOLIDWORKS Type Library

SetValues Method (IMateControllerFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetValues( _  
    ByVal PositionName As String, _  
    ByVal Values As Variant _  
)
```

IMateFeatureData (Type)

SOLIDWORKS Type Library

IMateFeatureData Object

Object Model

IMateFeatureData

SOLIDWORKS Type Library

IMateFeatureData Object Members

Public Properties

ErrorStatus

TypeName

SOLIDWORKS Type Library

ErrorStatus Property (IMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property ErrorStatus As Long

SOLIDWORKS Type Library

TypeName Property (IMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property TypeName As Long