

SOLIDWORKS API (VB6 COM) — Reference (45/102): IRayTraceRendererOptions- ISheetMetalFolder

SOLIDWORKS API Documentation (converted from CHM)

IRayTraceRendererOptions (Type)

SOLIDWORKS Type Library

IRayTraceRendererOptions Object

 Object Model

IRayTraceRendererOptions

SOLIDWORKS Type Library

IRayTraceRendererOptions Object Members

 Public Methods

 [UpdateGraphics](#)

 Public Properties

-  [AlphaOutput](#)
-  [BloomEnabled](#)
-  [BloomRadius](#)
-  [BloomThreshold](#)
-  [CausticAmount](#)
-  [CausticQuality](#)
-  [ClientWorkload](#)
-  [ContourCartoonRenderingEnabled](#)
-  [ContourEnabled](#)
-  [ContourLineColor](#)
-  [ContourLineThickness](#)
-  [CustomRenderSettings](#)
-  [DefaultImagePath](#)
-  [DirectCaustics](#)
-  [FinalRenderQuality](#)
-  [Gamma](#)
-  [HasCartoonEdges](#)
-  [HasCartoonShading](#)
-  [ImageFormat](#)
-  [ImageHeight](#)
-  [ImageWidth](#)
-  [IncludeAnnotationsInRendering](#)
-  [NetworkRendering](#)
-  [NetworkSharedDirectory](#)
-  [NumberOfReflections](#)
-  [NumberOfRefractions](#)
-  [OffloadedRendering](#)
-  [OutputAmbientOcclusion](#)
-  [PreviewRenderQuality](#)

 RenderAnnotationsToSeparateImage
 RenderType
 SendDataForNetworkJob
 ShadedContour
 UseSceneBackgroundImageAspectRatio
 UseSolidWorksViewAspectRatio

SOLIDWORKS Type Library

AlphaOutput Property (IRayTraceRendererOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property AlphaOutput As Boolean

SOLIDWORKS Type Library

BloomEnabled Property (IRayTraceRendererOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property BloomEnabled As Boolean

SOLIDWORKS Type Library

BloomRadius Property (IRayTraceRendererOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property BloomRadius As Long

SOLIDWORKS Type Library

BloomThreshold Property (IRayTraceRendererOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property BloomThreshold As Long

SOLIDWORKS Type Library

CausticAmount Property (IRayTraceRendererOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property CausticAmount As Long

SOLIDWORKS Type Library

CausticQuality Property (IRayTraceRendererOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property CausticQuality As Long

SOLIDWORKS Type Library

ClientWorkload Property (IRayTraceRendererOptions)

Syntax

Visual Basic for Applications (VBA)

Public Property ClientWorkload As Long

SOLIDWORKS Type Library

ContourCartoonRenderingEnabled Property (IRayTraceRendererOptions)



Syntax

Visual Basic for Applications (VBA)

Public Property ContourCartoonRenderingEnabled As Boolean

SOLIDWORKS Type Library

ContourEnabled Property (IRayTraceRendererOptions)



Syntax

Visual Basic for Applications (VBA)

Public Property ContourEnabled As Boolean

SOLIDWORKS Type Library

ContourLineColor Property (IRayTraceRendererOptions)



Syntax

Visual Basic for Applications (VBA)

Public Property ContourLineColor As Long

SOLIDWORKS Type Library

ContourLineThickness Property (IRayTraceRendererOptions)



Syntax

Visual Basic for Applications (VBA)

Public Property ContourLineThickness As Long

SOLIDWORKS Type Library

CustomRenderSettings Property (IRayTraceRendererOptions)



Syntax

Visual Basic for Applications (VBA)

Public Property CustomRenderSettings As Boolean

SOLIDWORKS Type Library

DefaultImagePath Property (IRayTraceRendererOptions)



Syntax

Visual Basic for Applications (VBA)

Public Property DefaultImagePath As String

SOLIDWORKS Type Library

DirectCaustics Property (IRayTraceRendererOptions)



Syntax

Visual Basic for Applications (VBA)

Public Property DirectCaustics As Boolean

SOLIDWORKS Type Library

FinalRenderQuality Property (IRayTraceRendererOptions)



Syntax

Visual Basic for Applications (VBA)

Public Property FinalRenderQuality As Long

SOLIDWORKS Type Library

Gamma Property (IRayTraceRendererOptions)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property Gamma As Double

SOLIDWORKS Type Library

HasCartoonEdges Property (IRayTraceRendererOptions)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property HasCartoonEdges As Boolean

SOLIDWORKS Type Library

HasCartoonShading Property (IRayTraceRendererOptions)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property HasCartoonShading As Boolean

SOLIDWORKS Type Library

ImageFormat Property (IRayTraceRendererOptions)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property ImageFormat As Long

SOLIDWORKS Type Library

ImageHeight Property (IRayTraceRendererOptions)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property ImageHeight As Long

SOLIDWORKS Type Library

ImageWidth Property (IRayTraceRendererOptions)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property ImageWidth As Long

SOLIDWORKS Type Library

IncludeAnnotationsInRendering Property (IRayTraceRendererOptions)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property IncludeAnnotationsInRendering As Boolean

SOLIDWORKS Type Library

NetworkRendering Property (IRayTraceRendererOptions)

 **Syntax**

Visual Basic for Applications (VBA)

Public Property NetworkRendering As Boolean

SOLIDWORKS Type Library

NetworkSharedDirectory Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property NetworkSharedDirectory As String

SOLIDWORKS Type Library

NumberOfReflections Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property NumberOfReflections As Long

SOLIDWORKS Type Library

NumberOfRefractions Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property NumberOfRefractions As Long

SOLIDWORKS Type Library

OffloadedRendering Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property OffloadedRendering As Boolean

SOLIDWORKS Type Library

OutputAmbientOcclusion Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property OutputAmbientOcclusion As Boolean

SOLIDWORKS Type Library

PreviewRenderQuality Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property PreviewRenderQuality As Long

SOLIDWORKS Type Library

RenderAnnotationsToSeparateImage Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property RenderAnnotationsToSeparateImage As Boolean

SOLIDWORKS Type Library

RenderType Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property RenderType As Long

SOLIDWORKS Type Library

SendDataForNetworkJob Property (IRayTraceRendererOptions)



Visual Basic for Applications (VBA)

Public Property SendDataForNetworkJob As Boolean

SOLIDWORKS Type Library

ShadedContour Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property ShadedContour As Boolean

SOLIDWORKS Type Library

UpdateGraphics Method (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Sub UpdateGraphics()

SOLIDWORKS Type Library

UseSceneBackgroundImageAspectRatio Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property UseSceneBackgroundImageAspectRatio As Boolean

SOLIDWORKS Type Library

UseSolidWorksViewAspectRatio Property (IRayTraceRenderOptions)



Visual Basic for Applications (VBA)

Public Property UseSolidWorksViewAspectRatio As Boolean

IRenamedDocumentReferences (Type)

SOLIDWORKS Type Library
IRenamedDocumentReferences Object

 Object Model

IRenamedDocumentReferences

SOLIDWORKS Type Library
IRenamedDocumentReferences Object Members

 Public Methods

	AddSearchFolder
	GetSearchPath
	ReferencesArray
	RemoveReference
	RemoveSearchFolder
	Search

 Public Properties

	CompletionAction
	IncludeFileLocations
	UpdateWhereUsedReferences

SOLIDWORKS Type Library
AddSearchFolder Method (IRenamedDocumentReferences)

 Syntax

Visual Basic for Applications (VBA)
<pre>Public Function AddSearchFolder(_ ByVal Folder As String _) As Boolean</pre>

SOLIDWORKS Type Library
CompletionAction Property (IRenamedDocumentReferences)

 Syntax

Visual Basic for Applications (VBA)
<pre>Public Property CompletionAction As Long</pre>

SOLIDWORKS Type Library
GetSearchPath Method (IRenamedDocumentReferences)

 Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetSearchPath() As Variant</pre>

SOLIDWORKS Type Library
IncludeFileLocations Property (IRenamedDocumentReferences)

 Syntax

Visual Basic for Applications (VBA)

Public Property IncludeFileLocations As Boolean

SOLIDWORKS Type Library

ReferencesArray Method (IRenamedDocumentReferences)



Visual Basic for Applications (VBA)

Public Function ReferencesArray() As Variant

SOLIDWORKS Type Library

RemoveReference Method (IRenamedDocumentReferences)



Visual Basic for Applications (VBA)

```
Public Function RemoveReference( _  
    ByVal Reference As String _  
) As Boolean
```

SOLIDWORKS Type Library

RemoveSearchFolder Method (IRenamedDocumentReferences)



Visual Basic for Applications (VBA)

```
Public Function RemoveSearchFolder( _  
    ByVal Folder As String _  
) As Boolean
```

SOLIDWORKS Type Library

Search Method (IRenamedDocumentReferences)



Visual Basic for Applications (VBA)

Public Sub Search()

SOLIDWORKS Type Library

UpdateWhereUsedReferences Property (IRenamedDocumentReferences)




Visual Basic for Applications (VBA)

Public Property UpdateWhereUsedReferences As Boolean

IRevisionCloud (Type)

SOLIDWORKS Type Library
IRevisionCloud Object

 Object Model



SOLIDWORKS Type Library
IRevisionCloud Object Members



 Public Methods

 Finalize
 GetAnnotation
 GetNext
 GetPathPointAtIndex
 GetPathPointCount
 IGetAnnotation
 IGetNext
 IGetPathPointAtIndex
 SetPathPointAtIndex

 Public Properties

 Angle
 ArcRadius
 Shape

SOLIDWORKS Type Library
Angle Property (IRevisionCloud)

 Syntax

Visual Basic for Applications (VBA)
Public Property Angle As Double

SOLIDWORKS Type Library
ArcRadius Property (IRevisionCloud)

 Syntax

Visual Basic for Applications (VBA)
Public Property ArcRadius As Double

SOLIDWORKS Type Library
Finalize Method (IRevisionCloud)

 Syntax

Visual Basic for Applications (VBA)
Public Function Finalize() As Boolean

SOLIDWORKS Type Library

GetAnnotation Method (IRevisionCloud)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotation() As Object
```

SOLIDWORKS Type Library

GetNext Method (IRevisionCloud)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext() As Object
```

SOLIDWORKS Type Library

GetPathPointAtIndex Method (IRevisionCloud)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPathPointAtIndex( _  
    ByVal Index As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetPathPointCount Method (IRevisionCloud)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPathPointCount() As Long
```

SOLIDWORKS Type Library

IGetAnnotation Method (IRevisionCloud)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAnnotation() As Annotation
```

SOLIDWORKS Type Library

IGetNext Method (IRevisionCloud)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNext() As RevisionCloud
```

SOLIDWORKS Type Library

IGetPathPointAtIndex Method (IRevisionCloud)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPathPointAtIndex( _  
    ByVal Index As Long _  
) As Double
```

SOLIDWORKS Type Library

SetPathPointAtIndex Method (IRevisionCloud)

Syntax

```
Public Function SetPathPointAtIndex( _  
    ByVal Index As Long, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```



```
Public Property Shape As Long
```

IRoutingSettings (Type)

SOLIDWORKS Type Library
IRoutingSettings Object

Object Model

IRoutingSettings

SOLIDWORKS Type Library
IRoutingSettings Object Members

Public Methods

	GetFromToListHeaderDefinitions
	GetRoutingUserPreferenceDoubleValue
	GetRoutingUserPreferenceIntegerValue
	GetRoutingUserPreferenceStringValue
	GetRoutingUserPreferenceToggle
	LoadDefaultRoutingSettings
	LoadRoutingSettingsFromFile
	SaveRoutingSettingsToFile
	SetFromToListHeaderDefinitions
	SetRoutingUserPreferenceDoubleValue
	SetRoutingUserPreferenceIntegerValue
	SetRoutingUserPreferenceStringValue
	SetRoutingUserPreferenceToggle

SOLIDWORKS Type Library
GetFromToListHeaderDefinitions Method (IRoutingSettings)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetFromToListHeaderDefinitions( _
    ByRef WireNameHdr As String, _
    ByRef FromRefHdr As String, _
    ByRef FromPinHdr As String, _
    ByRef FromPartnoHdr As String, _
    ByRef ToRefHdr As String, _
    ByRef ToPinHdr As String, _
    ByRef ToPartnoHdr As String, _
    ByRef CableNameHdr As String, _
    ByRef CoreNameHdr As String, _
    ByRef ColourHdr As String, _
    ByRef WireSpecHdr As String, _
    ByRef OtherAttribHdr As String _
) As Boolean
```

SOLIDWORKS Type Library
GetRoutingUserPreferenceDoubleValue Method (IRoutingSettings)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetRoutingUserPreferenceDoubleValue( _
    ByVal UserPreferenceValue As Long _
```

) As Double

SOLIDWORKS Type Library

GetRoutingUserPreferenceIntegerValue Method (IRoutingSettings)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRoutingUserPreferenceIntegerValue( _  
    ByVal UserPreferenceValue As Long _  
) As Long
```

SOLIDWORKS Type Library

GetRoutingUserPreferenceStringValue Method (IRoutingSettings)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRoutingUserPreferenceStringValue( _  
    ByVal UserPreference As Long, _  
    ByVal UseDefaultVal As Boolean _  
) As String
```

SOLIDWORKS Type Library

GetRoutingUserPreferenceToggle Method (IRoutingSettings)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRoutingUserPreferenceToggle( _  
    ByVal UserPreferenceToggle As Long _  
) As Boolean
```

SOLIDWORKS Type Library

LoadDefaultRoutingSettings Method (IRoutingSettings)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub LoadDefaultRoutingSettings()
```

SOLIDWORKS Type Library

LoadRoutingSettingsFromFile Method (IRoutingSettings)

Syntax

Visual Basic for Applications (VBA)

```
Public Function LoadRoutingSettingsFromFile( _  
    ByVal RoutingSettingsFilename As String _  
) As Boolean
```

SOLIDWORKS Type Library

SaveRoutingSettingsToFile Method (IRoutingSettings)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SaveRoutingSettingsToFile( _  
    ByVal RoutingSettingsFilename As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetFromToListHeaderDefinitions Method (IRoutingSettings)

Syntax

```
Public Function SetFromToListHeaderDefinitions( _
    ByVal WireNameHdr As String, _
    ByVal FromRefHdr As String, _
    ByVal FromPinHdr As String, _
    ByVal FromPartnoHdr As String, _
    ByVal ToRefHdr As String, _
    ByVal ToPinHdr As String, _
    ByVal ToPartnoHdr As String, _
    ByVal CableNameHdr As String, _
    ByVal CoreNameHdr As String, _
    ByVal ColourHdr As String, _
    ByVal WireSpecHdr As String, _
    ByVal OtherAttribHdr As String _
) As Boolean
```

SetRoutingUserPreferenceDoubleValue Method (IRoutingSettings)**Syntax**

```
Public Function SetRoutingUserPreferenceDoubleValue( _
    ByVal UserPreferenceValue As Long, _
    ByVal Value As Double _
) As Boolean
```

SetRoutingUserPreferenceIntegerValue Method (IRoutingSettings)**Syntax**

```
Public Function SetRoutingUserPreferenceIntegerValue( _
    ByVal UserPreferenceValue As Long, _
    ByVal Value As Long _
) As Boolean
```

SetRoutingUserPreferenceStringValue Method (IRoutingSettings)**Syntax**

```
Public Function SetRoutingUserPreferenceStringValue( _
    ByVal UserPreference As Long, _
    ByVal Value As String _
) As Boolean
```

SetRoutingUserPreferenceToggle Method (IRoutingSettings)**Syntax**

```
Public Sub SetRoutingUserPreferenceToggle( _
    ByVal UserPreferenceValue As Long, _
    ByVal OnFlag As Boolean _
)
```

ISafeArrayUtility (Type)

SOLIDWORKS Type Library
ISafeArrayUtility Object

Object Model

ISafeArrayUtility

SOLIDWORKS Type Library
ISafeArrayUtility Object Members

Public Methods

 GetBoolean
 GetBstr
 GetByte
 GetDispatch
 GetDouble
 GetInfo
 GetLong
 GetLongLong
 GetShort
 GetUNKNOWN
 PackVariant
 PutBoolean
 PutBstr
 PutByte
 PutDispatch
 PutDouble
 PutLong
 PutLongLong
 PutShort
 PutUNKNOWN
 UnPackVariant

SOLIDWORKS Type Library
GetBoolean Method (ISafeArrayUtility)

Syntax

```
Visual Basic for Applications (VBA)

Public Function GetBoolean( _
    ByVal VariantArray As Variant, _
    ByVal Index As Long _
) As Boolean
```

SOLIDWORKS Type Library
GetBstr Method (ISafeArrayUtility)

Syntax

```
Visual Basic for Applications (VBA)
```

```
Public Function GetBstr( _  
    ByVal VariantArray As Variant, _  
    ByVal Index As Long _  
) As String
```

SOLIDWORKS Type Library

GetByte Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetByte( _  
    ByVal VariantArray As Variant, _  
    ByVal Index As Long _  
) As Byte
```

SOLIDWORKS Type Library

GetDispatch Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDispatch( _  
    ByVal VariantArray As Variant, _  
    ByVal Index As Long _  
) As Object
```

SOLIDWORKS Type Library

GetDouble Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDouble( _  
    ByVal VariantArray As Variant, _  
    ByVal Index As Long _  
) As Double
```

SOLIDWORKS Type Library

GetInfo Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetInfo( _  
    ByVal VariantArray As Variant, _  
    ByRef Count As Long, _  
    ByRef Type As Long _  
)
```

SOLIDWORKS Type Library

GetLong Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLong( _  
    ByVal VariantArray As Variant, _  
    ByVal Index As Long _  
) As Long
```

SOLIDWORKS Type Library

GetLongLong Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLongLong( _  
    ByVal VariantArray As Variant, _  
    ByVal Index As Long _  
    ) As Unknown
```

SOLIDWORKS Type Library

GetShort Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetShort( _  
    ByVal VariantArray As Variant, _  
    ByVal Index As Long _  
    ) As Integer
```

SOLIDWORKS Type Library

GetUNKNOWN Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUNKNOWN( _  
    ByVal VariantArray As Variant, _  
    ByVal Index As Long _  
    ) As Unknown
```

SOLIDWORKS Type Library

PackVariant Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub PackVariant( _  
    ByRef VariantArray As Variant, _  
    ByVal Count As Long, _  
    ByVal Type As Long, _  
    ByRef Data As Long _  
    )
```

SOLIDWORKS Type Library

PutBoolean Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutBoolean( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As Boolean _  
    )
```

SOLIDWORKS Type Library

PutBstr Method (ISafeArrayUtility)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutBstr( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As String _  
    )
```

SOLIDWORKS Type Library

PutByte Method (ISafeArrayUtility)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutByte( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As Byte _  
)
```

SOLIDWORKS Type Library

PutDispatch Method (ISafeArrayUtility)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutDispatch( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As Object _  
)
```

SOLIDWORKS Type Library

PutDouble Method (ISafeArrayUtility)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutDouble( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As Double _  
)
```

SOLIDWORKS Type Library

PutLong Method (ISafeArrayUtility)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutLong( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As Long _  
)
```

SOLIDWORKS Type Library

PutLongLong Method (ISafeArrayUtility)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutLongLong( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As Unknown _  
)
```

SOLIDWORKS Type Library

PutShort Method (ISafeArrayUtility)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutShort( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As Integer _  
)
```

SOLIDWORKS Type Library

PutUNKNOWN Method (ISafeArrayUtility)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub PutUNKNOWN( _  
    ByRef VariantArray As Variant, _  
    ByVal Index As Long, _  
    ByVal Value As Unknown _  
)
```

SOLIDWORKS Type Library

UnPackVariant Method (ISafeArrayUtility)

Syntax

Visual Basic for Applications (VBA)

```
Public Function UnPackVariant( _  
    ByVal VariantArray As Variant, _  
    ByVal Count As Long _  
) As Long
```

ISaveTo3DExperienceOptions (Type)

SOLIDWORKS Type Library

ISaveTo3DExperienceOptions Object

Object Model

ISaveTo3DExperienceOptions

SOLIDWORKS Type Library

ISaveTo3DExperienceOptions Object Members

Public Methods

 [SetRevisionComments](#)

Public Properties

 [FileName](#)

SOLIDWORKS Type Library

FileName Property (ISaveTo3DExperienceOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FileName As String
```

SOLIDWORKS Type Library

SetRevisionComments Method (ISaveTo3DExperienceOptions)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetRevisionComments( _  
    ByVal RevisionComments As String _  
) As Boolean
```

IScrewMateFeatureData (Type)

SOLIDWORKS Type Library

IScrewMateFeatureData Object

Object Model

IScrewMateFeatureData

SOLIDWORKS Type Library

IScrewMateFeatureData Object Members

Public Properties

EntitiesToMate

MateAlignment

Reverse

RevolutionType

RevolutionVal

SOLIDWORKS Type Library

EntitiesToMate Property (IScrewMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property EntitiesToMate As Variant

SOLIDWORKS Type Library

MateAlignment Property (IScrewMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MateAlignment As Long

SOLIDWORKS Type Library

Reverse Property (IScrewMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property Reverse As Boolean

SOLIDWORKS Type Library

RevolutionType Property (IScrewMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property RevolutionType As Long

SOLIDWORKS Type Library

RevolutionVal Property (IScrewMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property RevolutionVal As Double

ISecondaryMemberBetweenPointsFeatureData (Type)

SOLIDWORKS Type Library

ISecondaryMemberBetweenPointsFeatureData Object

Object Model

ISecondaryMemberBetweenPointsFeatureData

SOLIDWORKS Type Library

ISecondaryMemberBetweenPointsFeatureData Object Members

Public Methods

 [GetMemberPairs](#)

 [SetMemberPairs](#)

Public Properties

 [DistanceMember1](#)

 [DistanceMember2](#)

 [LengthRatioMember1](#)

 [LengthRatioMember2](#)

 [RevDirectionDistanceMember1](#)

 [RevDirectionDistanceMember2](#)

 [RevDirectionLengthRatioMember1](#)

 [RevDirectionLengthRatioMember2](#)

 [SecondaryMemberOffsetType](#)

 [UnChainMemberPairs](#)

SOLIDWORKS Type Library

DistanceMember1 Property (ISecondaryMemberBetweenPointsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property DistanceMember1 As Double
```

SOLIDWORKS Type Library

DistanceMember2 Property (ISecondaryMemberBetweenPointsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property DistanceMember2 As Double
```

SOLIDWORKS Type Library

GetMemberPairs Method (ISecondaryMemberBetweenPointsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMemberPairs() As Variant
```

SOLIDWORKS Type Library

LengthRatioMember1 Property (ISecondaryMemberBetweenPointsFeatureData)



Visual Basic for Applications (VBA)

```
Public Property LengthRatioMember1 As Double
```

SOLIDWORKS Type Library

LengthRatioMember2 Property (ISecondaryMemberBetweenPointsFeatureData)



Visual Basic for Applications (VBA)

```
Public Property LengthRatioMember2 As Double
```

SOLIDWORKS Type Library

RevDirectionDistanceMember1 Property (ISecondaryMemberBetweenPointsFeatureData)



Visual Basic for Applications (VBA)

```
Public Property RevDirectionDistanceMember1 As Boolean
```

SOLIDWORKS Type Library

RevDirectionDistanceMember2 Property (ISecondaryMemberBetweenPointsFeatureData)



Visual Basic for Applications (VBA)

```
Public Property RevDirectionDistanceMember2 As Boolean
```

SOLIDWORKS Type Library

RevDirectionLengthRatioMember1 Property (ISecondaryMemberBetweenPointsFeatureData)



Visual Basic for Applications (VBA)

```
Public Property RevDirectionLengthRatioMember1 As Boolean
```

SOLIDWORKS Type Library

RevDirectionLengthRatioMember2 Property (ISecondaryMemberBetweenPointsFeatureData)



Visual Basic for Applications (VBA)

```
Public Property RevDirectionLengthRatioMember2 As Boolean
```

SOLIDWORKS Type Library

SecondaryMemberOffsetType Property (ISecondaryMemberBetweenPointsFeatureData)



Visual Basic for Applications (VBA)

```
Public Property SecondaryMemberOffsetType As Long
```

SOLIDWORKS Type Library

SetMemberPairs Method (ISecondaryMemberBetweenPointsFeatureData)



Visual Basic for Applications (VBA)

```
Public Function SetMemberPairs( _  
    ByVal Pairs As Variant _  
) As Boolean
```

SOLIDWORKS Type Library



Syntax

Visual Basic for Applications (VBA)

```
Public Property UnChainMemberPairs As Boolean
```

ISecondaryMemberSupportPlaneFeatureData (Type)

SOLIDWORKS Type Library

ISecondaryMemberSupportPlaneFeatureData Object

Object Model

ISecondaryMemberSupportPlaneFeatureData

SOLIDWORKS Type Library

ISecondaryMemberSupportPlaneFeatureData Object Members

Public Methods

 [GetIntersectingObjectTypes](#)

 [GetIntersectingPlanesAndFaces](#)

 [GetMemberPairs](#)

 [SetIntersectingPlanesAndFaces](#)

 [SetMemberPairs](#)

Public Properties

 [UnChainMemberPairs](#)

SOLIDWORKS Type Library

GetIntersectingObjectTypes Method (ISecondaryMemberSupportPlaneFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntersectingObjectTypes() As Variant
```

SOLIDWORKS Type Library

GetIntersectingPlanesAndFaces Method (ISecondaryMemberSupportPlaneFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIntersectingPlanesAndFaces() As Variant
```

SOLIDWORKS Type Library

GetMemberPairs Method (ISecondaryMemberSupportPlaneFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMemberPairs() As Variant
```

SOLIDWORKS Type Library

SetIntersectingPlanesAndFaces Method (ISecondaryMemberSupportPlaneFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetIntersectingPlanesAndFaces( _  
    ByVal RefArray As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SetMemberPairs Method (ISecondaryMemberSupportPlaneFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetMemberPairs( _  
    ByVal Pairs As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

UnChainMemberPairs Property (ISecondaryMemberSupportPlaneFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property UnChainMemberPairs As Boolean
```

ISecondaryMemberUpToMembersFeatureData (Type)

SOLIDWORKS Type Library

ISecondaryMemberUpToMembersFeatureData Object

Object Model

ISecondaryMemberUpToMembersFeatureData

SOLIDWORKS Type Library

ISecondaryMemberUpToMembersFeatureData Object Members

Public Methods

-  [GetFromPoint](#)
-  [GetFromPointMembers](#)
-  [GetPointMemberPairs](#)
-  [SetFromPoint](#)
-  [SetFromPointMembers](#)
-  [SetPointMemberPairs](#)

Public Properties

-  [DistanceMember](#)
-  [LengthRatioMember](#)
-  [MemberPointParametersType](#)
-  [RevDirectionDistanceMember](#)
-  [RevDirectionLengthRatioMember](#)
-  [SecondaryMemberOffsetType](#)

SOLIDWORKS Type Library

DistanceMember Property (ISecondaryMemberUpToMembersFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property DistanceMember As Double

SOLIDWORKS Type Library

GetFromPoint Method (ISecondaryMemberUpToMembersFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetFromPoint( _  
    ByRef Point As Object, _  
    ByRef PointType As Long _  
)
```

SOLIDWORKS Type Library

GetFromPointMembers Method (ISecondaryMemberUpToMembersFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Function GetFromPointMembers() As Variant

GetPointMemberPairs Method (ISecondaryMemberUpToMembersFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub GetPointMemberPairs( _  
    ByRef Points As Variant, _  
    ByRef Members As Variant, _  
    ByRef PointTypes As Variant _  
)
```

LengthRatioMember Property (ISecondaryMemberUpToMembersFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property LengthRatioMember As Double
```

MemberPointParametersType Property (ISecondaryMemberUpToMembersFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property MemberPointParametersType As Long
```

RevDirectionDistanceMember Property (ISecondaryMemberUpToMembersFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property RevDirectionDistanceMember As Boolean
```

RevDirectionLengthRatioMember Property (ISecondaryMemberUpToMembersFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property RevDirectionLengthRatioMember As Boolean
```

SecondaryMemberOffsetType Property (ISecondaryMemberUpToMembersFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property SecondaryMemberOffsetType As Long
```

SetFromPoint Method (ISecondaryMemberUpToMembersFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetFromPoint( _  
    ByVal Point As Object _  
) As Boolean
```

SetFromPointMembers Method (ISecondaryMemberUpToMembersFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetFromPointMembers( _  
    ByVal Members As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SetPointMemberPairs Method (ISecondaryMemberUpToMembersFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetPointMemberPairs( _  
    ByVal Points As Variant, _  
    ByVal Members As Variant _  
) As Boolean
```

ISecondaryStructuralMemberFeatureData (Type)

SOLIDWORKS Type Library

ISecondaryStructuralMemberFeatureData Object

 Object Model

ISecondaryStructuralMemberFeatureData

SOLIDWORKS Type Library

ISecondaryStructuralMemberFeatureData Object Members



 Public Properties

 [SecondaryMemberType](#)

SOLIDWORKS Type Library

SecondaryMemberType Property (ISecondaryStructuralMemberFeatureData)

 Syntax

Visual Basic for Applications (VBA)

Public Property SecondaryMemberType As Long

ISelectionSet (Type)

SOLIDWORKS Type Library

ISelectionSet Object

Object Model

ISelectionSet

SOLIDWORKS Type Library

ISelectionSet Object Members

Public Methods

- [GetName](#)
- [GetSelectionSetItems](#)
- [GetSelectionSetItemTypes](#)
- [RemoveSelectionSet](#)
- [Select](#)

SOLIDWORKS Type Library

GetName Method (ISelectionSet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetName() As String
```

SOLIDWORKS Type Library

GetSelectionSetItems Method (ISelectionSet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSelectionSetItems() As Variant
```

SOLIDWORKS Type Library

GetSelectionSetItemTypes Method (ISelectionSet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSelectionSetItemTypes() As Variant
```

SOLIDWORKS Type Library

RemoveSelectionSet Method (ISelectionSet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveSelectionSet() As Boolean
```

SOLIDWORKS Type Library

Select Method (ISelectionSet)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Select() As Boolean
```

ISelectionSetFolder (Type)

SOLIDWORKS Type Library

ISelectionSetFolder Object

 Object Model

ISelectionSetFolder

SOLIDWORKS Type Library

ISelectionSetFolder Object Members



 Public Methods

 [GetSelectionSetByName](#)

 [GetSelectionSets](#)

SOLIDWORKS Type Library

GetSelectionSetByName Method (ISelectionSetFolder)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSelectionSetByName( _  
    ByVal Name As String _  
) As Object
```

SOLIDWORKS Type Library

GetSelectionSets Method (ISelectionSetFolder)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSelectionSets() As Variant
```

ISelectionSetItem (Type)

SOLIDWORKS Type Library

ISelectionSetItem Object

Object Model

ISelectionSetItem

SOLIDWORKS Type Library

ISelectionSetItem Object Members

Public Methods

[GetCorrespondingItem](#)

[RemoveFromSelectionSet](#)

SOLIDWORKS Type Library

GetCorrespondingItem Method (ISelectionSetItem)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCorrespondingItem() As Object
```

SOLIDWORKS Type Library

RemoveFromSelectionSet Method (ISelectionSetItem)


Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveFromSelectionSet()
```

ISheetMetalFolder (Type)

SOLIDWORKS Type Library
ISheetMetalFolder Object



SOLIDWORKS Type Library
ISheetMetalFolder Object Members

Public Methods

-  [GetFeature](#)
-  [GetSheetMetalCount](#)
-  [GetSheetMetals](#)

SOLIDWORKS Type Library
GetFeature Method (ISheetMetalFolder)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeature() As Feature
```

SOLIDWORKS Type Library
GetSheetMetalCount Method (ISheetMetalFolder)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSheetMetalCount() As Long
```

SOLIDWORKS Type Library
GetSheetMetals Method (ISheetMetalFolder)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSheetMetals() As Variant
```