


SOLIDWORKS API (VB6 COM) — Reference (50/102): LocalLinearPatternFeatureData-Loop

SOLIDWORKS API Documentation (converted from CHM)

LocalLinearPatternFeatureData (Type)

SOLIDWORKS Type Library
LocalLinearPatternFeatureData Object

Object Model



SOLIDWORKS Type Library
LocalLinearPatternFeatureData Object Members

Public Methods

	AccessSelections
	GetD1AxisType
	GetD2AxisType
	GetModifiedInstance
	GetModifiedInstances
	GetSeedComponentCount
	GetSkippedItemCount
	GetTransform
	IAccessSelections
	IAccessSelections2
	IGetSeedComponentArray
	IGetSkippedItemArray
	ISetSeedComponentArray
	ISetSkippedItemArray
	ModifyInstance
	ReleaseSelectionAccess

Public Properties

	AlignToSeed
	D1Axis
	D1EndCondition
	D1EndReference
	D1EndReferenceType
	D1EndRefOffset
	D1EndRefReverseOffset
	D1EndSeedReference
	D1EndSeedReferenceType
	D1EndUseSeedReference
	D1EndUseSpacing
	D1ReverseDirection
	D1Spacing
	D1TotalInstances

	
	D2Axis
	D2EndCondition
	D2EndReference
	D2EndReferenceType
	D2EndRefOffset
	D2EndRefReverseOffset
	D2EndSeedReference
	D2EndSeedReferenceType
	D2EndUseSeedReference
	D2EndUseSpacing
	D2PatternSeedOnly
	D2ReverseDirection
	D2Spacing
	D2TotalInstances
	FixedAxisOfRotation
	ForceUseSeedConfiguration
	ReverseAxisOfRotation
	RotateInstances
	RotationAngle
	RotationAxis
	SeedAlignmentReferencePoint
	SeedComponentArray
	SkippedItemArray
	SynchronizeFlexibleComponents

SOLIDWORKS Type Library

AccessSelections Method (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

AlignToSeed Property (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AlignToSeed As Boolean
```

SOLIDWORKS Type Library

D1Axis Property (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property D1Axis As Object
```

SOLIDWORKS Type Library

D1EndCondition Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndCondition As Long
```

SOLIDWORKS Type Library

D1EndReference Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndReference As Object
```

SOLIDWORKS Type Library

D1EndReferenceType Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndReferenceType As Long
```

SOLIDWORKS Type Library

D1EndRefOffset Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndRefOffset As Double
```

SOLIDWORKS Type Library

D1EndRefReverseOffset Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndRefReverseOffset As Boolean
```

SOLIDWORKS Type Library

D1EndSeedReference Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndSeedReference As Object
```

SOLIDWORKS Type Library

D1EndSeedReferenceType Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndSeedReferenceType As Long
```

SOLIDWORKS Type Library

D1EndUseSeedReference Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndUseSeedReference As Boolean
```

SOLIDWORKS Type Library

D1EndUseSpacing Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1EndUseSpacing As Boolean
```

SOLIDWORKS Type Library

D1ReverseDirection Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1ReverseDirection As Boolean
```

SOLIDWORKS Type Library

D1Spacing Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1Spacing As Double
```

SOLIDWORKS Type Library

D1TotalInstances Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D1TotalInstances As Long
```

SOLIDWORKS Type Library

D2Axis Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D2Axis As Object
```

SOLIDWORKS Type Library

D2EndCondition Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D2EndCondition As Long
```

SOLIDWORKS Type Library

D2EndReference Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D2EndReference As Object
```

SOLIDWORKS Type Library

D2EndReferenceType Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Property D2EndReferenceType As Long
```

SOLIDWORKS Type Library

D2EndRefOffset Property (LocalLinearPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2EndRefOffset As Double
```

SOLIDWORKS Type Library

D2EndRefReverseOffset Property (LocalLinearPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2EndRefReverseOffset As Boolean
```

SOLIDWORKS Type Library

D2EndSeedReference Property (LocalLinearPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2EndSeedReference As Object
```

SOLIDWORKS Type Library

D2EndSeedReferenceType Property (LocalLinearPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2EndSeedReferenceType As Long
```

SOLIDWORKS Type Library

D2EndUseSeedReference Property (LocalLinearPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2EndUseSeedReference As Boolean
```

SOLIDWORKS Type Library

D2EndUseSpacing Property (LocalLinearPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2EndUseSpacing As Boolean
```

SOLIDWORKS Type Library

D2PatternSeedOnly Property (LocalLinearPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2PatternSeedOnly As Boolean
```

SOLIDWORKS Type Library

D2ReverseDirection Property (LocalLinearPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property D2ReverseDirection As Boolean
```

SOLIDWORKS Type Library

D2Spacing Property (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property D2Spacing As Double
```

SOLIDWORKS Type Library

D2TotalInstances Property (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property D2TotalInstances As Long
```

SOLIDWORKS Type Library

FixedAxisOfRotation Property (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FixedAxisOfRotation As Boolean
```

SOLIDWORKS Type Library

ForceUseSeedConfiguration Property (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ForceUseSeedConfiguration As Boolean
```

SOLIDWORKS Type Library

GetD1AxisType Method (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetD1AxisType() As Long
```

SOLIDWORKS Type Library

GetD2AxisType Method (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetD2AxisType() As Long
```

SOLIDWORKS Type Library

GetModifiedInstance Method (LocalLinearPatternFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetModifiedInstance( _  
    ByVal Instance As Long, _  
    ByRef D1Distance As Double, _  
    ByRef D1NominalVal As Double, _  
    ByRef D2Distance As Double, _  
    ByRef D2NominalVal As Double _  
)
```

SOLIDWORKS Type Library

GetModifiedInstances Method (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetModifiedInstances() As Variant
```

SOLIDWORKS Type Library

GetSeedComponentCount Method (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetSeedComponentCount() As Long
```

SOLIDWORKS Type Library

GetSkippedItemCount Method (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetSkippedItemCount() As Long
```

SOLIDWORKS Type Library

GetTransform Method (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function GetTransform( _  
    ByVal Instance As Long _  
    ) As MathTransform
```

SOLIDWORKS Type Library

IAccessSelections Method (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
    ) As Boolean
```

SOLIDWORKS Type Library

IAccessSelections2 Method (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As Boolean
```

SOLIDWORKS Type Library

IGetSeedComponentArray Method (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

```
Public Function IGetSeedComponentArray() As Object
```

SOLIDWORKS Type Library

IGetSkippedItemArray Method (LocalLinearPatternFeatureData)



```
Public Function IGetSkippedItemArray() As Long
```

SOLIDWORKS Type Library

ISetSeedComponentArray Method (LocalLinearPatternFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub ISetSeedComponentArray( _  
    ByVal FeatCount As Long, _  
    ByRef ArrayDataIn As Object _  
)
```

SOLIDWORKS Type Library

ISetSkippedItemArray Method (LocalLinearPatternFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub ISetSkippedItemArray( _  
    ByVal FeatCount As Long, _  
    ByRef ArrayDataIn As Long _  
)
```

SOLIDWORKS Type Library

ModifyInstance Method (LocalLinearPatternFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ModifyInstance( _  
    ByVal Instance As Long, _  
    ByVal D1Distance As Double, _  
    ByVal IsD1OffsetFromNominal As Boolean, _  
    ByVal D2Distance As Double, _  
    ByVal IsD2OffsetFromNominal As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (LocalLinearPatternFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

ReverseAxisOfRotation Property (LocalLinearPatternFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property ReverseAxisOfRotation As Boolean
```

SOLIDWORKS Type Library

RotateInstances Property (LocalLinearPatternFeatureData) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property RotateInstances As Boolean
```

SOLIDWORKS Type Library

RotationAngle Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property RotationAngle As Double

SOLIDWORKS Type Library

RotationAxis Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property RotationAxis As Object

SOLIDWORKS Type Library

SeedAlignmentReferencePoint Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SeedAlignmentReferencePoint As Long

SOLIDWORKS Type Library

SeedComponentArray Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SeedComponentArray As Variant

SOLIDWORKS Type Library

SkippedItemArray Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SkippedItemArray As Variant

SOLIDWORKS Type Library

SynchronizeFlexibleComponents Property (LocalLinearPatternFeatureData)



Visual Basic for Applications (VBA)


Public Property SynchronizeFlexibleComponents As Boolean

LocalSketchPatternFeatureData (Type)

SOLIDWORKS Type Library

LocalSketchPatternFeatureData Object

Object Model



SOLIDWORKS Type Library

LocalSketchPatternFeatureData Object Members

Public Methods

	AccessSelections
	GetBasePoint
	GetPatternComponentCount
	GetReferencePointType
	GetSkippedItemCount
	GetTransform
	ReleaseSelectionAccess

Public Properties

	ForceUseSeedConfiguration
	PatternComponentArray
	ReferencePoint
	SelectedPoint
	Sketch
	SkippedItemArray

SOLIDWORKS Type Library

AccessSelections Method (LocalSketchPatternFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

ForceUseSeedConfiguration Property (LocalSketchPatternFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Property ForceUseSeedConfiguration As Boolean
```

SOLIDWORKS Type Library

GetBasePoint Method (LocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBasePoint() As Variant
```

SOLIDWORKS Type Library

GetPatternComponentCount Method (LocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPatternComponentCount() As Long
```

SOLIDWORKS Type Library

GetReferencePointType Method (LocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetReferencePointType() As Long
```

SOLIDWORKS Type Library

GetSkippedItemCount Method (LocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSkippedItemCount() As Long
```

SOLIDWORKS Type Library

GetTransform Method (LocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTransform( _  
    ByVal Instance As Long _  
) As MathTransform
```

SOLIDWORKS Type Library

PatternComponentArray Property (LocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PatternComponentArray As Variant
```

SOLIDWORKS Type Library

ReferencePoint Property (LocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ReferencePoint As Long
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (LocalSketchPatternFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SelectedPoint Property (LocalSketchPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SelectedPoint As [SketchPoint](#)

SOLIDWORKS Type Library

Sketch Property (LocalSketchPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property Sketch As Object

SOLIDWORKS Type Library

SkippedItemArray Property (LocalSketchPatternFeatureData)



Visual Basic for Applications (VBA)

Public Property SkippedItemArray As Variant

LockMateFeatureData (Type)

SOLIDWORKS Type Library

LockMateFeatureData Object

 Object Model

LockMateFeatureData

SOLIDWORKS Type Library

LockMateFeatureData Object Members



 Public Properties

 [EntitiesToMate](#)

SOLIDWORKS Type Library

EntitiesToMate Property (LockMateFeatureData)

 Syntax

Visual Basic for Applications (VBA)

Public Property EntitiesToMate As Variant

LoftedBendsFeatureData (Type)

SOLIDWORKS Type Library

LoftedBendsFeatureData Object

Object Model

LoftedBendsFeatureData

SOLIDWORKS Type Library

LoftedBendsFeatureData Object Members

Public Methods

	AccessSelections
	CanCreateBendLines
	GetProfileCount
	IAccessSelections
	IGetProfiles
	ISetProfiles
	ReleaseSelectionAccess

Public Properties

	BendLineControlOption
	Direction
	FacetingOption
	FacetValue
	FormedMethod
	MaximumDeviation
	NumberOfBendLines
	Profiles
	ReferToEndPoint
	SymmetricThickness
	Thickness

SOLIDWORKS Type Library

AccessSelections Method (LoftedBendsFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

BendLineControlOption Property (LoftedBendsFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Property BendLineControlOption As Long
```

SOLIDWORKS Type Library

CanCreateBendLines Method (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CanCreateBendLines() As Boolean
```

SOLIDWORKS Type Library

Direction Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Direction As Boolean
```

SOLIDWORKS Type Library

FacetingOption Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FacetingOption As Long
```

SOLIDWORKS Type Library

FacetValue Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FacetValue As Double
```

SOLIDWORKS Type Library

FormedMethod Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FormedMethod As Boolean
```

SOLIDWORKS Type Library

GetProfileCount Method (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProfileCount() As Long
```

SOLIDWORKS Type Library

IAccessSelections Method (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As Boolean
```

SOLIDWORKS Type Library

IGetProfiles Method (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetProfiles( _  
    ByVal Count As Long _  
    ) As Object
```

SOLIDWORKS Type Library

ISetProfiles Method (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetProfiles( _  
    ByVal Count As Long, _  
    ByRef PDisp As Object _  
    )
```

SOLIDWORKS Type Library

MaximumDeviation Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaximumDeviation As Double
```

SOLIDWORKS Type Library

NumberOfBendLines Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property NumberOfBendLines As Long
```

SOLIDWORKS Type Library

Profiles Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Profiles As Variant
```

SOLIDWORKS Type Library

ReferToEndPoint Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ReferToEndPoint As Boolean
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

SymmetricThickness Property (LoftedBendsFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SymmetricThickness As Boolean
```

SOLIDWORKS Type Library



Syntax

Visual Basic for Applications (VBA)

Public Property Thickness As Double

LoftFeatureData (Type)

SOLIDWORKS Type Library
LoftFeatureData Object

Object Model

LoftFeatureData

IGetFeatureScopeBodies (Body2)

SOLIDWORKS Type Library
LoftFeatureData Object Members

Public Methods

	AccessSelections
	GetFeatureScopeBodiesCount
	GetGuideCurvesCount
	GetGuideCurvesType
	GetGuideTangencyType
	GetProfileCount
	GetWallThickness
	IAccessSelections
	IGetFeatureScopeBodies
	IGetGuideCurves
	IGetGuideCurvesType
	IGetProfiles
	IsBossFeature
	ISetFeatureScopeBodies
	ISetGuideCurves
	ISetProfiles
	IsThinFeature
	ReleaseSelectionAccess
	SetGuideTangencyType
	SetWallThickness

Public Properties

	AdvancedSmoothing
	AutoSelect
	Centerline
	Close
	EndConstraintApplyToAll
	EndConstraintDraftAngle
	EndConstraintDraftAngleDirection
	EndDirectionVector
	EndTangencyType
	EndTangentLength


 FeatureScope
 FeatureScopeBodies
 GuideCurveInfluence
 GuideCurves
 MaintainTangency
 Merge
 NumberOfSections
 PickPoints
 Profiles
 ReverseEndTangentDirection
 ReverseStartTangentDirection
 StartConstraintApplyToAll
 StartConstraintDraftAngle
 StartConstraintDraftAngleDirection
 StartDirectionVector
 StartTangencyType
 StartTangentLength
 ThinWallType

SOLIDWORKS Type Library

AccessSelections Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library

AdvancedSmoothing Property (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AdvancedSmoothing As Boolean
```

SOLIDWORKS Type Library

AutoSelect Property (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AutoSelect As Boolean
```

SOLIDWORKS Type Library

Centerline Property (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Centerline As Object
```

Close Property (LoftFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Close As Boolean
```

SOLIDWORKS Type Library
EndConstraintApplyToAll Property (LoftFeatureData)



Visual Basic for Applications (VBA)

```
Public Property EndConstraintApplyToAll As Boolean
```

SOLIDWORKS Type Library
EndConstraintDraftAngle Property (LoftFeatureData)



Visual Basic for Applications (VBA)

```
Public Property EndConstraintDraftAngle As Double
```

SOLIDWORKS Type Library
EndConstraintDraftAngleDirection Property (LoftFeatureData)



Visual Basic for Applications (VBA)

```
Public Property EndConstraintDraftAngleDirection As Boolean
```

SOLIDWORKS Type Library
EndDirectionVector Property (LoftFeatureData)



Visual Basic for Applications (VBA)

```
Public Property EndDirectionVector As Object
```

SOLIDWORKS Type Library
EndTangencyType Property (LoftFeatureData)



Visual Basic for Applications (VBA)

```
Public Property EndTangencyType As Integer
```

SOLIDWORKS Type Library
EndTangentLength Property (LoftFeatureData)



Visual Basic for Applications (VBA)

```
Public Property EndTangentLength As Double
```

SOLIDWORKS Type Library
FeatureScope Property (LoftFeatureData)



Visual Basic for Applications (VBA)

```
Public Property FeatureScope As Boolean
```

SOLIDWORKS Type Library

FeatureScopeBodies Property (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Property FeatureScopeBodies As Variant
```

SOLIDWORKS Type Library

GetFeatureScopeBodiesCount Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeatureScopeBodiesCount() As Long
```

SOLIDWORKS Type Library

GetGuideCurvesCount Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetGuideCurvesCount() As Integer
```

SOLIDWORKS Type Library

GetGuideCurvesType Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetGuideCurvesType() As Variant
```

SOLIDWORKS Type Library

GetGuideTangencyType Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetGuideTangencyType( _  
    ByVal GuideIndex As Integer _  
) As Integer
```

SOLIDWORKS Type Library

GetProfileCount Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetProfileCount() As Integer
```

SOLIDWORKS Type Library

GetWallThickness Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetWallThickness( _  
    ByVal Forward As Boolean _  
) As Double
```

SOLIDWORKS Type Library

GuideCurveInfluence Property (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property GuideCurveInfluence As Long

SOLIDWORKS Type Library

GuideCurves Property (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property GuideCurves As Variant

SOLIDWORKS Type Library

IAccessSelections Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As Boolean
```

SOLIDWORKS Type Library

IGetFeatureScopeBodies Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFeatureScopeBodies( _  
    ByVal Count As Long _  
) As Body2
```

SOLIDWORKS Type Library

IGetGuideCurves Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetGuideCurves( _  
    ByVal Count As Integer _  
) As Object
```

SOLIDWORKS Type Library

IGetGuideCurvesType Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetGuideCurvesType( _  
    ByVal Count As Long _  
) As Long
```

SOLIDWORKS Type Library

IGetProfiles Method (LoftFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetProfiles( _  
    ByVal Count As Integer _  
) As Object
```

SOLIDWORKS Type Library

IsBossFeature Method (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsBossFeature() As Boolean
```

SOLIDWORKS Type Library

ISetFeatureScopeBodies Method (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetFeatureScopeBodies( _  
    ByVal Count As Long, _  
    ByVal BodyArr As Body2 _  
)
```

SOLIDWORKS Type Library

ISetGuideCurves Method (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetGuideCurves( _  
    ByVal Count As Integer, _  
    ByRef PDisp As Object _  
)
```

SOLIDWORKS Type Library

ISetProfiles Method (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetProfiles( _  
    ByVal Count As Integer, _  
    ByRef PDisp As Object _  
)
```

SOLIDWORKS Type Library

IsThinFeature Method (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsThinFeature() As Boolean
```

SOLIDWORKS Type Library

MaintainTangency Property (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property MaintainTangency As Boolean
```

SOLIDWORKS Type Library

Merge Property (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Merge As Boolean
```

SOLIDWORKS Type Library

NumberOfSections Property (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property NumberOfSections As Double
```

SOLIDWORKS Type Library

PickPoints Property (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property PickPoints As Variant
```

SOLIDWORKS Type Library

Profiles Property (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Profiles As Variant
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

ReverseEndTangentDirection Property (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ReverseEndTangentDirection As Boolean
```

SOLIDWORKS Type Library

ReverseStartTangentDirection Property (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Property ReverseStartTangentDirection As Boolean
```

SOLIDWORKS Type Library

SetGuideTangencyType Method (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetGuideTangencyType( _  
    ByVal GuideIndex As Integer, _  
    ByVal TangType As Integer _  
)
```

SOLIDWORKS Type Library

SetWallThickness Method (LoftFeatureData)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetWallThickness( _  
    ByVal Forward As Boolean, _
```

```
ByVal WallThickness As Double _  
)
```

SOLIDWORKS Type Library
StartConstraintApplyToAll Property (LoftFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property StartConstraintApplyToAll As Boolean
```

SOLIDWORKS Type Library
StartConstraintDraftAngle Property (LoftFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property StartConstraintDraftAngle As Double
```

SOLIDWORKS Type Library
StartConstraintDraftAngleDirection Property (LoftFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property StartConstraintDraftAngleDirection As Boolean
```

SOLIDWORKS Type Library
StartDirectionVector Property (LoftFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property StartDirectionVector As Object
```

SOLIDWORKS Type Library
StartTangencyType Property (LoftFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property StartTangencyType As Integer
```

SOLIDWORKS Type Library
StartTangentLength Property (LoftFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)

```
Public Property StartTangentLength As Double
```

SOLIDWORKS Type Library
ThinWallType Property (LoftFeatureData)

 **Syntax**

Visual Basic for Applications (VBA)


```
Public Property ThinWallType As Integer
```

Loop (Type)

SOLIDWORKS Type Library

Loop Object

Object Model



SOLIDWORKS Type Library

Loop Object Members

Public Methods

 EnumCoEdges
 EnumEdges
 GetEdgeCount
 GetEdges
 GetFace
 GetFirstCoEdge
 GetNext
 IGetEdges
 IGetFace
 IGetFirstCoEdge
 IGetNext
 IRevolvePlanarLoop
 IsOuter
 ISweepPlanarLoop
 RevolvePlanarLoop
 SweepPlanarLoop

SOLIDWORKS Type Library

EnumCoEdges Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumCoEdges() As EnumCoEdges
```

SOLIDWORKS Type Library

EnumEdges Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumEdges() As EnumEdges
```

SOLIDWORKS Type Library

GetEdgeCount Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEdgeCount() As Long
```

SOLIDWORKS Type Library

GetEdges Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEdges() As Variant
```

SOLIDWORKS Type Library

GetFace Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFace() As Object
```

SOLIDWORKS Type Library

GetFirstCoEdge Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFirstCoEdge() As Object
```

SOLIDWORKS Type Library

GetNext Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext() As Object
```

SOLIDWORKS Type Library

IGetEdges Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEdges() As Edge
```

SOLIDWORKS Type Library

IGetFace Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFace() As Face
```

SOLIDWORKS Type Library

IGetFirstCoEdge Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFirstCoEdge() As CoEdge
```

SOLIDWORKS Type Library

IGetNext Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNext() As Loop
```

SOLIDWORKS Type Library

IRevolvePlanarLoop Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IRevolvePlanarLoop( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal Axisx As Double, _  
    ByVal Axisy As Double, _  
    ByVal Axisz As Double, _  
    ByVal RevAngle As Double, _  
    ByVal StopFacesOut As Face _  
    ) As Body
```

SOLIDWORKS Type Library

IsOuter Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsOuter() As Boolean
```

SOLIDWORKS Type Library

ISweepPlanarLoop Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISweepPlanarLoop( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal DraftAngle As Double, _  
    ByVal StopFacesOut As Face _  
    ) As Body
```

SOLIDWORKS Type Library

RevolvePlanarLoop Method (Loop)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RevolvePlanarLoop( _  
    ByVal X As Double, _
```

```
ByVal Y As Double, _  
ByVal Z As Double, _  
ByVal Axisx As Double, _  
ByVal Axisy As Double, _  
ByVal Axisz As Double, _  
ByVal RevAngle As Double _  
) As Variant
```

SOLIDWORKS Type Library

SweepPlanarLoop Method (Loop)



Visual Basic for Applications (VBA)

```
Public Function SweepPlanarLoop( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal DraftAngle As Double _  
) As Variant
```