

SOLIDWORKS API (VB6 COM) — Reference (57/102): ModelDoc (part 3 of 4)

SOLIDWORKS API Documentation (converted from CHM)

ModelDoc (part 3 of 4) (Type)

SOLIDWORKS Type Library

IGetCustomInfoNames2 Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetCustomInfoNames2( _  
    ByVal Configuration As String _  
) As String
```

SOLIDWORKS Type Library

IGetDependencies Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetDependencies( _  
    ByVal Traverseflag As Long, _  
    ByVal Searchflag As Long _  
) As String
```

SOLIDWORKS Type Library

IGetDependencies2 Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetDependencies2( _  
    ByVal Traverseflag As Boolean, _  
    ByVal Searchflag As Boolean, _  
    ByVal AddReadOnlyInfo As Boolean _  
) As String
```

SOLIDWORKS Type Library

IGetDesignTable Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetDesignTable() As DesignTable
```

SOLIDWORKS Type Library

IGetDetailingDefaults Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetDetailingDefaults() As DetailingDefaults
```

SOLIDWORKS Type Library

IGetEntityName Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetEntityName( _  
    ByVal Entity As Entity _  
) As String
```

SOLIDWORKS Type Library

IGetFirstAnnotation Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetFirstAnnotation() As Annotation
```

SOLIDWORKS Type Library

IGetFirstAnnotation2 Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetFirstAnnotation2() As Annotation
```

SOLIDWORKS Type Library

IGetFirstModelView Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetFirstModelView() As ModelView
```

SOLIDWORKS Type Library

IGetLayerManager Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetLayerManager() As LayerMgr
```

SOLIDWORKS Type Library

IGetLines Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetLines() As Double
```

SOLIDWORKS Type Library

IGetMassProperties Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetMassProperties( _  
    ByRef MPropsData As Double _  
) As Boolean
```

SOLIDWORKS Type Library

IGetMassProperties2 Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetMassProperties2( _  
    ByRef Status As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetModelViewNames Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetModelViewNames() As String
```

SOLIDWORKS Type Library

IGetNext Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNext() As ModelDoc
```

SOLIDWORKS Type Library

IGetNumDependencies Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNumDependencies( _  
    ByVal Traverseflag As Long, _  
    ByVal Searchflag As Long _  
) As Long
```

SOLIDWORKS Type Library

IGetNumDependencies2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNumDependencies2( _  
    ByVal Traverseflag As Boolean, _  
    ByVal Searchflag As Boolean, _  
    ByVal AddReadOnlyInfo As Boolean _  
) As Long
```

SOLIDWORKS Type Library

IGetRayIntersectionsPoints Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetRayIntersectionsPoints() As Double
```

SOLIDWORKS Type Library

IGetRayIntersectionsTopology Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetRayIntersectionsTopology() As Unknown
```

SOLIDWORKS Type Library

IGetStandardViewRotation Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetStandardViewRotation( _  
    ByVal ViewId As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetUnits Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUnits() As Integer
```

SOLIDWORKS Type Library

IGetUserPreferenceTextFormat Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUserPreferenceTextFormat( _  
    ByVal UserPreferenceValue As Long _  
) As TextFormat
```

SOLIDWORKS Type Library

IGetUserUnit Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetUserUnit( _  
    ByVal UnitType As Long _  
) As UserUnit
```

SOLIDWORKS Type Library

IGetVersionHistoryCount Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetVersionHistoryCount() As Integer
```

SOLIDWORKS Type Library

IInsertBOMBalloon2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IInsertBOMBalloon2( _  
    ByVal Style As Long, _  
    ByVal Size As Long, _  
    ByVal UpperTextStyle As Long, _  
    ByVal UpperText As String, _  
    ByVal LowerTextStyle As Long, _  
    ByVal LowerText As String _  
) As Note
```

SOLIDWORKS Type Library

IInsertDatumTag2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IInsertDatumTag2() As DatumTag
```

SOLIDWORKS Type Library

IInsertGtol Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IInsertGtol() As Gtol
```

SOLIDWORKS Type Library

IInsertMidSurfaceExt Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IInsertMidSurfaceExt( _  
    ByVal Placement As Double, _
```

```
ByVal KnitFlag As Boolean _  
) As MidSurface
```

SOLIDWORKS Type Library

IInsertNote Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IInsertNote( _  
    ByVal Text As String _  
) As Note
```

SOLIDWORKS Type Library

IInsertProjectedSketch2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IInsertProjectedSketch2( _  
    ByVal Reverse As Long _  
) As Feature
```

SOLIDWORKS Type Library

IInsertWeldSymbol3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IInsertWeldSymbol3() As WeldSymbol
```

SOLIDWORKS Type Library

ILightSourcePropertyValues Property (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ILightSourcePropertyValues( _  
    ByVal ID As Long _  
) As Double
```

SOLIDWORKS Type Library

IListExternalFileReferences Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IListExternalFileReferences( _  
    ByVal UseSearchRules As Boolean, _  
    ByVal NumRefs As Long _  
) As String
```

SOLIDWORKS Type Library

IMaterialPropertyValues Property (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IMaterialPropertyValues As Double
```

SOLIDWORKS Type Library

IMultiSelectByRay Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IMultiSelectByRay( _  
    ByRef PointIn As Double, _  
    ByRef VectorIn As Double, _  
    ByVal RadiusIn As Double, _  
    ByVal TypeWanted As Long, _  
    ByVal Append As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

Insert3DSketch Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub Insert3DSketch()
```

SOLIDWORKS Type Library

Insert3DSketch2 Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub Insert3DSketch2( _  
    ByVal UpdateEditRebuild As Boolean _  
)
```

SOLIDWORKS Type Library

Insert3DSplineCurve Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub Insert3DSplineCurve( _  
    ByVal CurveClosed As Boolean _  
)
```

SOLIDWORKS Type Library

InsertAxis Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertAxis() As Boolean
```

SOLIDWORKS Type Library

InsertBendTableEdit Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertBendTableEdit()
```

SOLIDWORKS Type Library

InsertBendTableNew Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBendTableNew( _  
    ByVal FileName As String, _  
    ByVal Units As String, _  
    ByVal Type As String _  
) As Boolean
```

SOLIDWORKS Type Library

InsertBendTableOpen Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBendTableOpen( _  
    ByVal FileName As String _  
) As Boolean
```

SOLIDWORKS Type Library

InsertBkgImage Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertBkgImage( _  
    ByVal NewName As String _  
)
```

SOLIDWORKS Type Library

InsertBOMBalloon Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertBOMBalloon()
```

SOLIDWORKS Type Library

InsertBOMBalloon2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBOMBalloon2( _  
    ByVal Style As Long, _  
    ByVal Size As Long, _  
    ByVal UpperTextStyle As Long, _  
    ByVal UpperText As String, _  
    ByVal LowerTextStyle As Long, _  
    ByVal LowerText As String _  
) As Object
```

SOLIDWORKS Type Library

InsertCompositeCurve Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertCompositeCurve() As Boolean
```

SOLIDWORKS Type Library

InsertConnectionPoint Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertConnectionPoint()
```

SOLIDWORKS Type Library

InsertCoordinateSystem Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)


```
Public Function InsertCoordinateSystem( _  
    ByVal XFlippedIn As Boolean, _  
    ByVal YFlippedIn As Boolean, _  
    ByVal ZFlippedIn As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

InsertCosmeticThread Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCosmeticThread( _  
    ByVal Type As Integer, _  
    ByVal Depth As Double, _  
    ByVal Length As Double, _  
    ByVal Note As String _  
)
```

SOLIDWORKS Type Library

InsertCurveFile Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertCurveFile( _  
    ByVal FileName As String _  
) As Boolean
```

SOLIDWORKS Type Library

InsertCurveFileBegin Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCurveFileBegin()
```

SOLIDWORKS Type Library

InsertCurveFileEnd Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertCurveFileEnd() As Boolean
```

SOLIDWORKS Type Library

InsertCurveFilePoint Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertCurveFilePoint( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

InsertCutBlend Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutBlend( _  
    ByVal Closed As Boolean _
```

)

SOLIDWORKS Type Library

InsertCutBlend2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutBlend2( _  
    ByVal Closed As Boolean, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean _  
)
```

SOLIDWORKS Type Library

InsertCutBlend3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutBlend3( _  
    ByVal Closed As Boolean, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean, _  
    ByVal TessToleranceFactor As Double, _  
    ByVal StartMatchingType As Integer, _  
    ByVal EndMatchingType As Integer _  
)
```

SOLIDWORKS Type Library

InsertCutBlend4 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutBlend4( _  
    ByVal Closed As Boolean, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean, _  
    ByVal TessToleranceFactor As Double, _  
    ByVal StartMatchingType As Integer, _  
    ByVal EndMatchingType As Integer, _  
    ByVal IsThinBody As Boolean, _  
    ByVal Thickness1 As Double, _  
    ByVal Thickness2 As Double, _  
    ByVal ThinType As Integer _  
)
```

SOLIDWORKS Type Library

InsertCutSurface Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutSurface( _  
    ByVal Flip As Boolean, _  
    ByVal KeepPieceIndex As Long _  
)
```

SOLIDWORKS Type Library

InsertCutSwept Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutSwept( _  
    ByVal Propagate As Boolean, _
```

```
ByVal Alignment As Boolean, _  
ByVal KeepNormalConstant As Boolean _  
)
```

SOLIDWORKS Type Library

InsertCutSwept2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutSwept2( _  
    ByVal Propagate As Boolean, _  
    ByVal Alignment As Boolean, _  
    ByVal TwistCtrlOption As Integer, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean _  
)
```

SOLIDWORKS Type Library

InsertCutSwept3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutSwept3( _  
    ByVal Propagate As Boolean, _  
    ByVal Alignment As Boolean, _  
    ByVal TwistCtrlOption As Integer, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean, _  
    ByVal StartMatchingType As Integer, _  
    ByVal EndMatchingType As Integer _  
)
```

SOLIDWORKS Type Library

InsertCutSwept4 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertCutSwept4( _  
    ByVal Propagate As Boolean, _  
    ByVal Alignment As Boolean, _  
    ByVal TwistCtrlOption As Integer, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean, _  
    ByVal StartMatchingType As Integer, _  
    ByVal EndMatchingType As Integer, _  
    ByVal IsThinBody As Boolean, _  
    ByVal Thickness1 As Double, _  
    ByVal Thickness2 As Double, _  
    ByVal ThinType As Integer _  
)
```

SOLIDWORKS Type Library

InsertDatumTag2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertDatumTag2() As Object
```

SOLIDWORKS Type Library

InsertDatumTargetSymbol Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertDatumTargetSymbol( _
    ByVal Datum1 As String, _
    ByVal Datum2 As String, _
    ByVal Datum3 As String, _
    ByVal AreaStyle As Integer, _
    ByVal AreaOutside As Boolean, _
    ByVal Value1 As Double, _
    ByVal Value2 As Double, _
    ByVal ValueStr1 As String, _
    ByVal ValueStr2 As String, _
    ByVal ArrowsSmart As Boolean, _
    ByVal ArrowStyle As Integer, _
    ByVal LeaderLineStyle As Integer, _
    ByVal LeaderBent As Boolean, _
    ByVal ShowArea As Boolean, _
    ByVal ShowSymbol As Boolean _
) As Boolean
```

SOLIDWORKS Type Library

InsertDeleteFace Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub InsertDeleteFace()
```

SOLIDWORKS Type Library

InsertDeleteHole Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub InsertDeleteHole()
```

SOLIDWORKS Type Library

InsertDome Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub InsertDome( _
    ByVal Height As Double, _
    ByVal ReverseDir As Boolean, _
    ByVal DoEllipticSurface As Boolean _
)
```

SOLIDWORKS Type Library

InsertExtendSurface Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub InsertExtendSurface( _
    ByVal ExtendLinear As Boolean, _
    ByVal EndCondition As Long, _
    ByVal Distance As Double _
)
```

SOLIDWORKS Type Library

InsertFamilyTableEdit Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub InsertFamilyTableEdit()
```

SOLIDWORKS Type Library

InsertFamilyTableNew Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertFamilyTableNew()
```

SOLIDWORKS Type Library

InsertFamilyTableOpen Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertFamilyTableOpen( _  
    ByVal FileName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

InsertFeatureShell Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertFeatureShell( _  
    ByVal Thickness As Double, _  
    ByVal Outward As Boolean _  
    )
```

SOLIDWORKS Type Library

InsertFeatureShellAddThickness Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertFeatureShellAddThickness( _  
    ByVal Thickness As Double _  
    )
```

SOLIDWORKS Type Library

InsertFramePoint Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertFramePoint( _  
    ByVal Xx As Double, _  
    ByVal Yy As Double, _  
    ByVal Zz As Double _  
    )
```

SOLIDWORKS Type Library

InsertGtol Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertGtol() As Object
```

SOLIDWORKS Type Library

InsertHatchedFace Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertHatchedFace()
```

SOLIDWORKS Type Library

InsertHelix Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertHelix( _  
    ByVal Reversed As Boolean, _  
    ByVal Clockwise As Boolean, _  
    ByVal Tapered As Boolean, _  
    ByVal Outward As Boolean, _  
    ByVal Helixdef As Long, _  
    ByVal Height As Double, _  
    ByVal Pitch As Double, _  
    ByVal Revolution As Double, _  
    ByVal TaperAngle As Double, _  
    ByVal Startangle As Double _  
)
```

SOLIDWORKS Type Library

InsertLibraryFeature Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertLibraryFeature( _  
    ByVal LibFeatPartNameIn As String _  
)
```

SOLIDWORKS Type Library

InsertLoftRefSurface Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertLoftRefSurface( _  
    ByVal Closed As Boolean, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean _  
)
```

SOLIDWORKS Type Library

InsertLoftRefSurface2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertLoftRefSurface2( _  
    ByVal Closed As Boolean, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean, _  
    ByVal TessToleranceFactor As Double, _  
    ByVal StartMatchingType As Integer, _  
    ByVal EndMatchingType As Integer _  
)
```

SOLIDWORKS Type Library

InsertMfDraft Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertMfDraft( _  
    ByVal Angle As Double, _
```

```
ByVal FlipDir As Boolean, _  
ByVal IsEdgeDraft As Boolean, _  
ByVal PropType As Long _  
)
```

SOLIDWORKS Type Library

InsertMfDraft2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertMfDraft2( _  
    ByVal Angle As Double, _  
    ByVal FlipDir As Boolean, _  
    ByVal IsEdgeDraft As Boolean, _  
    ByVal PropType As Long, _  
    ByVal StepDraft As Boolean _  
)
```

SOLIDWORKS Type Library

InsertMidSurfaceExt Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertMidSurfaceExt( _  
    ByVal Placement As Double, _  
    ByVal KnitFlag As Boolean _  
) As Object
```

SOLIDWORKS Type Library

InsertNewNote3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertNewNote3( _  
    ByVal UpperText As String, _  
    ByVal NoLeader As Boolean, _  
    ByVal BentLeader As Boolean, _  
    ByVal ArrowStyle As Integer, _  
    ByVal LeaderSide As Integer, _  
    ByVal Angle As Double, _  
    ByVal BalloonStyle As Integer, _  
    ByVal BalloonFit As Integer, _  
    ByVal SmartArrow As Boolean _  
)
```

SOLIDWORKS Type Library

InsertNote Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertNote( _  
    ByVal Text As String _  
) As Object
```

SOLIDWORKS Type Library

InsertObject Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertObject()
```

InsertObjectFromFile Method (ModelDoc)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function InsertObjectFromFile( _  
    ByVal FilePath As String, _  
    ByVal CreateLink As Boolean, _  
    ByVal Xx As Double, _  
    ByVal Yy As Double, _  
    ByVal Zz As Double _  
) As Boolean
```

InsertOffsetSurface Method (ModelDoc)**Syntax**

Visual Basic for Applications (VBA)

```
Public Sub InsertOffsetSurface( _  
    ByVal Thickness As Double, _  
    ByVal Reverse As Boolean _  
)
```

InsertPlanarRefSurface Method (ModelDoc)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function InsertPlanarRefSurface() As Boolean
```

InsertPoint Method (ModelDoc)**Syntax**

Visual Basic for Applications (VBA)

```
Public Sub InsertPoint()
```

InsertProjectedSketch Method (ModelDoc)**Syntax**

Visual Basic for Applications (VBA)

```
Public Sub InsertProjectedSketch()
```

InsertProjectedSketch2 Method (ModelDoc)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function InsertProjectedSketch2( _  
    ByVal Reverse As Long _  
) As Object
```

InsertProtrusionBlend Method (ModelDoc)**Syntax**

Visual Basic for Applications (VBA)


```
Public Sub InsertProtrusionBlend( _  
    ByVal Closed As Boolean _  
)
```

SOLIDWORKS Type Library

InsertProtrusionBlend2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertProtrusionBlend2( _  
    ByVal Closed As Boolean, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean _  
)
```

SOLIDWORKS Type Library

InsertProtrusionBlend3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertProtrusionBlend3( _  
    ByVal Closed As Boolean, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean, _  
    ByVal TessToleranceFactor As Double, _  
    ByVal StartMatchingType As Integer, _  
    ByVal EndMatchingType As Integer _  
)
```

SOLIDWORKS Type Library

InsertProtrusionBlend4 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertProtrusionBlend4( _  
    ByVal Closed As Boolean, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean, _  
    ByVal TessToleranceFactor As Double, _  
    ByVal StartMatchingType As Integer, _  
    ByVal EndMatchingType As Integer, _  
    ByVal IsThinBody As Boolean, _  
    ByVal Thickness1 As Double, _  
    ByVal Thickness2 As Double, _  
    ByVal ThinType As Integer _  
)
```

SOLIDWORKS Type Library

InsertProtrusionSwept Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertProtrusionSwept( _  
    ByVal Propagate As Boolean, _  
    ByVal Alignment As Boolean, _  
    ByVal KeepNormalConstant As Boolean _  
)
```

SOLIDWORKS Type Library

InsertProtrusionSwept2 Method (ModelDoc)

Syntax

```
Public Sub InsertProtrusionSwept2( _
    ByVal Propagate As Boolean, _
    ByVal Alignment As Boolean, _
    ByVal TwistCtrlOption As Integer, _
    ByVal KeepTangency As Boolean, _
    ByVal ForceNonRational As Boolean _
)
```

InsertProtrusionSwept3 Method (ModelDoc)

```
Public Sub InsertProtrusionSwept3( _
    ByVal Propagate As Boolean, _
    ByVal Alignment As Boolean, _
    ByVal TwistCtrlOption As Integer, _
    ByVal KeepTangency As Boolean, _
    ByVal ForceNonRational As Boolean, _
    ByVal StartMatchingType As Integer, _
    ByVal EndMatchingType As Integer _
)
```

InsertProtrusionSwept4 Method (ModelDoc)

```
Public Sub InsertProtrusionSwept4( _
    ByVal Propagate As Boolean, _
    ByVal Alignment As Boolean, _
    ByVal TwistCtrlOption As Integer, _
    ByVal KeepTangency As Boolean, _
    ByVal ForceNonRational As Boolean, _
    ByVal StartMatchingType As Integer, _
    ByVal EndMatchingType As Integer, _
    ByVal IsThinBody As Boolean, _
    ByVal Thickness1 As Double, _
    ByVal Thickness2 As Double, _
    ByVal ThinType As Integer _
)
```

InsertRadiateSurface Method (ModelDoc)

```
Public Sub InsertRadiateSurface( _
    ByVal Distance As Double, _
    ByVal FlipDir As Boolean, _
    ByVal TangentPropagate As Boolean _
)
```

InsertRefPoint Method (ModelDoc)

```
Public Function InsertRefPoint() As Boolean
```

InsertRevolvedRefSurface Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertRevolvedRefSurface( _  
    ByVal Angle As Double, _  
    ByVal ReverseDir As Boolean, _  
    ByVal Angle2 As Double, _  
    ByVal RevType As Integer _  
)
```

SOLIDWORKS Type Library

InsertRib Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertRib( _  
    ByVal Is2Sided As Boolean, _  
    ByVal ReverseThicknessDir As Boolean, _  
    ByVal Thickness As Double, _  
    ByVal ReferenceEdgeIndex As Long, _  
    ByVal ReverseMaterialDir As Boolean, _  
    ByVal IsDrafted As Boolean, _  
    ByVal DraftOutward As Boolean, _  
    ByVal DraftAngle As Double _  
)
```

SOLIDWORKS Type Library

InsertRib2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertRib2( _  
    ByVal Is2Sided As Boolean, _  
    ByVal ReverseThicknessDir As Boolean, _  
    ByVal Thickness As Double, _  
    ByVal ReferenceEdgeIndex As Long, _  
    ByVal ReverseMaterialDir As Boolean, _  
    ByVal IsDrafted As Boolean, _  
    ByVal DraftOutward As Boolean, _  
    ByVal DraftAngle As Double, _  
    ByVal IsNormToSketch As Boolean _  
)
```

SOLIDWORKS Type Library

InsertRoutePoint Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertRoutePoint()
```

SOLIDWORKS Type Library

InsertScale Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertScale( _  
    ByVal ScaleFactor_x As Double, _  
    ByVal ScaleFactor_y As Double, _  
    ByVal ScaleFactor_z As Double, _  
    ByVal IsUniform As Boolean, _  
)
```

```
ByVal ScaleType As Integer _  
)
```

SOLIDWORKS Type Library

InsertSewRefSurface Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertSewRefSurface()
```

SOLIDWORKS Type Library

InsertShape Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertShape( _  
    ByVal PressureOn As Long, _  
    ByVal TangentsOn As Long, _  
    ByVal PressureGain As Double, _  
    ByVal TangentGain As Double, _  
    ByVal CurveSpringGain As Double, _  
    ByVal Alpha As Double, _  
    ByVal Beta As Double, _  
    ByVal Gamma As Double, _  
    ByVal Delta As Double, _  
    ByVal Degree As Long, _  
    ByVal Split As Long, _  
    ByVal Tuning As Long _  
) As Long
```

SOLIDWORKS Type Library

InsertSheetMetal3dBend Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertSheetMetal3dBend( _  
    ByVal Angle As Double, _  
    ByVal Radius As Double, _  
    ByVal FlipDir As Boolean, _  
    ByVal BendPos As Integer _  
)
```

SOLIDWORKS Type Library

InsertSheetMetalBaseFlange Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertSheetMetalBaseFlange( _  
    ByVal Thickness As Double, _  
    ByVal ThickenDir As Boolean, _  
    ByVal Radius As Double, _  
    ByVal ExtrudeDist1 As Double, _  
    ByVal ExtrudeDist2 As Double, _  
    ByVal FlipExtruDir As Boolean, _  
    ByVal EndCondition1 As Long, _  
    ByVal EndCondition2 As Long, _  
    ByVal DirToUse As Long _  
)
```

SOLIDWORKS Type Library

InsertSheetMetalClosedCorner Method (ModelDoc)

Syntax

```
Public Sub InsertSheetMetalClosedCorner()
```

SOLIDWORKS Type Library

InsertSheetMetalFold Method (ModelDoc)

```
Public Sub InsertSheetMetalFold()
```

SOLIDWORKS Type Library

InsertSheetMetalMiterFlange Method (ModelDoc)

```
Public Sub InsertSheetMetalMiterFlange( _  
    ByVal UseReliefRatio As Boolean, _  
    ByVal UseDefaultGap As Boolean, _  
    ByVal UseAutoRelief As Boolean, _  
    ByVal GlobalRadius As Double, _  
    ByVal RipGap As Double, _  
    ByVal AutoReliefRatio As Double, _  
    ByVal AutoReliefWidth As Double, _  
    ByVal AutoReliefDepth As Double, _  
    ByVal ReliefType As Long, _  
    ByVal RipLocation As Long, _  
    ByVal TrimSideBends As Boolean _  
)
```

SOLIDWORKS Type Library

InsertSheetMetalUnfold Method (ModelDoc)

```
Public Sub InsertSheetMetalUnfold()
```

SOLIDWORKS Type Library

InsertSketch Method (ModelDoc)

```
Public Sub InsertSketch()
```

SOLIDWORKS Type Library

InsertSketch2 Method (ModelDoc)

```
Public Sub InsertSketch2( _  
    ByVal UpdateEditRebuild As Boolean _  
)
```

SOLIDWORKS Type Library

InsertSplinePoint Method (ModelDoc)

```
Public Sub InsertSplinePoint( _  
    ByVal X As Double, _
```

```
    ByVal Y As Double, _  
    ByVal Z As Double _  
)
```

SOLIDWORKS Type Library

InsertSplitLineProject Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertSplitLineProject( _  
    ByVal IsDirectional As Boolean, _  
    ByVal FlipDir As Boolean _  
)
```

SOLIDWORKS Type Library

InsertSplitLineSil Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertSplitLineSil()
```

SOLIDWORKS Type Library

InsertSurfaceFinishSymbol2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertSurfaceFinishSymbol2( _  
    ByVal SymType As Long, _  
    ByVal LeaderType As Long, _  
    ByVal LocX As Double, _  
    ByVal LocY As Double, _  
    ByVal LocZ As Double, _  
    ByVal LaySymbol As Long, _  
    ByVal ArrowType As Long, _  
    ByVal MachAllowance As String, _  
    ByVal OtherVals As String, _  
    ByVal ProdMethod As String, _  
    ByVal SampleLen As String, _  
    ByVal MaxRoughness As String, _  
    ByVal MinRoughness As String, _  
    ByVal RoughnessSpacing As String _  
) As Boolean
```

SOLIDWORKS Type Library

InsertSweepRefSurface Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertSweepRefSurface( _  
    ByVal Propagate As Boolean, _  
    ByVal TwistCtrlOption As Integer, _  
    ByVal KeepTangency As Boolean, _  
    ByVal ForceNonRational As Boolean _  
)
```

SOLIDWORKS Type Library

InsertSweepRefSurface2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertSweepRefSurface2( _  
    ByVal Propagate As Boolean, _
```

```
ByVal TwistCtrlOption As Integer, _  
ByVal KeepTangency As Boolean, _  
ByVal ForceNonRational As Boolean, _  
ByVal StartMatchingType As Integer, _  
ByVal EndMatchingType As Integer _  
)
```

SOLIDWORKS Type Library

InsertTangencySurface Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertTangencySurface( _  
    ByVal OneSide As Boolean, _  
    ByVal IsFlip As Boolean _  
)
```

SOLIDWORKS Type Library

InsertWeldSymbol2 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InsertWeldSymbol2( _  
    ByVal Dim1 As String, _  
    ByVal Symbol As String, _  
    ByVal Dim2 As String, _  
    ByVal Symmetric As Boolean, _  
    ByVal FieldWeld As Boolean, _  
    ByVal ShowOtherSide As Boolean, _  
    ByVal DashOnTop As Boolean, _  
    ByVal Peripheral As Boolean, _  
    ByVal HasProcess As Boolean, _  
    ByVal ProcessValue As String _  
)
```

SOLIDWORKS Type Library

InsertWeldSymbol3 Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertWeldSymbol3() As Object
```

SOLIDWORKS Type Library

InspectCurvature Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InspectCurvature()
```

SOLIDWORKS Type Library

IParameter Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IParameter( _  
    ByVal StringIn As String _  
) As Dimension
```

SOLIDWORKS Type Library

IRayIntersections Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IRayIntersections( _  
    ByVal BodiesIn As Body, _  
    ByVal NumBodies As Long, _  
    ByRef BasePointsIn As Double, _  
    ByRef VectorsIn As Double, _  
    ByVal NumRays As Long, _  
    ByVal Options As Long, _  
    ByVal HitRadius As Double, _  
    ByVal Offset As Double _  
) As Long
```

SOLIDWORKS Type Library

IRelease3rdPartyStorage Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IRelease3rdPartyStorage( _  
    ByVal StringIn As String _  
)
```

SOLIDWORKS Type Library

IsActive Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsActive( _  
    ByVal CompStr As String _  
) As Boolean
```

SOLIDWORKS Type Library

IsEditingSelf Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsEditingSelf() As Boolean
```

SOLIDWORKS Type Library

ISelectByRay Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ISelectByRay( _  
    ByRef PointIn As Double, _  
    ByRef VectorIn As Double, _  
    ByVal RadiusIn As Double, _  
    ByVal TypeWanted As Long _  
) As Boolean
```

SOLIDWORKS Type Library

ISelectionManager Property (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ISelectionManager As SelectionMgr
```

SOLIDWORKS Type Library

ISetAngularUnits Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetAngularUnits( _  
    ByVal UType As Integer, _  
    ByVal FractBase As Integer, _  
    ByVal FractDenom As Integer, _  
    ByVal SigDigits As Integer _  
)
```

SOLIDWORKS Type Library

ISetNextSelectionGroupId Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetNextSelectionGroupId( _  
    ByVal ID As Long _  
)
```

SOLIDWORKS Type Library

ISetUserPreferenceTextFormat Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ISetUserPreferenceTextFormat( _  
    ByVal UserPreferenceValue As Long, _  
    ByVal Value As TextFormat _  
) As Boolean
```

SOLIDWORKS Type Library

IsExploded Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsExploded() As Boolean
```

SOLIDWORKS Type Library

ISketchSplineByEqnParams Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ISketchSplineByEqnParams( _  
    ByRef PropArray As Integer, _  
    ByRef KnotsArray As Double, _  
    ByRef CntrlPntCoordArray As Double _  
) As Long
```

SOLIDWORKS Type Library

IsLightLockedToModel Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsLightLockedToModel( _  
    ByVal LightId As Long _  
) As Boolean
```

SOLIDWORKS Type Library

IsOpenedReadOnly Method (ModelDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IsOpenedReadOnly() As Boolean
```

SOLIDWORKS Type Library

IsOpenedViewOnly Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IsOpenedViewOnly() As Boolean
```

SOLIDWORKS Type Library

IsTessellationValid Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IsTessellationValid() As Boolean
```

SOLIDWORKS Type Library

IVersionHistory Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function IVersionHistory() As String
```

SOLIDWORKS Type Library

LBDownAt Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub LBDownAt( _  
    ByVal Flags As Long, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
)
```

SOLIDWORKS Type Library

LBUpAt Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub LBUpAt( _  
    ByVal Flags As Long, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
)
```

SOLIDWORKS Type Library

LengthUnit Property (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Property LengthUnit As Long
```

SOLIDWORKS Type Library

Lights Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub Lights()
```

SOLIDWORKS Type Library

LightSourcePropertyValues Property (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Property LightSourcePropertyValues( _  
    ByVal ID As Long _  
) As Variant
```

SOLIDWORKS Type Library

LightSourceUserName Property (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Property LightSourceUserName( _  
    ByVal ID As Long _  
) As String
```

SOLIDWORKS Type Library

ListExternalFileReferences Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function ListExternalFileReferences( _  
    ByVal UseSearchRules As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

ListExternalFileReferencesCount Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function ListExternalFileReferencesCount( _  
    ByVal UseSearchRules As Boolean _  
) As Long
```

SOLIDWORKS Type Library

Lock Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub Lock()
```

SOLIDWORKS Type Library

LockAllExternalReferences Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub LockAllExternalReferences()
```

SOLIDWORKS Type Library

LockFramePoint Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub LockFramePoint()
```

SOLIDWORKS Type Library

LockLightToModel Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function LockLightToModel( _  
    ByVal LightId As Long, _  
    ByVal Fix As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

MaterialIdName Property (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaterialIdName As String
```

SOLIDWORKS Type Library

MaterialPropertyValues Property (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaterialPropertyValues As Variant
```

SOLIDWORKS Type Library

MaterialUserName Property (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Property MaterialUserName As String
```

SOLIDWORKS Type Library

MultiSelectByRay Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MultiSelectByRay( _  
    ByVal DoubleInfoIn As Variant, _  
    ByVal TypeWanted As Long, _  
    ByVal Append As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

NameView Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub NameView( _  
    ByVal VName As String _  
    )
```

SOLIDWORKS Type Library

ObjectDisplayAsIcon Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ObjectDisplayAsIcon()
```

SOLIDWORKS Type Library

ObjectDisplayContent Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ObjectDisplayContent()
```

SOLIDWORKS Type Library

ObjectResetSize Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ObjectResetSize()
```

SOLIDWORKS Type Library

Parameter Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Function Parameter( _  
    ByVal StringIn As String _  
    ) As Object
```

SOLIDWORKS Type Library

ParentChildRelationship Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ParentChildRelationship()
```

SOLIDWORKS Type Library

Paste Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub Paste()
```

SOLIDWORKS Type Library

PostTrimSurface Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub PostTrimSurface( _  
    ByVal BSewSurfaceIn As Boolean _  
    )
```

SOLIDWORKS Type Library

PreTrimSurface Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub PreTrimSurface( _  
    ByVal BMutualTrimIn As Boolean _  
    )
```

PrintDirect Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PrintDirect()
```

PrintOut Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PrintOut( _  
    ByVal FromPage As Long, _  
    ByVal ToPage As Long, _  
    ByVal NumCopies As Long, _  
    ByVal Collate As Boolean, _  
    ByVal Printer As String, _  
    ByVal Scale As Double, _  
    ByVal PrintToFile As Boolean _  
)
```

PrintOut2 Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PrintOut2( _  
    ByVal FromPage As Long, _  
    ByVal ToPage As Long, _  
    ByVal NumCopies As Long, _  
    ByVal Collate As Boolean, _  
    ByVal Printer As String, _  
    ByVal Scale As Double, _  
    ByVal PrintToFile As Boolean, _  
    ByVal PtfName As String _  
)
```

PrintPreview Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PrintPreview()
```

PrintSetup Property (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property PrintSetup( _  
    ByVal SetupType As Long _  
) As Integer
```

PropertySheet Method (ModelDoc) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PropertySheet()
```

SOLIDWORKS Type Library

Quit Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Quit()
```

SOLIDWORKS Type Library

RayIntersections Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RayIntersections( _  
    ByVal BodiesIn As Variant, _  
    ByVal BasePointsIn As Variant, _  
    ByVal VectorsIn As Variant, _  
    ByVal Options As Long, _  
    ByVal HitRadius As Double, _  
    ByVal Offset As Double _  
) As Long
```

SOLIDWORKS Type Library

ReattachOrdinate Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReattachOrdinate() As Boolean
```

SOLIDWORKS Type Library

Rebuild Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Rebuild( _  
    ByVal Options As Long _  
)
```

SOLIDWORKS Type Library

RemoveGroups Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveGroups()
```

SOLIDWORKS Type Library

RemoveInspectCurvature Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveInspectCurvature()
```

SOLIDWORKS Type Library

RemoveItemsFromGroup Method (ModelDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveItemsFromGroup()
```

SOLIDWORKS Type Library

ResetBlockingState Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ResetBlockingState()
```

SOLIDWORKS Type Library

ResetConfiguration Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ResetConfiguration()
```

SOLIDWORKS Type Library

ResetLightSourceExtProperty Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ResetLightSourceExtProperty( _  
    ByVal ID As Long _  
)
```

SOLIDWORKS Type Library

ResetPropertyExtension Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ResetPropertyExtension()
```

SOLIDWORKS Type Library

ResetSceneExtProperty Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub ResetSceneExtProperty()
```

SOLIDWORKS Type Library

Save Method (ModelDoc)



Visual Basic for Applications (VBA)

```
Public Sub Save()
```