

SOLIDWORKS API (VB6 COM) — Reference (59/102): ModelDoc2 (part 1 of 5)

SOLIDWORKS API Documentation (converted from CHM)

ModelDoc2 (part 1 of 5) (Type)

SOLIDWORKS Type Library

ModelDoc2 Object

 Object Model

ModelDoc2

ConfigurationManager

EnumModelViews

Extension (ModelDocExtension)

FeatureManager

GetEquationMgr (EquationMgr)

GetPropertyManagerPage (PropertyManagerPage)

IActiveView (ModelView)

IAddConfiguration3 (Configuration)

IAddDiameterDimension2 (DisplayDimension)

IAddDimension2 (DisplayDimension)

IAddHorizontalDimension2 (DisplayDimension)

IAddRadialDimension2 (DisplayDimension)

IAddVerticalDimension2 (DisplayDimension)

ICreateArc2 (SketchSegment)

ICreateCircle2 (SketchSegment)

ICreateCircleByRadius2 (SketchSegment)

ICreateClippedSplines (EnumSketchSegments)

ICreateEllipse2 (SketchSegment)

ICreateEllipticalArc2 (SketchSegment)

ICreateFeatureMgrView (FeatMgrView)

ICreateFeatureMgrView2 (FeatMgrView)

ICreateFeatureMgrView3 (FeatMgrView)

ICreateLine2 (SketchSegment)

ICreatePlaneAtAngle2 (RefPlane)

ICreatePlaneAtAngle3 (RefPlane)

ICreatePlaneAtOffset2 (RefPlane)


ICreatePlaneAtOffset3 (RefPlane)

ICreatePlaneAtSurface2 (RefPlane)

ICreatePlaneAtSurface3 (RefPlane)

ICreatePlaneFixed2 (RefPlane)

ICreatePlanePerCurveAndPassPoint2 (RefPlane)
ICreatePlanePerCurveAndPassPoint3 (RefPlane)
ICreatePlaneThru3Points2 (RefPlane)
ICreatePlaneThru3Points3 (RefPlane)
ICreatePlaneThruLineAndPt (RefPlane)
ICreatePlaneThruPtParallelToPlane (RefPlane)
ICreatePoint2 (SketchPoint)
ICreateSpine (SketchSegment)
ICreateSpineByEqnParams (SketchSegment)
ICreateSpinesByEqnParams (EnumSketchSegments)
IFeatureByPositionReverse (Feature)
IFeatureReferenceCurve (ReferenceCurve)
IFirstFeature (Feature)
IGetActiveConfiguration (Configuration)
IGetActiveSketch (Sketch)
IGetActiveSketch2 (Sketch)
IGetColorTable (ColorTable)
IGetConfigurationByName (Configuration)
IGetDesignTable (DesignTable)
IGetDetailingDefaults (DetailingDefaults)
IGetFirstAnnotation (Annotation)
IGetFirstAnnotation2 (Annotation)
IGetFirstModelView (ModelView)
IGetLayerManager (LayerMgr)
IGetNext (ModelDoc2)
IGetUserPreferenceTextFormat (TextFormat)
IGetUserUnit (UserUnit)
IInsertBOMBalloon2 (Note)
IInsertDatumTag2 (DatumTag)
IInsertGtol (Gtol)
IInsertMacroFeature (Feature)
IInsertMacroFeature2 (Feature)



SOLIDWORKS Type Library
ModelDoc2 Object Members

Public Methods

- [ActivateFeatureMgrView](#)
- [ActivateSelectedFeature](#)
- [AddConfiguration](#)
- [AddConfiguration2](#)
- [AddConfiguration3](#)
- [AddCustomInfo](#)
- [AddCustomInfo2](#)
- [AddCustomInfo3](#)
- [AddDiameterDimension](#)
- [AddDiameterDimension2](#)
- [AddDimension](#)
- [AddDimension2](#)
- [AddFeatureMgrView](#)
- [AddFeatureMgrView2](#)
- [AddFeatureMgrView3](#)
- [AddHorizontalDimension](#)
- [AddHorizontalDimension2](#)
- [AddIns](#)
- [AddLightSource](#)
- [AddLightSourceExtProperty](#)
- [AddLightToScene](#)
- [AddLoftSection](#)

	
	AddOrEditConfiguration
	AddPropertyExtension
	AddRadialDimension
	AddRadialDimension2
	AddRelation
	AddSceneExtProperty
	AddVerticalDimension
	AddVerticalDimension2
	AlignDimensions
	AlignOrdinate
	AlignParallelDimensions
	AndSelect
	AndSelectByID
	AndSelectByMark
	AutoInferToggle
	AutoSolveToggle
	BlankRefGeom
	BlankSketch
	BreakAllExternalReferences
	BreakDimensionAlignment
	ChangeSketchPlane
	ClearSelection
	ClearSelection2
	ClearUndoList
	Close
	CloseFamilyTable
	ClosePrintPreview
	ClosestDistance
	Create3PointArc
	CreateArc
	CreateArc2
	CreateArcByCenter
	CreateArcDB
	CreateArcVB
	CreateCenterLine
	CreateCenterLineVB
	CreateCircle
	CreateCircle2
	CreateCircleByRadius
	CreateCircleByRadius2
	CreateCircleDB
	CreateCircleVB
	CreateCircularSketchStepAndRepeat

	
	CreateClippedSplines
	CreateEllipse
	CreateEllipse2
	CreateEllipseVB
	CreateEllipticalArc
	CreateEllipticalArcByCenter
	CreateEllipticalArcByCenterVB
	CreateFeatureMgrView
	CreateFeatureMgrView2
	CreateFeatureMgrView3
	CreateGroup
	CreateLine
	CreateLine2
	CreateLinearSketchStepAndRepeat
	CreateLineDB
	CreateLineVB
	CreatePlaneAtAngle
	CreatePlaneAtAngle2
	CreatePlaneAtAngle3
	CreatePlaneAtOffset
	CreatePlaneAtOffset2
	CreatePlaneAtOffset3
	CreatePlaneAtSurface
	CreatePlaneAtSurface2
	CreatePlaneAtSurface3
	CreatePlaneFixed
	CreatePlaneFixed2
	CreatePlanePerCurveAndPassPoint
	CreatePlanePerCurveAndPassPoint2
	CreatePlanePerCurveAndPassPoint3
	CreatePlaneThru3Points
	CreatePlaneThru3Points2
	CreatePlaneThru3Points3
	CreatePlaneThruLineAndPt
	CreatePlaneThruPtParallelToPlane
	CreatePoint
	CreatePoint2
	CreatePointDB
	CreateSpline
	CreateSplineByEqnParams
	CreateSplinesByEqnParams
	CreateTangentArc
	CreateTangentArc2

	
	DeActivateFeatureMgView
	DebugCheckBody
	DebugCheckigesGeom
	DeleteAllRelations
	DeleteBendTable
	DeleteBgImage
	DeleteConfiguration
	DeleteConfiguration2
	DeleteCustomInfo
	DeleteCustomInfo2
	DeleteDesignTable
	DeleteFeatureMgView
	DeleteLightSource
	DeleteNamedView
	DeleteSelection
	DeriveSketch
	DeSelectByID
	DimPreferences
	DissolveLibraryFeature
	DissolveSketchText
	DragTo
	DrawLightIcons
	EditBalloonProperties
	EditClearAll
	EditConfiguration
	EditConfiguration2
	EditConfiguration3
	EditCopy
	EditCut
	EditDatumTargetSymbol
	EditDelete
	EditDimensionProperties
	EditDimensionProperties2
	EditDimensionProperties3
	EditOrdinate
	EditRebuild3
	EditRedo
	EditRedo2
	EditRollback
	EditRollback2
	EditRoute
	EditSeedFeat
	EditSketch

	
	EditSketchOrSingleSketchFeature
	EditSuppress
	EditSuppress2
	EditUndo
	EditUndo2
	EditUnsuppress
	EditUnsuppress2
	EditUnsuppressDependent
	EditUnsuppressDependent2
	EntityProperties
	EnumModelViews
	FeatEdit
	FeatEditDef
	FeatureBoss
	FeatureBoss2
	FeatureBossThicken
	FeatureBossThicken2
	FeatureBossThin
	FeatureBossThin2
	FeatureByPositionReverse
	FeatureChamfer
	FeatureChamferType
	FeatureCirPattern
	FeatureCurvePattern
	FeatureCut
	FeatureCut2
	FeatureCut3
	FeatureCut4
	FeatureCut5
	FeatureCutThicken
	FeatureCutThicken2
	FeatureCutThin
	FeatureCutThin2
	FeatureExtruRefSurface
	FeatureExtruRefSurface2
	FeatureFillet
	FeatureFillet2
	FeatureFillet3
	FeatureFillet4
	FeatureFillet5
	FeatureLinearPattern
	FeatureReferenceCurve
	FeatureRevolve2

	
	FeatureRevolveCut2
	FeatureSketchDrivenPattern
	FileReload
	FileSummaryInfo
	FirstFeature
	FontBold
	FontFace
	FontItalic
	FontPoints
	FontUnderline
	FontUnits
	ForceRebuild3
	ForceReleaseLocks
	GetActiveConfiguration
	GetActiveSketch
	GetActiveSketch2
	GetAddToDB
	GetAmbientLightProperties
	GetAngularUnits
	GetArcCentersDisplayed
	GetBendState
	GetBlockingState
	GetColorTable
	GetConfigurationByName
	GetConfigurationCount
	GetConfigurationNames
	GetConsiderLeadersAsLines
	GetCoordinateSystemXformByName
	GetCurrentCoordinateSystemName
	GetCustomInfoCount
	GetCustomInfoCount2
	GetCustomInfoNames
	GetCustomInfoNames2
	GetCustomInfoType
	GetCustomInfoType2
	GetCustomInfoType3
	GetCustomInfoValue
	GetDefaultTextHeight
	GetDependencies
	GetDependencies2
	GetDesignTable
	GetDetailingDefaults
	GetDirectionLightProperties

	
	GetDisplayWhenAdded
	GetEntityName
	GetEquationMgr
	GetExternalReferenceName
	GetFeatureCount
	GetFeatureManagerWidth
	GetFirstAnnotation
	GetFirstAnnotation2
	GetFirstModelView
	GetGridSettings
	GetInferenceMode
	GetLayerManager
	GetLightSourceCount
	GetLightSourceExtProperty
	GetLightSourceIdFromName
	GetLightSourceName
	GetLineCount
	GetLines
	GetMassProperties
	GetMassProperties2
	GetModelViewCount
	GetModelViewNames
	GetNext
	GetNumDependencies
	GetPathName
	GetPointLightProperties
	GetPopupMenuMode
	GetPropertyExtension
	GetPropertyManagerPage
	GetRayIntersectionsPoints
	GetRayIntersectionsTopology
	GetSaveFlag
	GetSceneBkgDIB
	GetSceneExtProperty
	GetSpotlightProperties
	GetStandardViewRotation
	GetTessellationQuality
	GetTitle
	GetToolBarVisibility
	GetType
	GetUnits
	GetUpdateStamp
	GetUserPreferenceDoubleValue

  [GetUserPreferenceIntegerValue](#)

 [GetUserPreferenceStringValue](#)

 [GetUserPreferenceTextFormat](#)

 [GetUserPreferenceToggle](#)

 [GetUserUnit](#)

 [GetVisibilityOfConstructPlanes](#)

 [GetZebraStripeData](#)

 [GraphicsRedraw](#)

 [GraphicsRedraw2](#)

 [GridOptions](#)

 [HideComponent2](#)

 [HideCosmeticThread](#)

 [HideDimension](#)

 [HideFeatureDimensions](#)

 [HideShowBodies](#)

 [HideSolidBody](#)

 [HoleWizard](#)

 [IAddConfiguration3](#)

 [IAddDiameterDimension2](#)

 [IAddDimension2](#)

 [IAddHorizontalDimension2](#)

 [IAddOrEditConfiguration](#)

 [IAddRadialDimension2](#)

 [IAddVerticalDimension2](#)

 [IClosestDistance](#)

 [ICreateArc](#)

 [ICreateArc2](#)

 [ICreateCenterLine](#)

 [ICreateCircle2](#)

 [ICreateCircleByRadius](#)

 [ICreateCircleByRadius2](#)

 [ICreateClippedSplines](#)

 [ICreateEllipse](#)

 [ICreateEllipse2](#)

 [ICreateEllipticalArc2](#)

 [ICreateEllipticalArcByCenter](#)

 [ICreateFeatureMgrView](#)

 [ICreateFeatureMgrView2](#)

 [ICreateFeatureMgrView3](#)

 [ICreateLine](#)

 [ICreateLine2](#)

 [ICreatePlaneAtAngle2](#)

[ICreatePlaneAtAngle3](#)

	
	<u>ICreatePlaneAtOffset2</u>
	<u>ICreatePlaneAtOffset3</u>
	<u>ICreatePlaneAtSurface2</u>
	<u>ICreatePlaneAtSurface3</u>
	<u>ICreatePlaneFixed</u>
	<u>ICreatePlaneFixed2</u>
	<u>ICreatePlanePerCurveAndPassPoint2</u>
	<u>ICreatePlanePerCurveAndPassPoint3</u>
	<u>ICreatePlaneThru3Points2</u>
	<u>ICreatePlaneThru3Points3</u>
	<u>ICreatePlaneThruLineAndPt</u>
	<u>ICreatePlaneThruPtParallelToPlane</u>
	<u>ICreatePoint2</u>
	<u>ICreateSpline</u>
	<u>ICreateSplineByEqnParams</u>
	<u>ICreateSplinesByEqnParams</u>
	<u>IEditDimensionProperties3</u>
	<u>IFeatureByPositionReverse</u>
	<u>IFeatureFillet2</u>
	<u>IFeatureFillet3</u>
	<u>IFeatureFillet4</u>
	<u>IFeatureFillet5</u>
	<u>IFeatureReferenceCurve</u>
	<u>IFirstFeature</u>
	<u>IGet3rdPartyStorage</u>
	<u>IGetActiveConfiguration</u>
	<u>IGetActiveSketch</u>
	<u>IGetActiveSketch2</u>
	<u>IGetAngularUnits</u>
	<u>IGetColorTable</u>
	<u>IGetConfigurationByName</u>
	<u>IGetConfigurationNames</u>
	<u>IGetCoordinateSystemXformByName</u>
	<u>IGetCustomInfoNames</u>
	<u>IGetCustomInfoNames2</u>
	<u>IGetDependencies</u>
	<u>IGetDependencies2</u>
	<u>IGetDesignTable</u>
	<u>IGetDetailingDefaults</u>
	<u>IGetEntityName</u>
	<u>IGetFirstAnnotation</u>
	<u>IGetFirstAnnotation2</u>
	<u>IGetFirstModelView</u>

	
	<u>IGetLayerManager</u>
	<u>IGetLines</u>
	<u>IGetMassProperties</u>
	<u>IGetMassProperties2</u>
	<u>IGetModelViewNames</u>
	<u>IGetNext</u>
	<u>IGetNumDependencies</u>
	<u>IGetNumDependencies2</u>
	<u>IGetRayIntersectionsPoints</u>
	<u>IGetRayIntersectionsTopology</u>
	<u>IGetStandardViewRotation</u>
	<u>IGetUnits</u>
	<u>IGetUserPreferenceTextFormat</u>
	<u>IGetUserUnit</u>
	<u>IGetVersionHistoryCount</u>
	<u>InsertBOMBalloon2</u>
	<u>InsertDatumTag2</u>
	<u>InsertGbol</u>
	<u>InsertMacroFeature</u>
	<u>InsertMidSurfaceExt</u>
	<u>InsertNote</u>
	<u>InsertProjectedSketch2</u>
	<u>InsertSheetMetalEdgeFlange</u>
	<u>InsertSketchForEdgeFlange</u>
	<u>InsertSketchText</u>
	<u>InsertWeildSymbol3</u>
	<u>IListAuxiliaryExternalFileReferences</u>
	<u>IListExternalFileReferences</u>
	<u>IListExternalFileReferences2</u>
	<u>IMultiSelectByRay</u>
	<u>Insert3DSketch</u>
	<u>Insert3DSketch2</u>
	<u>Insert3DSplineCurve</u>
	<u>InsertAxis</u>
	<u>InsertAxis2</u>
	<u>InsertBendTableEdit</u>
	<u>InsertBendTableNew</u>
	<u>InsertBendTableOpen</u>
	<u>InsertBkgImage</u>
	<u>InsertBOMBalloon</u>
	<u>InsertBOMBalloon2</u>
	<u>InsertCompositeCurve</u>
	<u>InsertConnectionPoint</u>

	
	InsertCoordinateSystem
	InsertCosmeticThread
	InsertCurveFile
	InsertCurveFileBegin
	InsertCurveFileEnd
	InsertCurveFilePoint
	InsertCutBlend
	InsertCutBlend2
	InsertCutBlend3
	InsertCutBlend4
	InsertCutSurface
	InsertCutSwept
	InsertCutSwept2
	InsertCutSwept3
	InsertCutSwept4
	InsertDatumTag2
	InsertDatumTargetSymbol
	InsertDeleteFace
	InsertDeleteFace2
	InsertDeleteHole
	InsertDome
	InsertExtendSurface
	InsertFamilyTableEdit
	InsertFamilyTableNew
	InsertFamilyTableOpen
	InsertFeatureReplaceFace
	InsertFeatureShell
	InsertFeatureShellAddThickness
	InsertFramePoint
	InsertGtol
	InsertHatchedFace
	InsertHelix
	InsertLibraryFeature
	InsertLoftRefSurface
	InsertLoftRefSurface2
	InsertMacroFeature
	InsertMidDraft
	InsertMidDraft2
	InsertMidSurfaceExt
	InsertNewNote3
	InsertNote
	InsertObject
	InsertObjectFromFile

	
	InsertOffsetSurface
	InsertPlanarRefSurface
	InsertPoint
	InsertProjectedSketch
	InsertProjectedSketch2
	InsertProtrusionBlend
	InsertProtrusionBlend2
	InsertProtrusionBlend3
	InsertProtrusionBlend4
	InsertProtrusionSwept
	InsertProtrusionSwept2
	InsertProtrusionSwept3
	InsertProtrusionSwept4
	InsertRadiateSurface
	InsertRefPoint
	InsertRevolvedRefSurface
	InsertRib
	InsertRib2
	InsertRip
	InsertRoutePoint
	InsertScale
	InsertSewRefSurface
	InsertShape
	InsertSheetMetal3dBend
	InsertSheetMetalBaseFlange
	InsertSheetMetalBreakCorner
	InsertSheetMetalClosedCorner
	InsertSheetMetalEdgeFlange
	InsertSheetMetalFold
	InsertSheetMetalHem
	InsertSheetMetalJog
	InsertSheetMetalMiterFlange
	InsertSheetMetalUnfold
	InsertSketch
	InsertSketch2
	InsertSketchForEdgeFlange
	InsertSketchPicture
	InsertSketchPictureData
	InsertSketchPictureDatax64
	InsertSketchText
	InsertSplinePoint
	InsertSplitLineProject
	InsertSplitLineSil

	
	<u>InsertStackedBalloon</u>
	<u>InsertSurfaceFinishSymbol2</u>
	<u>InsertSweepRefSurface</u>
	<u>InsertSweepRefSurface2</u>
	<u>InsertTangencySurface</u>
	<u>InsertWeldSymbol2</u>
	<u>InsertWeldSymbol3</u>
	<u>InspectCurvature</u>
	<u>IParameter</u>
	<u>IRayIntersections</u>
	<u>IRelease3rdPartyStorage</u>
	<u>IsActive</u>
	<u>IsEditingSelf</u>
	<u>ISelectByRay</u>
	<u>ISetAngularUnits</u>
	<u>ISetNextSelectionGroupId</u>
	<u>ISetUserPreferenceTextFormat</u>
	<u>IsExploded</u>
	<u>ISketchSplineByEqnParams</u>
	<u>IsLightLockedToModel</u>
	<u>IsOpenedReadOnly</u>
	<u>IsOpenedViewOnly</u>
	<u>IsTessellationValid</u>
	<u>IVersionHistory</u>
	<u>LBDownAt</u>
	<u>LBUpAt</u>
	<u>Lights</u>
	<u>ListAuxiliaryExternalFileReferences</u>
	<u>ListAuxiliaryExternalFileReferencesCount</u>
	<u>ListExternalFileReferences</u>
	<u>ListExternalFileReferences2</u>
	<u>ListExternalFileReferencesCount</u>
	<u>ListExternalFileReferencesCount2</u>
	<u>Lock</u>
	<u>LockAllExternalReferences</u>
	<u>LockFramePoint</u>
	<u>LockLightToModel</u>
	<u>MoldDraftAnalysis</u>
	<u>MultiSelectByRay</u>
	<u>NameView</u>
	<u>ObjectDisplayAsIcon</u>
	<u>ObjectDisplayContent</u>
	<u>ObjectResetSize</u>

	
 Parameter	
 ParentChildRelationship	
 Paste	
 PostTrimSurface	
 PreTrimSurface	
 PrintDirect	
 PrintOut	
 PrintOut2	
 PrintPreview	
 PropertySheet	
 Quit	
 RayIntersections	
 ReattachOrdinate	
 Rebuild	
 ReloadOrReplace	
 RemoveGroups	
 RemoveInspectCurvature	
 RemoveItemsFromGroup	
 ResetBlockingState	
 ResetConfiguration	
 ResetLightSourceExtProperty	
 ResetPropertyExtension	
 ResetSceneExtProperty	
 Save	
 Save2	
 Save3	
 SaveAs	
 SaveAs2	
 SaveAs3	
 SaveAs4	
 SaveAsSilent	
 SaveBMP	
 SaveSilent	
 Scale	
 ScreenRotate	
 Select	
 SelectAt	
 SelectByID	
 SelectByMark	
 SelectByName	
 SelectByRay	
 SelectedEdgeProperties	
SelectedFaceProperties	


 SelectedFeatureProperties
 SelectLoop
 SelectMidpoint
 SelectSketchArc
 SelectSketchItem
 SelectSketchLine
 SelectSketchPoint
 SelectSketchSpline
 SelectTangency
 SetAddToDB
 SetAmbientLightProperties
 SetAngularUnits
 SetArcCentersDisplayed
 SetBendState
 SetBlockingState
 SetConsiderLeadersAsLines
 SetDirectionLightProperties
 SetDisplayWhenAdded
 SetFeatureManagerWidth
 SetInferenceMode
 SetLightSourceName
 SetLightSourcePropertyValuesVB
 SetNextSelectionGroupId
 SetParamValue
 SetPickMode
 SetPointLightProperties
 SetPopupMenuMode
 SetReadOnlyState
 SetSaveAsFileName
 SetSaveFlag
 SetSceneBkgDIB
 SetSpotlightProperties
 SetTessellationQuality
 SetTitle2
 SetToolbarVisibility
 SetUnits
 SetUserPreferenceDoubleValue
 SetUserPreferenceIntegerValue
 SetUserPreferenceStringValue
 SetUserPreferenceTextFormat
 SetUserPreferenceToggle
 SetZebraStripeData
 ShowComponent2

	
	ShowConfiguration
	ShowConfiguration2
	ShowCosmeticThread
	ShowFeatureDimensions
	ShowNamedView
	ShowNamedView2
	ShowSolidBody
	SimpleHole
	SimpleHole2
	SimpleHole3
	SimplifySpline
	Sketch3DIntersections
	SketchAddConstraints
	SketchAlign
	SketchArc
	SketchCenterline
	SketchChamfer
	SketchCircle
	SketchConstrainCoincident
	SketchConstrainConcentric
	SketchConstrainParallel
	SketchConstrainPerp
	SketchConstrainTangent
	SketchConstraintsDel
	SketchConstraintsDelAll
	SketchConvertIsoCurves
	SketchFillet
	SketchFillet1
	SketchFillet2
	SketchMirror
	SketchModifyFlip
	SketchModifyRotate
	SketchModifyScale
	SketchModifyTranslate
	SketchOffset
	SketchOffset2
	SketchOffsetEdges
	SketchOffsetEntities
	SketchOffsetEntities2
	SketchParabola
	SketchPoint
	SketchPolygon
	SketchRectangle

	
	SketchRectangleAtAnyAngle
	SketchSpline
	SketchSplineByEqnParams
	SketchSplineByEqnParams2
	SketchTangentArc
	SketchTrim
	SketchUndo
	SketchUseEdge
	SketchUseEdge2
	SketchUseEdgeCnline
	SkToolsAutoConstr
	SplitClosedSegment
	SplitOpenSegment
	Toolbars
	ToolsConfiguration
	ToolsDistance
	ToolsGrid
	ToolsMacro
	ToolsMassProps
	ToolsSketchScale
	ToolsSketchTranslate
	UnBlankRefGeom
	UnblankSketch
	UnderiveSketch
	UnLock
	UnlockAllExternalReferences
	UnlockFramePoint
	UserFavors
	UserPreferences
	VersionHistory
	ViewConstraint
	ViewDispCoordinateSystems
	ViewDisplayCurvature
	ViewDisplayFaceted
	ViewDisplayHiddengreyed
	ViewDisplayHiddenremoved
	ViewDisplayShaded
	ViewDisplayWireframe
	ViewDispOrigins
	ViewDispRefaxes
	ViewDispRefplanes
	ViewDispRefPoints
	ViewDispTempRefaxes

	
	ViewOglShading
	ViewOrientationUndo
	ViewRotate
	ViewRotateminusx
	ViewRotateminusy
	ViewRotateminusz
	ViewRotateplusx
	ViewRotateplusy
	ViewRotateplusz
	ViewRotXMinusNinety
	ViewRotXPlusNinety
	ViewRotYMinusNinety
	ViewRotYPlusNinety
	ViewRwShading
	ViewTranslate
	ViewTranslateminusx
	ViewTranslateminusy
	ViewTranslateplusx
	ViewTranslateplusy
	ViewZoomin
	ViewZoomout
	ViewZoomto
	ViewZoomTo2
	ViewZoomtofit
	ViewZoomtofit2
	ViewZoomToSelection
	WindowRedraw

Public Properties

	ActiveView
	ConfigurationManager
	CustomInfo
	CustomInfo2
	Extension
	FeatureManager
	FeatureManagerSplitterPosition
	IActiveView
	ILightSourcePropertyValues
	IMaterialPropertyValues
	IPageSetup
	ISelectionManager
	LargeAssemblyMode
	LengthUnit

 LightSourcePropertyValues
 LightSourceUserName
 MaterialIdName
 MaterialPropertyValues
 MaterialUserName
 ModelViewManager
 PageSetup
 Printer
 PrintSetup
 SceneBkgImageFileName
 SceneName
 SceneUserName
 SelectionManager
 ShowFeatureErrorDialog
 SketchManager
 SummaryInfo
 Visible

SOLIDWORKS Type Library

ActivateFeatureMgrView Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ActivateFeatureMgrView( _
    ByRef AppView As Long _
) As Long
```

SOLIDWORKS Type Library

ActivateSelectedFeature Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ActivateSelectedFeature()
```

SOLIDWORKS Type Library

ActiveView Property (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ActiveView As Object
```

SOLIDWORKS Type Library

AddConfiguration Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AddConfiguration( _
    ByVal Name As String, _
    ByVal Comment As String, _
    ByVal AlternateName As String, _
    ByVal SuppressByDefault As Boolean, _
    ByVal HideByDefault As Boolean, _
    ByVal MinFeatureManager As Boolean, _
```

```
ByVal InheritProperties As Boolean, _  
ByVal Flags As ULong _  
)
```

SOLIDWORKS Type Library

AddConfiguration2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddConfiguration2( _  
    ByVal Name As String, _  
    ByVal Comment As String, _  
    ByVal AlternateName As String, _  
    ByVal SuppressByDefault As Boolean, _  
    ByVal HideByDefault As Boolean, _  
    ByVal MinFeatureManager As Boolean, _  
    ByVal InheritProperties As Boolean, _  
    ByVal Flags As ULong _  
) As Boolean
```

SOLIDWORKS Type Library

AddConfiguration3 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddConfiguration3( _  
    ByVal Name As String, _  
    ByVal Comment As String, _  
    ByVal AlternateName As String, _  
    ByVal Options As Long _  
) As Object
```

SOLIDWORKS Type Library

AddCustomInfo Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddCustomInfo( _  
    ByVal FieldName As String, _  
    ByVal FieldType As String, _  
    ByVal FieldValue As String _  
) As Boolean
```

SOLIDWORKS Type Library

AddCustomInfo2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddCustomInfo2( _  
    ByVal FieldName As String, _  
    ByVal FieldType As Long, _  
    ByVal FieldValue As String _  
) As Boolean
```

SOLIDWORKS Type Library

AddCustomInfo3 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddCustomInfo3( _  
    ByVal Configuration As String, _  
    ByVal FieldName As String, _
```

```
ByVal FieldType As Long, _  
ByVal FieldValue As String _  
) As Boolean
```

SOLIDWORKS Type Library

AddDiameterDimension Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDiameterDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AddDiameterDimension2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDiameterDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

SOLIDWORKS Type Library

AddDimension Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AddDimension2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

SOLIDWORKS Type Library

AddFeatureMgrView Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddFeatureMgrView( _  
    ByRef Bitmap As Long, _  
    ByRef AppView As Long _  
) As Boolean
```

SOLIDWORKS Type Library

AddFeatureMgrView2 Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function AddFeatureMgrView2( _  
    ByRef Bitmap As Long, _  
    ByRef AppView As Long, _  
    ByVal ToolTip As String _  
) As Boolean
```

SOLIDWORKS Type Library

AddFeatureMgrView3 Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function AddFeatureMgrView3( _  
    ByRef Bitmap As Long, _  
    ByRef AppView As Long, _  
    ByVal ToolTip As String, _  
    ByVal WhichPane As Long _  
) As Boolean
```

SOLIDWORKS Type Library

AddHorizontalDimension Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function AddHorizontalDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AddHorizontalDimension2 Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function AddHorizontalDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Object
```

SOLIDWORKS Type Library

AddIns Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub AddIns()
```

SOLIDWORKS Type Library

AddLightSource Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function AddLightSource( _  
    ByVal IdName As String, _  
    ByVal LTyp As Integer, _  
    ByVal UserName As String _  
) As Boolean
```

AddLightSourceExtProperty Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddLightSourceExtProperty( _  
    ByVal ID As Long, _  
    ByVal PropertyExtension As Variant _  
) As Long
```

AddLightToScene Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddLightToScene( _  
    ByVal LpszNewValue As String _  
) As Long
```

AddLoftSection Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub AddLoftSection()
```

AddOrEditConfiguration Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddOrEditConfiguration( _  
    ByVal ConfigName As String, _  
    ByVal Params As Variant, _  
    ByVal Values As Variant _  
) As Long
```

AddPropertyExtension Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddPropertyExtension( _  
    ByVal PropertyExtension As Variant _  
) As Long
```

AddRadialDimension Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function AddRadialDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

AddRadialDimension2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddRadialDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Object
```

SOLIDWORKS Type Library

AddRelation Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AddRelation( _  
    ByVal RelStr As String _  
    )
```

SOLIDWORKS Type Library

AddSceneExtProperty Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddSceneExtProperty( _  
    ByVal PropertyExtension As Variant _  
    ) As Long
```

SOLIDWORKS Type Library

AddVerticalDimension Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddVerticalDimension( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

AddVerticalDimension2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddVerticalDimension2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Object
```

SOLIDWORKS Type Library

AlignDimensions Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AlignDimensions()
```

SOLIDWORKS Type Library

AlignOrdinate Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AlignOrdinate()
```

SOLIDWORKS Type Library

AlignParallelDimensions Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AlignParallelDimensions()
```

SOLIDWORKS Type Library

AndSelect Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AndSelect( _  
    ByVal SelID As String, _  
    ByVal SelParams As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
)
```

SOLIDWORKS Type Library

AndSelectByID Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AndSelectByID( _  
    ByVal SelID As String, _  
    ByVal SelParams As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

AndSelectByMark Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AndSelectByMark( _  
    ByVal SelID As String, _  
    ByVal SelParams As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal Mark As Long _  
) As Boolean
```

SOLIDWORKS Type Library

AutoInferToggle Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AutoInferToggle()
```

SOLIDWORKS Type Library

AutoSolveToggle Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub AutoSolveToggle()
```

SOLIDWORKS Type Library

BlankRefGeom Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub BlankRefGeom()
```

SOLIDWORKS Type Library

BlankSketch Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub BlankSketch()
```

SOLIDWORKS Type Library

BreakAllExternalReferences Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub BreakAllExternalReferences()
```

SOLIDWORKS Type Library

BreakDimensionAlignment Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub BreakDimensionAlignment()
```

SOLIDWORKS Type Library

ChangeSketchPlane Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Function ChangeSketchPlane() As Boolean
```

SOLIDWORKS Type Library

ClearSelection Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ClearSelection()
```

SOLIDWORKS Type Library

ClearSelection2 Method (ModelDoc2)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub ClearSelection2( _  
    ByVal All As Boolean _  
)
```

SOLIDWORKS Type Library

ClearUndoList Method (ModelDoc2)



Visual Basic for Applications (VBA)

```
Public Sub ClearUndoList()
```

SOLIDWORKS Type Library

Close Method (ModelDoc2)



Visual Basic for Applications (VBA)

```
Public Sub Close()
```

SOLIDWORKS Type Library

CloseFamilyTable Method (ModelDoc2)



Visual Basic for Applications (VBA)

```
Public Sub CloseFamilyTable()
```

SOLIDWORKS Type Library

ClosePrintPreview Method (ModelDoc2)



Visual Basic for Applications (VBA)

```
Public Sub ClosePrintPreview()
```

SOLIDWORKS Type Library

ClosestDistance Method (ModelDoc2)



Visual Basic for Applications (VBA)

```
Public Function ClosestDistance( _  
    ByVal Object1 As Object, _  
    ByVal Object2 As Object, _  
    ByRef Point1 As Variant, _  
    ByRef Point2 As Variant _  
) As Double
```

SOLIDWORKS Type Library

ConfigurationManager Property (ModelDoc2)



Visual Basic for Applications (VBA)

```
Public Property ConfigurationManager As ConfigurationManager
```

SOLIDWORKS Type Library

Create3PointArc Method (ModelDoc2)



Visual Basic for Applications (VBA)

```
Public Function Create3PointArc( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double, _  
    ByVal P3x As Double, _  
    ByVal P3y As Double, _
```

```
ByVal P3z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateArc Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateArc( _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant, _  
    ByVal P3 As Variant, _  
    ByVal Dir As Integer _  
) As Boolean
```

SOLIDWORKS Type Library

CreateArc2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateArc2( _  
    ByVal XC As Double, _  
    ByVal YC As Double, _  
    ByVal Zc As Double, _  
    ByVal Xp1 As Double, _  
    ByVal Yp1 As Double, _  
    ByVal Zp1 As Double, _  
    ByVal Xp2 As Double, _  
    ByVal Yp2 As Double, _  
    ByVal Zp2 As Double, _  
    ByVal Direction As Integer _  
) As Object
```

SOLIDWORKS Type Library

CreateArcByCenter Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateArcByCenter( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double, _  
    ByVal P3x As Double, _  
    ByVal P3y As Double, _  
    ByVal P3z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateArcDB Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateArcDB( _  
    ByVal X1 As Double, _  
    ByVal Y1 As Double, _  
    ByVal Z1 As Double, _  
    ByVal X2 As Double, _  
    ByVal Y2 As Double, _  
    ByVal Z2 As Double, _  
    ByVal X3 As Double, _  
    ByVal Y3 As Double, _
```

```
ByVal Z3 As Double, _  
ByVal Dir As Integer _  
) As Boolean
```

SOLIDWORKS Type Library

CreateArcVB Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreateArcVB( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double, _  
    ByVal P3x As Double, _  
    ByVal P3y As Double, _  
    ByVal P3z As Double, _  
    ByVal Dir As Integer _  
)
```

SOLIDWORKS Type Library

CreateCenterLine Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCenterLine( _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

CreateCenterLineVB Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreateCenterLineVB( _  
    ByVal X1 As Double, _  
    ByVal Y1 As Double, _  
    ByVal Z1 As Double, _  
    ByVal X2 As Double, _  
    ByVal Y2 As Double, _  
    ByVal Z2 As Double _  
)
```

SOLIDWORKS Type Library

CreateCircle Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircle( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateCircle2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircle2( _  
    ByVal XC As Double, _  
    ByVal YC As Double, _  
    ByVal Zc As Double, _  
    ByVal Xp As Double, _  
    ByVal Yp As Double, _  
    ByVal Zp As Double _  
) As Object
```

SOLIDWORKS Type Library

CreateCircleByRadius Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircleByRadius( _  
    ByVal P1 As Variant, _  
    ByVal Radius As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateCircleByRadius2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircleByRadius2( _  
    ByVal XC As Double, _  
    ByVal YC As Double, _  
    ByVal Zc As Double, _  
    ByVal Radius As Double _  
) As Object
```

SOLIDWORKS Type Library

CreateCircleDB Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircleDB( _  
    ByVal Cx As Double, _  
    ByVal Cy As Double, _  
    ByVal Cz As Double, _  
    ByVal Radius As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateCircleVB Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreateCircleVB( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal Radius As Double _  
)
```

SOLIDWORKS Type Library

CreateCircularSketchStepAndRepeat Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateCircularSketchStepAndRepeat( _
    ByVal ArcRadius As Double, _
    ByVal ArcAngle As Double, _
    ByVal PatternNum As Long, _
    ByVal PatternSpacing As Double, _
    ByVal PatternRotate As Boolean, _
    ByVal DeleteInstances As String _
) As Boolean
```

SOLIDWORKS Type Library

CreateClippedSplines Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateClippedSplines( _
    ByVal ParamsIn As Variant, _
    ByVal X1 As Double, _
    ByVal Y1 As Double, _
    ByVal X2 As Double, _
    ByVal Y2 As Double _
) As Variant
```

SOLIDWORKS Type Library

CreateEllipse Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipse( _
    ByVal Center As Variant, _
    ByVal Major As Variant, _
    ByVal Minor As Variant _
) As Boolean
```

SOLIDWORKS Type Library

CreateEllipse2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipse2( _
    ByVal CenterX As Double, _
    ByVal CenterY As Double, _
    ByVal CenterZ As Double, _
    ByVal MajorX As Double, _
    ByVal MajorY As Double, _
    ByVal MajorZ As Double, _
    ByVal MinorX As Double, _
    ByVal MinorY As Double, _
    ByVal MinorZ As Double _
) As Object
```

SOLIDWORKS Type Library

CreateEllipseVB Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipseVB( _
    ByVal CenterX As Double, _
    ByVal CenterY As Double, _
    ByVal CenterZ As Double, _
    ByVal MajorX As Double, _
    ByVal MajorY As Double, _
    ByVal MajorZ As Double, _
```

```
ByVal MinorX As Double, _  
ByVal MinorY As Double, _  
ByVal MinorZ As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateEllipticalArc2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipticalArc2( _  
    ByVal CenterX As Double, _  
    ByVal CenterY As Double, _  
    ByVal CenterZ As Double, _  
    ByVal MajorX As Double, _  
    ByVal MajorY As Double, _  
    ByVal MajorZ As Double, _  
    ByVal MinorX As Double, _  
    ByVal MinorY As Double, _  
    ByVal MinorZ As Double, _  
    ByVal StartX As Double, _  
    ByVal StartY As Double, _  
    ByVal StartZ As Double, _  
    ByVal EndX As Double, _  
    ByVal EndY As Double, _  
    ByVal EndZ As Double _  
) As Object
```

SOLIDWORKS Type Library

CreateEllipticalArcByCenter Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipticalArcByCenter( _  
    ByVal Center As Variant, _  
    ByVal Major As Variant, _  
    ByVal Minor As Variant, _  
    ByVal Start As Variant, _  
    ByVal End As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

CreateEllipticalArcByCenterVB Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateEllipticalArcByCenterVB( _  
    ByVal CenterX As Double, _  
    ByVal CenterY As Double, _  
    ByVal CenterZ As Double, _  
    ByVal MajorX As Double, _  
    ByVal MajorY As Double, _  
    ByVal MajorZ As Double, _  
    ByVal MinorX As Double, _  
    ByVal MinorY As Double, _  
    ByVal MinorZ As Double, _  
    ByVal StartX As Double, _  
    ByVal StartY As Double, _  
    ByVal StartZ As Double, _  
    ByVal EndX As Double, _  
    ByVal EndY As Double, _  
    ByVal EndZ As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateFeatureMgrView Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureMgrView( _  
    ByRef Bitmap As Long _  
) As Object
```

SOLIDWORKS Type Library

CreateFeatureMgrView2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureMgrView2( _  
    ByRef Bitmap As Long, _  
    ByVal ToolTip As String _  
) As Object
```

SOLIDWORKS Type Library

CreateFeatureMgrView3 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureMgrView3( _  
    ByRef Bitmap As Long, _  
    ByVal ToolTip As String, _  
    ByVal WhichPane As Long _  
) As Object
```

SOLIDWORKS Type Library

CreateGroup Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreateGroup()
```

SOLIDWORKS Type Library

CreateLine Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateLine( _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

CreateLine2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateLine2( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double _  
) As Object
```

CreateLinearSketchStepAndRepeat Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateLinearSketchStepAndRepeat( _  
    ByVal NumX As Long, _  
    ByVal NumY As Long, _  
    ByVal SpacingX As Double, _  
    ByVal SpacingY As Double, _  
    ByVal AngleX As Double, _  
    ByVal AngleY As Double, _  
    ByVal DeleteInstances As String _  
    ) As Boolean
```

CreateLineDB Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreateLineDB( _  
    ByVal Sx As Double, _  
    ByVal Sy As Double, _  
    ByVal Sz As Double, _  
    ByVal Ex As Double, _  
    ByVal Ey As Double, _  
    ByVal Ez As Double _  
    ) As Boolean
```

CreateLineVB Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub CreateLineVB( _  
    ByVal X1 As Double, _  
    ByVal Y1 As Double, _  
    ByVal Z1 As Double, _  
    ByVal X2 As Double, _  
    ByVal Y2 As Double, _  
    ByVal Z2 As Double _  
    )
```

CreatePlaneAtAngle Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub CreatePlaneAtAngle( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean _  
    )
```

CreatePlaneAtAngle2 Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtAngle2( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean _  
    ) As Object
```

CreatePlaneAtAngle3 Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtAngle3( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean, _  
    ByVal AutoSize As Boolean _  
) As Object
```

CreatePlaneAtOffset Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub CreatePlaneAtOffset( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean _  
)
```

CreatePlaneAtOffset2 Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtOffset2( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean _  
) As Object
```

CreatePlaneAtOffset3 Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtOffset3( _  
    ByVal Val As Double, _  
    ByVal FlipDir As Boolean, _  
    ByVal AutoSize As Boolean _  
) As Object
```

CreatePlaneAtSurface Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub CreatePlaneAtSurface( _  
    ByVal InterIndex As Integer, _  
    ByVal ProjOpt As Boolean, _  
    ByVal ReverseDir As Boolean, _  
    ByVal NormalPlane As Boolean, _  
    ByVal Angle As Double _  
)
```

CreatePlaneAtSurface2 Method (ModelDoc2) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtSurface2( _  
    ByVal InterIndex As Integer, _  
    ByVal ProjOpt As Boolean, _  
    ByVal ReverseDir As Boolean, _  
    ByVal NormalPlane As Boolean, _  
    ByVal Angle As Double _  
    ) As Object
```

SOLIDWORKS Type Library

CreatePlaneAtSurface3 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneAtSurface3( _  
    ByVal InterIndex As Integer, _  
    ByVal ProjOpt As Boolean, _  
    ByVal ReverseDir As Boolean, _  
    ByVal NormalPlane As Boolean, _  
    ByVal Angle As Double, _  
    ByVal AutoSize As Boolean _  
    ) As Object
```

SOLIDWORKS Type Library

CreatePlaneFixed Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneFixed( _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant, _  
    ByVal P3 As Variant, _  
    ByVal UseGlobal As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreatePlaneFixed2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneFixed2( _  
    ByVal P1 As Variant, _  
    ByVal P2 As Variant, _  
    ByVal P3 As Variant, _  
    ByVal UseGlobal As Boolean _  
    ) As Object
```

SOLIDWORKS Type Library

CreatePlanePerCurveAndPassPoint Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreatePlanePerCurveAndPassPoint( _  
    ByVal OrigAtCurve As Boolean _  
    )
```

SOLIDWORKS Type Library

CreatePlanePerCurveAndPassPoint2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlanePerCurveAndPassPoint2( _  
    ByVal OrigAtCurve As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreatePlanePerCurveAndPassPoint3 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlanePerCurveAndPassPoint3( _  
    ByVal OrigAtCurve As Boolean, _  
    ByVal AutoSize As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreatePlaneThru3Points Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub CreatePlaneThru3Points()
```

SOLIDWORKS Type Library

CreatePlaneThru3Points2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneThru3Points2() As Object
```

SOLIDWORKS Type Library

CreatePlaneThru3Points3 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneThru3Points3( _  
    ByVal AutoSize As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreatePlaneThruLineAndPt Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneThruLineAndPt( _  
    ByVal AutoSize As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreatePlaneThruPtParallelToPlane Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePlaneThruPtParallelToPlane( _  
    ByVal AutoSize As Boolean _  
) As Object
```

SOLIDWORKS Type Library

CreatePoint Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePoint( _  
    ByVal PointX As Double, _  
    ByVal PointY As Double, _  
    ByVal PointZ As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreatePoint2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePoint2( _  
    ByVal PointX As Double, _  
    ByVal PointY As Double, _  
    ByVal PointZ As Double _  
    ) As Object
```

SOLIDWORKS Type Library

CreatePointDB Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreatePointDB( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Boolean
```

SOLIDWORKS Type Library

CreateSpline Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSpline( _  
    ByVal PointData As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreateSplineByEqnParams Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSplineByEqnParams( _  
    ByVal ParamsIn As Variant _  
    ) As Object
```

SOLIDWORKS Type Library

CreateSplinesByEqnParams Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSplinesByEqnParams( _  
    ByVal ParamsIn As Variant _  
    ) As Variant
```

SOLIDWORKS Type Library

CreateTangentArc Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTangentArc( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double _  
) As Boolean
```

SOLIDWORKS Type Library

CreateTangentArc2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateTangentArc2( _  
    ByVal P1x As Double, _  
    ByVal P1y As Double, _  
    ByVal P1z As Double, _  
    ByVal P2x As Double, _  
    ByVal P2y As Double, _  
    ByVal P2z As Double, _  
    ByVal ArcTypeIn As Long _  
) As Boolean
```

SOLIDWORKS Type Library

CustomInfo Property (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CustomInfo( _  
    ByVal FieldName As String _  
) As String
```

SOLIDWORKS Type Library

CustomInfo2 Property (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Property CustomInfo2( _  
    ByVal Configuration As String, _  
    ByVal FieldName As String _  
) As String
```

SOLIDWORKS Type Library

DeActivateFeatureMgrView Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeActivateFeatureMgrView( _  
    ByRef AppView As Long _  
) As Boolean
```

SOLIDWORKS Type Library

DebugCheckBody Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DebugCheckBody()
```

SOLIDWORKS Type Library

DebugCheckIgesGeom Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DebugCheckIgesGeom()
```

SOLIDWORKS Type Library

DeleteAllRelations Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteAllRelations()
```

SOLIDWORKS Type Library

DeleteBendTable Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteBendTable()
```

SOLIDWORKS Type Library

DeleteBkgImage Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteBkgImage()
```

SOLIDWORKS Type Library

DeleteConfiguration Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteConfiguration( _  
    ByVal ConfigurationName As String _  
)
```

SOLIDWORKS Type Library

DeleteConfiguration2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteConfiguration2( _  
    ByVal ConfigurationName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteCustomInfo Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteCustomInfo( _  
    ByVal FieldName As String _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteCustomInfo2 Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteCustomInfo2( _  
    ByVal Configuration As String, _  
    ByVal FieldName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

DeleteDesignTable Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteDesignTable()
```

SOLIDWORKS Type Library

DeleteFeatureMgrView Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteFeatureMgrView( _  
    ByRef AppView As Long _  
    )
```

SOLIDWORKS Type Library

DeleteLightSource Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeleteLightSource( _  
    ByVal ID As Long _  
    )
```

SOLIDWORKS Type Library

DeleteNamedView Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteNamedView( _  
    ByVal ViewName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

DeleteSelection Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteSelection( _  
    ByVal ConfirmFlag As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

DeriveSketch Method (ModelDoc2)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub DeriveSketch()
```

SOLIDWORKS Type Library

 Syntax

Visual Basic for Applications (VBA)

```
Public Function DeSelectByID( _  
    ByVal SelID As String, _  
    ByVal SelParams As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```