

SOLIDWORKS API (VB6 COM) — Reference (65/102): ModelDocExtension (part 2 of 3)

SOLIDWORKS API Documentation (converted from CHM)

ModelDocExtension (part 2 of 3) (Type)

SOLIDWORKS Type Library

GetSustainability Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function GetSustainability() As Object
```

SOLIDWORKS Type Library

GetTemplateSheetMetal Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function GetTemplateSheetMetal() As Object
```

SOLIDWORKS Type Library

GetTexture Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function GetTexture( _  
    ByVal Config_name As String _  
) As Texture
```

SOLIDWORKS Type Library

GetUserPreferenceDouble Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function GetUserPreferenceDouble( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long _  
) As Double
```

SOLIDWORKS Type Library

GetUserPreferenceDoubleValueRange Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function GetUserPreferenceDoubleValueRange( _  
    ByVal UserPref As Long, _  
    ByRef Value As Double, _  
    ByRef MinValue As Double, _  
    ByRef MaxValue As Double _  
) As Long
```

SOLIDWORKS Type Library

GetUserPreferenceInteger Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function GetUserPreferenceInteger( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long _  
) As Long
```

SOLIDWORKS Type Library

GetUserPreferenceString Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUserPreferenceString( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long _  
    ) As String
```

SOLIDWORKS Type Library

GetUserPreferenceTextFormat Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUserPreferenceTextFormat( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long _  
    ) As TextFormat
```

SOLIDWORKS Type Library

GetUserPreferenceToggle Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetUserPreferenceToggle( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetVisibleBox Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetVisibleBox( _  
    ByRef UpperLeft As MathPoint, _  
    ByRef LowerRight As MathPoint _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetWhatsWrong Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetWhatsWrong( _  
    ByRef Features As Variant, _  
    ByRef ErrorCodes As Variant, _  
    ByRef Warnings As Variant _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetWhatsWrongCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetWhatsWrongCount() As Long
```

SOLIDWORKS Type Library

HasDesignTable Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function HasDesignTable() As Boolean
```

SOLIDWORKS Type Library

HasLegacyCThreads Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function HasLegacyCThreads() As Boolean
```

SOLIDWORKS Type Library

HasLegacyCustomProperties Property (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Property HasLegacyCustomProperties As Boolean
```

SOLIDWORKS Type Library

HasMaterialPropertyValues Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function HasMaterialPropertyValues() As Boolean
```

SOLIDWORKS Type Library

HasRenamedDocuments Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function HasRenamedDocuments() As Boolean
```

SOLIDWORKS Type Library

HideDecal Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function HideDecal( _  
    ByVal DecalID As Long, _  
    ByVal Hide As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

HideFeatureManager Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function HideFeatureManager( _  
    ByVal Hide As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

IAddDisplayStateSpecificRenderMaterial Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function IAddDisplayStateSpecificRenderMaterial( _  
    ByVal PRenderMaterial As RenderMaterial, _  
    ByVal DisplayStateOption As Long, _
```

```

    ByVal DisplayStateCount As Long, _
    ByRef DisplayStateNames As String, _
    ByRef PWMaterialId1 As Long, _
    ByRef PWMaterialId2 As Long _
) As Boolean

```

SOLIDWORKS Type Library

IChangeSketchPlane Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function IChangeSketchPlane( _
    ByVal Config_opt As Long, _
    ByVal Config_count As Long, _
    ByRef Config_names As String _
) As Boolean

```

SOLIDWORKS Type Library

ICreateOLEObject Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function ICreateOLEObject( _
    ByVal Aspect As Long, _
    ByRef Position As Double, _
    ByVal ByteCount As Long, _
    ByRef Buffer As Byte, _
    ByRef ErrorCode As Long _
) As SwOLEObject

```

SOLIDWORKS Type Library

IDeleteDisplayStateSpecificRenderMaterial Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function IDeleteDisplayStateSpecificRenderMaterial( _
    ByVal IdCount As Long, _
    ByRef PWMaterialId1 As Long, _
    ByRef PWMaterialId2 As Long _
) As Boolean

```

SOLIDWORKS Type Library

IEditDimensionProperties Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function IEditDimensionProperties( _
    ByVal TolType As Long, _
    ByVal TolMax As Double, _
    ByVal TolMin As Double, _
    ByVal TolMaxFit As String, _
    ByVal TolMinFit As String, _
    ByVal UseDocPrec As Boolean, _
    ByVal Precision As Long, _
    ByVal ArrowsIn As Long, _
    ByVal UseDocArrows As Boolean, _
    ByVal Arrow1 As Long, _
    ByVal Arrow2 As Long, _
    ByVal PrefixText As String, _
    ByVal SuffixText As String, _
    ByVal ShowValue As Boolean, _
    ByVal CalloutText1 As String, _
    ByVal CalloutText2 As String, _
    ByVal DimensionLowerText As String, _

```

```
ByVal CenterText As Boolean, _  
ByVal ConfigOption As Long, _  
ByVal Count As Long, _  
ByRef ConfigNames As String _  
) As Boolean
```

SOLIDWORKS Type Library

IGet3rdPartyStorageStore Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGet3rdPartyStorageStore( _  
    ByVal SubStorageName As String, _  
    ByVal IsStoring As Boolean _  
) As Unknown
```

SOLIDWORKS Type Library

IGetAnnotations Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAnnotations( _  
    ByVal NumAnnotations As Long _  
) As Annotation
```

SOLIDWORKS Type Library

IGetAnnotationViews Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAnnotationViews( _  
    ByVal AnnotationViewCount As Long _  
) As AnnotationView
```

SOLIDWORKS Type Library

IGetAttachments Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAttachments( _  
    ByVal NumAttachments As Long, _  
    ByRef LinkedArr As Boolean _  
) As String
```

SOLIDWORKS Type Library

IGetDecals Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetDecals( _  
    ByVal Count As Long _  
) As Decal
```

SOLIDWORKS Type Library

IGetFlattenSheetMetalPersistReference Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFlattenSheetMetalPersistReference( _  
    ByVal DispObj As Object, _
```

```
    ByVal Count As Long _  
) As Byte
```

SOLIDWORKS Type Library

IGetMassProperties Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetMassProperties( _  
    ByVal Accuracy As Long, _  
    ByRef Status As Long _  
) As Double
```

SOLIDWORKS Type Library

IGetMaterialPropertyValues Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetMaterialPropertyValues( _  
    ByVal Config_opt As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
) As Double
```

SOLIDWORKS Type Library

IGetModelViews Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetModelViews( _  
    ByVal NumModelViews As Long _  
) As ModelView
```

SOLIDWORKS Type Library

IGetNamedViewRotation Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNamedViewRotation( _  
    ByVal Name As String _  
) As Double
```

SOLIDWORKS Type Library

IGetObjectByPersistReference Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetObjectByPersistReference( _  
    ByVal Count As Long, _  
    ByRef PersistId As Byte _  
) As Object
```

SOLIDWORKS Type Library

IGetObjectByPersistReference2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetObjectByPersistReference2( _  
    ByVal Count As Long, _  
    ByRef PersistId As Byte, _
```

```
ByRef ErrorCode As Long _  
) As Object
```

SOLIDWORKS Type Library

IGetObjectByPersistReference3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetObjectByPersistReference3( _  
    ByVal Count As Long, _  
    ByRef PersistId As Byte, _  
    ByRef ErrorCode As Long _  
) As Object
```

SOLIDWORKS Type Library

IGetOLEObjects Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetOLEObjects( _  
    ByVal Options As Long, _  
    ByVal OleObjectCount As Long, _  
    ByRef LpOleObjects As SwOLEObject _  
)
```

SOLIDWORKS Type Library

IGetPersistReference Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPersistReference( _  
    ByVal DipsObj As Object, _  
    ByVal Count As Long _  
) As Byte
```

SOLIDWORKS Type Library

IGetPersistReference3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPersistReference3( _  
    ByVal DipsObj As Object, _  
    ByVal Count As Long _  
) As Byte
```

SOLIDWORKS Type Library

IGetRenderMaterials Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetRenderMaterials( _  
    ByVal Count As Long _  
) As RenderMaterial
```

SOLIDWORKS Type Library

IGetSearchData Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IGetSearchData( _
    ByVal AppName As String, _
    ByVal Count As Long, _
    ByRef AppNames As String, _
    ByRef NodeNames As String, _
    ByRef NodeValues As String _
)
```

SOLIDWORKS Type Library

IGetSectionProperties Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function IGetSectionProperties( _
    ByVal Count As Long, _
    ByRef Sections As Unknown _
) As Double
```

SOLIDWORKS Type Library

IGetSectionProperties2 Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function IGetSectionProperties2( _
    ByVal Count As Long, _
    ByRef Sections As Unknown _
) As Double
```

SOLIDWORKS Type Library

IGetSheetMetalObjectsByPersistReference Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function IGetSheetMetalObjectsByPersistReference( _
    ByVal Count As Long, _
    ByRef PersistId As Byte, _
    ByRef ErrorCode As Long _
) As Variant
```

SOLIDWORKS Type Library

IListExternalFileReferences Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Sub IListExternalFileReferences( _
    ByVal NumRefs As Long, _
    ByRef ModelPathName As String, _
    ByRef CompPathName As String, _
    ByRef Feature As String, _
    ByRef DataType As String, _
    ByRef Status As Long, _
    ByRef RefEntity As String, _
    ByRef FeatComp As String, _
    ByRef ConfigOption As Long, _
    ByRef ConfigName As String _
)
```

SOLIDWORKS Type Library

IMultiSelect Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function IMultiSelect( _  
    ByVal Count As Long, _  
    ByRef Objects As Unknown, _  
    ByVal AppendFlag As Boolean, _  
    ByVal Data As SelectData _  
    ) As Long
```

SOLIDWORKS Type Library

IncludeMassPropertiesOfHiddenBodies Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property IncludeMassPropertiesOfHiddenBodies As Boolean
```

SOLIDWORKS Type Library

InsertAnnotationFavorite Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertAnnotationFavorite( _  
    ByVal BstrFileName As String, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
    ) As Annotation
```

SOLIDWORKS Type Library

InsertAnnotationView Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertAnnotationView( _  
    ByVal AnnotationViewingDirection As Long, _  
    ByVal DirectionReference As Object, _  
    ByVal FlipDirection As Boolean, _  
    ByVal HorizontalDirectionReference As Object, _  
    ByVal AngleMadeWithHorizontal As Long _  
    ) As AnnotationView
```

SOLIDWORKS Type Library

InsertAttachment Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertAttachment( _  
    ByVal FileName As String, _  
    ByVal Linked As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

InsertBOMBalloon Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBOMBalloon( _  
    ByVal Style As Long, _  
    ByVal Size As Long, _  
    ByVal UpperTextStyle As Long, _  
    ByVal UpperText As String, _  
    ByVal LowerTextStyle As Long, _  
    ByVal LowerText As String, _
```

```
ByVal CustomSize As Double, _  
ByVal ShowQuantity As Boolean, _  
ByVal QuantityPlacement As Integer, _  
ByVal QuantityDenotationText As String _  
) As Object
```

SOLIDWORKS Type Library

InsertBOMBalloon2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBOMBalloon2( _  
ByVal BalloonOptions As BalloonOptions _  
) As Note
```

SOLIDWORKS Type Library

InsertBomTable Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable( _  
ByVal TemplateName As String, _  
ByVal X As Long, _  
ByVal Y As Long, _  
ByVal BomType As Long, _  
ByVal ConfigurationName As String _  
) As BomTableAnnotation
```

SOLIDWORKS Type Library

InsertBomTable2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable2( _  
ByVal TemplateName As String, _  
ByVal X As Long, _  
ByVal Y As Long, _  
ByVal BomType As Long, _  
ByVal ConfigurationName As String, _  
ByVal Hidden As Boolean _  
) As BomTableAnnotation
```

SOLIDWORKS Type Library

InsertBomTable3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable3( _  
ByVal TemplateName As String, _  
ByVal X As Long, _  
ByVal Y As Long, _  
ByVal BomType As Long, _  
ByVal ConfigurationName As String, _  
ByVal Hidden As Boolean, _  
ByVal IndentedNumberingType As Long, _  
ByVal DetailedCutList As Boolean _  
) As BomTableAnnotation
```

SOLIDWORKS Type Library

InsertBomTable4 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertBomTable4( _
    ByVal TemplateName As String, _
    ByVal X As Long, _
    ByVal Y As Long, _
    ByVal BomType As Long, _
    ByVal ConfigurationName As String, _
    ByVal Hidden As Boolean, _
    ByVal IndentedNumberingType As Long, _
    ByVal DetailedCutList As Boolean, _
    ByVal DissolvePartLevelRows As Boolean _
) As Object
```

SOLIDWORKS Type Library

InsertCamera Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertCamera() As Camera
```

SOLIDWORKS Type Library

InsertChainDimensions Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertChainDimensions( _
    ByVal Entities As Variant _
) As Variant
```

SOLIDWORKS Type Library

InsertDatumTargetSymbol2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertDatumTargetSymbol2( _
    ByVal Datum1 As String, _
    ByVal Datum2 As String, _
    ByVal Datum3 As String, _
    ByVal AreaStyle As Integer, _
    ByVal AreaOutside As Boolean, _
    ByVal Value1 As Double, _
    ByVal Value2 As Double, _
    ByVal ValueStr1 As String, _
    ByVal ValueStr2 As String, _
    ByVal ArrowsSmart As Boolean, _
    ByVal ArrowStyle As Integer, _
    ByVal LeaderLineStyle As Integer, _
    ByVal LeaderBent As Boolean, _
    ByVal ShowArea As Boolean, _
    ByVal ShowSymbol As Boolean _
) As DatumTargetSym
```

SOLIDWORKS Type Library

InsertDatumTargetSymbol3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertDatumTargetSymbol3( _
    ByVal Datum1 As String, _
    ByVal Datum2 As String, _
    ByVal Datum3 As String, _
    ByVal AreaStyle As Long, _
    ByVal AreaOutside As Boolean, _
```

```

    ByVal Value1 As Double, _
    ByVal Value2 As Double, _
    ByVal ValueStr1 As String, _
    ByVal ValueStr2 As String, _
    ByVal ArrowsSmart As Boolean, _
    ByVal ArrowStyle As Long, _
    ByVal LeaderLineStyle As Long, _
    ByVal LeaderBent As Boolean, _
    ByVal ShowArea As Boolean, _
    ByVal ShowSymbol As Boolean, _
    ByVal MoveableDatumStyle As Long _
) As DatumTargetSym

```

SOLIDWORKS Type Library

InsertDeleteFace Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function InsertDeleteFace( _
    ByVal Option As Long _
) As Boolean

```

SOLIDWORKS Type Library

InsertDwgOrDxfFile Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function InsertDwgOrDxfFile( _
    ByVal FileName As String _
) As Boolean

```

SOLIDWORKS Type Library

InsertGeneralTableAnnotation Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function InsertGeneralTableAnnotation( _
    ByVal UseAnchorPoint As Boolean, _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal AnchorType As Long, _
    ByVal TableTemplate As String, _
    ByVal Rows As Long, _
    ByVal Columns As Long _
) As TableAnnotation

```

SOLIDWORKS Type Library

InsertGeneralToleranceTableAnnotation Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```

Public Function InsertGeneralToleranceTableAnnotation( _
    ByVal TemplateName As String, _
    ByVal X As Long, _
    ByVal Y As Long _
) As GeneralToleranceTableAnnotation

```

SOLIDWORKS Type Library

InsertObjectFromFile Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertObjectFromFile( _
    ByVal FilePath As String, _
    ByVal CreateLink As Boolean, _
    ByVal Aspect As Long, _
    ByVal XPos As Double, _
    ByVal YPos As Double, _
    ByVal ZPos As Double _
) As SwOLEObject
```

SOLIDWORKS Type Library

InsertScene Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertScene( _
    ByVal SceneDefinitionFile As String _
) As Boolean
```

SOLIDWORKS Type Library

InsertStackedBalloon Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertStackedBalloon( _
    ByVal Style As Long, _
    ByVal Size As Long, _
    ByVal UpperTextStyle As Long, _
    ByVal UpperText As String, _
    ByVal LowerTextStyle As Long, _
    ByVal LowerText As String, _
    ByVal CustomSize As Double, _
    ByVal ShowQuantity As Boolean, _
    ByVal QuantityPlacement As Integer, _
    ByVal QuantityDenotationText As String _
) As Note
```

SOLIDWORKS Type Library

InsertStackedBalloon2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertStackedBalloon2( _
    ByVal BalloonOptions As StackedBalloonOptions _
) As Note
```

SOLIDWORKS Type Library

InsertSurfaceFinishSymbol3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertSurfaceFinishSymbol3( _
    ByVal SymType As Long, _
    ByVal LeaderType As Long, _
    ByVal LocX As Double, _
    ByVal LocY As Double, _
    ByVal LocZ As Double, _
    ByVal LaySymbol As Long, _
    ByVal ArrowType As Long, _
    ByVal MachAllowance As String, _
    ByVal OtherVals As String, _
    ByVal ProdMethod As String, _
    ByVal SampleLen As String, _
```

```
ByVal MaxRoughness As String, _  
ByVal MinRoughness As String, _  
ByVal RoughnessSpacing As String _  
) As SFSymbol
```

SOLIDWORKS Type Library

InsertTitleBlockTable Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function InsertTitleBlockTable( _  
    ByVal TemplateName As String, _  
    ByVal X As Long, _  
    ByVal Y As Long _  
) As TitleBlockTableAnnotation
```

SOLIDWORKS Type Library

InstallModelColorizer Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub InstallModelColorizer( _  
    ByVal PInterface As Object _  
)
```

SOLIDWORKS Type Library

IPrintOut2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IPrintOut2( _  
    ByVal ArraySize As Long, _  
    ByRef PageArray As Long, _  
    ByVal Copies As Long, _  
    ByVal Collate As Boolean, _  
    ByVal Printer As String, _  
    ByVal PrintFileName As String _  
)
```

SOLIDWORKS Type Library

IPrintOut3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub IPrintOut3( _  
    ByVal ArraySize As Long, _  
    ByRef PageArray As Long, _  
    ByVal Copies As Long, _  
    ByVal Collate As Boolean, _  
    ByVal Printer As String, _  
    ByVal PrintFileName As String, _  
    ByVal ConvertToHighQuality As Boolean _  
)
```

SOLIDWORKS Type Library

IRelease3rdPartyStorageStore Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IRelease3rdPartyStorageStore( _  
    ByVal SubStorageName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

IRemoveMaterialProperty Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IRemoveMaterialProperty( _  
    ByVal Config_opt As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

IsAbbreviatedViewActive Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsAbbreviatedViewActive() As Boolean
```

SOLIDWORKS Type Library

IsConverted Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsConverted() As Boolean
```

SOLIDWORKS Type Library

IsDisplayPaneVisible Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsDisplayPaneVisible() As Boolean
```

SOLIDWORKS Type Library

ISetMaterialPropertyValues Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetMaterialPropertyValues( _  
    ByRef Material_values As Double, _  
    ByVal Config_opt As Long, _  
    ByVal Config_count As Long, _  
    ByRef Config_names As String _  
    )
```

SOLIDWORKS Type Library

IsExploded Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsExploded( _  
    ByRef ViewName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

IsFutureVersion Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsFutureVersion() As Boolean
```

SOLIDWORKS Type Library

IsSamePersistentID Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsSamePersistentID( _  
    ByVal PersistentID1 As Variant, _  
    ByVal PersistentID2 As Variant _  
) As Long
```

SOLIDWORKS Type Library

IsVirtualComponent Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsVirtualComponent() As String
```

SOLIDWORKS Type Library

IsVirtualComponent2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsVirtualComponent2() As Variant
```

SOLIDWORKS Type Library

IsVirtualComponent3 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsVirtualComponent3( _  
    ByRef PathChain As Variant, _  
    ByRef TitleChain As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

JogDimension Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function JogDimension( _  
    ByVal Jog As Boolean, _  
    ByVal WitnessIndex As Integer _  
) As Boolean
```

SOLIDWORKS Type Library

LinkedDisplayState Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property LinkedDisplayState As Boolean
```

SOLIDWORKS Type Library

ListExternalFileReferences Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ListExternalFileReferences( _  
    ByRef ModelPathName As Variant, _  
    ByRef ComponentPathName As Variant, _  
    ByRef Feature As Variant, _  
    ByRef DataType As Variant, _  
    ByRef Status As Variant, _  
    ByRef RefEntity As Variant, _  
    ByRef FeatCom As Variant, _  
    ByRef ConfigOption As Long, _  
    ByRef ConfigName As String _  
)
```

SOLIDWORKS Type Library

ListExternalFileReferences2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ListExternalFileReferences2( _  
    ByRef ModelPathName As Variant, _  
    ByRef ComponentPathName As Variant, _  
    ByRef Feature As Variant, _  
    ByRef DataType As Variant, _  
    ByRef Status As Variant, _  
    ByRef RefEntity As Variant, _  
    ByRef FeatCom As Variant, _  
    ByRef ConfigOptions As Variant, _  
    ByRef ConfigNames As Variant _  
)
```

SOLIDWORKS Type Library

ListExternalFileReferencesCount Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ListExternalFileReferencesCount() As Long
```

SOLIDWORKS Type Library

LoadDraftingStandard Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function LoadDraftingStandard( _  
    ByVal FileName As String _  
) As Boolean
```

SOLIDWORKS Type Library

Make3DExperienceCompatible Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Make3DExperienceCompatible( _  
    ByVal IncludeComponents As Boolean, _  
    ByRef Result As Boolean _  
)
```

SOLIDWORKS Type Library

MoveDecal Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MoveDecal( _  
    ByVal DecalID As Long, _  
    ByVal MoveUp As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

MoveOrCopy Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub MoveOrCopy( _  
    ByVal Copy As Boolean, _  
    ByVal NumCopies As Long, _  
    ByVal KeepRelations As Boolean, _  
    ByVal BaseX As Double, _  
    ByVal BaseY As Double, _  
    ByVal BaseZ As Double, _  
    ByVal DestX As Double, _  
    ByVal DestY As Double, _  
    ByVal DestZ As Double _  
)
```

SOLIDWORKS Type Library

MultiSelect Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MultiSelect( _  
    ByVal Objects As Variant, _  
    ByVal AppendFlag As Boolean, _  
    ByVal Data As Object _  
) As Long
```

SOLIDWORKS Type Library

MultiSelect2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function MultiSelect2( _  
    ByVal Objects As Variant, _  
    ByVal AppendFlag As Boolean, _  
    ByVal Data As Object _  
) As Long
```

SOLIDWORKS Type Library

NeedsRebuild Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property NeedsRebuild As Boolean
```

SOLIDWORKS Type Library

NeedsRebuild2 Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property NeedsRebuild2 As Long
```

PrintOut Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PrintOut( _  
    ByVal FromPage As Long, _  
    ByVal ToPage As Long, _  
    ByVal Copies As Long, _  
    ByVal Collate As Boolean, _  
    ByVal Printer As String, _  
    ByVal PrintFileName As String _  
)
```

PrintOut2 Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PrintOut2( _  
    ByVal PageArray As Variant, _  
    ByVal Copies As Long, _  
    ByVal Collate As Boolean, _  
    ByVal Printer As String, _  
    ByVal PrintFileName As String _  
)
```

PrintOut3 Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PrintOut3( _  
    ByVal PageArray As Variant, _  
    ByVal Copies As Long, _  
    ByVal Collate As Boolean, _  
    ByVal Printer As String, _  
    ByVal PrintFileName As String, _  
    ByVal ConvertToHighQuality As Boolean _  
)
```

PrintOut4 Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub PrintOut4( _  
    ByVal Printer As String, _  
    ByVal PrintFileName As String, _  
    ByVal PrintSpecification As Object _  
)
```

PublishSTEP242File Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function PublishSTEP242File( _  
    ByVal Path As String _  
) As Long
```

PublishSTEP242File2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function PublishSTEP242File2( _  
    ByVal MBDSTEP242Data As Object _  
) As Long
```

SOLIDWORKS Type Library

PublishTo3DPDF Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function PublishTo3DPDF( _  
    ByVal MBDPdfData As Object _  
) As Long
```

SOLIDWORKS Type Library

PurgeDisplayState Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function PurgeDisplayState() As Boolean
```

SOLIDWORKS Type Library

RayIntersections Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RayIntersections( _  
    ByVal BodiesIn As Variant, _  
    ByVal BasePointsIn As Variant, _  
    ByVal VectorsIn As Variant, _  
    ByVal Options As Long, _  
    ByVal HitRadius As Double, _  
    ByVal Offset As Double, _  
    ByVal HighPrecision As Boolean _  
) As Long
```

SOLIDWORKS Type Library

Rebuild Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function Rebuild( _  
    ByVal Options As Long _  
) As Boolean
```

SOLIDWORKS Type Library

Refresh3DViews Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Refresh3DViews()
```

SOLIDWORKS Type Library

ReJogRunningDimension Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ReJogRunningDimension()
```

SOLIDWORKS Type Library

ReleaseStream Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReleaseStream( _  
    ByVal StreamType As Long _  
) As Boolean
```

SOLIDWORKS Type Library

ReloadOrReplace Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReloadOrReplace( _  
    ByVal ReadOnly As Boolean, _  
    ByVal ReplaceFileName As String, _  
    ByVal DiscardChanges As Boolean, _  
    ByVal ForceReload As Boolean _  
) As Long
```

SOLIDWORKS Type Library

ReloadWithReferences Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReloadWithReferences( _  
    ByVal ReadOnly As Boolean, _  
    ByVal DiscardChanges As Boolean, _  
    ByVal ReferencesToReload As Variant _  
) As Long
```

SOLIDWORKS Type Library

RemoveMaterialProperty Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveMaterialProperty( _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

RemoveModelColorizer Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveModelColorizer( _  
    ByVal PInterface As Object _  
)
```

SOLIDWORKS Type Library

RemoveTexture Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTexture() As Boolean
```

SOLIDWORKS Type Library

RemoveTexture2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTexture2( _  
    ByVal Config_name As String _  
) As Boolean
```

SOLIDWORKS Type Library

RemoveTextureByDisplayState Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RemoveTextureByDisplayState( _  
    ByVal DisplayStateName As String _  
) As Boolean
```

SOLIDWORKS Type Library

RemoveVisibleBox Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RemoveVisibleBox()
```

SOLIDWORKS Type Library

RenameDocument Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RenameDocument( _  
    ByVal NewName As String _  
) As Long
```

SOLIDWORKS Type Library

RenameDraftingStandard Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RenameDraftingStandard( _  
    ByVal Name As String _  
) As Boolean
```

SOLIDWORKS Type Library

ReorderFeature Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReorderFeature( _  
    ByVal FeatureToMove As String, _  
    ByVal TargetFeature As String, _  
    ByVal MoveLocation As Long _  
) As Boolean
```

SOLIDWORKS Type Library

ReorderFeature2 Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReorderFeature2( _  
    ByVal FeatToMove As String, _  
    ByVal TargetFeat As String, _  
    ByVal MoveLocation As Long _  
) As Boolean
```

SOLIDWORKS Type Library

ResetStandardViews Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ResetStandardViews() As Boolean
```

SOLIDWORKS Type Library

ReverseDecalsOrder Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ReverseDecalsOrder( _  
    ByVal DecalID As Long _  
) As Boolean
```

SOLIDWORKS Type Library

RotateOrCopy Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub RotateOrCopy( _  
    ByVal Copy As Boolean, _  
    ByVal NumCopies As Long, _  
    ByVal KeepRelations As Boolean, _  
    ByVal BaseX As Double, _  
    ByVal BaseY As Double, _  
    ByVal BaseZ As Double, _  
    ByVal DestX As Double, _  
    ByVal DestY As Double, _  
    ByVal DestZ As Double, _  
    ByVal Angle As Double _  
)
```

SOLIDWORKS Type Library

RunCommand Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function RunCommand( _  
    ByVal CommandID As Long, _  
    ByVal NewTitle As String _  
) As Boolean
```

SOLIDWORKS Type Library

SaveAs Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SaveAs( _  
    ByVal Name As String, _  
    ByVal Version As Long, _  
    ByVal Options As Long, _
```

```
ByVal ExportData As Object, _  
ByRef Errors As Long, _  
ByRef Warnings As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SaveAs2 Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function SaveAs2( _  
    ByVal Name As String, _  
    ByVal Version As Long, _  
    ByVal Options As Long, _  
    ByVal ExportData As Object, _  
    ByVal ReferencePrefixOrSuffixText As String, _  
    ByVal AddTextAsPrefix As Boolean, _  
    ByRef Errors As Long, _  
    ByRef Warnings As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SaveAs3 Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function SaveAs3( _  
    ByVal Name As String, _  
    ByVal Version As Long, _  
    ByVal Options As Long, _  
    ByVal ExportData As Object, _  
    ByVal AdvancedSaveAsOptions As Object, _  
    ByRef Errors As Long, _  
    ByRef Warnings As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SaveDeFeaturedFile Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function SaveDeFeaturedFile( _  
    ByVal FileName As String _  
) As Boolean
```

SOLIDWORKS Type Library

SaveDraftingStandard Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function SaveDraftingStandard( _  
    ByVal FileName As String _  
) As Boolean
```

SOLIDWORKS Type Library

SavePackAndGo Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function SavePackAndGo( _  
    ByVal PackAndGo As PackAndGo _  
    ) As Variant
```

SOLIDWORKS Type Library

SaveSelection Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SaveSelection( _  
    ByRef Status As Long _  
    ) As Object
```

SOLIDWORKS Type Library

SaveTo3DExperience Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SaveTo3DExperience( _  
    ByVal Options As Object, _  
    ByRef Errors As Long, _  
    ByRef Warnings As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

SaveViewToSolidworks Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SaveViewToSolidworks( _  
    ByVal ViewName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

ScaleOrCopy Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ScaleOrCopy( _  
    ByVal Copy As Boolean, _  
    ByVal NumCopies As Long, _  
    ByVal BaseX As Double, _  
    ByVal BaseY As Double, _  
    ByVal BaseZ As Double, _  
    ByVal Scale As Double _  
    )
```

SOLIDWORKS Type Library

SelectAll Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SelectAll()
```

SOLIDWORKS Type Library

SelectByID Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SelectByID( _
    ByVal Name As String, _
    ByVal Type As String, _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal Z As Double, _
    ByVal Append As Boolean, _
    ByVal Mark As Long, _
    ByVal Callout As Callout _
) As Boolean
```

SOLIDWORKS Type Library

SelectByID2 Method (ModelDocExtension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SelectByID2( _
    ByVal Name As String, _
    ByVal Type As String, _
    ByVal X As Double, _
    ByVal Y As Double, _
    ByVal Z As Double, _
    ByVal Append As Boolean, _
    ByVal Mark As Long, _
    ByVal Callout As Callout, _
    ByVal SelectOption As Long _
) As Boolean
```

SOLIDWORKS Type Library

SelectByRay Method (ModelDocExtension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SelectByRay( _
    ByVal WorldX As Double, _
    ByVal WorldY As Double, _
    ByVal WorldZ As Double, _
    ByVal RayVecX As Double, _
    ByVal RayVecY As Double, _
    ByVal RayVecZ As Double, _
    ByVal RayRadius As Double, _
    ByVal TypeWanted As Long, _
    ByVal Append As Boolean, _
    ByVal Mark As Long, _
    ByVal Option As Long _
) As Boolean
```

SOLIDWORKS Type Library

SetAdvancedSpotLightProperties Method (ModelDocExtension)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetAdvancedSpotLightProperties( _
    ByVal Name As String, _
    ByVal Exponent As Double, _
    ByVal AttenuationConst As Double, _
    ByVal AttenuationLinear As Double, _
    ByVal AttenuationQuad As Double _
)
```

SOLIDWORKS Type Library

SetApiUndoObject Method (ModelDocExtension)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetApiUndoObject( _  
    ByVal PHandler As Object, _  
    ByVal DisplayName As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetKeepLightInRenderScene Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Sub SetKeepLightInRenderScene( _  
    ByVal ID As Long, _  
    ByVal Val As Boolean _  
    )
```

SOLIDWORKS Type Library

SetLightEnabledInRender Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Sub SetLightEnabledInRender( _  
    ByVal ID As Long, _  
    ByVal Val As Boolean _  
    )
```

SOLIDWORKS Type Library

SetMaterialPropertyValues Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Sub SetMaterialPropertyValues( _  
    ByVal Material_property_values As Variant, _  
    ByVal Config_opt As Long, _  
    ByVal Config_names As Variant _  
    )
```

SOLIDWORKS Type Library

SetParameterValue Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Function SetParameterValue( _  
    ByVal DimName As String, _  
    ByVal Value As Double, _  
    ByVal Reserved As Long _  
    ) As Long
```

SOLIDWORKS Type Library

SetSceneBkgDIBx64 Method (ModelDocExtension)



Visual Basic for Applications (VBA)

```
Public Sub SetSceneBkgDIBx64( _  
    ByVal L_dib As Unknown _  
    )
```

SOLIDWORKS Type Library

SetSunLightAdvancedPropertyValues Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetSunLightAdvancedPropertyValues( _  
    ByVal Haze As Double, _  
    ByVal SunDiameter As Double, _  
    ByVal GroundAlbedo As Long, _  
    ByVal SkyGamma As Double _  
) As Boolean
```

SOLIDWORKS Type Library

SetSunLightSourcePropertyValues Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetSunLightSourcePropertyValues( _  
    ByVal NorthDirection As MathVector, _  
    ByVal NorthLatitude As Double, _  
    ByVal EastLongitude As Double, _  
    ByVal TimeZone As Double, _  
    ByVal DateTime As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetTexture Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTexture( _  
    ByVal Config_name As String, _  
    ByVal TextureIn As Texture _  
) As Boolean
```

SOLIDWORKS Type Library

SetTextureByDisplayState Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTextureByDisplayState( _  
    ByVal DisplayStateName As String, _  
    ByVal TextureIn As Texture _  
) As Boolean
```

SOLIDWORKS Type Library

SetTopLevelTransparency Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetTopLevelTransparency( _  
    ByVal InValue As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

SetUserPreferenceDouble Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetUserPreferenceDouble( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long, _  
    ByVal Value As Double _  
) As Boolean
```

SOLIDWORKS Type Library

SetUserPreferenceInteger Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetUserPreferenceInteger( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long, _  
    ByVal Value As Long _  
) As Boolean
```

SOLIDWORKS Type Library

SetUserPreferenceString Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetUserPreferenceString( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long, _  
    ByVal Value As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetUserPreferenceTextFormat Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetUserPreferenceTextFormat( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long, _  
    ByVal Value As TextFormat _  
) As Boolean
```

SOLIDWORKS Type Library

SetUserPreferenceToggle Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetUserPreferenceToggle( _  
    ByVal UserPref As Long, _  
    ByVal UserPrefOption As Long, _  
    ByVal Value As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

SetVisibleBox Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetVisibleBox( _  
    ByVal UpperLeft As MathPoint, _  
    ByVal LowerRight As MathPoint _  
)
```

ShowMessageBar Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ShowMessageBar( _
    ByVal Definition As Object, _
    ByVal Handler As Object _
) As Long
```

ShowModelBreakView Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ShowModelBreakView( _
    ByVal ShowView As Boolean, _
    ByVal ViewName As String _
) As Boolean
```

ShowPartRebuildIndicators Property (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Property ShowPartRebuildIndicators As Boolean
```

ShowSmartMessage Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Sub ShowSmartMessage( _
    ByVal Name As String, _
    ByVal TimeInMillSec As Long, _
    ByVal ShowInStatusBar As Boolean, _
    ByVal RemoveDefaultTip As Boolean _
)
```

ShowUserNotification Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function ShowUserNotification( _
    ByVal Definition As Object, _
    ByVal Handler As Object _
) As Long
```

SketchBoxSelect Method (ModelDocExtension) **Syntax**

Visual Basic for Applications (VBA)

```
Public Function SketchBoxSelect( _
    ByVal FirstPtX As Double, _
    ByVal FirstPtY As Double, _
    ByVal FirstPtZ As Double, _
    ByVal SecondPtX As Double, _
    ByVal SecondPtY As Double, _
```

```
ByVal SecondPtZ As Double _  
) As Boolean
```

SOLIDWORKS Type Library

SketchOffsetOnSurface Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SketchOffsetOnSurface( _  
    ByVal Offset As Double, _  
    ByVal Reverse As Boolean, _  
    ByVal UseFront As Boolean, _  
    ByVal MakeConstruct As Boolean _  
) As Boolean
```

SOLIDWORKS Type Library

StartFormatPainter Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub StartFormatPainter()
```

SOLIDWORKS Type Library

StartRecordingUndoObject Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub StartRecordingUndoObject()
```

SOLIDWORKS Type Library

StopFormatPainter Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub StopFormatPainter()
```

SOLIDWORKS Type Library

Stretch Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Stretch( _  
    ByVal KeepRelations As Boolean, _  
    ByVal BaseX As Double, _  
    ByVal BaseY As Double, _  
    ByVal DestX As Double, _  
    ByVal DestY As Double _  
)
```

SOLIDWORKS Type Library

SunLightInformation Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SunLightInformation( _  
    ByVal Type As Long _  
) As Double
```

SOLIDWORKS Type Library

ToolboxPartType Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property ToolboxPartType As Long
```

SOLIDWORKS Type Library

Transparency Property (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Transparency( _  
    ByVal Setting As DisplayStateSetting _  
    ) As Variant
```

SOLIDWORKS Type Library

UpdateExternalFileReferences Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub UpdateExternalFileReferences( _  
    ByVal ConfigOption As Long, _  
    ByVal ConfigName As String, _  
    ByVal UpdateStatus As Long _  
    )
```

SOLIDWORKS Type Library

UpdateFrozenFeatures Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function UpdateFrozenFeatures( _  
    ByVal UpdateAllConfigs As Boolean _  
    ) As Long
```

SOLIDWORKS Type Library

UpdateRenderMaterialsInSceneGraph Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub UpdateRenderMaterialsInSceneGraph( _  
    ByVal AddToSG As Boolean _  
    )
```

SOLIDWORKS Type Library

UpdateStandardViews Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function UpdateStandardViews( _  
    ByVal ViewName As String, _  
    ByVal ViewId As Long _  
    ) As Boolean
```

SOLIDWORKS Type Library

UpdateSunLight Method (ModelDocExtension)

Syntax

Visual Basic for Applications (VBA)

```
Public Function UpdateSunLight() As Boolean
```