

SOLIDWORKS API (VB6 COM) — Reference (71/102): PageSetup-Parameter

SOLIDWORKS API Documentation (converted from CHM)

PageSetup (Type)

SOLIDWORKS Type Library

PageSetup Object

Object Model

PageSetup

FooterTextFormat (TextFormat)

HeaderTextFormat (TextFormat)

SOLIDWORKS Type Library

PageSetup Object Members

Public Methods

 [GetHeaderFooterString](#)

 [GetResolution](#)

 [GetUseDefaultResolution](#)

 [SetFooter](#)

 [SetHeader](#)

 [SetResolution](#)

Public Properties

 [CenterFooter](#)

 [CenterHeader](#)

 [DrawingColor](#)

 [FooterTextFormat](#)

 [HeaderTextFormat](#)

 [HighQuality](#)

 [LeftFooter](#)

 [LeftHeader](#)

 [Orientation](#)

 [PrinterPaperLength](#)

 [PrinterPaperSize](#)

 [PrinterPaperSource](#)

 [PrinterPaperWidth](#)

 [RightFooter](#)

 [RightHeader](#)

 [Scale2](#)

 [ScaleDraftEdges](#)

 [ScaleToFit](#)

 [UsePageSetupOnSheets](#)

SOLIDWORKS Type Library

CenterFooter Property (PageSetup)

Syntax

Public Property CenterFooter As String

SOLIDWORKS Type Library

CenterHeader Property (PageSetup)



Public Property CenterHeader As String

SOLIDWORKS Type Library

DrawingColor Property (PageSetup)



Public Property DrawingColor As Long

SOLIDWORKS Type Library

FooterTextFormat Property (PageSetup)



Public Property FooterTextFormat As [TextFormat](#)

SOLIDWORKS Type Library

GetHeaderFooterString Method (PageSetup)



```
Public Function GetHeaderFooterString( _  
    ByVal WhichOne As Long _  
) As String
```

SOLIDWORKS Type Library

GetResolution Method (PageSetup)



Public Function GetResolution() As Long

SOLIDWORKS Type Library

GetUseDefaultResolution Method (PageSetup)



Public Function GetUseDefaultResolution() As Boolean

SOLIDWORKS Type Library

HeaderTextFormat Property (PageSetup)



Public Property HeaderTextFormat As [TextFormat](#)

SOLIDWORKS Type Library

HighQuality Property (PageSetup)



Visual Basic for Applications (VBA)

Public Property HighQuality As Boolean

SOLIDWORKS Type Library

LeftFooter Property (PageSetup)



Visual Basic for Applications (VBA)

Public Property LeftFooter As String

SOLIDWORKS Type Library

LeftHeader Property (PageSetup)



Visual Basic for Applications (VBA)

Public Property LeftHeader As String

SOLIDWORKS Type Library

Orientation Property (PageSetup)



Visual Basic for Applications (VBA)

Public Property Orientation As Long

SOLIDWORKS Type Library

PrinterPaperLength Property (PageSetup)



Visual Basic for Applications (VBA)

Public Property PrinterPaperLength As Long

SOLIDWORKS Type Library

PrinterPaperSize Property (PageSetup)



Visual Basic for Applications (VBA)

Public Property PrinterPaperSize As Long

SOLIDWORKS Type Library

PrinterPaperSource Property (PageSetup)



Visual Basic for Applications (VBA)

Public Property PrinterPaperSource As Long

SOLIDWORKS Type Library

PrinterPaperWidth Property (PageSetup)



Visual Basic for Applications (VBA)

Public Property PrinterPaperWidth As Long

SOLIDWORKS Type Library

RightFooter Property (PageSetup)



Visual Basic for Applications (VBA)

```
Public Property RightFooter As String
```

SOLIDWORKS Type Library

RightHeader Property (PageSetup)



Visual Basic for Applications (VBA)

```
Public Property RightHeader As String
```

SOLIDWORKS Type Library

Scale2 Property (PageSetup)



Visual Basic for Applications (VBA)

```
Public Property Scale2 As Double
```

SOLIDWORKS Type Library

ScaleDraftEdges Property (PageSetup)



Visual Basic for Applications (VBA)

```
Public Property ScaleDraftEdges As Boolean
```

SOLIDWORKS Type Library

ScaleToFit Property (PageSetup)



Visual Basic for Applications (VBA)

```
Public Property ScaleToFit As Boolean
```

SOLIDWORKS Type Library

SetFooter Method (PageSetup)



Visual Basic for Applications (VBA)

```
Public Function SetFooter( _  
    ByVal Left As String, _  
    ByVal Center As String, _  
    ByVal Right As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetHeader Method (PageSetup)



Visual Basic for Applications (VBA)

```
Public Function SetHeader( _  
    ByVal Left As String, _  
    ByVal Center As String, _  
    ByVal Right As String _  
    ) As Boolean
```

SOLIDWORKS Type Library

SetResolution Method (PageSetup)



```
Public Function SetResolution( _  
    ByVal UseDefault As Boolean, _  
    ByVal DPI As Long _  
    ) As Boolean
```



```
Public Property UsePageSetupOnSheets As Boolean
```

Paragraphs (Type)

SOLIDWORKS Type Library
Paragraphs Object

Object Model

Paragraphs

SOLIDWORKS Type Library
Paragraphs Object Members

Public Methods

	GetBulletsAndNumbering
	GetFormatting
	GetIndentation
	GetText
	GetTextSegmentCount
	GetTextSegmentFormat
	GetTextSegmentText
	SetBulletsAndNumbering
	SetFormatting
	SetIndentation
	SetTextSegmentFormat
	UpdateParagraph

Public Properties

	Count
	CurrentParagraph

SOLIDWORKS Type Library
Count Property (Paragraphs)

Syntax

Visual Basic for Applications (VBA)
Public Property Count As Long

SOLIDWORKS Type Library
CurrentParagraph Property (Paragraphs)

Syntax

Visual Basic for Applications (VBA)
Public Property CurrentParagraph As Long

SOLIDWORKS Type Library
GetBulletsAndNumbering Method (Paragraphs)

Syntax

Visual Basic for Applications (VBA)
Public Function GetBulletsAndNumbering(_ ByRef ParagraphType As Long, _ ByRef NumberingType As Long, _

```
ByRef StartAt As Long, _  
ByRef Type As Long, _  
ByRef Format As Long _  
) As Boolean
```

SOLIDWORKS Type Library

GetFormatting Method (Paragraphs)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFormatting( _  
ByRef Paragraphspacing As Double, _  
ByRef LineSpacing As Double _  
) As Boolean
```

SOLIDWORKS Type Library

GetIndentation Method (Paragraphs)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIndentation( _  
ByRef FirstlineIndent As Double, _  
ByRef Indent As Double, _  
ByRef IndentIncrement As Double _  
) As Boolean
```

SOLIDWORKS Type Library

GetText Method (Paragraphs)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetText( _  
ByVal ShowWordWrap As Boolean _  
) As String
```

SOLIDWORKS Type Library

GetTextSegmentCount Method (Paragraphs)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTextSegmentCount() As Long
```

SOLIDWORKS Type Library

GetTextSegmentFormat Method (Paragraphs)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTextSegmentFormat( _  
ByVal Index As Long _  
) As Object
```

SOLIDWORKS Type Library

GetTextSegmentText Method (Paragraphs)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTextSegmentText( _  
ByVal Index As Long _  
) As String
```


SetBulletsAndNumbering Method (Paragraphs)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetBulletsAndNumbering( _  
    ByVal ParagraphType As Long, _  
    ByVal NumberingType As Long, _  
    ByVal StartAt As Long, _  
    ByVal Type As Long, _  
    ByVal Format As Long _  
) As Boolean
```

SetFormatting Method (Paragraphs)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetFormatting( _  
    ByVal Paragraphspacing As Double, _  
    ByVal LineSpacing As Double _  
) As Boolean
```

SetIndentation Method (Paragraphs)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetIndentation( _  
    ByVal FirstlineIndent As Double, _  
    ByVal Indent As Double, _  
    ByVal IndentIncrement As Double _  
) As Boolean
```

SetTextSegmentFormat Method (Paragraphs)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function SetTextSegmentFormat( _  
    ByVal Segment As Long, _  
    ByVal Format As Object _  
) As Boolean
```

UpdateParagraph Method (Paragraphs)**Syntax**

Visual Basic for Applications (VBA)

```
Public Function UpdateParagraph() As Boolean
```

ParallelMateFeatureData (Type)

SOLIDWORKS Type Library

ParallelMateFeatureData Object

Object Model

ParallelMateFeatureData

SOLIDWORKS Type Library

ParallelMateFeatureData Object Members

Public Properties

EntitiesToMate

MateAlignment

PickPoints

SOLIDWORKS Type Library

EntitiesToMate Property (ParallelMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property EntitiesToMate As Variant

SOLIDWORKS Type Library

MateAlignment Property (ParallelMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property MateAlignment As Long

SOLIDWORKS Type Library

PickPoints Property (ParallelMateFeatureData)

Syntax

Visual Basic for Applications (VBA)

Public Property PickPoints As Variant

Parameter (Type)

SOLIDWORKS Type Library

Parameter Object

Object Model

Parameter

SOLIDWORKS Type Library

Parameter Object Members

Public Methods

	GetDoubleValue
	GetName
	GetOption
	GetStringValue
	GetType
	GetVector
	GetVectorVB
	SetDoubleValue
	SetDoubleValue2
	SetOption
	SetStringValue
	SetStringValue2
	SetVector
	SetVector2

SOLIDWORKS Type Library

GetDoubleValue Method (Parameter)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDoubleValue() As Double
```

SOLIDWORKS Type Library

GetName Method (Parameter)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetName() As String
```

SOLIDWORKS Type Library

GetOption Method (Parameter)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetOption( _  
    ByVal WhichOption As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetStringValue Method (Parameter)



Visual Basic for Applications (VBA)

```
Public Function GetStringValue() As String
```

SOLIDWORKS Type Library

GetType Method (Parameter)



Visual Basic for Applications (VBA)

```
Public Function GetType() As Long
```

SOLIDWORKS Type Library

GetVector Method (Parameter)



Visual Basic for Applications (VBA)

```
Public Sub GetVector( _  
    ByRef X As Double, _  
    ByRef Y As Double, _  
    ByRef Z As Double _  
)
```

SOLIDWORKS Type Library

GetVectorVB Method (Parameter)



Visual Basic for Applications (VBA)

```
Public Function GetVectorVB() As Variant
```

SOLIDWORKS Type Library

SetDoubleValue Method (Parameter)



Visual Basic for Applications (VBA)

```
Public Function SetDoubleValue( _  
    ByVal Value As Double _  
) As Boolean
```

SOLIDWORKS Type Library

SetDoubleValue2 Method (Parameter)



Visual Basic for Applications (VBA)

```
Public Function SetDoubleValue2( _  
    ByVal Value As Double, _  
    ByVal ConfigurationOption As Long, _  
    ByVal ConfigurationName As String _  
) As Boolean
```

SOLIDWORKS Type Library

SetOption Method (Parameter)



Visual Basic for Applications (VBA)

```
Public Function SetOption( _  
    ByVal WhichOption As Long, _
```

```
    ByVal OptionValue As Long _  
  ) As Boolean
```

SOLIDWORKS Type Library

SetStringValue Method (Parameter)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetStringValue( _  
    ByVal StringValue As String _  
  ) As Boolean
```

SOLIDWORKS Type Library

SetStringValue2 Method (Parameter)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetStringValue2( _  
    ByVal StringValue As String, _  
    ByVal ConfigurationOption As Long, _  
    ByVal ConfigurationName As String _  
  ) As Boolean
```

SOLIDWORKS Type Library

SetVector Method (Parameter)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetVector( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
  ) As Boolean
```

SOLIDWORKS Type Library

SetVector2 Method (Parameter)

Syntax

Visual Basic for Applications (VBA)

```
Public Function SetVector2( _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double, _  
    ByVal ConfigurationOption As Long, _  
    ByVal ConfigurationName As String _  
  ) As Boolean
```