

SOLIDWORKS API (VB6 COM) — Reference (72/102): PartDoc (part 1 of 2)

SOLIDWORKS API Documentation (converted from CHM)

PartDoc (part 1 of 2) (Type)

SOLIDWORKS Type Library

PartDoc Object

 Object Model

PartDoc

EnumBodies

EnumBodies2

EnumBodies3 (EnumBodies2)

EnumRelatedBodies (EnumBodies)

EnumRelatedBodies2 (EnumBodies2)

EnumRelatedSectionedBodies (EnumBodies)

EnumRelatedSectionedBodies2 (EnumBodies2)

GetMaterialVisualProperties (MaterialVisualPropertiesData)

IBodyObject (Body)

IBodyObject2 (Body2)

ICreateFeatureFromBody (Feature)

ICreateFeatureFromBody2 (Feature)

ICreateFeatureFromBody3 (Feature)

ICreateFeatureFromBody4 (Feature)

ICreateNewBody (Body)

ICreateNewBody2 (Body2)

ICreateSurfaceFeatureFromBody (Feature)

IFeatureById (Feature)

IFeatureByName (Feature)

IFirstFeature (Feature)

IGetCorrespondingEntity (Entity)

IGetEntityByName (Entity)

IGetNamedEntities (Entity)

IGetProcessedBody (Body)

IGetProcessedBody2 (Body2)


IGetProcessedBodyWithSelfFace (Body)

IGetProcessedBodyWithSelfFace2 (Body2)

IGetSectionedBody (Body)

IGetSectionedBody2 (Body2)

InsertPart (Feature)



SOLIDWORKS Type Library
PartDoc Object Members

Public Methods

AddPropertyExtension
Body
CreateExplodedView
CreateFeatureFromBody
CreateFeatureFromBody2
CreateFeatureFromBody3
CreateNewBody
CreateSurfaceFeatureFromBody
DeleteEntityName
DumpFacets
EditRebuild
EditRollback
EditRollforward
EditSuppress
EditUnsuppress
EditUnsuppressDependent
EnumBodies
EnumBodies2
EnumBodies3
EnumRelatedBodies
EnumRelatedBodies2
EnumRelatedSectionedBodies
EnumRelatedSectionedBodies2
ExportFlatPatternView
ExportToDWG
ExportToDWG2
FeatureById
FeatureByName
FeatureExtrusion
FeatureExtrusion2
FeatureExtrusion3
FeatureExtrusionThin
FeatureExtrusionThin2
FeatureExtrusionThin3
FeatureRevolve

	FeatureRevolve2
	FeatureRevolveCut
	FeatureRevolveThin
	FeatureRevolveThin2
	FeatureRevolveThinCut
	FeatureStock
	FeatureXpert
	FirstFeature
	ForceRebuild
	GetBodies
	GetBodies2
	GetCorresponding
	GetCorrespondingEntity
	GetEntityByName
	GetEntityName
	GetExplodedViewConfigurationName
	GetExplodedViewCount
	GetExplodedViewNames
	GetMateReferenceEntity
	GetMaterialPropertyName
	GetMaterialPropertyName2
	GetMaterialVisualProperties
	GetNamedEntities
	GetNamedEntitiesCount
	GetPartBox
	GetProcessedBody
	GetProcessedBodyWithSelfFace
	GetPropertyExtension
	GetRelatedBodies
	GetRelatedSectionedBodies
	GetSectionedBody
	GetTessNorms
	GetTessTriangleCount
	GetTessTriangles
	GetTessTriStripEdges
	GetTessTriStripNorms
	GetTessTriStrips
	GetTessTriStripSize
	GetTessTriStripTextures
	IBodyObject
	IBodyObject2
	ICreateFeatureFromBody
	ICreateFeatureFromBody2

	<u>ICreateFeatureFromBody3</u>
	<u>ICreateFeatureFromBody4</u>
	<u>ICreateNewBody</u>
	<u>ICreateNewBody2</u>
	<u>ICreateSurfaceFeatureFromBody</u>
	<u>ICreateSurfaceFeatureFromBodyCount</u>
	<u>ICreateSurfaceFeatureFromBodyCount2</u>
	<u>IDeleteEntityName</u>
	<u>IExportToDWG</u>
	<u>IExportToDWG2</u>
	<u>IFeatureById</u>
	<u>IFeatureByName</u>
	<u>IFirstFeature</u>
	<u>IGetCorrespondingEntity</u>
	<u>IGetEntityByName</u>
	<u>IGetEntityName</u>
	<u>IGetNamedEntities</u>
	<u>IGetPartBox</u>
	<u>IGetProcessedBody</u>
	<u>IGetProcessedBody2</u>
	<u>IGetProcessedBodyWithSelFace</u>
	<u>IGetProcessedBodyWithSelFace2</u>
	<u>IGetSectionedBody</u>
	<u>IGetSectionedBody2</u>
	<u>IGetTessNorms</u>
	<u>IGetTessTriangles</u>
	<u>IGetTessTriStripEdges</u>
	<u>IGetTessTriStripEdgeSize</u>
	<u>IGetTessTriStripNorms</u>
	<u>IGetTessTriStrips</u>
	<u>InsertCombineFeature</u>
	<u>ImportDiagnosis</u>
	<u>ImportDiagnosisGapCloser</u>
	<u>InsertBasePart</u>
	<u>InsertBendNotes</u>
	<u>InsertBends</u>
	<u>InsertBends2</u>
	<u>InsertBendTable</u>
	<u>InsertCombineFeature</u>
	<u>InsertImportedFeature</u>
	<u>InsertMirrorAll</u>
	<u>InsertMirrorFeature</u>
	<u>InsertPart</u>

 InsertPart2
 InsertPart3
 InsertStockTurned
 ISetEntityName
 IsMirrored
 IsWeldment
 MakeSection
 MirrorFeature
 MirrorPart
 MirrorPart2
 RemoveAllDisplayStates
 ReorderFeature
 ResetPropertyExtension
 SaveToFile
 SaveToFile2
 SaveToFile3
 SetCosmosWorksMaterial
 SetDroppedFileName
 SetEntityName
 SetFaceMap
 SetLineColor
 SetLineStyle
 SetLineWidth
 SetMaterialPropertyName
 SetMaterialPropertyName2
 SetMaterialVisualProperties
 ShowExploded

Public Properties

 MaterialPropertyValues
 MaterialIdName
 MaterialPropertyValues
 MaterialUserName

Events

 ActiveAnnotationViewChangeNotify
 ActiveConfigChangeNotify
 ActiveConfigChangePostNotify
 ActiveDisplayStateChangePostNotify
 ActiveDisplayStateChangePreNotify
 ActiveViewChangeNotify
 AddCustomPropertyNotify
 AddDependencyNotify
 AddDvePagePreNotify

 AddItemNotify
 AutoSaveNotify
 AutoSaveToStorageNotify
 AutoSaveToStorageStoreNotify
 BodyVisibleChangeNotify
 ChangeCustomPropertyNotify
 ClearSelectionsNotify
 CloseDesignTableNotify
 CommandManagerTabActivatedPreNotify
 ConfigurationChangeNotify
 ConvertToBodiesPostNotify
 ConvertToBodiesPreNotify
 DeleteCustomPropertyNotify
 DeleteDependencyNotify
 DeleteItemNotify
 DeleteItemPreNotify
 DeleteSelectionPreNotify
 DestroyNotify
 DestroyNotify2
 DimensionChangeNotify
 DisplayPaneCollapseNotify
 DisplayPaneExpandNotify
 DragStateChangeNotify
 DynamicHighlightNotify
 EquationEditorPostNotify
 EquationEditorPreNotify
 FeatureEditPreNotify
 FeatureManagerFilterStringChangeNotify
 FeatureManagerTabActivatedNotify
 FeatureManagerTabActivatedPreNotify
 FeatureManagerTreeRebuildNotify
 FeatureSketchEditPreNotify
 FileDropPostNotify
 FileDropPreNotify
 FileReloadCancelNotify
 FileReloadNotify
 FileReloadPreNotify
 FileSaveAsNotify
 FileSaveAsNotify2
 FileSaveNotify
 FileSavePostCancelNotify
 FileSavePostNotify
 FlipLoopNotify

 InsertTableNotify
 LightingDialogCreateNotify
 LoadFromStorageNotify
 LoadFromStorageStoreNotify
 ModifyNotify
 ModifyTableNotify
 NewSelectionNotify
 OpenDesignTableNotify
 PreRenameItemNotify
 PromptBodiesToKeepNotify
 PublishTo3DPDFNotify
 RedoPostNotify
 RedoPreNotify
 RegenNotify
 RegenPostNotify
 RegenPostNotify2
 RenamedDocumentNotify
 RenameDisplayTitleNotify
 RenameItemNotify
 SaveToStorageNotify
 SaveToStorageStoreNotify
 SensorAlertPreNotify
 SketchSolveNotify
 SolidBodyFolderReorderNotify
 SuppressionStateChangeNotify
 UndoPostNotify
 UndoPreNotify
 UnitsChangeNotify
 UserSelectionPostNotify
 UserSelectionPreNotify
 ViewNewNotify
 ViewNewNotify2
 WeldmentCutListUpdatePostNotify

SOLIDWORKS Type Library

ActiveAnnotationViewChangeNotify Event (PartDoc)



 Syntax

Visual Basic for Applications (VBA)

Public Event ActiveAnnotationViewChangeNotify()

SOLIDWORKS Type Library

ActiveConfigChangeNotify Event (PartDoc)



 Syntax

Visual Basic for Applications (VBA)

Public Event ActiveConfigChangeNotify()

SOLIDWORKS Type Library

ActiveConfigChangePostNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

Public Event ActiveConfigChangePostNotify()

SOLIDWORKS Type Library

ActiveDisplayStateChangePostNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ActiveDisplayStateChangePostNotify( _  
    ByVal DisplayStateName As String _  
)
```

SOLIDWORKS Type Library

ActiveDisplayStateChangePreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

Public Event ActiveDisplayStateChangePreNotify()

SOLIDWORKS Type Library

ActiveViewChangeNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

Public Event ActiveViewChangeNotify()

SOLIDWORKS Type Library

AddCustomPropertyNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AddCustomPropertyNotify( _  
    ByVal propName As String, _  
    ByVal Configuration As String, _  
    ByVal Value As String, _  
    ByVal valueType As Long _  
)
```

SOLIDWORKS Type Library

AddDependencyNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AddDependencyNotify( _  
    ByVal PathName As String _  
)
```

SOLIDWORKS Type Library

AddDvePagePreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AddDvePagePreNotify( _  
    ByVal Command As Long, _  
    ByRef PageToAdd As Object _  
)
```

SOLIDWORKS Type Library

AddItemNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AddItemNotify( _  
    ByVal EntityType As Long, _  
    ByVal itemName As String _  
)
```

SOLIDWORKS Type Library

AddPropertyExtension Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddPropertyExtension( _  
    ByVal PropertyExtension As Variant _  
) As Long
```

SOLIDWORKS Type Library

AutoSaveNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AutoSaveNotify( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

AutoSaveToStorageNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event AutoSaveToStorageNotify()
```

SOLIDWORKS Type Library

AutoSaveToStorageStoreNotify Event (PartDoc)





Syntax

Visual Basic for Applications (VBA)

```
Public Event AutoSaveToStorageStoreNotify()
```

SOLIDWORKS Type Library

Body Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function Body() As Object
```

SOLIDWORKS Type Library

BodyVisibleChangeNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event BodyVisibleChangeNotify()
```

SOLIDWORKS Type Library

ChangeCustomPropertyNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ChangeCustomPropertyNotify( _  
    ByVal propName As String, _  
    ByVal Configuration As String, _  
    ByVal oldValue As String, _  
    ByVal NewValue As String, _  
    ByVal valueType As Long _  
)
```

SOLIDWORKS Type Library

ClearSelectionsNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ClearSelectionsNotify()
```

SOLIDWORKS Type Library

CloseDesignTableNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event CloseDesignTableNotify( _  
    ByVal DesignTable As Object _  
)
```

SOLIDWORKS Type Library

CommandManagerTabActivatedPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event CommandManagerTabActivatedPreNotify( _  
    ByVal CommandTabIndex As Long, _  
    ByVal CommandTabName As String _  
)
```

SOLIDWORKS Type Library

ConfigurationChangeNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ConfigurationChangeNotify( _  
    ByVal ConfigurationName As String, _  
    ByVal Object As Object, _  
    ByVal ObjectType As Long, _  
    ByVal changeType As Long _  
)
```

SOLIDWORKS Type Library

ConvertToBodiesPostNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ConvertToBodiesPostNotify( _  
    ByVal FileName As String, _  
    ByVal SaveOption As Long, _  
    ByVal PreserveGeometryAndSketches As Boolean _  
)
```

SOLIDWORKS Type Library

ConvertToBodiesPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event ConvertToBodiesPreNotify( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

CreateExplodedView Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateExplodedView() As Boolean
```

SOLIDWORKS Type Library

CreateFeatureFromBody Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureFromBody( _  
    ByVal Body As Object _  
) As Object
```

SOLIDWORKS Type Library

CreateFeatureFromBody2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureFromBody2( _  
    ByVal Body As Object, _  
    ByVal MakeRefSurface As Boolean _  
    ) As Object
```

SOLIDWORKS Type Library

CreateFeatureFromBody3 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateFeatureFromBody3( _  
    ByVal Body As Object, _  
    ByVal MakeRefSurface As Boolean, _  
    ByVal Options As Long _  
    ) As Object
```

SOLIDWORKS Type Library

CreateNewBody Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateNewBody() As Object
```

SOLIDWORKS Type Library

CreateSurfaceFeatureFromBody Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function CreateSurfaceFeatureFromBody( _  
    ByVal Body As Object, _  
    ByVal Options As Long _  
    ) As Variant
```

SOLIDWORKS Type Library

DeleteCustomPropertyNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteCustomPropertyNotify( _  
    ByVal propName As String, _  
    ByVal Configuration As String, _  
    ByVal Value As String, _  
    ByVal valueType As Long _  
    )
```

SOLIDWORKS Type Library

DeleteDependencyNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteDependencyNotify( _  
    ByVal PathName As String _  
    )
```

SOLIDWORKS Type Library

DeleteEntityName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteEntityName( _  
    ByVal Entity As Object _  
) As Boolean
```

SOLIDWORKS Type Library

DeleteItemNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteItemNotify( _  
    ByVal EntityType As Long, _  
    ByVal itemName As String _  
)
```

SOLIDWORKS Type Library

DeleteItemPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteItemPreNotify( _  
    ByVal EntityType As Long, _  
    ByVal itemName As String _  
)
```

SOLIDWORKS Type Library

DeleteSelectionPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DeleteSelectionPreNotify()
```

SOLIDWORKS Type Library

DestroyNotify2 Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DestroyNotify2( _  
    ByVal DestroyType As Long _  
)
```

SOLIDWORKS Type Library

DestroyNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DestroyNotify()
```

SOLIDWORKS Type Library

DimensionChangeNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DimensionChangeNotify( _  
    ByVal displayDim As Object _  
)
```

SOLIDWORKS Type Library

DisplayPaneCollapseNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DisplayPaneCollapseNotify()
```

SOLIDWORKS Type Library

DisplayPaneExpandNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DisplayPaneExpandNotify()
```

SOLIDWORKS Type Library

DragStateChangeNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DragStateChangeNotify( _  
    ByVal State As Boolean _  
)
```

SOLIDWORKS Type Library

Dumpfacets Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub Dumpfacets()
```

SOLIDWORKS Type Library

DynamicHighlightNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event DynamicHighlightNotify( _  
    ByVal bHighlightState As Boolean _  
)
```

SOLIDWORKS Type Library

EditRebuild Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub EditRebuild()
```

SOLIDWORKS Type Library

EditRollback Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Sub EditRollback()
```

SOLIDWORKS Type Library

EditRollforward Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Sub EditRollforward()
```

SOLIDWORKS Type Library

EditSuppress Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Sub EditSuppress()
```

SOLIDWORKS Type Library

EditUnsuppress Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Sub EditUnsuppress()
```

SOLIDWORKS Type Library

EditUnsuppressDependent Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Sub EditUnsuppressDependent()
```

SOLIDWORKS Type Library

EnumBodies Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function EnumBodies( _  
    ByVal BodyType As Long _  
) As EnumBodies
```

SOLIDWORKS Type Library

EnumBodies2 Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function EnumBodies2( _  
    ByVal BodyType As Long _  
) As EnumBodies2
```

SOLIDWORKS Type Library

EnumBodies3 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumBodies3( _  
    ByVal BodyType As Long, _  
    ByVal BVisibleOnly As Boolean _  
    ) As EnumBodies2
```

SOLIDWORKS Type Library

EnumRelatedBodies Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumRelatedBodies() As EnumBodies
```

SOLIDWORKS Type Library

EnumRelatedBodies2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumRelatedBodies2() As EnumBodies2
```

SOLIDWORKS Type Library

EnumRelatedSectionedBodies Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumRelatedSectionedBodies( _  
    ByVal ViewIn As ModelView _  
    ) As EnumBodies
```

SOLIDWORKS Type Library

EnumRelatedSectionedBodies2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function EnumRelatedSectionedBodies2( _  
    ByVal ViewIn As ModelView _  
    ) As EnumBodies2
```

SOLIDWORKS Type Library

EquationEditorPostNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event EquationEditorPostNotify( _  
    ByVal Changed As Boolean _  
    )
```

SOLIDWORKS Type Library

EquationEditorPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

Public Event EquationEditorPreNotify()

SOLIDWORKS Type Library

ExportFlatPatternView Method (PartDoc)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function ExportFlatPatternView( _  
    ByVal FilePath As String, _  
    ByVal Options As Long _  
) As Boolean
```

SOLIDWORKS Type Library

ExportToDWG Method (PartDoc)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function ExportToDWG( _  
    ByVal FilePath As String, _  
    ByVal ModelName As String, _  
    ByVal Action As Long, _  
    ByVal ExportToSingleFile As Boolean, _  
    ByVal Alignment As Variant, _  
    ByVal IsXDirFlipped As Boolean, _  
    ByVal IsYDirFlipped As Boolean, _  
    ByVal SheetMetalOptions As Long, _  
    ByVal Views As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

ExportToDWG2 Method (PartDoc)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function ExportToDWG2( _  
    ByVal FilePath As String, _  
    ByVal ModelName As String, _  
    ByVal Action As Long, _  
    ByVal ExportToSingleFile As Boolean, _  
    ByVal Alignment As Variant, _  
    ByVal IsXDirFlipped As Boolean, _  
    ByVal IsYDirFlipped As Boolean, _  
    ByVal SheetMetalOptions As Long, _  
    ByVal Views As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

FeatureById Method (PartDoc)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function FeatureById( _  
    ByVal ID As Long _  
) As Object
```

SOLIDWORKS Type Library

FeatureByName Method (PartDoc)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function FeatureByName( _  
    ByVal Name As String _  
    ) As Object
```

SOLIDWORKS Type Library

FeatureEditPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FeatureEditPreNotify( _  
    ByVal EditFeature As Object _  
    )
```

SOLIDWORKS Type Library

FeatureExtrusion Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureExtrusion( _  
    ByVal Sd As Boolean, _  
    ByVal Flip As Boolean, _  
    ByVal Dir As Boolean, _  
    ByVal T1 As Long, _  
    ByVal T2 As Long, _  
    ByVal D1 As Double, _  
    ByVal D2 As Double, _  
    ByVal Dchk1 As Boolean, _  
    ByVal Dchk2 As Boolean, _  
    ByVal Ddir1 As Boolean, _  
    ByVal Ddir2 As Boolean, _  
    ByVal Dang1 As Double, _  
    ByVal Dang2 As Double, _  
    ByVal OffsetReverse1 As Boolean, _  
    ByVal OffsetReverse2 As Boolean _  
    )
```

SOLIDWORKS Type Library

FeatureExtrusion2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureExtrusion2( _  
    ByVal Sd As Boolean, _  
    ByVal Flip As Boolean, _  
    ByVal Dir As Boolean, _  
    ByVal T1 As Long, _  
    ByVal T2 As Long, _  
    ByVal D1 As Double, _  
    ByVal D2 As Double, _  
    ByVal Dchk1 As Boolean, _  
    ByVal Dchk2 As Boolean, _  
    ByVal Ddir1 As Boolean, _  
    ByVal Ddir2 As Boolean, _  
    ByVal Dang1 As Double, _  
    ByVal Dang2 As Double, _  
    ByVal OffsetReverse1 As Boolean, _  
    ByVal OffsetReverse2 As Boolean, _  
    ByVal Merge As Boolean _  
    )
```

SOLIDWORKS Type Library

FeatureExtrusion3 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureExtrusion3( _  
    ByVal Sd As Boolean, _  
    ByVal Flip As Boolean, _  
    ByVal Dir As Boolean, _  
    ByVal T1 As Long, _  
    ByVal T2 As Long, _  
    ByVal D1 As Double, _  
    ByVal D2 As Double, _  
    ByVal Dchk1 As Boolean, _  
    ByVal Dchk2 As Boolean, _  
    ByVal Ddir1 As Boolean, _  
    ByVal Ddir2 As Boolean, _  
    ByVal Dang1 As Double, _  
    ByVal Dang2 As Double, _  
    ByVal OffsetReverse1 As Boolean, _  
    ByVal OffsetReverse2 As Boolean, _  
    ByVal TranslateSurface1 As Boolean, _  
    ByVal TranslateSurface2 As Boolean, _  
    ByVal Merge As Boolean _  
)
```

SOLIDWORKS Type Library

FeatureExtrusionThin Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureExtrusionThin( _  
    ByVal Sd As Boolean, _  
    ByVal Flip As Boolean, _  
    ByVal Dir As Boolean, _  
    ByVal T1 As Long, _  
    ByVal T2 As Long, _  
    ByVal D1 As Double, _  
    ByVal D2 As Double, _  
    ByVal Dchk1 As Boolean, _  
    ByVal Dchk2 As Boolean, _  
    ByVal Ddir1 As Boolean, _  
    ByVal Ddir2 As Boolean, _  
    ByVal Dang1 As Double, _  
    ByVal Dang2 As Double, _  
    ByVal OffsetReverse1 As Boolean, _  
    ByVal OffsetReverse2 As Boolean, _  
    ByVal Thk1 As Double, _  
    ByVal Thk2 As Double, _  
    ByVal EndThk As Double, _  
    ByVal RevThinDir As Long, _  
    ByVal CapEnds As Long, _  
    ByVal AddBends As Boolean, _  
    ByVal BendRad As Double _  
)
```

SOLIDWORKS Type Library

FeatureExtrusionThin2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureExtrusionThin2( _  
    ByVal Sd As Boolean, _  
    ByVal Flip As Boolean, _  
    ByVal Dir As Boolean, _  
    ByVal T1 As Long, _  
    ByVal T2 As Long, _  
    ByVal D1 As Double, _  
    ByVal D2 As Double, _
```

```

    ByVal Dchk1 As Boolean, _
    ByVal Dchk2 As Boolean, _
    ByVal Ddir1 As Boolean, _
    ByVal Ddir2 As Boolean, _
    ByVal Dang1 As Double, _
    ByVal Dang2 As Double, _
    ByVal OffsetReverse1 As Boolean, _
    ByVal OffsetReverse2 As Boolean, _
    ByVal Merge As Boolean, _
    ByVal Thk1 As Double, _
    ByVal Thk2 As Double, _
    ByVal EndThk As Double, _
    ByVal RevThinDir As Long, _
    ByVal CapEnds As Long, _
    ByVal AddBends As Boolean, _
    ByVal BendRad As Double _
)

```

SOLIDWORKS Type Library

FeatureExtrusionThin3 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```

Public Sub FeatureExtrusionThin3( _
    ByVal Sd As Boolean, _
    ByVal Flip As Boolean, _
    ByVal Dir As Boolean, _
    ByVal T1 As Long, _
    ByVal T2 As Long, _
    ByVal D1 As Double, _
    ByVal D2 As Double, _
    ByVal Dchk1 As Boolean, _
    ByVal Dchk2 As Boolean, _
    ByVal Ddir1 As Boolean, _
    ByVal Ddir2 As Boolean, _
    ByVal Dang1 As Double, _
    ByVal Dang2 As Double, _
    ByVal OffsetReverse1 As Boolean, _
    ByVal OffsetReverse2 As Boolean, _
    ByVal TranslateSurface1 As Boolean, _
    ByVal TranslateSurface2 As Boolean, _
    ByVal Merge As Boolean, _
    ByVal Thk1 As Double, _
    ByVal Thk2 As Double, _
    ByVal EndThk As Double, _
    ByVal RevThinDir As Long, _
    ByVal CapEnds As Long, _
    ByVal AddBends As Boolean, _
    ByVal BendRad As Double _
)

```

SOLIDWORKS Type Library

FeatureManagerFilterStringChangeNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```

Public Event FeatureManagerFilterStringChangeNotify( _
    ByVal FilterString As String _
)

```

SOLIDWORKS Type Library

FeatureManagerTabActivatedNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FeatureManagerTabActivatedNotify( _  
    ByVal CommandIndex As Long, _  
    ByVal CommandTabName As String _  
)
```

SOLIDWORKS Type Library

FeatureManagerTabActivatedPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FeatureManagerTabActivatedPreNotify( _  
    ByVal CommandIndex As Long, _  
    ByVal CommandTabName As String _  
)
```

SOLIDWORKS Type Library

FeatureManagerTreeRebuildNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FeatureManagerTreeRebuildNotify()
```

SOLIDWORKS Type Library

FeatureRevolve Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureRevolve( _  
    ByVal Angle As Double, _  
    ByVal ReverseDir As Boolean, _  
    ByVal Angle2 As Double, _  
    ByVal RevType As Long _  
)
```

SOLIDWORKS Type Library

FeatureRevolve2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureRevolve2( _  
    ByVal Angle As Double, _  
    ByVal ReverseDir As Boolean, _  
    ByVal Angle2 As Double, _  
    ByVal RevType As Long, _  
    ByVal Merge As Boolean _  
)
```

SOLIDWORKS Type Library

FeatureRevolveCut Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureRevolveCut( _  
    ByVal Angle As Double, _  
    ByVal ReverseDir As Boolean, _
```

```
ByVal Angle2 As Double, _  
ByVal RevType As Long _  
)
```

SOLIDWORKS Type Library

FeatureRevolveThin Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureRevolveThin( _  
    ByVal Angle As Double, _  
    ByVal ReverseDir As Boolean, _  
    ByVal Angle2 As Double, _  
    ByVal RevType As Long, _  
    ByVal Thickness1 As Double, _  
    ByVal Thickness2 As Double, _  
    ByVal ReverseThinDir As Long _  
)
```

SOLIDWORKS Type Library

FeatureRevolveThin2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureRevolveThin2( _  
    ByVal Angle As Double, _  
    ByVal ReverseDir As Boolean, _  
    ByVal Angle2 As Double, _  
    ByVal RevType As Long, _  
    ByVal Thickness1 As Double, _  
    ByVal Thickness2 As Double, _  
    ByVal ReverseThinDir As Long, _  
    ByVal Merge As Boolean _  
)
```

SOLIDWORKS Type Library

FeatureRevolveThinCut Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureRevolveThinCut( _  
    ByVal Angle As Double, _  
    ByVal ReverseDir As Boolean, _  
    ByVal Angle2 As Double, _  
    ByVal RevType As Long, _  
    ByVal Thickness1 As Double, _  
    ByVal Thickness2 As Double, _  
    ByVal ReverseThinDir As Long _  
)
```

SOLIDWORKS Type Library

FeatureSketchEditPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FeatureSketchEditPreNotify( _  
    ByVal EditFeature As Object, _  
    ByVal featureSketch As Object _  
)
```

SOLIDWORKS Type Library

FeatureStock Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureStock()
```

SOLIDWORKS Type Library

FeatureXpert Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub FeatureXpert()
```

SOLIDWORKS Type Library

FileDropPostNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FileDropPostNotify( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

FileDropPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FileDropPreNotify( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

FileReloadCancelNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FileReloadCancelNotify( _  
    ByVal ErrorCode As Long _  
)
```

SOLIDWORKS Type Library

FileReloadNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FileReloadNotify()
```

SOLIDWORKS Type Library

FileReloadPreNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

Public Event FileReloadPreNotify()

SOLIDWORKS Type Library

FileSaveAsNotify2 Event (PartDoc)



 Syntax

Visual Basic for Applications (VBA)

```
Public Event FileSaveAsNotify2( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

FileSaveAsNotify Event (PartDoc)



 Syntax

Visual Basic for Applications (VBA)

```
Public Event FileSaveAsNotify( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

FileSaveNotify Event (PartDoc)



 Syntax

Visual Basic for Applications (VBA)

```
Public Event FileSaveNotify( _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

FileSavePostCancelNotify Event (PartDoc)



 Syntax

Visual Basic for Applications (VBA)

```
Public Event FileSavePostCancelNotify()
```

SOLIDWORKS Type Library

FileSavePostNotify Event (PartDoc)



 Syntax

Visual Basic for Applications (VBA)

```
Public Event FileSavePostNotify( _  
    ByVal saveType As Long, _  
    ByVal FileName As String _  
)
```

SOLIDWORKS Type Library

FirstFeature Method (PartDoc)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function FirstFeature() As Object
```

SOLIDWORKS Type Library

FlipLoopNotify Event (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Event FlipLoopNotify( _  
    ByVal TheLoop As Object, _  
    ByVal TheEdge As Object _  
)
```

SOLIDWORKS Type Library

ForceRebuild Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ForceRebuild()
```

SOLIDWORKS Type Library

GetBodies Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBodies( _  
    ByVal BodyType As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetBodies2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetBodies2( _  
    ByVal BodyType As Long, _  
    ByVal BVisibleOnly As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetCorresponding Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCorresponding( _  
    ByVal InputObject As Object _  
) As Object
```

SOLIDWORKS Type Library

GetCorrespondingEntity Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetCorrespondingEntity( _  
    ByVal Entity As Object _  
) As Object
```

SOLIDWORKS Type Library

GetEntityByName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEntityByName( _  
    ByVal Name As String, _  
    ByVal EntityType As Long _  
) As Object
```

SOLIDWORKS Type Library

GetEntityName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEntityName( _  
    ByVal Entity As Object _  
) As String
```

SOLIDWORKS Type Library

GetExplodedViewConfigurationName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetExplodedViewConfigurationName( _  
    ByVal ExplodedViewName As String _  
) As String
```

SOLIDWORKS Type Library

GetExplodedViewCount Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetExplodedViewCount( _  
    ByVal ConfigurationName As String _  
) As Long
```

SOLIDWORKS Type Library

GetExplodedViewNames Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetExplodedViewNames( _  
    ByVal ConfigurationName As String _  
) As Variant
```

SOLIDWORKS Type Library

GetMateReferenceEntity Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMateReferenceEntity() As Object
```

SOLIDWORKS Type Library

GetMaterialPropertyName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetMaterialPropertyName( _  
    ByRef Database As String _
```

```
) As String
```

SOLIDWORKS Type Library

GetMaterialPropertyName2 Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function GetMaterialPropertyName2( _  
    ByVal ConfigName As String, _  
    ByRef Database As String _  
) As String
```

SOLIDWORKS Type Library

GetMaterialVisualProperties Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function GetMaterialVisualProperties() As MaterialVisualPropertiesData
```

SOLIDWORKS Type Library

GetNamedEntities Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function GetNamedEntities() As Variant
```

SOLIDWORKS Type Library

GetNamedEntitiesCount Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function GetNamedEntitiesCount() As Long
```

SOLIDWORKS Type Library

GetPartBox Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function GetPartBox( _  
    ByVal NoConversion As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetProcessedBody Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function GetProcessedBody() As Object
```

SOLIDWORKS Type Library

GetProcessedBodyWithSelFace Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function GetProcessedBodyWithSelFace() As Object
```

SOLIDWORKS Type Library

GetPropertyExtension Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPropertyExtension( _  
    ByVal ID As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetRelatedBodies Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRelatedBodies() As Variant
```

SOLIDWORKS Type Library

GetRelatedSectionedBodies Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRelatedSectionedBodies( _  
    ByVal ViewIn As Object _  
) As Variant
```

SOLIDWORKS Type Library

GetSectionedBody Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSectionedBody( _  
    ByVal ViewIn As Object _  
) As Object
```

SOLIDWORKS Type Library

GetTessNorms Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessNorms() As Variant
```

SOLIDWORKS Type Library

GetTessTriangleCount Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTriangleCount() As Long
```

SOLIDWORKS Type Library

GetTessTriangles Method (PartDoc)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTriangles( _  
    ByVal NoConversion As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetTessTriStripEdges Method (PartDoc)



Syntax

```
Public Function GetTessTriStripEdges() As Variant
```

SOLIDWORKS Type Library

GetTessTriStripNorms Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTriStripNorms() As Variant
```

SOLIDWORKS Type Library

GetTessTriStrips Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTriStrips( _  
    ByVal NoConversion As Boolean _  
) As Variant
```

SOLIDWORKS Type Library

GetTessTriStripSize Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTriStripSize() As Long
```

SOLIDWORKS Type Library

GetTessTriStripTextures Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTessTriStripTextures() As Variant
```

SOLIDWORKS Type Library

IBodyObject Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IBodyObject() As Body
```

SOLIDWORKS Type Library

IBodyObject2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IBodyObject2() As Body2
```

SOLIDWORKS Type Library

ICreateFeatureFromBody Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateFeatureFromBody( _  
    ByVal Body As Body _  
) As Feature
```

SOLIDWORKS Type Library

ICreateFeatureFromBody2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateFeatureFromBody2( _  
    ByVal Body As Body, _  
    ByVal MakeRefSurface As Boolean _  
    ) As Feature
```

SOLIDWORKS Type Library

ICreateFeatureFromBody3 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateFeatureFromBody3( _  
    ByVal Body As Body, _  
    ByVal MakeRefSurface As Boolean, _  
    ByVal Options As Long _  
    ) As Feature
```

SOLIDWORKS Type Library

ICreateFeatureFromBody4 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateFeatureFromBody4( _  
    ByVal Body As Body2, _  
    ByVal MakeRefSurface As Boolean, _  
    ByVal Options As Long _  
    ) As Feature
```

SOLIDWORKS Type Library

ICreateNewBody Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateNewBody() As Body
```

SOLIDWORKS Type Library

ICreateNewBody2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateNewBody2() As Body2
```

SOLIDWORKS Type Library

ICreateSurfaceFeatureFromBody Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateSurfaceFeatureFromBody() As Feature
```

SOLIDWORKS Type Library

ICreateSurfaceFeatureFromBodyCount Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateSurfaceFeatureFromBodyCount( _  
    ByVal Body As Body, _
```

```
    ByVal Options As Long _  
  ) As Long
```

SOLIDWORKS Type Library

ICreateSurfaceFeatureFromBodyCount2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function ICreateSurfaceFeatureFromBodyCount2( _  
    ByVal Body As Body2, _  
    ByVal Options As Long _  
  ) As Long
```

SOLIDWORKS Type Library

IDeleteEntityName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IDeleteEntityName( _  
    ByVal Entity As Entity _  
  ) As Boolean
```

SOLIDWORKS Type Library

IExportToDWG Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IExportToDWG( _  
    ByVal FilePath As String, _  
    ByVal ModelName As String, _  
    ByVal Action As Long, _  
    ByVal ExportToSingleFile As Boolean, _  
    ByRef Alignment As Double, _  
    ByVal IsXDirFlipped As Boolean, _  
    ByVal IsYDirFlipped As Boolean, _  
    ByVal SheetMetalOptions As Long, _  
    ByVal ViewsCount As Long, _  
    ByRef Views As String _  
  ) As Boolean
```

SOLIDWORKS Type Library

IExportToDWG2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IExportToDWG2( _  
    ByVal FilePath As String, _  
    ByVal ModelName As String, _  
    ByVal Action As Long, _  
    ByVal ExportToSingleFile As Boolean, _  
    ByRef Alignment As Double, _  
    ByVal IsXDirFlipped As Boolean, _  
    ByVal IsYDirFlipped As Boolean, _  
    ByVal SheetMetalOptions As Long, _  
    ByVal ViewsCount As Long, _  
    ByRef Views As String _  
  ) As Boolean
```

SOLIDWORKS Type Library

IFeatureById Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IFeatureById( _  
    ByVal ID As Long _  
) As Feature
```

SOLIDWORKS Type Library

IFeatureByName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IFeatureByName( _  
    ByVal Name As String _  
) As Feature
```

SOLIDWORKS Type Library

IFirstFeature Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IFirstFeature() As Feature
```

SOLIDWORKS Type Library

IGetCorrespondingEntity Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetCorrespondingEntity( _  
    ByVal PEntity As Entity _  
) As Entity
```

SOLIDWORKS Type Library

IGetEntityByName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEntityByName( _  
    ByVal Name As String, _  
    ByVal EntityType As Long _  
) As Entity
```

SOLIDWORKS Type Library

IGetEntityName Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEntityName( _  
    ByVal Entity As Entity _  
) As String
```

SOLIDWORKS Type Library

IGetNamedEntities Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNamedEntities( _  
    ByVal Count As Long _  
) As Entity
```

SOLIDWORKS Type Library

IGetPartBox Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPartBox( _  
    ByVal NoConversion As Boolean _  
    ) As Double
```

SOLIDWORKS Type Library

IGetProcessedBody Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetProcessedBody() As Body
```

SOLIDWORKS Type Library

IGetProcessedBody2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetProcessedBody2() As Body2
```

SOLIDWORKS Type Library

IGetProcessedBodyWithSelFace Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetProcessedBodyWithSelFace() As Body
```

SOLIDWORKS Type Library

IGetProcessedBodyWithSelFace2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetProcessedBodyWithSelFace2() As Body2
```

SOLIDWORKS Type Library

IGetSectionedBody Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSectionedBody( _  
    ByVal ViewIn As ModelView _  
    ) As Body
```

SOLIDWORKS Type Library

IGetSectionedBody2 Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetSectionedBody2( _  
    ByVal ViewIn As ModelView _  
    ) As Body2
```

SOLIDWORKS Type Library

IGetTessNorms Method (PartDoc)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTessNorms() As Single
```

SOLIDWORKS Type Library

IGetTessTriangles Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriangles( _  
    ByVal NoConversion As Boolean _  
) As Single
```

SOLIDWORKS Type Library

IGetTessTriStripEdges Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriStripEdges() As Long
```

SOLIDWORKS Type Library

IGetTessTriStripEdgeSize Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriStripEdgeSize() As Long
```

SOLIDWORKS Type Library

IGetTessTriStripNorms Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriStripNorms() As Single
```

SOLIDWORKS Type Library

IGetTessTriStrips Method (PartDoc)



Visual Basic for Applications (VBA)

```
Public Function IGetTessTriStrips( _  
    ByVal NoConversion As Boolean _  
) As Single
```