

SOLIDWORKS API (VB6 COM) — Reference (78/102): RenderMaterial-RevolveFeatureData

SOLIDWORKS API Documentation (converted from CHM)

RenderMaterial (Type)

SOLIDWORKS Type Library
RenderMaterial Object

Object Model

RenderMaterial

SOLIDWORKS Type Library
RenderMaterial Object Members

Public Methods

	AddEntity
	GetCenterPoint
	GetCenterPoint2
	GetDSPBRMaterial
	GetEntities
	GetEntitiesCount
	GetLinkedDisplayStates
	GetMaterialIds
	GetUDirection
	GetUDirection2
	GetVDirection
	GetVDirection2
	IGetEntities
	RemoveAllEntities
	SetCenterPoint
	SetCenterPoint2
	SetLinkedDisplayStates
	SetUDirection
	SetUDirection2
	SetVDirection
	SetVDirection2

Public Properties

	AboutAxis
	AccurateReflections
	AlongAxis
	Ambient
	AnisotropicBias
	AnisotropicCylinderDistance
	AnisotropicFloorHeight
	Brightness
	BumpAmplitude

 BumpBlend
 BumpDetail
 BumpMap
 BumpRadius
 BumpRoughHigh
 BumpRoughLow
 BumpScale
 BumpSharpness
 BumpStrength
 BumpTextureFilename
 BumpUseMappingScale
 CausticsCast
 CausticsReceive
 ColorForm
 CustomHoleMeshFile
 DensityOfHoles
 Diffuse
 DimpleSize
 Direction1RotationAngle
 Direction2RotationAngle
 DoubleSided
 Emission
 FaceWidth
 FileName
 FillHeight
 FitWidth
 FixedAspectRatio
 GlobalIlluminationCast
 GlobalIlluminationReceive
 Glossy
 HasDSPBRProperties
 Height
 HeightMirror
 HoleMeshSize
 IgnoreMissingFile
 IlluminationShaderType
 IndexOfRefraction
 KnurlAngle
 KnurlHeightCap
 LinkToFile
 MappingType
 MaterialID
 MetallicAmplitude

 MetallicFlakeMaterial
 MetallicMix
 MetallicRoughness
 MetallicScale
 NSamples
 ObjectAreaLight
 OffsetLatitude
 OffsetLongitude
 PatternScale
 PrimaryColor
 ProjectionReference
 Reflectivity
 RotationAngle
 Roughness
 RoundSharpEdges
 SecondaryColor
 Specular
 SpecularColor
 SurfaceFinishFile
 SurfaceFinishFileNormalMap
 SurfaceFinishShaderType
 TertiaryColor
 TextureFilename
 ToonShaderTextureFilename
 Translucency
 Transparency
 TransparencyMappingShaderType
 Width
 WidthMinor
 XPosition
 YPosition

SOLIDWORKS Type Library

AboutAxis Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

Public Property AboutAxis As Double

SOLIDWORKS Type Library

AccurateReflections Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

Public Property AccurateReflections As Boolean

AddEntity Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddEntity( _  
    ByVal Entity As Object _  
    ) As Boolean
```

SOLIDWORKS Type Library

AlongAxis Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AlongAxis As Double
```

SOLIDWORKS Type Library

Ambient Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Ambient As Double
```

SOLIDWORKS Type Library

AnisotropicBias Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AnisotropicBias As Double
```

SOLIDWORKS Type Library

AnisotropicCylinderDistance Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AnisotropicCylinderDistance As Double
```

SOLIDWORKS Type Library

AnisotropicFloorHeight Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property AnisotropicFloorHeight As Double
```

SOLIDWORKS Type Library

Brightness Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Brightness As Double
```

SOLIDWORKS Type Library

BumpAmplitude Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property BumpAmplitude As Double
```

SOLIDWORKS Type Library

BumpBlend Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpBlend As Double
```

SOLIDWORKS Type Library

BumpDetail Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpDetail As Long
```

SOLIDWORKS Type Library

BumpMap Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpMap As Long
```

SOLIDWORKS Type Library

BumpRadius Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpRadius As Double
```

SOLIDWORKS Type Library

BumpRoughHigh Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpRoughHigh As Double
```

SOLIDWORKS Type Library

BumpRoughLow Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpRoughLow As Double
```

SOLIDWORKS Type Library

BumpScale Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpScale As Double
```

SOLIDWORKS Type Library

BumpSharpness Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpSharpness As Double
```

SOLIDWORKS Type Library

BumpStrength Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpStrength As Double
```

SOLIDWORKS Type Library

BumpTextureFilename Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpTextureFilename As String
```

SOLIDWORKS Type Library

BumpUseMappingScale Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property BumpUseMappingScale As Boolean
```

SOLIDWORKS Type Library

CausticsCast Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property CausticsCast As Boolean
```

SOLIDWORKS Type Library

CausticsReceive Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property CausticsReceive As Boolean
```

SOLIDWORKS Type Library

ColorForm Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property ColorForm As Long
```

SOLIDWORKS Type Library

CustomHoleMeshFile Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property CustomHoleMeshFile As String
```

SOLIDWORKS Type Library

DensityOfHoles Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property DensityOfHoles As Double
```

SOLIDWORKS Type Library

Diffuse Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property Diffuse As Double
```

SOLIDWORKS Type Library

DimpleSize Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property DimpleSize As Double
```

SOLIDWORKS Type Library

Direction1RotationAngle Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property Direction1RotationAngle As Double
```

SOLIDWORKS Type Library

Direction2RotationAngle Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property Direction2RotationAngle As Double
```

SOLIDWORKS Type Library

DoubleSided Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property DoubleSided As Boolean
```

SOLIDWORKS Type Library

Emission Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property Emission As Double
```

SOLIDWORKS Type Library

FaceWidth Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property FaceWidth As Double
```

SOLIDWORKS Type Library

FileName Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property FileName As String
```

SOLIDWORKS Type Library

FitHeight Property (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Property FitHeight As Boolean
```

SOLIDWORKS Type Library

FitWidth Property (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Property FitWidth As Boolean
```

SOLIDWORKS Type Library

FixedAspectRatio Property (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Property FixedAspectRatio As Boolean
```

SOLIDWORKS Type Library

GetCenterPoint Method (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetCenterPoint( _  
    ByRef CenterPt As Double _  
)
```

SOLIDWORKS Type Library

GetCenterPoint2 Method (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetCenterPoint2( _  
    ByRef CenterPt_X As Double, _  
    ByRef CenterPt_Y As Double, _  
    ByRef CenterPt_Z As Double _  
)
```

SOLIDWORKS Type Library

GetDSPBRMaterial Method (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetDSPBRMaterial() As Object
```

SOLIDWORKS Type Library

GetEntities Method (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEntities() As Variant
```

SOLIDWORKS Type Library

GetEntitiesCount Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetEntitiesCount() As Long
```

SOLIDWORKS Type Library

GetLinkedDisplayStates Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetLinkedDisplayStates() As Variant
```

SOLIDWORKS Type Library

GetMaterialIds Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetMaterialIds( _  
    ByRef PWMaterialId1 As Long, _  
    ByRef PWMaterialId2 As Long _  
)
```

SOLIDWORKS Type Library

GetUDirection Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetUDirection( _  
    ByRef UDir As Double _  
)
```

SOLIDWORKS Type Library

GetUDirection2 Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetUDirection2( _  
    ByRef UDir_X As Double, _  
    ByRef UDir_Y As Double, _  
    ByRef UDir_Z As Double _  
)
```

SOLIDWORKS Type Library

GetVDirection Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetVDirection( _  
    ByRef VDir As Double _  
)
```

SOLIDWORKS Type Library

GetVDirection2 Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub GetVDirection2( _  
    ByRef VDir_X As Double, _  
    ByRef VDir_Y As Double, _
```

```
ByRef VDir_Z As Double _  
)
```

SOLIDWORKS Type Library

GlobalIlluminationCast Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property GlobalIlluminationCast As Boolean
```

SOLIDWORKS Type Library

GlobalIlluminationReceive Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property GlobalIlluminationReceive As Boolean
```

SOLIDWORKS Type Library

Glossy Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property Glossy As Double
```

SOLIDWORKS Type Library

HasDSPBRProperties Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property HasDSPBRProperties As Boolean
```

SOLIDWORKS Type Library

Height Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property Height As Double
```

SOLIDWORKS Type Library

HeightMirror Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property HeightMirror As Boolean
```

SOLIDWORKS Type Library

HoleMeshSize Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property HoleMeshSize As Double
```

SOLIDWORKS Type Library

IGetEntities Method (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetEntities( _  
    ByVal Count As Long _  
    ) As Object
```

SOLIDWORKS Type Library

IgnoreMissingFile Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property IgnoreMissingFile As Boolean
```

SOLIDWORKS Type Library

IlluminationShaderType Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property IlluminationShaderType As Long
```

SOLIDWORKS Type Library

IndexOfRefraction Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property IndexOfRefraction As Double
```

SOLIDWORKS Type Library

KnurlAngle Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property KnurlAngle As Double
```

SOLIDWORKS Type Library

KnurlHeightCap Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property KnurlHeightCap As Double
```

SOLIDWORKS Type Library

LinkToFile Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property LinkToFile As Boolean
```

SOLIDWORKS Type Library

MappingType Property (RenderMaterial)

 Syntax

Visual Basic for Applications (VBA)

```
Public Property MappingType As Long
```

SOLIDWORKS Type Library

MaterialID Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property MaterialID As Long

SOLIDWORKS Type Library

MetallicAmplitude Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property MetallicAmplitude As Double

SOLIDWORKS Type Library

MetallicFlakeMaterial Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property MetallicFlakeMaterial As Long

SOLIDWORKS Type Library

MetallicMix Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property MetallicMix As Double

SOLIDWORKS Type Library

MetallicRoughness Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property MetallicRoughness As Double

SOLIDWORKS Type Library

MetallicScale Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property MetallicScale As Double

SOLIDWORKS Type Library

NSamples Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property NSamples As Double

SOLIDWORKS Type Library

ObjectAreaLight Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property ObjectAreaLight As Long

SOLIDWORKS Type Library

OffsetLatitude Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property OffsetLatitude As Double
```

SOLIDWORKS Type Library

OffsetLongitude Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property OffsetLongitude As Double
```

SOLIDWORKS Type Library

PatternScale Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property PatternScale As Double
```

SOLIDWORKS Type Library

PrimaryColor Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property PrimaryColor As Long
```

SOLIDWORKS Type Library

ProjectionReference Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property ProjectionReference As Long
```

SOLIDWORKS Type Library

Reflectivity Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property Reflectivity As Double
```

SOLIDWORKS Type Library

RemoveAllEntities Method (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Sub RemoveAllEntities()
```

SOLIDWORKS Type Library

RotationAngle Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property RotationAngle As Double
```

SOLIDWORKS Type Library

Roughness Property (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Property Roughness As Double
```

SOLIDWORKS Type Library

RoundSharpEdges Property (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Property RoundSharpEdges As Double
```

SOLIDWORKS Type Library

SecondaryColor Property (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Property SecondaryColor As Long
```

SOLIDWORKS Type Library

SetCenterPoint Method (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetCenterPoint( _  
    ByRef CenterPt As Double _  
)
```

SOLIDWORKS Type Library

SetCenterPoint2 Method (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetCenterPoint2( _  
    ByVal CenterPt_X As Double, _  
    ByVal CenterPt_Y As Double, _  
    ByVal CenterPt_Z As Double _  
)
```

SOLIDWORKS Type Library

SetLinkedDisplayStates Method (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Function SetLinkedDisplayStates( _  
    ByVal DisplayStateOption As Long, _  
    ByVal DisplayStateNames As Variant _  
) As Boolean
```

SOLIDWORKS Type Library

SetUDirection Method (RenderMaterial)



Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetUDirection( _  
    ByRef UDir As Double _  
)
```

SOLIDWORKS Type Library

SetUDirection2 Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetUDirection2( _  
    ByVal UDir_X As Double, _  
    ByVal UDir_Y As Double, _  
    ByVal UDir_Z As Double _  
)
```

SOLIDWORKS Type Library

SetVDirection Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetVDirection( _  
    ByRef VDir As Double _  
)
```

SOLIDWORKS Type Library

SetVDirection2 Method (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub SetVDirection2( _  
    ByVal VDir_X As Double, _  
    ByVal VDir_Y As Double, _  
    ByVal VDir_Z As Double _  
)
```

SOLIDWORKS Type Library

Specular Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property Specular As Double
```

SOLIDWORKS Type Library

SpecularColor Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SpecularColor As Long
```

SOLIDWORKS Type Library

SurfaceFinishFile Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SurfaceFinishFile As String
```

SOLIDWORKS Type Library

SurfaceFinishFileNormalMap Property (RenderMaterial)

Syntax

Visual Basic for Applications (VBA)

```
Public Property SurfaceFinishFileNormalMap As Boolean
```

SOLIDWORKS Type Library

SurfaceFinishShaderType Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property SurfaceFinishShaderType As Long
```

SOLIDWORKS Type Library

TertiaryColor Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property TertiaryColor As Long
```

SOLIDWORKS Type Library

TextureFilename Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property TextureFilename As String
```

SOLIDWORKS Type Library

ToonShaderTextureFilename Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property ToonShaderTextureFilename As String
```

SOLIDWORKS Type Library

Translucency Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property Translucency As Double
```

SOLIDWORKS Type Library

Transparency Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property Transparency As Double
```

SOLIDWORKS Type Library

TransparencyMappingShaderType Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property TransparencyMappingShaderType As Long
```

SOLIDWORKS Type Library

Width Property (RenderMaterial)



Visual Basic for Applications (VBA)

```
Public Property Width As Double
```

WidthMirror Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property WidthMirror As Boolean

XPosition Property (RenderMaterial)



Visual Basic for Applications (VBA)

Public Property XPosition As Double

YPosition Property (RenderMaterial)




Visual Basic for Applications (VBA)

Public Property YPosition As Double

ReplaceFaceFeatureData (Type)

SOLIDWORKS Type Library
ReplaceFaceFeatureData Object

Object Model



SOLIDWORKS Type Library
ReplaceFaceFeatureData Object Members

Public Methods

	AccessSelections
	GetFacesForReplacementCount
	GetReplacementSurfacesCount
	IAccessSelections
	IGetFacesForReplacement
	IGetReplacementSurfaces
	ISetFacesForReplacement
	ISetReplacementSurfaces
	ReleaseSelectionAccess

Public Properties

	FacesForReplacement
	ReplacementSurfaces

SOLIDWORKS Type Library
AccessSelections Method (ReplaceFaceFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Function AccessSelections( _
    ByVal TopDoc As Object, _
    ByVal Component As Object _
) As Boolean
```

SOLIDWORKS Type Library
FacesForReplacement Property (ReplaceFaceFeatureData)

Syntax

```
Visual Basic for Applications (VBA)

Public Property FacesForReplacement As Variant
```

SOLIDWORKS Type Library
GetFacesForReplacementCount Method (ReplaceFaceFeatureData)

Syntax

```
Visual Basic for Applications (VBA)
```

```
Public Function GetFacesForReplacementCount() As Long
```

SOLIDWORKS Type Library

GetReplacementSurfacesCount Method (ReplaceFaceFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetReplacementSurfacesCount() As Long
```

SOLIDWORKS Type Library

IAccessSelections Method (ReplaceFaceFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As Boolean
```

SOLIDWORKS Type Library

IGetFacesForReplacement Method (ReplaceFaceFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetFacesForReplacement( _  
    ByVal Count As Long _  
) As Face2
```

SOLIDWORKS Type Library

IGetReplacementSurfaces Method (ReplaceFaceFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetReplacementSurfaces( _  
    ByVal Count As Long _  
) As Feature
```

SOLIDWORKS Type Library

ISetFacesForReplacement Method (ReplaceFaceFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetFacesForReplacement( _  
    ByVal Count As Long, _  
    ByVal SurfDisp As Face2 _  
)
```

SOLIDWORKS Type Library

ISetReplacementSurfaces Method (ReplaceFaceFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Sub ISetReplacementSurfaces( _  
    ByVal Count As Long, _  
    ByVal SurfDisp As Feature _  
)
```

SOLIDWORKS Type Library

ReleaseSelectionAccess Method (ReplaceFaceFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub ReleaseSelectionAccess()
```

SOLIDWORKS Type Library

ReplacementSurfaces Property (ReplaceFaceFeatureData)




Visual Basic for Applications (VBA)

```
Public Property ReplacementSurfaces As Variant
```

RevisionCloud (Type)

SOLIDWORKS Type Library
RevisionCloud Object

Object Model



SOLIDWORKS Type Library
RevisionCloud Object Members



Public Methods

	Finalize
	GetAnnotation
	GetNext
	GetPathPointAtIndex
	GetPathPointCount
	IGetAnnotation
	IGetNext
	IGetPathPointAtIndex
	SetPathPointAtIndex

Public Properties

	Angle
	ArcRadius
	Shape

SOLIDWORKS Type Library
Angle Property (RevisionCloud)

Syntax

Visual Basic for Applications (VBA)
Public Property Angle As Double

SOLIDWORKS Type Library
ArcRadius Property (RevisionCloud)

Syntax

Visual Basic for Applications (VBA)
Public Property ArcRadius As Double

SOLIDWORKS Type Library
Finalize Method (RevisionCloud)

Syntax

Visual Basic for Applications (VBA)
Public Function Finalize() As Boolean

SOLIDWORKS Type Library

GetAnnotation Method (RevisionCloud)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAnnotation() As Object
```

SOLIDWORKS Type Library

GetNext Method (RevisionCloud)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetNext() As Object
```

SOLIDWORKS Type Library

GetPathPointAtIndex Method (RevisionCloud)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPathPointAtIndex( _  
    ByVal Index As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetPathPointCount Method (RevisionCloud)



Syntax

Visual Basic for Applications (VBA)

```
Public Function GetPathPointCount() As Long
```

SOLIDWORKS Type Library

IGetAnnotation Method (RevisionCloud)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAnnotation() As Annotation
```

SOLIDWORKS Type Library

IGetNext Method (RevisionCloud)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetNext() As RevisionCloud
```

SOLIDWORKS Type Library

IGetPathPointAtIndex Method (RevisionCloud)



Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetPathPointAtIndex( _  
    ByVal Index As Long _  
) As Double
```

SOLIDWORKS Type Library

SetPathPointAtIndex Method (RevisionCloud)



Syntax

```
Public Function SetPathPointAtIndex( _  
    ByVal Index As Long, _  
    ByVal X As Double, _  
    ByVal Y As Double, _  
    ByVal Z As Double _  
) As Boolean
```



```
Public Property Shape As Long
```

RevisionTableAnnotation (Type)

SOLIDWORKS Type Library

RevisionTableAnnotation Object

Object Model

RevisionTableAnnotation

GetSheet (Sheet)

IGetRevisionSymbols (Note)

RevisionTableFeature

SOLIDWORKS Type Library

RevisionTableAnnotation Object Members

Public Methods

	AddRevision
	DeleteRevision
	GetAllCustomProperties
	GetAllCustomPropertiesCount
	GetColumnCustomProperty
	GetIdForRowIndex
	GetRevisionId
	GetRevisionSymbolCount
	GetRevisionSymbols
	GetRowIndexForId
	GetSheet
	IGetAllCustomProperties
	IGetRevisionSymbols
	SetColumnCustomProperty

Public Properties

	CurrentRevision
	RevisionTableFeature

SOLIDWORKS Type Library

AddRevision Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function AddRevision( _  
    ByVal Revision As String _  
    ) As Long
```

SOLIDWORKS Type Library

CurrentRevision Property (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

Public Property CurrentRevision As String

SOLIDWORKS Type Library

DeleteRevision Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function DeleteRevision( _  
    ByVal RevisionId As Long, _  
    ByVal DeleteSymbols As Boolean _  
    ) As Boolean
```

SOLIDWORKS Type Library

GetAllCustomProperties Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAllCustomProperties() As Variant
```

SOLIDWORKS Type Library

GetAllCustomPropertiesCount Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetAllCustomPropertiesCount() As Long
```

SOLIDWORKS Type Library

GetColumnCustomProperty Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetColumnCustomProperty( _  
    ByVal Index As Long _  
    ) As String
```

SOLIDWORKS Type Library

GetIdForRowIndex Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetIdForRowIndex( _  
    ByVal RowIndex As Long _  
    ) As Long
```

SOLIDWORKS Type Library

GetRevisionForId Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRevisionForId( _  
    ByVal RevisionId As Long _  
    ) As String
```

SOLIDWORKS Type Library

GetRevisionSymbolCount Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRevisionSymbolCount( _  
    ByVal RevisionId As Long _  
) As Long
```

SOLIDWORKS Type Library

GetRevisionSymbols Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRevisionSymbols( _  
    ByVal RevisionId As Long _  
) As Variant
```

SOLIDWORKS Type Library

GetRowNumberForId Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetRowNumberForId( _  
    ByVal RevisionId As Long _  
) As Long
```

SOLIDWORKS Type Library

GetSheet Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetSheet() As Sheet
```

SOLIDWORKS Type Library

IGetAllCustomProperties Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetAllCustomProperties( _  
    ByVal Count As Long _  
) As String
```

SOLIDWORKS Type Library

IGetRevisionSymbols Method (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetRevisionSymbols( _  
    ByVal RevisionId As Long, _  
    ByVal Count As Long _  
) As Note
```

SOLIDWORKS Type Library

RevisionTableFeature Property (RevisionTableAnnotation)

Syntax

Visual Basic for Applications (VBA)

```
Public Property RevisionTableFeature As RevisionTableFeature
```

SOLIDWORKS Type Library

SetColumnCustomProperty Method (RevisionTableAnnotation)

```
Public Function SetColumnCustomProperty( _  
    ByVal Index As Long, _  
    ByVal CustomProp As String _  
    ) As Boolean
```

RevisionTableFeature (Type)

SOLIDWORKS Type Library

RevisionTableFeature Object

Object Model

RevisionTableFeature

GetFeature (Feature)

IGetTableAnnotations (RevisionTableAnnotation)

SOLIDWORKS Type Library

RevisionTableFeature Object Members

Public Methods

 [GetFeature](#)

 [GetTableAnnotationCount](#)

 [GetTableAnnotations](#)

 [IGetTableAnnotations](#)

SOLIDWORKS Type Library

GetFeature Method (RevisionTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetFeature() As Feature
```

SOLIDWORKS Type Library

GetTableAnnotationCount Method (RevisionTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotationCount() As Long
```

SOLIDWORKS Type Library

GetTableAnnotations Method (RevisionTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function GetTableAnnotations() As Variant
```

SOLIDWORKS Type Library

IGetTableAnnotations Method (RevisionTableFeature)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IGetTableAnnotations( _  
    ByVal Count As Long _  
) As RevisionTableAnnotation
```

RevolveFeatureData (Type)

SOLIDWORKS Type Library
RevolveFeatureData Object

Object Model

RevolveFeatureData

SOLIDWORKS Type Library
RevolveFeatureData Object Members

Public Methods

	GetRevolutionAngle
	GetWallThickness
	IsBossFeature
	IsThinFeature
	SetRevolutionAngle
	SetWallThickness

Public Properties

	ReverseDirection
	Type

SOLIDWORKS Type Library
GetRevolutionAngle Method (RevolveFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetRevolutionAngle(_ ByVal <i>Forward</i> As Boolean _) As Double</pre>

SOLIDWORKS Type Library
GetWallThickness Method (RevolveFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function GetWallThickness(_ ByVal <i>Forward</i> As Boolean _) As Double</pre>

SOLIDWORKS Type Library
IsBossFeature Method (RevolveFeatureData)

Syntax

Visual Basic for Applications (VBA)
<pre>Public Function IsBossFeature() As Boolean</pre>

SOLIDWORKS Type Library
IsThinFeature Method (RevolveFeatureData)

Syntax

Visual Basic for Applications (VBA)

```
Public Function IsThinFeature() As Boolean
```

SOLIDWORKS Type Library

ReverseDirection Property (RevolveFeatureData)



Visual Basic for Applications (VBA)

```
Public Property ReverseDirection As Boolean
```

SOLIDWORKS Type Library

SetRevolutionAngle Method (RevolveFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub SetRevolutionAngle( _  
    ByVal Forward As Boolean, _  
    ByVal Angle As Double _  
)
```

SOLIDWORKS Type Library

SetWallThickness Method (RevolveFeatureData)



Visual Basic for Applications (VBA)

```
Public Sub SetWallThickness( _  
    ByVal Forward As Boolean, _  
    ByVal WallThickness As Double _  
)
```

SOLIDWORKS Type Library

Type Property (RevolveFeatureData)



Visual Basic for Applications (VBA)

```
Public Property Type As Integer
```